

Programmable Controller

MELSEC iQ-R
series

MELSEC iQ-R
Motion Module
User's Manual (Application)

-RD78G4
-RD78G8
-RD78G16
-RD78G32
-RD78G64
-RD78GHV
-RD78GHW

SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the MELSEC iQ-R Module Configuration Manual.

In this manual, the safety precautions are classified into two levels: "⚠ WARNING" and "⚠ CAUTION".

 WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
 CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Design Precautions]

WARNING

- Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Emergency stop circuits, protection circuits, and protective interlock circuits for conflicting operations (such as forward/reverse rotations or upper/lower limit positioning) must be configured external to the programmable controller.
 - (2) When the programmable controller detects an abnormal condition, it stops the operation and all outputs are:
 - Turned off if the overcurrent or overvoltage protection of the power supply module is activated.
 - Held or turned off according to the parameter setting if the self-diagnostic function of the CPU module detects an error such as a watchdog timer error.
 - (3) All outputs may be turned on if an error occurs in a part, such as an I/O control part, where the CPU module cannot detect any error. To ensure safety operation in such a case, provide a safety mechanism or a fail-safe circuit external to the programmable controller. For a fail-safe circuit example, refer to the MELSEC iQ-R Module Configuration Manual.
 - (4) Outputs may remain on or off due to a failure of a component such as a relay and transistor in an output circuit. Configure an external circuit for monitoring output signals that could cause a serious accident.
- In an output circuit, when a load current exceeding the rated current or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
- Configure a circuit so that the programmable controller is turned on first and then the external power supply. If the external power supply is turned on first, an accident may occur due to an incorrect output or malfunction.
- When the programmable controller is turned off, configure a circuit so that the external power supply is turned off first and then the programmable controller. If the programmable controller is turned off first, an accident may occur due to an incorrect output or malfunction.

[Design Precautions]

WARNING

- For the operating status of each station after a communication failure, refer to manuals for the network used. For the manuals, please consult your local Mitsubishi representative. Incorrect output or malfunction due to a communication failure may result in an accident.
 - When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents. When a Safety CPU is used, data cannot be modified while the Safety CPU is in SAFETY MODE.
 - Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
 - Do not write any data to the "system area" and "write-protect area" of the buffer memory in the module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system. For the "system area", "write-protect area", and the "use prohibited" signals, refer to the user's manual for the module used. For areas used for safety communications, they are protected from being written by users, and thus safety communications failure caused by data writing does not occur.
 - If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Incorrect output or malfunction due to a communication failure may result in an accident. When safety communications are used, an interlock by the safety station interlock function protects the system from an incorrect output or malfunction.
 - Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Machine homing is controlled by two kinds of data: a homing direction and a homing speed. Deceleration starts when the proximity dog signal turns on. If an incorrect homing direction is set, motion control may continue without deceleration. To prevent machine damage caused by this, configure an interlock circuit external to the programmable controller.
 - (2) When the module detects an error, the motion slows down and stops or the motion rapidly stops, depending on the stop group setting in parameter. Set the parameter to meet the specifications of a positioning control system. In addition, set the homing parameter and positioning data within the specified setting range.
 - (3) Outputs may remain on or off, or become undefined due to a failure of a component such as an insulation element and transistor in an output circuit, where the module cannot detect any error. In a system that the incorrect output could cause a serious accident, configure an external circuit for monitoring output signals.
 - If safety standards (ex., robot safety rules, etc.,) apply to the system using the module, drive unit and servo motor, make sure that the safety standards are satisfied.
 - Construct a safety circuit externally of the module or drive unit if the abnormal operation of the module or drive unit differs from the safety directive operation in the system.
-

[Design Precautions]

CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may result in malfunction due to electromagnetic interference. Keep a distance of 100mm or more between those cables.
 - During control of an inductive load such as a lamp, heater, or solenoid valve, a large current (approximately ten times greater than normal) may flow when the output is turned from off to on. Therefore, use a module that has a sufficient current rating.
 - After the CPU module is powered on or is reset, the time taken to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
 - Do not power off the programmable controller or reset the CPU module while the settings are being written. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so also may cause malfunction or failure of the module.
 - When changing the operating status of the CPU module from external devices (such as the remote RUN/STOP functions), select "Do Not Open by Program" for "Opening Method" of "Module Parameter". If "Open by Program" is selected, an execution of the remote STOP function causes the communication line to close. Consequently, the CPU module cannot reopen the line, and external devices cannot execute the remote RUN function.
-

[Security Precautions]

WARNING

- To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from external devices via the network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.
-

[Installation Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in electric shock or cause the module to fail or malfunction.
-

[Installation Precautions]

CAUTION

- Use the programmable controller in an environment that meets the general specifications in the MELSEC iQ-R Module Configuration Manual. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
 - To mount a module, place the concave part(s) located at the bottom onto the guide(s) of the base unit, and push in the module, until the hook(s) located at the top snaps into place. Incorrect interconnection may cause malfunction, failure, or drop of the module.
 - To mount a module with no module fixing hook, place the concave part(s) located at the bottom onto the guide(s) of the base unit, push in the module, and fix it with screw(s). Incorrect interconnection may cause malfunction, failure, or drop of the module.
 - Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction. For the specified torque range, refer to the MELSEC iQ-R Module Configuration Manual.
 - When using an extension cable, connect it to the extension cable connector of the base unit securely. Check the connection for looseness. Poor contact may cause malfunction.
 - When using an SD memory card, fully insert it into the SD memory card slot. Check that it is inserted completely. Poor contact may cause malfunction.
 - Securely insert an extended SRAM cassette or a battery-less option cassette into the cassette connector of the CPU module. After insertion, close the cassette cover and check that the cassette is inserted completely. Poor contact may cause malfunction.
 - Beware that the module could be very hot while power is on and immediately after power-off.
 - Do not directly touch any conductive parts and electronic components of the module, SD memory card, extended SRAM cassette, battery-less option cassette, or connector. Doing so can cause malfunction or failure of the module.
-

[Wiring Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or cause the module to fail or malfunction.
- After installation and wiring, attach a blank cover module (RG60) to each empty slot before powering on the system for operation. Also, attach an extension connector protective cover^{*1} to each unused extension cable connector as necessary. Directly touching any conductive parts of the connectors while power is on may result in electric shock.

^{*1} For details, please consult your local Mitsubishi Electric representative.

[Wiring Precautions]

CAUTION

- Individually ground the FG and LG terminals of the programmable controller with a ground resistance of 100 ohms or less. Failure to do so may result in electric shock or malfunction.
 - Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
 - Check the rated voltage and signal layout before wiring to the module, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
 - Connectors for external devices must be crimped or pressed with the tool specified by the manufacturer, or must be correctly soldered. Incomplete connections may cause short circuit, fire, or malfunction.
 - Securely connect the connector to the module. Poor contact may cause malfunction.
 - Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may result in malfunction due to noise. Keep a distance of 100mm or more between those cables.
 - Place the cables in a duct or clamp them. If not, dangling cables may swing or inadvertently be pulled, resulting in malfunction or damage to modules or cables.
In addition, the weight of the cables may put stress on modules in an environment of strong vibrations and shocks.
Do not clamp the extension cables with the jacket stripped. Doing so may change the characteristics of the cables, resulting in malfunction.
 - Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device.
 - Tighten the terminal screws or connector screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
 - When disconnecting the cable from the module, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. For the cable connected to the terminal block, loosen the terminal screw. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
 - Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
 - When a protective film is attached to the top of the module, remove it before system operation. If not, inadequate heat dissipation of the module may cause a fire, failure, or malfunction.
 - Programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring, refer to the MELSEC iQ-R Module Configuration Manual.
 - For Ethernet cables to be used in the system, select the ones that meet the specifications in the user's manual for the module used. If not, normal data transmission is not guaranteed.
-

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
 - Correctly connect the battery connector. Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire. Also, do not expose it to liquid or strong shock. Doing so will cause the battery to produce heat, explode, ignite, or leak, resulting in injury and fire.
 - Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws, connector screws, or module fixing screws. Failure to do so may result in electric shock.
-

[Startup and Maintenance Precautions]

CAUTION

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
 - Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
 - Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
 - Use any radio communication device such as a cellular phone or PHS (Personal Handy-phone System) 25cm or more away in all directions from the programmable controller. Failure to do so may cause malfunction.
 - Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction.
 - Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
 - After the first use of the product, do not perform each of the following operations more than 50 times (IEC 61131-2/JIS B 3502 compliant).
Exceeding the limit may cause malfunction.
 - Mounting/removing the module to/from the base unit
 - Inserting/removing the extended SRAM cassette or battery-less option cassette to/from the CPU module
 - Mounting/removing the terminal block to/from the module
 - Connecting/disconnecting the extension cable to/from the base unit
 - After the first use of the product, do not insert/remove the SD memory card to/from the CPU module more than 500 times. Exceeding the limit may cause malfunction.
 - Do not touch the metal terminals on the back side of the SD memory card. Doing so may cause malfunction or failure of the module.
 - Do not touch the integrated circuits on the circuit board of an extended SRAM cassette or a battery-less option cassette. Doing so may cause malfunction or failure of the module.
-

[Startup and Maintenance Precautions]

CAUTION

- Do not drop or apply shock to the battery to be installed in the module. Doing so may damage the battery, causing the battery fluid to leak inside the battery. If the battery is dropped or any shock is applied to it, dispose of it without using.
 - Startup and maintenance of a control panel must be performed by qualified maintenance personnel with knowledge of protection against electric shock. Lock the control panel so that only qualified maintenance personnel can operate it.
 - Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Wearing a grounded antistatic wrist strap is recommended. Failure to discharge the static electricity may cause the module to fail or malfunction.
 - After unpacking, eliminate static electricity from the module to prevent electrostatic discharge from affecting the module. If an electrostatically charged module comes in contact with a grounded metal object, a sudden electrostatic discharge of the module may cause failure.
For details on how to eliminate static electricity from the module, refer to the following.
Safety Precautions For Static Electricity Before Using MELSEC MX Controller MX-R Model and MELSEC iQ-R Series Models (FA-A-0368)
 - Use a clean and dry cloth to wipe off dirt on the module.
 - Before testing the operation, set a low speed value for the speed limit parameter so that the operation can be stopped immediately upon occurrence of a hazardous condition.
 - Confirm and adjust the program and each parameter before operation. Unpredictable movements may occur depending on the machine.
 - When using the absolute position system function, on starting up, and when the module or absolute position motor has been replaced, always perform a homing.
 - Before starting the operation, confirm the brake function.
 - Do not perform a megger test (insulation resistance measurement) during inspection.
 - After maintenance and inspections are completed, confirm that the position detection of the absolute position detection function is correct.
 - Lock the control panel and prevent access to those who are not certified to handle or install electric equipment.
-

[Operating Precautions]

CAUTION

- When changing data and operating status, and modifying program of the running programmable controller from an external device such as a personal computer connected to an intelligent function module, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
 - Do not power off the programmable controller or reset the CPU module while the setting values in the buffer memory are being written to the flash ROM in the module. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so can cause malfunction or failure of the module.
 - Note that when the reference axis speed is specified for interpolation operation, the speed of the partner axis (2nd, 3rd, or 4th axis) may exceed the speed limit value.
 - Do not go near the machine during test operations or during operations such as teaching. Doing so may lead to injuries.
-

[Computer Connection Precautions]

CAUTION

- When connecting a personal computer to a module having a USB interface, observe the following precautions as well as the instructions described in the manual for the personal computer used. Failure to do so may cause the module to fail.
 - (1) When the personal computer is AC-powered
 - When the personal computer has a 3-pin AC plug or an AC plug with a grounding wire, connect the plug to a grounding receptacle or ground the grounding wire. Ground the personal computer and the module with a ground resistance of 100 ohms or less.
 - When the personal computer has a 2-pin AC plug without a grounding wire, connect the computer to the module by following the procedure below. For power supplied to the personal computer and the module, using the same power source is recommended.
 1. Unplug the personal computer from the AC receptacle.
 2. Check that the personal computer is unplugged. Then, connect the personal computer to the module with a USB cable.
 3. Plug the personal computer into the AC receptacle.
 - (2) When the personal computer is battery-powered
 - The personal computer can be connected to the module without taking specific measures. For details, refer to the following.

Cautions When Using Mitsubishi Electric Controllers or GOTs Connected to a Personal Computer Via RS-232/USB Interface (FA-A-0298)

When the USB cable used is the GT09-C30USB-5P manufactured by Mitsubishi Electric, specific measures are not required to connect the AC-powered personal computer to the module. However, note that the signal ground (SG) is common for the module and its USB interface. Therefore, if an SG potential difference occurs between the module and the connected devices, it causes failures of the module and the connected devices.
-

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.
 - When disposing of batteries, separate them from other wastes according to the local regulations. For details on battery regulations in EU member states, refer to the MELSEC iQ-R Module Configuration Manual.
-

[Transportation Precautions]

CAUTION

- When transporting lithium batteries, follow the transportation regulations. For details on the regulated models, refer to the MELSEC iQ-R Module Configuration Manual.
 - The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.
-

INTRODUCTION

Thank you for purchasing the Mitsubishi Electric MELSEC iQ-R series programmable controllers.

This manual describes the functions and programming of the relevant products listed below. Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC iQ-R series programmable controller to handle the product correctly.

When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Please make sure that the end users read this manual.

Relevant products

RD78G4, RD78G8, RD78G16, RD78G32, RD78G64, RD78GHV, RD78GHW

Point

Symbols used in this manual are shown below.

- Underlined variables (AxisName, etc.): Variables defined by users

COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

Method of ensuring compliance

To ensure that Mitsubishi programmable controllers maintain EMC and Low Voltage Directives when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to one of the following manuals.

📖 MELSEC iQ-R Module Configuration Manual (SH-081262ENG)

📖 Safety Guidelines (IB-0800525)

The CE mark on the side of the programmable controller indicates compliance with EMC and Low Voltage Directives.

Additional measures

To ensure that this product maintains EMC and Low Voltage Directives, please refer to one of the following manuals.

📖 MELSEC iQ-R Module Configuration Manual (SH-081262ENG)

📖 Safety Guidelines (IB-0800525)

CONTENTS

SAFETY PRECAUTIONS	1
INTRODUCTION	10
COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES	10
RELEVANT MANUALS	23
TERMS	24
GENERIC TERMS AND ABBREVIATIONS	27

PART 1 BASIC SPECIFICATIONS

CHAPTER 1	AXIS SETTING	30
1.1	Axis	30
	Relevant variables	30
	Maximum number of controlled axes	31
	Required settings for axes	31
	Axis variables	31
	Axis variable initialization timing	33
	How to specify in a user program	33
	Axis status	34
	Precautions	36
1.2	Axis Type	37
	Relevant variables	37
	Real drive axis	41
	Real encoder axis	43
	Virtual drive axis	49
	Virtual encoder axis	49
	Virtual linked axis	56
1.3	Axis Assignment	57
	Relevant variables	59
	Object data settings	60
	PDO mapping settings	61
	Setting procedure	61
	Memory usage	61
	Object data list	62
	Motion system function and object data	65
	Precautions	65
1.4	Axes Group	66
	Relevant variables	66
	Relevant FBs	66
	Settings required for axes group	67
	Axes group variables	67
	Axes group variable initialization timing	67
	How to specify in a user program	68
	Axes group status	68
	Axes group enabled	70
	Axes group disabled	71
	Precautions	72
1.5	Axes Group Assignment	73

Relevant variables	73
Setting with Engineering tool	74
Memory usage	74

CHAPTER 2 AXIS MANAGEMENT FUNCTIONS 75

2.1 Technical Units	75
Relevant variables	75
Setting methods	76
Precautions	80
2.2 Positioning Range	81
Relevant variables	81
Set position	82
Combination with other functions	83
Precautions	83
2.3 Velocity Range	84
Relevant variables	84
Velocity set range	85
Precautions	85
2.4 Servo ON/OFF	86
Relevant variables	86
Relevant FBs	86
Control details	87
Precautions	88
2.5 Follow Up	89
Relevant variables	89
Disabling follow up	91
Precautions	93
2.6 Absolute Position Control	94
Relevant variables	94
Current position restoration	96
Absolute position data backup	100
Current position restoration for each axis type	103
Precautions	106

CHAPTER 3 BASIC FUNCTIONS 107

3.1 Operation Cycle	107
Relevant variables	107
System basic cycle	108
Operation cycle settings	109
Operation cycle assignment	111
Send/Receive data refresh of network connected devices	112
Buffer memory refresh	115
Axis operation process fast operation mode	116
Operation cycle 31.25 setting (Only when using RD78GH)	117
Precaution	119
3.2 Add-on Function	120
Relevant variables	120
Add-on library configuration	121
Management of add-on library	122
Loading add-on library	122

3.3	System Memory Settings	123
	Relevant variables	123
	System memory (RAM)	124
	System memory (backup RAM)	125
	Precautions	125
3.4	Software Reboot	126
	Relevant variables	126
	Reset	127
	Clear	128
	Quick clear	128
	Precautions	128

PART 2 MOTION CONTROL

CHAPTER 4 START AND STOP 130

4.1	Start	130
	Relevant variables	130
	Starting conditions	132
4.2	Retrigger/Continuous Update	133
4.3	Multiple Start (Buffer Mode)	134
	Relevant variables	138
	Multiple start during single axis operation	139
	Multiple start during multiple axes operation	146
	Option of buffering FB	153
	Near pass	154
	Combination with retrigger/continuous update	155
	Precautions	161
4.4	Stop	163
	Relevant variables	164
	Relevant FBs	167
	Stop cause lists	168
	Types of stop processes	170
	Order of priority for stop process	173
	Overrun at stop cause occurrence	174
	Stop during single axis operation	175
	Stop during axes group operation	182
	Precautions	189
4.5	Forced Stop	190
	Relevant variables	191
	Operation at the forced stop occurrence	193
	Operation at the forced stop release	194
	Check method	195
	Precautions	195

CHAPTER 5 HOMING 196

5.1	Overview	196
	Relevant variables	197
	Relevant FB	197
	Homing request	197
	Driver homing method	198

	Data set homing method	202
	Precautions	203
5.2	Operation Setting for Incompletion of Homing	204
	Relevant variables	204
	FBs that can be started when homing is incompletion	205
	Homing request clear	205
	Precautions	205

CHAPTER 6 AXIS CONTROL FUNCTION 206

6.1	Single Axis Positioning Control	206
	Relevant FBs	206
	Absolute positioning control	206
	Relative positioning control	207
6.2	Single Axis Speed Control	208
	Relevant FB	208
	Control details	208
	Buffer mode (BufferMode)	209
	Necessary object data	209
6.3	Single Axis Manual Control	210
	Relevant variables	210
	Relevant FB	210
	Types of manual control	210
	JOG operation	211
6.4	Multiple Axes Positioning Control	213
	Relevant variables	213
	Relevant FBs	213
	Types of multiple axes positioning control	214
	Operation in multiple axes positioning control	214
	Positioning speed in multiple axes positioning control	215
	Command unit in the multiple axes positioning control	223
	Acceleration/deceleration processing	226
	State transition in the multiple axes positioning control	226
	Linear interpolation control	227
	Circular interpolation control	233
	Necessary object data	241
6.5	Multiple Axes Positioning Data Operation	242
	Overall block diagram	243
	Relevant variables	243
	Relevant FB	243
	Control details	244
	Positioning data setting	245
	Sub functions	272
	Precautions	286
6.6	Speed to Positioning Move Control	288
	Relevant FBs	288
	Speed to absolute positioning	289
	Speed to relative positioning	291
	Precautions	293

CHAPTER 7 DIRECT CONTROL 294

7.1	Velocity Control	295
	Relevant variables	295
	Relevant FB	295
	Control details	295
	Buffer mode (BufferMode)	297
	Precautions	305
7.2	Torque Control	306
	Relevant variables	306
	Relevant FB	306
	Control details	307
	Buffer mode (BufferMode)	311
	Precautions	320
7.3	Pressure Control	322
	Relevant variables	322
	Relevant FB	322
	Overall block diagram	323
	Control details	324
	Pressure ramp function	327
	Acceleration/deceleration processing function for limit velocity	328
	Pressure control process	329
	Limit position/last position (forward-side position)	330
	Multiple start (Buffer mode)	333
	Precautions	336

CHAPTER 8 FUNCTIONS RELEVANT TO POSITION 338

8.1	Current Position Change Function	338
	Relevant FB	338
	Current position change	339
	Cancel	341
8.2	Command In-position	342
	Relevant variables	342
	Command in-position width check	343
8.3	Software Stroke Limit	344
	Relevant variables	344
	Definition of movable range	345
	Specifications of the software stroke limit check	350
	Precautions	350
8.4	Hardware Stroke Limit	351
	Relevant variables	352
	Hardware stroke limit check details	354
	Returning from outside the hardware stroke limit range	355
	Checking the hardware stroke limit enabled/disabled	356
	Precautions	356

CHAPTER 9 FUNCTIONS RELEVANT TO VELOCITY 358

9.1	Acceleration/deceleration Processing Function	358
	Relevant variables	360
	Acceleration/deceleration method	363
	Acceleration/deceleration waveform adjustment when specifying jerk	370
	Operation when specifying acceleration/deceleration 0	372

Acceleration limit value/deceleration limit value	373
Jerk limit value	374
Limit of acceleration time/deceleration time	375
Automatic deceleration	376
Changing control of jerk acceleration/deceleration	377
Acceleration/deceleration method and multiple start	382
Velocity bias	383
Precautions	385
9.2 Velocity Limit	388
Relevant variables	388
How to set the velocity limit function	388
Operation when the velocity limit value is exceeded	389
Operation setting at velocity limit value exceeded	391
9.3 Override Function	392
Relevant variables	392
Relevant FBs	393
How to change control data	393
Precautions	397

CHAPTER 10 FUNCTIONS RELEVANT TO TORQUE **398**

10.1 Torque Limit	398
Relevant variables	398
Object data setting	399
Torque limit value setting range	399
Torque limit maximum value setting range	400
Precautions	400
10.2 Torque Limit Value Change Function	401
Relevant variables	401
Relevant FB	401
How to change control data	402

CHAPTER 11 CONTROL SUB FUNCTIONS **403**

11.1 Compensation Function	403
Relevant variables	403
Driver unit conversion function	403
11.2 Command Filter	406
Relevant FBs	406
Smoothing filter	407
Moving direction restriction filter	409
Speed limit filter	410
Backlash compensation filter	411
Precautions	417
11.3 Input Variable Change in Execution	418
Relevant variables	418
Target position/movement distance change	419
Set velocity change	422
Acceleration/deceleration and acceleration/deceleration time change	423
Precautions	423

CHAPTER 12 COMMON FUNCTIONS **424**

12.1	External Signal Selection	424
	Overall block diagram	424
	Relevant variables	425
	SIGNAL_SELECT structure	426
	TARGET_REF structure	428
	External signal high-accuracy input	431
	Precautions	431
12.2	Touch Probe	432
	Overall block diagram	432
	Relevant FBs	432
	Touch probe valid	433
	Touch probe invalid	436
	Precautions	437
	Example programs	437
12.3	Axis Emulation	440
	Relevant variables	440
	Setting procedures	440
	Operation during emulate function	440
	Specification of the emulated device station	441
	Precaution	442
12.4	Inter-Module Synchronization Function	443
	Operation using the multiple Motion module	444
	Program example	448
	Precautions	451
12.5	Master-Slave Operation	452
	Relevant variables	453
	Control details	454
	Parameter setting	456
	Precautions	463

CHAPTER 13 SYNCHRONOUS CONTROL 464

13.1	Overview of Single Axis Synchronization Control FBs	464
13.2	Axis Configuration	465
13.3	Master Axis Data Source Selection	466
13.4	Start and Stop Operation	467
13.5	Required Object Data	467
13.6	Restrictions	468
13.7	Cam Operation	468
	Relevant variable	468
	Relevant FB	468
	Control details	469
	Precautions	496
13.8	Gear Operation	497
	Relevant FB	497
	Control details	497
	Precautions	499
13.9	Addition/Subtraction Positioning	500
	Relevant FB	500
	Control details	500
13.10	Precautions	501

CHAPTER 14 OPERATION PROFILE FUNCTION**502**

14.1	Operation Profile	502
	Overall block diagram	502
	Relevant variables	503
	Relevant FBs	503
	Operation profile types	504
	Creating operation profile	531
	Operating operation profile	533
	Control of operation profile	537
	Start mode	537
	Sub function of operation profile	539
	Precautions	542
14.2	Operation Profile Format	543
	Operation profile details	543
	Notation for different setting formats	554

CHAPTER 15 ADVANCED SYNCHRONOUS CONTROL**555**

15.1	Overview of Advanced Synchronous Control	555
	Relevant variables	556
	Relevant FBs	560
15.2	Control Details for Advanced Synchronous Control	561
	Procedure for executing advanced synchronous control	562
	Starting/stopping for advanced synchronous control	566
	Advanced synchronous control precautions	572
15.3	Input Axis Function	576
	Input axis initialization timing	577
	Input axis position command unit	578
	Input axis positioning range	578
	Input axis relevant variables	578
	Precautions	584
15.4	Output Axis Function	585
	Output axis initialization timing	585
	Output axis positioning range	586
	Output axis relevant variables	586
	Main shaft module	589
	Auxiliary shaft module	600
	Clutch	611
	Speed change gear	624
	Output axis module	628
	Cam function	636
	Synchronous control change function	648
	Precautions	652
15.5	Synchronous Control Initial Position	653
	Backup data management for advanced synchronous control	654
	Restoration method for current position after composite main shaft gear, current position per cycle after main shaft gear, and current position per cycle after auxiliary shaft gear at start of synchronous control	655
	Cam axis position at synchronous control start	658
	Synchronous control analysis mode	666
	Variables related to synchronous control initial position	668
	Precautions	671

	Method to restart synchronous control	671
15.6	Cam Position Calculation Function	672
	Control details	672
	Precautions	678
15.7	Applied Functions	679
	Phase compensation function	679
15.8	Example Programs	681
	Flying cutter	681
	Filling machine	691

PART 3 CONNECTABLE DEVICE to CC-Link IE TSN

CHAPTER 16	CONNECTABLE DEVICE to CC-Link IE TSN	718
16.1	Common Items for All Devices	718
	How to use the slave label	718
	PDO mapping setting	721
	Communication period setting	723
	Device station parameter automatic setting	724
16.2	Connection Method for MELSERVO	725
	MR-J5(W)-G (Cyclic synchronous mode)	725
	MR-J5(W)-G (other than Cyclic synchronous mode)	739
	How to connect MR-JET-G	745
16.3	Connection Method for Drive Unit other than MELSERVO	746
	Drive unit other than MELSERVO (cyclic synchronous mode)	746
	Drive unit other than MELSERVO (other than cyclic synchronous mode)	758
16.4	Relevant Functions	759
	Driver control mode	759
	Safety communication	766
	External signal high-accuracy input	767
	Master-slave operation	775
16.5	Precautions	783

PART 4 CONTROL/OPERATION/MAINTENANCE

CHAPTER 17	LOGGING	786
17.1	Data Logging/Real-Time Monitor	786
	Relevant variables	786
	Data logging function	788
	Real-time monitor	788
	Steps until the collected data is saved	789
	Logging setting	793
	Application function	799
	Precautions	801
	Folder configuration	803
17.2	Data Logging Format	804
	CSV file data specifications	804
	JSON file data specifications	806
17.3	Logging Data (JSON format)	809
	Basic specifications	809

Whole configuration	809
Data specification	810

CHAPTER 18 RAS FUNCTIONS **813**

18.1 Execution Time Monitor	813
Relevant variables	814
Control details	815
Processing time over check.	817
Output of errors	818
18.2 History Data	819
Relevant variables	820
Event history function	821
Positioning data history	824
Precautions	824
18.3 Servo System Recorder	825
Relevant variables	826
Control details	827
Co-recording function	833
Restart from the logging interruption	835
How to check the logging data	836
How to delete the logging setting file.	840
How to disable servo system recorder	842
Precautions	844

CHAPTER 19 MOTION SERVICE PROCESSING **846**

19.1 Motion Service Processing Control.	846
19.2 Motion Service Processing Description	847

CHAPTER 20 HOW TO CONTROL FROM CPU MODULE **848**

20.1 Specifications of I/O Signals with CPU Modules	848
Module label	848
I/O signals	855
Buffer Memory	856
20.2 Using Motion control FB.	857
Relevant variable.	857
Control details	857

CHAPTER 21 FILE CONTROL **863**

21.1 Memory and File	863
Relevant variables	863
Drive	864
Path setting	866
Operation that can be executed	868
Storage files.	868
Module extended parameters	870
Data backup	870
Operation folder.	872
Precautions	872
21.2 Parameter Read/Write Function.	873
Relevant FBs.	873

Control details	873
Response code (SDO abort code)	876
Precautions	876
21.3 File Transfer Function	877
Relevant variables	877
Access control setting	878
Functions of file transfer	878
Command format	879
Log file	883
Precautions	883
21.4 SD Memory Card	884
Relevant variables	884
SD memory card handling	885
Installation and removal of SD memory card	885
Precautions	885
CHAPTER 22 SECURITY	886
22.1 Security Key Authentication Function	887
Control details	889
Precautions	891
Version combinations	892
CHAPTER 23 MOTION MODULE SOFTWARE INSTALLATION	894
23.1 Motion System Software Installation	894
Relevant variables	895
Software file configuration of motion system	895
How to batch install the motion system software	896
Checking software version	899
Precautions	900
23.2 Installation of Basic System Software and Add-on Libraries	901
How to install the basic system software and Add-on libraries	901
23.3 Boot Software Installation	904
How to install the boot software	905
CHAPTER 24 TROUBLESHOOTING	908
24.1 LED Control	908
24.2 Checking Errors and Warnings	909
Overall block diagram	909
Relevant variables	910
Control details	911
Precautions	911
24.3 Error and Warning Reset	912
Relevant variables	913
Relevant FBs	913
System error reset	914
Axis error reset	918
Axes group error reset	920
Precautions	922
24.4 Troubleshooting by Symptom	923
24.5 List of Warning Codes	924

24.6	List of Error Codes	935
24.7	List of Logging Error Codes.....	978
24.8	List of Event Codes.....	979
APPENDICES		981
Appendix 1 Restrictions by the version.....		981
Appendix 2 List of Add-on Library		987
Appendix 3 List of Boot software		992
INDEX		993
REVISIONS.....		995
WARRANTY		997
INFORMATION AND SERVICES		998
TRADEMARKS		998

RELEVANT MANUALS

The following manuals are relevant to this product.

Manual name [manual number]	Description
MELSEC iQ-R Motion Module User's Manual (Application) [IB-0300411ENG] (this manual)	Functions, I/O signals, variables, labels, programming, and troubleshooting of the Motion module
MELSEC iQ-R Motion Module User's Manual (Startup) [IB-0300406ENG]	Specifications, procedures before operation, system configuration, and wiring of the Motion module
MELSEC iQ-R Motion Module User's Manual (Network) [IB-0300426ENG]	Functions, parameter settings, troubleshooting, and buffer memory of CC-Link IE TSN
MELSEC iQ-R Programming Manual (Motion Module Instructions, Standard Functions/Function Blocks) [IB-0300431ENG]	Instructions for the Motion module and standard functions/function blocks
MELSEC iQ-R Programming Manual (Motion Control Function Blocks) [IB-0300533ENG]	Motion control function blocks, variables, and programming
Motion Module Quick Start Guide [L03191ENG]	Describes system startup, parameter settings, and programming methods for first-time users of the Motion module
Motion Module Quick Start Guide (PLC CPU Ladder Program) [L03194ENG]	Describes system startup, parameter settings, and programming methods for first-time users of the Motion module

For programs, refer to the following.

 MELSEC iQ-R Programming Manual (Program Design)

TERMS

Unless otherwise specified, this manual uses the following terms.

Term	Description
Aborting, Buffered, Blending	Various modes of the buffer mode.
Actual position	A position address returned by a device station assigned to an axis that is rounded by the ring counter. It is affected by a current position change.
Actual pressure	Feedback value of pressure.
Actual velocity	A value obtained by converting the actual value from the device station on the real axis into the technical units of the axis.
Administrative FB	A Motion control FB that takes an axis or an axes group for the argument and does not change the axis status or the axes group status by execution.
Axes group variable	An AXES_GROUP type variable instance including parameters and data related to the axes group.
Axis variable	An AXIS_* type variable instance including parameters and data related to the axis.
Axis	A target for motion control.
Axis error	An error or a warning related to an axis.
Axis warning	
Axes group error	
Axes group warning	
Buffering	That a Motion control FB enters the standby status in multiple start.
Buffering FB	A Motion control FB that is carried out multiple start and waits for execution (Busy is TRUE).
Buffer memory	A memory in an intelligent function module, where data (such as setting values and monitoring values) are stored.
Buffer mode	A generic term for multiple start.
Cam table	An operation profile used for cam control. (Example) Operation profile of cam data format or operation profile of cam data format for rotary cutter.
CC-Link IE TSN	An open network that uses "TSN (Time-Sensitive Networking)", which is an extension of the Ethernet standard, to ensure real-time control and handle information from other open networks simultaneously.
CC-Link IE TSN Class	A group of devices and industrial switches compatible with CC-Link IE TSN, classified according to the functions and performance by the CC-Link Partner Association. For CC-Link IE TSN Class, refer to the CC-Link IE TSN Installation Manual (BAP-C3007ENG-001) published by the CC-Link Partner Association.
Commanded position	A commanded position address that is specified in the motion FB.
Commanded pressure	A specified value for pressure.
Commanded limit velocity	A specified value for limit velocity.
Commanded velocity	A set velocity that is specified in the motion FB.
Continuous path data	Any positioning data when the operation pattern is "Continuous path".
Continuous positioning data	Positioning data when the operation pattern is "Continuous positioning".
Continuous update	Continuously reflecting input values to the control while the ContinuousUpdate input of the Motion control FB is TRUE.
Control slave axis	A device that has the servo parameter "Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting (PD23.1)" set to "1 to 8 (Master axis control station)" in a slave axis of the master-slave operation.
Cumulative current position	A commanded position address that is not rounded by a ring counter. It is affected by a current position change.
Cyclic transmission	A function by which data is periodically exchanged among stations on the network.
Dedicated instruction	An instruction for using functions of the module.
Device	Various types of memory in a module. Some devices are handled in units of bits and some in units of words.
Disconnection	A process of stopping data link if a data link error occurs.
Driver communication	Using the master-slave operation function, this function controls the master axis with the motion system, while the slave axes are controlled by data communication between servo amplifiers (driver communication) without using the motion system.
Drive unit error	An error or a warning occurred in the drive unit.
Error reset	Clearing the detection status of errors and warnings.
Execute	Set TRUE to the Execute input or the Enable input to the Motion control FB.
External signal high-accuracy input	An input signal linked with signal detection time of the device station.
First point of cam table	The meaning is different depending on the interpolation method specification for the cam data. <ul style="list-style-type: none"> • For Section interpolation, Spline interpolation: Point of Table No.1 • For linear interpolation: Point of No.1

Term	Description
Forward-side position	Data sent to the drive unit as object data "Forward-side stop function (2E56H)". The limit position to which an axis can move in the pressure increase direction at feed/dwell, or the last position at pressure release.
General FB	A Motion control FB that does not take an axis or an axes group for the argument.
Global label	A label that is enabled for all program data when creating multiple program data in the project. The global label in the motion system can be made public as the module label (global label) in the control CPU module.
GX Works3	The product name of the software package for the MELSEC programmable controllers.
Hardware reboot	Turning ON the power of the system again or resetting.
Input variable	An FB input argument.
Intelligent function module	A module that has functions other than input and output, such as an A/D converter module and D/A converter module.
Jerk	Chronological change ratio of the acceleration or the deceleration.
Label	A variable used in a program.
Link device	A device in a module on CC-Link IE.
Link refresh	Automatic data transfer between a link device of the Motion module and a device in a CPU module.
Machine feed value	A commanded position address that is not rounded by the ring counter. It is based on the home position, and it is not affected by a current position change.
Master axis	A device that sends commands to the slave axis of the master-slave operation. This applies to real drive axes.
Master axis (input) absolute coordinate	Another term combining input variable Master axis absolute coordinate (MasterAbsolute) of MC_CamTableSelect (Cam Table Selection).
Module label	A label that represents one of memory areas (I/O signals and buffer memory areas) specific to each module in a given character string. From the module used, GX Works3 automatically generates this label, which can be used as a global label in the CPU module.
Motion area	A software that performs the motion control in the Motion module.
Motion control FB	FB related to motion control whose name begins with MC_ or MCv_.
Motion control station	A device station that exchanges cyclic data by using slave labels and the motion control.
Motion FB	A Motion control FB that takes an axis or an axes group for the argument and changes the axis status or the axes status by execution.
Motion module	Another term for RD78G(H).
Motion service processing	Processing in the motion system that does not require real-time.
Motion synchronization station	Another term for the motion control station.
MR-J5-G	Servo amplifier model MR-J5-_G_/MR-J5-_G_-RJ/MR-J5-_G_-LL.
MR-J5D-G	Servo amplifier model MR-J5D-_G_.
MR-J5W-G	Servo amplifier model MR-J5W-_G_.
MR-JET-G	Servo amplifier model MR-JET-_G_.
MR Configurator2	The product name of the setup software for the servo amplifier.
Multiple axes interpolation control	Control in which multiple axes work such as linear interpolation and circular interpolation. Axes to be cooperated by an axes group are specified.
Multiple axes interpolation data	Positioning data belonging to the "Positioning (multiple axes interpolation)" control method type.
Multiple start	Executing another Motion control FB to the same axis while a Motion control FB is executed.
Network area	A software that performs the network control in the Motion module.
Next FB	Another Motion control FB that starts while an axis and an axes group are operated.
Normal axis	A device with no master-slave operation setting.
Object	Various data held by the CANopen-compatible device station.
Object data	The data that sends/receives information to/from the connected device in the motion operation processing.
On-going FB	Motion control FB that is in execution on the axis and the axes group (FB whose Busy is TRUE).
Output variable	An output argument of FB.
Positioning complete data	Positioning data when the operation pattern is "Positioning complete".
Positioning continue data	Positioning data when the operation pattern is other than "Positioning complete".
Previous FB	The previous Motion control FB of a buffering FB (If only one FB is buffered, it indicates on-going FB).
RD78G	Another term for the MELSEC iQ-R series Motion module (compatible with CC-Link IE TSN).
RD78GH	
Real axis	An axis that is linked with a device station on network.
Real drive axis	An axis that is linked with a device station which supports CC-Link IE TSN compatible with csp/csv/cst mode (sequential command) of the CiA402 drive profile.

Term	Description
Real encoder axis	An axis that generates a commanded position from the current position of the encoder connected with a device station. It is used for the master axis of the single axis synchronous control.
Reconnection	A process of restarting data link when a faulty station recovers from an error.
Retrigger	Starting up the Execute input again while executing an FB to a Motion control FB that has the Execute input.
Safety communications	A function to exchange safety data between safety stations on the same network.
Service task	A dedicated task for executing the motion service processing.
Set limit velocity	A set value for limit velocity.
Set position	A commanded position address rounded by the ring counter. It is affected by a current position change.
Set pressure	A set value for pressure.
Set velocity	A current control value that is generated by motion operation.
Single axis synchronization	A control to output the position information (command) of Slave (slave axis) 1-axis that is synchronized with Master (master axis).
Slave axis	A device that receives commands from a master axis under master-slave operation. This applies to Motion control stations to which axes are not assigned.
Slave axis (output) absolute coordinate	Another term combining input variable Slave axis absolute coordinate (SlaveAbsolute) of MC_CamTableSelect (Cam Table Selection).
Software reboot	Resetting only motion area and network area without a hardware reboot.
Standard station	A device station other than a motion control station.
Start	Executing a motion FB for the first time to an axis or an axes group.
Switching speed	<ul style="list-style-type: none"> • The set velocity of the on-going Motion control FB when specifying Aborting. • The set velocity when the on-going Motion control FB reached the target position when specifying Blending.
System basic cycle	A basic cycle of fixed cycle processing such as motion operation processing.
System error	An error or a warning not related to an axis. When Axis information (Axis) and Axes Group Information (AxesGroup) of the Motion control FBs are not correct, the system error will occur.
System start	Carrying out an initialization processing of the Motion module by power ON or a reboot of the system.
System memory	A generic term for memory areas which are available add-ons in the motion system. The areas do not include the memory area used for baseSystem.
Target position	A commanded position address that is specified in the motion FB.
Transient transmission	A function of non-periodic data communication among nodes (station) on network. A function used to send message to the target station when requested by a link dedicated instruction or the engineering tool. Communication is available with station on another network via relay station, or gateway.
Under-control FB	Motion control FB that is in execution on the axis and the axes group (FB whose Active is TRUE).
Virtual axis	An axis that is not linked with a device station on network.
Virtual encoder axis	An axis that generates a command position from a variable. It is used for the master axis of the single axis synchronous control.
Virtual drive axis	A virtual axis that can generate a command virtually.
Virtual linked axis	An axis that connects FBs and transmits a command in the single axis synchronous control.

GENERIC TERMS AND ABBREVIATIONS

Unless otherwise specified, this manual uses the following generic terms and abbreviations.

Generic term/abbreviation	Description
CC-Link IE	A generic term for the following: <ul style="list-style-type: none"> • CC-Link IE TSN • CC-Link IE Controller Network (MELSEC iQ-R CC-Link IE Controller Network User's Manual (Application)) • CC-Link IE Field Network (MELSEC iQ-R CC-Link IE Field Network User's Manual (Application))
Continuous path	An abbreviation for the operation patterns "Continuous path (BlendingLow)", "Continuous path (BlendingPrevious)", "Continuous path (BlendingNext)", and "Continuous path (BlendingHigh)".
CPU module	An abbreviation for the MELSEC iQ-R series CPU module.
csp	An abbreviation for the cyclic synchronous position mode (one of the control modes on the drive unit side).
cspr	An abbreviation for the cyclic synchronous pressure mode (one of the control modes on the drive unit side).
cst	An abbreviation for the cyclic synchronous torque mode (one of the control modes on the drive unit side).
csv	An abbreviation for the cyclic synchronous velocity mode (one of the control modes on the drive unit side).
ct	An abbreviation for the continuous operation to torque control mode (one of the control modes on the drive unit side).
Data link	A generic term for a cyclic transmission and a transient transmission.
Device station	A generic term for a local station and remote station on CC-Link IE TSN.
Drive unit	A generic term for motor drive devices, such as servo amplifiers.
Engineering tool	A generic term for GX Works3 and MR Configurator2.
GOT	A generic term for the Mitsubishi Electric GOTs (GOT1000, GOT2000 series).
hm	An abbreviation for the homing mode (one of the control modes on the drive unit side).
LB	An abbreviation for a link relay of the link device. Bit data sent from each station of the network.
LW	An abbreviation for a link register of the link device. 16-bit (1-word) data sent from each station of the network.
MCFB	An abbreviation for Motion Control FB.
Motion system	A generic term for software that performs the motion control and the network control.
MR-J5(W)-G	A generic term for MR-J5-_G_/MR-J5-_G_-RJ/MR-J5-_G_-LL/MR-J5W-_G_/MR-J5D-_G_ model servo amplifiers.
Operation profile	A generic term for waveform data used for each control.
PDO	An abbreviation for Process Data Object. A collection of the application objects transmitted periodically between multiple CANopen nodes.
RAS	An abbreviation for Reliability, Availability, and Serviceability. This term refers to the overall usability of automated equipment.
RD78G(H)	A generic term for RD78G_, RD78GH_ (high performance version).
Reboot	A generic term for hardware reboot and software reboot.
RW _r	An abbreviation for a remote register of the link device. This refers to 16-bit (1-word) data input from a device station to the master station. (Not applicable for some local stations.)
RW _w	An abbreviation for a remote register of the link device. This refers to 16-bit (1-word) data output from the master station to a device station. (Not applicable for some local stations.)
RX	An abbreviation for remote input of the link device. This refers to bit data input from a device station to the master station. (Not applicable for some local stations.)
RY	An abbreviation for remote output of the link device. This refers to bit data output from the master station to a device station. (Not applicable for some local stations.)
Safety station	A generic term for a station that performs safety communications and standard communications.
SDO	An abbreviation for Service Data Object. A message used to access the object entries inside the object dictionary of an optional CANopen node. Used for non-periodic transmission between stations.
SLMP	An abbreviation for Seamless Message Protocol. It is a protocol to access SLMP compatible devices from external devices such as personal computers and display devices, as well as from SLMP compatible modules (such as Ethernet-equipped modules or CC-Link IE TSN modules).
Software	A generic term for a firmware which configures the motion system. It consists of add-ons, baseSystem software, and boot software.

MEMO

PART 1

BASIC SPECIFICATIONS

PART 1

This part consists of the following chapters.

1 AXIS SETTING

2 AXIS MANAGEMENT FUNCTIONS

3 BASIC FUNCTIONS

1 AXIS SETTING

1.1 Axis

The target controlled in the motion system is called an axis. Axes are classified into real axes which target the drive units and the I/O devices connected to the network, and virtual axes which virtually generate commands and position in the motion system.

Classification	Axis type	Description
Real axis	Real drive axis	Uses the drive unit corresponding to the CiA402 drive profile connected to CC-Link IE TSN. Included in the number of controlled axes.
	Real encoder axis	Generates the current position from the synchronous encoder output pulse connected to the drive unit on the CC-Link IE TSN.
Virtual axis	Virtual drive axis	Virtually generates commands in the motion system. The real drive unit is not used.
	Virtual encoder axis	Generates the current position from the motion system variables. Used as an input axis for the single axis synchronous control.
	Virtual linked axis	Connects FBs of the single axis synchronous control. Only the minimum data required in the single axis synchronous control is defined.

Operation of this function for each system status

○: Possible, △: Possible (restricted), ×: Not possible

System status	Operation availability
STOP	○
RUN	○
Moderate error	△ (Operation may not be possible according to the error status.)* ¹
Major error	×

*¹ When a required add-on is stopped due to "Add-on Library Load Error" (error code: 3205H) or "Insufficient Add-on System Memory (RAM)" (error code: 3209H), operation will not be possible.

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the current axis status. <ul style="list-style-type: none">• -1: Axis variable uninitialization/Axis parameter error (Invalid)• 0: Axis disabled (Disabled)• 1: Stopping on error (ErrorStop)• 2: Decelerating to stop (Stopping)• 3: During homing (Homing)• 4: Standby (Standstill)• 5: During positioning operation (DiscreteMotion)• 6: During continuous operation (ContinuousMotion)• 7: During synchronous operation (SynchronizedMotion)

Maximum number of controlled axes

The maximum number of controlled axes controlled by the motion system is the number of real drive axes. The other type of axes are not counted in the number of axes.

Axis type	RD78G4	RD78G8	RD78G16	RD78G32	RD78G64	RD78GHV	RD78GHW
Real drive axis ^{*1}	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	256 axes
Virtual drive axis	Up to 1024 axes can be set. Settable number of axis varies depending on the system memory capacity setting. ^{*2} Axis assignment method is as follows. • Set on the Engineering tool (Axis setting window)						
Virtual linked axis							
Real encoder axis							
Virtual encoder axis							

*1 When a multi-axis drive unit and a general output device are used as multiple axes, the number of those axes is counted.

<Example> For a 2-axis drive unit the number of axes counted is 2 axes.

*2 For the memory capacity, refer to the following.

☞ Page 61 Memory usage

If the axis setting exceeds the maximum number of controlled axes, "Maximum Setting Axis Number Over Warning" (warning code: 0F0BH) occurs.

An axis is used as the control axis in the order it is assigned as the axis variable to the global label.

For axes exceeding the maximum number of controlled axes, Axis Status (AxisName.Md.AxisStatus) turns to "-1: Axis variable uninitialization/Axis parameter error (Invalid)" and, thus they cannot be used for the control.

Required settings for axes

The following items are required to be set in the axis setting window of the engineering tool to set the axes. For axis setting methods, refer to the following.

☞ Page 57 Axis Assignment

Item	Description
Axis name	Sets an arbitrary axis name.
Axis No.	Sets a control axis No. of the motion system.
Axis type	Sets the axis type.
Station address	Sets the station address of a drive unit related to the axis. In case of a multi-axis drive unit, sets the multidrop No. as well.
Absolute position control setting	Sets the absolute position control method of axis.
Control cycle	Sets the cycle to execute control.

Other than above items, additional parameters must be set for each axis type.

For details on parameter settings, refer to the specifications of each axis type.

Axis variables

An axis is generated/initialized by the axis setting in the engineering tool. The set axis is assigned to the global label data as an axis variable.

The axis is defined as an axis variable configured with monitor information axes such as the parameter information, the current position, and the status, etc.

An axis variable data type changes depending on the axis type.

For the setting of the engineering tool, refer to the following.

☞ Navigation window ⇒ "Parameter" ⇒ "Module information" ⇒ Target module ⇒ "Module extended parameter" ⇒ [Motion Control Setting Function] ⇒ Navigation window ⇒ "Axis" ⇒ Right-click ⇒ [Add New Data]

Axis variable name (default)

The following names are assigned based on the setting axis No. These can be changed to an arbitrary name. For details, refer to the following.

 Page 57 Axis Assignment

Setting axis No.	Engineering tool default axis name
1	Axis0001
2	Axis0002
⋮	⋮
10000	Axis10000

Data type

The following data types are assigned based on the axis type. For details on data type, refer to the relevant variables of each axis type.

Axis type	Data type
Real drive axis	AXIS_REAL
Real encoder axis	AXIS_ENCODER
Virtual drive axis	AXIS_VIRTUAL
Virtual encoder axis	AXIS_VIRTUAL_ENCODER
Virtual linked axis	AXIS_VIRTUAL_LINK

Each data type has the following members respectively.

Member name	Data type	Description
AxisRef	AXIS_REF	The data structure for input/output of the Motion control FBs. The type is fixed regardless of the axis type.
PrConst	Differs by the axis type.	Stores the axis parameter data (constant). Opens the setting value at the axis variable initialization. Re-importing to the control data is not executed after axis variables initialization.
Pr		Stores the axis parameter data. Opens the default value at the axis variable initialization. Re-importing to the control data is executed after axis variables initialization. The fetch timing to the control changes depending on the parameter.
Md		Stores the axis monitor data. Executes the refresh in the fixed cycle for each monitor data.
Cd		Stores the axis control command data. Acquires the latest value every control operation cycle and uses it for the control.

Precautions

- Do not assign axis variables to each other. Writing an expression on a program that assigns axis variables to each other will copy all of the axis variables of the assignment source to the assignment target when the program is executed. Note that operating the axis variables of the assignment target after the assignment will not affect the internal status of the assignment source axis variables. (Operating the parameter (Pr)/control data (Cd) of the assignment target does not operate the parameter (Pr)/control data (Cd) of the assignment source.)
- Since obtaining all of the axis variables by assignment greatly affects the program processing time when referencing multiple monitor data, alternative methods such as defining the axis monitor variables (such as AXIS_REAL_MONI type/ AXIS_VIRTUAL_MONI type) to be obtained in assignments or copying only the required data are recommended.

Axis variable initialization timing

Axis variables are initialized at the following timing.

Timing	Processing
Power ON/CPU module reset	Refers to the global label data, and initializes all set axis variables.
PLC READY OFF → ON	<p>■Uninitialized axes Refers to the global label data and initializes all axes variables.</p> <p>■Initialized axes Refer to the global label data for the axis parameter data and reload again. When the parameter error occurs at loading, the axis is not deleted. In this case, the READY does not turn to ON. For the label initialization processing when the PLC READY turns OFF to ON, refer to "Label initialization function" in the following manual.  MELSEC iQ-R Programming Manual (Motion Control Function Blocks)</p>

In case of a real axis, the device network connection is required to operate an axis after the axis variable is initialized. If the device of the station address has been connected, it must be disconnected and then reconnected. (The axes can be emulated without network connection. ( Page 440 Axis Emulation))


How to specify in a user program

When specifying the axis by the Motion control FB, set the AXIS_REF type member (AxisName.AxisRef) of the axis variable to the I/O variables which the data type is "AXIS_REF".

Ex.

When executing the MC_Power (Operation Available) with the following conditions:

- Axis type: Real drive axis
- Axis No.: 1
- Axis name: Axis0001



Axis status

Axis state transition


The following shows the status that a single axis can be in.

The current status can be confirmed in Axis Status (AxisName.Md.AxisStatus).

Status	Description
-1: Axis variable uninitialization/Axis parameter error (Invalid)	Axes cannot be used in this status due to axis variable uninitialization (parameter error occurrence at an initialization, etc.).
0: Axis disabled (Disabled)	The status where the axis cannot be used. In case of a real drive axis, this status indicates the servo OFF stop. In case of a real axis, this status occurs also when the device station is disconnected from the network.
1: Stopping on error (ErrorStop)	The status of the deceleration stop or stop by error occurrence. In case of a real drive axis, the axis is servo ON or servo OFF depending on the error.
2: Decelerating to stop (Stopping)	The status where the deceleration stop is in execution by MC_Stop (Forced Stop). After the axis stop is completed, this status continues until the Execute command (Execute) of MC_Stop (Forced Stop) changes to FALSE. The Motion control FB cannot be executed in this status.
3: During homing (Homing)	The status where the homing is in execution in the drive unit or the motion system by the homing FB.
4: Standby (Standstill)	The status where the Motion control FB can be used. In case of a real drive axis, the axis is servo ON stop.
5: During positioning operation (DiscreteMotion)	The status where the positioning operation is in execution by the positioning control FB.
6: During continuous operation (ContinuousMotion)	The status where the continuous control is in execution by the continuous control FB (such as the FB of speed control and torque control) or the manual control FB.
7: During synchronous operation (SynchronizedMotion)	The status where the axis synchronizes with the master axis by the single synchronous control FB. Transits to this status after the axes group set as the configuration axes changes to the "5: Operating (GroupMoving)" status.

The status transits as shown below according to the start of the Motion control FB. The state transition may varies depending on the axis type. For the specifications of each axis type, refer to the following.

Page 37 Axis Type



*1 The status transits when the conditions ((1) to (10), Done) are satisfied.

Event transitions with no transition conditions perform state transitions at axis start according to the types of Motion control FBs.

No.	State transition description
(1)	From any state, transits when an error in the axis occurred.
(2)	<ul style="list-style-type: none"> From any state, transits when Enable (Enable) of MC_Power (Operation Available) is FALSE, and no error occurs in the axis. Transits from "4: Standby (Standstill)" when Enable (Enable) of MC_Power (Operation Available) is TRUE, Servo ON request (ServoON) is FALSE, and no error occurs in the axis. Transits when Process Selection at Servo OFF Command During Operation (<u>AxisName</u>.Pr.StopMode_ServoOff) is changed to which Servo ON request (ServoON) is FALSE from "0: Ignore (Ignore)" and "2: Decelerating to stop (Stopping)"^{*2}.
(3)	Transits by the status error cancel for the error reset command during the servo OFF state.
(4)	Transits by the status error cancel for the error reset command during the servo ON state.
(5)	Transits when Enable (Enable) of MC_Power (Operation Available) is TRUE, Servo ON request (ServoON) is TRUE, and Operable (Status) of MC_Power (Operation Available) is TRUE.
(6)	Transits when Execution completion (Done) of MC_Stop (Forced Stop) is TRUE and Execute command (Execute) of MC_Stop (Forced Stop) is FALSE.
(7)	<ul style="list-style-type: none"> Transits from "4: Standby (Standstill)" when the forced servo OFF by the drive unit is executed and the axis is enabled. Transits when a communication with the drive unit is failed from 4: Standby (Standstill).
(8)	Transits automatically when the virtual axis is enabled.
(9)	Transits when the axes group used as configuration axes changes to "5: Operating (GroupMoving)".
(10)	The transition conditions differ depending on the function. For details, refer to each function.

*2 The axis status does not transit until the axis is stopped completely. After the axis stops completely the status transits to "0: Axis disabled (Disabled)". For details, refer to the following.

Page 163 Stop

Precautions

"Out of Parameter Range (Axis)" (error code: 1D80H) occurs if a parameter error occurs at the axis variable initialization. At this time, Axis Status (AxisName.Md.AxisStatus) will be "-1: Axis variable uninitialization/Axis parameter error (Invalid)". The monitor data, etc. of the axis where "-1: Axis variable uninitialization/Axis parameter error (Invalid)" occurred is not refreshed. If the axis is specified by the user program, "Out of Axis No. Range" (error code: 3400H) occurs.

Relevant add-ons

The following add-ons are required to use this function.

- Axis
- MotionEngine
- NetworkDriver_CCIETSN^{*1}
- ServoDriver_CANopen^{*1}

^{*1} When using the real axis

System memory capacity

For details, refer to the following.

 Page 61 Memory usage

1.2 Axis Type

Relevant variables

Real drive axis data type AXIS_REAL members (excluding AxisRef)

■Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
AxisType	Axis Type Setting	Sets the axis type. ☞ Page 57 Axis type
AddressOfStation	Station Address Setting	Sets the station address (IP address) with a character string. ☞ Page 58 Station address
OperationCycle	Control Cycle Setting	Sets the control operation cycle. ☞ Page 58 Control cycle
SlaveObject	Object Data	Sets the object data to the real drive axis ☞ Page 60 Object data settings

■Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the current axis status. <ul style="list-style-type: none">• -1: Axis variable uninitialization/Axis parameter error (Invalid)• 0: Axis disabled (Disabled)• 1: Stopping on error (ErrorStop)• 2: Decelerating to stop (Stopping)• 3: During homing (Homing)• 4: Standby (Standstill)• 5: During positioning operation (DiscreteMotion)• 6: During continuous operation (ContinuousMotion)• 7: During synchronous operation (SynchronizedMotion)
UseInGroup	Using Axes Group	Displays whether the drive unit is being used in the axes group or not. <ul style="list-style-type: none">• FALSE: Not used• TRUE: Used
Io_PosActualValue	Object Data_PosActualValue	Displays a value of object data "Position actual value (6064H)". ☞ Page 60 Object data settings
Io_Statusword	Object Data_Statusword	Displays a value of object data "Statusword (6041H)". ☞ Page 60 Object data settings
Io_TargetPos	Object Data_TargetPos	Displays a value of object data "Target position (607AH)". ☞ Page 60 Object data settings

Real encoder axis data type AXIS_ENCODER members (excluding AxisRef)

■Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
AxisType	Axis Type Setting	Sets the axis type. ☞ Page 57 Axis type
AddressOfStation	Station Address Setting	Via drive unit: Sets the same station address as the real drive axis that the encoder is connected.
Encoder_AxisType	Real Encoder Axis Type Setting	Sets the type of the real encoder axis. • 1: Via drive unit (Drive)
Encoder_CounterDisableSignal	Counter Disabling Signal	Sets the signal to switch to the counter disable. ☞ Page 89 Follow Up

■Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the current axis status. • 0: Axis disabled (Disabled) • 1: Stopping on error (ErrorStop) • 2: Decelerating to stop (Stopping) • 3: During homing (Homing) • 4: Standby (Standstill)
Encoder_CounterDisable	Counter Disabled	Becomes TRUE while disabling the input from the encoder. • FALSE: Counter enabled • TRUE: Counter disabled
Io_Statusword	Object Data_Statusword	Displays the synchronous encoder status emulated by the motion system.
Io_PosActualValue	Object Data_PosActualValue	Displays the input pulse value [encoder pulse unit] acquired from the synchronous encoder.
Io_PosEncoderResolution	Object Data_PosEncoderResolution	Displays the synchronous encoder resolution. Reads the value from the setting location when the drive unit is connected.

Virtual drive axis data type AXIS_VIRTUAL members (excluding AxisRef)

■Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
AxisType	Axis Type Setting	Sets the axis type. ☞ Page 57 Axis type
OperationCycle	Control Cycle Setting	Sets the control operation cycle. ☞ Page 58 Control cycle

■Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the current axis status. • -1: Axis variable uninitialization/Axis parameter error (Invalid) • 0: Axis disabled (Disabled) • 1: Stopping on error (ErrorStop) • 2: Decelerating to stop (Stopping) • 3: During homing (Homing) • 4: Standby (Standstill) • 5: During positioning operation (DiscreteMotion) • 6: During continuous operation (ContinuousMotion) • 7: During synchronous operation (SynchronizedMotion)
Io_TargetPos	Object Data_TargetPos	Displays a value which is converted into the command value in a driver unit from the cumulative current position.

Virtual encoder axis data type AXIS_VIRTUAL_ENCODER members (excluding AxisRef)

■Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
AxisType	Axis Type Setting	Sets the axis type. ☞ Page 57 Axis type
Encoder_CounterDisableSignal	Counter Disabling Signal	Sets the signal to switch to the counter disable. ☞ Page 89 Follow Up
Encoder_RingCout_LowerValue	Encoder Ring Counter Lower Limit Value	Sets the encoder ring counter lower limit value. ■ One-word PosActualValue -32768 to 32767*1 ■ Two-word PosActualValue or omits PosActualValue -2147483648 to 2147483647
Encoder_RingCout_UpperValue	Encoder Ring Counter Upper Limit Value	Sets the encoder ring counter upper limit value. ■ One-word PosActualValue -32768 to 32767*1 ■ Two-word PosActualValue or omits PosActualValue -2147483648 to 2147483647
SlaveObject	Object Data	Sets the object data
PosActualValue	PosActualValue	Sets the data storing synchronous encoder input. • One-word specified: -32768 to 32767 • Two-word specified: -2147483648 to 2147483647

*1 When the out of one-word range value is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.

■Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the current axis status. • 0: Axis disabled (Disabled) • 1: Stopping on error (ErrorStop) • 2: Decelerating to stop (Stopping) • 3: During homing (Homing) • 4: Standby (Standstill)
Encoder_Connected	Connection Status	Displays the virtual encoder axis connection status. • FALSE: Not connected • TRUE: Connected
Encoder_CounterDisable	Counter Disabled	Becomes TRUE while disabling the input from the encoder. • FALSE: Counter enabled • TRUE: Counter disabled
Io_PosActualValue	Object Data_PosActualValue	Displays the value [encoder pulse unit] acquired from the encoder input.
Io_PosEncoderResolution	Object Data_PosEncoderResolution	Displays the synchronous encoder resolution.

■Axis control data (AxisName.Md.)

Variable/Structure name	Name	Details
Encoder_Connect	Connection Command	The signal for enabling the connection status of the virtual encoder axis input. • FALSE: Invalid • TRUE: Valid
Encoder_InputValue	Encoder Input Value	Sets the value sequentially used as the virtual encoder axis input value.

Virtual linked axis data type AXIS_VIRTUAL_LINK members (excluding AxisRef)

■Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
AxisType	Axis Type Setting	Sets the axis type.  Page 57 Axis type
OperationCycle	Control Cycle Setting	Sets the control operation cycle.  Page 58 Control cycle

■Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the current axis status. <ul style="list-style-type: none">• -1: Axis variable uninitialization/Axis parameter error (Invalid)• 0: Axis disabled (Disabled)• 1: Stopping on error (ErrorStop)• 2: Decelerating to stop (Stopping)• 3: During homing (Homing)• 4: Standby (Standstill)• 5: During positioning operation (DiscreteMotion)• 6: During continuous operation (ContinuousMotion)• 7: During synchronous operation (SynchronizedMotion)

Real drive axis

This axis uses a drive unit which is compatible with the CiA402 drive profile connected to CC-Link IE TSN. It is counted as the number of control axes.

Driver control mode transition


A drive unit connected as a real drive axis follows the CiA402 drive protocol, and changes the control mode according to the "Modes of operation" object output from the motion system. The drive unit inputs the current mode as the "Modes of operation display" object in the motion system and displays it in Driver control mode (AxisName.Md.Driver_Mode).

The motion system supports the operations of the following modes. In addition, some control modes are available for some drive units. For details, refer to the following.

☞ Page 759 Driver control mode

Supported control mode	Driver control mode (<u>AxisName</u> .Md.Driver_Mode)	Description	Reference
Homing mode (hm)	6: Homing mode (hm)	Executes homing operation by a driver.	☞ Page 198 Driver homing method
Cyclic synchronous position mode (csp)	8: Cyclic synchronous position mode (csp)	Executes control following the sequential positioning command from the controller in each communication cycle.	☞ Page 294 DIRECT CONTROL
Cyclic synchronous velocity mode (csv)	9: Cyclic synchronous velocity mode (csv)	Executes control following the velocity command from the controller in each communication cycle.	
Cyclic synchronous torque mode (cst)	10: Cyclic synchronous torque mode (cst)	Executes control following the torque command from the controller in each communication cycle.	

The control mode of the drive unit must be "Cyclic synchronous position mode (csp)" when the drive unit is connected. Control mode switching of the driver is executed at the same time when the Motion control FB is executed. The state transition is shown below.



No.	State transition description
(1)	Transits after the axis is stopped by homing completion or error occurrence.
(2)	Transits at stop completion or error occurrence.
(3)	Transits at multiple start of the motion FBs (positioning control FB, etc.) operating in the cyclic synchronous position mode (csp).

Object data setting

The values to be set for each drive unit used are as follows.

■MELSERVO

When using MELSERVO, do not change the initial values.

■Drive unit other than MELSERVO

For the object data setting when using a drive unit other than MELSERVO, refer to the following.

☞ Page 753 Module extended parameter [Motion control setting function]

- Set the value according to the format of the setting value. If the value is not set according to the setting value format, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.

Type	Setting value format	
	Format	Description
[OBJ]* ¹	[OBJ] 0x□□□□**##	Set the index, subindex, and size of the object. <ul style="list-style-type: none">• □□□□: Index• **: Subindex• ##: Size (in bits)
[CONST]* ²	[CONST] <u>Constant</u> [CONST] 0x <u>Constant</u>	Specify <u>Constant</u> as floating decimal (E format is also available)/decimal integer/hexadecimal integer.
Other than above	—	Values other than [OBJ] and [CONST] cannot be set. If set, "Object Data Setting Incorrect" (error code: 1A96) occurs.

*1 If the object data and setting values in the same axis overlap, the intended data cannot be sent or received because the object data and the object cannot be linked. In this case, the function using the object data does not operate properly.

*2 The object data in which [CONST] is set for the data type does not use the value received from the device station by PDO, but operates using the set constant. Also, the set constant is not sent to the device station by PDO.

Precautions

If the axis parameter has an error when the controller power is turned ON with the drive unit connected, the drive unit is connected as the standard station although the axis which has an error is not generated.

If the axis parameter is reviewed to turn the PLC READY from OFF to ON again in this state, the axis is generated, but the drive unit cannot be connected as the axis.

To connect the drive unit as the axis, power on the controller and the drive unit again.

Real encoder axis

This axis generates the current position from the synchronous encoder output pulse connected to the drive unit on CC-Link IE TSN.

This will be used at the "single axis synchronous control".

This axis can control the synchronous encoder shown below as the real encoder axis.

Real encoder axis type	Description
Via drive unit	Uses the following synchronous encoder connected to the drive unit (such as MR-J5(W)-G) corresponding to the scale measurement function as the real encoder axis. <ul style="list-style-type: none"> • HK-KT servo motor encoder • HK-MT servo motor encoder

Point

When using linear encoders and A/B/Z-phase differential output type rotary encoders that are connected to the drive unit, use them for a virtual encoder axis. For details, refer to the following.

☞ Page 49 Virtual encoder axis

Parameter setting items

The following items are required to set up in order to use the real encoder axis.

○: Necessary, △: Optional, ●: Necessary for the same station address real drive axis

Setting item		Real encoder axis type	Reference
		Via drive unit	
Axis No.		○	☞ Page 57 Axis No.
Axis type		○	☞ Page 57 Axis type
Real encoder axis type setting		○	☞ Page 44 Real encoder axis type setting
Station address		○	☞ Page 44 Station address ☞ Page 58 Station address
Absolute position control setting		○	☞ Page 58 Absolute position control setting
Control cycle		○	☞ Page 58 Control cycle
Object data setting	Encoder status 2	●	☞ Page 44 Object data setting ☞ Page 60 Object data settings
	Scale ABS counter	●	
	Scale cycle counter	●	
	Scale measurement encoder resolution	●	
	Scale measurement encoder reception status	●	
Driver unit conversion numerator		○	☞ Page 403 Compensation Function
Driver unit conversion denominator		○	
Position command unit setting		○	
Velocity command unit setting		○	
Command unit string		○	☞ Page 81 Positioning Range
Ring counter enabled selection		○	
Ring counter upper limit value		△	
Ring counter lower limit value		△	
Counter disabling signal		△	☞ Page 89 Follow Up

Real encoder axis type setting

Sets the synchronous encoder type which will be the origin of generating the real encoder axis input value.

Setting value	Description
1: Via Drive Unit (Drive)	Uses the synchronous encoder input value via drive unit connected to the specified drive unit as the synchronous encoder input.

In order to use via drive unit type, set the real drive axis of the same station address and assign the required objects listed below.

☞ Page 44 Object data setting

For details on the real drive axis setting method, refer to the following.

☞ Page 57 Axis Assignment

Station address

Depending on the real encoder axis type, set the following.

Real encoder axis type	Applicable hardware and software to setup as station address
Via drive unit	Drive unit connected with the synchronous encoder

For details on the setting value, refer to the following.

☞ Page 57 Axis Assignment

Object data setting

Depending on the real encoder axis type, set the following.

Real encoder axis type	Setting item	Setting required object	Description ^{*1}
Via drive unit	Real drive axis of the same station address ^{*2}	Encoder status 2	Specify the object ID storing the drive unit scale measurement function setting. <ul style="list-style-type: none"> • bit0: Scale measurement function ABS system correspondent • bit1: Scale measurement function <p>*: Valid when TRUE</p> <p>*: Reads the value from the setting location when connecting to the drive unit. When bit1 is FALSE, "Synchronous Encoder Via Drive Unit Setting Incorrect" (error code: 1A90H) occurs.</p>
		Scale ABS counter ^{*3}	Specify the object ID storing the current synchronous encoder multiple revolution counter. <p>■Setting range Handled as -32768 to 32767.</p>
		Scale cycle counter ^{*3}	Specify the object ID storing the current synchronous encoder position within one revolution. <p>■Setting range 0 to the range specified by the scale measurement encoder resolution.</p>
		Scale measurement encoder resolution	Specify the object ID storing the synchronous encoder resolution. The synchronous encoder with setting value 0 cannot be connected.
		Scale measurement encoder reception status ^{*3}	Specify the object ID storing the alarm information of the scale measurement encoder. <ul style="list-style-type: none"> • Bit0: CPU alarm • Bit1: LED alarm • Bit2: Data alarm • Bit5: Multi-revolution counter alarm • Bit6: ABS erased alarm <p>*: When TRUE, corresponding alarm occurs</p>

^{*1} For details on the setting value, refer to the following.

☞ Page 428 TARGET_REF structure

^{*2} If a setting required object is not assigned in the object data, "Synchronous Encoder Via Drive Unit Setting Incorrect" (error code: 1A90H) occurs.

^{*3} If all of the object data are not assigned to PDO, "Synchronous Encoder Via Drive Unit Setting Incorrect" (error code: 1A90H) occurs.

Required functions to use

The required functions to use the real encoder axis are shown below.


Function		Reference	Axis type specific detailed information
Axis assignment		☞ Page 57 Axis Assignment	—
Technical units		☞ Page 75 Technical Units	—
Compensation function	Driver unit conversion function	☞ Page 403 Compensation Function	—
Absolute position control		☞ Page 94 Absolute Position Control	—
Operation cycle		☞ Page 107 Operation Cycle	—
State transition	Single axis state transition	☞ Page 51 Single axis state transition	—
Follow up (counter enabled/counter disabled)		☞ Page 89 Follow Up	—
Servo ON/OFF		☞ Page 86 Servo ON/OFF	—
Ring counter setting		☞ Page 81 Positioning Range	—
Control change function	Current position change function	☞ Page 338 Current Position Change Function	☞ Page 47 Control change function
Command filter	Smoothing filter	☞ Page 406 Command Filter	—
	Moving direction restriction filter		—

For other functions, refer to each function and check the required object data for the function. If the axis holds the required object data, the function is valid.

State transitions

■Single axis state transition

The real encoder axis (via drive unit) transits to the status shown below.



No.	State transition description
(1)	Transits from any state when an error of the axis occurs.
(2)	<ul style="list-style-type: none"> Transits from any state when Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) is FALSE and no error occurs in the axis. Transits from "4: Standby (Standstill)" when Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) is TRUE, Servo ON request (ServoON) is FALSE, and no error occurs in the axis.
(3)	Transits when the status error is cleared by the error reset command during servo OFF. (The state is the current position restoration not executed when the axis status transits to "0: Axis disabled (Disabled)" because the follow up is not executed in the "1: Stopping on error (ErrorStop)" state.)
(4)	After the real drive axis which is the same station address is connected, transits when Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) is TRUE, Servo ON request (ServoON) is TRUE, and Operable (Status) of MC_Power (Operation Available) is TRUE.
(5)	Transits when Execution completion (Done) of MC_Stop (Forced Stop) is TRUE and Execute command (Execute) of MC_Stop (Forced Stop) is FALSE.
(6)	Transits from any state other than the "1: Stopping on error (ErrorStop)" state when the real drive axis which is the same station address is not to be connected.

Point

- Follow-up is executed during Standby (Standstill) and During homing (Homing).
- Follow-up is disabled during Axis disabled (Disabled), Decelerating to stop (Stopping) and Stopping on error (ErrorStop). For details on the set position when follow-up is disabled, refer to the following.
 📖 Page 91 For real encoder axis/virtual encoder axis
- When receiving encoder alarm information from the real drive axis to which the encoder is connected, "Communication Error of Connected Encoder" (error code: 1AE5H) occurs to disconnect the real encoder axis. Check the real drive axis, clear the error factor, and then reconnect the real drive axis.

Control change function

When starting the current position change control unconditionally, use MC_SetPosition (Current Position Change).

Point

To use the control change function by the real encoder axis, Axis Status (AxisName.Md.AxisStatus) of the real encoder axis is required to be set as "4: Standby (Standstill)" by Servo ON/OFF function.

Setting examples


The setting example of the real encoder axis is shown below.

[Via drive unit]

Depending on the connected drive unit or version, available functions and encoders are restricted. For details, refer to the drive unit manual.

Ex.

To use the real encoder axis1 (MR-J5(W)-G station address 192.168.3.1) scale measurement device as the input of the real encoder axis 2.



Axis setting

Setting item	Axis setting	
	Real drive axis setting	Real encoder axis setting
Axis No.	1	2
Axis type	0: Real Drive Axis (DriveAxis)	2: Real Encoder Axis (EncoderAxis)
Real encoder axis type setting	Unnecessary	1: Via Drive Unit (Drive)
Station address	192.168.3.1	192.168.3.1 (Specify the station address of the drive unit that the synchronous encoder is connected)
Absolute position control setting	-1: Automatic Setting (Acquire from Connected Device) (Auto)	Arbitrary ^{*1}
Control cycle	0: Operate in the first operation cycle	0: Operate in the first operation cycle ^{*2}


^{*1} Set the setting that matches with the setting of the synchronous encoder and drive unit side to be connected. When "-1: Automatic Setting (Acquire from Connected Device) (Auto)" is set, acquires the absolute position system setting from the drive unit side.

^{*2} The data refresh cycle of the synchronous encoder is the control cycle of the connected real drive axis and the axis control may not be executed by each data refresh cycle when it differs with the real encoder axis setting. Thus, It is recommended that the real encoder axis control cycle is set as the same cycle as the connecting real drive axis.


■PDO mapping setting

Regarding the "CC-Link IE TSN Configuration" screen under network configuration setting of GX Works3, set all three objects of the following to the PDO mapping (TxPDO) of the real drive axis 1 (MR-J5(W)-G station address 192.168.3.1).

- Scale cycle counter (Index: 2d36, subindex: 00)
- Scale ABS counter (Index: 2d37, subindex: 00)
- Scale measurement encoder reception status (Index: 2d3c, subindex: 00)



The setting screen of TPDO and RPDO can be switched here.



Add required objects via drive unit.

■Drive unit side (MR-J5(W)-G) setting

To enable the scale measurement function on MR-J5(W)-G, set the parameter below. (For MR-J5W-G, only MR-J5W2-G is supported)

For details on the parameter and connection method of the encoder, refer to the drive unit manual.

No.	Abbreviation	Name	Overview
PA22.3*1	**PCS	Scale measurement function selection	Select scale measurement function. <ul style="list-style-type: none"> • 0: Invalid (initial setting) • 1: Used in absolute position detect system • 2: Used in incremental system

*1 Applicable to MR-J5(W)-G (A5 version) or later

When the applicable real drive axis is not connected, the real encoder axis connection becomes invalid. (It becomes valid by connecting the applicable real drive axis.)

Virtual drive axis

This axis can generate commands virtually in the motion system. A real drive unit is not used. The available commands/functions are partly different from those of the real axis.

Point

Since the virtual drive axis is specialized for generating the position command and it does not simulate a situation that the drive unit is connected, available functions are restricted. For simulating the operation close to the state when the drive unit is connected, use the axis emulation function to the real axis drive. For details, refer to the following.

☞ Page 440 Axis Emulation

Virtual encoder axis

Generates the current position from the values of the motion system variables. Used as an input axis for the single axis synchronous control.

Parameter setting items

The following items are required to set up in order to use the virtual encoder axis.

○: Necessary, △: Optional, —: Unnecessary

Setting item	Virtual encoder axis	Reference
Axis No.	○	☞ Page 57 Axis No.
Axis type	○	☞ Page 57 Axis type
Station address	—	—
Absolute position control setting	○	☞ Page 58 Absolute position control setting
Control cycle	○	☞ Page 58 Control cycle
Object data setting	PosActualValue	△
Driver unit conversion numerator	○	☞ Page 403 Compensation Function
Driver unit conversion denominator	○	
Position command unit setting	○	☞ Page 75 Technical Units
Velocity command unit setting	○	
Command unit string	○	
Ring counter enabled selection	○	☞ Page 81 Positioning Range
Ring counter upper limit value	△	
Ring counter lower limit value	△	
Encoder ring counter upper limit value	○	☞ Page 50 Encoder ring counter upper limit value/ lower limit value
Encoder ring counter lower limit value	○	
Counter disabling signal	△	☞ Page 89 Follow Up

Object data setting

Set the following.

Object required setting	Description
PosActualValue	<p>Set the string format data used as the encoder input value.*1</p> <ul style="list-style-type: none"> The settable types are only [VAR], [DEV] and [CONST]. If the setting value is not within the valid range, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs. When [VAR] type is set, specify the data type to be (INT), (DINT), (WORD) or (DWORD) data. If the data type is other than the above, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs. When [DEV] or [CONST] type is set, specify the data type to be (INT), (DINT), (WORD) or (DWORD). If the data type is not specified nor the data type is other than the above, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs. When [VAR] type is used, do not specify the local label. Use "Encoder Input Value (AxisName.Cd.Encoder_InputValue)" as the encoder input value when omitted. Set the encoder input value sequentially by encoder pulse unit.

*1 For details on the setting value, refer to the following.

☞ Page 428 TARGET_REF structure

Encoder ring counter upper limit value/lower limit value

Sets the upper limit value and lower limit value of the encoder input value.

Set the encoder ring counter lower limit value and encoder ring counter upper limit value corresponds to the lower limit value/upper limit value of the encoder input value. If the range of the encoder input value and "the encoder ring counter lower limit value to the encoder ring counter upper limit value" differ, the encoder input value will not be read correctly.

If "the encoder ring counter upper limit value = encoder ring counter lower limit value is set", the encoder input value is processed as the 32-bit counter of "-2147483648 to 2147483647" or as the 16-bit counter of "-32768 to 32767".

If the encoder ring counter lower limit value > the encoder ring counter upper limit value, "Out of Encoder Ring Counter Setting Range" (error code: 1AE1H) occurs.

Point

- For the encoder input value, set the cycle counter of "the encoder ring counter lower limit value ≤ the encoder input value ≤ the encoder ring counter upper limit value" as the input value. If the encoder input value is out of the above range, the encoder input value will not be read.
- Set the encoder input value that one operation cycle movement amount meets the following equation. If it does not meet, the actual input movement amount and the movement amount counted by the motion system may not match.

$$\text{One operation cycle movement amount} < \frac{|\text{the encoder ring counter upper limit value} - \text{the encoder ring counter lower limit value} + 1|}{2}$$

- If the encoder input value is out of range of "the encoder ring counter lower limit value to the encoder ring counter upper limit value" when it is connected to the encoder, the encoder current value will restore as below.
 - Absolute position system: Restore to the backup data value
 - Incremental system: Clamp by the encoder ring counter upper limit value/lower limit value

Required setting to use

The required functions to use the virtual encoder axis are shown below.

Function		Reference	Axis type specific detailed information
Axis assignment		Page 57 Axis Assignment	—
Technical units		Page 75 Technical Units	—
Compensation function	Driver unit conversion function	Page 403 Compensation Function	—
Absolute position control		Page 94 Absolute Position Control	—
Operation cycle		Page 107 Operation Cycle	—
State transition	Single axis state transition	Page 51 Single axis state transition	Page 46 State transitions
Follow up (counter enabled/counter disabled)		Page 89 Follow Up	—
Ring counter setting		Page 81 Positioning Range	—
Control change function	Current position change function	Page 338 Current Position Change Function	Page 47 Control change function
Command filter	Smoothing filter	Page 406 Command Filter	—
	Moving direction restriction filter		—


For other functions, refer to each function, check the required object data for the function. If the axis holds the required object data, the function is valid.

State transition

■Single axis state transition

The virtual encoder axis transits to the following state.

-----▶ : Automatic transition
 —————▶ : Event transition



No.	State transition description
(1)	Transits from any state when an error of the axis occurs.
(2)	<ul style="list-style-type: none"> Transits from any state when Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) is FALSE and no error occurs in the axis. Transits from "4: Standby (Standstill)" when Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) is TRUE, Servo ON request (ServoON) is FALSE, and no error occurs in the axis.
(3)	Transits when the status error is cleared by the error reset command during servo OFF.
(4)	Transits when the status error is cleared by the error reset command during servo ON.
(5)	After Connection Command (<u>AxisName</u> .Cd.Encoder_Connect) is set to TRUE, transits when Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) is TRUE, Servo ON request (ServoON) is TRUE, and Operable (Status) of MC_Power (Operation Available) is TRUE.
(6)	Transits when Execution completion (Done) of MC_Stop (Forced Stop) is TRUE and Execute command (Execute) of MC_Stop (Forced Stop) is FALSE.
(7)	Transits from any state other than the "1: Stopping on error (ErrorStop)" state when Connection Command (<u>AxisName</u> .Cd.Encoder_Connect) is FALSE.

Point

- Follow-up is performed during Standby (Standstill) and During homing (Homing).
- Follow-up is disabled during Axis disabled (Disabled), Decelerating to stop (Stopping) and Stopping on error (ErrorStop). For details on the set position when follow-up is disabled, refer to the following.

📖 Page 91 For real encoder axis/virtual encoder axis

Control change function

When starting the current position change control unconditionally, use the MC_SetPosition (Current Position Change).

Restriction

The encoder input value will be read by every virtual encoder axis control cycle. When the encoder input value update cycle is slow, the velocity change increases. Use the smoothing filter to smooth the velocity change.

Setting example


The setting example of the virtual encoder axis and the method of use are shown below.

■When using the encoder value of the gray code encoder connected to the input module

Ex.

When the axis 4 is used as the virtual encoder axis

(The encoder value of gray code encoder (resolution: 4096 [pulse/rev]) connected to the input module is used to control)



• Axis setting

Setting items	Setting value
AxisNo.	4
AxisType	4: Virtual Encoder Axis (VirtualEncoderAxis)
Absolute position control setting	0: Disable Absolute Position System (ABSDisabled)
Encoder ring counter upper limit value	4095
Encoder ring counter lower limit value	0
Slave object data_PosActualValue	[DEV](DINT)G11478000

• How to use virtual encoder axis

1. Set Command (AxisName.Cd.Encoder_Connect) to TRUE.
2. Check Current Position Restoration Status (AxisName.Md.PosRestoration_Status) is "2: Restoration Completed in Incremental System (RestoredInIncSystem)", and Connection Status (AxisName.Md.Encoder_Connected) is TRUE.
3. Set Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) and Servo ON request (ServoON) to TRUE.
4. Check Axis Status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)".
5. Read the encoder value of the gray code encoder by program, update the device setup on PosActualValue with object data setting sequentially. (The virtual encoder axis will be controlled based on the change amount of PosActualValue.)


■When using the encoder value of a scale measurement encoder connected with the drive unit

Ex.

When the axis 4 is used as the virtual encoder axis

(The encoder value of A/B/Z-phase differential output type rotary encoder (incremental type) (resolution: 5000 [pulse/rev]) is used to control)


The axis to which the scale measurement encoder is connected (axis 1) is used as the real drive axis.




• PDO mapping setting

In the "CC-Link IE TSN Configuration" screen under Network Configuration Settings in GX Works3, set the following objects to the PDO mapping (TxPDO) for the real drive axis 1 (MR-J5(W)-G station address "192.168.3.1").

- Scale cycle counter (Index: 2d36, Sub-index: 00)
- Scale measurement encoder reception status (Index: 2d3c, Sub-index: 00)



Switch between the setting screen of TPDO and RPDO here. Select TPDO.



Add the required objects via drive unit.

- Network I/O setting

In the "Network I/O" screen under Motion Control Setting Function in GX Works3, set the following slave labels.

- Scale cycle counter (Index: 2d36, Sub-index: 00)
- Scale measurement encoder reception status (Index: 2d3c, Sub-index: 00)

Select Network I/O.

Insert checks in Labeling Target.

Click the [Create Label] button.

- Drive unit side (MR-J5(W)-G) setting

To enable the scale measurement function on MR-J5(W)-G, set the parameters below.

For details on the parameters and connection method of the encoder, refer to the drive unit manual.

No.	Symbol	Name	Overview
PA22.3 ^{*1}	**PCS	Scale measurement function selection	Select scale measurement function. <ul style="list-style-type: none"> • 0: Disabled (initial setting) • 1: Use with absolute position detection system • 2: Use with incremental system
PE51 ^{*2}	**EDV2	Load-side encoder resolution setting	Set "0". When using A/B/Z-phase differential output type rotary encoders, if a value other than "0" is set, Scale cycle counter may change rapidly.

*1 Supported by MR-J5(W)-G (version A5) or later

*2 Supported by MR-J5(W)-G (version B2) or later

Point

If the "Load-side encoder resolution setting (PE51)" servo parameter is set to a value other than "0" when using A/B/Z-phase differential output type rotary encoders, Scale cycle counter may be disabled or change rapidly due to the following factors.

- When the Z-phase is passed for the first time
- If an incorrect encoder resolution is set to "Load-side encoder resolution setting (PE51)"
- If A/B/Z-phase differential output type rotary encoders are disconnected

- Axis setting

Setting items	Setting value	
	Real drive axis	Virtual encoder axis
Axis No.	1	4
Axis type	0: Real Drive Axis (DriveAxis)	4: Virtual Encoder Axis (VirtualEncoderAxis)
Station address	192.168.3.1	Unnecessary
Encoder ring counter upper limit value*1	Unnecessary	0
Encoder ring counter lower limit value*1	Unnecessary	0
Absolute position control setting	-1: Automatic Setting (Acquire from Connected Device) (Auto)	0: Disable Absolute Position System (ABSDisabled)
Control cycle	0: Operate in the first operation cycle	0: Operate in the first operation cycle
Object data_PosActualValue	Unnecessary	[VAR](DWORD)MR_J5_G_RJ_001_ScaleCycleCounter

*1 Set the value within the range of Scale cycle counter.

When the range of Scale cycle counter is "0 to 4294967295", the axis can be used by setting "Encoder ring counter upper limit value = Encoder ring counter lower limit value".

<Example>

Encoder ring counter upper limit value and Encoder ring counter lower limit value are set to "0" so that the range of Scale cycle counter becomes "0 to 4294967295".

- How to use virtual encoder axis

1. Set Enable (Enable) of MC_Power (Operation Available)/MCv_AllPower (All Axes Operation Available) and Servo ON request (ServoON) to TRUE.
2. Check that Driver Status (AxisName.Md.Driver_State) of the real drive axis (Axis 1) with a scale measurement encoder connected is "6: Operation Enable".
3. Set Connection Command (AxisName.Cd.Encoder_Connect) of the virtual encoder axis (Axis 4) to TRUE.
4. Check that Current Position Restoration Status (AxisName.Md.PosRestoration_Status) of the virtual encoder axis (Axis 4) is "2: Restoration Completed in Incremental System (RestoredInIncSystem)", and Connection Status (AxisName.Md.Encoder_Connected) is TRUE.
5. Check that Axis Status (AxisName.Md.AxisStatus) of the virtual encoder axis (Axis 4) is "4: Standby (Standstill)". (The virtual encoder axis will be controlled according to the encoder value of the scale measurement encoder.)

Point

The virtual encoder axis will continue to be controlled even when an alarm occurs on the scale measurement encoder.

To stop controlling the virtual encoder axis, set Connection Command (AxisName.Cd.Encoder_Connect) of the virtual encoder axis (Axis 4) to FALSE when the value of MR_J5_G_RJ_001_ScaleMeasurementEncoderReceptionStatus becomes "other than 0 (an encoder alarm occurs)".

Virtual linked axis

This axis connects FBs of single axis synchronous control. Since the minimum data for FB connection is defined, the processing load is reduced compared to the FB connection using a virtual drive axis, etc.

Without axis assignment in the engineering tool, an axis can be temporarily generated during program execution by only declaring the instance of the AXIS_REF structure in the local label. In this case, the motion system discards the axis data generated temporarily when the PLC READY is turned ON to OFF. (If axis assignment is executed in the engineering tool, the axis data will be maintained even after the PLC READY is turned ON to OFF.)

How to generate an axis

Set it according to axis assignment. For the axis assignment method, refer to the following.

 Page 57 Axis Assignment

Precautions

- Software stroke limit cannot be set in the virtual linked axis. When virtual linked axes are used to connect between each user program of single axis synchronous control, set the software stroke limit in the end axis of connected single axis synchronous control.
- When temporarily generated axis is started, it will take longer than the usual to start the axis because the axis variables are generated in the motion service processing.

1.3 Axis Assignment

Axes are generated/initialized by setting axis settings on the axis setting window in the engineering tool. The axes set on the axis setting window are assigned to the global label as axis variables. For the setting method, refer to Help of the engineering tool.

Operation of this function for each system status

○: Possible, ×: Not possible

System status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	×

Setting items

The items set to the axis type are shown below.

○: Necessary, —: Unnecessary

Axis type	Setting items					
	Axis name	Axis No.	Axis type	Station address	Absolute position control setting	Control cycle
Real drive axis	○	○	○	○	○	○
Real encoder axis	○	○	○	○	○	○
Virtual drive axis	○	○	○	—	○	○
Virtual encoder axis	○	○	○	—	○	○
Virtual linked axis	○	○	○	—	○	○

■Axis name

Set an arbitrarily axis name of the applicable axes within 127 characters.

An instance is generated as the set axis name.

■Axis No.

Axis No. is an identifier to control in the motion system.

If the same No. is set in the multiple axes, "Axis No. Setting Duplication Error" (error code: 1A91H) will occur.

Axis setting	Axis No.
User specification	1 to 10000
Virtual linked axis generated automatically	20001 to 30000

■Axis type

Specify an axis type of the axis.

Axis type	Setting value
Real drive axis	0: DriveAxis
Real encoder axis	2: EncoderAxis
Virtual drive axis	3: VirtualDriveAxis
Virtual encoder axis	4: VirtualEncoderAxis
Virtual linked axis	5: VirtualLinkAxis

The data type that an axis variable can take differs depending on the axis type.

For details on data types of each axis type, refer to the following.


📖 Page 32 Data type

■Station address

- Specify the station address (IP address) of the target device to connect a network device as a real axis. Also, specify the axis ID (multidrop No.) for connecting a device which can control multiple axes with one device (multiple axes device).

Ex.

When specifying the C-axis of a multiple axes device (MR-J5W-G)



- *1 The multidrop No. is specified as "# + No. (decimal format)". When omitted, it is regarded as "#0".
- #0: A-axis
 - #1: B-axis
 - #2: C-axis
- When a station address of a device that cannot be a real axis is specified, "SLMP Communication Error" (error code: 1C43H) or "Station Address Setting Incorrect" (error code: 1A95H) occurs. (Example: When a station address of an I/O unit is specified)
 - These settings are unnecessary to the virtual axis.
 - For the station address, specify the same format as "Target modification (character string starts with @)" of TARGET_REF structure. For details on the TARGET_REF structure, refer to the following.
 Page 428 TARGET_REF structure
 - Even though the station address have not been set ("") in the real axis, by setting Axis Emulation Enabled (AxisName.PrConst.SlaveEmulate_Enable) to TRUE, it enables to use as the axis emulate function. If axis emulate function is not used, "Station Address Setting Incorrect" (error code: 1A95H) occurs and the axis will not be ready for operation.

■Absolute position control setting

Specify whether applicable axes are used as the absolute position system or not. For details, refer to the following.

 Page 94 Absolute Position Control

■Control cycle

Specify which operation cycle is used for the applicable axis to control. For details, refer to the following.

When the specified operation cycle does not support axis control, "Cycle Assignment Incorrect (Axis)" (error code: 1AF9H) occurs.

 Page 107 Operation Cycle

The following shows the communication cycles that can be specified as the control cycle of an axis.

Add-on Axis version	Communication cycle
Earlier than "1.31"	31.25μs, 62.5μs, 125μs, 250μs, 500μs, 1.0ms, 2.0ms, 4.0ms, 8.0ms
"1.31" or later	31.25μs, 62.5μs, 125μs, 250μs, 500μs, 1.0ms, 1.5ms, 2.0ms, 2.5ms, 3.0ms, 3.5ms, 4.0ms, 4.5ms, 5.0ms, 5.5ms, 6.0ms, 6.5ms, 7.0ms, 7.5ms, 8.0ms

When setting the communication cycle to a value other than " 31.25×2^n [μs]", set it in "Communication Period Interval Setting (Set it in units of 1μs)" under "Basic Settings" of Module Parameter (Network).

For the setting method, refer to "Communication Period Setting" of the following manual.

 MELSEC iQ-R Motion Module User's Manual (Network)

<When using MR-J5(W)-G series>

To check whether communication cycles other than " 31.25×2^n [μs]" are supported, refer to the manual of your drive unit.

Relevant variables

AxisName in the following table indicates the instance name of the structure type for each axis type.

- **AXIS_REAL**: Real drive axis
- **AXIS_ENCODER**: Real encoder axis
- **AXIS_VIRTUAL**: Virtual drive axis
- **AXIS_VIRTUAL_ENCODER**: Virtual encoder axis
- **AXIS_VIRTUAL_LINK**: Virtual linked axis


Axis information (AxisName.AxisRef.)

Variable/Structure name	Name	Details
AxisNo	Axis No.	Sets the axis No. • 0: Not set • 1 to 10000: Setting axis No.

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
AxisType	Axis Type Setting	Sets the axis type. • 0: Real Drive Axis (DriveAxis) • 2: Real Encoder Axis (EncoderAxis) • 3: Virtual Drive Axis (VirtualDriveAxis) • 4: Virtual Encoder Axis (VirtualEncoderAxis) • 5: Virtual Linked Axis (VirtualLinkAxis)
AddressOfStation	Station Address Setting	Sets network address of the device station with a character string.
PosRestoration_AbsPosEnable	Absolute Position Control Setting	Sets the absolute position control setting. • 0: Disable Absolute Position System (ABSDisabled) • 1: Enable Absolute Position System (Enabled) • -1: Automatic Setting (Acquire from Connected Device) (Auto)
OperationCycle	Control Cycle Setting	Sets Control cycle setting. For details, refer to the following. ☞ Page 107 Operation Cycle
SlaveObject	Object Data	Sets the object of the device station. *: Availability depends on the axis type. For details, refer to the following. ☞ Page 37 Axis Type

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisName	Axis Name	Displays the axis name.
Io_PosActualValue	Object Data_PosActualValue	Displays a value of object data "Position actual value (6064H)".
Io_PosEncoderResolution	Object Data_PosEncoderResolution	Displays a value of object data "Position encoder resolution (608FH)".
Io_Statusword	Object Data_Statusword	Displays a value of object data "Statusword (6041H)".
Io_TargetPos	Object Data_TargetPos	Displays a value of object data "Target position (607AH)".
Drive_RPDO[1..64]	RPDO (Motion System → Device Station) Mapping	Displays the object index specified to the nth place in the RDPO/TPDO mapping settings of the network parameter.  <ul style="list-style-type: none"> • The object size displays 1 byte, 2 bytes, 4 bytes, and 8 bytes in bits. • When the size of the nth object is 1 byte, a padding object is inserted in the nth+1 place.
Drive_TPDO[1..64]	TPDO (Device Station → Motion System) Mapping	

Object data settings

In the motion system, the data that sends/receives information to/from the connected device in the motion operation processing is called an object data. With object data settings, the motion system can be customized to adjust to the device station by setting the data related to the device station to the object data.

For one object data, set as the following.

Setting item	Setting value
Each object data name	<p>Specifies the target data to set. Usable data differs depending on the axis type. For details, refer to the following.</p> <p>☞ Page 37 Axis Type</p> <p>For details on the format to specify the data, refer to the following.</p> <p>☞ Page 428 TARGET_REF structure</p> <p>*: For mapping availability to cyclic data when using [OBJ], refer to the following.</p> <p>☞ Page 62 Object data list</p> <p>*: For target modification availability, refer to the following.</p> <ul style="list-style-type: none"> · Real encoder axis (☞ Page 44 Object data setting) · Virtual encoder axis (☞ Page 49 Object data setting)

- If unavailable data is set, "Mapping Communication Error" (error code: 1A5FH) will occur at the axis variable initialization.
- There are object data whose settings are necessary depending on the axis type. A valid setting value other than "no setting" must be set to the applicable object data. (If the setting is illegal, "Object Data Setting Incorrect" (error code: 1A96H) will occur at the axis variable initialization.)
- For object data whose settings are necessary, refer to the following.
 - ☞ Page 62 Object data list
- When "no setting" is set to the object data setting, functions that need the applicable object data cannot be used. For details, refer to the following.
 - ☞ Page 65 Motion system function and object data
- Data and information of the setting location are sent/received based on the data type of each object data in the motion operation processing.

Access	Data size	Description of the motion operation processing
R: Device → Motion system	(Object data) < (Setting location data)	Converts the setting location data to data size of an object data and imports it. Exceeded upper bit information is discarded.
	(Setting location data) ≤ (Object data)	Converts the setting location data to data type of the object data and imports it.
W: Motion system → Device	(Setting location data) < (Object data)	Stores an object data value as it is to the setting location data. After it is stored, shorted upper bit does not change before and after refreshing.
	(Object data) ≤ (Setting location data)	Converts a value to data size of the setting location data and stores it. Exceeded upper bit information is discarded.

PDO mapping settings

Data (object) that sent/received between the controller and the device in cyclic communication (PDO communication) must be mapped in advance in order to control each function in the real drive axis.

For details on PDO mapping settings, refer to "Cyclic Transmission" in the following manual.

 MELSEC iQ-R Motion Module User's Manual (Network)

Mapping is required for some objects to be connected as real drive axes in the motion system. The following objects must be mapped. (If those are not mapped, "Necessary Object Data Unset" (error code: 1AA8H) will occur.)

Mapping	Mapping required object data
Output (RPDO)	Controlword (6040H)
	Target position (607AH)
	Modes of operation (6060H)
Input (TPDO)	Statusword (6041H)
	Position actual value (6064H)
	Modes of operation display (6061H)

Setting procedure

This section describes the procedure to newly set a real drive axis by using the engineering tool.

1. Add device station settings to the network setting, and set IP address and PDO map information.
2. Select adding axis in the axis setting of the motion system, and set axis information.
3. Double-click the set axis and set the axis parameters.
4. Select the object data setting, and assign object data.
5. Write the parameters in the motion system.

Memory usage

The memory usage differs depending on the axis types. Specify the memory capacity of the axis data according to the axis type and the number of the axis to be used.

The memory usage of each axis type is shown below and these indicate the usage of every axis.

Axis type	Memory usage [k bytes/axis]
Real drive axis	160
Real encoder axis	40
Virtual drive axis	60
Virtual encoder axis	40
Virtual linked axis	40

The memory capacity for axis data is specified by Maximum RAM Size (System.PrConst.Addon_Axis.RamSizeMax).

When the axis data memory usage exceeds the capacity at initializing the axis variable, "Axis Data Memory Size Over" (error code: 1A5DH) occurs and the axis is not generated. Check the memory capacity and execute the software reboot.

Check the memory capacity of the following add-on library as needed.

- MotionEngine
- NetworkDriver_CCIETSN^{*1}
- ServoDriver_CANopen^{*1}
- SignalIO^{*2}
- ExternalSignal^{*2}

^{*1} For using real drive axis

^{*2} For using external signal

Object data list

The following shows attributes of slave objects.

Attribute	Description
PDO mapping	<p>Indicates whether the mapping to cyclic communication of the object is enabled or not when specifying [OBJ].</p> <ul style="list-style-type: none"> • No: Mapping to TxPDO and RxPDO is not required. • TxPDO: Mapping to TxPDO is enabled. • RxPDO: Mapping to RxPDO is enabled. <p>■Real drive axis and real encoder axis</p> <p>Indicates the relationship between the motion system and device station access.</p> <ul style="list-style-type: none"> • No: Even mapping allows the motion system to access data non-periodically. • TxPDO: Mapping allows the motion system to read data from the device station at regular intervals. • RxPDO: Mapping allows the motion system to write data from the device station at regular intervals.
Default	Indicates the default value of the object data for the real drive axis.

The object data lists are shown below.

Whether the object data is available in each axis type or not is as shown below depending on the object data setting and the PDO mapping setting.

- : Setting possible... It can be set in the object data setting of the engineering tool. For an object data whose PDO mapping attribute is TxPDO or RxPDO in the real drive axis, be sure to set the setting value of the object data setting to the PDO mapping setting. When the setting is valid, the axis holds the applicable object data.
- ×: Setting not possible... It cannot be set in the object data setting of the engineering tool. The axis does not hold the applicable object data.
- : Unnecessary... It cannot be set in the object data setting of the engineering tool. However, since it is emulated in the motion system, the axis holds the applicable object data.

Object data name*1	PDO mapping	Default	Description	Slave object name				
				Real drive axis	Real Encoder axis*2	Virtual drive axis	Virtual Encoder axis	Virtual linked axis
Supported drive modes	No	65020020	Gets the control mode supported by the drive unit.	○	×	×	×	×
Modes of operation	RxPDO	60600008	Requires switching the control mode to the drive unit.	○	×	×	×	×
Modes of operation display	TxPDO	60610008	Gets the drive unit control mode.	○	×	×	×	×
Controlword	RxPDO	60400010	Requires switching the status to the drive unit.	○	×	×	×	×
Control DI 1	RxPDO	2D010010	Sets the input device in drive unit.	○	×	×	×	×
Control DI 2	RxPDO	2D020010		○	×	×	×	×
Control DI 3	RxPDO	2D030010		○	×	×	×	×
Control DI 4	RxPDO	2D040010		○	×	×	×	×
Control DI 5	RxPDO	2D050010		○	×	×	×	×
Control DI 6	No	2D060010		○	×	×	×	×
Control DI 7	No	2D070010		○	×	×	×	×
Statusword	TxPDO	60410010	Gets the status of the drive unit.	○	×	×	×	×
Status DO 1	TxPDO	2D110010	Sets the output device in drive unit.	○	×	×	×	×
Status DO 2	TxPDO	2D120010		○	×	×	×	×
Status DO 3	TxPDO	2D130010		○	×	×	×	×
Status DO 4	TxPDO	2D140010		○	×	×	×	×
Status DO 5	TxPDO	2D150010		○	×	×	×	×
Status DO 6	No	2D160010		○	×	×	×	×
Status DO 7	No	2D170010		○	×	×	×	×
Target position	RxPDO	607A0020	The command position to output to the drive unit.	○	×	—	×	×
Target velocity	RxPDO	60FF0020	The set velocity to output to the drive unit.	○	×	×	×	×
Target torque	RxPDO	60710010	The command torque to output to the drive unit.	○	×	×	×	×
Positive torque limit value	RxPDO	60E00010	Sets positive direction torque limit value in the drive unit.	○	×	×	×	×

Object data name ^{*1}	PDO mapping	Default	Description	Slave object name				
				Real drive axis	Real Encoder axis ^{*2}	Virtual drive axis	Virtual Encoder axis	Virtual linked axis
Negative torque limit value	RxPDO	60E10010	Sets negative direction torque limit value in the drive unit.	○	×	×	×	×
Position actual value	TxPDO	60640020	The current value of the drive unit.	○	—	—	○	×
Velocity actual value	TxPDO	606C0020	The current speed of the drive unit.	○	×	×	×	×
Following error actual value	TxPDO	60F40020	The droop pulse of the drive unit.	○	×	×	×	×
Torque actual value	TxPDO	60770010	The current torque of the drive unit.	○	×	×	×	×
Polarity	No	607E0008	Sets the rotation direction selection of drive unit.	○	×	×	×	×
Position encoder resolution	No	608F0008	Returns the total number of Sub Index (=2).	○	×	×	×	×
Encoder increments	No	608F0120	Gets the encoder resolution of drive unit.	○	×	×	×	×
Motor revolutions (Position encoder resolution)	No	608F0220	Gets the motor speed of the drive unit.	○	×	×	×	×
Motor revolutions (Gear ratio)	No	60910120	Sets the servo motor axis rotation number (numerator) of the drive unit.	○	×	×	×	×
Shaft revolutions	No	60910220	Sets the number of drive axis rotations (denominator) of the drive unit.	○	×	×	×	×
SI unit position	No	60A80020	Gets the SI unit position of the drive unit.	○	×	×	×	×
SI unit velocity	No	60A90020	Gets the SI unit velocity of the drive unit.	○	×	×	×	×
Max motor speed	No	60800020	Gets the maximum speed of the servo motor from the drive unit.	○	×	×	×	×
Max torque	No	60720010	Gets the maximum torque of the servo motor from the drive unit.	○	×	×	×	×
Watch dog counter DL	RxPDO	1D010110	Notifies the watch dog counter value to the drive unit.	○	×	×	×	×
Watch dog counter UL	TxPDO	1D020110	Gets the watch dog counter value to the drive unit.	○	×	×	×	×
Supported Control DI 1	No	2D000110	Gets the input device supported by the drive unit.	○	×	×	×	×
Supported Control DI 2	No	2D000210		○	×	×	×	×
Supported Control DI 3	No	2D000310		○	×	×	×	×
Supported Control DI 4	No	2D000410		○	×	×	×	×
Supported Control DI 5	No	2D000510		○	×	×	×	×
Supported Control DI 6	No	2D000610		○	×	×	×	×
Supported Control DI 7	No	2D000710		○	×	×	×	×

Object data name ^{*1}	PDO mapping	Default	Description	Slave object name				
				Real drive axis	Real Encoder axis ^{*2}	Virtual drive axis	Virtual Encoder axis	Virtual linked axis
Supported Status DO 1	No	2D100110	Gets the output device supported by the drive unit.	○	×	×	×	×
Supported Status DO 2	No	2D100210		○	×	×	×	×
Supported Status DO 3	No	2D100310		○	×	×	×	×
Supported Status DO 4	No	2D100410		○	×	×	×	×
Supported Status DO 5	No	2D100510		○	×	×	×	×
Supported Status DO 6	No	2D100610		○	×	×	×	×
Supported Status DO 7	No	2D100710		○	×	×	×	×
Home offset	No	607C0020	Sets the difference between zero position and homing position of the machine coordinate system in the drive unit.	○	×	×	×	×
Home cycle counter	No	2D3D0020	Gets the encoder position within one revolution saved as the home position from the drive unit.	○	×	×	×	×
Home ABS counter	No	2D3E0010	Gets the encoder multiple revolution counter saved as the home position from the drive unit.	○	×	×	×	×
Initial position	No	2D3F0020	Gets the current position at power-on from the drive unit.	○	×	×	×	×
Initial cycle counter	No	2D400020	Gets the encoder position within one revolution at power-on from the drive unit.	○	×	×	×	×
Initial ABS counter	No	2D410010	Gets the encoder multiple revolution counter at power-on from the drive unit.	○	×	×	×	×
Max ABS counter	No	2D420020	Gets the maximum value of the encoder multiple revolution counter from the drive unit.	○	×	×	×	×
Velocity limit value	RxPDO	2D200020	Sets the velocity limit value in the drive unit.	○	×	×	×	×
Encoder status 1	No	2D350120	Gets the encoder status from the drive unit.	○	×	×	×	×
Encoder status 2	No	2D350220	Gets the scale measurement encoder status from the drive unit.	○	×	×	×	×
Scale measurement encoder resolution	No	2D380020	Gets the scale measurement encoder resolution from the drive unit.	○	×	×	×	×
Current alarm	TxPDO	2A410020	Gets the occurring alarm from the drive unit.	○	×	×	×	×
Sync ABS counter	TxPDO	2D220010	Gets the encoder multiple revolution counter from the drive unit.	○	×	×	×	×
Sync cycle counter	TxPDO	2D210020	Gets the encoder position within one revolution from the drive unit.	○	×	×	×	×
Scale measurement encoder reception status	No	2D3C0020	Gets the alarm data of the scale measurement encoder from the drive unit.	○	×	×	×	×
Scale cycle counter	No	2D360020	Gets the position within one revolution of the scale measurement encoder from the drive unit.	○	×	×	×	×
Scale ABS counter	No	2D370020	Gets the multiple revolution counter of the scale measurement encoder from the drive unit.	○	×	×	×	×
Target pressure	RxPDO	2E500020	Set pressure output to the drive unit	○	×	×	×	×
Pressure actual value	TxPDO	2E520020	Current pressure of the drive unit	○	×	×	×	×

Object data name*1	PDO mapping	Default	Description	Slave object name				
				Real drive axis	Real Encoder axis*2	Virtual drive axis	Virtual Encoder axis	Virtual linked axis
Forward-side stop function	RxPDO	2E560020	Forward-side position output to the drive unit	○	×	×	×	×

*1 For the object data with matching names, the object name associated with the Index is shown in "()".

*2 For the object data name of the real encoder axis, refer to the following.

☞ Page 43 Real encoder axis

Point

- If a value larger than DataType is set in the object data, the upper bits equal to or more than DataType are rounded down and converted into the same size as DataType.
- If the data type [OBJ] is set, an object whose DataType is "INTEGER8, 16, 32" or "UNSIGNED8, 16, 32" can be set. If an object whose DataType is other than the above is set, the intended data cannot be sent and received, and the function that uses the object data cannot be operated properly. Also, if a size other than 8bits, 16bits, or 32bits is set to DataType of the setting value, "Object Data Setting Incorrect" (error code: 1A96H) occurs.

Motion system function and object data

When no object data is set to the axis or mapped to PDO, some functions are subject to errors or specification restrictions. Refer to each function for details.

Precautions

- The motion system does not perform the limit check of the command, issue the forced stop command, or reset an error for MR-J5(W)-G to which an axis is not assigned. Carry out safety measures at the user's program or MR-J5(W)-G side.
- When including a drive unit to which an axis is not assigned in axes to be measured by using the MR Configurator2 graph function, specify a drive unit to which an axis is assigned as the trigger axis. Also, generate a slave label and add the fixed cycle execution program (cycle: operation cycle) as shown below. If a drive unit to which an axis is not assigned is specified as the trigger axis, or if the following program is not added, waveform data measurement cannot be completed even if the trigger condition is satisfied.

■Slave label

Drive unit to be measured	Object to be used	Slave label name example
Drive unit specified as the trigger axis	Status DO 4	MR_J5_G_001_StatusDO4
Drive unit to which any axes other than the trigger axis are not assigned	Control DI 4	MR_J5_G_002_ControlDI4 MR_J5_G_003_ControlDI4
Drive unit to which any axes other than the trigger axis are assigned	None	

■Fixed cycle execution program

ST program

```
// MR Configurator2 multiple axes graph measurement
MR_J5_G_002_ControlDI4.c := MR_J5_G_001_StatusDO4.c;
MR_J5_G_003_ControlDI4.c := MR_J5_G_001_StatusDO4.c;
```

Relevant add-ons

The following add-on is required to use this function.

- Axis

System memory capacity

For details, refer to the following.

☞ Page 61 Memory usage

1.4 Axes Group

Axes group is used for multiple axes control such as linear interpolation control and circular interpolation control, etc. The maximum setting number of axes groups depends on the memory. If an axes group cannot be set for memory shortage, "Maximum Number of Registrations for Axes Group Over" (error code: 1A60H) will occur. The maximum number of configuration axes of the axes group to be registered is 16.

Operation of this function for each system status

○: Possible, △: Possible (restricted), ×: Not possible

System status	Operation availability
STOP	△ (Only monitoring is available. When the axes group status is Standby, the axes group is disabled.)
RUN	○
Moderate error	△ (Operation may not be possible according to the error status.)*1
Major error	×

*1 When a required add-on is stopped due to "Add-on Library Load Error" (error code: 3205H) or "Insufficient Add-on System Memory (RAM)" (error code: 3209H), operation will not be possible.

Relevant variables

Axes group information (AxesGroupName.AxesGroupRef.)

Variable/Structure name	Name	Details
GroupNo	Axes Group No.	Sets axes group No. in the motion system. <ul style="list-style-type: none">• 0: Not set• 1 and later: Setting axes group No.

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
Axis[1..16]	Configuration Axis	Sets Axis No. (AxisNo) of Axis Information (<u>AxisName</u> .AxisRef) which configures the axes group.

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
GroupStatus	Axes Group Status	Displays the current axes group status. <ul style="list-style-type: none">• -1: Axes group variable uninitialization/Axes group parameter error (Invalid)• 0: Axes group disabled (GroupDisabled)• 1: Stopping on error (GroupErrorStop)• 2: Decelerating to stop (GroupStopping)• 4: Standby (GroupStandby)• 5: Operating (GroupMoving)
GroupName	Axes Group Name	Stores the axes group name.
Axis[1..16]	Configuration Axis	Sets Axis No. (AxisNo) of Axis Information (<u>AxisName</u> .AxisRef) which configures the axes group.

Relevant FBs

For details on Motion control FBs, refer to the following.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_GroupEnable	Axes Group Enabled	Transits the specified axes group status from "0: Axes group disabled (GroupDisabled)" to "4: Standby (GroupStandby)".
MC_GroupDisable	Axes Group Disabled	Transits the specified axes group status to "0: Axes group disabled (GroupDisabled)".

Settings required for axes group

The following parameters must be set in the engineering tool in order to set axes groups.

For setting methods of axes group, refer to the following.

 Page 73 Axes Group Assignment

Item	Description
Axes group No.	Sets axes group No. of the motion system.
Axes group name	Sets an arbitrary axes group name.
Configuration axis	Sets Axis No. (AxisNo) of Axis Information (<u>AxisName</u> , AxisRef) which configures the axes group.

Axes group variables

Axes group variables are generated by adding the axes group setting in the engineering tool. A generated axes group is assigned to the global label as an axes group variable.

Axes group is defined as an axes group variable configured with monitor information such as parameter information, the current position, and the status.

Axes group variable name (default)

The following names are assigned based on the setting axes group No. It can be changed to an arbitrary name. For details, refer to the following.

 Page 73 Axes Group Assignment

Setting axes group No.	Engineering tool default axis name
1	AxesGroup001
2	AxesGroup002
⋮	⋮

Data type

Data types of axes groups are described with the AXES_GROUP type. Data types of axes groups have the following members respectively.

Member name	Data type	Description
AxesGroupRef	AXES_GROUP_REF	Data structure for input/output of the Motion control FB
Pr	AXES_GROUP_PRM	Stores parameter data of the axes group. Opens the default value at axes group variable generation. Re-importing to the control data is executed after axes group variables initialization. The timing to import to the control changes depending on the parameter.
Md	AXES_GROUP_MONI	Stores monitor data of the axes group. Executes refresh in the fixed cycle for each monitor data.
Cd	AXES_GROUP_CMD	Stores command data for axes group control. Gets the newest value every control operation cycle and uses it for control.

Axes group variable initialization timing

Axes group variables are initialized at the following timings.

Timing	Processing
Power ON/CPU module reset	Refers to the global label data, and initializes all set axes group variables.
PLC READY is turned ON	<p>■ Uninitialized axis group Refers to the global label data and initializes all axes group variables.</p> <p>■ Initialized axes group Refer to the global label data for the axes group parameter data and import it again. However, do not import again the configuration axis. When the parameter error occurs at importing, the axes group is not deleted. At this time, READY does not turn ON. For the label initialization processing when the PLC READY turns OFF to ON, refer to "Label initialization function" in the following manual.  MELSEC iQ-R Programming Manual (Motion Control Function Blocks)</p>


How to specify in a user program

When specifying the axes group by the Motion control FB, set the AXES_GROUP_REF type member (AxesGroupName.AxesGroupRef) of each axes group variable to the I/O variables which the data type is "AXES_GROUP_REF".

Ex.

When executing the MC_GroupEnable (Axes Group Enabled) with the following settings

- Axes group No.: 1
- Axes group name: AxesGroup001



Axes group status

When an axes group is used in the motion FB, Axes Group Status (AxesGroupName.Md.GroupStatus) must be "4: Standby (GroupStandby)" by executing MC_GroupEnable (Axes Group Enabled) to the axes group. The axes group can be started in the motion FB when Axes Group Status (AxesGroupName.Md.GroupStatus) is "4: Standby (GroupStandby)" and Axis Status (AxisName.Md.AxisStatus) of all configuration axis is "4: Standby (Standstill)".

Axes group state transition

The following shows status that an axes group can enter.


The current status can be confirmed with Axes Group Status (AxesGroupName.Md.GroupStatus).

When the axes group changes to "4: Standby (GroupStandby)", Using Axes Group (AxisName.Md.UseInGroup) of the configuration axis becomes TRUE.

When the motion FB is executed for the axis (the axis of which Using Axes Group (AxisName.Md.UseInGroup) is TRUE) used in the axes group, "Start Not Possible" (error code: 1AADH) occurs. Disable the axes group by MC_GroupDisable (Axes Group Disabled).

Status	Description
-1: Axes group variable uninitialization/Axes group parameter error (Invalid)	Axes group is disabled because of the axes group variables are not initialized (such as a parameter error occurrence at initialization).
0: Axes group disabled (GroupDisabled)	Axes group is disabled. Motion control FB cannot be executed in this status. The axis which is being controlled will be stopped immediately to transit this status.
1: Stopping on error (GroupErrorStop)	Axes group is in the deceleration stop or the stop status by an error occurrence. When Axis Status (<u>AxisName.Md.AxisStatus</u>) is set to "1: Stopping on error (ErrorStop)" in any of the configuration axes, the axes group also enters this status.
2: Decelerating to stop (GroupStopping)	The deceleration stop is executed by MC_GroupStop (Group Forced Stop). After the axis stop is completed, this status will be maintained until the Execute command (Execute) of MC_GroupStop (Group Forced Stop) becomes FALSE. The Motion control FB cannot be executed in this status.
4: Standby (GroupStandby)	Axes group is enabled and stand-by. (Not depending on the servo ON/OFF status of the configuration axis.)
5: Operating (GroupMoving)	The positioning control FB is executed in an axes group. When transiting into this status, Axis Status (<u>AxisName.Md.AxisStatus</u>) of all configuration axes turn to "7: During synchronous operation (SynchronizedMotion)".

The status is transited as the following figure according to start of the Motion control FB.



No.	State transition description
(1)	All group motion FB
(2)	<ul style="list-style-type: none"> Transits when an error caused by an axes group occurs in the status other than "0: Axes group disabled (GroupDisabled)". Transits when an error caused by a configuration axes occurs in the status other than "0: Axes group disabled (GroupDisabled)".
(3)	Transits when status error is cleared by axes group error reset. For details of axes group error reset, refer to the following.  Page 913 Axes group error reset
(4)	Transits when Execution completion (Done) of MC_GroupStop (Group Forced Stop) is TRUE and Execute command (Execute) MC_GroupStop (Group Forced Stop) is FALSE.
(5)	Transits when the axes group is disabled at executing MC_GroupDisable (Axes Group Disabled), or clearing the status error by axes group error reset.
(6)	Transits when a stop of program execution is completed by RUN status → STOP status.

Axes group enabled


This section describes enabling an axes group.

Control details


- Specify Axes Group Information (AxesGroup) and change Axes Group Status (AxesGroupName.Md.GroupStatus) to "4: Standby (GroupStandby)".
- The axes group can start the motion FB only when Axes Group Status (AxesGroupName.Md.GroupStatus) is "4: Standby (GroupStandby)".
 - MC_GroupEnable (Axes Group Enabled) can be executed only when Axis Status (AxisName.Md.AxisStatus) of all configuration axes is "4: Standby (Standstill)" or "0: Axis disabled (Disabled)".
 - When Axes Group Status (AxesGroupName.Md.GroupStatus) changes to the "4: Standby (GroupStandby)", Using Axes Group (AxisName.Md.UseInGroup) of the configuration axis becomes TRUE.
 - When MC_GroupEnable (Axes Group Enabled) is executed by specifying another axes group including the configuration axis of which Using Axes Group (AxisName.Md.UseInGroup) is TRUE, "Axes Group Configuration Axis Is in Use" (error code: 3496H) occurs.
 - If the error occurs in any of the configuration axis, Axes Group Status (AxesGroupName.Md.GroupStatus) will be "1: Stopping on error (GroupErrorStop)".
 - When MC_GroupEnable (Axes Group Enabled) is executed for an axes group that has already been enabled, Execution completion (Done) becomes TRUE and the execution ends.

■Timing chart


- When the operation is normally completed



- When there is an I/O variable error



- When an error occurs



Axes group disabled

This section describes disabling an axes group.

Control details

Axes Group Status (AxisGroupName.Md.GroupStatus) can be changed to "0: Axes group disabled (GroupDisabled)" by specifying Axes Group Information (AxesGroup).


- An axes group cannot execute the motion FB when Axes Group Status (AxisGroupName.Md.GroupStatus) is "0: Axes group disabled (GroupDisabled)".
- MC_GroupDisable (Axes Group Disabled) can only be executed when Axes Group Status (AxisGroupName.Md.GroupStatus) is "4: Standby (GroupStandby)" or "1: Stopping on error (GroupErrorStop)". When executing this FB while Axes Group Status is "1: Stopping on error (GroupErrorStop)" and the axes group is in operation, the axes group status transits to "0: Axes group disabled (GroupDisabled)" after the stop completes. When this FB is executed while Axes Group Status (AxisGroupName.Md.GroupStatus) is other than "4: Standby (GroupStandby)" or "1: Stopping on error (GroupErrorStop)", "Axes Group Status Incorrect (When Axes Group is Disabled)" (error code: 1A97H) occurs. The positioning control FB stops. For details on stop processing, refer to the following.

➡ Page 163 Stop


- When Axes Group Status (AxisGroupName.Md.GroupStatus) changes to "0: Axes group disabled (GroupDisabled)", Using axes group (AxisName.Md.UseInGroup) of the configuration axis becomes FALSE.
- When MC_GroupDisable (Axes Group Disabled) is executed for an axes group that has already been disabled, Execution completion (Done) becomes TRUE and the execution ends.

Timing chart

- When the operation is normally completed




- When there is an I/O variable error



- When an error occurs

Ex.

When executing Axes Group Disable while Axes Group Status (`AxesGroupName.Md.GroupStatus`) is "5: Operating (GroupMoving)"



Precautions

If the parameter error occurs at axes group variable initialization, "Out of Parameter Range (Axes Group)" (error code: 1D81H) occurs. In this case, Axes Group Status (`AxesGroupName.Md.GroupStatus`) changes to "-1: Axis variable uninitialization/Axis parameter error (Invalid)". Refreshing of the monitor data, etc. is not executed for axes groups whose status is "-1: Axis variable uninitialization/Axis parameter error (Invalid)". If the axes group is specified by the user program, "Out of Axes Group No. Range" (error code: 3402H) occurs.

Relevant add-ons

The following add-on is required to use this function.

- Axis
- MotionEngine
- MotionControl_General

1.5 Axes Group Assignment

Axes groups can be set in the engineering tool. For the setting method, refer to Help of the engineering tool.
Based on parameter settings of the axes group, the instance of the axes group is initialized when the power turns ON or when the PLC READY turns ON.

Relevant variables

Axes group monitor data (AxesGroupName.AxesGroupRef.)

Variable/Structure name	Name	Details
GroupNo	Axes Group No.	Sets the axes group No. <ul style="list-style-type: none">• 0: No setting• 1 to 10000: Setting axes group No.

Axes group monitor data (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
Axis[1..16]	Configuration Axis	Sets Axis No. (AxisNo) of Axis Information (<u>AxisName</u> .AxisRef) which configures the axes group.

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
NumberOfAxes	Number of Configuration Axes	Indicates the number of configuration axes of the axes group.
GroupName	Axes Group Name	Stores the axes group name.
Axis[1..16]	Configuration Axis	Stores Axis No. (AxisNo) of Axis Information (<u>AxisName</u> .AxisRef) which configures the axes group.

Setting with Engineering tool

In the axes group setting window of the engineering tool, an axes group can be generated/initialized by setting the axes group setting as a parameter. The axes group set in the axes group setting window is assigned to the global label data as an axes group variable.

Setting items

■Axes group No.

It is an identifier on the motion system control.

If the same No. is set in the multiple axes groups, "Axes Group No. Setting Duplication Error" (error code: 1A58H) will occur. The axes group whose axes group No. is "0" is regarded as an unset axes group, and it cannot be used for control.

Item	Setting range
Axes group No.	1 to 10000

■Axes group name

Set an axes group name of the applicable axes group arbitrarily with up to 127 characters.

An instance is generated as a set axes group name.

■Configuration axis

Set configuration axes of an applicable axes group with Configuration Axis (AxesGroupName.Pr.Axis[1..16]).

Set the AxisName.AxesRef structure of the axis variable for the configuration axes.

Set the configuration axes of the maximum 16 axes in the left-justified format from the configuration axis 1.

"No axis" (error code: 1A99H) and "Axes Group Configuration Axis Operation Cycle Incorrect" (error code: 1A59H) occur for the following cases.

- When there is no configuration axis
- When the operation cycles of the configuration axes are mismatched.

Setting procedures with the engineering tool

The following shows how to create an axes group with the engineering tool.

1. Create an axis, and set the axis name. (A variable instance of the AXIS_ * type is generated.)

 Navigation window ⇒ "Axis" ⇒ Right-click ⇒ [New Data]

2. Create an axes group, and set the axes group No. and the axes group name. (A variable instance of the AXES_GROUP type is generated.)

 Navigation window ⇒ "Axis" ⇒ Right-click ⇒ [New Data]

3. Add an axis to the configuration axes of the axes group.

 [Axes group setting]

Memory usage

Memory usage for the axes group is 60 [K bytes] per an axes group.

The memory capacity for axis data is specified by Maximum RAM Size (System.PrConst.Addon_Axis.RamSizeMax).

When the axis data memory usage exceeds the capacity at initializing the axes group variable, "Maximum Number of Registrations for Axes Group Over" (error code: 1A60H) occurs and the axes group is not generated. Check the memory capacity and execute the software reboot.

2 AXIS MANAGEMENT FUNCTIONS

2.1 Technical Units

The position command unit and the velocity command unit used in the motion control can be set in the "unit setting". Since the unit can be specified freely depending on the control target, intuitive programming and monitoring are available.

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
Unit_Position	Position Command Unit	Sets the position command unit to be used in the motion control. ☞ Page 76 Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position)
Unit_Velocity	Velocity Command Unit	Sets the velocity command unit to be used in the motion control. ☞ Page 77 Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity)
Unit_PositionString	Position Command Unit String	Sets the command unit to be used in the motion control in a character string. It is used when the position unit is set to HFF (an arbitrary unit character string).

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
Unit_PositionDisplay	Position Command Unit Display	Outputs the position command unit that is being controlled in a character string.
Unit_VelocityDisplay	Velocity Command Unit Display	Outputs the velocity command unit that is being controlled in a character string.

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
Unit_Position	Position Command Unit	Sets the position command unit to be used in the motion control. ☞ Page 76 Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position)
Unit_Velocity	Velocity Command Unit	Sets the velocity command unit to be used in the motion control. ☞ Page 77 Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity)
Unit_PositionString	Position Command Unit String	Sets the command unit to be used in the motion control in a character string. It is used when the position unit is set to HFF (an arbitrary unit character string).


Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
Unit_PositionDisplay	Position Command Unit Display	Outputs the position command unit that is being controlled in a character string.
Unit_VelocityDisplay	Velocity Command Unit Display	Outputs the velocity command unit that is being controlled in a character string.

Setting methods

The position command unit and the velocity command unit setting method is shown below.

Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position)



■Setting value of the position command unit

Setting value	Position command unit
H00	pulse
H01	m
H41	degree
HB4	Revolution
HC0	inch
HFF	An arbitrary unit character string ^{*1}

^{*1} For setting an arbitrary unit character string, set Position Command Unit String (AxisName(AxesGroupName).Pr.Unit_PositionString). (This can also be set as blank ("").)

■Setting value of the prefix

When the position command unit setting is HFF (an arbitrary unit character string), this setting is ignored and the control is operated with H00 ($\times 10^0$).

Setting value	Prefix
H00	$\times 10^0$
HFD	$\times 10^{-3}$ [m]
HFA	$\times 10^{-6}$ [μ]
HF7	$\times 10^{-9}$ [n]

■Display example

The following shows display examples of Position Command Unit Display

(AxisName(AxesGroupName).Md.Unit_PositionDisplay) according to the setting value of Position Command Unit

(AxisName(AxesGroupName).Pr.Unit_Position).

Ex.

The Setting value of Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position) and Position Command Unit Display (AxisName(AxesGroupName).Md.Unit_PositionDisplay).

Position Command Unit (<u>AxisName(AxesGroupName)</u> .Pr.Unit_Position)	Position Command Unit Display (<u>AxisName(AxesGroupName)</u> .Md.Unit_PositionDisplay)
H00010000	m
HFD010000	mm
HFA010000	μ m
HF7010000	nm
H00B40000	Revolution
H00410000	degree
HFA410000	$\times 10^{-6}$ degree
H00000000	pulse
H00C00000	inch

Point

If "1" is set in the program when Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position) is "HFD010000", the position will be regarded as "1.0mm".

Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity)



■Setting value of the velocity command unit

Setting value	Velocity command unit
H03	s
H47	min

■Setting value of prefix

Setting value	Prefix
H00	$\times 10^0$
HFD	$\times 10^{-3}$ (m)
HFA	$\times 10^{-6}$ (μ)
HF7	$\times 10^{-9}$ (n)

■Display example

The following shows display examples of Velocity Command Unit Display.

(AxisName(AxesGroupName).Md.Unit_VelocityDisplay) according to the setting value of Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity).

Ex.

The Setting value of Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) and Velocity Command Unit Display (AxisName(AxesGroupName).Md.Unit_VelocityDisplay).

Velocity Command Unit (<u>AxisName(AxesGroupName).Pr.Unit_Velocity</u>)	Velocity Command Unit Display (<u>AxisName(AxesGroupName).Md.Unit_VelocityDisplay</u>)
H00004700	[Position command unit]/min
HFD000300	[Position command unit]/ms
HFA000300	[Position command unit]/ μ s
HF7000300	[Position command unit]/ns

Point

- If Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position) is HFF000000 (An arbitrary unit character string), number of displayable characters from the beginning out of the position command unit character strings is displayed on Velocity Command Unit Display.
(AxisName(AxesGroupName).Md.Unit_VelocityDisplay).
- If "1" is set in the program when Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) is HFD000300, the velocity will be regarded as "1.0 [position command unit]/ms".

- The following shows display examples of Velocity Command Unit Display.
(AxisName(AxesGroupName).Md.Unit_VelocityDisplay) according to the setting value of Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position) and Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity).

Ex.

The Setting value of Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position) and Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) and Velocity Command Unit Display (AxisName(AxesGroupName).Md.Unit_VelocityDisplay).

Position Command Unit (<u>AxisName(AxesGroupName).Pr.Unit_Position</u>)	Velocity Command Unit (<u>AxisName(AxesGroupName).Pr.Unit_Velocity</u>)	Velocity Command Unit Display (<u>AxisName(AxesGroupName).Md.Unit_VelocityDisplay</u>)
HFD010000	HFD000300	[mm/ms]

Combination of command units during multiple axes positioning control

During multiple axes positioning control, set command units of the axes group and the interpolation axes to be matched. When the command units are mismatched, set the input value of FB and the operation profile in the multiple axes positioning data format as shown below.

- For the input (Target position (Position), Movement amount (Distance), etc.) regarding position in multiple axes positioning control, specify the value based on the position command unit of the each interpolation axes necessarily.
- For the input (Velocity (Velocity), Acceleration (Acceleration), Deceleration (Deceleration), and Jerk (Jerk)) of multiple axes positioning control, specify the value based on the velocity command unit used for each control necessarily.
- When the combination of the position command unit between the axes group and the interpolation axes is different, "Position Command Unit Mismatch Warning" (warning code: 0D08H) will occur at start and multiple start.
- When the combination is different between the velocity command unit and the FB being executed at multiple start, "Velocity Command Unit Mismatch Warning" (warning code: 0D1EH) will occur at multiple start.

Velocity command units used for each control are shown below.

The following operations depend on interpolation controls.

■Linear interpolation control (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control), MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control))

VelocityMode	Operation
0: Vector Velocity (VectorSpeed)	<ul style="list-style-type: none">• The movement amount on the linear path (combined movement amount) is calculated from the value of current position and Target position (Position) or Movement amount (Distance). The position command unit of the axes group and the interpolation axes is not affected.• Unit of the axes group is used for the velocity command unit in controlling.
1: Long Axis Velocity (LongAxisSpeed)	<ul style="list-style-type: none">• The axis whose movement amount value is the largest is regarded as the long axis from the value of current position and Target position (Position) or Movement amount (Distance). The position command unit of the axes group and the interpolation axes is not affected.• The unit of the long axis is used for the velocity command unit in controlling. Unit of the axes group is not used.
2: Reference Axis Velocity (ReferenceAxisSpeed)	<ul style="list-style-type: none">• The unit of the reference axis (First element of Linear interpolation axes (LinearAxes)) is used for the velocity command unit in controlling.

- For details of linear interpolation control, refer to the following.

📖 Page 215 Linear interpolation control

■Circular interpolation control (MCv_MoveCircularInterpolateAbsolute (Absolute Value Circular Interpolation Control), MCv_MoveCircularInterpolateRelative (Relative Value Circular Interpolation Control))

- Calculates circular path from the value of current position, Sub point (AuxPoint), and End point (EndPoint). The position command unit of the axes group and the configuration axes is not affected.
- The unit of the axes group is used for the velocity command unit in controlling.
- For details of circular interpolation control, refer to the following.

📖 Page 220 Circular interpolation control

■Operation when axes group unit and interpolation axes unit are mismatched

The following shows the operation example when the position/velocity command units of the configuration axis 1 and 2, and axes group in linear interpolation control are different.

Ex.

Operation example

- Axis setting and Axes group setting

Setting item	Setting details	Setting value
Position/Velocity command unit of the axes group	mm/ms	Position Command Unit (<u>AxisGroupName</u> .Pr.Unit_Position): HFD010000 Velocity Command Unit (<u>AxisGroupName</u> .Pr.Unit_Velocity): HFD000300
Position/Velocity command unit of the configuration axis 1	mm/s	Position Command Unit (<u>AxisName</u> .Pr.Unit_Position): HFD010000 Velocity Command Unit (<u>AxisName</u> .Pr.Unit_Velocity): H00000300
Position/Velocity command unit of the configuration axis 2	degree/min	Position Command Unit (<u>AxisName</u> .Pr.Unit_Position): H00410000 Velocity Command Unit (<u>AxisName</u> .Pr.Unit_Velocity): H00004700

- FB input (MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control))

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Movement amount (Distance[0])	300
Movement amount (Distance[1])	400
Velocity (Velocity)	1000
Velocity Mode (VelocityMode)	0: Vector Velocity (VectorSpeed)


<Operation>

- Linear interpolation is performed by Movement amount (Distance) "300 [mm]" of the configuration axis 1, and "400 [degree]" of the configuration axis 2.
- Position and velocity command units of axes group are used for the unit of Velocity (Velocity) as a vector velocity. It will be controlled by the vector velocity at "1000 [mm/ms]".
- The motion system calculates a "combined movement amount $\sqrt{(300^2 + 400^2)} = 500$ [mm]" from each value of the configuration axis movement amount. Each axis movement amount of every operation cycle is calculated from the combined movement amount (500 [mm]) and vector velocity (1000 [mm/s]). The calculated amount is commanded as a movement amount in the position command unit of each axis.

The motion system calculates positioning speed of each axis such as follow.

A monitor value of each axis speed is stored by the velocity command unit of each axis.

Positioning speed of each axis	Calculated value
Positioning speed of configuration axis 1	$1000 \times 300 / 500 = 600$ [mm/ms] (= 600000 [mm/s])
Positioning speed of configuration axis 2	$1000 \times 400 / 500 = 800$ [degree/ms] (= 48000000 [degree/min])



Precautions

- When "Out of Position Command Unit Range Warning" (warning code: 0D2DH) occurs, the initial value is stored in Position Command Unit Display (AxisName(AxesGroupName).Md.Unit_PositionDisplay) (The default value of position command unit: pulse)
- When "Out of Velocity Command Unit Range Warning" (warning code: 0D2EH) occurs, the initial value is stored in Velocity Command Unit Display (AxisName(AxesGroupName).Md.Unit_VelocityDisplay). (The default value of velocity command unit: pulse/s)
- Even if Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position), Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) and Position Command Unit String (AxisName(AxesGroupName).Pr.Unit_PositionString) are changed, the homing request will not become TRUE.
- When the number of characters exceeds 31, the 32 or later character is not displayed in the position/velocity command unit display.
- When the character string is not input, the position command unit is not displayed.

2.2 Positioning Range

"Positioning range" is $-10000000000.0 \leq \text{positioning range} < 10000000000.0$.

The range of Set Position (AxisName.Md.SetPosition) is determined by Ring Counter Upper Limit Value (AxisName.PrConst.RingCount_UpperValue) and Ring Counter Lower Limit Value (AxisName.PrConst.RingCount_LowerValue).

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
RingCount_Enable	Ring Counter Enabled Selection	Selects the ring counter enable/disable. • FALSE: Disabled ^{*1} • TRUE: Enabled ^{*2}
RingCount_UpperValue	Ring Counter Upper Limit Value	Sets the ring counter upper limit value. ^{*3} • -10000000000.0 to 10000000000.0
RingCount_LowerValue	Ring Counter Lower Limit Value	Sets the ring counter lower limit value. ^{*3} • -10000000000.0 to 10000000000.0

*1 Positioning range is $-10000000000.0 \leq \text{positioning range} < 10000000000.0$.

*2 If the ring counter upper limit value and ring counter lower limit value are set to match the positioning range, the ring counter is disabled.

*3 The value is not fetched when the ring counter is disabled.

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
SetPosition	Set Position	Stores the current position address. ^{*1} The set position is a value which the cumulative current value is rounded with the ring counter range.
CumulativePosition	Cumulative Current Position	Stores the current position address. When the current position is changed, the address is changed to the current position change value. The ring address is $-10000000000.0 \leq \text{CumulativePosition} < 10000000000.0$.
FeedMachinePosition	Machine Feed Value	Stores the current position address by the machine coordinate. The accumulative value from the homing completed position is set. The address is not changed even if the current position is changed. The ring address is $-10000000000.0 \leq \text{Machine feed value} < 10000000000.0$.
CommandedPosition	Commanded Position	Stores Target position (Position)/Movement amount (Distance) imported to the positioning FB being controlled. Stores "0.0" after the positioning is completed.
ActualPosition	Actual Position	Stores the actual current position. The value of "current position $\times$ driver unit conversion denominator / driver unit conversion numerator" is set. For details, refer to the following.  Page 403 Driver unit conversion function The actual position is a value which is rounded with the ring counter range.

*1 The stored value includes an error because a floating-point error occurs.

Set position

Set Position (AxisName.Md.SetPosition) can be set to an arbitrary ring address by setting Ring Counter Upper Limit Value (AxisName.PrConst.RingCount_UpperValue) and Ring Counter Lower Limit Value (AxisName.PrConst.RingCount_LowerValue). The ring counter upper/lower limit value can be set within the range of -10000000000.0 to 10000000000.0.

Restrictions

The motion control function uses the real number data (floating-point data) for the axis current position and the command target position, etc. Therefore, it may include the truncation error.

Example	Description
1	When the positioning of relative position specification such as MC_MoveRelative (Relative Value Positioning) is executed repeatedly, it may accumulate the truncation error between the set position and the specified movement value. If the truncation error is a problem, execute the positioning of absolute position specification such as MC_MoveAbsolute (Absolute Value Positioning). In addition, refer to the following setting example to suppress the truncation error.
2	During positioning control such as automatic deceleration at low speed, "Overrun Warning" (warning code: 0D10H) or "Overrun Error" (error code: 1A7EH) may occur due to truncation error when the axis reaches the target position. Refer to the following setting example to suppress the truncation error.

■Setting example

Setting real number type parameters that are related to Motion control functions in a way that does not include numbers after the decimal point can suppress truncation errors because all data being processed within the function is in real numbers. In the following example, when the truncation error is a problem in setting (A), setting (B) can be used alternatively.

• Setting (A)

Setting item	Setting detail
Position command unit*1	[mm]
Ring counter upper value	100.3 [mm]
Ring counter lower value	-100.7 [mm]
The minimum scale of the target position/movement amount specified by FB input	0.05 [mm]

• Setting (B)

Setting item	Setting detail
Position command unit*1	[μm]
Ring counter upper value	10300 [μm]
Ring counter lower value	-10700 [μm]
The minimum scale of the target position/movement amount specified by FB input	50 [μm]

*1 For details on the setting method, refer to the following.


📖 Page 75 Technical Units

Control details

Set Position (AxisName.Md.SetPosition) to be the ring address is calculated based on Cumulative Current Position (AxisName.Md.CumulativePosition). The cumulative current position will be the ring address of " $-10000000000.0 \leq$ cumulative current position < 10000000000.0 " regardless of the setting of the ring counter upper/lower value.

Ex.

When the ring counter lower limit value is -5000000000.0 and the ring counter upper limit value is 5000000000.0 , the set position is the ring address of " $-5000000000.0 \leq$ set position < 5000000000.0 ".



The ring counter upper/lower limit value is fetched to the parameter at the timing when the axis is enabled.

Combination with other functions

The available range of positioning differs depending on the type of the positioning control FB.

- Absolute position specification: Within the range of the ring counter
- Relative position specification: Maximum movement amount $| 10000000000.0 |$

Precautions

When Ring Counter Enabled Selection (AxisName.PrConst.RingCount_Enable) is "TRUE (Enabled)", error is checked.

If the ring counter upper/lower limit value is set as follows, an error will occur.

- The ring counter upper/lower limit value is set outside the positioning range.
- The ring counter lower limit value $>$ The ring counter upper limit value
- $| \text{The ring counter upper limit value} - \text{The ring counter lower limit value} | < 2.0$

2.3 Velocity Range

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
SetVelocity	Set Velocity	Stores the set output velocity.* ¹ This velocity is calculated from the difference of the set position. The value is positive when moving to the positive direction (Address increase direction), and the value is negative when moving to the negative direction (Address decrease direction). Stores the set velocity of the configuration axis during the axes group operation.
CommandedVelocity	Commanded Velocity	Stores commanded velocity imported to the motion FB being controlled. Stores "0.0" after the control is completed. Stores "0.0" in Commanded Velocity (<u>AxisName</u> .Md.CommandedVelocity) of the configuration axis during the axes group operation.
TargetVelocity	Target Velocity	Stores the actual target velocity whose override and velocity limit value are considered. Stores "0.0" after the control is completed. Stores "0.0" in Target Velocity (<u>AxisName</u> .Md.TargetVelocity) of the configuration axis during axes group operation. ■For the positioning control FB The value becomes more than "0.0" regardless of the movement direction. ■For other than the positioning control FB The value is positive when moving to the positive direction (Address increase direction), and the value is negative when moving to the negative direction (Address decrease direction)
ActualVelocity	Actual Velocity	Stores the actual velocity. This velocity is calculated from the difference of the actual position. The value is positive when moving to the positive direction (Address increase direction), and the value is negative when moving to the negative direction (Address decrease direction).

*1 The stored value includes an error because a floating-point error occurs.

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
SetVelocity	Set Velocity	Stores the set output velocity during the axes group operation. The value becomes more than "0.0" as it is regardless of the movement direction of the configuration axes. Stores "0.0" after the control is completed. *: When "1: Long Axis Velocity (LongAxisSpeed)" or 2: Reference Axis Velocity (ReferenceAxisSpeed) is specified in the linear interpolation control, stores the absolute value of set velocity of the relevant axis.
CommandedVelocity	Commanded Velocity	Stores the commanded velocity imported to the motion FB being controlled. Stores "0.0" after the control is completed. *: When "1: Long Axis Velocity (LongAxisSpeed)" or 2: Reference Axis Velocity (ReferenceAxisSpeed) is specified on Velocity mode (VelocityMode) in the linear interpolation control, stores the commanded velocity of relevant axis.
TargetVelocity	Target Velocity	Stores the actual target velocity whose override and velocity limit value are considered. The value becomes more than "0.0" regardless of the movement direction of the configuration axis. Stores "0.0" after the control is completed. *: When "1: Long Axis Velocity (LongAxisSpeed)" or 2: Reference Axis Velocity (ReferenceAxisSpeed) is specified on Velocity mode (VelocityMode) in the linear interpolation control, stores the target velocity of relevant axis.

Variable/Structure name	Name	Details
ActualVelocity	Actual Velocity	Stores the actual velocity. It is the vector velocity of the actual velocity of the configuration axes. The value becomes more than "0.0" as it is regardless of the movement direction of the configuration axes. Stores "0.0" when the axes group is invalid.

Velocity set range

The set velocity in the motion system is as follow.

Name	Description	Range
Commanded velocity	Set velocity that is specified in the motion FB.	0.0, ± 0.0001 to ± 2500000000.0
Target velocity	The actual set velocity whose override and velocity limit value are considered with the commanded velocity.	

- For the valid range of the commanded velocity of each motion FB, refer to the each FB specifications.
- The operation that the target velocity be out of the range because of using override function, refer to the following.
 Page 392 Override Function
- When "0.0" is set to the commanded velocity in the FB to execute multiple start, the commanded velocity of previous FB will be set. For details, refer to the following.
 Page 134 Multiple Start (Buffer Mode)
- To perform floating-point operation, the lower limit value of the commanded velocity is limited by the following restrictions.
If the speed that is converted from commanded velocity to operation cycle is less than 0.00001, "Out of Operation Cycle Converted Velocity Range" (error code: 1AE4H) (when changing the velocity, "Out of Operation Cycle Converted Velocity Range Warning" (warning code: 0D2FH)) occurs.
To improve the precision of floating-point operation, specify the speed that is converted into operation cycle so as not to be less than 0.00001 by changing Position Command Unit (AxisName(AxesGroupName).Pr.Unit_Position) or Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity).

Ex.

When the operation cycle is "0.5 [ms]" and the commanded velocity is set with the following units

If specifying the commanded velocity to "0.0001" with the following units, the calculation cycle converted speed is as follows.

Variable name	Setting value	Units
Position command unit (<u>AxisName(AxesGroupName).Pr.Unit_Position</u>)	H00000000	1×10^0 [pulse]
Velocity command unit (<u>AxisName(AxesGroupName).Pr.Unit_Velocity</u>)	H00000300	1×10^0 [pulse/s]

Calculation Cycle Converted Speed = $0.0001 \text{ [pulse/s]} \div 1000 \times 0.5 \text{ [ms]} = 0.00000005 \text{ [pulse]}$

"Out of Operation Cycle Converted Velocity Range" (error code: 1AE4H) occurs.

If changing Position command unit (AxisName(AxesGroupName).Pr.Unit_Position) from " [pulse] (H00000000)" to " $\times 10^{-3}$ [pulse](HFD000000)", and changing commanded velocity to "0.1", the calculation cycle converted speed is as follows.

Calculation Cycle Converted Speed = $0.1 \times 10^{-3} \text{ [pulse/s]} \div 1000 \times 0.5 \text{ [ms]} = 0.00005 \times 10^{-3} \text{ [pulse]}$

Thus an error can be avoided by changing the commanded velocity to match the change of the position command unit.

Precautions

When " $0.0 < \text{velocity after velocity override} < 0.0001$ ", "Out of Velocity Range Clamping Warning" (warning code: 0D34H) occurs and becomes "0.0".

2.4 Servo ON/OFF

This function executes servo ON/OFF of the real axis connected to the motion system.
The servo ON enables the operation of the real axis.

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
Driver_ReadyOn	Driver Ready On Status	Displays the connected drive unit status. Becomes TRUE when Driver Status (<u>AxisName</u> .Md.Driver_State) of the connected drive unit is as follows. <ul style="list-style-type: none">• 2: Fault Reaction Active (FaultReactionActive)• 5: Switched On (SwitchedOn)• 6: Operation Enable (OperationEnable)• 7: Quick Stop Active (QuickStopActive)
Driver_ServoOn	Driver Servo On Status	Displays the connected drive unit status. Becomes TRUE when Driver Status (<u>AxisName</u> .Md.Driver_State) of the connected drive unit is as follows. <ul style="list-style-type: none">• 6: Operation Enable (OperationEnable)• 7: Quick Stop Active (QuickStopActive)

Relevant FBs

For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_Power	Operation Available	Switches a specified axis to the operation possible status.
MCv_AllPower	All Axes Operation Available	Switches every axis to the operation possible status.

Control details

Servo ON/OFF

The servo ON/OFF of the real axis connected to the motion system is controlled by MC_Power (Operation Available) for single axis and MCv_AllPower (All Axes Operation Available) for all axes. For the drive unit status, refer to the following.

☞ Page 88 Drive unit state transition

■MC_Power (Operation Available) input/output and servo ON/OFF status

The servo ON/OFF status and the drive unit status of the selected axis can be switched as the follows by inputting Enable (Enable) and Servo ON request (ServoON) of MC_Power (Operation Available).

Input variables		Output variables		Servo ON/OFF status	Driver Status (AxisName.Md.Driver_State)
Enable (Enable)	Servo ON request (ServoON)	Ready ON status (ReadyStatus)	Operable (Status)		
TRUE	TRUE	TRUE	TRUE	Servo ON	6: Operation Enable (OperationEnable)
	FALSE	TRUE	FALSE	Servo OFF	5: Switched On (SwitchedOn)
FALSE	TRUE	FALSE	FALSE	Servo OFF	3: Switch On Disabled (SwitchOnDisabled)
	FALSE	FALSE	FALSE	Servo OFF	3: Switch On Disabled (SwitchOnDisabled)

- If the real axis is rotated by external force during the servo OFF status, follow up processing is performed.
- The servo ON/OFF control can be operated regardless of the control mode. The control mode during the servo OFF status depends on the drive unit specification.
- While the drive unit error occurs, Enable (Enable) and Servo ON request (ServoON) are not required to be turned from FALSE to TRUE again since MC_Power (Operation Available) has been sent to the drive unit.

■MCv_AllPower (All Axes Operation Available) input/output and servo ON/OFF status

The servo ON/OFF status and the drive unit status of all real axes can be switched as follows by inputting Enable (Enable) and Servo ON request (ServoON) of MCv_AllPower (All Axes Operation Available).

Input variables		Servo ON/OFF status	Driver Status (AxisName.Md.Driver_State)
Enable (Enable)	Servo ON request (ServoON)		
TRUE	TRUE	Servo ON	6: Operation Enable (OperationEnable)
	FALSE	Servo OFF	5: Switched On (SwitchedOn)
FALSE	TRUE	Servo OFF	3: Switch On Disabled (SwitchOnDisabled)
	FALSE	Servo OFF	3: Switch On Disabled (SwitchOnDisabled)

- If the real axis is rotated by external force during the servo OFF status, follow up processing is performed.
- The servo ON/OFF control can be operated regardless of the control mode. The control mode during the servo OFF status depends on the drive unit specification.
- While the drive unit error occurs, since MCv_AllPower (All Axes Operation Available) has been sent to the drive unit, Enable (Enable) and Servo ON request (ServoON) are not required to be turned from FALSE to TRUE again.

Point

To individually execute servo OFF when using MCv_AllPower (All Axes Operation Available), use MC_Power (Operation Available) together.


When MCv_AllPower (All Axes Operation Available) and MC_Power (Operation Available) are used together, the command of MC_Power (Operation Available) is given priority.

Drive unit state transition

The connected drive unit as an axis performs operation according to the state transition defined by the CiA402 drive profile shown below. The motion system determines whether the drive unit is being servo ON or OFF status based on the current drive unit status.

The current drive unit status can be monitored by Driver Status (AxisName.Md.Driver_State).

For details on operation in each status, refer to the connected drive unit manual.



Precautions

- When MC_Power (Operation Available) calls the instruction first after the PLC READY is switched to ON, the axis information is determined. Even if the axis information is changed while Enable (Enable) is FALSE, the change is not reflected.
- Do not set two or more MC_Power (Operation Available) for one axis. The operation is not guaranteed if those are set.
- The servo ON/OFF status when stopping the program is maintained while the READY is OFF.

2.5 Follow Up

Follow up is the function to reflect the input (current position) from the device station assigned to an axis to the set position of the axis.

In an axis which has the current position (Position actual value) as the object data, this function can convert the unit of the current position by the driver unit conversion numerator/denominator (electronic gear) and reflect in the set position.

Axis type	Description
real drive axis	<p>The current position of the drive unit is converted and reflected in the set position in the servo OFF status. For this processing, even if the current position of the drive unit is moved during servo OFF, the drive unit will not move by the amount of droop pulses and can execute positioning from the stop position.</p> <p>For the following cases, the follow up is executed when servo status is ON.</p> <ul style="list-style-type: none"> • In execution in a driver control mode other than csp (cyclic synchronous position mode). • The driver control mode of the drive unit is connected by motion system axis control unsupported mode. • MC_Home (OPR) is in execution. (When "1: Follow up enabled" is selected in Follow-up enabled/disabled selection (Options (Options): Bit 16))
Real Encoder axis	This function can convert the unit of the current position of the synchronous encoder and reflect it in the set position. By switching the follow up enabled/disabled allows input enabled/disabled from the synchronous encoder.
Virtual Encoder axis	

Operation of this function for each system status

○: Possible, △: Possible (restricted), ×: Not possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	△ *1
Major error	×

*1 Operation may not be possible depending on the add-on and device station status.

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
Encoder_CounterDisableSignal	Counter Disabling Signal	<p>Sets a signal to switch to the counter disable.</p> <p>The following shows the specific setting and the operation of Counter Disabling Signal (Encoder_CounterDisableSignal).</p> <p>■Target (Source.Target)</p> <p>Only [VAR], [DEV] and [CONST] can be specified to data type for Target.</p> <p>■Signal detection method (Detection)</p> <p>Only the following level detections can be set.</p> <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel) <p>■Compensation time (CompensationTime)</p> <p>Only "0.0 [s]" can be specified</p> <p>■Filter time (FilterTime)</p> <p>The setting range is "0.0 to 5.0 [s]"</p> <p>*: When a value outside the range is set, "Out of Parameter Range" (Axis) (error code: 1D80H) will occur.</p>

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
FollowupDisable	Follow-up Disabled	Displays the follow up disable status. When it is disabled, the follow up is not executed. <ul style="list-style-type: none">• FALSE: Follow-up enabled• TRUE: Follow-up disabled
Encoder_CounterDisable	Counter Disabled	Becomes TRUE while disabling the input from the synchronous encoder. <ul style="list-style-type: none">• FALSE: Counter enabled• TRUE: Counter disabled
Io_PosActualValue	Object Data_PosActualValue	Follow up can be used in the axis which has this object data.

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
FollowupDisable	Follow-up Disabled	Disables follow up. <ul style="list-style-type: none">• FALSE: Not execute• TRUE: Execute the followup disable request
Encoder_CounterDisable	Counter Disabled	Switches to the counter disable. <ul style="list-style-type: none">• FALSE: Not execute• TRUE: Execute the counter disable request

Disabling follow up


The follow up enabled/disabled can be switched for each axis (default status: enabled). Input (the current position) from the device station assigned to an axis is disabled and not reflected in the set position by switching the follow up to enabled.

Point

That the follow up enabled/disabled is switched is recorded in the event history. Also, for the real drive axis, the servo ON from the follow up disabled status during the servo OFF is recorded in the event history as well. At this time, the difference [driver-based] between the drive unit target position (Target position) and the current position (Position actual value) is also recorded in the event history.

For real drive axis

Follow-up Disabled (AxisName.Md.FollowupDisable) becomes TRUE by setting Follow-up Disabled (AxisName.Cd.FollowupDisable) to TRUE, and the follow up is disabled.




*1 When checking with slave label

*2 When driver unit conversion (Numerator / Denominator) is (1 / 1).

For real encoder axis/virtual encoder axis

■When Counter Disabling Signal (AxisName.PrConst.Encoder_CounterDisableSignal) is "no setting"


Counter Disabled (AxisName.Md.Encoder_CounterDisable) becomes TRUE by setting Counter Disabled (AxisName.Cd.Encoder_CounterDisable) to TRUE and the input from the synchronous encoder will be disabled.



*1 When checking with the slave label

*2 When driver unit conversion (Numerator / Denominator) is (1 / 1).

■ **When Counter Disabling Signal (AxisName.PrConst.Encoder_CounterDisableSignal) is set**
While Counter Disabled (AxisName.Cd.Encoder_CounterDisable) is TRUE, the counter disabling signal will be valid. Counter Disabled (AxisName.Cd.Encoder_CounterDisable) becomes TRUE while the signal is in detection, and becomes the counter disable. While Counter Disabled (AxisName.Cd.Encoder_CounterDisable) is FALSE, the counter disable signal becomes invalid.




*1 When checking with the slave label

*2 When driver unit conversion (Numerator / Denominator) is (1 / 1).

■ **When Axis Status (AxisName.Md.AxisStatus) is "0: Axis disabled (Disabled)", "1: Stopping on error (ErrorStop)" or "2: Decelerating to stop (Stopping)"**

Follow-up is disabled while Axis Status (AxisName.Md.AxisStatus) is "0: Axis disabled (Disabled)", "1: Stopping on error (ErrorStop)" or "2: Deceleration to stop (Stopping)".

At this time, Counter Disabled (AxisName.Md.Encoder_CounterDisable) does not change.



*1 When checking with slave label

*2 When driver unit conversion (Numerator / Denominator) is (1 / 1).

Precautions

For real drive axes

- When the follow up is enabled after the current position of the drive unit is moved while the follow up is disabled, the motion system reflects the distance from the drive unit in the set position within one operation cycle. Therefore, when a single axis synchronous control is executed using an applicable axis as the master axis, the command of the movement amount of the set position is transmitted to the slave axis.
- The motion system outputs the distance to the drive unit within one operation cycle for the following cases. Note that a rapid operation may occur in the drive unit.
 - When the servo ON occurs next time after the current position of the drive unit is moved in the follow up disabled status during the servo OFF
 - When the system stopped in the servo ON status after the control excluding the position loop, such as the speed control, was executed with the follow up disabled status
- The software stroke limit function is invalid during the servo OFF. Therefore, set the software stroke limit in the slave axis or the following axis for safety in order to transmit the command under follow up in the single axis synchronous control to the slave axis.

For real encoder axes/virtual encoder axes

- The follow-up may not operate depending on the axis status. For details refer to the following.

☞ Page 43 Real encoder axis

☞ Page 49 Virtual encoder axis

For all axes types

- When the movement amount of every operation cycle exceeds the following range, the follow-up does not operate normally because of the movement amount of axis are different with the movement amount of device station. Use the device stations so that their movement amount is within the following range.

Axis type	Valid range for available follow-up per operation cycle
Real drive axis	(Movement amount per operation cycle) [Driver unit] within signed 32bit integral number range
Real encoder axis (Real encoder axis type: via drive unit)	- $((\text{Multiple revolution counter maximum value}) / 2 \times (\text{Encoder resolution})) \leq (\text{Movement amount per operation cycle})$ [Encoder pulse unit] $\leq ((\text{Multiple revolution counter maximum value}) / 2 \times (\text{Encoder resolution}) - 1)$
Virtual encoder axis	- $(\text{Encoder ring counter upper limit value} - \text{Encoder ring counter lower limit value} + 1) / 2 < (\text{Movement amount per operation cycle})$ [Encoder pulse unit] $< (\text{Encoder ring counter upper limit value} - \text{Encoder ring counter lower limit value} + 1) / 2$

Relevant add-ons

The following add-ons are required to use this function.

- Axis
- MotionEngine

2.6 Absolute Position Control

This function restores the current position of axes.

Absolute position system

The absolute position system maintains the current position of axes. The absolute position system configuration differs depending on the axis type. For details, refer to the following.

📖 Page 103 Current position restoration for each axis type

The absolute position data used in the absolute position control is maintained inside the motion system as a backup file.

Current position restoration

This function restores the current position of the axis to the previous position when the motion system power is turned ON again or reset or when the device station assigned to an axis is connected.

Whether restoration is carried out with the maintained absolute position data or not can be specified in the absolute position control setting (AxisName.PrConst.PosRestoration_AbsPosEnable) of the axis parameter. For details, refer to the following.

📖 Page 96 Current position restoration

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
PosRestoration_AbsPosEnable	Absolute Position Control Setting	Sets the absolute position control setting. <ul style="list-style-type: none">• 0: Disable Absolute Position System (ABSDisabled)• 1: Enable Absolute Position System (Enabled)• -1: Automatic Setting (Acquire from Connected Device) (Auto)

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
Homing_Required	Homing Required or Not	Sets whether homing is required or not. Sets FALSE when the homing is not required. If FALSE is set, the homing request will not become TRUE at the current position restoration. <ul style="list-style-type: none">• FALSE: Homing Not Required• TRUE: Homing Required

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
Homing_Required	Homing Required or Not	Displays whether the axis requires the homing or not. If FALSE is set, the homing request will not become TRUE at the current position restoration. <ul style="list-style-type: none"> • FALSE: Homing Not Required • TRUE: Homing Required
PosRestoration_Status	Current Position Restoration Status	Displays the current position restoration status. <ul style="list-style-type: none"> • 0: Not Executed (NotExecute) • 1: Waiting for Restoration Request (WaitingRequest) • 2: Restoration Completed in Incremental System (RestoredInIncSystem) • 3: Restoration Completed in Absolute Position System (Homing Uncompleted) (RestoredInAbsSystemUnHomed) • 4: Restoration Completed in Absolute Position System (RestoredInAbsSystem) *: "0: Not Executed (NotExecute)" is displayed when the device station is disconnected.
Homing_Request	Homing Request	Displays whether homing is required or not. The timing of becoming TRUE differs depending on the absolute position control setting (AxisName.PrConst.PosRestoration_AbsPosEnable). For details, refer to the following.  Page 98 Homing request Becomes FALSE when the homing is completed. <ul style="list-style-type: none"> • FALSE: No homing request • TRUE: Homing request
SetPosition	Set Position	Stores the current position address. The set position is a value which rounds the cumulative current value with the ring counter range.
CumulativePosition	Cumulative Current Position	Stores the current position address. The address is changed to the current position change value when the current position is changed.
FeedMachinePosition	Machine Feed Value	Stores the current position address by the machine coordinate. It is the cumulative current value from the homing completed position. The address is not change even though the current position is changed.

System monitor data (System.Md.)

Variable/Structure name	Name	Details
BackupRestoreStatus	Backup/Restore Information	Displays the status of backup restore. <ul style="list-style-type: none"> • 0: Backup restore not executed • 1: Backup stop required • 2: Backup stop • 3: Backup stop canceled • 4: Restored data saving • 5: Restored data saving completed

System control data (System.Cd.)

Variable/Structure name	Name	Details
BackupRestore	Backup/Restore Request	Executes backup stop and restored data saving. <ul style="list-style-type: none"> • 0000H: No request • ABCDH: Backup stop request • FFEH: Restored data saving request • Other than the above: No operation

Current position restoration

Specify whether the absolute position system is used for the current position restoration or not in the absolute position control setting (AxisName.PrConst.PosRestoration_AbsPosEnable).

Absolute position control setting (<u>AxisName</u> .PrConst.PosRestoration_AbsPosEnable)	Details
0: Disable absolute position system (ABSDisabled)	 Page 96 Incremental system
1: Enable absolute position system (Enabled)	 Page 97 Absolute position system
-1: Automatic setting (Acquire from connected device) (Auto)	 Page 98 Connected device setting

- "-1: Automatic Setting (Acquire from Connected Device) (Auto)" can be set when the connected device has the Encoder status 1 object.
- When "-1: Automatic Setting (Acquire from Connected Device) (Auto)" is not set, the connected device side setting and the motion system side setting must be matched. When those are mismatched, normal current position control cannot be executed. (If the connected device has the Encoder status 1 object and the settings are mismatched, "Absolute Position Control Setting Mismatch" (error code: 1A9AH) will occur at the current position restoration.)

Ex.

When the absolute position system is used.

Select "1: Enabled (absolute position detection system)" for "absolute position detection system selection (PA03.0)" of the servo parameter (basic parameter) in MR-J5(W)-G. In the motion system, select "1: Enable Absolute Position System (Enabled)" for Absolute Position Control Setting (AxisName.PrConst.PosRestoration_AbsPosEnable) in the real drive axis which uses MR-J5(W)-G as the connected device.

The current position restoration timing differs depending on the axis type. For details, refer to the following.

 Page 103 Current position restoration for each axis type

Point

- Whether "incremental system" or "absolute position system" was used for the current position restoration is recorded in the event history.
- When "-1: Automatic Setting (Acquire from Connected Device) (Auto)" was set in the absolute position control setting (AxisName.PrConst.PosRestoration_AbsPosEnable) for an axis with setting value for object data "Encoder status (2D35H)" left blank, "Absolute Position Management Setting Incorrect Warning" (warning code: 0D4CH) occurs, and operation is performed as "incremental system".

Incremental system

This system restores the current position without using the absolute position data.

When the current position restoration has been completed, the axis current position (cumulative current position and machine feed value) becomes "0.0", and the homing request (AxisName.Md.Homing_Request) becomes TRUE. (The set position may not become "0.0" depending on the ring counter setting. ( Page 81 Positioning Range))

When restoration is completed, the axis current position restoration status (AxisName.Md.PosRestoration_Status) is "2: Restoration Completed in Incremental System (RestoredInIncSystem)".

If the machine position establishment with the device station is not required, set to FALSE in the homing request or not.

(AxisName.Pr.Homing_Required) This prevents the homing request (AxisName.Md.Homing_Request) from becoming TRUE at the restoration.

The absolute position data backup is not executed.

Absolute position system

This system restores the current position using the absolute position data.

At the current position restoration, the axis current position (set position, cumulative current position, and machine feed value) is restored based on backed up absolute position data. When restoration is completed, the axis current position restoration status (AxisName.Md.PosRestoration_Status) becomes "4: Restoration Completed in Absolute Position System (RestoredInAbsSystem)".

However, if "Absolute Position Data Incorrect Warning" (warning code: 0D00H) has been detected at restoration, the axis current position restoration status (AxisName.Md.PosRestoration_Status) becomes "3: Restoration Completed in Absolute Position System (Homing Uncompleted) (RestoredInAbsSystemUnHomed)". The current position is restored with the same content as the incremental system and the homing request (AxisName.Md.Homing_Request) becomes TRUE. (The absolute position data is maintained.) At this time, the absolute position system is not enabled until homing is completed. Be sure to execute homing. (When homing has been normally completed, the axis current position restoration status (AxisName.Md.PosRestoration_Status) becomes "4: Restoration Completed in Absolute Position System (RestoredInAbsSystem)".)

When the absolute position system is used, the restoration content differs depending on the axis type. For details, refer to the following.

 Page 103 Current position restoration for each axis type

In the following case, "Absolute Position Data Incorrect Warning" (warning code: 0D00H) occurs.

- The absolute position data is illegal at the current position restoration by the following causes
 - The axis type has been changed. (The axis type of the absolute position data does not match the axis variable.)
 - The absolute position data is deleted by the memory error, etc.
 - The homing request has been TRUE at backup.
 - The axis driver unit conversion (numerator/denominator) is changed.
- Even though the machine homing has been started, it has not been normally completed.
- For real drive axes, an error occurs by the following causes.
 - "Absolute position erased" is detected on the drive unit side.
 - "Polarity (607EH)" b7: position polarity of the object data is changed.
 - "Home Offset (607CH)" of the object data is changed.
 - The connected drive unit is changed.
 - The encoder resolution of the drive unit is changed.
- For real encoder axes (via drive unit), an error occurs by the following causes.
 - "Absolute position erased" is detected in the scale measurement encoder.
 - The encoder resolution of the scale measurement encoder is changed.
- For virtual encoder axes, an error occurs by the following causes.
 - The upper limit value/the lower limit value of the encoder ring counter is changed.

The object data used to obtain the detection results of absolute position erased/current position restoration impossible on the drive unit side is shown below.

Setting item Object data (<u>AxisName.PrConst.SlaveObject</u>) (SLAVE_OBJECT_REAL)	Setting details
vStatusDo1 (StatusDo1)	Determines whether the current position restoration is possible or the absolute position is erased on the drive unit side.
vStatusDo2 (StatusDo2)	Determines whether the absolute position is erased on the drive unit side.
vSupportedStatusDo1 (SupportedStatusDo1)	Obtains the supported status for each bit of StatusDo1.
vSupportedStatusDo2 (SupportedStatusDo2)	Obtains the supported status for each bit of StatusDo2.

Precautions

- All object data setting values used to obtain the detection results of absolute position erased/current position restoration impossible must be set. If even one setting value is left blank, it may not be possible to restore to the correct position.
- If a drive unit other than MELSERVO is used, the detection result of the absolute position erased of the drive unit is not obtained. When using the absolute position system with a drive unit other than MELSERVO, make sure that the drive unit is not in the absolute position erased status before the operation. If the drive unit is in the absolute position erased status, perform homing before the operation.

Connected device setting

For a real axis, the connected device with the Encoder status 1 object acquires the absolute position system setting by the SDO communication, and the current position is restored.

Set the absolute position system setting in the connected device side.

For a real axis, if the connected device does not have the Encoder status 1 object, it operates as the incremental system without an error.

For a virtual axis, it operates as the incremental system.

Homing request

The homing request (AxisName.Md.Homing_Request) will be TRUE in the following cases.



The reason why the homing request (AxisName.Md.Homing_Request) became TRUE is recorded in event history.

Absolute position control setting (<u>AxisName.PrConst.PosRestoration_AbsPosEnable</u>)*1	Cause	Detection timing*2
Common	The system power is turned ON or reset.*3	At the system power ON or after reset
	The axis type is changed.	At the current position restoration
	Homing is started. (The homing request flag will not become FALSE unless homing is normally completed.)	At homing start
	The axis driver unit conversion (numerator/denominator) is changed.	At current position restoration At the PLC READY ON
	The drive unit power turns on.*3 (The real drive axis only)	At current position restoration
Disable absolute position system	The current position restoration is executed.	At the current position restoration

Absolute position control setting (AxisName.PrConst.PosRestoration_AbsPosEnable) ^{*1}	Cause	Detection timing ^{*2}
Enable absolute position system	Since the absolute position data has been erased by the memory error, etc..	At the current position restoration
	Change of the drive unit and the motor encoder is detected.	
	Only for real drive axes	
	"Polarity (607EH)" b7: position polarity of the object data is changed.	At the current position restoration and cause occurring
	An electric gear is changed on the drive unit side.	
	"Absolute position erased" is detected on the drive unit side.	At the current position restoration
	Only for real encoder axes (via drive unit)	
	"Absolute position erased" is detected by the scale measurement encoder.	
	The encoder resolution of the scale measurement encoder is changed.	
	Only for virtual encoder axes	
	The upper limit value/lower limit value of the encoder ring counter is changed.	

*1 For the "-1: Automatic Setting (Acquire from Connected Device) (Auto)" setting, refer based on the connected device setting.

*2 When the homing required or not (AxisName.Pr.Homing_Required) is FALSE, the homing request (AxisName.Md.Homing_Request) will not become TRUE even though the cause is occurring at the current position restoration.

*3 When the system/drive unit power is OFF when "1: Enable Absolute Position System (Enabled)" is set and the homing is completed at resetting, the homing request will not become TRUE.

Absolute position data backup

When the absolute position system is used, the absolute position data of each axis is backed up. The absolute position data is backed up linked to the axis variable and the axis type. At the current position restoration, if the setting values do not match with the axis variable and the axis type of the absolute position data, the absolute position data will be discarded. ("Absolute Position Data Incorrect Warning" (warning code: 0D00H) occurs.)

At the current position restoration, if the setting values match with the axis variable and the axis type of the absolute position data, the absolute position data will be taken over even when the variable names are different.

Ex.

When the following operations are performed, Axis0002 takes over the absolute position data of Axis0001.

- Deletes an axis (Variable name: Axis0001, Axis No.: 1, Axis type: Real drive axis) and executes writing
- Adds an axis (Variable name: Axis0002, Axis No.: 1, Axis type: Real drive axis) and executes writing
- Executes the current position restoration

Backup is executed while the homing request (AxisName.Md.Homing_Request) is FALSE. (When the homing request (AxisName.Md.Homing_Request) becomes TRUE, the absolute position data is discarded.)

Backups will take place in intervals of 2 [s] from the previous backup.

- Storage folder and file name

The following shows the storage folder and file name of the backed up absolute position data.

- Storage folder: /lch
- File name: abs_axis.bin

- Memory capacity

Memory capacity of the absolute position data differs depending on the axis type. Specify memory capacity of the absolute position data according to the axis type and the number of axes. Memory capacity per one axis for each axis type is shown below.

Axis type	Memory capacity [byte/axis]
Real drive axis	220
Real encoder axis	170
Virtual drive axis	90
Virtual encoder axis	170
Virtual linked axis	90

Memory capacity used for the absolute position data can be specified in Maximum Backup RAM Size (System.PrConst.AddonAbsSystem.BackupRamSizeMax).

If the file size required for backup exceeds specified memory capacity when the current position of each axis is restored, "Insufficient Current Position Backup Capacity" (error code: 1ADFH) occurs and the target axis is not restored completely. Reconsider the memory capacity and carry out software reboot.

Saving (backup) and restoration (restored) of the absolute position data

The absolute position data maintained inside the motion system can be data saved/restored by saving/restoring functions of the engineering tool, etc. When exchanging the Motion module, restarting time can be shortened by saving/restoring not only programs and parameters but also the absolute position data.

During backup or restoration, the motion system stops backing up the absolute position data. Do not turn OFF the power of the motion system during backup or restoration.


After restoring is completed, software reboot is required to enable the restored absolute position data. (The backup is maintained stop and it cannot be cleared until software reboot is carried out.)

For real drive axis, the homing request (AxisName.Md.Homing_Request) becomes TRUE when the restored absolute position data is different from HomeOffset (home position), the device, and the resolution of the connected drive unit.

Ex.

When saving absolute position data to an SD memory card

1. Set "ABCDH: Backup stop request" in Backup/Restore Request (System.Cd.BackupRestore).
2. Confirm Backup/Restore Information (System.Md.BackupRestoreStatus) changes to "1: Backup stop required" and "2: Backup stop".
3. Transfer absolute position data "/lch/axis_abs.bin" to an arbitrary folder in an SD memory card by using file transfer (Execution data backup).
4. Set "0000H: No request" to Backup/Restore Request (System.Cd.BackupRestore) after confirming file transfer (Execution data backup).
5. Confirm Backup/Restore Information (System.Md.BackupRestoreStatus) changes to "3: Backup stop canceled" and "0: Backup restore not executed".




Point

- The current position of moved axes after backup stop is not saved.
To execute backup after confirming all axes stop is recommended.
- When performing the current position restoration using 32-bit restoration, if the value of the current position (Position actual value) has changed by equal to or more than the signed 32-bit integral number range since the last backup, the current position after reconnection of the drive unit becomes an abnormal value.

Ex.

When restoring absolute position data saved in an SD memory card

1. Set "ABCDH: Backup stop request" to Backup/Restore Request (System.Cd.BackupRestore).
2. Confirm Backup/Restore Information (System.Md.BackupRestoreStatus) changes to "1: Backup stop required" and "2: Backup stop".
3. Transfer the "axis_abs.bin" file backed up in an arbitrary folder in an SD memory card by using file transfer (Execution data backup).
4. Set "FFFEH: Restored data saving request" to Backup/Restore Request (System.Cd.BackupRestore) after confirming file transfer (Execution data backup).
5. Confirm Backup/Restore Information (System.Md.BackupRestoreStatus) changes to "4: Restored data saving" and "5: Restored data saving completed".
6. Carry out software reboot and enable restored data.


Point

After saved data required, the absolute position data of motion system may break if software reboot is carried out or power is supplied again before Backup/Restore Information (System.Md.BackupRestoreStatus) changes to "5: Restored data saving completed". Carry out restoration again.

Current position restoration for each axis type

This section describes the current position restoration for each axis type.

Real drive axis

Each current position is restored as the following.

Current position			Incremental system	Absolute position system	
				Reference position	
				Backup position	Home position
Machine feed value			Restored in "0.0".	Differs depending on the restoration method. For details, refer to the following. 👉 Page 103 Absolute position system	
Cumulative current position				The same value as restored machine feed value.	
Set position	Ring counter enabled selection	Disabled		The same value as restored cumulative current position.	
		Enabled		Restored in the backup data value.*1	A value obtained by rounding the restored machine feed value with the ring counter range.

*1 If the setting for the ring counter upper limit value or the ring counter lower limit value is changed after homing, proper restoration may not be achieved as restoration is based on the backup data before change. Perform homing again in this case.

- When current position change is executed, the current positions restored after the motion system or drive unit is powered on again are as follows.

Current position			Reference position	
			Backup position	Home position
Machine feed value			— (No position change after current position change)	
Cumulative current position			Returns to the position before current position change.	Returns to the position before current position change.
Set position	Ring counter enabled selection	Disabled	The position after current position change	
		Enabled		

Current position restoration timing

When an object data that constructs the absolute position system to execute the 64-bit current position restoration is required, restoration is automatically executed at the initial communication with the device station. For details on the absolute position system to execute the 64-bit current position restoration, refer to the following.


☞ Page 94 Absolute position system

The servo ON status is not established until the current position restoration is completed.

Absolute position system

This section describes precautions for constructing the absolute position system in a real drive axis.

The following shows the absolute position system configuration when the drive unit is used as the servo amplifier.



A drive unit/servo motor which can detect the absolute position must be used to construct the absolute position system.

For details on the absolute position system setting of the drive unit side, refer to each drive unit manual.

For MR-J5(W)-G: ☞ MR-J5-G/MR-J5W-G User's Manual (Parameters)

- The current position restoration of the absolute position system can be classified into the following three methods.

Current position restoration method	Basis position	Description	Remark
32-bit restoration (Drive unit current position restoration)	Backup position	Correctly executes the current position restoration within the signed 32-bit integral number range [driver-based] from the reference position. Restores by using position data backed up by the motion system.	<ul style="list-style-type: none"> • If the object data required to construct the 64-bit absolute position system is not set, the 32-bit current position restoration is used. • 64-bit restoration is the home position restoration when the device station to be connected is changed.
64-bit restoration (Drive unit ABS counter position restoration)	Backup position	Correctly executes the current position restoration within up to the signed 64-bit integral number range ^{*1} [driver-based] from the reference position. Restores by using position data backed up by the motion system.	
	Home position	Correctly executes the current position restoration within up to the signed 64-bit integral number range ^{*1} [driver-based] from the reference position. Restores based on the drive unit current position.	

^{*1} Actual restoration possible range is shown below.

- ((Multiple revolution counter maximum value) / 2 × (Encoder resolution)) to ((Multiple revolution counter maximum value) / 2 × (Encoder resolution) - 1)

Point

In the real drive axis, which method was used for the current position restoration of the absolute position system, "32-bit restoration (backup position), 64-bit restoration (backup position), or 64-bit restoration (home position)" is recorded in the event history.

- The following shows the object data required to construct the 64-bit absolute position system.

If any one of the above parameters is not specified, 32-bit restoration is executed.

Setting item Slave Object Data (AxisName.PrConst.SlaveObject) (SLAVE_OBJECT_REAL)	Setting description
vHomeCycleCounter(HomeCycleCounter)	Specifies the object ID storing the encoder position within one revolution at homing.
vHomeAbsCounter(HomeAbsCounter)	Specifies the object ID storing the encoder multiple revolution counter at homing.
vInitialPos(InitialPos)	Specifies the object ID storing Position actual value at connection.
vInitialCycleCounter(InitialCycleCounter)	Specifies the object ID storing the encoder position within one revolution at connection.
vInitialAbsCounter(InitialAbsCounter)	Specifies the object ID storing the encoder multiple revolution counter at connection.
vMaxAbsCounter(MaxAbsCounter)	Specifies the object ID storing the maximum value of the multiple revolution counter.

Precautions

- Even if the above parameters have been specified, "Driver Restoration Data Incorrect" (error code: 1AE0H (detail code: 0001H)) will occur and the current position restoration may not be completed. Execute reconnecting after correcting the parameter of the drive unit.
- If the encoder resolution or the maximum value of the encoder multiple revolution counter is other than 2 to the power of n, 32-bit restoration is executed.
- When executing 32-bit restoration, if the value of the current position (Position actual value) has changed by equal to or more than the signed 32-bit integral number range while the drive unit is connected, the current position after the drive unit is connected becomes an abnormal value. Perform homing if necessary.
- When performing 32-bit restoration, if a disconnection or power off occurs during operation at a drive unit command velocity of "1073741824 U/s" or higher, the current position may not be restored normally. Perform homing if necessary.
- For MR-J5(W)-G

When the drive unit cannot restore the current position, "Driver Restoration Data Incorrect" (error code: 1AE0H (detail code: 0001H)) will occur in the motion system, and the current position restoration is not completed. The current position may be restored by checking the status of the drive unit and reconnecting it. During reconnection, when homing request becomes TRUE, execute homing again.

■When using MR-J5(W)-G

The following describes the settings and the current position restoration method when the absolute position system is constructed using MR-J5(W)-G.

- MR-J5(W)-G setting

Select "1: Enabled (absolute position detection system)" in "Absolute position detection system selection" (PA03.0) of the servo parameter (basic setting). In addition, select "0: Disabled" in "Absolute position counter warning (AL. E3)" selection (PC29.5) of the servo parameter (extension setting).

Depending on the "Electronic gear numerator (PA06)" and "Electronic gear denominator (PA07)" setting of the servo parameter, "Driver Restoration Data Incorrect" (error code: 1AE0H) may occur. Correct the following.

- When the resolution of the connected encoder is 2 to the power of n, set the electronic gear of MR-J5(W)-G to be "1 : 1" or multiple of 2 to the power of n.
- When the resolution of the connected encoder is other than 2 to the power of n, set the electronic gear of MR-J5(W)-G to "1 : 1".

- The motion system setting

Select "-1: Automatic Setting (Acquire from Connected Device) (Auto)" or "1: Enable Absolute Position System (Enabled)" in Absolute Position Control Setting (AxisName.PrConst.PosRestoration_AbsPosEnable) in the real drive axis whose connected device is MR-J5(W)-G.

- The current position restoration method

Execute the 64-bit current position restoration.

Real encoder axis

Each current position is restored as follows.

Current position	Incremental system	Absolute position system
Cumulative current position	Restored in "0.0".	Restores based on the synchronous encoder movement amount by using backup data of the motion system. Follows up the movement amount after restoration completion when the axis status transits to Standby (Standstill) for the first time after restoration completion.
Set position	A value which rounds the restored cumulative current position with the ring counter.	

The restoration method for the absolute position system is depending on Real Encoder Axis Type Setting (AxisName.PrConst.Encoder_AxisType) of the axis parameter shown below.

Real encoder axis type	Current position restoration method	Description	Remark
Via drive unit	64-bit current position restoration	Correctly executes the current position restoration within up to the signed 64-bit integral number range*1 [encoder pulse unit] from the backup position.	Only the synchronous encoder connected to the drive unit can be used. For details on the setting, refer to the following. ☞ Page 30 Axis

*1 Actual restoration possible range is shown below.

- ((Multiple revolution counter maximum value) / 2 × (Encoder resolution)) to ((Multiple revolution counter maximum value) / 2 × (Encoder resolution - 1))

■Current position restoration timing

Current position restoration is executed after the real drive axis of the same station address is connected.

Virtual drive axis

Each current position is restored as follows.

Current position	Incremental system	Absolute position system
Cumulative current position	Restored in "0.0".	Restored in the backup data value.
Set position	A value which rounds the restored cumulative current value with the ring counter.	

■Current position restoration timing

Current position restoration is executed at the axis variable initialization. For details on the axis variable initialization timing, refer to the following.

☞ Page 33 Axis variable initialization timing

Virtual encoder axis

Each current position is restored as follows.

Current position	Incremental system	Absolute position system
Cumulative current position	Restored in "0.0".	Restores the current position based on the movement amount from the backup data to the position at restoration. Correctly executes the current position restoration within the signed 32-bit integral number range [encoder pulse unit] from the backup position. Follows up the movement amount after restoration completion when the axis status transits to Standby (Standstill) for the first time after restoration completion.
Set position	A value which rounds the restored cumulative current position with the ring counter.	

■Current position restoration timing

Executes the current position restoration as Connection Command (AxisName.Cd.Encoder_Connect) becomes TRUE.

Virtual linked axis

Each current position is restored as follows.

Current position	Incremental system	Absolute position system
Cumulative current position	Restored in "0.0".	Restored in the backup data value.
Set position	A value which rounds the restored cumulative current value with the ring counter.	

■Current position restoration timing

Current position restoration is executed at the axis variable initialization. For details on the axis variable initialization timing, refer to the following.

📖 Page 33 Axis variable initialization timing

Precautions

- In the absolute position control setting, when the connected device side setting and the motion system side setting are mismatched, the absolute position control may not be executed correctly. (If there is the Encoder status 1 object in the connected device, "Absolute Position Control Setting Mismatch" (error code: 1A9AH) will occur at current position restoration.)
- If the homing required or not (AxisName.Pr.Homing_Required) is set to TRUE, address information stored in the motion system is not guaranteed.
- During backup/restoration by the engineering tool, do not write in Backup/Restore Request (System.Cd.BackupRestore).
- A backup file created with a different model can be used. However, current position restoration can only be executed for the number of axes of the backup file.

Ex.

When a backup file is created with a 4-axis model, and the backup file is moved to an 8-axis model.
Current position restoration is executed for 4 axes and the not for the remaining 4 axes.

Version combinations

This function varies depending on the version used as follows.

Motion system software version	Details
"36" or later	The absolute position system can be used with a drive unit other than MELSERVO.
"34" or earlier	When the absolute position system is used with a drive unit other than MELSERVO, the current position restoration fails and the axis status does not transit from "Axis disabled".

3 BASIC FUNCTIONS

3.1 Operation Cycle

In the motion system, operation processing related to the motion control is performed in the fixed cycle (operation cycle). This section describes operation cycles which can be set in the motion system.

Operation of this function for each system status

○: Possible, ×: Not possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	×

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
OperationCycle	Control Cycle Setting	Sets the control operation cycle. 0: Operate in the first operation cycle
FastOperationMode ^{*1}	Fast Operation Mode Setting	Switch the operation process of the set axis to fast operation mode. ^{*2} <ul style="list-style-type: none">• 5FE2H: Fast operation mode• Others: Normal mode

*1 In order to switch to the fast operation mode, set both the system parameter and axis parameter to the fast operation mode. If both system parameter and axis parameter are not set to the fast operation mode, it is not switched to the fast operation mode.

*2 Only the real drive axis is supported.

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
OperationCycle	Control Cycle	Stores the control operation cycle of the axis. <ul style="list-style-type: none">• 0: Not initialized/Outside the range of the operation cycle setting• 1: Operate in the first operation cycle

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
OperationCycle[1].Cycle	Operation Cycle Setting (cycle setting)	<p>Sets the first operation cycle.</p> <p>Setting and operations specific to Operation cycle setting (OperationCycle[1]) are shown below.</p> <p>■ Cycle setting (Cycle)</p> <ul style="list-style-type: none"> • 0: Synchronizes with the basic cycle of network
BuffermemoryRefreshCycle.Cycle	Buffer Memory Refresh Cycle Setting (cycle setting)	<p>Sets the buffer memory refresh cycle.</p> <p>Setting and operations specific to Buffer memory refresh cycle setting (BuffermemoryRefreshCycle) are shown below.</p> <p>■ Cycle setting (Cycle)</p> <ul style="list-style-type: none"> • 0: The nth operation cycle ("n" is the slowest operation cycle among operation cycles whose setting is enabled.) • -118192 to -110001: Multiplication by n of the first operation cycle (1 to 8192)
Link_MotionStationRefreshType	Motion Synchronization Station Send/Receive Data Refresh Method	<p>Sets the send/receive data refresh method of the motion synchronization station.</p> <ul style="list-style-type: none"> • 0: Response preferred method (EmphasisResponse) • 1: Operation cycle preferred method (EmphasisOperationCycle)
FastOperationMode ^{*1}	Fast Operation Mode Setting	<p>Switch the operation process of the entire system to fast operation mode.</p> <ul style="list-style-type: none"> • 50EFH: Fast operation mode • Others: Normal mode

*1 In order to switch to the fast operation mode, set both the system parameter and axis parameter to the fast operation mode. If both system parameter and axis parameter are not set to the fast operation mode, it is not switched to the fast operation mode.

System monitor data (System.Md.)

Variable/Structure name	Name	Details
SystemBaseCycle_Counter	System Basic Cycle Counter	<p>Stores the system basic cycle counter.</p> <p>Counts up every time when executing system basic processing.</p>

System basic cycle

The system basic cycle is a basic cycle of the motion control such as operation cycle processing. System basic cycle settings are shown below.

System basic cycle is the same as the first operation cycle.

Operation cycle settings

Operation cycle is set in Operation Cycle Setting (System.PrConst.OperationCycle[1]).

"Synchronize with the network setting" must be set to control real axes connected to the network.

A rough standard for the operation cycle settings

The following shows a reference of the operation cycle settings.


■A rough standard for the number of axes and the operation cycle settings when using the positioning control

A rough standard is shown below when using real axis set as the axes group of two axes each and performing positioning control repeatedly.

Operation cycle	RD78G4	RD78G8	RD78G16	RD78G32	RD78G64	RD78GHV	RD78GHW
31.25 [μs]	—					—	
62.5 [μs]	—					—	
125 [μs]	—					2 axes	
250 [μs]	2 axes					8 axes	
500 [μs]	4 axes	8 axes				22 axes	
1.0 [ms]	4 axes	8 axes	16 axes	20axes		44 axes	
1.5 [ms]	4 axes	8 axes	16 axes	32 axes		66 axes	
2.0 [ms]	4 axes	8 axes	16 axes	32 axes	40 axes	74 axes	
3.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	96 axes	
4.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
5.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
6.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
7.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
8.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	256 axes

■A rough standard for the number of axes and the operation cycle settings when using the synchronous control

A rough standard is shown below when Synchronous control 1 in the following configuration example is one unit, Virtual drive axis 1 and Virtual drive axis 2 are controlled, and four Real drive axes are synchronized. (The number of using axes shown in the table indicates the number of real drive axes in the configuration example.)



Operation cycle	RD78G4	RD78G8	RD78G16	RD78G32	RD78G64	RD78GHV	RD78GHW
31.25 [μs]	—					—	
62.5 [μs]	—					—	
125 [μs]	—					—	
250 [μs]	—					8 axes	
500 [μs]	4 axes	8 axes				16 axes	
1.0 [ms]	4 axes	8 axes	16 axes			28 axes	
1.5 [ms]	4 axes	8 axes	16 axes			38 axes	
2.0 [ms]	4 axes	8 axes	16 axes	28 axes			48 axes
3.0 [ms]	4 axes	8 axes	16 axes	32 axes			66 axes
4.0 [ms]	4 axes	8 axes	16 axes	32 axes	48 axes	84 axes	
5.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
6.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
7.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	
8.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes	152 axes

■ A rough standard for the number of axes and the operation cycle settings for the configuration minimized system load

A rough standard when using axis operation process fast operation mode and executing MCv_Jog (JOG) by each real drive axis is shown below.

Operation cycle	RD78G4	RD78G8	RD78G16	RD78G32	RD78G64	RD78GHV	RD78GHW
31.25 [μs]	—					2 axes	
62.5 [μs]	1 axes					4 axes	
125 [μs]	4 axes					14 axes	
250 [μs]	4 axes	8 axes	14 axes			20 axes	
500 [μs]	4 axes	8 axes	16 axes	20 axes			32 axes
1.0 [ms]	4 axes	8 axes	16 axes	32 axes			64 axes
1.5 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	82 axes	
2.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	100 axes	
3.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes ^{*1}	
4.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes ^{*1}	
5.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes ^{*1}	
6.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes ^{*1}	
7.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes ^{*1}	
8.0 [ms]	4 axes	8 axes	16 axes	32 axes	64 axes	128 axes ^{*1}	256 axes ^{*1}

*1 Using Normal mode.

- Adjust the operation cycle setting depending on the system load status.
- The following functions increase the operation cycle, so use them depending on the system load status.
 - Public label
 - Device label setting
 - Instantiating and execution of the Motion control FB
 - Logging
- Set execution scan of ST programs depending on the system load status as executing ST programs by fixed scan increases operation time.
- The operation time increases when the function block starts. The increase of operation time can be reduced by changing the start timing. Note the following for parameter setting values, and adjust them depending on the system load status.
- The operation time increases at output "Cycle Over Warning" (warning code: 0F08H).
 - (1) Set 0 to number of cycle over warning detections (System.PrConst.OperationCycle[1].NumOfCycleOverWngDetectTimes), so "Cycle Over Warning" (warning code: 0F08H) will not be output.
 - (2) User needs to check the normal operation range of the number of cycle over error detections (System.PrConst.OperationCycle[1].NumOfCycleOverErrDetectTimes), and change values to avoid "Cycle Over" (error code: 1C80H) and "Cycle Over" (error code: 320CH).
- When the operation cycle is set to 31.25 [μ s], specify "1: Operation cycle preferred method (EmphasisOperationCycle)" for Operation Cycle Preferred Method (System.PrConst.Link_MotionStationRefreshType).

Operation cycle assignment

An operation cycle of the axis can be set by Control Cycle Setting (AxisName.PrConst.OperationCycle).


Send/Receive data refresh of network connected devices

Network connected devices are distinguished between stations controlled by the motion system and standard stations, and those data refresh methods are different.


Station	Explanation
Motion synchronization station	<ul style="list-style-type: none"> The motion system refreshes data by directly synchronizing the network send/receive with the operation cycle. The target link device is not refreshed.
Standard station ^{*1}	<ul style="list-style-type: none"> Stations other than motion synchronization stations are standard stations. The programmable controller refreshes data. The link device is refreshed by synchronizing with the programmable controller.

^{*1} Control by the programmable controller

- The following figure shows the relation of data areas and the refresh.



- The internal process timing of the motion system is shown below.



Motion synchronization station

Select a data refresh method from the following for motion synchronization station.

It can be set in Motion Synchronization Station Send/Receive Data Refresh Method


(System.PrConst.Link_MotionStationRefreshType). It is common in all of the operation cycles.

Motion synchronization station send/receive data refresh method	Description
Operation cycle preferred method (default)	<ul style="list-style-type: none"> Data receive, motion operation, and data send are executed in different operation cycles.
Response preferred method	<ul style="list-style-type: none"> Data receive, motion operation, and data send are executed in the same operation cycles. The timing of data update is earlier compared to operation cycle preferred method so that the responsiveness to feedback is high. More processing steps are needed in one operation cycle compared to operation cycle preferred method so that it takes long for the operation cycle processing time.

■Operation cycle preferred method

With operation cycle preferred method, data receive, operation processing, and data send are executed in different operation cycles.

For the connected device, it takes five cycles to receive a feedback to the data sent from the connected device.



Point

Slave label executes the refresh at the following timing.

- Receive data (RX, RWr): (3) Operation processing (reflect data received before two cycles from the connected station)
- Send data (RY, RWw): (4) Data send (send to the connected station after one cycle)


Real drive axis/Real encoder axis executes the refresh at the following timing.

- Receive data (TPDO): (3) Operation processing (reflect data received before two cycles from the connected station)
- Send data (RPDO): (4) Data send (send to the connected station after two cycles)

■Response preferred method

With response preferred method, data receive, operation processing, and data send are executed in one operation cycle. For the connected device, it takes three cycles to receive a feedback to the data sent from the connected device. Even though the timing of data update is earlier compared to operation cycle preferred method so that the responsiveness to feedback is high, it takes long for the operation cycle processing time because more processing steps are needed in one operation cycle.

When 31.25 [μ s] is selected in the communication cycle setting and the motion synchronization station send/receive data refresh method is set to response preferred method, "Motion Synchronization Station Send/Receive Data Refresh Method Setting Combination Error" (error code: 3229H) will occur.



Slave label executes the refresh at the following timing.

- Receive data (RX, RWr): (2) Data receive/Operation processing/Data send (reflect data received before one cycle from the connected station)
- Send data (RY, RWw): (2) Data receive/Operation processing/Data send (send to the connected station after one cycle)

Real drive axis/Real encoder axis executes the refresh at the following timing.

- Receive data (TPDO): (2) Data receive/Operation processing/Data send (reflect data received before one cycle from the connected station)
- Send data (RPDO): (2) Data receive/Operation processing/Data send (send to the connected station after one cycle)

■Slave label

The I/O data which the device station of motion synchronization stations exchanges with motion system by cyclic communication registers as labels and enables read/write. Refreshing slave labels are carried out in operation cycle. For the using and setting methods of slave label, refer to the following.

☞ Page 718 CONNECTABLE DEVICE to CC-Link IE TSN

Standard station

The following stations update the data.

- Programmable controller

For details, refer to "CC-Link IE TSN Network Synchronous Communication Function" in the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Network)

Buffer memory refresh

Data which are used to issue the Motion control FB by programmable controller and to get axis monitor information, etc. are refreshed in the buffer memory refresh cycle.

The target of the buffer memory refresh is as follows.

- Area for the Motion control FB
- Area for the public labels (module labels)

Buffer memory refresh cycle

Data used between the motion system and the programmable controller is refreshed in a buffer memory refresh cycle.

This function is set in Buffer Memory Refresh Cycle Setting (System.PrConst.BuffermemoryRefreshCycle).

Axis operation process fast operation mode

The following shows the axis operation process fast operation mode.

If it is switched to the fast operation mode, some of the functions will be restricted, but it may be able to communicate with shorter operation cycle.

Axis operation process fast operation mode restrictions

In the fast operation mode, compared to the normal mode, it has the following function restrictions.

■Function restrictions of the motion system

No.	Restriction	Detail
1	Object data unsettingtable	Operates by fixed initial setting ([OBJ] setting).
2	PDO mapping cannot be changed	Operates by fixed fast operation mode mapping. Cannot delete, add nor change the mapping objects.
3	A part of axis monitor unusable	The following monitor stops the updates. The slave feedback can be confirmed by using the device labels. Use depending on the system load status. <ul style="list-style-type: none">• Set Acceleration (AxisName.Md.SetAcceleration)• Actual Velocity (AxisName.Md.ActualVelocity)• Actual Position (AxisName.Md.ActualPosition) (For real encoder axis)• Object Data_TargetPos(AxisName.Md.lo_TargetPos)• Object Data_PosActualValue (AxisName.Md.lo_PosActualValue)• Object Data_VelActualValue (AxisName.Md.lo_VelActualValue)• Object Data_TargetVelocity (AxisName.Md.lo_TargetVelocity)• Object Data_TorqueActualValue (AxisName.Md.lo_TorqueActualValue)• Object Data_Statusword (AxisName.Md.lo_Statusword)• Drive Unit Error Detection (AxisName.Md.DriverError)• Drive Unit Error Code (AxisName.Md.DriverErrorID)• Drive Unit Error Detail Code (AxisName.Md.DriverErrorDetailID)• Velocity Override Factor (AxisName.Md.VelocityOverride)• Acceleration Override Factor (AxisName.Md.AccelerationOverride)• Jerk Override Factor (AxisName.Md.JerkOverride)• Positive Direction Torque Limit Value (AxisName.Md.TorqueLimit_Positive)• Negative Direction Torque Limit Value (AxisName.Md.TorqueLimit_Negative)• Driver Ready On Status (AxisName.Md.Driver_ReadyOn)• Driver Servo On Status (AxisName.Md.Driver_ServoOn)• Velocity Override Factor (AxesGroupName.Md.VelocityOverride)• Acceleration Override Factor (AxesGroupName.Md.AccelerationOverride)
4	A part of axis command unusable	The input of the following command will be ignored. <ul style="list-style-type: none">• Homing Request Clear (AxisName.Cd.Homing_ClearRequest)• Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive)• Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative)• Velocity Override Factor (AxisName.Cd.VelocityOverride)• Acceleration Override Factor (AxisName.Cd.AccelerationOverride)• Velocity Override Factor (AxesGroupName.Cd.VelocityOverride)• Acceleration Override Factor (AxesGroupName.Cd.AccelerationOverride) Even if the FB is executed to change the command to be ignored, the change is not carried out.
5	Synchronous control previously used the operation cycle data is unusable	Synchronous control previously used the operation cycle data cannot be used. Use the latest operation cycle data.

■Function restrictions when combined with MR Configurator2

No.	Restriction	Detail
1	Multiple axes graph unusable	Multiple axes function cannot be used. Do not waveform measure including the fast operation mode axis.

Precautions

- In the high speed-mode, only the position control can be executed.
If used by direct control (velocity control, torque control) "Necessary Object Data Unset" (error code: 1AA8H) occurs.
- The fast operation mode of the axes group becomes valid when axes set to fast operation mode are included in configuration axes.
- Note the description in the following Point.
 Page 109 Operation cycle settings

Operation cycle 31.25 setting (Only when using RD78GH)

By using RD78GH enables to communicate by operation cycle 31.25 [μs] setting.

The procedure to operate by 31.25 [μs] is shown below.

Procedure to operate by 31.25 [μs]

■Enabling add-on

When using by 31.25 [μs], start from the minimum configuration and add required add-on depending on the system load status.

The add-ons assumed as minimum configuration are shown below.

○: Enabled, ×: Disabled

No.	Add-on name	Enabled/Disabled
1	AbsSystem	×
2	Axis	○
3	baseSystem	○
4	ExternalSignal	×
5	FileTransfer	×
6	Logging	×
7	MotionControl_AxisFilter	○
8	MotionControl_General	○
9	MotionControl_Sync	○
10	MotionEngine	○
11	MotionEventHist	×
12	NetworkDriver_CCIETSN	○
13	PackagingApp	×
14	PlcInstruction	○
15	ProfileControl	×
16	Program_ST	○
17	ServoDriver_CANOpen	○
18	ServoSystemRecorder	×
19	SignalIO	○
20	SimpleMotion	×
21	MotionControl_AdvancedSync	×

■Parameter setting

Set the axis to be operated by 31.25 [μs] to the fast operation mode. For details, refer to the following.

☞ Page 116 Axis operation process fast operation mode

Point

The system load status can be confirmed by Processing Time (System.Md.OperationCycle[1].ProcessingTime).

Do not let Processing Time (System.Md.OperationCycle[1].ProcessingTime) keep exceeding the setting operation cycle.

Precautions

- By minimum configuration add-on, the forced stop command cannot be input from the Motion module.
Depending on the system load status, adding the add-on ExternalSignal make it usable. If the operation cycle exceeds by adding this add-on, take an alternative measure such as using the forced stop input from the servo amplifier, not the forced stop command from the Motion module.
- By minimum configuration add-on, the absolute position system cannot be used. Depending on the system load status, adding add-on AbsSystem make it usable.
- By minimum configuration add-on, the data logging function cannot be used. Depending on the system load status, adding the add-on Logging make it usable.
- The operation time increases when the number of device labels increases. When the number of axis is 1-axis and using the device labels, adjust the number of device labels depending on the system load status. When the number of axis is 2-axes, do not use the device labels. The operation cycle exceeds at start of function block, but soon the operation time settles within the operation cycle thus the motion control is not affected.

Setting example

The setting examples for operations under the 2-axis interpolation control in the operation cycle 31.25 [μs] are shown below.

■Configuration

- Real drive axis: MR-J5-G, 2-axes
- Axes group setting: 1
- Device label: No setting

■Parameter setting

- System setting

The initial value is applied for the setting value of parameters not listed below.

Item		Setting value
Buffer memory refresh cycle setting	Number of cycle over warning detections	0
	Number of cycle over error detections	20
High-speed mode setting		50EFH
Operation cycle setting	Number of cycle over warning detections	0
	Number of cycle over error detections	20

- Axis parameter

The initial value is applied for the setting value of parameters not listed below.

Item	Setting value
Absolute position control setting	0: ABSDisabled (Disable absolute position system)
High-speed mode setting	5FE2H
Command in-position width	0.0

- Axes group parameter

For the setting value of parameters other than configuration axis, the initial value is applied.

■Program

Executes the following Motion control FBs by normal execution type program of the motion ST program.

- MCv_AllPower (All Axes Operation Available)
- MC_GroupEnable (Axes Group Enabled)
- MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control)

Precaution

Combination of the version

- Response preferred method support

Tool name	Add-on name	
Motion control setting function	NetworkDriver_CCIETSN	
	"1.18" or earlier	"1.19" or later
"1.021X" or earlier	—	— (Only operation cycle preferred method can be selected)
"1.030G" or later	Operates as operation cycle preferred method regardless of the setting values of Motion Synchronization Station Send/Receive Data Refresh Method (System.PrConst.Link_MotionStationRefreshType).	—

3.2 Add-on Function

This section describes add-on Function.

The motion system functions are configured with basic functions provided by the motion system software and functions provided by the add-on library. The motion system functions can be expanded by installing add-on libraries.

For details on the standard function add-on library, refer to the following.

 Page 987 List of Add-on Library

Operation of this function for each system status

○: Possible

System status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

The following shows common variables in each add-on library.

Available variables other than the following are different depending on the add-on library. For details, refer to the specifications of each add-on library.

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
Addon_ <u>AddonLibraryName</u>	Add-on <u>AddonLibraryName</u> Parameter	Sets the maximum capacity for the memory used in Add-on <u>AddonLibraryName</u> parameter (Addon_ <u>AddonLibraryName</u>). ADDON_PARAM structure For add-on used for Addon_ <u>AddonLibraryName</u> , refer to the "system variables" in the following.  MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Addon_ <u>AddonLibraryName</u>	Add-on <u>AddonLibraryName</u> Monitor	Displays the maximum capacity for the memory used in Add-on <u>AddonLibraryName</u> parameter (Addon_ <u>AddonLibraryName</u>). ADDON_MON structure For add-on used for Addon_ <u>AddonLibraryName</u> , refer to the "system variables" in the following.  MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

ADDON_PARAM

Variable/Structure name	Name	Details
RamSizeMax	Maximum RAM Size	Specifies the maximum amount of system memory (RAM) used in the add-on in k bytes. For details on the setting method, refer to the following.  Page 123 System Memory Settings
BackupRamSizeMax	Maximum Backup RAM Size	Specifies the maximum amount of system memory (backup RAM) used in the add-on in k bytes. For details on the setting method, refer to the following.  Page 123 System Memory Settings


ADDON_MONI

Variable/Structure name	Name	Details
RamUsage	RAM Usage	Stores the current amount of system memory (RAM) used in the add-on in k bytes.
RamMaxUsage	RAM Usage Maximum	Stores the maximum amount of system memory (RAM) used in the add-on in k bytes.
BackupRamUsage	Backup RAM Usage	Stores the current amount of system memory (backup RAM) used in the add-on in k bytes.
BackupRamMaxUsage	Backup RAM Usage Maximum	Stores the maximum amount of system memory (backup RAM) used in the add-on in k bytes.
Version	Version	Stores the version information of the add-on.

Add-on library configuration

File configuration

Add-on libraries are included in the motion software package and controlled by the engineering tool. Add-on library functions can be used by installing add-on libraries in the engineering tool and the motion system.



Installation file configuration

The installation file of the software is one file.

For details, refer to the following.

📖 Page 895 Software file configuration of motion system

Provision of installation file

The installation file is provided in the MITSUBISHI ELECTRIC FA Global Website, etc.

The installation file is common between RD78G and RD78GH. (The both BootRoms are packed.)

For details on configuration of the motion software package, refer to the following.

📖 Page 895 Software file configuration of motion system

Functions configuration

Depending on the add-on library, one of the following lists or all of those are expanded.

- Axis label, system label, or control data of variables for each function (Pr./Md./Cd.)
- Function block (for the CPU module)
- Function block (for internal ST programs)

Management of add-on library

Installation/Uninstallation

Add-on libraries are installed in the system folder (/sys) of the motion system. The motion system recognizes direct add-on libraries of the system folder (/sys).

For installation of add-on libraries, refer to the following.

 Page 894 Motion System Software Installation

For the uninstallation of add-on libraries, refer to Help of the engineering tool.

Enabling/Disabling

Functions which are infrequently used, such as adjustment functions used for starting up the system and the functions for debugging used only when an error occurs, can be disabled and enabled when needed. However, unlike uninstallation, the occupied capacity of the system folder is not reduced.

The disabled add-on library is moved to /sys/disabled.

Enabling/Disabling status is reflected when the motion system is initialized next time.

Amount of memory consumed setting

Amount of memory each add-on library can consume can be changed by the parameter, and the amount of memory between each function can be adjusted flexibly according to the application.

For details on the setting method, refer to the following.

 Page 123 System Memory Settings

■ Examples of adjustable memory

- Buffer size available in logging
- Operation profile open area size
- Label area size
- ST program area


Loading add-on library

Add-on libraries are loaded when the motion system is initialized. When the loading cannot be performed because of the followings, "Add-on Library Load Error" (error code: 3205H) occurs and the motion system does not turn to RUN.

- The file of add-on library is broken.
- The add-on library with dependencies has not been installed or enabled.
- The add-on library that cannot be combined has been installed or enabled.
- The add-on library with the same name is installed or enabled.
- Inconsistency occurred in the versions of the add-on libraries.
- Inconsistency occurred in the versions of the add-on library and the software of the module.

3.3 System Memory Settings

This section describes setting methods of memory size used in the add-on library in the system memory (RAM) and the system memory (backup RAM).



3

Operation of this function for each system status

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

The following shows common variables in each add-on library.

Available variables other than the following are different depending on the add-on library.

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
Addon_ <u>AddonLibraryName</u>	Add-on <u>AddonLibraryName</u> Parameter	Sets the maximum capacity for the memory used in Add-on <u>AddonLibraryName</u> parameter (Addon_ <u>AddonLibraryName</u>). ADDON_PARAM structure For add-on used for Addon_ <u>AddonLibraryName</u> , refer to the "system variables" in the following. MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Addon_ <u>AddonLibraryName</u>	Add-on <u>AddonLibraryName</u> Monitor	Displays the maximum capacity for the memory used in Add-on <u>AddonLibraryName</u> parameter (Addon_ <u>AddonLibraryName</u>). ADDON_MONI structure For add-on used for Addon_ <u>AddonLibraryName</u> , refer to the "system variables" in the following. MELSEC iQ-R Programming Manual (Motion Control Function Blocks)
MemoryUsage	System Memory Usage	Stores the current usage amount and the maximum usage amount for the system memory (RAM) and system memory (backup RAM). ADDON_MON structure
MemorySize	System Memory Size	Stores the maximum usage amount for the system memory (RAM) and system memory (backup RAM). ADDON_PARAM structure

ADDON_PARAM

Variable/Structure name	Name	Details
RamSizeMax	Maximum RAM Size	Specifies the maximum amount of system memory (RAM) used in the add-on in k bytes. For details on the setting method, refer to the following.  Page 124 System memory (RAM) usage setting method
BackupRamSizeMax	Maximum Backup RAM Size	Specifies the maximum amount of system memory (backup RAM) used in the add-on in k bytes. For details on the setting method, refer to the following.  Page 125 System memory (backup RAM) usage setting method

ADDON_MONI

Variable/Structure name	Name	Details
RamUsage	RAM Usage	Stores the current amount of system memory (RAM) used in the add-on in k bytes.
RamMaxUsage	RAM Usage Maximum	Stores the current amount of system memory (backup RAM) used in the add-on in k bytes.
BackupRamUsage	Backup RAM Usage	Stores the maximum amount of system memory (backup RAM) used in the add-on in k bytes.
BackupRamMaxUsage	Backup RAM Usage Maximum	Stores the maximum amount of system memory (backup RAM) used in the add-on in k bytes.
Version	Version	Stores the version information of the add-on.

System memory (RAM)

System memory (RAM) stores the data used for the control in an add-on library.

The following shows the total size of system memory (RAM).

Model	RD78G	RD78GH
System memory (RAM) size	96M bytes	256M bytes

System memory (RAM) usage setting

The amount of system memory (RAM) available in each add-on library is set by Maximum RAM Size (System.PrConst.Addon_AddonLibraryName.RamSizeMax). Memory usage between each function can be flexibly adjusted according to the application with this parameter.

System memory (RAM) usage setting method

- The maximum amount of system memory (RAM) used in the add-on can be set by the engineering tool.
 - The maximum usage of system memory (RAM) can be set in k bytes.
 - The set maximum usage is applied at system start.
- The current usage amount and the maximum usage amount for the system memory (RAM) used in the add-ons can be monitored by the following variables. The value is stored in k bytes.
 - RAM Usage (System.Md.Addon_AddonLibraryName.RamUsage)
 - RAM Usage Maximum (System.Md.Addon_AddonLibraryName.RamMaxUsage)
- The current usage amount and the maximum usage amount for system memory (RAM) used in the all add-ons can be monitored by the following variables. The value is stored in k bytes.
 - RAM Usage (System.Md.MemoryUsage.RamUsage)
 - RAM Usage Maximum (System.Md.MemoryUsage.RamMaxUsage)

■Examples of adjustable memory

- Buffer size available in logging
- Operation profile open area size
- Axis/variable instance size (It determines the total number of available axes.)
- ST program area (It determines the maximum number of program steps.)

System memory (backup RAM)

System memory (backup RAM) is a file system (latch drive) which stores the backup data used for the control in an add-on library.

System memory (backup RAM) size is as shown below.

Model	RD78G	RD78GH
System memory (backup RAM) size	232k bytes	472k bytes

System memory (backup RAM) usage setting

The amount of system memory (backup RAM) available in each add-on library is set by Maximum Backup RAM Size (`System.PrConst.Addon_AddonLibraryName.BackupRamSizeMax`). Memory usage between each function can be flexibly adjusted according to the application with this parameter.

System memory (backup RAM) usage setting method

- The maximum amount of system memory (backup RAM) used in the add-on can be set by the engineering tool.
 - The maximum usage of system memory (backup RAM) can be set in k bytes.
 - The set maximum usage is applied at system start.
- The current usage amount or the maximum usage amount for the system memory (RAM) used in add-on can be monitored by the following variables. The value is stored in k bytes.
 - Backup RAM Usage (`System.Md.Addon_AddonLibraryName.BackupRamUsage`)
 - Backup RAM Usage Maximum (`System.Md.Addon_AddonLibraryName.BackupRamMaxUsage`)
- The current usage amount and the maximum usage amount for system memory (RAM) used in the all add-ons can be monitored by the following variables. The value is stored in k bytes.
 - Backup RAM Usage (`System.Md.MemoryUsage.BackupRamUsage`)
 - Backup RAM Usage Maximum (`System.Md.MemoryUsage.BackupRamMaxUsage`)

■ Examples of adjustable memory

- Number of ABS axes
- Number of event history storage
- Number of synchronous restoration function axes

Point

If the maximum usage of system memory (backup RAM) is changed, the backup data stored in the system memory (backup RAM) will be cleared.

Precautions

- The system memory usage can increase/decrease depending on the usage of add-on libraries. Allow a margin for the maximum memory to use.
- When more system memory capacity is required during RUN, an error or a warning is output for each add-on library. If memory cannot be secured in the function that affects the control, the whole motion system stops as the WDT error.

3.4 Software Reboot

The software reboot (system reset) is executed by writing the reboot command to the control command. When "Clear" is specified at the software reboot request, the system restarts and all data of the system is deleted.

This function is used to fetch parameters again and reset the motion system to the factory setting without stopping the system caused by the system power ON again.

The software reboot can execute reset and clear by setting a target specified value in Software Reboot Request (System.Cd.SoftRebootRequest).

Action	Software Reboot Request (System.Cd.SoftRebootRequest)	Target	Details
Reset	MOTION_RESET	Motion area	Resets parameters and control data.
Clear	MOTION_CLEAR	Motion area	Clears built-in memory.
Quick clear	MOTION_QCLEAR	Motion area	Clears built-in memory quickly.

Software Reboot Enabled (System.PrConst.SoftReboot_Enable) setting must be allowed (TRUE) to execute the software reboot. If the software reboot is executed with the setting prohibited (FALSE), the software reboot will not be executed and "Software Reboot Disabled Warning" (warning code: 0F00H) will be detected.

Register event history (type: operation power ON/reset) after the software reboot.

Relevant variables

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
SoftReboot_Enable	Software Reboot Enabled	Sets the software reboot execution enable/disable. When prohibited, the software reboot is not executed. <ul style="list-style-type: none">• FALSE: Disabled• TRUE: Enabled

System control data (System.Cd.)

Variable/Structure name	Name	Details
SoftRebootRequest	Software Reboot Request	Executes the software reboot. <ul style="list-style-type: none">• MOTION_RESET: Executes a reset of the motion area only.• MOTION_CLEAR: Executes a clear of the memory after rebooting the motion area.• MOTION_QCLEAR: Executes a quick clear of the memory after rebooting the motion area.• Others: Not executed. *: The memory is deleted after the software reboot is completed (after the system restart).

Reset

This function imports parameters, etc., which are imported at system start, again without stopping the whole system. As MOTION_RESET is issued, motion area is reset, however, network area is not reset.

- The each type data and the status of the network communication after the software reboot and hardware reboot are shown below.

Item		Software reboot (MOTION_RESET)	Hardware reboot
Parameter	Module parameter (Motion/Network)	Holds parameters during operation	Imports again
	Basic settings	Imports again	
	Control data		
	Global label		
	Global label initial value		
	Program		
	Program component		
Variable/ Program	Label	Sets the default value	Sets the default value
	Device	Clear*1	Clear
	Program	Equivalent to STOP → RUN	Equivalent to STOP → RUN
Network communication		All stations are disconnected and then reconnected after restart	All stations are disconnected and then reconnected after restart
File transmission by script file		Execute	Execute
Base system software/add-on		Reload	Reload
CPU module		Continues the operation	Reset
RAM drive		Clear	Clear
Errors/warnings*2		Clear*3	Clear

*1 The outside data of the reset target is maintained.

*2 Check the event history for the error details before the software reboot.

*3 Moderate errors and major errors cannot be cleared.

- While the reset is operated, the RUN LED turns OFF.

Clear

The following data of the Motion module is deleted after the software reboot is carried out.

- User drive (/rom) storage data
- Latch drive (/lch) storage data
- Security information
- A part of system drive (/sys) storage data
- RAM drive (/ram) storage data

Point

- Write required data such as the add-on libraries, the parameters, and the programs after clear is completed.
- Since the password and key information related to security which are registered in the motion system are also deleted, set them again in needed.

- It may take some time to complete a low-level format of the drive. Approximate completion times are shown below.

Motion module	Time
RD78G	Approximately 4 minutes (could take up to 30 minutes depending on the operating environment.)
RD78GH	Approximately 9 minutes (could take up to 60 minutes depending on the operating environment.)

- While the clear is executed, the RUN LED is flashing (every 500 [ms]).
- After the clear is completed, the RUN LED turns ON. The system starts with the parameters, the programs, and the backup data, etc. deleted.
- When the clear is failure, the ERR LED is flashing (every 200 [ms]). In this case, execute clear again.

Quick clear

- The data of the Motion module is deleted after the software reboot is carried out. That data is the same as the data from the time of "Clear".
- The drive carries out quick format. Quick format can clear the data faster than low-level format ("Clear" is at run time). However, if an access to the file cannot be performed normally after quick clear by reason of file system damage, etc., execute a low-level ("Clear") format.
- While the quick clear is executed, the RUN LED is flashing (every 500 [ms]).
- After the quick clear is completed normally, the RUN LED turns ON. The system starts with the parameters, the programs, and the backup data, etc. deleted.
- When the quick clear is failed, the ERR LED is flashing (every 200 [ms]). In this case, execute quick clear or clear again.

Precautions

- It is recommended to execute the software reboot during the PLC READY OFF.
- When data reset by the software reboot is executed, the variables and status of the device station change.
- During software reset of the motion area, the communication with the engineering tool and the dedicated instruction issued from the CPU module may be completed with an error.
- When software reboot is executed while monitoring the engineering tool, incorrect variable values may appear on the monitor. In such a case, stop the monitor once after software reboot completion and restart.
- Do not turn OFF the power of the motion system while clear or quick clear is executed. "Drive Error" (error code: 3207H) may occur along with format failure of the drive (only for add-on baseSystem version "1.5" or later). In such a case, execute clear again.

This part consists of the following chapters.

4 START AND STOP

5 HOMING

6 AXIS CONTROL FUNCTION

7 DIRECT CONTROL

8 FUNCTIONS RELEVANT TO POSITION

9 FUNCTIONS RELEVANT TO VELOCITY

10 FUNCTIONS RELEVANT TO TORQUE

11 CONTROL SUB FUNCTIONS

12 COMMON FUNCTIONS

13 SYNCHRONOUS CONTROL

14 OPERATION PROFILE FUNCTION

15 ADVANCED SYNCHRONOUS CONTROL

4 START AND STOP

4.1 Start

This section describes how to start an axis of the motion system.

In the motion system, motion control can be executed by executing Motion control FBs with programs of the control CPU module, such as the PLC CPU and the C language CPU, or the motion system built-in program language such as ST language.

Starting the motion control by executing the motion FB with Axis Status (AxisName.Md.AxisStatus) of "4: Standby (Standstill)" or Axes Group Status (AxesGroupName.Md.GroupStatus) of "4: Standby (GroupStandby)" is called "start" of the axis.

Function blocks have Execute command (Execute) type and Enable (Enable) type, and these are started at the rising edge of Execute command (Execute) or Enable (Enable) which are input variables of the Motion control FB.

Operation of this function for each system status

○: Possible, ×: Not possible

System status	Operation availability
STOP	×
RUN	○
Moderate error	×
Major error	×

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
AxisStatus	Axis Status	Displays the axis status. <ul style="list-style-type: none">• 0: Axis disabled (Disabled)• 1: Stopping on error (ErrorStop)• 2: Decelerating to stop (Stopping)• 3: During homing (Homing)• 4: Standby (Standstill)• 5: During positioning operation (DiscreteMotion)• 6: During continuous operation (ContinuousMotion)• 7: During synchronous operation (SynchronizedMotion)
UseInGroup	Using Axes Group	Displays whether the axis is being used in the axes group or not. <ul style="list-style-type: none">• FALSE: Not used• TRUE: Used
Homing_Request	Homing Request	Displays whether homing is required or not. Becomes FALSE when the homing is completed. <ul style="list-style-type: none">• FALSE: No homing request• TRUE: Homing request
HwStrokeLimit_FlsStatus	Upper Limit Signal Status	Displays the detection status of the upper limit signal (FLS). <ul style="list-style-type: none">• FALSE: Detecting the upper limit signal (FLS)• TRUE: Not detecting the upper limit signal (FLS)
HwStrokeLimit_RlsStatus	Lower Limit Signal Status	Displays the detection status of the lower limit signal (RLS). <ul style="list-style-type: none">• FALSE: Detecting the lower limit signal (RLS)• TRUE: Not detecting the lower limit signal (RLS)
ForcedStop_Released	Forced Stop Cancelling	Displays the forced stop cancel status. <ul style="list-style-type: none">• FALSE: Forced stop• TRUE: Forced stop release
StopStatus	Stop Status	Displays the input status of the stop signal (STOP). <ul style="list-style-type: none">• FALSE: Stop processing released• TRUE: During stop processing

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
GroupStatus	Axes Group Status	Displays the axes group status <ul style="list-style-type: none"> • 0: Axes group disabled (GroupDisabled) • 1: Stopping on error (GroupErrorStop) • 2: Decelerating to stop (GroupStopping) • 4: Standby (GroupStandby) • 5: Operating (GroupMoving)

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Ready	Ready	Displays the ON/OFF status of the READY. <ul style="list-style-type: none"> • FALSE: OFF (Not READY) • TRUE: ON (READY)
Sync	Synchronization flag	Displays the ON/OFF status of the synchronization flag. <ul style="list-style-type: none"> • FALSE: OFF (Module access disabled) • TRUE: ON (Module access enabled)

System control data (System.Cd.)

Variable/Structure name	Name	Details
SequenceReady	PLC Ready	Specifies RUN/STOP of PLC READY. <ul style="list-style-type: none"> • FALSE: STOP • TRUE: RUN *: Becomes TRUE/FALSE automatically by rising/falling of the Motion module.



Note the following when switching STOP/RUN by operating PLC Ready (System.Cd.SequenceReady).

- When setting PLC Ready (System.Cd.SequenceReady) to the public label, do not operate PLC Ready of the Motion module. STOP/RUN may not be switched correctly.
- The STOP/RUN status of the CPU module and the Motion module do not interlock. Even if the CPU module turns to STOP status with the axis controlled state by Motion control FB of the CPU module side, the axis control does not stop. Monitor the CPU operating status by the Motion module side program as necessary and stop the axis control. "CPU operating status of own station (SB004C)" or "CPU status of own station (SW004B)" shows the CPU operating status. For "CPU operating status of own station (SB004C)" and "CPU status of own station (SW004B)", refer to "List of Link Special Relay (SB)" and "List of Link Special Register (SW)" in the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Network)

When the stop error occurs in the CPU module, the Motion module also turns to STOP automatically.

Starting conditions

To start the control, the following conditions must be satisfied.

The necessary conditions must be incorporated in the program so that the axis is not started when the conditions are not satisfied.

Starting conditions of the axis are mainly controlled by the state transition and the signal state of the axis and axes group.

Starting conditions for motion function blocks of the axis

■State transition

Name	State	Variable name
Axis Status	4: Standby (Standstill)	<u>AxisName</u> .Md.AxisStatus

■Signal state

Signal name		Signal state		Variable name
I/O signal	PLC Ready	ON	RUN	System.Cd.SequenceReady
	Ready	ON	Ready	System.Md.Ready
	Synchronization flag	ON	Module access enabled	System.Md.Sync
	Using Axes Group	FALSE	Not used	<u>AxisName</u> .Md.UseInGroup
	Homing Request	FALSE	Homing request FALSE	<u>AxisName</u> .Md.Homing_Request
External signal	Forced Stop Cancelling	TRUE	Emergency stop input FALSE (Forced stop cancel)	<u>AxisName</u> .Md.ForcedStop_Released
	Upper Limit Signal Status	FALSE	Within the upper limit range	<u>AxisName</u> .Md.HwStrokeLimit_FlsStatus
	Lower Limit Signal Status	FALSE	Within the lower limit range	<u>AxisName</u> .Md.HwStrokeLimit_RlsStatus
	Stop Status	FALSE	Stop signal (STOP) FALSE	<u>AxisName</u> .Md.StopStatus

Starting conditions for motion function blocks of the axes group

■State transition

Name	State	Variable name
Axis Status	4: Standby (Standstill)	<u>AxisName</u> .Md.AxisStatus
Axes Group Status	4: Standby (GroupStandby)	<u>AxesGroupName</u> .Md.AxesGroupStatus

■Signal state

Signal name		Signal state		Variable name
I/O signal	PLC Ready	ON	RUN	System.Cd.SequenceReady
	Ready	ON	Ready	System.Md.Ready
	Synchronization flag	ON	Module access enabled	System.Md.SyncFlag
	Homing Request	FALSE	Homing request FALSE	<u>AxisName</u> .Md.Homing_Request
External signal	Forced Stop Cancelling	TRUE	Emergency stop input FALSE (Forced stop cancel)	<u>AxisName</u> .Md.ForcedStop_Released
	Upper Limit Signal Status	FALSE	Within the upper limit range	<u>AxisName</u> .Md.HwStrokeLimit_FlsStatus
	Lower Limit Signal Status	FALSE	Within the lower limit range	<u>AxisName</u> .Md.HwStrokeLimit_RlsStatus
	Stop Status	FALSE	Stop signal (STOP) FALSE	<u>AxisName</u> .Md.StopStatus

4.2 Retrigger/Continuous Update

How to re-import input variables of a Motion control FB in execution will be described below.
Retrigger and continuous update are available for re-importing input variables.

Re-importing input variables enables control change without interrupting the operation of the Motion control FB in execution.
When a control change is applied to a Motion control FB being buffered by multiple start of the Motion control FB, the change will be reflected at the Motion control FB switching.

Retrigger

To a Motion control FB whose start condition is Execute command (Execute), a retrigger can be executed by the re-rising edge.

For input variables that can be changed at retrigger, refer to the specification of each Motion control FB.

Continuous update

If Continuous update (ContinuousUpdate) is TRUE when executing Motion control FBs, input variables will be continuously imported.

For input variables that can be imported, refer to each Motion control FB specification.

Precautions

- The fetch cycle of each input variable depends on the longest of the cycles listed below. When re-importing variables, be sure to secure time longer than the said cycle.
 - Execution cycle of POU that calls the Motion control FB
 - Buffer memory refresh cycle (Only when using the Motion control FB on the CPU module side)
 - Operation cycle
- Control changes immediately after execution and before termination of a Motion control FB may be ignored.
 - Immediately after execution: During Analyzing (AxisName.Md.Analyzing) is TRUE
 - Immediately before termination: Immediately before Execution completion (Done) becomes TRUE
- Even if control change is applied to a buffering FB, the control in operation may be affected.

4.3 Multiple Start (Buffer Mode)

Motion control FBs can be executed continuously without stopping multiple Motion control FBs by executing the motion FB of another instance to the axis and the axes group that are executing the Motion control FB.

Point

- To execute the Motion control FB with the axis and the axes group stop status ("4: Standby (Standstill)" or "4: Standby (GroupStandby)") is called "start". For details, refer to the following.
 Page 130 Start
 - When Axis Status (AxisName.Md.AxisStatus) and Axes Group Status (AxesGroupName.Md.GroupStatus) are as the following, to execute the motion FB of another instance is called "multiple start".
[Axis Status (AxisName.Md.AxisStatus) that can be multiple started]
 - 3: During homing (Homing) (Only MC_Stop (Forced Stop) is possible)
 - 5: During positioning operation (DiscreteMotion)
 - 6: During continuous operation (ContinuousMotion)
 - 7: During synchronous operation (SynchronizedMotion)
[Axes Group Status (AxesGroupName.Md.GroupStatus) that can be multiple started]
 - 5: Operating (GroupMoving)
 - Multiple start of the single axis control FB cannot be executed to an axis operated in the axes group. If the operation stops due to the multiple start, it will cause "Motion FB Issue Error to the Axis during Axes Group Operating" (error code: 1A7CH). Otherwise, "Start Not Possible" (error code: 1AADH) will occur.
-

Buffer mode type

The following types can be specified to the buffer mode, and the type that can be specified differs depending on the FB.

Setting value	Buffer mode type	Description	Reference	
			During single axis operation	During multiple axes operation
0: mcAborting	Aborting	Aborts (cancels) the under-control FB and executes the next FB immediately.	 Page 142 Aborting during single axis operation	 Page 149 Aborting during multiple axes operation
1: mcBuffered	Buffered	Buffers the next FB on the under-control FB. If the under-control FB already has an FB buffering on it, subsequent FBs are buffered consecutively. (Up to 2.) Buffering FBs are executed in order after completion of the under-control FB.	 Page 143 Buffered during single axis operation	 Page 150 Buffered during multiple axes operation
2: mcBlendingLow	BlendingLow	Buffers the next FB on the under-control FB.*1 If the under-control FB already has an FB buffering on it, subsequent FBs are buffered consecutively. (Up to 2.) Buffering FBs are executed in order after the under-control FB reaches the target position. The lower target velocity between the under-control FB and the buffering FB is used as the switching speed.	 Page 145 BlendingLow	 Page 152 BlendingLow
3: mcBlendingPrevious	BlendingPrevious	Buffers the next FB on the under-control FB.*1 If the under-control FB already has an FB buffering on it, subsequent FBs are buffered consecutively. (Up to 2.) Buffering FBs are executed in order after the under-control FB reaches the target position. The switching speed changes to the target velocity of the under-control FB.	 Page 144 BlendingPrevious	 Page 151 BlendingPrevious
4: mcBlendingNext	BlendingNext	Buffers the next FB on the under-control FB.*1 If the under-control FB already has an FB buffering on it, subsequent FBs are buffered consecutively. (Up to 2.) Buffering FBs are executed in order after the under-control FB reaches the target position. The switching speed changes to the target velocity of the buffering FB.	 Page 144 BlendingNext	 Page 151 BlendingNext
5: mcBlendingHigh	BlendingHigh	Buffers the next FB on the under-control FB.*1 If the under-control FB already has an FB buffering on it, subsequent FBs are buffered consecutively. (Up to 2.) Buffering FBs are executed in order after the under-control FB reaches the target position. The switching speed changes to the higher target velocity value between the under-control FB and the buffering FB.	 Page 145 BlendingHigh	 Page 152 BlendingHigh

*1 Stops are not performed between the under-control FB and the buffering FB.

- Up to two motion FBs can be buffered after multiple start in one axis and an axes group. If multiple start is executed when two FBs have already been multiple started, "Warning Starting over Number of Buffering FBs" (warning code: 0D22H) occurs and waits the analysis of the buffering FB until under-control FB is completed. Even though the warning occurs each multiple start, filter setting can be set not to detect the warning. For details on filter setting, refer to the following.

 Page 909 Checking Errors and Warnings

When an error or a stop cause occurred in the under-control FB, FBs which are waiting for the analysis are interrupted.


- When "Warning starting over number of buffering FBs" (warning code: 0D22H) occurs, note that not to execute the multiple start until the under-control FB is completed. If the multiple FBs are waiting for the analysis by the multiple start, the next buffering FB may not be in order.
- Since multiple started FBs are executed immediately when Aborting has been specified, the FBs are not buffered. When the under-control FBs include a buffering FB, all buffering FBs are interrupted. However, as the FBs which are awaiting analysis are not interrupted, those FBs start after the multiple started FBs are completed by specifying Aborting.
- When an error or a stop cause occurred in the under-control FB, all buffering FBs are interrupted (the output of Abortion of execution (CommandAborted) becomes TRUE).

Command omission at multiple start

When omitting the commanded velocity, the acceleration specification, and the deceleration specification in an FB that executes multiple start, commanded velocity of "the previous FB of buffering FB" at multiple start is taken over. If the commanded velocity input does not exist in "the previous FB of buffering FB", buffering is executed with speed 0.0.

Point

When buffering with velocity 0.0 using Blending buffer mode type, the target velocity may not be reached when the velocity of the previous FB becomes 0.0 (switching speed), and the FB may not switch. When buffering with velocity 0.0, use Buffered buffer mode type.



- When FB switching is executed by multiple start, velocity change is executed to the target velocity of next FB. For the velocity waveform operation when the jerk is not specified with "0.0", refer to the following.

☞ Page 358 Acceleration/deceleration method

- When multiple FBs are multiple started at the same execution cycle, the order of FBs to be buffered is uncertain. In order to determine the buffering order, execute multiple start after checking that the previous FB is started (Executing (Busy) is TRUE).

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
OverrunOperation	Operation Setting at Overrun	Sets the operation settings when overrun occurs during operation. <ul style="list-style-type: none">• 1: Immediate Stop (ImmediateStop)• 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
BufferingFBs	Number of Buffering FBs	Displays the number of buffering FBs (0 to 2)

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
OverrunOperation	Operation Setting at Overrun	Sets the operation settings when overrun occurs during operation. <ul style="list-style-type: none">• 1: Immediate Stop (ImmediateStop)


Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
BufferingFBs	Number of Buffering FBs	Displays the number of buffering FBs (0 to 2)

Multiple start during single axis operation

- When axis operation state is as the following, multiple start is enabled by starting a motion FB of another instance. (If the axis operation is in the "4: Standby (Standstill)" status, it is regarded as "start".)
 - Axis Status (`AxisName.Md.AxisStatus`) that can be multiple started
 - 3: During homing (Homing) (Only MC_Stop (Forced Stop) is possible)
 - 5: During positioning operation (DiscreteMotion)
 - 6: During continuous operation (ContinuousMotion)
 - 7: During synchronous operation (SynchronizedMotion)
- When the buffering FB input includes Direction selection (Direction) and "4: Current Direction (mcCurrentDirection)" is selected, the previous FB operation direction is taken over.
- When the directions are different between the under-control FB and next FB in the single operation, the operation differs depending on the selection in case of having Reverse rotation permission selection (Options (Options): Bit 5). The operation is the same as the operation at reverse rotation permission in case of not having Reverse rotation permission selection (Options (Options): Bit 5).
- When the direction is reversed at while Blending is specified, a deceleration stop is executed at the target position of the under-control FB, and velocity change is executed to the target velocity of the buffering FB after the under-control FB is switched to the buffering FB. (It is the same operation as Buffered is specified.)


Deceleration stop setting at reverse (BlendingPrevious)



Operations with Reverse rotation permission selection (Options (Options): Bit 5)


■When reverse is enabled

When reverse rotation permission (0: Allow) is set in Reverse rotation permission selection (Options (Options): Bit 5), a deceleration stop is executed once. After completing deceleration stop, the operation is started in the changed direction.



■When reverse is disabled

When reverse rotation no permission (1: Do not allow) is set in Reverse rotation permission selection (Options (Options): Bit 5), "Overrun Error" (error code: 1A7EH) occurs at switching and the axis decelerates to a stop.



Buffer mode that can be set

The following shows buffer modes that can be specified in the single axis control FB. For operation details on each FB, refer to each FB specifications.

○: Buffer mode setting possible, —: Buffer mode setting not possible (axis error)

FB	Setting possible in FB			Completion output	Setting possible in the later motion FB		
	Aborting	Buffered	Blending		Aborting	Buffered	Blending
MC_Home (OPR)	—*1	—	—	Execution completion (Done)	○*2	—	—
MC_Stop (Forced Stop)	○	—	—	Execution completion (Done)	○*2	—	—
MC_MoveAbsolute (Absolute Value Positioning)	○	○	○	Execution completion (Done)	○	○	○
MC_MoveRelative (Relative Value Positioning)	○	○	○	Execution completion (Done)	○	○	○
MCv_SpeedToMoveAbsolute (Speed To Absolute Positioning)	○	○	○	Execution completion (Done)	○	○	○
MCv_SpeedToMoveRelative (Speed To Relative Positioning)	○	○	○	Execution completion (Done)	○	○	○
MCv_Jog (JOG)	—*1	—	—	Execution completion (Done)	○	○	—
MCv_SpeedControl (Speed Control (Including Position Loop))	○	○	○	Target velocity reached (InVelocity)	○	○	—
MC_MoveVelocity (Speed Control)	○	○	—	Target velocity reached (InVelocity)	○	○	—
MC_TorqueControl (Torque Control)	○	○	—	Target torque reached (InTorque)	○	○	—
MCv_PressureControl (Pressure Control)	○	○	—	Target pressure reached (InPressure)	○*3	○*3	—
MC_CamIn (Cam Operation Start)	○	○	—	Cam cycle completion (EndOfProfile)	○	○	—
MC_GearIn (Gear Operation Start)	○	○	—	Gear ratio reached (InGear)	○	○	—
MC_CombineAxes (Addition/Subtraction Positioning)	○	○	—	In synchronization (InSync)	○	○	—
MCv_SmoothingFilter (Smoothing Filter)	—*1	—	—	—	○*2	—	—
MCv_DirectionFilter (Moving Direction Restriction Filter)	—*1	—	—	—	○*2	—	—
MCv_SpeedLimitFilter (Speed Limit Filter)	—*1	—	—	—	○*2	—	—
MCv_BacklashCompensationFilter (Backlash Compensation Filter)	—*1	—	—	—	○*2	—	—
MCv_AdvancedSync (Advanced Synchronous Control)	—*1	—	—	Cam cycle completion (CycleZeroPoint)	○	○	—

*1 Multiple start cannot be executed because this FB can be started only when Axis Status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)".

*2 Only MC_Stop (Forced Stop) is possible.

*3 MCv_PressureControl (Pressure Control) cannot be specified.


Aborting during single axis operation

The under-control FB is interrupted and the next FB is executed.

Since a buffer is not used, an error does not occur even if two of under-control FBs have already been in buffering, and the FB is executed. (All FBs during buffering are interrupted.)


When omitting to specify the buffer mode, this operation is performed.

An operation example when Aborting is executed to the under-control FB1 with the linked start FB2 is shown below.



Buffered during single axis operation

Multiple started FBs are buffered and wait (Executing (Busy) is TRUE) until the under-control FB is completed. After the under-control FB is normally completed, multiple started FBs are performed in the order of being buffered.




Conditions to determine completion are different depending on the Motion control FB, and the FB may not be in the stop status with speed 0 at completion. For details, refer to the following.

☞ Page 139 Multiple start during single axis operation

Ex.

When an FB is multiple started with Buffered in MCv_SpeedControl (Speed Control (Including Position Loop))

In MCv_SpeedControl (Speed Control (Including Position Loop)), the FB is determined that it is completed when Target velocity reached (InVelocity) becomes TRUE, and the following buffering FB is executed. (The current speed at this time is used as the switching speed.)




Blending during single axis operation

Multiple started FBs are buffered and wait until the under-control FB is completed. After the under-control FB reached the target position, buffering FBs are performed in order. In this case, the switching speed differs depending on the mode specified in the buffer mode.


■BlendingPrevious

The FB is operated at the speed of the current under-control FB to the target position of the under-control FB. After switching to the FB that is during buffering, velocity change is executed to the target velocity of the buffering FB.




■BlendingNext

The FB is operated so that the velocity becomes the target velocity of the FB in buffering at the target position of the under-control FB.



Depending on the multiple start timing, the movement amount in order to change the speed to the target velocity of the FB in buffering may be in short at the target position of the under-control FB. In this case, velocity change is executed immediately, but the velocity cannot reach the target velocity of the FB that is during buffering at the target position of the under-control FB. If the target velocity of an under-control FB is reached during acceleration/deceleration, control is changed by the acceleration/deceleration of the buffering FB at that time.



When the acceleration/deceleration method set in the FB under control is jerk acceleration/deceleration, if the next FB is multiple started during acceleration/deceleration of the FB under control, the target velocity of the buffering FB may not be reached at the target position of the FB under control.

■BlendingLow

The slower target velocity between the under-control FB and the buffering FB is used as the switching speed.

The operation is same as BlendingPrevious when the under-control FB target velocity is slower, and it is same as BlendingNext when the buffering FB target velocity is slower.


■BlendingHigh

The higher target velocity between the under-control FB and the buffering FB is used as the switching speed.

The operation is same as BlendingPrevious when the under-control FB target velocity is higher, and it is same as BlendingNext when the buffering FB target velocity is higher.

Multiple start during multiple axes operation


- When axes group operation state is as the following, multiple start is enabled by executing the motion FB of another instance. (If the axis operation is in the "4: Standby (GroupStandby)" status, it is regarded as "start".)
 ■ Axes Group Status (`AxesGroupName.Md.GroupStatus`) that can be multiple started
 - 5: Operating (GroupMoving)
- In multiple start during multiple axes operation, the current interpolation speed of the under-control FB is used as the switching speed. Therefore, acceleration/deceleration may not be executed and rapid a velocity change may occur depending on the movement amount and direction of each axis in the buffering FB.



- When multiple start by specifying Aborting or Blending, if the under-control FB (FB1) or next FB (FB2) has Velocity mode (VelocityMode) input and the velocity mode settings are different between FBs, "Multiple Start Velocity Mode Specified Mismatch Warning" (warning code: 0D11H) is output because the velocity may change suddenly. In such a case, FB1 Velocity mode (VelocityMode) is used in FB1 and FB2 Velocity mode (VelocityMode) is used in FB2 to control. In this case, the switching speed is controlled using only values. (Unit/speed conversion by Velocity mode (VelocityMode) is not executed.)

Ex.

When multiple start by specifying BlendingPrevious from FB1 with the reference axis velocity to FB2 with the vector velocity.



The operation is carried out so that the reference axis velocity of FB1 becomes the velocity set in Velocity (Velocity) (reference axis velocity 1000 [mm/s]). The reference axis velocity at the target position of FB1 is regarded as the switching speed and the current vector velocity value of FB2 without conversion, and it accelerates and decelerates the vector velocity (200 [mm/s]) set in Velocity (Velocity) of FB2.

- Multiple start of the single axis control FB cannot be executed to the axis that is during operation in the axes group. If it is executed, "Motion FB Issue Error to the Axis during Axes Group Operating" (error code: 1A7CH) will occur in the target axis, and the axes group FB that is during execution will stop.

Buffer mode that can be set

The following shows buffer modes that can be specified in the multiple axes control FB. For operation details on each FB, refer to each FB specifications.

○: Buffer mode setting possible, —: Buffer mode setting not possible (axes group error)

FB	Setting possible in FB			Completion output	Setting possible in the later motion FB		
	Aborting	Buffered	Blending		Aborting	Buffered	Blending
MC_GroupStop (Group Forced Stop)	—*1	—	—	Execution completion (Done)	○*2	—	—
MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)	○	○	○	Execution completion (Done)	○	○	○
MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control)	○	○	○	Execution completion (Done)	○	○	○
MCv_MoveCircularInterpolateAbsolute (Absolute Value Circular Interpolation Control)	○	○	○	Execution completion (Done)	○	○	○
MCv_MoveCircularInterpolateRelative (Relative Value Circular Interpolation Control)	○	○	○	Execution completion (Done)	○	○	○
MCv_MovePositioningData (Multiple Axes Positioning Data Operation)	○	○	—	Execution completion (Done)	○	—	—

*1 When it is started during axis operation, the operation will be same as Aborting.

*2 Only MC_GroupStop (Group Forced Stop) is possible.


Aborting during multiple axes operation

The under-control FB is interrupted and the multiple started FB is executed.

Since a buffer is not used, an error does not occur even if two of the under-control FBs have already been in buffering, and the FB is executed. (All FBs during buffering are interrupted.)

When omitting to specify the buffer mode, this operation is performed.

An operation example when Aborting is executed to the under-control FB1 with the linked start FB2 is shown below.




Point

For multiple start during multiple axes operation, when an axes group error such as "Software Stroke Limit Over" (Target Position) (error code: 1A00H) is detected at the same time as the switching of an FB, it may immediately stop regardless of the axes group Stop Selection at Stop Cause Occurrence (AxesGroupName.Pr.StopMode_General) setting.

Buffered during multiple axes operation

Multiple started FBs are buffered and wait until the under-control FB is completed. After the under-control FB is normally completed, multiple started FBs are performed in the order of being buffered.




Blending during multiple axes operation

Multiple started FBs are buffered and wait until the under-control FB is completed. After the under-control FB reached the target position, buffering FBs are performed in order. In this case, the switching speed differs depending on the mode specified in the buffer mode.


■BlendingPrevious

The FB is operated with the interpolation velocity of current under-control FB to the target position of the under-control FB. After switching to the FB that is during buffering, velocity change is executed to the target velocity of buffering FB.




■BlendingNext

The FB is operated so that the interpolation velocity becomes the target velocity of FB that is during buffering at the target position of the under-control FB.



Depending on the multiple start timing, the movement amount to change velocity to the target velocity of the FB that is during buffering at the target position of the under-control FB. In this case, velocity change is executed immediately, but the velocity cannot reach the target velocity of the FB that is during buffering at the target position of the under-control FB. If the target velocity of an under-control FB is reached during acceleration/deceleration, control is changed by the acceleration/deceleration of the buffering FB at that time.



When the acceleration/deceleration method set in the FB under control is jerk acceleration/deceleration, if the next FB is multiple started during acceleration/deceleration of the FB under control, the target velocity of the buffering FB may not be reached at the target position of the FB under control.

■BlendingLow

The smaller target velocity between the under-control FB and the buffering FB is used as the switching velocity.

When the smaller switching velocity is the under-control FB, the control is the same as BlendingPrevious, and when the smaller switching velocity is the buffering FB, the control is the same as BlendingNext.

■BlendingHigh

The larger target velocity between the under-control FB and the buffering FB is used as the switching velocity.

When the larger switching velocity is the under-control FB, the control is the same as BlendingPrevious, and when the larger switching velocity is the buffering FB, the control is the same as BlendingNext.

Option of buffering FB

Set the option of the function used for the buffering FB by Options (Options) of the buffering FB. For the positioning control FB which can be specified, refer to details for the operation of the each positioning control FB.

The option to be used by the multiple start is shown below.

Positioning selection in the buffer mode (Options (Options): Bit 3)

When the relative value positioning control is multiple started, the relative value positioning control from set position or actual position is carried out by Position selection at the multiple start of FB (Options (Options): Bit 3).

The axis type which does not have the actual position ignores this setting.

Setting value	Description
0: Set position	<p>The relative value positioning control from set position</p> <p><Example></p> <p>Multiple start with movement amount (Distance) set to "5000.0" and Options (Options) set to "00000000H (bit 3 is 0: Set position)"</p>
1: Actual position	<p>The relative value positioning control from actual position</p> <p><Example></p> <p>Multiple start with movement amount (Distance) set to "5000.0" and Options (Options) set to "00000008H (bit 3 is 1: Actual position)"</p>

Reverse rotation permission selection (Options (Options): Bit 5)

In the single axis motion FB, reverse rotation is allowed when the operation direction differs between the under-control FB and the buffering FB. For details, refer to the following.

Page 139 Multiple start during single axis operation

Setting value	Description
0: Allow	<p>Reverse rotation is allowed.</p> <p>Performs a deceleration stop once, and starts operation in the changed direction after deceleration stop is completed.</p>
1: Do not allow	<p>Reverse rotation is not allowed.</p> <p>While switching, "Overrun Error" (error code: 1A7EH) occurs and a deceleration stop is performed.</p>


Near pass

At multiple start by Blending, near pass is performed to suppress machine vibration which occurs at switching of the positioning control FB.

The remainder of the movement amount which occurs at the end of the positioning control FB is used for the next one. Set velocity does not decrease and machine vibration which occurs by the velocity change can be suppressed as the positioning is not carried out for each positioning control FB. Since the alignment is not performed every positioning control FB, the operation is controlled in a path that passes near the position set in the FB.

Ex.

For multiple starting the 2-axes linear interpolation control with Blending (multiple start of FB2 during controlled of FB1)



Precautions

- When executing multiple start by Blending, the set velocity will not reach the target velocity if the movement amount of the previous FB is small.

Combination with retrigger/continuous update


Reanalysis of the buffering FB by retrigger/continuous update

When the target position or the target velocity is changed by retrigger/continuous update for the under-control FB, the reanalysis of the buffering FB may be needed.

As a result of reanalysis, when an error occurs in any of the FBs, Axis Status (AxisName.Md.AxisStatus) becomes "1: Stopping on error (ErrorStop)" or Axes Group Status (AxesGroupName.Md.GroupStatus) becomes "1: Stopping on error (GroupErrorStop)" and the under-control FB is stopped. (The buffering FB is canceled.)

Ex.

The changed target position is out of the software stroke limit range by retriggering the under-control FB.




*1 The target position is within the software stroke limit range for all Motion control FBs.


*2 The target position is out of the software stroke limit range for FB2.

BlendingNext changes target velocity at accelerating/decelerating

When BlendingNext is specified and the multiple start is executed, target velocity change by input variables of the under-control FB is not allowed while the buffering FB is accelerating/decelerating to its target velocity (transfer speed). Target velocity change by changing the Velocity override factor (AxisName(AxesGroupName).Cd.VelocityOverride) is allowed.



After reaching the buffering FB target velocity using acceleration/deceleration by BlendingNext, velocity change by input variables of the under-control FB is allowed. However, the velocity change values during acceleration/deceleration by BlendingNext are ignored for a retrigger/continuous update after reaching the buffering FB target velocity. In addition, when a target velocity change is executed in the under-control FB, accelerate/decelerate to the target velocity of the buffering FB will occur after the FB has switched.



BlendingLow/BlendingHigh changes target velocity after multiple start


Multiple start by BlendingLow/BlendingHigh determines whether to switch with the velocity of the under-control FB or the buffering FB.

Therefore, if the size related to the target velocity between the under-control FB and the buffering FB is changed by target velocity change after multiple start, the switching velocity is still determined as the target velocity that was determined at multiple start.

When the velocity for the under-control FB and buffering FB is the same at multiple start, the velocity of the under-control FB is used for switching for both BlendingLow and BlendingHigh. Therefore, if the target velocity is changed after multiple start, the under-control FB velocity after the change is used for switching.

Ex.


When the target velocity is changed after multiple start by BlendingHigh



BlendingNext changes target position/movement distance at accelerating/decelerating


When multiple start is executed by specifying BlendingNext, the operation when the target position/movement distance change is executed during accelerating/decelerating to the target velocity (transfer speed) of the buffering FB is shown below.

- When the movement amount is increased by a target position/movement distance change, positioning to the changed target position is executed at the target velocity (transfer speed) of the buffering FB.



- When the movement amount is decreased by a target position/movement distance change, the FB is switched while accelerating/decelerating to the target velocity (transfer speed) of the buffering FB. In addition, if the target position/movement distance is changed to before the current position, the operation direction will be reversed. For the operation when reversed, refer to the following.

☞ Page 139 Multiple start during single axis operation




Precautions

- When deceleration distance of a buffering FB cannot be secured with the switching speed and the target position is overrun at switching to the buffering FB, automatic deceleration operation is performed according to the setting of Operation Setting at Overrun (AxisName(AxesGroupName).Pr.OverrunOperation).


■For "1: Immediate Stop (ImmediateStop)"

The axis starts deceleration immediately, and it stops immediately at reaching the target position after outputting "Overrun Warning" (warning code: 0D10H).



■For "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" (Only for single axis)

The axis starts deceleration immediately, and it stops after exceeding the target position. When the stop address is exceeded, "Overrun Error" (error code: 1A7EH) is output. However, when the error occurs, the operation stops according to the setting of Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General). To stop the axis after it exceeds the target position, set "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" in Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).



When a new FB is multiple started during deceleration by movement amount shortage, the operation becomes as the following.


<When the Operation Setting at Overrun (AxisName.Pr.OverrunOperation) setting is "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)">

- If the target position has already been reached when the multiple start happens (when "Overrun Error" (error code: 1A7EH) occurs), the buffering FBs will be disabled.
- If the target position has not been reached when the multiple start happens and if Aborting and Blending are set, deceleration will be canceled. If Buffered is set, the multiple start will be executed but canceled with "Overrun Error" (error code: 1A7EH) occurrence.

<When the Operation Setting at Overrun (AxisName.Pr.OverrunOperation) setting is other than "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)">

- If a new FB is multiple started when Aborting and Blending are set, deceleration stop will be canceled.
- If a new FB is multiple started when Buffered is set, automatic deceleration will be continued. The multiple started axes will be executed after the axis stops.

- If an error occurs in the following FB analysis processing at multiple start, Axis Status (AxisName.Md.AxisStatus) and Axes Group Status (AxesGroupName.Md.GroupStatus) will be "1: Stopping on error (GroupErrorStop)" and the under-control FBs will stop.



- If the acceleration/deceleration method settings are different between the under-control FB and the next FB, "Acceleration/Deceleration Method Mismatched" (error code: 1A0EH) will occur and the FBs will stop. Set the same acceleration/deceleration method in the FBs to be carried out multiple start.
- Changes are reflected at the switching of FB when restart or continuous update is executed to the buffering FB after multiple start. If the warning occurs at the switching of FB, it operates with the value at multiple start without accepting the changes.

4.4 Stop

This section describes how to stop control.

Each control is stopped in the following cases.

This section describes stop processing other than when each control in the above cases is completed normally.

For operation details when a stop cause occurs in another function (stop processing of homing, etc.), refer to each function.

Axis operation stop

- When each control is completed normally
- When the "forced stop input" is turned OFF
- When the drive unit power supply is turned OFF
- When the drive unit network disconnection is detected
- When the drive unit error occurs
- When the forced stop is input to the drive unit
- When "Enable (Enable)" of MC_Power (Operation Available) is FALSE
- When "Servo ON request (ServoON)" of MC_Power (Operation Available) is FALSE
- When the hardware stroke limit upper/lower limit error occurs
- When a CPU module error occurs
- When the PLC READY is turned OFF
- When the cycle over error occurs
- When a moderate error or a major error of the motion system occurs
- When the software stroke limit upper/lower limit error occurs
- When an axis error is detected
- When "Execute command (Execute)" of MC_Stop (Forced Stop) is TRUE
- When the "stop signal (STOP)" of external input signal is TRUE

Hardware stroke limit upper/lower limit error	Software stroke limit upper/lower limit error
<ul style="list-style-type: none">• FLS Signal Detection (at Start) (error code: 1A2DH)• RLS Signal Detection (at Start) (error code: 1A2EH)• FLS Signal Detection (Controlling) (error code: 1A2FH)• RLS Signal Detection (Controlling) (error code: 1A30H)	<ul style="list-style-type: none">• Software Stroke Limit Over (Forward Direction) (error code: 1A03H)• Software Stroke Limit Over (Reverse Direction) (error code: 1A04H)

Axes group operation stop

- When each control is completed normally
- When a stop cause occurs in the configuration axis
- When an axes group error is detected
- When "Execute command (Execute)" of MC_GroupStop (Group Forced Stop) is TRUE
- When the "stop signal (STOP)" of external input signal is TRUE

Operation of this function for each system status

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
StopMode_HwStrokeLimit	Stop Selection at Hardware Stroke Limit Error Occurrence	<p>Selects operation when the hardware stroke limit upper/lower limit error occurs.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) (Initial value) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc) • 3: Alternative Acceleration/Deceleration (AlternativeAcc) <p>*: (Immediate stop will be executed when executing an instruction without deceleration specification.)</p>
StopMode_SwStrokeLimit	Stop Selection at Software Stroke Limit Error Occurrence	<p>Selects operation when the software stroke limit upper/lower limit error occurs.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) (Initial value) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc) • 3: Alternative Acceleration/Deceleration (AlternativeAcc) <p>*: (Immediate stop will be executed when executing an instruction without deceleration specification.)</p>
StopMode_General	Stop Selection at Stop Cause Occurrence	<p>Selects operation when a stop cause for each axis other than the stop cause 1 and 2 occurs.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc) • 3: Alternative Acceleration/Deceleration (AlternativeAcc) (initial value) <p>*: (Immediate stop will be executed when executing an instruction without deceleration specification.)</p>
StopMode_Deceleration	Deceleration at Stop	<p>Specifies the deceleration/deceleration time at deceleration stop by stop cause occurrence.</p> <p>■When acceleration/deceleration method to specify the acceleration/deceleration</p> <ul style="list-style-type: none"> • Unit: specify with U/s^2 • Range: 0.0000, a positive number from 0.0001 to 2,147,483,647 $[\text{U/s}^2]^*1$ <p>■When acceleration/deceleration method to specify the acceleration/deceleration time</p> <ul style="list-style-type: none"> • Unit: specify with s. • Range: 0.000000, a positive number from 0.000001 to 8400.0 $[\text{s}]^*1$ <p>*: If "0.0" is set, immediately stops regardless of the operation selection at acceleration/deceleration 0 (AccelerationZeroBehavior) setting.</p>
StopMode_DecelerationCurve	Stop Selection at Deceleration to Stop	<p>Selects operation when a stop cause occurs during deceleration (including a stop cause and automatic deceleration).</p> <ul style="list-style-type: none"> • 1: Recreate Deceleration Curve (OverrideCurve) (Initial value)
StopMode_ServoOff	Process Selection at Servo OFF Command During Operation	<p>Selects operation when Servo ON request (ServoON) of MC_Power (Operation Available) becomes FALSE during operation.</p> <ul style="list-style-type: none"> • 0: Ignore (Ignore) (Initial value) • 4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop) • 5: Servo OFF After Deceleration to Stop (ServoOffAfterDecelStop)
OverrunOperation	Operation Setting at Overrun	<p>Selects operation when stop position is reached during deceleration stop processing by a stop cause.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) (Initial value) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)

Variable/Structure name	Name	Details
StopSignal	Stop Signal	<p>Sets a signal that uses the stop signal (STOP) of the external input signal. Stop signal (StopSignal) is a structure of SIGNAL_SELECT type. The fetch timing of the label is at Ready ON, and the detection timing of the signal is the axis operation cycle.</p> <p>For details on SIGNAL_SELECT type, refer to the following.</p> <p>☞ Page 424 External Signal Selection</p> <p>The specific setting and operation for this signal are shown below.</p> <p>■ I/O Number (StartIO) Ignores input values.</p> <p>■ Target (Target) If the target is unspecified, it is regarded as invalid signal and it is always in the signal undetection status.</p> <p>Only [VAR] , [DEV] , and [CONST] can be specified for the data type.</p> <p>*: When unavailable data is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■ Signal Detection Method (Detection) The specification is allowed at the following level detection only.</p> <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel) <p>*: When edge detection specification is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■ Compensation Time (CompensationTime) Ignores the input value.</p> <p>■ Filter Time (FilterTime) Setting range of the filter time is 0.0 to +5.0.</p> <p>*: When a value outside the range is set, "Out of Filter Time Setting Range of Each Axis Signal Warning" (warning code: 0D24H) occurs) and the axis operates with 0.0 of the filter time.</p>
StopOption_DriverTargetIgnored	Driver Command Discard Detection Setting	<p>Select whether to detect the command discard status (Statusword bit12) of the drive unit and stop with error during operation of the axis or not.</p> <ul style="list-style-type: none"> • 0: FALSE Detection Disabled • 1: TRUE Detection Enabled (Initial value)

*1 Clamp by the upper limit value when the upper limit value is out of the range at stop by factors, and handle as 0 (Immediate stop) when lower limit value is out of the range.

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
StopSignal	Stop Signal	<p>Displays input status of the stop signal (STOP) of the external input signal. Stop signal (StopSignal) is a structure of SIGNAL_SELECT type. For details on SIGNAL_SELECT type, refer to the following.</p> <p>☞ Page 424 External Signal Selection</p> <p>The specific output for this signal is shown below.</p> <p>■ I/O Number (StartIO) 0 is always displayed.</p> <p>■ Target (Target) The fetch result of the parameter is displayed.</p> <p>■ Signal Detection Method (Detection) The fetch result of the parameter is displayed.</p> <p>■ Compensation Time (CompensationTime) 0.0 is always displayed.</p> <p>■ Filter Time (FilterTime) The fetch result of the parameter is displayed.</p>
StopStatus	Stop Status	<p>Displays the input status of the stop signal (STOP) among external input signals.</p> <ul style="list-style-type: none"> • FALSE: Stop processing released • TRUE: During stop processing
StopMode_DecelerationCurve	Stop Selection at Deceleration to Stop	Displays input status of the stop processing selection at deceleration stop.
StopMode_Deceleration	Deceleration at Stop	Displays input status of the deceleration at stop.
StopMode_General	Stop Selection at Stop Cause Occurrence	Displays input status of the stop selection at stop cause occurrence.
StopMode_HwStrokeLimit	Stop Selection at Hardware Stroke Limit Error Occurrence	Displays input status of the stop selection at the hardware stroke limit error occurrence.
StopMode_ServoOff	Process Selection at Servo OFF Command During Operation	Displays input status of the processing selection at servo OFF command during operation.
StopMode_SwStrokeLimit	Stop Selection at Software Stroke Limit Error Occurrence	Displays input status of the stop selection at the software stroke limit error occurrence.

Variable/Structure name	Name	Details
OverrunOperation	Operation Setting at Overrun	Displays input status of the overrun operation setting.
StopOption_DriverTargetIgnored	Driver Command Discard Detection Setting	Displays driver command discard detection setting status.

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
StopMode_General	Stop Selection at Stop Cause Occurrence	<p>Selects operation when a stop cause of the axes group occurs.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc) • 3: Alternative Acceleration/Deceleration (AlternativeAcc) (Initial value) <p>*: (Immediate stop will be executed when executing an instruction without deceleration specification.)</p>
StopMode_DecelerationCurve	Stop Selection at Deceleration to Stop	<p>Selects operation when a stop cause occurs during deceleration (including a stop cause and automatic deceleration).</p> <ul style="list-style-type: none"> • 1: Recreate Deceleration Curve (OverrideCurve) (Initial value)
OverrunOperation	Operation Setting at Overrun	<p>Selects operation when stop position is reached during deceleration stop processing by a stop cause. If other than "1: Immediate Stop (ImmediateStop)" (Initial value) is set, an error will occur.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop)
StopMode_ErrorInGroup	Configuration Axes Operation Selection at Axis Stop Cause Occurrence	<p>During operation in the axes group, when the drive unit servo is turned OFF on the configuration axis and an immediate stop axis error occurs, it sets the operation of the axis to which an axis error does not occur.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop)
StopMode_Deceleration	Deceleration at Stop	<p>Specifies the deceleration/deceleration time at deceleration stop by axes group stop cause occurrence.</p> <p>■When acceleration/deceleration method to specify the acceleration/ deceleration</p> <ul style="list-style-type: none"> • Unit: Specify with U/s^2. • Range: 0.0000, a positive number from 0.0001 to 2147483647.0 $[U/s^2]^{*1}$ <p>■When acceleration/deceleration method to specify the acceleration/ deceleration time</p> <ul style="list-style-type: none"> • Unit: Specify with s. • Range: 0.000000, a positive number from 0.000001 to 8400.0 $[s]^{*1}$ <p>*: If "0.0" is set, immediately stops regardless of the operation selection at acceleration/deceleration 0 (AccelerationZeroBehavior) setting.</p>

*1 Clamp by the upper limit value when the upper limit value is out of the range at stop by factors, and handle as 0 (Immediate stop) when lower limit value is out of the range.

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
StopMode_Deceleration	Deceleration at Stop	Displays input status of the deceleration at stop.
StopMode_DecelerationCurve	Stop Selection at Deceleration to Stop	Displays input status of the stop processing selection at deceleration stop.
StopMode_ErrorInGroup	Configuration Axes Operation Selection at Axis Stop Cause Occurrence	Displays input status of the configuration axes operation selection at axis stop cause occurrence.
StopMode_General	Stop Selection at Stop Cause Occurrence	Displays input status of the stop selection at stop cause occurrence.
OverrunOperation	Operation Setting at Overrun	Displays input status of the overrun operation setting.

System parameter (System.Pr.)

Variable/Structure name	Name	Details
StopMode_All	Stop Selection at All Axes Stop Cause Occurrence	<p>Selects whether to stop immediately or decelerate to stop when an all axes stop cause occurs.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc) • 3: Alternative Acceleration/Deceleration (AlternativeAcc) <p>*: (Immediate stop will be executed when executing an instruction without deceleration specification.)</p>
StopMode_AllDeceleration	Deceleration at All Axes Stop	<p>Specifies the deceleration/deceleration time at deceleration stop when an all axes stop cause occurred.</p> <p>■ When acceleration/deceleration method to specify the acceleration/ deceleration</p> <ul style="list-style-type: none"> • Unit: Specify with U/s^2. • Range: 0.0000, a positive number from 0.0001 to 2147483647.0 $[\text{U/s}^2]$*1 <p>■ When acceleration/deceleration method to specify the acceleration/ deceleration time</p> <ul style="list-style-type: none"> • Unit: Specify with s. • Range: 0.000000, a positive number from 0.000001 to 8400.0 $[\text{s}]$*1 <p>*: If "0.0" is set, immediately stops regardless of the operation selection at acceleration/deceleration 0 (AccelerationZeroBehavior) setting.</p>

*1 Clamp by the upper limit value when the upper limit value is out of the range at stop by factors, and handle as 0 (Immediate stop) when lower limit value is out of the range.

Relevant FBs

For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_Stop	Forced Stop	Decelerates specified axis to stop.
MC_GroupStop	Group Forced Stop	Decelerates specified axes group to stop.

Stop cause lists

Stop causes during axis operation

The following shows stop causes during axis operation and the process when each cause occurs.

Cause No.	Stop cause	Stop axis	Axis Status (<u>AxisName</u> .Md.AxisStatus)		Stop process* ¹
			During deceleration stop	After stop	
1	"Forced stop input" is FALSE	Each axis/ All axes	—	1: Stopping on error (ErrorStop)	Immediate stop* ²
2	Drive unit power supply is OFF	Each axis	—	1: Stopping on error (ErrorStop)	Immediate stop* ²
	Drive unit network disconnection detection				
	Drive unit error				
	Forced stop input to the drive unit				
	Enable (Enable) of MC_Power (Operation Available) is FALSE				
	Servo ON request (ServoON) of MC_Power (Operation Available) is FALSE (When Process Selection at Servo OFF Command During Operation (<u>AxisName</u> .Pr.StopMode_ServoOff) is "4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)")* ³				
	Drive unit control mode has switched to the control mode which the motion system axis control is not supported.				Immediate stop* ⁶
3	Hardware stroke limit upper/lower limit error occurrence	Each axis	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/immediate stop (Follows Stop Selection at Hardware Stroke Limit Error Occurrence (<u>AxisName</u> .Pr.StopMode_HwStrokeLimit))
4	CPU module error occurrence	All axes	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/immediate stop (Follows Stop Selection at All Axes Stop Cause Occurrence (System.Pr.StopMode_All))* ⁷
	PLC READY is OFF				
	Cycle over error occurrence				
	Motion system moderate error or major error occurrence				
5	Software stroke limit upper/lower limit error occurrence	Each axis	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/immediate stop (Follows Stop Selection at Software Stroke Limit Error Occurrence (<u>AxisName</u> .Pr.StopMode_SwStrokeLimit))
6	Axis error detection* ⁴	Each axis	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxisName</u> .Pr.StopMode_General))
7	Execute command (Execute) of MC_Stop (Forced Stop) is TRUE	Each axis	2: Decelerating to stop (Stopping)	2: Decelerating to stop (Stopping)* ⁵	Deceleration stop/immediate stop (Follows the deceleration (Deceleration) set in the FB)
8	"Stop signal (STOP)" of external input signal is TRUE	Each axis	No change	4: Standby (Standstill)	Deceleration stop/immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxisName</u> .Pr.StopMode_General))

*¹ For each operation of the stop process, refer to the following.

☞ Page 170 Stop processes for single axis

*² The servo turns OFF on the drive unit side and immediate stop is performed, and also the motion system side command is stopped.

*³ Operation differs depending on the setting value selected in Process Selection at Servo OFF Command During Operation (AxisName.Pr.StopMode_ServoOff). For details, refer to the following.

☞ Page 175 Stop causes by Servo ON request (ServoON) input of MC_Power (Operation Available)

*⁴ If an axis error (the error that transits the state into the "1: Stopping on error (ErrorStop)" status) occurs in the buffering FB, deceleration stop will be performed from the error occurrence.

*⁵ When Execute command (Execute) of MC_Stop (Forced Stop) is FALSE at stop completion, Axis Status (AxisName.Md.AxisStatus) after stop will be "4: Standby (Standstill)".

*6 Immediately stops the motion system side command, and follow up on the current position.

*7 The deceleration stop can be performed independently on the drive unit side depending on the drive unit specifications. For details, refer to the manual of the drive unit.

Precautions

Provide the emergency stop circuits outside the servo system to prevent cases where danger may result from abnormal operation of the entire system in the event of an external power supply fault or servo system failure.

Stop causes during axes group operation

The following shows stop causes during axes group operation and the process when each cause occurs.

Cause No.	Stop cause		Stop axis	Axes Group Status (<u>AxesGroupName</u> .Md.GroupStatus)		Stop process*1	
				During deceleration stop	After stop		
1	Stop cause occurrence in the configuration axis	Axis error detection	Axes group	1: Stopping on error (GroupErrorStop)	1: Stopping on error (GroupErrorStop)	Stop cause occurrence axis	Axes group deceleration stop/immediate stop*2 (For axes group deceleration stop, it follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName</u> .Pr.StopMode_General))
						Other configuration axes	Axes group deceleration stop/immediate stop (For axes group deceleration stop, it follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName</u> .Pr.StopMode_General))*3
2		"Stop signal (STOP)" of external input signal is TRUE	Axes group	No change	4: Standby (GroupStandby)	Axes group deceleration stop/immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName</u> .Pr.StopMode_General))	
3	Axes group error detection*4		Axes group	1: Stopping on error (GroupErrorStop)	1: Stopping on error (GroupErrorStop)	Axes group deceleration stop/immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName</u> .Pr.StopMode_General))	
4	Execute command (Execute) of MC_GroupStop (Group Forced Stop) is TRUE		Axes group	2: Decelerating to stop (GroupStopping)	2: Decelerating to stop (GroupStopping)*5	Axes group deceleration stop/immediate stop (Follows the deceleration (Deceleration) set in the FB)	

*1 For each operation of the stop process, refer to the following.

☞ Page 172 Stop processes for axes group

*2 The servo OFF is executed on the drive unit side and the axis immediately stops, and also the motion system side command is stopped.

*3 When the stop cause occurrence axis is immediately stopped by servo OFF, operation differs depending on the setting selected in Configuration Axes Operation Selection at Axis Stop Cause Occurrence (AxesGroupName.Pr.StopMode_ErrorInGroup). For details, refer to the following.

☞ Page 182 Stop cause occurrence in the configuration axis

*4 If an axes group error (the error that transits the state into the "1: Stopping on error (GroupErrorStop)" status) occurs in the buffering FB, automatic deceleration will be performed from the axes group error occurrence.

*5 When Execute command (Execute) of MC_GroupStop (Group Forced Stop) is FALSE at stop completion, Axes Group Status (AxesGroupName.Md.GroupStatus) after stop will be "4: Standby (GroupStandby)".

Types of stop processes

This section describes types of stop processes for a single axis and an axes group.

Stop operation by Stop Selection at Stop Cause Occurrence (AxisName(AxesGroupName).Pr.StopMode_General) and Deceleration at Stop (AxisName(AxesGroupName).Pr. StopMode_Deceleration) are described in this section.

For the stop operation by MC_Stop (Forced Stop) or MC_GroupStop (Group Forced Stop), refer to the following.

☞ Page 179 MC_Stop (Forced Stop)

☞ Page 187 MC_GroupStop (Group Forced Stop)

Stop processes for single axis

■Deceleration stop

The operation decelerates from the speed during operation to speed 0. The deceleration differs depending on Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).


Stop Selection at Stop Cause Occurrence (<u>AxisName.Pr.StopMode_General</u>) setting value	Deceleration at stop
2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)	Deceleration at instruction during operation
3: Alternative Acceleration/Deceleration (AlternativeAcc)	Deceleration at Stop (<u>AxisName.Pr. StopMode_Deceleration</u>)

The acceleration/deceleration method and the jerk setting of deceleration stop take over the setting value of the FB which was in execution when stop cause occurred. For FBs for which the acceleration/deceleration method cannot be set, the operation decelerates in the trapezoidal acceleration/deceleration.

For details of each stop method, refer to the following.


☞ Page 358 Acceleration/deceleration Processing Function

- When "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" is set to Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General) (When the instruction in operation is MCv_Jog (JOG))



- When "3: Alternative Acceleration/Deceleration (AlternativeAcc)" is set to Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General) (When the instruction in operation is MCv_Jog (JOG))

MCv_Jog: Deceleration	100
<u>AxisName</u> .Pr.StopMode_Deceleration	300




■ Immediate stop

The operation does not decelerate and immediately stops the command.

For the stop method of the drive unit, refer to each drive unit manual.

For MR-J5(W)-G: MR-J5 User's Manual (Function)



Stop processes for axes group

Deceleration stop

The operation decelerates from the interpolation speed during operation to the interpolation speed 0. The deceleration differs depending on Stop Selection at Stop Cause Occurrence (AxesGroupName.Pr.StopMode_General).

Stop Selection at Stop Cause Occurrence (<u>AxesGroupName.Pr.StopMode_General</u>) setting value	Deceleration at stop
2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)	Deceleration at instruction during operation
3: Alternative Acceleration/Deceleration (AlternativeAcc)	Deceleration at Stop (<u>AxesGroupName.Pr. StopMode_Deceleration</u>)


The acceleration/deceleration method and the jerk setting of deceleration stop take over the setting value of FB which was being executed when stop cause occurred.

For specifications of each stop method, refer to the following.

Page 358 Acceleration/deceleration Processing Function


- When "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" is set to Stop Selection at Stop Cause Occurrence (AxesGroupName.Pr.StopMode_General) (When the instruction in operation is MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control))

MCv_MoveLinearInterpolateRelative: Deceleration	100
<u>AxesGroupName.Pr.StopMode_Deceleration</u>	300




- When "3: Alternative Acceleration/Deceleration (AlternativeAcc)" is set to Stop Selection at Stop Cause Occurrence (AxesGroupName.Pr.StopMode_General) (When the instruction in operation is MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control))

MCv_MoveLinearInterpolateRelative: Deceleration	100
<u>AxesGroupName.Pr.StopMode_Deceleration</u>	300



■ Immediate stop

The operation does not decelerate and immediately stops the command.
 For the stop method of the drive unit, refer to each drive unit manual.
 For MR-J5(W)-G:  MR-J5 User's Manual (Function)



Order of priority for stop process

This section describes the processes when multiple stop causes occur.
 The order of priority is as shown below based on the stop process of occurred stop cause.

Priority	Stop method
1	Immediate stop
2	Deceleration stop

When a deceleration stop cause occurs again during deceleration stop (including a stop cause and automatic deceleration), the deceleration process differs depending on the following parameter settings for a single axis or an axes group.

Item	Parameter	Setting value
Single axis	Stop Selection at Deceleration to Stop (<u>AxisName</u> .Pr.StopMode_DecelerationCurve)	1: Recreate Deceleration Curve (OverrideCurve)
Axes group	Stop Selection at Deceleration to Stop (<u>AxesGroupName</u> .Pr.StopMode_DecelerationCurve)	

Deceleration curve re-processing

■ 1: Recreate Deceleration Curve (OverrideCurve)

A deceleration curve is re-processed from the deceleration of the new stop cause.
 During single axis operation, the stop position can be overrun depending on the deceleration and the jerk setting. To avoid overrun, set "1: Immediate Stop (ImmediateStop)" in Operation Setting at Overrun (AxisName.Pr.OverrunOperation).
 For operation details, refer to the following.
 Page 174 Overrun at stop cause occurrence

Overrun at stop cause occurrence

This function selects operation for the case that the positioning address of an instruction which was executed before a stop cause occurs is reached during deceleration stop and immediate stop process.

This function is enabled only when the target position exists at stop cause occurrence.


The following parameters for a single axis or an axes group are need to be set in this function.

Item	Parameter	Setting value
Single axis	Operation Setting at Overrun (<u>AxisName</u> .Pr.OverrunOperation)	1: Immediate Stop (ImmediateStop) 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)
Single axis	Operation Setting at Overrun (<u>AxesGroupName</u> .Pr.OverrunOperation)	1: Immediate Stop (ImmediateStop)

Immediate stop

■1: Immediate Stop (ImmediateStop)


The operation is immediately stopped when reaching the original positioning address during deceleration by a stop cause. In this case, the operation does not exceed the positioning address set in the under-control FB.



Keep current acceleration/deceleration (Only for a single axis)

■2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)

Deceleration continues even though the operation reached the original deceleration stop position during deceleration by a stop cause. In this case, there is no guarantee that it stops before the positioning address set in the under-control FB.



Stop during single axis operation

This section describes each stop cause.

Stop causes of immediate stop with no condition

When the following stop causes occur, the servo OFF is executed in the drive unit and the axis stops immediately.

For how to stop the drive unit, refer to each drive unit manual.

For MR-J5(W)-G:  MR-J5 User's Manual (Function)

- "Forced stop input" is turned OFF from an external device^{*1}
- Drive unit power supply OFF
- Drive unit network disconnection detection
- Drive unit error
- Forced stop input to drive unit
- "Enable (Enable)" of MC_Power (Operation Available) is FALSE

^{*1} The forced stop input is set in Forced Stop Signal (AxisName.Pr.ForcedStop_Signal). For operation details, refer to the following.

 Page 190 Forced Stop

Stop causes by Servo ON request (ServoON) input of MC_Power (Operation Available)

■ Process selection at servo OFF command during operation

When Servo ON request (ServoON) of MC_Power (Operation Available) is set to FALSE, the stop operation differs depending on the setting of Process Selection at Servo OFF Command During Operation (AxisName.Pr.StopMode_ServoOff). Process Selection at Servo OFF Command During Operation (AxisName.Pr.StopMode_ServoOff) has the following three functions.

Process selection at servo OFF command during operation (<u>AxisName</u> .Pr.StopMode_ServoOff) ^{*1}	Description
0: Ignore (Ignore)	During operation, this function ignores the servo OFF command even though it is input and continues on-going operation. If Servo ON request (ServoON) of MC_Power (Operation Available) is set to FALSE when Axis Status (<u>AxisName</u> .Md.AxisStatus) of the operation completion axis turns "4: Standby (Standstill)", servo OFF will be executed. (The axis will not stop.)
4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)	During operation, the command is immediately stopped by "Immediate Stop by Servo OFF During Operation" (error code: 1A3CH) occurrence, and a servo OFF is issued to the driver.
5: Servo OFF After Deceleration to Stop (ServoOffAfterDecelStop)	During operation, when receiving the servo OFF command input, "Deceleration Stop by Servo OFF During Operation" (error code: 1A3BH) occurs and deceleration stop is executed. If Servo ON request (ServoON) of MC_Power (Operation Available) is FALSE when the operation has reached speed 0, servo OFF will be executed.

^{*1} Process selection at servo OFF command during operation (AxisName.Pr.StopMode_ServoOff) during operation operates "4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)".

■Axis state transition

The axis state changes based on the input combination of Enable (Enable) and Servo ON request (ServoON) of MC_Power (Operation Available).

Axis status before input operation (<u>AxisName</u> .Md.AxisStatus)	Input		Process Selection at Servo OFF Command During Operation (<u>AxisName</u> .Pr.StopMode_ServoOff)	Axis Status (<u>AxisName</u> .Md.AxisStatus) after input operation
	Enable (Enable)	Servo ON request (ServoON)		
4: Standby (Standstill) 0: Axis disabled (Disabled)	TRUE	TRUE	Independent of the setting	4: Standby (Standstill) 0: Axis disabled (Disabled)
		FALSE		
	FALSE	TRUE		1: Stopping on error (ErrorStop)
		FALSE		
1: Stopping on error (ErrorStop)	TRUE	TRUE	Independent of the setting	1: Stopping on error (ErrorStop)
		FALSE		
	FALSE	TRUE		No transition
		FALSE		
Others	TRUE	TRUE	0: Ignore (Ignore)	No transition ^{*1,2}
		FALSE	4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)	1: Stopping on error (ErrorStop) ^{*4}
			5: Servo OFF After Deceleration to Stop (ServoOffAfterDecelStop)	1: Stopping on error (ErrorStop) ^{*3}
			Independent of the setting	1: Stopping on error (ErrorStop) ^{*4}
	FALSE	TRUE	Independent of the setting	1: Stopping on error (ErrorStop) ^{*4}
		FALSE		

*1 It is "0: Axis disabled (Disabled)" when Axis Status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)" or "2: Decelerating to stop (Stopping)" after deceleration stop.

*2 Axis Status (AxisName.Md.AxisStatus) will not transit if Axis Status (AxisName.Md.AxisStatus) is "1: Stopping on error (ErrorStop)" after deceleration stop.

*3 If ServoON becomes FALSE during operation, "Deceleration Stop by Servo OFF During Operation" (error code: 1A3BH) will occur.

*4 When Enable (Enable)/Servo ON request (ServoON) becomes FALSE during operation, "Immediate Stop by Servo OFF During Operation" (error code: 1A3CH) occurs. In this case, the under-control FB will be completed or stop immediately, and servo OFF will be executed.

Hardware stroke limit upper/lower limit error occurrence

When the hardware stroke limit upper/lower limit error occurs, the operation stops according to the process selected by Stop Selection at Hardware Stroke Limit Error Occurrence (AxisName.Pr.StopMode_HwStrokeLimit).

For details, refer to the following.

📖 Page 351 Hardware Stroke Limit

CPU module error occurrence

When the stop error occurs in the control CPU module, PLC READY holds ON, and the motion side will be STOP status.

PLC READY OFF

When the PLC READY is turned OFF, the operation stops according to the process selected by Stop Selection at All Axes Stop Cause Occurrence (System.Pr.StopMode_All).

Cycle over error occurrence

When the cycle over error occurs in operation cycle processing or buffer memory refresh processing, the operation stops according to the process selected by Stop Selection at All Axes Stop Cause Occurrence (System.Pr.StopMode_All). According to the set values of Cycle Over Error Selection (System.PrConst.OperationCycle[1].CycleOverErrorType) and Cycle Over Error Selection (System.PrConst.BuffermemoryRefreshCycle.CycleOverErrorType), different error code is output in every axis.

Setting value	Occurring error	
	System	Axis
2: Minor error (MinorError)	Cycle Over (error code: 1C80H)	Cycle Over (error code: 1C80H)
3: Moderate error (ModerateError)	Cycle Over (error code: 3200H)	Module Error During Operation (error code: 1AB1H)*1

*1 It causes the operation stop as the stop cause at the motion system moderate error or major error occurrence.

Software stroke limit upper/lower limit error occurrence

When the software stroke limit upper/lower limit error occurs, the operation stops according to the process selected by Stop Selection at Software Stroke Limit Error Occurrence (AxisName.Pr.StopMode_SwStrokeLimit).

For details, refer to the following.


 Page 344 Software Stroke Limit

Axis error detection

When an axis error other than the errors below is detected, the operation stops according to the process selected by Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General). In this case, Axis Status (AxisName.Md.AxisStatus) transits to "1: Stopping on error (ErrorStop)".

- Hardware stroke limit upper/lower limit error
- The CPU module error
- An error by the PLC READY OFF
- Cycle Over (error code: 1C80H)
- The software stroke limit upper/lower limit error
- The drive unit error

- Operation of the FB that received a stop cause by axis error occurrence



Driver command discard detection

This function is used to stop commands from the motion system in accordance with detection actions of the drive unit such as limit detection and forced stop.

When the drive unit operates by discarding a command received from the motion system, for example, at the time of limit detection or forced stop, Statusword (Bit12) is turned from ON to OFF. At this point, if the Motion module is in axis operation on a real drive axis, "Driver Command Discard Detection" (error code: 1AE6H) will occur to stop the command.

Point


Before or after "Driver Command Discard Detection" (error code: 1AE6H), an alarm that causes a command discard may occur in the drive unit. If the alarm occurs in the drive unit, troubleshoot it according to the drive unit manuals.

- Driver command discard detection can be enabled/disabled for each axis by setting Driver Command Discard Detection Setting (AxisName.Pr.StopOption_DriverTargetIgnore). (Detection is enabled in the initial state.)
If Driver Command Discard Detection Setting (AxisName.Pr.StopOption_DriverTargetIgnore) is set to FALSE (Detection Disabled), the command from the motion system is continued regardless of Statusword (Bit12). In addition, "Driver Command Discard Detection" (error code: 1AE6H) is not detected.

MC_Stop (Forced Stop)


In MC_Stop (Forced Stop), Deceleration (Deceleration) is set and the under-control FB is decelerated to stop. When MC_Stop (Forced Stop) is executed, Abortion of execution (CommandAborted) of the on-going FB becomes TRUE and Axis Status (AxisName.Md.AxisStatus) transits to the "2: Decelerating to stop (Stopping)" status. While Execute command (Execute) is TRUE or while the speed does not reach 0, the "2: Decelerating to stop (Stopping)" status is maintained. When Execution completion (Done) becomes TRUE and Execute command (Execute) becomes FALSE at stop completion, the axis status changes to the "4: Standby (Standstill)" status.

■MC_Stop (Forced Stop) execution during MCv_SpeedControl (Speed Control (Including Position Loop))




■Operation description

- During deceleration to stop by this FB and while Execute command (Execute) of the input variable is TRUE, any operation command other than MC_Stop (Forced Stop) is not accepted.
- If the deceleration is set to "0.0" or omitted, immediate stop will be executed.
- The acceleration/deceleration method and the jerk take over the method specified in the control being executed and decelerate.
- If MC_GroupStop (Group Forced Stop) is executed during single axis synchronous control, synchronization to the master axis will be canceled.
- When the setting value of Deceleration (Deceleration) is changed and MC_Stop (Forced Stop) is restarted
A deceleration stop is executed from the restart point based on Deceleration (Deceleration) set in MC_Stop (Forced Stop).



- When an FB that operates axes other than MC_Stop (Forced Stop) is executed while Axis Status (AxisName.Md.AxisStatus) is the "2: Decelerating to stop (Stopping)" status "Start Not Possible" (error code: 1AADH) occurs and Error of MC_Stop (Forced Stop) becomes TRUE, and then Axis Status (AxisName.Md.AxisStatus) changes to "1: Stopping on error (ErrorStop)".
- After axis stop, the axis status can be transited to "4: Standby (Standstill)" by executing Axis Error Reset (AxisName.Cd.ErrorReset).
- Even if Execute command (Execute) of command aborted FB by MC_Stop (Forced Stop) set to FALSE, once the stop operation is started, TRUE of Abortion of execution (CommandAborted) will be continued until it is completed. After it stops completely, change Abortion of execution (CommandAborted) to FALSE if Execute command (Execute) of command aborted FB is FALSE.




"Stop signal (STOP)" of external input signal is TRUE

The under-control FB is stopped by setting the stop signal (STOP) set by Stop Signal (AxisName.Pr.StopSignal) to TRUE.

- The operation stops by the operation set in Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).
- The on-going FB sets Abortion of execution (CommandAborted) to TRUE by changing the stop signal (STOP) to TRUE.


When the speed reached 0, Axis Status (AxisName.Md.AxisStatus) transits to "4: Standby (Standstill)".



Point

- When the process is stopped by TRUE of Stop Signal (AxisName.Pr.StopSignal), Axis Status (AxisName.Md.AxisStatus) after stop will not change.
- The deceleration can be changed by executing MC_Stop (Forced Stop) while process stop is executed by TRUE of Stop Signal (AxisName.Pr.StopSignal).
- The deceleration can be changed when Stop Signal (AxisName.Pr.StopSignal) is TRUE during MC_Stop (Forced Stop) execution. In this case, Axis Status (AxisName.Md.AxisStatus) after deceleration stop will not change.

- Even if Execute command (Execute) of command aborted FB is set to FALSE by changing the stop signal (STOP) to TRUE, once the stop operation is started, TRUE of Abortion of execution (CommandAborted) will be continued until it is completed. After it stops completely, change Abortion of execution (CommandAborted) to FALSE if Execute command (Execute) of command aborted FB is FALSE.



Stop during axes group operation

This section describes each stop cause.

Stop cause occurrence in the configuration axis

The following describes the axes group operation when a stop cause of the configuration axis occurs.

Stop cause occurrence axis				Axes group	
Cause No.	Stop cause	Axis Status (<u>AxisName.Md.AxisStatus</u>) at stop cause occurrence	Stop process	Axes Group Status (<u>AxesGroupName.Md.GroupStatus</u>)	Stop process
1	"Forced stop input" is OFF	1: Stopping on error (ErrorStop)	Immediate stop*1	1: Stopping on error (GroupErrorStop)	<p>■ Stop cause occurrence axis Immediate stop</p> <p>■ Other configuration axes Axes group deceleration stop/immediate stop (Follows Configuration Axes Operation Selection at Axis Stop Cause Occurrence (<u>AxesGroupName.Pr.StopMode_ErrorInGroup</u>))</p>
2	Drive unit power supply is OFF Drive unit network disconnection detection Drive unit error Forced stop input to the drive unit Enable (Enable) of MC_Power (Operation Available) is FALSE Servo ON request (ServoON) of MC_Power (Operation Available) is FALSE (When Process Selection at Servo OFF Command During Operation (<u>AxisName.Pr.StopMode_ServoOff</u>) is "4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)")	1: Stopping on error (ErrorStop)			
3	Hardware stroke limit upper/lower limit error occurrence in the configuration axis	1: Stopping on error (ErrorStop)	Based on the axes group stop process		<p>Operation differs depending on the setting value of Stop Selection at Hardware Stroke Limit Error Occurrence (<u>AxisName.Pr.StopMode_HwStrokeLimit</u>) of the configuration axis.</p> <p>■ When the configuration axis has an axis set to "1: Immediate Stop (ImmediateStop)" Immediately stop</p> <p>■ When the configuration axis does not have an axis set to "1: Immediate Stop (ImmediateStop)" Axes group deceleration stop/immediately stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName.Pr.StopMode_General</u>))</p>
4	CPU module error occurrence PLC READY is OFF Cycle over error occurrence	1: Stopping on error (ErrorStop)			<p>Axes group deceleration stop/immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName.Pr.StopMode_General</u>))</p>
5	Software stroke limit upper/lower limit error occurrence in the configuration axis	1: Stopping on error (ErrorStop)			<p>Operation differs depending on the setting value of Stop Selection at Software Stroke Limit Error Occurrence (<u>AxisName.Pr.StopMode_SwStrokeLimit</u>) of the configuration axis.</p> <p>■ When the configuration axis has an axis set to "1: Immediate Stop (ImmediateStop)" Immediately stop</p> <p>■ When the configuration axis does not have an axis set to "1: Immediate Stop (ImmediateStop)" Axes group deceleration stop/Immediately stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName.Pr.StopMode_General</u>))</p>

Stop cause occurrence axis				Axes group	
Cause No.	Stop cause	Axis Status (<u>AxisName.Md.AxisStatus</u>) at stop cause occurrence	Stop process	Axes Group Status (<u>AxesGroupName.Md.GroupStatus</u>)	Stop process
6	Axis error detection	1: Stopping on error (ErrorStop)	Based on the axes group stop process	1: Stopping on error (GroupErrorStop)	Axes group deceleration stop/immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxesGroupName.Pr.StopMode_General</u>))
7	Execute command (Execute of MC_Stop (Forced Stop) is TRUE)	1: Stopping on error (ErrorStop)*2			
8	"Stop signal (STOP)" of external input signal is TRUE	No change		No change	

*1 The servo OFF is executed on the drive unit side and the axis immediately stops, and also the motion side command is stopped.

*2 If a single axis FB is executed during axes group operation, an axis error will occur and the single axis FB will be disabled. For details, refer to the following.

☞ Page 184 Axis error

When a stop cause has occurred in a configuration axis of the axes group, operation differs depending on the following four patterns.

■ For an axis error (drive unit servo OFF and immediate stop)


"Stop Cause of Axes Group Configuration Axis" (error code: 1A3DH) occurs in the axes group.

Also, if the drive unit of the configuration axis in which the stop cause has occurred turns to servo OFF to immediately stop the operation, the other configuration axes will be operated according to the stop process selected in Configuration Axes Operation Selection at Axis Stop Cause Occurrence (AxesGroupName.Pr.StopMode_ErrorInGroup).

When a stop cause has occurred in a configuration axis during the axes group operation, the following methods show how to stop the other configuration axes.

- 1: Immediate Stop (ImmediateStop)

In the axes group configuration axes other than the axis which an axis error has occurred in, a command to the drive unit is stopped.



■Axis error


If an axis error has occurred in the configuration axis, "Stop Cause of Axes Group Configuration Axis" (error code: 1A3DH) will occur in the axes group. In this case, the axes group will pass through the path and stop according to the setting of Stop Selection at Stop Cause Occurrence (AxesGroupName.Pr.StopMode_General).

If a single axis control FB is executed to the configuration axis being operated in the axes group, an error will occur in the single axis control FB, and the specified axis will be in "Start Not Possible" (error code: 1AADH) or "Motion FB Issue Error to the Axis during Axes Group Operating" (error code: 1A7CH), and then enter the "1: Stopping on error (ErrorStop)" status. By an error occurrence in the configuration axis, "Stop Cause of Axes Group Configuration Axis" (error code: 1A3DH) occurs in the axes group, and the axes group will stop according to the process selected in Stop Selection at Stop Cause Occurrence (AxesGroupName.Pr.StopMode_General).

■"Stop signal (STOP)" of external input signal is TRUE

When the stop signal (STOP) of external input signal (AxisName.Pr.StopSignal) is set to TRUE with respect to any configuration axis, the current under-control FB stops.


- The FB stops according to the operation set with the stop selection at stop cause occurrence (AxesGroupName.Pr.StopMode_General).
- The axes group will pass through the path and decelerate to a stop.
- When Stop Signal (AxisName.Pr.StopSignal) is set to TRUE, the current under-control FB sets Abortion of execution (CommandAborted) to TRUE. When the speed reaches 0, Abortion of execution (CommandAborted) will become TRUE, and Axes Group Status (AxesGroupName.Md.GroupStatus) will transit to "4: Standby (GroupStandby)". The value set in Deceleration at Stop (AxesGroupName.Pr.StopMode_Deceleration) will be used for the deceleration at this time.



Point

- When stopping by setting Stop Signal (AxisName.Pr.StopSignal) to TRUE, Axes Group Status (AxesGroupName.Md.GroupStatus) after stop will not change.
- When the stop processing is being executed by setting Stop Signal (AxisName.Pr.StopSignal) to TRUE, the deceleration can be changed by executing MC_GroupStop (Group Forced Stop).
- The deceleration can be changed by setting Stop Signal (AxisName.Pr.StopSignal) to TRUE during MC_GroupStop (Group Forced Stop) execution. In this case, Axes Group Status (AxesGroupName.Md.GroupStatus) after the deceleration stop will not change.

- Even if Execute command (Execute) of command aborted FB is set to FALSE by changing Stop Signal (AxisName.Pr.StopSignal) to TRUE, once the stop operation is started, TRUE of Abortion of execution (CommandAborted) will be continued until it is completed. After it stops completely, change Abortion of execution (CommandAborted) to FALSE if Execute command (Execute) of command aborted FB is FALSE.



■Hardware stroke limit error/Software stroke limit error

When any of the following conditions is satisfied, the axes group will immediately stop regardless of the axes group setting. In this case, "Stop Cause of Axes Group Configuration Axis" (error code: 1A3DH) occurs in the axes group and its status changes to the "1: Stopping on error (GroupErrorStop)".

- When the stop cause "Hardware stroke limit error" is occurring in any axis of configuration axes, "1: Immediate Stop (ImmediateStop)" is set to Stop Selection at Hardware Stroke Limit Error Occurrence (AxisName.Pr.StopMode_HwStrokeLimit) in one or more axes.
- When the stop cause "Software stroke limit error" is occurring in any axis of configuration axes, "1: Immediate Stop (ImmediateStop)" is set to Stop Selection at Software Stroke Limit Error Occurrence (AxisName.Pr.StopMode_SwStrokeLimit) in one or more axes.

Hardware stroke limit error	Software stroke limit error
<ul style="list-style-type: none"> • FLS Signal Detection (at Start) (error code: 1A2DH) • RLS Signal Detection (at Start) (error code: 1A2EH) • FLS Signal Detection (Controlling) (error code: 1A2FH) • RLS Signal Detection (Controlling) (error code: 1A30H) 	<ul style="list-style-type: none"> • Software Stroke Limit Over (Target Position) (error code: 1A00H) • Software Stroke Limit Over (Start Position) (error code: 1A01H) • Software Stroke Limit Over (Forward Direction) (error code: 1A03H) • Software Stroke Limit Over (Reverse Direction) (error code: 1A04H)


Axes group error detection

When an axes group error other than the "Stop cause occurrence in the configuration axis" is detected, the operation will be stopped according to the process selected by Stop Selection at Stop Cause Occurrence

(AxesGroupName.Pr.StopMode_General). The value set in Deceleration at Stop

(AxesGroupName.Pr.StopMode_Deceleration) will be used for the deceleration at this time.

- Operation of the FB that received a stop cause by axes group error occurrence




MC_GroupStop (Group Forced Stop)

In MC_GroupStop (Group Forced Stop), Deceleration (Deceleration) is set and the under-control FB is decelerated to stop. The axes group passes through the previous operation path and decelerates to a stop.


When MC_GroupStop (Group Forced Stop) is executed, Abortion of execution (CommandAborted) of the on-going FB becomes TRUE and Axes Group Status (AxesGroupName.Md.GroupStatus) transits to the "2: Decelerating to stop (GroupStopping)" status. While Execute command (Execute) is TRUE or while the speed does not reach 0, the "2: Decelerating to stop (GroupStopping)" status is maintained. When Execution completion (Done) becomes TRUE and Execute command (Execute) becomes FALSE at stop completion, the axes group status changes to the "4: Standby (GroupStandby)" status.

■MC_GroupStop (Group Forced Stop) execution during MCv_MoveLinearInterpolateRelative (Relative Value Linear Interpolation Control)




■ Operation description

- During deceleration stop by this FB and while Execute command (Execute) of the input variable is TRUE, any operation command other than MC_GroupStop (Group Forced Stop) is not accepted.
- If Deceleration (Deceleration) is set with "0.0" or omitted, immediate stop will be executed.
- The acceleration/deceleration method and the jerk take over the method specified in the on-going control.
- When the setting value of Deceleration (Deceleration) is changed and MC_GroupStop (Group Forced Stop) is restarted, A deceleration stop is executed from the restart point based on Deceleration (Deceleration) set in MC_GroupStop (Group Forced Stop) and Jerk (Jerk) used in the under-control FB.



- When an FB that operates axes other than MC_GroupStop (Group Forced Stop) is executed while Axes Group Status (AxesGroupName.Md.GroupStatus) is the "2: Decelerating to stop (GroupStopping)" status, "Start Not Possible" (error code: 1AADH) occurs and Error of MC_GroupStop (Group Forced Stop) becomes TRUE, and then Axes Group Status (AxesGroupName.Md.GroupStatus) changes to "1: Stopping on error (GroupErrorStop)".
- Even if Execute command (Execute) of command aborted FB is set to FALSE by MC_GroupStop (Group Forced Stop), once the stop operation is started, Abortion of execution (CommandAborted) will remain TRUE until it is completed. After it stops completely, change Abortion of execution (CommandAborted) to FALSE if Execute command (Execute) of command aborted FB is FALSE.



Precautions

Relevant add-ons

The following add-on is required to use this function.

- Axis
- MotionEngine
- ExternalSignal^{*1}
- MotionControl_General^{*2}
- ServoDriver_CANopen^{*3}

^{*1} For using the stop signal, the forced stop signal, the all axes forced stop signal, and the upper/lower limit signal

^{*2} For using the following FBs

- MC_Stop (Forced stop)
- MC_GroupStop (Group Forced Stop)

^{*3} For using the real drive axis or the real encoder axis

4.5 Forced Stop

This function stops axes with the forced stop signal.

The axis types which the forced stop is valid are as follows.

- The forced stop signal is valid for the following axis types which supports Forced Stop Signal (AxisName.Pr.ForcedStop_Signal).
 - Real drive axis
 - Virtual drive axis
- The all axes forced stop signal is valid for the following axes including the types which do not support Forced Stop Signal (AxisName.Pr.ForcedStop_Signal).
 - Real drive axis
 - Virtual drive axis
 - Virtual linked axis
- Refer to the drive unit manual for the drive unit after the forced stop signal is sent.

WARNING

- When the forced stop is required to be wired, ensure to wire it in the negative logic, and b-contact is recommended.
- When using the forced stop function, confirm the wiring and the settings, and check whether it works or not at startup.

Point

The forced stop function immediately stops the instruction and issues "Quick Stop" to the device station at the same time. For operation when "Quick Stop" is issued, refer to the manual of the device station.

Operation of this function for each system status

○: Possible, △: Possible (restricted)

Status	Operation availability
STOP	△ ^{*1}
RUN	○
Moderate error	△ ^{*2}
Major error	△ ^{*2}

*1 Since the Forced Stop Signal (AxisName.Pr.ForcedStop_Signal) cannot be read, if it has never been set to RUN, operation will not be possible.

*2 Depending on the error, it may not be possible to issue QuickStop.

When a moderate or major error occurs, the motion system notifies the device station that an error has been detected in the CPU operating status. For details on the operation of the device station when an error is detected, refer to each device station manual.

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
ForcedStop_Signal	Forced Stop Signal	<p>Sets a signal using the each axis forced stop.</p> <p>Forced Stop Signal (ForcedStop_Signal) is the structure of SIGNAL_SELECT type.</p> <p>The fetch timing of the setting is at Ready ON, and the detection timing of the signal is the axis operation cycle.</p> <p>For details on SIGNAL_SELECT type, refer to the following.</p> <p>☞ Page 424 External Signal Selection</p> <p>The specific setting and the operation of this signal are shown below.</p> <p>■ I/O Number (StartIO) Ignores the input value.</p> <p>■ Target (Target) If the target is unspecified, it is regarded as invalid signal and it is always in the signal undetection status.</p> <p>Only [VAR] , [DEV] , and [CONST] can be specified for the data type.</p> <p>*: When unavailable data is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■ Signal Detection Method (Detection) The specification is allowed at the following level detection only.</p> <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel) <p>*: When edge detection specification is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■ Compensation Time (CompensationTime) Ignores the input value.</p> <p>■ Filter Time (FilterTime) Setting range of the filter time is 0.0 to +5.0.</p> <p>*: When a value outside the range is set, "Out of Filter Time Setting Range of Each Axis Signal Warning" (warning code: 0D24H) occurs. and the axis operates with 0.0 of the filter time.</p>

Axis monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
ForcedStop_Released	Forced Stop Cancelling	<p>Displays the forced stop cancel status.</p> <ul style="list-style-type: none"> • FALSE: Forced stop input TRUE (Forced stop) • TRUE: Forced stop input FALSE (Forced stop release)
ForcedStop_Signal	Forced Stop Signal	<p>Displays the input status of axis forced stop signal.</p> <p>Forced Stop Signal (ForcedStop_Signal) is the structure of SIGNAL_SELECT type.</p> <p>For details on SIGNAL_SELECT type, refer to the following.</p> <p>☞ Page 424 External Signal Selection</p> <p>The specific output of this signal is shown below.</p> <p>■ I/O Number (StartIO) "0" is always displayed.</p> <p>■ Target (Target) The fetch result of the parameter is displayed.</p> <p>■ Signal Detection Method (Detection) The fetch result of the parameter is displayed.</p> <p>■ Compensation Time (CompensationTime) "0.0" is always displayed.</p> <p>■ Filter Time (FilterTime) The fetch result of the parameter is displayed.</p>

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
StopMode_ErrorInGroup	Configuration Axes Operation Selection at Axis Stop Cause Occurrence	<p>During operation in the axes group, when the drive unit servo is turned OFF on the configuration axis and an immediate stop axis error occurs, it sets the operation of the axes to which no axis error occurs.</p> <ul style="list-style-type: none"> • 1: Immediate Stop (ImmediateStop) (Default value)

System parameter (System.Pr.)

Variable/Structure name	Name	Details
ForcedStop_Signal	All Axes Forced Stop Signal	<p>Sets a signal using the all axes forced stop.</p> <p>All Axes Forced Stop Signal (ForcedStop_Signal) is the structure of SIGNAL_SELECT type.</p> <p>The fetch timing of the setting is at Ready ON, the detection timing of the signal is the first operation cycle, and the timing for starting the stop processing is the axis operation cycle.</p> <p>For details on SIGNAL_SELECT type, refer to the following.</p> <p>☞ Page 424 External Signal Selection</p> <p>The specific setting and the operation of this signal are shown below.</p> <p>■ I/O Number (StartIO)</p> <p>"0" is always displayed.</p> <p>■ Target (Target)</p> <p>If the target is unspecified, it is regarded as invalid signal and it is always in the signal undetection status.</p> <p>Only [VAR] , [DEV] , and [CONST] can be specified for the data type.</p> <p>*: When unavailable data is set, "Out of Parameter Range(System)" (error code: 1D82H) occurs.</p> <p>■ Signal Detection Method (Detection)</p> <p>The specification is allowed at the following level detection only.</p> <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel) <p>*: When edge detection specification is set, "Out of Parameter Range (System)" (error code: 1D82H) occurs.</p> <p>■ Compensation Time (CompensationTime)</p> <p>Ignores the input value.</p> <p>■ Filter Time (FilterTime)</p> <p>Setting range of the filter time is 0.0 to +5.0.</p> <p>*: When a value outside the range is set, "Out of Filter Time Setting Range of System Signal Warning" (warning code: 0F0FH) is output occurs and the axis operates with 0.0 of the filter time.</p>

System monitor data (System.Md.)


Variable/Structure name	Name	Details
ForcedStop_Released	Forced Stop Cancelling	<p>Displays the forced stop cancel status.</p> <ul style="list-style-type: none"> • FALSE: All axes forced stop input TRUE (Forced stop) • TRUE: All axes forced stop input FALSE (Forced stop release)
ForcedStop_Signal	All Axes Forced Stop Signal	<p>Displays the input status of all axes forced stop signal.</p> <p>All Axes Forced Stop Signal (ForcedStop_Signal) is the structure of SIGNAL_SELECT type.</p> <p>For details on SIGNAL_SELECT type, refer to the following.</p> <p>☞ Page 424 External Signal Selection</p> <p>The specific output of this signal is shown below.</p> <p>■ I/O Number (StartIO)</p> <p>"0" is always displayed.</p> <p>■ Target (Target)</p> <p>The fetch result of the parameter is displayed.</p> <p>■ Signal Detection Method (Detection)</p> <p>The fetch result of the parameter is displayed.</p> <p>■ Compensation Time (CompensationTime)</p> <p>"0.0" is always displayed.</p> <p>■ Filter Time (FilterTime)</p> <p>The fetch result of the parameter is displayed.</p>

Operation at the forced stop occurrence

This section describes the operation when a forced stop has occurred.

An example of a device station which servo OFF is executed when "Quick Stop" is issued is connected is shown below.

During axis operation




- In the axis to which a forced stop has occurred, the servo OFF is executed. The servo ON will not be executed until the forced stop is released.
- The error is not output when the axis is not operated.
- In positioning or stopping, "Forced stop detection" is registered in the event history.
- "Forced Stop Status" (error code: 1A5BH) is also registered in positioning.
- When the axis is in the forced stop status at start, the command will not be issued, and it will be in the same "1: Stopping on error (ErrorStop)" status as the forced stop that is in operation.

During stop

When the axis the forced stop occurred in is during stop, "Forced Stop Status" (error code: 1A5BH) will not occur. Axis Status (AxisName.Md.AxisStatus) transits according to the drive unit operation that received the forced stop signal of the controller.

During axes group operation

The following shows the operation when a forced stop has occurred to the axis A while an axes group configured with the axis A and B is being operated.




The stop method of the axis B can be set in Configuration Axes Operation Selection at Axis Stop Cause Occurrence (AxesGroupName.Pr.StopMode_ForcedStopInGroup). For the operation of each setting, refer to the following.

☞ Page 182 Stop cause occurrence in the configuration axis

Operation at the forced stop release

The operation the forced stop is released from the forced stop occurrence status is shown below.


Single axis



1. Release the forced stop.
 - The forced stop input changes to "1".
 - Axis Status (AxisName.Md.AxisStatus) is still "1: Stopping on error (ErrorStop)".
2. Execute the axis error reset.
 - Axis Status (AxisName.Md.AxisStatus) changes to "0: Axis disabled (Disabled)".

Axes group

The following shows the release operation when a forced stop has occurred to the axis A while an axes group configured with the axis A and B is being operated.



1. Release the forced stop.
 - The forced stop input changes to "1".
 - Axes Group Status (AxesGroupName.Md.GroupStatus) is still "1: Stopping on error (GroupErrorStop)".
2. Execute the axes group error reset.
 - Axes Group Status (AxesGroupName.Md.GroupStatus) changes to "4: Standby (GroupStandby)", and the error Nos. are cleared in both the axis A and the axes group.



When the forced stop is issued, the servo ON command of MC_Power (Operation Available) continues.

Check method

Whether the forced stop input is in the TRUE/FALSE status can be checked with Forced Stop Cancelling (AxisName.Md.ForcedStop_Released).

Precautions

Relevant add-ons

The following add-ons are required to use this function.

- Axis
- MotionEngine
- ExternalSignal

5 HOMING

In "homing", a position is established as the starting (or "home position") when carrying out positioning control, and positioning is carried out toward that start point.

It is used to return a machine system at any position other than the home position to the home position when the motion system issues a "homing request" with the power turned ON or others, or after a positioning stop.

The address information stored in the motion system cannot be guaranteed while the Homing Request (AxisName.Md.Homing_Request) is TRUE.

Homing Request (AxisName.Md.Homing_Request) is FALSE and Homing Completed (AxisName.Md.Homing_Complete) is TRUE if the homing is executed and is completed normally.

⚠ CAUTION


- When using an absolute position system, execute a homing always at the following cases: on starting up and when the controller or absolute position motor has been replaced. Check the homing request signal using the program, etc. before performing the positioning control. Failure to observe this could lead to an accident such as a collision.

5.1 Overview

In homing, a machine home position is established.

None of the address information stored in the motion system or drive unit is used at this time.

The position mechanically established after the homing is regarded as the "home position" to be the start point for positioning control.



Homing method at homing starts is "driver homing method" when all of the following conditions are satisfied, or "data set homing method" when the following conditions are not satisfied.

- Axis type is real drive axis
- Drive unit supports Homing mode
- "Home offset (607CH)" of the object data is set.

Operation of this function for each system status

○: Possible, ×: Not possible

System status	Operation availability
STOP	×
RUN	○
Moderate error	×
Major error	×

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
Homing_Status	Homing Operation Status	Stores the homing status of the drive unit.*1
Homing_Request	Homing Request	Becomes TRUE when homing is required and becomes FALSE when it is completed. For details, refer to the following.  Page 197 Homing request
Homing_Complete	Homing Completed	Becomes TRUE when homing is normally completed, and it becomes FALSE when operation starts and homing is required.

*1 The following value of homing operation status is stored.

Stored value	Status	Statusword		
		Bit 13	Bit 12	Bit 10
FFFFH	Homing procedure is not in progress	—		
0000H	Homing procedure is in progress	0	0	0
0001H	Homing procedure is interrupted or not started	0	0	1
0002H	Homing is attained, but target is not reached	0	1	0
0003H	Homing procedure is completed successfully	0	1	1
0004H	Homing error occurred, velocity is not 0	1	0	0
0005H	Homing error occurred, velocity is 0	1	0	1

Relevant FB

For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_Home	OPR	Executes homing of the specified axis.

Homing request

Homing Request (AxisName.Md.Homing_Request) must be TRUE in the motion system, and homing must be executed.

Point

The reason why Homing Request (AxisName.Md.Homing_Request) is TRUE is recorded in event history.

For causes of which Homing Request (AxisName.Md.Homing_Request) becomes TRUE, refer to the following.

 Page 98 Homing request

Homing Request (AxisName.Md.Homing_Request) becomes FALSE at homing completion.

When homing is not required

Execute a homing request clear in systems that do not require homing. Homing Request (AxisName.Md.Homing_Request) becomes FALSE by performing the homing request clear. For details, refer to the following.

 Page 204 Operation Setting for Incompletion of Homing

Precautions


Directly rewriting Homing Request (AxisName.Md.Homing_Request) to FALSE with a program, etc. will not clear the homing request in the Motion system. Be sure to use the homing request clear to set Homing Request (AxisName.Md.Homing_Request) to FALSE.

Driver homing method

The drive unit is switched to the Homing mode, and the homing is executed based on the positioning pattern set on the drive unit side. Change the homing data of the drive unit with MC_WriteParameter (Parameter Write) to change the homing method or each parameter. Refer to the manual of the drive unit because the homing operation and parameters depend on the specification of the drive unit.

Timing chart

Normal operation




*1 When "0: Follow-up disabled" is selected in Follow-up enabled/disabled selection (Options (Options): Bit 16), it will not be updated during homing. When "0: Follow-up enabled" is selected, it will be updated at being changed the current position during homing.

When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ When MC_Stop (Forced Stop) is executed



- When MC_Stop (Forced Stop) is set to TRUE at homing, the "HALT" signal is sent to the drive unit. When using a drive unit that does not support HALT, use the forced stop because it does not stop with this signal.
- Stop processing at homing depends on the drive unit specifications. Therefore, Deceleration (Deceleration) and Jerk (Jerk) of MC_Stop (Forced Stop) are ignored.

Precautions

- The homing cannot be started during servo-off. Thus, the drive unit homing method, Homing method 35 and 37 (Data set method), cannot be executed during servo-off.
- When the external signals (the hardware stroke limit specified with axis variables and the proximity dog specified with Home position switch (AbsSwitch)) are assigned, the external signals are transmitted to the drive unit. However, when the position accuracy is required in the proximity dog based (not Z-phase based) method, using the drive unit built-in DI is recommended.
- Just before homing is completed, a monitor data such as Actual Position (AxisName.Md.ActualPosition) may fluctuate rapidly regardless of the actual motor operation. Even if this symptom occurs, there is no effect on the monitor data after homing.
- When "0: Follow-up disabled" is selected in Follow-up enabled/disabled selection (Options (Options): Bit 16), the follow up of set position is not performed during driver homing method.
In this case, do not perform synchronous control with the setting the axis during homing as the master axis. In the slave axis, "Velocity Range Over during Controlling" (error code: 1AE8H) may occur.
- When "1: Follow-up enabled" is selected in Follow-up enabled/disabled selection (Options (Options): Bit 16) and synchronous control is performed with the setting the axis during homing as the master axis, the slave axis operation is as follows depending on Master axis data source selection (MasterValueSource).

Master axis data source selection (MasterValueSource)	Slave axis operation during synchronous control
1: Set Value (mcSetValue) 101: Latest Set Value (mcLatestSetValue)	Continues synchronous control after homing completion.
2: Actual Value (mcActualValue) 102: Latest Actual Value (mcLatestActualValue)	Although the slave axis synchronizes to the master axis until homing completion, synchronous control may not be performed and an error or an alarm may occur on the drive unit side due to rapid motor acceleration or excessive command input. For details, refer to the manual of each drive unit. <Example> MR-J5(W)-G • A servo alarm [AL. 031.1_Servo motor speed error] or [AL. 035.1_Command frequency error] may occur.

- If the stop cause occurs when Homing Operation Status (AxisName.Md.Homing_Status) is set to "0002H: Homing completed (target is not reached to the target position)", the set position executed follow-up changed significantly. Therefore, an error or a servo alarm may occur on the drive unit side even if "1: Set Value (mcSetValue)" or "101: Latest Set Value (mcLatestSetValue)" is selected in Master axis data source selection (MasterValueSource). For details, refer to the manual of each drive unit. In MR-J5(W)-G, the servo alarm [AL. 031.1_Servo motor speed error] or the servo alarm [AL. 035.1_Command frequency error] may occur.
- If the following items are not mapped, backup is not guaranteed.
Home cycle counter (2D3DH)
Home ABS counter (2D3EH)
- DOG signal inputted in the servo amplifier at MR-J5(W)-G connection can be specified as a home position switch signal. For details on the setting method, refer to the following.
 Page 732 Using methods
- The hardware stroke limit signal detection is performed during the homing in the Motion module. When the signal is detected, "HALT" signal is sent to the drive unit. To execute homing in the homing method using the hardware stroke limit signal, make the hardware stroke limit check of the Motion module side invalid temporarily by turning Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) to DISABLE (Check disabled).
- If ONLY_INSIDE (Check disabled for movement returning to the range) is set in Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) at homing start, "Start Not Possible" (error code: 1AADH) occurs and the homing start is not carried out.
- When executing homing in a drive unit other than MELSERVO, set the parameter of the drive unit so that "Home offset" is 0. If other than 0 is set, an unintended operation may occur at homing completion.

Relevant object

Functions subject to errors and restrictions under the following conditions will be shown below.

- No object data set
- No PDO mapping
- No object for the device station

Refer to the following for details of object data setting.

📖 Page 60 Object data settings

■PDO

Not applicable

■SDO

○: Object recommended


Motion control FB/ function	Required object data	Object necessary or not	Operation when no object is set
Driver homing method	Home offset (607CH)	○	Operates with data set method. For details, refer to the following. 📖 Page 202 Data set homing method

Data set homing method

"Data set homing method" is executed to a virtual axis and a real axis that does not have the home position information in the device station side. It is completed in the motion system, and external signals, etc. are not used. Target position (Position) (home position address) at homing is registered in the motion system as the home position, and Set Position (AxisName.Md.SetPosition) and Cumulative Current Position (AxisName.Md.CumulativePosition) are rewritten to Target position (Position) (home position address).

Timing chart

■Normal operation



■When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Precautions

- FBs other than MC_Stop (Forced Stop) cannot start during homing.
- The software stroke limit check for Target position (Position) (home position address) at homing start is shown below.

Home position return method	Description
Driver homing method	The software stroke limit check is not performed.
Data set homing method	The software stroke limit check is performed.

- The software stroke limit check of the start position is not performed at homing start.
- The software stroke limit is not checked during homing.
- The movement direction at homing completion is in positive direction.
- Homing does not support the velocity bias function. Set the minimum speed of the driver homing method by the drive unit.

Relevant add-ons

The following add-ons are required to use this function.

- Axis
- MotionEngine
- MotionControl_General
- NetworkDriver_CCIETSN^{*1}
- ServoDriver_CANopen^{*1}
- SignalIO^{*2}

^{*1} When using the real axis

^{*2} When using the Home position switch (AbsSwitch)

Error

Check that Axis Status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)" at MC_Home (OPR) execution. If it is other than "4: Standby (Standstill)", an error will occur and the control during operation will stop.

5.2 Operation Setting for Incompletion of Homing

The operation setting for incompletion of homing is provided to select whether the axis is started or not when the homing request, Homing Request (AxisName.Md.Homing_Request) is TRUE.

When starting the axis at homing incompletion, whether the axis can startup or not is determined by the executed FB and Start Permission at Homing Uncompleted (AxisName.Pr.StartableAtUnhomed).

○: Axis start possible, ×: Axis start impossible

FB	Start Permission at Homing Uncompleted (<u>AxisName</u> .Pr.StartableAtUnhomed)	
	"TRUE: Allow" and the homing request (<u>AxisName</u> .Md.Homing_Request) is TRUE	"FALSE: Not allowed" and the homing request (<u>AxisName</u> .Md.Homing_Request) is TRUE
FBs that can be started when homing is incompletion	○ ^{*1}	○ ^{*1}
The motion FBs other than the above	○ ^{*1}	×

*1 There may be restrictions in the operation for incompletion of homing depending on the setting or specifications of the drive unit. For details, refer to each drive unit manual.

For MR-J5(W)-G:  MR-J5 User's Manual (Function)

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
StartableAtUnhomed	Start Permission at Homing Uncompleted	Sets whether axis start is allowed or not when homing is incompletion is incomplete. <ul style="list-style-type: none">• FALSE: Disabled• TRUE: Enabled

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
Homing_Request	Homing Request	Becomes TRUE when homing is required and becomes FALSE when it is completed. For details, refer to the following.  Page 197 Homing request

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
Homing_ClearRequest	Homing Request Clear	Sets the homing request to FALSE forcibly. After the homing request is set to FALSE, FALSE is set in this variable automatically. <ul style="list-style-type: none">• FALSE: Not executed• TRUE: Executes the homing request clear

FBs that can be started when homing is incomplection

The following FBs can start the axis regardless of Start Permission at Homing Uncompleted (AxisName.Pr.StartableAtUnhomed) and Homing Request (AxisName.Md.Homing_Request) status.

FBs that can be started when homing is incomplection
MC_Home (OPR)
MCv_Jog (JOG)
MC_Stop (Forced Stop)
MC_GroupStop (Group Forced Stop)
FBs other than the motion FBs

The axis start other than the above cannot start the axis when Start Permission at Homing Uncompleted (AxisName.Pr.StartableAtUnhomed) is FALSE and Homing Request (AxisName.Md.Homing_Request) is TRUE, and "Start at Homing Incomplete" (error code: 1A22H) occurs.

Homing request clear

When Homing Request (AxisName.Md.Homing_Request) is TRUE, Homing Request (AxisName.Md.Homing_Request) can be changed to FALSE forcibly by setting Homing Request Clear (AxisName.Cd.Homing_ClearRequest) to TRUE.

Precautions

- In Homing Request Clear (AxisName.Cd.Homing_ClearRequest), when turning Homing Request (AxisName.Md.Homing_Request) FALSE and starting the axis, it is operated not based on the home position but based on the current coordinate system.
- Do not turn Homing Request Clear (AxisName.Cd.Homing_ClearRequest) TRUE during homing.

6 AXIS CONTROL FUNCTION

6.1 Single Axis Positioning Control

The details and usages of the single axis positioning controls are described in this section.

The single axis positioning controls execute positioning to the specified position by using address information.

Relevant FBs

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)


Motion control FB	Name	Description
MC_MoveAbsolute	Absolute Value Positioning	Executes positioning after specifying the target position of the absolute position.
MC_MoveRelative	Relative Value Positioning	Executes positioning after specifying the movement amount of the relative position.

Absolute positioning control

In MC_MoveAbsolute (Absolute Value Positioning), Target position (Position), Velocity (Velocity), Acceleration (Acceleration), Deceleration (Deceleration), Jerk (Jerk), Direction selection (Direction), Buffer mode (BufferMode), and Options (Options) can be set, and positioning is executed from the current position at start (start point address) to the address set in Target position (Position) (end point address).

Ex.

When the start point address is "1000.0" and Target position (Position) is "8000.0", positioning is carried out in the positive direction for a movement amount of "7000.0 (8000.0 - 1000.0)".



Necessary object data

When using MC_MoveAbsolute (Absolute Value Positioning), map the object assigned to the following object data to PDO.

- Target position (607AH)

If the above object is not mapped to PDO, "Necessary Object Data Unset" (error code: 1AA8H) will occur, and the operation will not start.

For details on the object data setting, refer to the following.


📖 Page 57 Axis Assignment

Relative positioning control

In MC_MoveRelative (Relative Value Positioning), Movement amount (Distance), Velocity (Velocity), Acceleration (Acceleration), Deceleration (Deceleration), Jerk (Jerk), and Buffer mode (BufferMode) can be set, and positioning corresponding to movement amount set in Movement amount (Distance) is executed from the current position at start (start point address). The movement direction is determined by the sign of the movement amount. Axis Status (AxisName.Md.AxisStatus) becomes "5: During positioning operation (DiscreteMotion)".

Ex.

When the start point address is "-3000.0", and the movement amount is "-5000.0", positioning is carried out to "-8000.0".



Necessary object data

When using MC_MoveRelative (Relative Value Positioning), map the object assigned to the following object data to PDO.

- Target position (607AH)

If the above object is not mapped to PDO, "Necessary Object Data Unset" (error code: 1AA8H) will occur, and the FB will not start.

For details on the object data setting, refer to the following.

 Page 57 Axis Assignment

Precautions

- Even though a FB is restarted or continuously updated, the current position where this FB was started for the first time is the starting address.
- Since it is processed with the floating point type, if the relative value positioning control is repeatedly executed, the movement amount specified may not be reached due to the calculation error.

6.2 Single Axis Speed Control

This section describes operation of the single axis speed control (including position loop).

For speed control excluding position loop, refer to the following.

📖 Page 295 Velocity Control

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)


Motion control FB	Name	Description
MCv SpeedControl	Speed Control (Including Position Loop)	Executes the speed control including position loop.

Control details

Set the control mode of the drive unit side to csp (cyclic synchronous position mode) and execute the speed control for the specified axis with the specified speed. MCv_SpeedControl (Speed Control (Including Position Loop)) is used to execute. To stop the axis, use MC_Stop (Forced Stop) or start another motion FB.


To perform the speed control with the control mode of the drive unit side set to csv (cyclic synchronous velocity mode), use MC_MoveVelocity (Speed Control), etc.

Timing chart at start and the stop cause occurrence



Timing chart when the operation direction is changed

If the sign of Velocity (Velocity) is reversed and the operation direction is changed when Continuous update (ContinuousUpdate) is TRUE, the axis accelerates toward the target velocity once after the deceleration stop.



Buffer mode (BufferMode)

Select a buffer mode. Aborting, Buffered, BlendingLow, BlendingPrevious, BlendingNext, and BlendingHigh can be set. For details on the operation, refer to the following.

Page 135 Buffer mode type

Necessary object data

When using Speed Control (Including Position Loop) for a single axis, map the object assigned to the following object data to PDO.

- Target position (607AH)

If the above object is not mapped to PDO, "Necessary Object Data Unset" (error code: 1AA8H) occurs, and the velocity control of the axis does not start.

For details of object data settings, refer to the following.

Page 57 Axis Assignment

6.3 Single Axis Manual Control

This section describes the single axis manual control.

Relevant variables

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
SwStrokeLimit_Override	Software Stroke Limit Override	Temporarily switches valid/invalid of the software stroke limit check. <ul style="list-style-type: none">• DISABLE: Check disabled• ONLY_INSIDE: Disables the check only for movement toward the setting range.• Other than the above: Check enabled (no disable request)
HwStrokeLimit_Override	Hardware Stroke Limit Override	Temporarily switches valid/invalid of the hardware stroke limit check. <ul style="list-style-type: none">• DISABLE: Check disabled• ONLY_INSIDE: Disables the check only for movement toward the setting range.• Other than the above: Check enabled (no disable request)

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)


Motion control FB	Name	Description
MCv Jog	JOG Operation	Executes JOG operation according to the commanded velocity.

Types of manual control

There is the following type of manual control.

JOG operation

JOG operation is a control method in which the machine is moved by only a movement amount (commands are continuously output while the JOG command is TRUE).



JOG operation


In JOG operation, the command is output from the motion system to the axis while the positive/reverse rotation JOG command is input by using MCv_Jog (JOG), and then the axis operates to the specified direction.

Point

- JOG operation can be executed even though the homing is not completed.
- JOG operation can be started from outside to inside of the software stroke limit range. (If the JOG operation is started to outside direction of the software stroke limit range, an error will occur.)
- JOG operation can be started from outside to inside of the hardware stroke limit range. (If the JOG operation is started to outside direction of the hardware stroke limit range, an error will occur.)

Ex.

When a reverse rotation JOG operation is executed after a positive rotation JOG operation



Control details

- JOG operation is carried out with MCv_Jog (JOG).
- The target axis is moved to the specified direction during TRUE, by setting Positive rotation JOG command (JogForward) or Reverse rotation JOG command (JogBackward) to TRUE.
- Axis Status (AxisName.Md.AxisStatus) during JOG operation is "6: During continuous operation (ContinuousMotion)".
- A deceleration stop is executed by setting Positive rotation JOG command (JogForward) or Reverse rotation JOG command (JogBackward) to FALSE.
Axis Status (AxisName.Md.AxisStatus) changes to "4: Standby (Standstill)" after the deceleration stop is completed.
- When Error (Error) becomes TRUE during the deceleration by setting Positive rotation JOG command (JogForward) or Reverse rotation JOG command (JogBackward) to FALSE, Error (Error) becomes TRUE until Positive rotation JOG command (JogForward) or Reverse rotation JOG command (JogBackward) is changed TRUE.
- When another operation instruction is started during a JOG operation, the operation is carried out based on the Buffer mode (BufferMode) setting.
- When a JOG operation is started during another operation instruction, the start request will be ignored and "Start during Operation Warning" (warning code: 0D01H) will occur. Start a JOG operation when Axis Status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)".
- Use velocity change by override function to change the velocity during JOG operation. For details on the override function, refer to the following.


➞ Page 392 Override Function

Precautions

- For safety, set a small value in Velocity (Velocity) first and check the movement, and then gradually increase the value.
- Use the hardware stroke limit function when carrying out JOG operation near the upper or lower limits. If the hardware stroke limit function is not used, the workpiece may exceed the moving range and cause an accident.
- When software stroke limit function is valid and Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) is other than DISABLE (Check disabled) or ONLY_INSIDE (Check disabled for movement returning to the range), rewrites Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) into ONLY_INSIDE (Check disabled for movement returning to the range) during MCv_Jog (JOG) execution, and rewrites it into "" during JOG operation completion.
- When hardware stroke limit function is valid and Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) is other than DISABLE (Check disabled) or ONLY_INSIDE (Check disabled for movement returning to the range), rewrites Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) into ONLY_INSIDE (Check disabled for movement returning to the range) during MCv_Jog (JOG) execution, and rewrites it into "" during JOG operation completion.
- Do not change Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) and Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) during MCv_Jog (JOG) execution.
- Note that the value of Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) and Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) are retained to the next instruction during multiple start because the next instruction is analyzed during operation when multiple start is executed during JOG operation.
- When moving to negative direction against at start after deceleration stop during JOG operation, and when the target velocity exceeds the velocity limit value, "Velocity Limit Value Over Warning on Direction Change" (warning code: 0D20H) occurs. Also, when the acceleration time exceeds 8400.0 [s] "Acceleration Time Over Warning on Direction Change" (warning code: 0D32H) occurs. (The operation continues with velocity 0.) The moving starts after changing control to remove the cause.

Ex.

When setting Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) to "2000.0", and Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) to "1000.0"



Necessary object data

When using JOG operation, map the object assigned to the following object data to PDO.

- Target position (607AH)

If the above object is not mapped to PDO, "Necessary Slave Object Unset" (error code: 1AA8H) occurs, and the axis will not start.

For details of slave object settings, refer to the following.

☞ Page 57 Axis Assignment

6.4 Multiple Axes Positioning Control

The details and usages of the multiple axes positioning controls are described in this section.

The multiple axes positioning controls use address information and execute positioning to the specified position using interpolation control.

Relevant variables

Axes group information (AxesGroupName.AxesGroupRef.)

Variable/Structure name	Name	Details
GroupNo	Axes Group No.	Indicates axes group No. <ul style="list-style-type: none">• 0: No setting• 1 to 10000: Set axes group No.

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
Axis[1..16]	Configuration Axis	Sets Axis No. (AxisNo) of Axis Information (<u>AxisName</u> .AxisRef) configuring the axes group.
VelocityLimit	Velocity Limit Value	Specifies the velocity.

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
NumberOfAxes	Number of Configuration Axes	Displays the number of configuration axes of the axes group.
InterpolationAxes	Interpolation Axes	Displays the configuration axis that is executing the interpolation control of the axes group.
SetVelocity	Set Velocity	Displays the set output velocity of the axes group.

Monitor data in multiple axes positioning control

Configuration axes of the axes group that are used for the multiple axes positioning control can be checked in Interpolation Axes (AxesGroupName.Md.InterpolationAxes).

Relevant FBs

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_MoveLinearInterpolateAbsolute	Absolute Value Linear Interpolation Control	Specifies the target position of the absolute position of specified axes group, and executes positioning by linear interpolation control.
MCv_MoveLinearInterpolateRelative	Relative Value Linear Interpolation Control	Specifies the movement amount of the relative position of specified axes group, and executes positioning by linear interpolation control.
MCv_MoveCircularInterpolateAbsolute	Absolute Value Circular Interpolation Control	Executes positioning by 2-axis circular interpolation by using configuration axes of set axes group, and by specifying the end point and the sub point of the absolute position.
MCv_MoveCircularInterpolateRelative	Relative Value Circular Interpolation Control	Executes positioning by 2-axis circular interpolation by using configuration axes of set axes group, and by specifying the relative position from the current position at start to the end point and the sub point.

Types of multiple axes positioning control

- The multiple axes positioning control includes the following types.

Classification of positioning control	Classification of multiple axes	Classification of interpolation	Classification of control
Multiple axes positioning control	Multiple axes interpolation control	Linear interpolation control	Absolute value linear interpolation control
			Relative value linear interpolation control
		Circular interpolation control	Absolute value circular interpolation control
			Relative value circular interpolation control

- The FBs that execute multiple axes positioning control and the multiple axes positioning controls that can be executed are shown below.

Motion FB classification	Description	Motion control FB	Executable multiple axes positioning control
Multiple axes positioning control FB	A motion FB that executes one multiple axes positioning control for one FB instance. The input to the multiple axes position control is set using FB input variables.	MCv_MoveLinearInterpolateAbsolute	Absolute value linear interpolation control
		MCv_MoveLinearInterpolateRelative	Relative value linear interpolation control
		MCv_MoveCircularInterpolateAbsolute	Absolute value circular interpolation control
		MCv_MoveCircularInterpolateRelative	Relative value circular interpolation control
Multiple axes positioning data operation FB*1	A motion FB that continuously executes axes positioning controls within one FB instance. The FB I/O variable has an operation profile ID structure, and inputs to the multiple axes positioning control are set using operation profile.	MCv_MovePositioningData	<ul style="list-style-type: none"> Absolute value linear interpolation control Relative value linear interpolation control Absolute value circular interpolation control Relative value circular interpolation control

*1 For details on multiple axes positioning data operation, refer to the following.

➡ Page 242 Multiple Axes Positioning Data Operation

Operation in multiple axes positioning control

- In the multiple axes positioning control, the positioning control with multiple axes using an axes group can be executed.
- To execute the multiple axes positioning control, axes group settings and enabling are required. For details, refer to the following.
 - ➡ Page 66 Axes Group
 - ➡ Page 73 Axes Group Assignment
- In multiple axes positioning control, specify axes (interpolation axes) to be used for interpolation control in the configuration axis of the axes group. Up to 4 axes can be set.

Positioning speed in multiple axes positioning control

Positioning speed at multiple axes positioning control can be set in Velocity (Velocity) of the Motion control FB. In the multiple axes positioning control, a control target is controlled at the specified positioning speed.

Linear interpolation control

To specify the positioning speed for the linear interpolation control, the following three methods can be used.

- Vector velocity specification
- Long axis velocity specification
- Reference axis velocity specification

The motion system control methods for each set method are described in the following.

■Vector velocity specification


The positioning speed of each interpolation axis is calculated from the movement amount of each interpolation axis by the motion system based on the positioning speed of the set control target.

The positioning speed of the control target is called the vector velocity.

Set each inputs in the Motion control FB: Linear interpolation axes (LinearAxes) as the interpolation axes, Target position (Position) or Movement amount (Distance) as the movement amount of each interpolation axis, and Velocity (Velocity) as the vector velocity.

Ex.

For 2-axis linear interpolation control.



Setting item	Setting value
Linear interpolation axes	Configuration axis 1, Configuration axis 2
Configuration axis 1 movement amount (D ₁)	10000.0 [pulses]
Configuration axis 2 movement amount (D ₂)	15000.0 [pulses]
Velocity unit of axes group	[s]
Vector velocity (V)	7000.0 [pulses/s]

For the above conditions, the positioning speed of each axis is calculated by the motion system with the following calculation formulas.

Setting item	Setting value
Configuration axis 1 positioning speed	$V_1 = V \times D_1 / \sqrt{(D_1^2 + D_2^2)}$
Configuration axis 2 positioning speed	$V_2 = V \times D_2 / \sqrt{(D_1^2 + D_2^2)}$



For the vector velocity specification, the set velocity limit value is valid to the Velocity (Velocity) which is as the vector velocity. For details, refer to the following.

☞ Page 388 Velocity Limit

■Long axis velocity specification

The control is carried out based on the positioning speed (the long axis velocity) of interpolation axes whose movement amount is the largest in the addresses set in each interpolation axis.

The positioning speed of the other interpolation axes is calculated by the motion system from the movement amount of each interpolation axis.

Set each inputs in the Motion control FB: Linear interpolation axes (LinearAxes) as the interpolation axes, Target position (Position) or Movement amount (Distance) as the movement amount of each interpolation axis, and Velocity (Velocity) as the long axis velocity.

Ex.

For 4-axis linear interpolation control.

Setting item	Setting value
Linear	Configuration axis 1, Configuration axis 2, Configuration axis 3, Configuration axis 4
Configuration axis 1 movement amount (D_1)	10000.0 [pulses]
Configuration axis 2 movement amount (D_2)	15000.0 [pulses]
Configuration axis 3 movement amount (D_3)	5000.0 [pulses]
Configuration axis 4 movement amount (D_4)	20000.0 [pulses]
Configuration axis 4 velocity unit	[s]
Long axis velocity (V)	7000.0 [pulses/s]

In the above case, the long axis is the configuration axis 4 whose movement amount is the largest, and the control is carried out by long axis velocity to the configuration axis 4. The positioning speed of the other interpolation axes is calculated by the motion system with the following calculation formulas.

Setting item	Setting value
Configuration axis 1 positioning speed	$V_1 = D_1 / D_4 \times V$
Configuration axis 2 positioning speed	$V_2 = D_2 / D_4 \times V$
Configuration axis 3 positioning speed	$V_3 = D_3 / D_4 \times V$

- For the long axis velocity specification, set velocity limit value is valid for the Velocity (Velocity) which is as the long axis velocity. For details, refer to the following.

Page 388 Velocity Limit

- Note that the vector velocity when specifying the long axis velocity may be larger than the velocity limit value. When setting a value like the following in the 2-axis linear interpolation, the vector velocity exceeds the velocity limit value.


<Example>

When the setting items and the setting values are as follows.

- Linear interpolation axes: Configuration axis 1, Configuration axis 2
- Configuration axis 1 movement amount: 100 [pulses]
- Configuration axis 2 movement amount: 200 [pulses]
- Long axis velocity: 50 [pulses/s]
- Velocity limit value of configuration axis 2: 55 [pulses/s]

In the above case, the reference axis is configuration axis 2 whose movement amount is the largest, and the control is carried out based on the positioning speed specified to the configuration axis 2. The positioning speed and the vector velocity of each axis are shown below.

- Configuration axis 1 positioning speed: $100 / 200 \times 50 = 25$ [pulses/s]
- Configuration axis 2 positioning speed: 50 [pulses/s]
- Vector velocity: $\sqrt{(25^2 + 50^2)} = 55.9$ [pulses/s]



The vector velocity becomes a value that exceeds the velocity limit value 55 of configuration axis 2.

■Reference axis velocity specification

The motion system controls the positioning speed of other interpolation axes calculating from each interpolation axis movement amount based on the positioning speed of the set reference axis (the reference axis velocity), and carries out the control.

In Motion control FB, set Linear interpolation axes (LinearAxes) to the reference axis as a interpolation axes to the first element of the array in Linear interpolation axes (LinearAxes). Also, set Target position (Position) or Movement amount (Distance) as the movement amount of each axis and set the Velocity (Velocity) as the reference axis speed.

- If "0.0" is set to the axis movement amount of configuration axes specified as the reference axis, "Reference Axis Movement Amount 0" (error code: 1AABH) occurs.

Ex.

For 4-axis linear interpolation control.

Setting item	Setting value
Linear interpolation axes	Configuration axis 4, Configuration axis 1, Configuration axis 2, Configuration axis 3
Configuration axis 1 movement amount (D_1)	10000.0 [pulses]
Configuration axis 2 movement amount (D_2)	15000.0 [pulses]
Configuration axis 3 movement amount (D_3)	5000.0 [pulses]
Configuration axis 4 movement amount (D_4)	20000.0 [pulses]
Configuration axis 4 velocity unit	[s]
Reference axis velocity (V)	7000.0 [pulses/s]

In the above case, the reference axis is the configuration axis 4, and control is carried out at the positioning speed specified to the configuration axis 4.

The positioning speed of the other interpolation axes is calculated by the motion system with the following calculation formula.

Setting item	Setting value
Configuration axis 1 positioning speed	$V_1 = D_1 / D_4 \times V$
Configuration axis 2 positioning speed	$V_2 = D_2 / D_4 \times V$
Configuration axis 3 positioning speed	$V_3 = D_3 / D_4 \times V$

- For the reference axis velocity specification, set velocity limit value is valid to the Velocity (Velocity) which is as the reference axis velocity. For details, refer to the following.

☞ Page 388 Velocity Limit

- Note that the positioning speed of the axis whose movement amount is larger than that of the reference axis is larger than the set reference axis velocity. When setting a value like the following in the 2-axis linear interpolation, the positioning speed and the vector velocity of the configuration axis 2 exceed the velocity limit value.


<Example>

When the setting items and the setting values are as follows.

- Linear interpolation axes: Configuration axis 1, Configuration axis 2
- Configuration axis 1 movement amount: 100 [pulses]
- Configuration axis 2 movement amount: 200 [pulses]
- Reference axis velocity: 50 [pulses/s]
- Configuration axis 1 velocity limit value: 55 [pulses/s]

In the above case, the reference axis is the configuration axis 1, and control is carried out with the velocity limit value set to the configuration axis 1. The positioning speed and the vector velocity of each configuration axis are shown below.


- Configuration axis 1 positioning speed: 50 [pulses/s]
- Configuration axis 2 positioning speed: $200 / 100 \times 50 = 100$ [pulses/s]
- Vector velocity: $\sqrt{(50^2 + 100^2)} = 111.8$ [pulses/s]



The positioning speed and the vector velocity of the configuration axis 2 become a value that exceeds the velocity limit value "55" of configuration axis 1.

Circular interpolation control

For the circular interpolation, the control is performed so that the positioning speed on the circular path becomes the specified speed.



Blending of the multiple axes positioning control

The basic operation is based on Blending during multiple axes operation. For details on Blending during multiple axes operation, refer to the following.

📖 Page 139 Multiple start during single axis operation

This section describes operation when selecting BlendingLow, BlendingPrevious, BlendingNext, and BlendingHigh in Buffer mode (BufferMode) of the Motion control FB and setting different speed mode to the Velocity mode (VelocityMode) of the first FB (FB1) and the second FB (FB2) in the multiple axes positioning control.

- It can multiple start even when Velocity mode (VelocityMode) is different between FB1 and FB2. However, during Blending, "Multiple Start Velocity Mode Specified Mismatch Warning" (warning code: 0D11H) occurs.
- The control is carried out using the FB1 Velocity mode (VelocityMode) in FB1 and using the FB2 Velocity mode (VelocityMode) in FB2.
- During Blending of FB1 and FB2, the speed is not converted by the speed mode. The positioning speed value as the FB1 speed mode is used for Blending in the positioning speed as the FB2 speed mode.
- Note that the speed of each axis and the vector velocity may rapidly change when Velocity mode (VelocityMode) of FB1 and FB2 is different during Blending.

■Operation for BlendingPrevious

Blending from the reference axis velocity specification to the vector velocity specification is as shown below.

It operates so that the FB1 reference axis velocity becomes the speed set to Velocity (Velocity) of FB1 (the reference axis velocity) at the FB1 target position. The reference axis velocity when reaching the FB1 target position is read as the current vector velocity value of FB2 without unit conversion, and it accelerates/decelerates the vector velocity set to Velocity (Velocity) of FB2.

Ex.

When FB1 and FB2 are set to the following

- Axis setting, Axes group setting


Setting item	Setting value
Position and velocity command unit of the configuration axis 1	mm/s
Position and velocity command unit of the configuration axis 2	mm/s
Position and velocity command unit of the axes group	mm/s

- FB1 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: mm/s)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[0])	100.0
Target position (Position[1])	100.0
Velocity (Velocity)	1000.0
Velocity mode (VelocityMode)	2: Reference Axis Velocity (ReferenceAxisSpeed)

- FB2 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: mm/s)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[0])	200.0
Target position (Position[1])	200.0
Velocity (Velocity)	200.0
Velocity mode (VelocityMode)	0: Vector Velocity (VectorSpeed)
Buffer mode (BufferMode)	3: BlendingPrevious (mcBlendingPrevious)



- Reaches the target position of FB1 at the reference axis velocity of 1000.0 [mm/s] of the configuration axis 1 that is the reference axis, and switches to FB2.
- FB2 starts operation at the vector velocity of 1000.0 [mm/s].
- Decelerates to the vector velocity of 200.0 [mm/s].
- Performs positioning to the target position of FB2.

■Operation for BlendingNext

FB1: The reference axis velocity → FB2: The vector velocity

It operates so that the FB1 reference axis velocity becomes the speed set to Velocity (Velocity) of FB2 (the vector velocity) at the FB1 target position.

The reference axis velocity when reaching the FB1 target position is read as the current vector velocity value of FB2 without unit conversion, and it accelerates/decelerates the vector velocity set to Velocity (Velocity) of FB2.

Ex.

When FB1 and FB2 are set to the following

- Axis setting, Axes group setting


Setting item	Setting value
Position and velocity command unit of the configuration axis 1	mm/s
Position and velocity command unit of the configuration axis 2	mm/s
Position and velocity command unit of the axes group	mm/s

- FB1 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: mm/s)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[0])	100.0
Target position (Position[1])	100.0
Velocity (Velocity)	1000.0
Velocity mode (VelocityMode)	2: Reference Axis Velocity (ReferenceAxisSpeed)

- FB2 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: mm/s)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[0])	200.0
Target position (Position[1])	200.0
Velocity (Velocity)	200.0
Velocity mode (VelocityMode)	0: Vector Velocity (VectorSpeed)
Buffer mode (BufferMode)	4: BlendingNext (mcBlendingNext)



- Operates to the middle of the positioning to the target position of FB1 at the reference axis velocity 1000.0 [mm/s] of the configuration axis 1.
- The configuration axis 1 as a reference axis reaches the target position of FB1 at the reference axis velocity of 200.0 [mm/s], and switches to FB2.
- FB2 starts operation at the vector velocity 200.0 [mm/s].
- Performs positioning to the target position of FB2.

Command unit in the multiple axes positioning control

Command unit of the multiple axes positioning control

The command unit in the multiple axes positioning control differs depending on Velocity mode (VelocityMode) of the Motion control FB. For details and precautions, refer to the following.

☞ Page 75 Technical Units

☞ Page 139 Multiple start during single axis operation

Blending of the multiple axes positioning control

The basic operation is based on Blending during multiple axes operation. For details on Blending during multiple axes operation, refer to the following.

☞ Page 146 Multiple start during multiple axes operation

This section describes operation when selecting BlendingLow, BlendingPrevious, BlendingNext, and BlendingHigh in Buffer mode (BufferMode) of the Motion control FB, and the command unit is different between the first FB (FB1) and the second FB (FB2) in the multiple axes positioning control.

- It can multiple start even when the command unit is different between FB1 and FB2. However, during Blending, "Velocity Command Unit Mismatch Warning" (warning code: 0D1EH) occurs.
- The control is carried out using the FB1 command unit in FB1 and using the FB2 command unit in FB2.
- During Blending of FB1 and FB2, the speed is not converted by the command unit mode. The positioning speed value as the FB1 command unit is used for Blending in the positioning speed as the FB2 command unit.

■Operation for BlendingPrevious

During Blending, it can multiple start even when the command unit of FB1 and FB2 is different. Unit conversion is not carried out, and the speed value of FB1 is given as the speed of FB2.

Ex.

When FB1 and FB2 are set to the following

- Axis setting


Setting item	Setting value
Position and velocity command unit of the configuration axis 1	mm/s
Position and velocity command unit of the configuration axis 2	mm/s
Position and velocity command unit of the configuration axis 3	degree/min
Position and velocity command unit of the configuration axis 4	degree/min

- FB1 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: mm/s from the command unit of the configuration axis 1)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[0])	100.0
Target position (Position[1])	100.0
Velocity (Velocity)	1000.0
Velocity mode (VelocityMode)	2: Reference Axis Velocity (ReferenceAxisSpeed)

- FB2 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: degree/min from the command unit of the configuration axis 3)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	3
Linear interpolation axes (LinearAxes[1])	4
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[2])	200.0
Target position (Position[3])	200.0
Velocity (Velocity)	200.0
Velocity mode (VelocityMode)	2: Reference Axis Velocity (ReferenceAxisSpeed)
Buffer mode (BufferMode)	3: BlendingPrevious (mcBlendingPrevious)



- Configuration axis 1 as a reference axis reaches the target position of FB1 at the velocity of 1000.0 [mm/s], and switches to FB2.
- Configuration axis 3 as a reference axis starts operation from the current position of FB2 at the velocity of 1000.0 [degree/min].
- Configuration axis 3 as a reference axis decelerates to the velocity of 200.0 [degree/min].
- Performs positioning to the target position of FB2.

■Operation for BlendingNext

During Blending, it can multiple start even when the command unit of FB1 and FB2 is different. Unit conversion is not carried out, and the speed value of FB1 is given as the speed of FB2.

Ex.

When FB1 and FB2 are set to the following

- Axis setting


Setting item	Setting value
Position and velocity command unit of the configuration axis 1	mm/s
Position and velocity command unit of the configuration axis 2	mm/s
Position and velocity command unit of the configuration axis 3	degree/min
Position and velocity command unit of the configuration axis 4	degree/min

- FB1 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: mm/s)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	1
Linear interpolation axes (LinearAxes[1])	2
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[0])	100.0
Target position (Position[1])	100.0
Velocity (Velocity)	1000.0
Buffer mode (VelocityMode)	2: Reference Axis Velocity (ReferenceAxisSpeed)

- FB2 input (MCv_MoveLinearInterpolateAbsolute (Absolute Value Linear Interpolation Control)) (Command unit: degree/min)

Setting item	Setting value
Linear interpolation axes (LinearAxes[0])	3
Linear interpolation axes (LinearAxes[1])	4
Linear interpolation axes (LinearAxes[2])	0
Target position (Position[2])	200.0
Target position (Position[3])	200.0
Velocity (Velocity)	200.0
Velocity mode (VelocityMode)	2: Reference Axis Velocity (ReferenceAxisSpeed)
Buffer mode (VelocityMode)	4: BlendingNext (mcBlendingNext)



- Configuration axis 1 as a reference axis operates to the middle of the target position of FB1 at the velocity of 1000.0 [mm/s].
- Configuration axis 1 as a reference axis reaches the target position of FB1 at the speed of 200.0 [mm/s], and switches to FB2.
- FB2 with a configuration axis 3, as a reference axis, starts operation at the velocity of 200.0 [degree/min].
- Operates positioning to the target position of FB2.

Acceleration/deceleration processing

The basic operation for acceleration/deceleration processing is based on the acceleration/deceleration processing function. For details on each acceleration/deceleration processing function, refer to the following.

 Page 358 Acceleration/deceleration Processing Function

This section describes the operations depending on the Velocity mode (VelocityMode) setting of the Motion control FB. The relationship between the positioning speed and the acceleration/deceleration processing depending on the Velocity mode (VelocityMode) is shown below.

- 0: Vector Velocity (VectorSpeed)

The acceleration/deceleration processing is applied to the vector velocity.

- 1: Long Axis Velocity (LongAxisSpeed)

The acceleration/deceleration processing is applied to the long axis velocity.

- 2: Reference Axis Velocity (ReferenceAxisSpeed)

The acceleration/deceleration processing is applied to the reference axis velocity.

State transition in the multiple axes positioning control

Axes Group Status (AxesGroupName.Md.GroupStatus) of the axes group in the positioning control is "5: Operating (GroupMoving)". For Axes Group Status (AxesGroupName.Md.GroupStatus), refer to the following.

 Page 68 Axes group state transition

Linear interpolation control

Linear interpolation control specifies an axes group and performs interpolation control so that the path from the start point (move start point) to the end point becomes a straight line. In linear interpolation control, interpolation control using a maximum of 4 axes is performed.

Linear interpolation control includes the following two control methods.

For the Motion control FBs that execute each control, refer to the following.

☞ Page 214 Types of multiple axes positioning control

Linear interpolation control	Description
Absolute value linear interpolation control	Specifies the target position of the absolute position, and executes linear interpolation control.
Relative value linear interpolation control	Specifies the relative movement amount from the current position, and executes linear interpolation control.

The following shows examples of interpolation control for each number of interpolation axes.

1-axis linear interpolation control

■1-axis linear interpolation control (absolute value)

1-axis linear interpolation is executed from the current position at start (start point address) to the address set to Target position (Position) (end point address).


Ex.

When start point address of configuration axis 1 is "1000.0" and Target position (Position) is set to "8000.0"

LinearAxes[0]: 1

(LinearAxes[1]: 0)

Position[0]: 8000.0



■1-axis linear interpolation control (relative value)

1-axis linear interpolation is executed by the movement amount set to Movement amount (Distance) from the current position at start (start point address).

The movement direction is determined by a sign (+/-) of the movement amount.

Movement amount	Description
positive (+)	Positioning to the positive direction (address increasing direction)
negative (-)	Positioning to the negative direction (address decreasing direction)


Ex.

When start point address of configuration axis 1 is "-3000.0" and Movement amount (Distance) is set to "-5000.0"

LinearAxes[0]: 1

(LinearAxes[1]: 0)

Distance[0]: -5000.0




2-axis linear interpolation control

■2-axis linear interpolation control (absolute value)

2-axis linear interpolation is executed from the current position at start (start point address) to the address set to Target position (Position) (end point address).

The movement direction is determined by the current position at start point address and the end point address of each axis.



Ex.

When the start point addresses are "configuration axis 1: 1000.0, configuration axis 2: 1000.0" and Target position (Position) settings are "configuration axis 1: 10000.0, configuration axis 2: 4000.0"


LinearAxes[0]: 1

LinearAxes[1]: 2

(LinearAxes[2]: 0)

Position[0]: 10000.0

Position[1]: 4000.0




■2-axis linear interpolation control (relative value)

2-axis linear interpolation is executed by the movement amount set to Movement amount (Distance) from the current position at start (start point address).

The movement direction is determined by a sign (+/-) of the movement amount.

Movement amount	Description
positive (+)	Positioning to the positive direction (address increasing direction)
negative (-)	Positioning to the negative direction (address decreasing direction)



Ex.

When the start point addresses are "configuration axis 1: 1000.0, configuration axis 2: 4000.0" and Movement amount (Distance) settings are "configuration axis 1: 9000.0, configuration axis 2: -3000.0"


LinearAxes[0]: 1

LinearAxes[1]: 2

(LinearAxes[2]: 0)

Distance[0]: 9000.0

Distance[1]: -3000.0




3-axis linear interpolation control

■3-axis linear interpolation control (absolute value)

3-axis linear interpolation is executed from the current position at start (start point address) to the commanded position set to Target position (Position) (end point address).

The movement direction is determined by the current position at start point address and the end point address of each axis.



Ex.

When the start point addresses are "configuration axis 1: 1000.0, configuration axis 2: 2000.0, configuration axis 3: 1000.0" and Target position (Position) settings are "configuration axis 1: 7000.0, configuration axis 2: 8000.0, configuration axis 3: 4000.0"

LinearAxes[0]: 1

LinearAxes[1]: 2


LinearAxes[2]: 3

(LinearAxes[3]: 0)

Position[0]: 7000.0

Position[1]: 8000.0

Position[2]: 4000.0




■3-axis linear interpolation control (relative value)

3-axis linear interpolation is executed by the movement amount set to Movement amount (Distance) from the current position at start (start point address).

The movement direction is determined by a sign (+/-) of the movement amount.


Movement amount	Description
positive (+)	Positioning to the positive direction (address increasing direction)
negative (-)	Positioning to the negative direction (address decreasing direction)



Ex.


When the start point addresses are "configuration axis 1: 2000.0, configuration axis 2: 1000.0, configuration axis 3: 1000.0" and Movement amount (Distance) settings are "configuration axis 1: 10000.0, configuration axis 2: 5000.0, configuration axis 3: 6000.0".

```
LinearAxes[0]: 1
LinearAxes[1]: 2
LinearAxes[2]: 3
(LinearAxes[3]: 0)
Distance[0]: 10000.0
Distance[1]: 5000.0
Distance[2]: 6000.0
```



Timing chart

■When the FB is normally completed



■When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Circular interpolation control

Circular interpolation control specifies an axes group and performs interpolation control so that the path from the start point (move start point) to the end point becomes an arc to a linear axis which is arranged mechanically orthogonally.

In circular interpolation control, interpolation control using arbitrary two axes from the configuration axes set to the axes group.

Circular interpolation control has the following two control methods.

For the Motion control FBs that execute each control, refer to the following.

☞ Page 214 Types of multiple axes positioning control

Circular interpolation control	Description
Absolute value circular interpolation control	Specifies the end point and the sub point of the absolute position, and executes 2-axis circular interpolation control.
Relative value circular interpolation control	Specifies the end point and the movement amount of the sub point from the current point, and executes 2-axis circular interpolation control.

The border point specification, the central point specification, and the radius specification, can be specified with Circular interpolation mode (CircMode) for circular interpolation control.

Circular interpolation method	Description
Border point specification	Positioning control is carried out in an arc path passing through the specified border point by using two configuration axes specified to Circular interpolation mode (CircMode).
Central point specification	Two configuration axes specified in Circular interpolation axes (CircAxes) are used to carry out positioning control in an arc path having the specified center point as a center point.
Radius specification	Two configuration axes specified in Circular interpolation axes (CircAxes) are used to carry out positioning control in an arc path having the specified radius.


The operations of circular interpolation control with each circular interpolation mode are shown below.

Circular interpolation control with border point specification

■Border point specification circular interpolation control (absolute value)


In absolute value circular interpolation control with border point specification, positioning is carried out from the current position at start (start point address) to the address set to End point (EndPoint) (end point address) in an arc path that passes through the address (border point address) set to Sub point (AuxPoint).

The resulting control path is an arc having as its center the intersection point of perpendicular bisectors of a straight line between the current position at start and the border point address, and a straight line between the border point address and the end point address. However, a perfect circle cannot be drawn with the border point specification.




■Border point specification circular interpolation control (relative value)

In relative value circular interpolation control with border point specification, positioning is carried out from the current position at start (start point address) to the address of the movement amount set to End point (EndPoint) in an arc path (end point address) that passes through the address of the movement amount set to Sub point (AuxPoint) (border point address). The resulting control path is an arc having as its center the intersection point of perpendicular bisectors of a straight line between the current position at start and the border point address, and a straight line between the border point address and the end point address.



- When "actual position" is selected in position selection during buffer mode (Options (Options): Bit 3) of relative value circular interpolation control, the border point and the end point are calculated based on the actual position. The center point is determined from the start point (set position), the border point, and the end point.



Restriction

2-axis circular interpolation control cannot be set in the following cases.

- When the radius exceeds "2147483647.0", the maximum radius for which 2-axis circular interpolation control is possible. (Out of Radius Range (error code: 1A6CH))
- When the border point address exceeds positioning range. (Out of Boundary Point Address Range (error code: 1A64H))
- When the end point address exceeds positioning range. (Out of End Point Address Range (error code: 1A6DH))
- When the start point address, border point address, and end point address are in the same straight line. (Start Point - Boundary Point - End Point Address Same Straight Line (error code: 1A6AH))
- When the start point address is the same as the end point address. (Start Point - End Point Address Same Value (error code: 1A66H))
- When the start point address is the same as the border point address. (Start Point - Boundary Point Address Same Value (error code: 1A68H))
- When the end point address is the same as the border point address. (End Point - Boundary Point Address Same Value (error code: 1A69H))


Circular interpolation control with central point specification

■ Central point specification circular interpolation control (absolute value)


In absolute value circular interpolation control operation with center point specification, positioning is carried out from the current position at start (start point address) to the end position set in End point (EndPoint) in an arc path having the center point set in Sub point (AuxPoint) as its center.

For absolute value circular interpolation control with center point specification, the arc path is set using Path selection (PathChoice). For details, refer to the following.

☞ Page 237 Path of central point specification circular interpolation control



- To perform positioning for a perfect circle with a radius from the start point address to the arc center point, set the End point (EndPoint) to the same address as the start point. Setting the end point in End point (EndPoint) to the same value as the start point causes the end point and the start point to be identical.



Ex.

When End point (EndPoint) is set to the same value as the start point

```
AxesGroup001.Pr.Axis[1]:= Axis0001.AxisRef;
```

```
AxesGroup001.Pr.Axis[2]:= Axis0002.AxisRef;
```

```
EndPoint[0]:= Axis0001.Md.SetPosition;
```

```
EndPoint[1]:= Axis0002.Md.SetPosition;
```


Specify the set position of the configuration axes to be used in circular interpolation to End point (EndPoint) as shown above.

■Central point specification circular interpolation control (relative value)


In relative value circular interpolation control operation with center point specification, positioning is carried out from the current position at start (start point address) to the movement amount address set in End point (EndPoint) in an arc path having the movement amount address (center point address) set in Sub point (AuxPoint) as its center.

For relative value circular interpolation control with center point specification, the arc path is set using Path selection (PathChoice). For details, refer to the following.


☞ Page 237 Path of central point specification circular interpolation control



- Setting the movement amount to the end point as "0.0" in End point (EndPoint) causes the end point and the start point to be identical and performs positioning for a perfect circle with a radius from the start point address to the arc center point.



- When "actual position" is selected in position selection during buffer mode (Options (Options): Bit 3) of relative value circular interpolation control, the center point and the end point are calculated based on the actual position. The circular path may be ellipse.



2-axis circular interpolation control with center point specification cannot be set in the following cases.

- When the radius exceeds "2147483647.0", the maximum radius for which 2-axis circular interpolation control is possible. (Out of Radius Range (error code: 1A6CH))
- When the center point address exceeds positioning range. (Out of Center Point Address Range (error code: 1A6BH))
- When the start point address is the same as the center point address. (Start Point - Center Point Address Same Value (error code: 1A65H))
- When the end point address is the same as the center point address. (End Point - Center Point Address Same Value (error code: 1A67H))

■Path of central point specification circular interpolation control

The path in the circular interpolation control with the central point specification can be set by Path selection (PathChoice). The setting value, setting description, arc center angle that can be controlled, and path of Path selection (PathChoice) are shown below.

Setting value	Setting description	Arc center angle that can be controlled	Path
0: CW (mcCW)	CW	$0^\circ < \theta \leq 360^\circ$	
1: CCW (mcCCW)	CCW	$0^\circ < \theta \leq 360^\circ$	
2: Shortcut (mcShortWay)	Shortcut <ul style="list-style-type: none"> • When the start point, center point, and end point are on one straight line, becomes CW. (A semicircle is drawn in the CW direction.) • When the start point is same as the end point, "Path Choice Setting Incorrect" (error code: 1AB7H) occurs. 	$0^\circ < \theta \leq 180^\circ$	
3: Detour (mcLongWay)	Detour <ul style="list-style-type: none"> • When the start point, center point, and end point are on one straight line, becomes CW. (A semicircle is drawn in the CW direction.) • When the start point is same as the end point, becomes CW. (A perfect circle is drawn in CW direction.) 	$180^\circ < \theta \leq 360^\circ$	


■Circular interpolation error tolerance

In central point specification circular interpolation control, the arc path calculated from the start position and center point position may deviate from the end position set in End point (EndPoint).

Circular interpolation error tolerance (CircularErrorTolerance) is set to allowable range of an error between the calculated arc path and the end position.

- Calculated error $\leq$ Circular interpolation error tolerance (CircularErrorTolerance)

Circular interpolation control to the set end point address is carried out while the error compensation is carried out by spiral interpolation.



- Calculated error > Circular interpolation error tolerance (CircularErrorTolerance)

At the positioning start, "Circular Interpolation Error Allowable Value Over" (error code: 1A71H) will occur and the control will not start. The machine will immediately stop if the error is detected during positioning control.

Radius specification circular interpolation control


■Radius specification circular interpolation control (absolute value)

In absolute value circular interpolation control operation with the radius specification, positioning is carried out from the current position at start (start point address) to the address set to End point (EndPoint) (end point address) in an arc path having the radius set in Sub point (AuxPoint). The resulting control path is an arc with the intersection of the perpendicular bisector of the current position at start and the end point address, and the specified radius as the center point.

For absolute value circular interpolation control with radius specification, the arc path is set using Path selection (PathChoice).

For details, refer to the following.

👉 Page 240 Path of radius specification circular interpolation control




■Radius specification circular interpolation control (relative value)


In relative value circular interpolation control operation with radius specification, positioning is carried out from the current position at start (start point address) to the movement amount address (end point address) set in End point (EndPoint) in an arc path having the radius set in Sub point (AuxPoint). The resulting control path is an arc having as its center the intersection point between the perpendicular bisectors of the straight line between the current position at start and the end point address and the set radius.

For relative value circular interpolation control with radius specification, the arc path is set using Path selection (PathChoice). For details, refer to the following.

☞ Page 240 Path of radius specification circular interpolation control



- When "actual position" is selected in position selection during buffer mode (Options (Options): Bit 3) of relative value circular interpolation control, the center point and the end point are calculated based on the actual position. The center point is determined by the start point (set position), radius, and end point.



Restriction

2-axis circular interpolation control with center point specification cannot be set in the following cases.

- When the radius exceeds "2147483647.0", the maximum radius for which 2-axis circular interpolation control is possible. (Out of Radius Range (error code: 1A6CH))
- When the end point address exceeds positioning range. (Out of End Point Address Range (error code: 1A6DH))
- When the start point address is the same as the end point address. (Start Point - End Point Address Same Value (error code: 1A66H))
- When the distance between the start point address and the end point address is larger than the radius. (Radius Setting Error (error code: 1A6EH))


■Path of radius specification circular interpolation control

The path in the circular interpolation control with the radius specification can be set by Path selection (PathChoice). The setting value, setting description, arc center angle that can be controlled, and path of Path selection (PathChoice) are shown below.

Setting value	Setting description	Arc center angle that can be controlled	Path
0: CW (mcCW)	CW (CW shortcut) • When the start point, end point, and center point are on one straight line, "Path Choice Setting Incorrect" (error code: 1AB7H) will occur.	$0^\circ < \theta < 180^\circ$	
1: CCW (mcCCW)	CCW (CCW shortcut) • When the start point, end point, and center point are on one straight line, "Path Choice Setting Incorrect" (error code: 1AB7H) will occur.	$0^\circ < \theta < 180^\circ$	
4: CW Detour (mcCWLongWay)	CW Detour • When the start point, end point, and center point are on one straight line, a semicircle is drawn.	$180^\circ \leq \theta < 360^\circ$	
5: CCW Detour (mcCCWLongWay)	CCW Detour • When the start point, end point, and center point are on one straight line, a semicircle is drawn.	$180^\circ \leq \theta < 360^\circ$	

Timing chart

■When the operation completes normally



■When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Precautions


- Circular interpolation including an axis whose stroke limit is set to invalid cannot be carried out. "Software Stroke Limit Invalid at Circular Interpolation" (error code: 1A72H) will occur, and the operation does not start.
- When the interpolation path exceeds the stroke limit range during interpolation operation, "Software Stroke Limit Over (Forward Direction)" (error code: 1A03H) or "Software Stroke Limit Over (Reverse Direction)" (error code: 1A04H) will occur, and the operation will stop.

Ex.

When the upper limit of the software stroke limit is exceeded in the positive direction of the Y-axis

For an immediate stop, stops at the same time that the error occurs.

For a deceleration stop, decelerates to a stop along the arc of the circle as shown below.



Necessary object data

When using multiple axes positioning control, map the object assigned to the object data to PDO.

- Target position (607AH)

If there is a configuration axis present that does not map the above object data to PDO, "Necessary Object Data Unset" (error code: 1AA8H) occurs and the axis will not start.

For details of object data settings, refer to the following.

📖 Page 57 Axis Assignment

6.5 Multiple Axes Positioning Data Operation

Multiple axes positioning data operation performs positioning for an axes group with a specified positioning method or velocity up to a predetermined pass point in one start. The positioning method and velocity can be changed for each pass point. Interpolation operation is possible for 1 to 4 configuration axes of the axes group.


The following parameters are set in the operation profile (multiple axes positioning data format). For details on operation profile, refer to the following.

☞ Page 523 Multiple axes positioning data

- Commanded position address of the pass point
- Control method from an arbitrary pass point to the next pass point
- Velocity from an arbitrary pass point to the next pass point

Point

By using the multiple axes positioning data operation, a continuous multiple axes positioning operation is possible without writing a user program to multiple start positioning control FBs.




Operation of this function for each system status

○: Possible, ×: Not possible

System status	Operation availability
STOP	×
RUN	○
Moderate error	×
Major error	×

Overall block diagram

The relationship between data used in the multiple axes positioning operation function and other functions is shown below.



*1 For relevancy with the operation profile, refer to the following.

📖 Page 502 Overall block diagram

Relevant variables

MC_POSITIONING_DATA_ID

Variable/Structure name	Name	Details
ProfileID	Profile ID	Sets the operation profile ID. The Profile ID (ProfileID) is a PROFILE_ID structure.

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_MovePositioningData	Multiple Axes Positioning Data Operation	Operates the axes group by following the specified positioning data.

Control details


- This function performs the continuous positioning operation specified in the operation profile (multiple axes positioning data format) for the axes group.
- This function is executed by MCv_MovePositioningData (Multiple Axes Positioning Data Operation)
- Before using this function, it is required to set and enable the axes group. For details, refer to the following.
 - ☞ Page 66 Axes Group
 - ☞ Page 73 Axes Group Assignment
- Before using this function, it is necessary to make the operation profile in the multiple axes positioning data format controllable by opening it in the open area. For the operation profile format and details on operating the operation profile, refer to the following.
 - ☞ Page 502 Operation Profile
- The multiple axes positioning data operation reads the positioning data from the Start positioning data No. (StartDataNo) in ascending order, and continuously executes the multiple axes positioning operation internally. For details, refer to the following.
 - ☞ Page 245 Positioning data setting

Timing chart

The Axes group status (AxesGroupName.Md.GroupStatus) of the axes group in control becomes "5: Operating (GroupMoving)". For axes group statuses, refer to the following.

☞ Page 68 Axes group state transition

■When the operation completes normally



■When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Positioning data setting

This section describes the positioning operation of the multiple axes positioning data operation based on the positioning data settings.

Positioning data is set in the operation profile (multiple axes positioning data format). For details on the operation profile (multiple axes positioning data format), refer to the following.

☞ Page 523 Multiple axes positioning data

Setting positioning data

The positioning data set differs depending on the Control method (ControlMethod). The following table shows the positioning data that can be set.

◎: Always set, ○: Set as required ("—" when not required),

—: Setting not required (Use the initial value or a value within the setting range.)

Variable name	Name	Control method (ControlMethod)					
		Linear interpolation	Circular interpolation	NOP	JUMP	LOOP	LEND
DataNo	Positioning data No.	◎	◎	◎	◎	◎	◎
OperationPattern	Operation pattern	◎	◎	—	—	—	—
ControlMethod	Control method	◎	◎	◎	◎	◎	◎
InterpolationAxis1 to InterpolationAxis4	Interpolation axes 1 to Interpolation axes 4	◎*1	◎*2	—	—	—	—
CircMode	Circular interpolation mode	—	◎	—	—	—	—
CircPathChoice	Path selection	—	◎	—	—	—	—
Position1 to Position4	Target position/movement amount/ end point 1 to Target position/ movement amount/end point 4	◎*1	◎*2	—	—	—	—
Direction1 to Direction4	Direction selection 1 to Direction selection 4	○	—	—	—	—	—
CircAuxPoint1 to CircAuxPoint4	Sub point 1 to Sub point 4	—	◎*2	—	—	—	—
VelocityMode	Velocity mode	○	—	—	—	—	—
Velocity	Velocity	○	○	—	—	—	—
Acceleration	Acceleration	○	○	—	—	—	—
Deceleration	Deceleration	○	○	—	—	—	—
Jerk	Jerk	○	○	—	—	—	—
CircErrorTolerance	Circular interpolation error tolerance	—	○	—	—	—	—
DataOptions	Positioning data options	○	○	—	—	—	—
DwellTime	Dwell time	○	○	—	—	—	—
Mcode	M code	○	○	—	—	—	—
McodeOutput_Override	M code output timing override	○	○	—	—	—	—
JumpDestinationDataNo	JUMP destination positioning data No.	—	—	—	◎	—	—
ConditionSignalNo	Condition signal No.	—	—	—	○	—	—
LoopCount	LOOP to LEND loop count	—	—	—	—	◎	—
SkipSignalNo	Skip signal No.	○	○	—	—	—	—
Pitch	Pitch	—	—	—	—	—	—

*1 The settings are as follows depending on the number of configuration axes set.

◎: Always set, —: Setting not required

Variable name	Name	1 axis	2 axes	3 axes	4 axes
InterpolationAxis1	Interpolation axes 1	◎	◎	◎	◎
InterpolationAxis2	Interpolation axes 2	—	◎	◎	◎
InterpolationAxis3	Interpolation axes 3	—	—	◎	◎
InterpolationAxis4	Interpolation axes 4	—	—	—	◎
Position1	Target position/movement amount/end point 1	◎	◎	◎	◎
Position2	Target position/movement amount/end point 2	—	◎	◎	◎
Position3	Target position/movement amount/end point 3	—	—	◎	◎
Position4	Target position/movement amount/end point 4	—	—	—	◎

*2 Interpolation axes 3 (InterpolationAxis3), Interpolation axes 4 (InterpolationAxis4), Target position/movement amount/end point 3 (Position3), Target position/movement amount/end point 4 (Position4), Sub point 3 (CircAuxPoint3) and Sub point 4 (CircAuxPoint4) do not require setting "—: setting not required".




■Positioning data No. (DataNo)

- The positioning data No. sets the index No. of the positioning data.
- MCv_MovePositioningData (Multiple Axes Positioning Data Operation) executes the positioning data in Positioning data No. (DataNo) order. The positioning data is set with the Positioning data No. (DataNo) in ascending order.
- The multiple axes positioning data operation reads the positioning data from the Start positioning data No. (StartDataNo) in ascending order, and continuously executes the multiple axes interpolation operation internally.
- Sets whether to continue executing the next positioning data or not in the operation pattern. ( Page 247 Operation pattern (OperationPattern))
- The positioning data can be set with the positioning data No. value blank. However, a blank (unset) positioning data No. cannot be used for the multiple axes positioning data operation. If an unset positioning data No. is executed for the multiple axes positioning data operation, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) occurs when the corresponding positioning data is read.
- The setting range is "1 to Total number of positioning data".

■Operation pattern (OperationPattern)

- Set whether to continue executing the positioning data after the set data or not.
- For positioning continue data, the positioning data of the next data No. is automatically executed. In order to complete multiple axes positioning data operation, set the Operation pattern (OperationPattern) of the positioning data of the last operation to "0: Positioning complete (PositioningComplete)".
- Positioning continue data will continue operation until it reaches positioning complete data. Therefore, if there is no positioning complete data, the operation is performed up to the positioning data No. of the total number of positioning data and then the operation is performed again from the No.1 positioning data.
- The types of Operation pattern (OperationPattern) are shown below. The types that can be set differ depending on Control method (ControlMethod).

Positioning continue/complete	Setting value	Description
Complete	0: Positioning complete (PositioningComplete)	<ul style="list-style-type: none"> • Executes positioning of the specified 1 data, and completes the multiple axes positioning data operation when the target position is reached. • When the dwell time is set, control will complete after the set time is passed.
Continue	1: Continuous positioning (ContinuousPositioning)	<ul style="list-style-type: none"> • Automatically executes the positioning of the next positioning data No. • The next positioning will be executed in order after the target position is reached. When the target position is reached the operation will automatically decelerate, and the next positioning will be executed after the set velocity of the axes group becomes zero. • When the dwell time is set, the next positioning will be executed after the set time is passed. • When M code is set, the next positioning will be executed after M code reset. For details, refer to the following.
Continue	2: Continuous path (BlendingLow)(ContinuousBlendingLow)	<ul style="list-style-type: none"> • Automatically executes the positioning of the next positioning data No. • The next positioning will be executed in order after the target position is reached. The operation will not stop between the positioning being executed and the next positioning. • When the dwell time is set, the operation will be the same as continuous positioning. • The switching speed is the lower target velocity of either the positioning being executed or the next positioning. • The operation is the same operation as Continuous path (BlendingPrevious) when the target velocity of the positioning being executed is smaller, and Continuous path (BlendingNext) when the target velocity of the next positioning is smaller.

Positioning continue/ complete	Setting value	Description
Continue	3: Continuous path (BlendingPrevious)(ContinuousBlendingPrevious)	<ul style="list-style-type: none"> Automatically executes the positioning of the next positioning data No. The next positioning will be executed in order after the target position is reached. The operation will not stop between the positioning being executed and the next positioning. When the dwell time is set, the operation will be the same as continuous positioning. This will operate using the target velocity of the positioning being executed until the target position is reached. When the positioning data switches, the velocity will change until the target velocity of the next positioning. 
Continue	4: Continuous path (BlendingNext)(ContinuousBlendingNext)	<ul style="list-style-type: none"> Automatically executes the positioning of the next positioning data No. The next positioning will be executed in order after the target position is reached. The operation will not stop between the positioning being executed and the next positioning. When the dwell time is set, the operation will be the same as continuous positioning. This is operated so that the set velocity becomes the target velocity of the next positioning.  <ul style="list-style-type: none"> Depending on the movement amount of the positioning being executed, the movement amount to change velocity to the target velocity of the next positioning may be insufficient at the target position of the positioning being executed. In this case, velocity change is executed immediately, but the velocity cannot reach the target velocity of the next positioning at the target position of the positioning being executed. 
Continue	5: Continuous path (BlendingHigh)(ContinuousBlendingHigh)	<ul style="list-style-type: none"> Automatically executes the positioning of the next positioning data No. The next positioning will be executed in order after the target position is reached. The operation will not stop between the positioning being executed and the next positioning. When the dwell time is set, the operation will be the same as continuous positioning. The switching speed is the higher target velocity of either the positioning being executed or the next positioning. The operation is the same operation as Continuous path (BlendingPrevious) when the target velocity of the positioning being executed is higher, and Continuous path (BlendingNext) when the target velocity of the next positioning is higher.
Continue	— (no setting)	<p>When the operation pattern setting is not required for the control method (NOP, JUMP, LOOP, and LEND), positioning will continue, but the positioning data No. executed next will differ depending on the control method. For details, refer to the following.</p> <p>☞ Page 249 Control method (ControlMethod)</p>

■Control method (ControlMethod)

- Set the control method of positioning data.
- When the control method of the positioning data specified in the Positioning data No. (DataNo) is other (NOP, JUMP, LOOP, and LEND) when executing the multiple axes positioning data operation, the operation will read in order from the Start Positioning Data No. (StartDataNo) until the positioning data of the positioning operation (linear interpolation, circular interpolation) is read.

The positioning data of the positioning operation read first, will be the first executed positioning operation. For reading after the positioning data No. that executes the first positioning operation, refer to the following.

☞ Page 260 Pre-reading

- The types of control methods are shown below.

Positioning operation	Setting value	Description
Linear interpolation	0101H: Absolute value linear interpolation (LinearAbsolute)	Specifies the target position of the absolute position, and performs a linear interpolation operation so that the path from the start point (move start point) to the end point is linear. For control details of linear interpolation, refer to the following.* ¹ ☞ Page 227 Linear interpolation control
	0102H: Relative value linear interpolation (LinearRelative)	Specifies the relative movement amount from the current position, and performs linear an interpolation operation so that the path from the start point (move start point) to the end point is linear. For control details of linear interpolation, refer to the following.* ¹ ☞ Page 227 Linear interpolation control
Circular interpolation	0103H: Absolute value circular interpolation (CircularAbsolute)	Specifies the absolute position end point and the sub point, and performs 2 axes circular interpolation operation so that the path from the start point (move start point) to the end point forms an arc for 2 linear axes that is arranged orthogonally and mechanically. For control details of circular interpolation, refer to the following.* ¹ ☞ Page 233 Circular interpolation control
	0104H: Relative value circular interpolation (CircularRelative)	Specifies the movement amount of end point and the sub point from the current position, and performs 2 axes circular interpolation so that the path from the start point (move start point) to the end point forms an arc for 2 linear axes that is arranged orthogonally and mechanically. For control details of circular interpolation, refer to the following.* ¹ ☞ Page 233 Circular interpolation control

Positioning operation	Setting value	Description
Other	0080H: NOP(NOP)	Moves to the next positioning data No. without any processing. ■NOP use example When a speed switch or temporary stop (automatic deceleration) may be performed between the positioning of two points, NOP can be used to reserve the data. The positioning operation can then be changed just by changing the control method.
	0082H: JUMP(JUMP)	JUMP positioning data jumps to the specified positioning data No. The types of JUMP are shown below. ■Unconditional JUMP <ul style="list-style-type: none"> • Execution conditions are not set for JUMP. • Jumps to the positioning data No. set in JUMP destination positioning data No. (JumpDestinationDataNo) of the positioning data. • The Condition signal No. (ConditionSignalNo) of the positioning data is set to "0", or the setting is omitted. ■Conditional JUMP <ul style="list-style-type: none"> • Execution conditions are set for JUMP. • The condition signals set in Condition signal No. (ConditionSignalNo) of the positioning data are used as execution conditions. • Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) of the operation profile (multiple axes positioning data format) are used for execution conditions. Set the condition signal to external signal (bit input signal). For the setting details, refer to the following.  Page 270 Condition signal setting • From the condition signals, set the numbers used for each positioning data to Condition signal No. (ConditionSignalNo). For example, when using Condition signal 2 (ConditionSignal2), Condition signal No. (ConditionSignalNo) is set to "2". • If the condition signal set in Condition Signal No. (ConditionSignalNo) is in the signal input status, the execution conditions will be judged as established. If it is not in the signal input status, the execution conditions will be judged as not established. • If the execution conditions are established, the operation jumps to the positioning data No. set in JUMP destination positioning data No. (JumpDestinationDataNo) of the positioning data. If the execution conditions are not established, the next positioning data No. is executed without jumping. • The execution conditions are judged when pre-reading the applicable positioning data whose Control method (ControlMethod) is "0082H: JUMP (JUMP)".
	0083H: LOOP(LOOP)	Loop control by repetition (LOOP to LEND). ^{*2} Repeats the positioning data between the LOOP to LEND loop for the number of times set in Number of LOOP to LEND repetitions (LoopCount).
	0084H: LEND(LEND)	Returns the operation to the top of the repeating loop (LOOP to LEND). ^{*2} The loop ends after executing the number of loops set in Number of LOOP to LEND repetitions (LoopCount). After that, the positioning data of the next positioning data No. is executed. Set as shown below when control is completed after repeating execution by the number of times set in Number of LOOP to LEND repetitions (LoopCount). <ul style="list-style-type: none"> • Set positioning data with an Operation pattern (OperationPattern) that is "1: Continuous Positioning (ContinuousPositioning)" to the positioning data No. before LEND. • Set a dummy positioning data (for example, relative value linear interpolation with movement amount 0) to the positioning data No. after LEND.

*1 Positioning operations (linear interpolation and circular interpolation) have the following differences.

Function	Description
Control change function	There is no control change function by retrigger/continuous update. Use the override function when changing the target velocity or acceleration/deceleration and acceleration/deceleration time. For details on the override function, refer to the following.  Page 269 Override function  Page 392 Override Function
Positioning data continuous execution	There is no multiple start relating to continuous execution of operation data. To perform a continuous execution of operation data, use the Operation pattern (OperationPattern).

*2 The operation of the repeating loop with the set LOOP, LEND is shown below.

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	Number of LOOP to LEND repetitions (LoopCount)	Operation
1	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	<p>The operation is executed in the order of the Positioning data No.1 → 2 → 3 → 4 → 5 → 2 → 3 → 4 → 5 → 6.</p> <p>• Timing chart</p>
2	—	0083H: LOOP(LOOP)	2	
3	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	
4	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	
5	—	0084H: LEND(LEND)	—	
6	0: Positioning complete (PositioningComplete)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	

Precautions

- Set a positioning data No. of positioning data with a setting other than JUMP to JUMP destination positioning data No. (JumpDestinationDataNo). When the jump destination Control method (ControlMethod) is "0083H: JUMP (JUMP)", "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1FAFH) occurs when executing an FB or during control.
- When using conditional JUMP, execution conditions (signal status of the condition signal) are judged when pre-reading the applicable positioning data whose Control method (ControlMethod) is "0082H: JUMP (JUMP)". Establish the execution conditions before the Pre-reading positioning data No. (PrereadingDataNo) passes JUMP. If the conditions are not established before passing JUMP, the execution conditions will be processed as not established.


Ex.

When the following positioning data are set


Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	JUMP destination positioning data No. (JumpDestinationDataNo)	Condition signal No. (ConditionSignalNo)
1	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
2	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
3	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
4	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
5	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
6	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
7	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
8	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
9	—	0082H: JUMP(JUMP)	100	1
10	0: Positioning complete (PositioningComplete)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—
⋮	⋮	⋮	⋮	⋮

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	JUMP destination positioning data No. (JumpDestinationDataNo)	Condition signal No. (ConditionSignalNo)
100	0: Positioning complete (PositioningComplete)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—

■When the condition signal is set to signal input status before the conditional JUMP pre-read



■When the condition signal is set to signal input status after the conditional JUMP pre-read



- An error does not occur if there is no LEND after LOOP, however LOOP control will not be executed.
- Any LEND before LOOP is executed will be ignored.
- When there is positioning complete data between LOOP to LEND, the multiple axes positioning data operation will complete after that positioning data has been executed, and loop control will not be executed.

- Nesting of LOOP to LEND is not possible. If set, loop control for the inner level LOOP to LEND only will be executed.

Ex.

When loop control is executed for the inner level LOOP to LEND only

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	Number of LOOP to LEND repetitions (LoopCount)	Operation
1	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	<ul style="list-style-type: none"> • The operation is executed in the order of the Positioning data No.1 → 2 → 3 → 4 → 5 → 6 → 7 → 4 → 5 → 6 → 7 → 8 → 9. • The settings for positioning data No.2 LOOP and positioning data No.8 LEND are ignored.
2	—	0083H: LOOP (LOOP)	3	
3	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	
4	—	0083H: LOOP (LOOP)	2	
5	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	
6	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	
7	—	0084H: LEND (LEND)	—	
8	—	0084H: LEND (LEND)	—	
9	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	


- When JUMP is set after LOOP, loop control will still be executed if LEND is set after the positioning data No. of the JUMP destination.

Ex.


When LOOP to LEND and JUMP (unconditional JUMP) are used together

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	Positioning data No. (DataNo)	Jump destination positioning data No. (JumpDestinationDataNo)	Operation
1	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—	<ul style="list-style-type: none"> • The operation is executed in the order of the Positioning data No.1 → 2 → 3 → 4 → 101 → 102 → 2 → 3 → 4 → 101 → 102 → 103. • When there is a LOOP or LEND in positioning data No.5 to 100, these settings will be ignored as they are not in the execution order.
2	—	0083H: LOOP (LOOP)	2	—	
3	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—	
4	—	0082H: JUMP (JUMP)	—	101	
:	:	:	:	:	
101	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—	
102	—	0084H: LEND (LEND)	—	—	
103	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	—	

- When switching from positioning data that is multiple axes interpolation data and continuous path data to the next positioning data, the interpolation speed at switching is used as the switching speed. Therefore, a rapid speed change without performing acceleration/deceleration may occur depending on the movement amount and direction of each axis in the next positioning data.



- When switching from continuous path data to positioning complete data or continuous positioning data, the operation may not be able to secure the appropriate distance for deceleration after switching with the switching speed, leading to the target position being overrun. In this case, the automatic deceleration operation will be based on the Operation setting at overrun (AxisGroupName.Pr.OverrunOperation) setting.



Point

When switching to continuous positioning data and decelerating due to an insufficient movement amount, the positioning of the next positioning data No. is executed after the axis stops.

- There is an upper limit to the number of continuous executions for other (NOP, JUMP, LOOP, and LEND) positioning data. Set positioning data so that it does not exceed the number of continuous executions. When the upper limit is exceeded when executing an FB or during control, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) occurs.

Upper limit of the number of continuous executions

100 times

Ex.

When NOP is used for positioning data No.2 to No.102

In the following case, an error can be avoided by setting the Control method (ControlMethod) of No.2 to "0082H: JUMP (JUMP)", and JUMP destination positioning data No. (JumpDestinationDataNo) to "103".

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	JUMP destination positioning data No. (JumpDestinationDataNo)	Operation
1	1: Continuous positioning (ContinuousPositioning)	0101H:Absolute value linear interpolation (LinearAbsolute)	—	<ul style="list-style-type: none"> The upper limit for the number of continuous executions is exceeded with positioning data No.2 → ... → 102, and an error occurred.
2	—	0080H: NOP (NOP)	—	
⋮	⋮	⋮	⋮	
102	—	0080H: NOP (NOP)	—	
103	1: Continuous positioning (ContinuousPositioning)	0101H:Absolute value linear interpolation (LinearAbsolute)	—	

Ex.

When looping a wait operation until the conditions are established using only the conditional JUMP

When performing a wait operation before FB execution, configure a user program that interlocks FB start.

When performing a wait operation with intermediate positioning data, use the M code output function. For details on the M code output function, refer to the following.

☞ Page 279 M code output function

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	JUMP destination positioning data No. (JumpDestinationDataNo)	Operation
1	—	0080H: NOP (NOP)	—	• The upper limit for the number of continuous executions is exceeded by repeating NOP and JUMP as positioning data No.1 → 2 → 1 → ..., and an error occurred.
2	—	0082H: JUMP (JUMP)	1	
3	1: Continuous positioning (ContinuousPositioning)	0101H: Absolute value linear interpolation (LinearAbsolute)	—	

■ Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4)

- Sets the interpolation axes from the configuration axes of the axes group.
- The setting contents differ depending on the Control method (ControlMethod) setting.

Control method (ControlMethod)	Description
0101H: Absolute value linear interpolation (LinearAbsolute)	Set the Linear interpolation axes (LinearAxes) of linear interpolation. For details, refer to the following. ☞ Page 227 Linear interpolation control
0102H: Relative value linear interpolation (LinearRelative)	Note that Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4), should each be interpreted as Linear interpolation axes (LinearAxes[0] to LinearAxes[3]).
0103H: Absolute value circular interpolation (CircularAbsolute)	Set the Circular interpolation axes (CircAxes"0", CircAxes"1") of circular interpolation to Interpolation axes 1 (InterpolationAxis1) and Interpolation axes 2 (InterpolationAxis2). For details, refer to the following. ☞ Page 233 Circular interpolation control
0104H: Relative value circular interpolation (CircularRelative)	Interpolation axes 3 (InterpolationAxis3) and Interpolation axes 4 (InterpolationAxis4) are not used. The settings are ignored.

- The configuration axes specified as interpolation axes can be set differently for each positioning data. A different number of interpolation axes can also be set. However, if the specified configuration axes and number of interpolation axes is different between continuous path data and the next positioning data, note that the speed of each axis can rapidly change when switching positioning data. For details on positioning speed, refer to the following.

☞ Page 263 Positioning speed

☞ Page 215 Positioning speed in multiple axes positioning control

■ Circular interpolation mode (CircMode)

Sets the circular interpolation method (border point specification, center point specification, and radius specification) used to perform circular interpolation control.

For details on Circular interpolation mode (CircMode), refer to the following.

☞ Page 233 Circular interpolation control with border point specification

☞ Page 235 Circular interpolation control with central point specification

☞ Page 238 Radius specification circular interpolation control

■ Path selection (CircPathChoice)

Sets the rotation direction (CW, CCW, Shortcut, Detour, CW Detour, CCW Detour) of the circular interpolation control.

The Path selection (CircPathChoice) that can be set differs depending on Circular interpolation mode (CircMode). For details, refer to the following.

☞ Page 237 Path of central point specification circular interpolation control

☞ Page 240 Path of radius specification circular interpolation control

■Target position/movement amount/end point 1 to target position/movement amount/end point 4 (Position1 to Position4)

The setting contents differ depending on the Control Method (ControlMethod) settings.

Control method (ControlMethod)	Description
0101H: Absolute value linear interpolation (LinearAbsolute)	<ul style="list-style-type: none"> Sets the target position of the absolute position. Target position/movement amount/end point 1 to Target position/movement amount/end point 4 (Position1 to Position4) indicate the target position of the configuration axes set in Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4). Target position/movement amount/end point 1 to target position/movement amount/end point 4 (Position1 to Position4) corresponding to "0" or omitted Interpolation axes 1 to interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4) can be omitted. For setting values, refer to "Target position (Position)" under "MC_MoveAbsolute (Absolute Value Positioning)" in the following manual. MELSEC iQ-R Programming Manual (Motion Control Function Blocks)
0102H: Relative value linear interpolation (LinearRelative)	<ul style="list-style-type: none"> Sets the movement amount from the current position when positioning data is executed. Target position/movement amount/end point 1 to Target position/movement amount/end point 4 (Position1 to Position4) indicate the movement amount of the configuration axes set in Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4). Target position/movement amount/end point 1 to Target position/movement amount/end point 4 (Position1 to Position4) corresponding to "0" or omitted Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4) can be omitted. The setting value is "-10000000000.0 to 10000000000.0".
0103H: Absolute value circular interpolation (CircularAbsolute)	<ul style="list-style-type: none"> Sets the end point position of the absolute position. Target position/movement amount/end point 1 (Position1) and Target position/movement amount/end point 2 (Position2) indicate the target position of the configuration axes set in Interpolation axes 1 (InterpolationAxis1) and Interpolation axes 2 (InterpolationAxis2). Target position/movement amount/end point 3 (Position3) and Target position/movement amount/end point 4 (Position4) can be omitted. (The settings are ignored.) The setting value is "-10000000000.0 ≤ Setting value < 10000000000.0". *: When the ring counter is enabled, it will be the ring counter range.
0104H: Relative value circular interpolation (CircularRelative)	<ul style="list-style-type: none"> Sets the movement amount from the current position to the end point when positioning data is executed. Target position/movement amount/end point 1 (position1) and Target position/movement amount/end point 2 (position2) indicate the movement amount of the configuration axes set in Interpolation axes 1 (InterpolationAxis1) and Interpolation axes 2 (InterpolationAxis2). Target position/movement amount/end point 3 (Position3) and Target position/movement amount/end point 4 (Position4) can be omitted. (The settings are ignored.) The setting value is "-10000000000.0 to 10000000000.0".

■Direction selection 1 to Direction selection 4 (Direction1 to Direction4)

Sets the direction (positive direction, negative direction, and shortest path) used to move using linear interpolation control.

The setting contents differ depending on the Control method (ControlMethod) settings.

Control method (ControlMethod)	Description
0101H: Absolute value linear interpolation (LinearAbsolute)	<ul style="list-style-type: none"> Sets the direction (positive direction, negative direction, shortest path) used to move from the current position to the target position. Direction selection 1 to Direction selection 4 (Direction1 to Direction4) indicate the direction selection of the configuration axes set in Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4). A linear axis with a valid software stroke limit ignores this setting. Direction selection 1 to Direction selection 4 (Direction1 to Direction4) corresponding to "0" or omitted Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4) can be omitted. For details on each direction selection, refer to "Direction selection (Direction)" under "MC_MoveAbsolute (Absolute Value Positioning)" in the following manual. MELSEC iQ-R Programming Manual (Motion Control Function Blocks)
0102H: Relative value linear interpolation (LinearRelative)	<p>Setting is not required. The values are ignored.</p>

■Sub point 1 to sub point 4 (CircAuxPoint1 to CircAuxPoint4)

Sets the position of the sub point (border point, center point, and radius) that executes circular interpolation control.

The setting contents differ depending on the Circular interpolation mode (CircMode) settings.

Circular interpolation mode (CircMode)	Description
0: Border point specification (mcBorder)	<ul style="list-style-type: none">Sub point 1 (CircAuxPoint1) and Sub point 2 (CircAuxPoint2) indicate the border point/center point of the configuration axes set in Interpolation axes 1 (InterpolationAxis1) and Interpolation axes 2 (InterpolationAxis2). It is set with an absolute value or a relative value.Sub point 3 (CircAuxPoint3) and Sub point 4 (CircAuxPoint4) can be omitted. (The settings are ignored.)The setting range depending on the set Control method (ControlMethod) is as follows.<ul style="list-style-type: none">■0103H: Absolute value circular interpolation (CircularAbsolute) -10000000000.0 ≤ Setting value < 10000000000.0*: When ring counter is enabled, this becomes the ring counter range.■0104H: Relative value circular interpolation (CircularRelative) -10000000000.0 to 10000000000.0
1: Center point specification (mcCenter)	
2: Radius specification (mcRadius)	<ul style="list-style-type: none">Sub point 1 (CircAuxPoint1) indicates the radius of the arc.Sub point 2 to Sub point 4 (CircAuxPoint2 to CircAuxPoint4) can be omitted. (The settings are ignored.)The setting range is "0.000001 to 2147483647.0".

■Velocity mode (VelocityMode)

Sets the velocity mode (vector velocity specification, long axis velocity specification, and reference axis velocity specification) of linear interpolation control. For details on the Velocity mode (VelocityMode), refer to the following.

☞ Page 215 Vector velocity specification

☞ Page 216 Long axis velocity specification

☞ Page 218 Reference axis velocity specification

■Velocity (Velocity)

Sets the positioning speed of the multiple axes interpolation. For details, refer to the following.

☞ Page 215 Positioning speed in multiple axes positioning control

The setting range is "0, 0.0001 to 2500000000.0".

■Acceleration (Acceleration)

Sets the acceleration for multiple axes interpolation. The setting contents differ depending on the acceleration/deceleration method setting (bit 0 to 2) of Positioning data options (DataOptions). For details on the acceleration/deceleration method, refer to the following.

☞ Page 358 Acceleration/deceleration Processing Function

■Deceleration (Deceleration)

Sets the deceleration for the multiple axes interpolation. The setting contents differ depending on the acceleration/deceleration method setting (bit 0 to 2) of Positioning data options (DataOptions). For details on the acceleration/deceleration method, refer to the following.

☞ Page 358 Acceleration/deceleration Processing Function

■Jerk (Jerk)

Sets the jerk for the multiple axes positioning control. The setting contents differ depending on the acceleration/deceleration method setting (bit 0 to 2) of Positioning data options (DataOptions). For details on the acceleration/deceleration method, refer to the following.

☞ Page 358 Acceleration/deceleration Processing Function

■Circular interpolation error tolerance (CircErrorTolerance)

Sets the circular interpolation error tolerance when executing circular interpolation control with the center point specification. For details on Circular interpolation error tolerance (CircErrorTolerance), refer to the following.

☞ Page 238 Circular interpolation error tolerance

The setting range is "0.000001 to 100000.0".

■Positioning data options (DataOptions)

Sets the function options for linear interpolation control and circular interpolation control by specifying the bit.



^{*1} Set empty areas to "0". When a value other than "0" is set, "Out of Options Range" (error code: 1A4EH) occurs.

Bit	Name	Description
0 to 2	Acceleration/deceleration method setting	Sets the acceleration/deceleration method for executing control. <ul style="list-style-type: none"> • 0: Acceleration/deceleration specification method (mcAccDec) • 1: Acceleration/deceleration time-fixed method (mcFixedTime) [*] : For details on the acceleration/deceleration method, refer to the following. Page 363 Acceleration/deceleration method
16	Target position specification exceeding the ring counter	Sets to allow or not allow the target position to exceed the ring counter upper limit value and ring counter lower limit value when software stroke limit is disabled. Set when "0101H: Absolute Value Linear Interpolation (LinearAbsolute)" is set in the Control method (ControlMethod). <ul style="list-style-type: none"> • 0: Do not allow • 1: Allow

■Dwell time (DwellTime)

Sets the dwell time.

The setting range is shown below.

- 0.0 [s]: Dwell function disabled
- 0.000001 [s] to 8400.0 [s]: Dwell function enabled

^{*1} When set to a positive number less than 0.000001, it will be read as "0.0 [s]".

■M code (Mcode)

Sets the M code for each positioning data.

- Set "0 (default value)" to not output the M code.
- The setting range is "1 to 65535".

■M code output timing override (McodeOutput_Override)

Sets the M code output timing for each positioning data.

For details on the M code output timing, refer to the following.

[Page 279 M code output function](#)

Setting value	Description
0: Use FB options (UseFbOptions)	Uses the M code output timing (Options (Options): Bit 16) setting value of MCv_MovePositioningData (Multiple Axes Positioning Data Operation).
1: WITH mode (WithMode)	Changes M strobe (Mstrobe) to TRUE when positioning of the positioning data starts, and stores the positioning data M code (Mcode) in Valid M code (ValidMcode).
2: AFTER mode (AfterMode)	Changes M strobe (Mstrobe) to TRUE when the target position is reached (after the setting time has passed when the dwell time has been set), and stores the positioning data M code in M code (Mcode).

■JUMP destination data No. (JumpDestinationDataNo)

Sets the position data No. of the jump destination in JUMP.

Sets the Positioning data No. (DataNo) of a positioning data whose Control method (ControlMethod) is other than "0082H: JUMP (JUMP)".

The setting range is "1 to Total number of positioning data".

■Condition signal No. (ConditionSignalNo)

Sets the Condition signal No.

- Set "0 (default value)" when not using the condition signal.
- The setting range is "1 to 10".

■Number of LOOP to LEND repetitions (LoopCount)

Sets the number of repetitions for loop control.

The setting range is "1 to 65535".

■Skip signal No. (SkipSignalNo)

Set the skip signal No.

Set the following depending on the version of add-on MotionControl_General used.

Add-on MotionControl_General version	Description
"1.33" or later	<ul style="list-style-type: none">• Set the skip signal No.• Set "0" when not using the skip signal.• The setting range is "1 to 10".
"1.31" or earlier	<ul style="list-style-type: none">• Set "0".

■Pitch (Pitch)

Set this to "0".

Pre-reading

- The Motion system imports positioning data by pre-reading the positioning data ahead of the positioning data being executed in MCv_MovePositioningData (Multiple Axes Positioning Data Operation) from the operation profile open area.
- When executing an FB, up to 4 multiple axes interpolation data ahead of the Start positioning data No. (StartDataNo) are pre-read. When positioning continues after the pre-read multiple axes interpolation data, pre-reading continues while the FB is being executed. Pre-reading occurs when switching positioning data so that the number of pre-read multiple axes interpolation data stays at the maximum of 4.
- During FB execution, the last positioning data No. of the pre-read multiple axis interpolation data is stored in the Pre-reading positioning data No. (PrereadingDataNo).

Precautions

- When positioning data with short movement amounts are executed continuously where positioning data switches in several operation cycles, the operation may wait for pre-read to occur in the middle of positioning data execution.
When waiting for pre-read to occur in continuous path data, the set velocity will suddenly change to "0" in one operation cycle when the target position is reached. After that, when pre-read occurs and the positioning data switches to the next positioning data, the set velocity will suddenly change to switching speed in one operation cycle. To avoid the sudden change in velocity due to pre-read waiting, increase the movement amount of each positioning data, or decrease the target velocity.

Near pass


When executing continuous path data, near pass is performed to suppress machine vibration that occurs when switching to the next positioning data.

The near pass carries over the remaining movement amount at the end of positioning to the next positioning. Speed reductions are eliminated by not aligning positions at each positioning operation, which suppresses machine vibrations caused by speed changes.

Since position alignment is not performed for each positioning, the operation is controlled in a path that passes near the target position of the positioning data.

Ex.

For executing 2-axes linear interpolation with continuous path (No.1 operation pattern set to continuous path and continuing to No.2)



Precautions

- When using the multiple axes interpolation operation with continuous path data, if the movement amount of the multiple axes interpolation operation is too small, the set velocity may not reach the target velocity.

Combination with other functions

This section describes when positioning data is executed with the operation pattern of continuous positioning.

■Software stroke limit

The basic operation is based on the specifications of the software stroke limit relevant to operation FBs. For details, refer to the following.

📖 Page 344 Software Stroke Limit

- Returning from outside the software stroke limit range

While the software stroke limit is disabled by Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) of the axes group configuration axes, in addition to when a start, or multiple start occurs, if positioning data is pre-read, "Start when SW Stroke Limit is Disabled" (event code: 07F5) is recorded in the event history.

- Checking the software stroke limit enabled/disabled status

- The software stroke limit enabled/disabled status can be checked with the Software stroke limit override (AxisName.Md.SwStrokeLimit_Override) of each axes group configuration axis.
- In addition to when a start or multiple start occurs, the Software stroke limit override (AxisName.Cd.SwStrokeLimit_Override) of the axes group configuration axis is imported when positioning data is pre-read, and the Software stroke limit override (AxisName.Cd.SwStrokeLimit_Override) is updated. For details of imported values and updated values, refer to the following.

📖 Page 356 Checking the hardware stroke limit enabled/disabled

- Software stroke limit check specifications

For MCv_MovePositioningData (Multiple Axes Positioning Data Operation), an additional check is performed for each positioning data.

Check timing	Check details	Processing when an error occurs
When FB is executing, or during control (When positioning data is pre-read)	An error occurs when the target position of positioning data is outside the software stroke limit range.	"Software Stroke Limit Over (Target Position)" (error code: 1A00H) occurs, and the axis is not controlled.
	An error occurs when the position at positioning data execution is outside the software stroke limit range.	"Software Stroke Limit Over (Start Position)" (error code: 1A01H) occurs, and the axis is not controlled.
During control	An error occurs when the current position is outside the software stroke limit range during control.	"Software Stroke Limit Over (Forward Direction)" (error code: 1A03H) or "Software Stroke Limit Over (Reverse Direction)" (error code: 1A04H) occurs and stop processing is executed.*1

*1 The error occurs when detecting a command to outside the software stroke limit range, and stop processing is executed.
To stop within the software stroke limit range, set to "immediate stop".

■Hardware stroke limit check

The basic operation is based on the specifications of the hardware stroke limit relevant to operation FBs. For details, refer to the following.

📖 Page 351 Hardware Stroke Limit

- Returning from outside the hardware stroke limit range

While the hardware stroke limit is disabled by Hardware stroke limit override (AxisName.Cd.HwStrokeLimit_Override) of the axes group configuration axes, in addition to when a start, or multiple start occurs, if positioning data is pre-read, "Start when HW Stroke Limit is Disabled" (event code: 07F6) is recorded in the event history.

- Checking the hardware stroke limit enabled/disabled status

- The hardware stroke limit check enabled/disabled status can be checked with the Hardware stroke limit override (AxisName.Md.HwStrokeLimit_Override) of each axes group configuration axis.
- In addition to when a start or multiple start occurs, the Hardware stroke limit override (AxisName.Cd.HwStrokeLimit_Override) of the axes group configuration axis is imported when positioning data is pre-read, and the Hardware stroke limit override (AxisName.Cd.SwStrokeLimit_Override) is updated. For details of imported values and updated values, refer to the following.

📖 Page 356 Checking the hardware stroke limit enabled/disabled

■Positioning speed

The basic operation is based on the specifications of the positioning speed when using multiple axes positioning control. For details, refer to the following.

☞ Page 215 Positioning speed in multiple axes positioning control

• Operation when specifying speed 0

- When the Velocity (Velocity) of the first executed positioning data in positioning is set to "0.0", and MCv_MovePositioningData (Multiple Axes Positioning Data Operation) is started, "Out of Velocity Range" (error code: 1A4DH) occurs. When starting positioning with the target velocity as "0.0", and executing speed change during control, use the override function". For details on the override function, refer to the following.

☞ Page 392 Override Function

For details on the override function in multiple axes positioning data operation, refer to the following.

☞ Page 269 Override function

- When the Velocity (Velocity) of the first executed positioning data in positioning is set to "0.0", and MCv_MovePositioningData (Multiple Axes Positioning Data Operation) is multiple started, depending on the set velocity of the previous FB, the following occurs.
 - 0.0: "Out of Velocity Range" (error code: 1A4DH) occurs at multiple start.
 - Other than 0.0: The specified velocity of the previous FB is used.
- When the Velocity (Velocity) of a positioning data in the middle of the operation is set to "0.0", the specified speed of the previous positioning data is used.

• During continuous path

The following describes the operation in the multiple axes positioning data operation when "2: Continuous path (BlendingLow) (ContinuousBlendingLow)", "3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)", "4: Continuous path (BlendingNext) (ContinuousBlendingNext)", or "5: Continuous path (BlendingHigh) (ContinuousBlendingHigh)" is selected in Operation pattern (OperationPattern) of the first positioning data (No.1) and different velocity modes are set to the Velocity mode (VelocityMode) of the first positioning data (No.1) and the second positioning data (No.2).

- Positioning can continue for positioning data (No.1) and positioning data (No.2) when the Velocity mode (VelocityMode) is different for positioning data (No.1) and positioning data (No.2). However, when positioning data (No.2) is pre-read, "Multiple Start Velocity Mode Specified Mismatch Warning" (warning code: 0D11H) occurs.
- Positioning data (No.1) uses the positioning data (No.1) Velocity mode (VelocityMode), and positioning data (No.2) uses positioning data (No.2) Velocity mode (VelocityMode) for the positioning operation.
- When switching between positioning data (No.1) and positioning data (No.2), the velocity is not converted using the Velocity mode (Velocity). The value of the positioning velocity in the velocity mode of the positioning data (No. 1) is switched as it is to the positioning speed in the velocity mode of the positioning data (No.2).
- When Velocity mode (VelocityMode) is different for positioning data (No.1) and positioning data (No.2), note that the speed of each axis and the vector velocity may rapidly change when switching positioning data.

Ex.

When "3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)" is selected

The operation when switching from positioning data with reference axis velocity specification to positioning data with vector velocity specification is as follows.

It operates so that the No.1 axis reference velocity becomes the velocity (reference axis velocity) set in Velocity (Velocity) of No. 1 at the No.1 target position.

The reference axis velocity when reaching the No.1 target position is read as the current vector velocity value of No.2 without unit conversion, and it accelerates/decelerates the vector velocity set in Velocity (Velocity) of No.2.


- Axis setting, axes group setting

Setting item	Setting value
Position and velocity command unit of configuration axis 1	mm/s
Position and velocity command unit of configuration axis 2	mm/s
Position and velocity command unit of the axes group	mm/s

- No.1 (command unit: mm/s), No.2 (command unit: mm/s) settings

Setting item	Setting value	
	No.1*1	No.2*1
Operation pattern (OperationPattern)	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	1: Continuous positioning (ContinuousPositioning)
Control method (ControlMethod)	0101H: Absolute value linear interpolation (LinearAbsolute)	0101H: Absolute value linear interpolation (LinearAbsolute)
Interpolation axes 1 (InterpolationAxis1)	1	1
Interpolation axes 2 (InterpolationAxis2)	2	2
Interpolation axes 3 (InterpolationAxis3)	0	0
Target position/movement amount/end point 1 (Position1)	100	200
Target position/movement amount/end point 2 (Position2)	100	200
Velocity mode (VelocityMode)	2: Reference axis velocity specification (ReferenceAxisSpeed)	0: Vector velocity specification (VectorSpeed)
Velocity (Velocity)	1000	200

*1 The command unit for No.1 and No.2 is "mm/s".



■ Operation example

- (1) The operation reaches the target position of No.1 at the reference axis velocity 1000 [mm/s] of configuration axis 1 (the reference axis), and switches to No.2.
- (2) No.2 starts operation at vector velocity 1000 [mm/s].
- (3) Decelerates until the vector velocity 200 [mm/s].
- (4) Positioning is performed to the target position of No.2.

■Command unit

The basic operation is based on the specifications of the command unit when using multiple axes positioning control. For details, refer to the following.

📖 Page 223 Command unit in the multiple axes positioning control

- Position command unit

When the position command unit of the axes group and the interpolation axes set in positioning data are different, "Position Command Unit Mismatch Warning" (warning code: 0D08H) occurs at start or pre-read.

- Velocity command unit during continuous path

The operation in the multiple axes positioning data operation when "2: Continuous path (BlendingLow) (ContinuousBlendingLow)", "3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)", "4: Continuous path (BlendingNext) (ContinuousBlendingNext)", or "5: Continuous path (BlendingHigh) (ContinuousBlendingHigh)" is selected in Operation pattern (OperationPattern) of the first positioning data (No.1) and different velocity command units are used for the first positioning data (No.1) and the second positioning data (No.2) is as follows.

- Positioning can continue for positioning data (No.1) and positioning data (No.2) when the command unit is different for positioning data (No.1) and positioning data (No.2). However, when positioning data (No.2) is pre-read, "Position Command Unit Mismatch Warning" (warning code: 0D08H) occurs.
- Positioning data (No.1) uses the positioning data (No.1) command unit, and positioning data (No.2) uses positioning data (No.2) command unit for the positioning operation.
- When switching between positioning data (No.1) and positioning data (No.2), the velocity is not converted using the position command mode. The value of the positioning velocity in the command unit of the positioning data (No.1) is switched as it is to the positioning speed in the command unit of the positioning data (No.2).

Ex.

When "3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)" is selected

When the command units of No.1 and No.2 are different, positioning can continue with No.2 when the operation pattern of No.1 is set to continuous path.

The velocity value for No.1 will be taken as the velocity for No.2 without unit conversion.

- Axis setting


Setting item	Setting value
Position and velocity command unit of configuration axis 1	mm/s
Position and velocity command unit of configuration axis 2	mm/s
Position and velocity command unit of configuration axis 3	degree/min
Position and velocity command unit of configuration axis 4	degree/min

- No.1 and No.2 settings

Setting item	Setting value	
	No.1 ^{*1}	No.2 ^{*2}
Operation pattern (OperationPattern)	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	1: Continuous positioning (ContinuousPositioning)
Control method (ControlMethod)	0101H: Absolute value linear interpolation (LinearAbsolute)	0101H: Absolute value linear interpolation (LinearAbsolute)
Interpolation axes 1 (InterpolationAxis1)	1	3
Interpolation axes 2 (InterpolationAxis2)	2	4
Interpolation axes 3 (InterpolationAxis3)	0	0
Target position/movement amount /end point 1 (Position1)	100	200
Target position/movement amount/end point 2 (Position2)	100	200
Velocity mode (VelocityMode)	2: Reference axis velocity specification (ReferenceAxisSpeed)	2: Reference axis velocity specification (ReferenceAxisSpeed)
Velocity (Velocity)	1000	200

*1 The command unit for No.1, and command unit for configuration axis 1 is "mm/s".

*2 The command unit for No.2, and command unit for configuration axis 3 is "degree/min".



■ Operation example

- (1) The operation reaches the target position of No.1 at the reference axis velocity 1000 [mm/s] of configuration axis 1 (the reference axis), and switches to No.2.
- (2) No.2 starts operation at vector velocity 1000 [mm/s].
- (3) Decelerates until the vector velocity 200 [mm/s].
- (4) Positioning is performed to the target position of No.2.

■Acceleration/deceleration processing function

The basic operation is based on the specifications of the acceleration/deceleration processing function. For details, refer to the following.

📖 Page 358 Acceleration/deceleration Processing Function

- Acceleration/deceleration method setting

The acceleration/deceleration method is set in Positioning data options (DataOptions) in positioning data.

Do not use Options (Options) in MCv_MovePositioningData (Multiple Axes Positioning Data Operation).

- Operation when specifying acceleration/deceleration 0

When the acceleration or deceleration of a positioning data in the middle of the operation is set to "0.0", the specified acceleration or specified deceleration of the previous positioning data is used.

- Acceleration limit/deceleration limit

The acceleration limit and deceleration limit are executed for each positioning data. When the target acceleration, or target deceleration of a positioning data in the middle of the operation exceeds the acceleration limit value, or deceleration limit value, "Acceleration Limit Value Over" (error code: 1A38H), or "Deceleration Limit Value Over" (error code: 1A39H) occurs. The timing when the error is output is at the start, or when pre-reading during control.

- Jerk limit

The jerk limit is executed for each positioning data. When the jerk set in a positioning data in the middle of the operation exceeds the jerk limit value, "Jerk Limit Value Over" (error code: 1A3AH) occurs. The timing when the error is output is at the start, or when pre-reading during control.

- Acceleration/deceleration method and operation pattern


■Switching "from jerk acceleration/deceleration to another jerk acceleration/deceleration"

The axis accelerates/decelerates taking over the velocity and the acceleration (deceleration) when switching positioning data. However, when the jerk setting values are different between the positioning data being executed and the next positioning data, the jerk of the next positioning data will be the same as the jerk of the positioning data being executed.

Also, when switching during acceleration (deceleration), the on-going velocity waveform continues in case all settings of the target velocity, the acceleration, the deceleration, and the jerk are the same between the positioning data being executed and the next positioning data. If there is a different setting in any of those, the velocity change is performed to the target velocity of the next positioning data.

Also, when switching the positioning data by the skip function, the acceleration (deceleration) may not be taken over. For details, refer to the following.


📖 Page 274 Skip function



■Switching from other than "jerk acceleration/deceleration to another jerk acceleration/deceleration"

In the following cases, the acceleration (deceleration) is not taken over when switching positioning data.

- Switching from the jerk acceleration/deceleration to the trapezoidal acceleration/deceleration
- Switching from the trapezoidal acceleration/deceleration to another trapezoidal acceleration/deceleration
- Switching from the trapezoidal acceleration/deceleration to the jerk acceleration/deceleration



- Acceleration/deceleration method and multiple start

The specific acceleration/deceleration operation for MCv_MovePositioningData (Multiple Axes Positioning Data Operation) is shown below.

Depending on the version of the add-on MotionControl_General and the setting of options (Options), there are restrictions specific to the Motion control FB.


Add-on MotionControl_General version	Selection when taking over jerk acceleration/deceleration at switching FB in multiple start (Options (Options): Bit 17)	Restriction specific to Motion control FB
"1.33" or later	0: Take over	No
	1: Not take over	Yes
"1.31" or earlier	— (No setting)	

■When restriction specific to Motion control FB is "No"

When a restriction specific to Motion control FB is "No", the operation is according to the acceleration/deceleration function (Page 382 Acceleration/deceleration method and multiple start). (There is no specific acceleration/deceleration operation.)

When switching "from jerk acceleration/deceleration to another jerk acceleration/deceleration" with the same acceleration/deceleration method in the under-control FB and the next FB, the axis takes over the velocity and the acceleration (deceleration) at FB switching.


However, when the jerk setting values are different between the under-control FB and the next FB, the jerk of the next FB will be the same as the jerk of the under-control FB.



■When restriction specific to Motion control FB is "Yes"

When the acceleration/deceleration methods are the same between the under-control FB and the next FB, the acceleration/deceleration operation is as follows.

When MCv_MovePositioningData (Multiple Axes Positioning Data Operation) is included in either the under-control FB or the next FB, acceleration (deceleration) is not taken over at FB switching.



Even when switching from "jerk acceleration/deceleration to another jerk acceleration/deceleration", acceleration/deceleration may change rapidly if Aborting is executed during accelerating/decelerating of the under-control FB.

(Acceleration/deceleration is taken over only when multiple start occurs for the group force stop FB during the control of MCv_MovePositioningData (Multiple Axes Positioning Data Operation)).

To avoid rapid change in acceleration/deceleration, execute Aborting when the under-control FB is at a fixed speed.

Or, review the version of the add-on MotionControl_General and the setting of options (Options) so that the restriction specific to Motion control FB becomes "No".

■Velocity limit

The basic operation is based on the specifications of the velocity limit during interpolation control. For details, refer to the following.

☞ Page 388 Velocity Limit

- The velocity limit is executed for each positioning data. If the target velocity of a positioning data in the middle of the operation is exceeding the velocity limit value, it will be the same operation as at start. The timing when "Velocity Limit Value Over" (error code: 1A07H) is output is at start, or when pre-reading during control.

■Override function


The basic operation is based on the specifications of the override function. For details, refer to the following.

☞ Page 392 Override Function


- Operation at velocity/acceleration/deceleration limit value over by override

The operation when velocity/acceleration/deceleration limit value over occurs at positioning data switching is shown below.

- The next positioning data control change is executed at switching.
- When the control is changed at switching, velocity/acceleration/deceleration limit value over may occur. When velocity/acceleration/deceleration limit value over occurs, the override factor at pre-read is used to control.
- The override factor is also imported when velocity/acceleration/deceleration limit value over occurs at switching. When the limit value is not exceeded at the next control change, the override factor after change will be used for operation.



- Target velocity change during acceleration/deceleration by "4: Continuous path (BlendingNext) (ContinuousBlendingNext)"
The operation when the target velocity has changed during acceleration/deceleration to the target velocity of the next positioning while executing positioning data with the operation pattern set to "4: Continuous path (BlendingNext) (ContinuousBlendingNext)" is shown below.



Condition signal setting

This section describes the setting items of Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) when used in Multiple Axes Positioning Data Operation.

- The condition signal is used for setting the execution conditions for JUMP in the positioning data in which the Control method (ControlMethod) is "0082H: JUMP (JUMP)". For details, refer to the following.

☞ Page 249 Control method (ControlMethod)

- The following shows the setting range and description of each item.

Setting item	Setting range	Description
I/O Number (StartIO)	—	Not used. The setting is ignored.
Target (Target)	<ul style="list-style-type: none"> • ""*1 ■ Data type <ul style="list-style-type: none"> • [OBJ]*2 • [VAR] • [DEV] ■ Type <ul style="list-style-type: none"> • BOOL type data *1: For details on the character string format to be set, refer to the following. ☞ Page 428 TARGET_REF structure 	Set the signal to be used. ■ Setting example [VAR]Axis0001.Md.InVelocity [OBJ](WORD)0x60FD0020.0@192.168.4.1
Signal detection method (Detection)	0: Detection at TRUE (HighLevel) 1: Detection at FALSE (LowLevel)	Set the signal logic.
Compensation time (CompensationTime)	0.0	Set to "0.0".
Filter time (FilterTime)	0.0	Set to "0.0".

*1 When Target (Target) is "" (a character string of length 0), the corresponding condition signal is treated as not set.

*2 When [OBJ] is set as the data type, the target modification cannot be omitted. If the setting is omitted, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) will occur.

- When a value outside the range is set, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) will occur at FB execution.

Skip signal setting

This section describes the setting items of Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10) when used in Multiple Axes Positioning Data Operation.

- The skip signals are set when using the skip function. For details, refer to the following.

 Page 274 Skip function

- The following shows the setting range and description of each item.

Setting item	Setting range	Description
I/O Number (StartIO)	—	Not used. The setting is ignored.
Target (Target)	<ul style="list-style-type: none"> • ""*1 ■ Data type <ul style="list-style-type: none"> • [OBJ]*2 • [VAR] • [DEV] ■ Type <ul style="list-style-type: none"> • BOOL type data *: For details on the character string format to be set, refer to the following.  Page 428 TARGET_REF structure	Set the signal to be used. ■ Setting example [VAR]Axis0001.Md.InVelocity [OBJ](WORD)0x60FD0020.0@192.168.4.1
Signal detection method (Detection)	0: Detection at TRUE (HighLevel) 1: Detection at FALSE (LowLevel)	Set the signal logic.
Compensation time (CompensationTime)	0.0	Set to "0.0".
Filter time (FilterTime)	0.0 to 5.0 [s]	Set the filter time for removing chattering of the input signal in units of seconds.

*1 When Target (Target) is "" (a character string of length 0), the corresponding condition signal is treated as not set.

*2 When [OBJ] is set as the data type, the target modification cannot be omitted. If it is omitted, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) will occur.

- When a value outside the range is set, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) will occur at FB execution.

Point

The skip signal setting can be set when the version of the add-on MotionControl_General is "1.33" or later. If the version of the add-on MotionControl_General is "1.31" or earlier, the skip function cannot be used. In this case, Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10) are not used in multiple axes positioning data operation. The setting is ignored.

Sub functions

Dwell function

The dwell function sets the time to wait until completing positioning data after positioning stops.


When dwell time is set to a value other than "0.0 [s]", the dwell function is enabled.

The dwell time is set to Dwell time (DwellTime) of the positioning data.

The operations depending on the operation pattern are shown below.


■When the operation pattern is positioning complete

When the dwell time has passed after stopping positioning, the positioning data operation is completed.



■When the operation pattern is continuous positioning

When the dwell time has passed after stopping positioning, the operation transitions to the positioning operation of the next positioning data.



■When the operation pattern is continuous path

The operation is the same as when the operation pattern is "continuous positioning".

When not waiting for the dwell time to elapse or executing a continuous path operation, specify "0.0 [s] (disabled)" to the dwell time.

Precautions

- Setting the dwell time with the control cycle interval (the value of the control cycle multiplied by an integer) of the axes group configuration axes is recommended.

When the dwell time is not the control cycle interval, the operation when waiting for the dwell time to pass depending on the dwell time setting value and length of one control cycle is shown in the table below.

Dwell time (DwellTime) setting value	Operation for waiting for dwell time to pass
Shorter than one control cycle	The operation waits for dwell time to pass only for one control cycle.*1
Equal to or longer than one control cycle	The operation waits for dwell time to pass only for a time scaled with the control cycle, and with any fractional parts truncated.

*1 To disable waiting for dwell time to pass, set Dwell time (DwellTime) to "0.0 [s]".

Ex.

For the following cases

Example	Description
1	■When the dwell time is shorter than one control cycle When the control cycle is "0.001 [s] (1.0 [ms])", if Dwell time (DwellTime) is set to "0.0005 (0.5 [ms])", the operation waits for dwell time to pass only for "0.001 (1.0 [ms])".
2	■When the dwell time is exceeds one control cycle When the control cycle is "0.001 [s] (1.0 [ms])", if Dwell time (DwellTime) is set to "0.0025 (2.5 [ms])", the operation waits for dwell time to pass only for "0.002 (2.0 [ms])".

Skip function

By setting a skip signal for each positioning data, the operation of the currently executed positioning data is canceled and the next positioning data is executed.


- The skip function uses Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10) of the operation profile (multiple axes positioning data format). Set an external signal (bit input signal) as the skip signal. For details on the setting, refer to the following.

☞ Page 271 Skip signal setting

- Set the skip signal No. (SkipSignalNo) to the number to be used for each positioning data from among the skip signals.
- When the skip signal No. (SkipSignalNo) of positioning data is set for "0", the skip function is disabled while the relevant positioning data is being executed.
- Skipping is performed when the skip signal set by the skip signal No. (SkipSignalNo) of the currently executed positioning data is input.
- The operations depending on the operation pattern are shown below.

■ When the operation pattern is continuous positioning or continuous path

By the input of a skip signal, the operation of the positioning data is canceled while it is being executed, and the operation is transferred to the next positioning data.




*1 Skip signal No. (SkipSignalNo) "1" of positioning data No.1, Skip signal No. (SkipSignalNo) "0" of positioning data No.2

■ When the operation pattern is positioning complete

By the input of a skip signal, the operation decelerates and stops.

- The acceleration/deceleration method, deceleration, and jerk of deceleration stop take over the value of the skipped positioning data.
- When the command speed reaches 0, the execution of under-control MCv_MovePositioningData (Multiple Axes Positioning Data Operation) is aborted (CommandAborted is TRUE) and the axis group status (AxesGroupName.Md.GroupStatus) is transited to "4: Standby (GroupStandby)".



*1 Skip signal No. (SkipSignalNo) "1" of positioning data No.1

- When skipping, the next positioning data (multiple axes interpolation data) performs positioning with the position at the skip signal input as the starting point. The following is an example of the setting for the positioning position when skipping.

■Setting example

The setting is as follows for an axis group that consists of one axis with the ring counter enabled and the software stroke limit disabled.

- Axis specified by configuration axis 1 (AxisGroupName.Pr.Axis[1])

Setting item	Setting value
Ring counter enabled selection (<u>AxisName.PrConst.RingCount_Enable</u>)	TRUE
Ring counter lower limit value (<u>AxisName.PrConst.RingCount_LowerValue</u>)	0.0
Ring counter upper limit value (<u>AxisName.PrConst.RingCount_UpperValue</u>)	360.0
Software stroke limit target (<u>AxisName.Pr.SwStrokeLimit_Target</u>)	-1: Disabled (Invalid)
Position command unit (<u>AxisName.Pr.Unit_Position</u>)	H00410000 (degree)


Under this condition, if there is a positioning data of absolute position specification after skip, the set position at the rising edge of execution completion (Done) is the same regardless of whether a skip signal is input or not. However, the cumulative current position (movement distance during operation) at the rising edge of execution completion (Done) may differ. Also, depending on whether or not the skip signal is input, the movement direction may change with a positioning data of absolute position specification.

- When all positioning data after skip are data of relative position specifications
 - Positioning data setting


—: Setting not required

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	Interpolation axes 1 (InterpolationAxis1)	Target position/ movement amount/end point 1 (Position1)	Direction selection 1 (Direction1)	Skip signal No. (SkipSignalNo)
1	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0102H: Relative value linear interpolation (LinearRelative)	1	180.0	—	1
2	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0102H: Relative value linear interpolation (LinearRelative)	1	180.0	—	—
3	0: Positioning complete (PositioningComplete)	0102H: Relative value linear interpolation (LinearRelative)	1	270.0	—	—

- Positioning movement
[When not inputting skip signal]



[When inputting skip signal]



■When positioning data immediately after skip is a data of relative position specification


- Positioning data setting

—: Setting not required


Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	Interpolation axes 1 (InterpolationAxis1)	Target position/movement amount/end point 1 (Position1)	Direction selection 1 (Direction1)	Skip signal No. (SkipSignalNo)
1	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0102H: Relative value linear interpolation (LinearRelative)	1	540.0	—	1
2	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0101H: Absolute value linear interpolation (LinearRelative)	1	310.0	3: Shortest path (mcShortestWay)	—
3	0: Positioning complete (PositioningComplete)	0102H: Relative value linear interpolation (LinearRelative)	1	320.0	—	—

- Positioning movement


[When not inputting skip signal]



[When inputting skip signal]



*: When the above setting (direction selection 1 (Direction1) of positioning data No. 2) is "3: Shortest path", by setting the direction selection 1 (Direction1) of positioning data No. 2 to "1: Positive direction (mcPositiveDirection)," positioning is performed in the positive direction with the positioning data No. 2 even when a skip signal is input during the execution of positioning data No. 1.




- When the positioning data immediately after skip is a data of relative position specification followed by a data of absolute position specification
- Positioning data setting


—: Setting not required

Positioning data No. (DataNo)	Operation pattern (OperationPattern)	Control method (ControlMethod)	Interpolation axes 1 (InterpolationAxis1)	Target position/ movement amount/end point 1 (Position1)	Direction selection 1 (Direction1)	Skip signal No. (SkipSignalNo)
1	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0102H: Relative value linear interpolation (LinearRelative)	1	360.0	—	1
2	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0102H: Relative value linear interpolation (LinearRelative)	1	180.0	—	—
3	3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious)	0102H: Relative value linear interpolation (LinearRelative)	1	180.0	—	—
4	0: Positioning complete (PositioningComplete)	0101H: Absolute value linear interpolation (LinearAbsolute)	1	90.0	3: Shortest path (mcShortestWay)	—

- Positioning movement
[When not inputting skip signal]




- [When inputting skip signal]



Precautions

- The skip function is the function to cancel the currently executed positioning data, and does not omit pre-reading and execution even if a skip signal is input to the positioning data before executed. If the skip signal is set to the input status before the execution of positioning data, skip is performed when the positioning data is executed. Therefore, it takes one control cycle from the start of execution to the switching of next positioning data.
- If the positioning data to be executed is skipped continuously within several operation cycles by setting the same skip signal, etc., pre-read waiting may occur. When waiting for pre-reading due to skip, the set velocity rapidly changes to 0 in one operation cycle when the skip signal is input. When the next positioning data is switched after the subsequent pre-read, the set velocity changes rapidly to the switching speed in one operation cycle. To avoid rapid change in velocity caused by waiting for pre-reading, review the positioning data settings so that the skip operation does not occur continuously.
- When the control method (ControlMethod) is set to "0103H: Absolute value circular interpolation (CircularAbsolute)" for the positioning data after the positioning data for which the skip signal is set, set the positioning data of "0101H: Absolute value linear interpolation (LinearAbsolute)" between the data for which the skip signal is set and the data after that. In addition, set the interpolation axis of the positioning data "0101H: Absolute value linear interpolation (LinearAbsolute)" to include the interpolation axis of the positioning data "0103H: Absolute value circular interpolation (CircularAbsolute)". If not set, after the skip signal is input, "Invalid Post-Skip Control Method" (error code: 1AFBH) occurs and the operation stops.

- When the control method (ControlMethod) is set to "0101H: Absolute value linear interpolation (LinearAbsolute)" for the positioning data after the positioning data for which the skip signal is set, set the velocity mode (VelocityMode) to other than "1: Long Axis Velocity (LongAxisSpeed)". If the positioning data for which the control method (ControlMethod) is set to "0101H: Absolute value linear interpolation (LinearAbsolute)" and the velocity mode (VelocityMode) is set to "1: Long Axis Velocity (LongAxisSpeed)" is pre-read when the skip signal is input, "Invalid Post-Skip Control Method" (error code: 1AFBH) occurs, and the operation stops.
- If skip is performed while waiting for the dwell time to elapse, the waiting is ignored and the positioning moves to the next positioning data.
- If skip is performed during M code output (while M strobe (Mstrobe) is TRUE), M strobe (Mstrobe) becomes FALSE and the M code reset does not wait to be executed.
- For the positioning data of which the M code output timing is "AFTER mode", if skip is performed before M code is output, M code is not output and the positioning is moved to the next positioning data. (In this case, M strobe (Mstrobe) does not rise during the execution of the relevant positioning data, and Mcode is not stored in Valid M code (ValidMcode).)
- When switching to the next positioning data by inputting a skip signal, the interpolation velocity at the time of switching is used as the switching velocity. Therefore, depending on the movement amount of each axis and the movement direction in the next positioning data, acceleration/deceleration may not be performed and rapid velocity change may occur.




*1 Skip signal No. (SkipSignalNo) of positioning data No.1 is "1", Skip signal No. (SkipSignalNo) of positioning data No.2 is "0"

- When switching to the positioning complete data or the continuous positioning data by inputting a skip signal, the target position may be overrun because the deceleration distance cannot be secured after the switching at the switching velocity. In this case, automatic deceleration operation is performed according to the setting of Operation Setting at Overrun (`AxesGroupName.Pr.OverrunOperation`).

For "1: Immediate Stop (ImmediateStop)"

The axis starts deceleration immediately, and it stops immediately at reaching the target position after outputting the overrun warning.



*1 Skip signal No. (SkipSignalNo) of positioning data No.1 is "1", Skip signal No. (SkipSignalNo) of positioning data No.2 is "0"

Point

If the data is switched to the continuous positioning data and deceleration due to insufficient movement amount occurs, positioning of the next positioning data No. is executed after the axis is stopped.

- During the deceleration stop of the positioning complete data due to the input of a skip signal, a change made by the override function is not immediately reflected in the currently executed operation. The change is reflected at the timing when another stop factor occurs.
- If skip is performed during acceleration/deceleration of the continuous positioning data, acceleration (deceleration) is not taken over at the time of switching positioning data even in the case of switching to "jerk acceleration/deceleration to jerk acceleration/deceleration".

M code output function

This function is used to command sub functions (such as clamping, drill rotation, and tool replacement) related to the positioning data being executed.

M code can be set to each positioning data. The timing of the M code output (storage) can also be set.

- This function is enabled when a value other than "0" is set to M code.
- M code is set in M code (Mcode) of the positioning data.
- When executing each positioning data of multiple axes positioning data operation, M strobe (Mstrobe) is changed to TRUE at the set output timing, and the M code is stored in Valid M code (ValidMcode).



■M code output timing

- The output timing of M code is set in M code output timing (Options (Options): Bit 16) of MCv_MovePositioningData (Multiple Axes Positioning Data Operation). The output timing of M code for each positioning data can also be set with M code output timing override (McodeOutput_Override) of the positioning data.
- There is "WITH mode" and "AFTER mode" for the output timing of M code.

Output timing	Description
WITH mode	<p>Changes M strobe (Mstrobe) to TRUE when positioning of the positioning data starts, and stores the positioning data M code (Mcode) in Valid M code (ValidMcode).</p> <p>*1: m1 and m2 indicate the M code (Mcode) set to each positioning data No.</p>
AFTER mode	<p>Changes M strobe (Mstrobe) to TRUE when the target position is reached (after the setting time has passed when the dwell time has been set), and stores the positioning data M code in M code (Mcode).</p> <p>*1: m1 and m2 indicate the M code (Mcode) set to each positioning data No.</p>


■ M code reset wait function

- During M code output (while M strobe (Mstrobe) is TRUE), the operation waits to complete positioning data processing until M code reset is executed. While waiting, multiple axes positioning data operation control is continued.
- M code is reset when M code reset (ResetMcode) turns ON. M strobe (Mstrobe) becomes FALSE when M code is reset.
- The following are the operations depending on the operation pattern.

Operation pattern	Description
Positioning complete	The operation does not wait for M code reset. The FB completes even when M strobe (Mstrobe) is TRUE.
Continuous positioning	While M strobe (Mstrobe) is TRUE, the operation waits to transit to the next positioning data.
Continuous path	<p>The operation does not wait for M code reset. The next positioning operation is executed even when M strobe (Mstrobe) is TRUE.</p> <p>■ When M code is set in the next positioning data "Operation Profile Data Control Profile ID Setting Incorrect Warning" (warning code: 0D48H) occurs.</p>  <p>*1: m1, m2, and m3 indicate the M code (Mcode) set to each positioning data No.</p> <p>■ When M code is not set in the next positioning data A warning is not output, but M code outputting continues.</p>  <p>*1: m1 and m2 indicate the M code (Mcode) set to each positioning data No. (The M code (Mcode) of positioning data No.3 is "0 (no setting)")</p>


Precautions

- If M code (Mcode) is set to "0", M code is not output. (M strobe (Mstrobe) does not become TRUE at the M code output timing, and Valid M code (ValidMcode) is not updated.)
- M code is reset when M code reset (ResetMcode) turns ON. M code will not reset when M code reset (ResetMcode) is changed to TRUE in advance, before M strobe (Mstrobe) becomes TRUE. Perform mutual exclusion in the user program to prevent M code reset (ResetMcode) from turning ON while M strobe (Mstrobe) is FALSE.
- For continuous path, if positioning operation time is short, there may not be enough time to reset M code and "Operation Profile Data Control Profile ID Setting Incorrect Warning" (warning code: 0D48H) may occur. In this case, setting "0" to the M code (Mcode) of the positioning data for which the warning occurs allow the warning to be avoided by not outputting M code.
- Valid M code (ValidMcode) and M strobe (Mstrobe) are reset at completion when Execute command (Execute) is FALSE at completion. When Execute command (Execute) is TRUE at completion, they are reset when Execute command (Execute) changes to FALSE.



*1 m1 and m2 indicate the M code (Mcode) set to each positioning data No.

- If an error occurs or execution is canceled while waiting for M code reset, waiting for reset status will be canceled with M strobe (Mstrobe) remaining TRUE.



*2 $m1$ indicates the M code (Mcode) set to each positioning data No.

Step function

This function is used to check positioning operations one by one. Use this function for debugging operations.

The multiple axes positioning data operation with "step function" enabled is called "step operation".

In step operation, the timing for pausing operation can be set. This is called "step mode". (Even during the pause, the multiple axes positioning data operation remains in control.)

- To perform the step operation, set the step mode (StepMode) to "1: Deceleration unit step (StepPerDec)" or "2: Positioning data unit step (StepPerPositioningData)", and execute MCv_MovePositioningData (Multiple Axes Positioning Data Operation).
- For the positioning data that is paused in the step operation, wait for M code reset. Also when the M code output of which M code (Mcode) is set to "0" is disabled in the positioning data, M strobe (Mstrobe) becomes TRUE, and M code reset waits to be executed. (The valid M code (ValidMcode) is not updated.)
- During M code output (while M strobe (Mstrobe) is TRUE), wait for the next step to be continued.


■Step mode

There are two types of "step mode", which are "deceleration unit step" and "positioning data unit step".

In either mode, to cancel the pause and continue the next one step, set M code reset (ResetMcode) to TRUE during M code output. Moreover, as is the case of the normal operation, the multiple axes positioning data operation is completed at the completion of positioning complete data processing.

- 1: Deceleration unit step (StepPerDec)

Pause on the continuous positioning data. Normal operation is performed for the continuous path data and the positioning complete data.




*1 m2 indicates M code (Mcode) set for each positioning data No. (Not updated if M code (Mcode) is "0 (no setting)".)

*2 When the M code output timing of each positioning data No. is "WITH mode"

- 2: Positioning data unit step (StepPerPositioningData)

Automatically decelerates and pauses for each positioning data. Automatically decelerates and pauses forcibly even in the case of continuous path data.




*1 m1 and m2 indicate M code (Mcode) set for each positioning data No. (Not updated if M code (Mcode) is "0 (no setting)".)

*2 When the M code output timing of each positioning data No. is "AFTER mode"

■How to use step operation

The procedure for checking the positioning data using the step operation is shown below.



■Precautions

- The skip function is valid for the step operation as well as for the normal operation. In the positioning data that pauses in the step operation, if skip is performed before the pause, the next one step is continued without pausing. (When M code is being output, M strobe (Mstrobe) becomes FALSE.) If skip is performed during the pause, M strobe (Mstrobe) becomes FALSE, the pause is canceled, and then the next one step is continued.

Precautions

- In MCv_MovePositioningData (Multiple Axes Positioning Data Operation), the time taken for start and multiple start (Aborting) may be extended due to operation profile analysis such as pre-reading and external signal settings.
- When an error is detected during multiple axes positioning data operation control, "MCv_MovePositioningData Instruction Error" (error code: 34B2H) is output together with an error indicating the abnormality details. Detailed information such as the detected positioning data No. is recorded in the event history as the information for "MCv_MovePositioningData Instruction Error" (error code: 34B2H).
- The timing of importing items from the open area of the operation profile (multiple axes positioning data format) differs for each item. The timing for each item is shown below.

—: Not imported

Setting item	Import timing
Profile ID	When FB is executed
Periodic	—
Input absolute coordinate	—
Output absolute coordinate	—
Operation profile format	When FB is executed
Profile data type	When FB is executed
Interpolation method specification	—
Resolution/coordinate number	—
Start point	—
Initial stroke amount	—
Initial velocity	—
Initial acceleration	—
Options	—
Number of positioning data settings	When FB is executed
Total number of positioning data	When FB is executed
Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10)	When FB is executed
Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10)	When FB is executed
Positioning data	When FB is executed or controlled (when pre-reading positioning data)
Length per cycle	—
Length per cycle unit setting	—
Length per cycle unit character string	—
Minimum value per cycle	—
Maximum value per cycle	—
Time per cycle	—
Stroke amount	—
Stroke amount unit setting	—
Stroke amount unit character string	—

Required object data

When using MCv_MovePositioningData (Multiple Axes Positioning Data Operation), map the object assigned to the following object data to the PDO for all of the configuration axes of the specified axes group.

- Target position (607AH)

When there is a configuration axis which does not map the above object to the PDO, "Necessary Object Data Unset" (error code: 1AA8H) occurs and the axis does not start.

For details on object data settings, refer to the following.

 Page 57 Axis Assignment

Relevant add-ons

The following add-ons are required to use this function.

- MotionEngine
- MotionControl_General
- ProfileControl
- SignalIO^{*1}

^{*1} For setting any of Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) of the operation profile (multiple axes positioning data format) and Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10)

Combination of the version

The versions of the engineering tool which are compatible with this function are as follows.

Function	Engineering tool	Version
Multiple Axes Positioning Data Operation (MCv_MovePositioningData) compatible	Motion control setting function	"1.042U" or later
Multiple Axes Positioning Data Operation (MCv_MovePositioningData) conditional JUMP compatible		"1.050C" or later
Multiple Axes Positioning Data Operation (MCv_MovePositioningData) skip function, step function compatible		"1.055H" or later

6.6 Speed to Positioning Move Control

This section describes the operation of speed to positioning move.

The speed to positioning move starts with speed control (including position loop) and switches to positioning control at any timing by an external signal.

The speed to positioning move allows a workpiece being conveyed on conveyors, etc. to stop at a fixed position every time, and press equipment, etc. to stop at a standby location in each cycle.

Specifically, at the timing when the Motion module detects a signal specified by Speed position switching signal (ChangeSignal), it makes an estimated calculation of estimated movement amount after switching to positioning control.

Compared to multiple start of MC_MoveAbsolute (Absolute Value Positioning) and MC_MoveRelative (Relative Value Positioning) while executing MCv_SpeedControl (Speed Control (Including Position Loop)) of Motion control FB, speed to positioning move control enables faster control switching and positioning of higher precision.

Relevant FBs

For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_SpeedToMoveAbsolute	Speed To Absolute Positioning	Executes positioning to a specified target position after switching to positioning control.
MCv_SpeedToMoveRelative	Speed To Relative Positioning	Executes positioning corresponding to a specified movement amount after switching to positioning control.


Speed to absolute positioning

This Motion control FB executes speed control based on a speed set in Velocity (Velocity) with the driver control mode set to csp (cyclic synchronous position mode), and upon detecting the input of Speed position switching signal (ChangeSignal), executes positioning control to an address set to Target position (Position).

MCv_SpeedToMoveAbsolute (Speed To Absolute Positioning) can start only when the ring counter is enabled and the software stroke limit is disabled. When switching to MCv_SpeedToMoveAbsolute (Speed To Absolute Positioning) during axis operation, Direction selection (Direction) needs to be specified to the same direction as an under-control FB.

Timing chart

■When the operation completes normally



■When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Set velocity


In MCv_SpeedToMoveAbsolute (Speed To Absolute Positioning), set Velocity (Velocity), which is a speed during speed control, and End velocity (EndVelocity), which is a speed during positioning control. The first timing for reflecting Velocity (Velocity) and End velocity (EndVelocity) on control is as follows.

- Velocity (Velocity): At the rising edge of Speed controlling (InSpeedControl)
- End velocity (EndVelocity): At the falling edge of Speed controlling (InSpeedControl)

Precautions

- If attempting to start with the ring counter disabled, "Ring Counter Invalid Start" (error code: 1AB5H) occurs to fail in start. When the software stroke limit is enabled, "Start when Software Stroke Limit is Valid" (error code: 1A02H) occurs to fail in start.
- When switching to MCv_SpeedToMoveAbsolute (Speed To Absolute Positioning) during axis operation and specifying the movement direction to one different from the under-control FB, "Overrun Error" (error code: 1A7EH) occurs at switching. Thus, the operation stops according to the setting of Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).
- When a Target position (Position) is reached during deceleration even if automatic deceleration starts from the time of switching to positioning control, the operation stops not immediately but always at a positioning address after N rotations (N: natural number) to ensure automatic deceleration.

In the example below, if deceleration begins along the trajectory (dotted line) immediately after inputting a Speed position switching signal (ChangeSignal), the Target position (Position) will be exceeded twice. Therefore, the operation is controlled so as to stop at the third Target position (Position). The final positioning movement amount is reflected on Positioning movement amount (PositionAmount).



- If the movement amount up to the positioning address recalculated when switching to positioning control exceeds "20000000000.0", "Speed To Positioning Move Target Position Calculation Error" (error code: 1B04H) occurs. Thus, the operation stops according to the setting of Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).
- When switching from velocity control to positioning control during acceleration (deceleration), the following operations will be observed.
 - For trapezoidal acceleration/deceleration: No acceleration (deceleration) is taken over at the time of switching.
 - For jerk acceleration/deceleration: The velocity waveform in execution is continued.


Speed to relative positioning

This Motion control FB executes velocity control based on a speed set in Velocity (Velocity) with the driver control mode set to csp (cyclic synchronous position mode), and upon detecting the input of a Speed position switching signal (ChangeSignal), executes positioning control corresponding to a movement amount set to Movement amount (Distance).

When switching to MCv_SpeedToMoveRelative (Speed To Relative Positioning) during axis operation, specify Movement amount (Distance) to the same direction as an under-control FB.

Timing chart

■When the operation completes normally



■When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)


Set velocity

In MCv_SpeedToMoveRelative (Speed To Relative Positioning), set Velocity (Velocity), which is a speed during speed control, and End velocity (EndVelocity), which is a speed during positioning control. The first timing for reflecting Velocity (Velocity) and End velocity (EndVelocity) on control is as follows.

- Velocity (Velocity): At the rising edge of Speed controlling (InSpeedControl)
- End velocity (EndVelocity): At the falling edge of Speed controlling (InSpeedControl)

Precautions

- When switching to MCv_SpeedToMoveRelative (Speed To Relative Positioning) during axis operation and specifying the movement direction to one different from the under-control FB, "Overrun Error" (error code: 1A7EH) occurs at switching. Then, the operation stops according to the setting of Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).
- Enter a speed position switching signal in the constant velocity section. When setting Position selection at speed position switching signal detection (Options (Options): Bit 18) to "1: Actual position", the positioning movement amount is calculated from Actual Position (AxisName.Md.ActualPosition) when switching to positioning control. Therefore, if the input of the speed position switching signal is detected during acceleration/deceleration and others, the stop position accuracy will decrease due to a large fluctuation range of droop pulse amount.
- When switching from velocity control to positioning control during acceleration (deceleration), the following operations will be observed.
 - For trapezoidal acceleration/deceleration: No acceleration (deceleration) is taken over at the time of switching.
 - For jerk acceleration/deceleration: The velocity waveform in execution is continued.
- When the movement amount of positioning control is smaller than the deceleration distance at an under-control speed, the operation follows Operation Setting at Overrun (AxisName.Pr.OverrunOperation) at the time of detecting the input of a speed position switching signal. The operation proceeds in a similar manner as when overrunning the target position in the buffer mode. For details, refer to the following.
 - ☞ Page 134 Multiple Start (Buffer Mode)
- If any of the following conditions are satisfied, a current position may exceed an estimated stop position when switching to positioning control. If the current position exceeds the estimated stop position, "Speed To Positioning Move Target Position Calculation Error" (error code: 1B04H) occurs, and thus the operation stops according to the setting of Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).
 - When Compensation time (ChangeSignal.Signal.CompensationTime) is set to a positive value (to compensate signal input delay)
 - When using an external signal high-accuracy input as a speed position switching signal
 - When setting Position selection at speed position switching signal detection (Options (Options): Bit 18) to "1: Actual position"



Precautions

Relevant object

Functions subject to errors and restrictions under the following conditions will be shown below.

- No object data set
- No PDO mapping
- No object for the device station

Refer to the following for details of object data setting.

 Page 60 Object data settings

■PDO

⊙: PDO mapping required

Motion control FB/function	Required object data	Mapping availability	Operation when no object is set
MCv_SpeedToMoveAbsolute (Speed To Absolute Positioning)	Target position (607AH)	⊙	"Necessary Object Data Unset" (error code: 1AA8H) will occur.
MCv_SpeedToMoveRelative (Speed To Relative Positioning)			

■SDO

Not applicable

Relevant add-ons

The following add-ons are required to use this function.

- Axis
- MotionEngine
- MotionControl_General
- NetworkDriver_CCIETSN^{*1}
- ServoDriver_CANopen^{*1}
- SignalIO

^{*1} When using the real axis

System memory capacity

■RAM Usage

Memory capacity of MCv_SpeedToMoveRelative (Speed To Relative Positioning) differs depending on Compensation time (ChangeSignal.Signal.CompensationTime). For details, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Backup RAM Usage

Backup RAM is not used.


7 DIRECT CONTROL

Direct control includes velocity control, torque control and pressure control. The operation details of each control is as shown below.

Control Name	Driver control mode	Applicable instruction	Operation details	Reference
Velocity control	Cyclic synchronous position mode (csp)	MCv_SpeedControl (Speed Control (Including Position Loop))	This function outputs the commanded position based on the set velocity for each control cycle.	☞ Page 208 Single Axis Speed Control
	Cyclic synchronous velocity mode (csv)	MC_MoveVelocity (Speed Control)	This function outputs the set velocity for each control cycle. (Excluding the position loop.)	☞ Page 295 Velocity Control
Torque control	Cyclic synchronous torque mode (cst)	MC_TorqueControl (Torque Control)	This function outputs the commanded torque for each control cycle. (Excluding the position loop.)	☞ Page 306 Torque Control
Pressure control	Cyclic synchronous pressure mode (cspr)	MCv_PressureControl (Pressure Control)	This function outputs the set pressure for each control cycle. (Excluding the position loop.)	☞ Page 322 Pressure Control

The drive unit side control mode must be csp at connection.

Switching the drive unit control mode is simultaneously executed when the Motion control FB is executed. The following shows the state transition.



No.	State transition description
(1)	Transits after the axis stops by homing completion or error occurrence.
(2)	Transits at stop completion or error occurrence.
(3)	Transits when Aborting or Buffered is executed to a Motion control FB other than MC_MoveVelocity (Speed Control) and MC_TorqueControl (Torque Control).

Point

Switch to the continuous operation to torque control mode for the usage such as pressing a workpiece. Using the continuous operation to torque control mode can switch the operation smoothly without stopping the operation from the cyclic synchronous position mode or the cyclic synchronous velocity mode to the pressing operation. Therefore, reducing load to a machine and molding high in quality are provided as the velocity and torque do not change abruptly. For details, refer to the following.

☞ Page 760 Continuous operation to torque control mode

7.1 Velocity Control

In velocity control, the drive unit control mode is switched to csv (cyclic synchronous velocity mode), and the control excluding the position loop is executed.

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
SetVelocity	Set Velocity	Stores the velocity calculated from the difference of the set position updated by the follow up.
SetAcceleration	Set Acceleration	Stores a value calculated from the difference of the set velocity.
TargetVelocity	Target Velocity	Stores the actual set velocity whose override and the velocity limit value are considered to Velocity (Velocity).
ActualVelocity	Actual Velocity	Stores the actual velocity (same as positioning control).
Io_TargetVelocity	Object Data_TargetVelocity	Displays the value of object data "Target Velocity (60FFH)".*1 (The velocity command to send to device stations)
Io_VelActualValue	Object Data_VelActualValue	Displays the value of object data "Velocity actual value (606CH)".*1 (Feedback of the velocity which is received from device stations)
InVelocity	Target Velocity Reached	Indicates that Object Data_TargetVelocity (<u>AxisName</u> .Md.Io_TargetVelocity) has reached the target velocity.

*1 For details of object data, refer to the following.

📖 Page 60 Object data settings

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_MoveVelocity	Speed Control	The drive unit control mode is switched to the csv (cyclic synchronous velocity mode), and the velocity control is executed based on the specified velocity.

Control details

MC_MoveVelocity (Speed Control) switches the drive unit control mode to the csv (cyclic synchronous velocity mode) and executes control. This function controls the set velocity based on the specified Acceleration (Acceleration), Deceleration (Deceleration), and Jerk (Jerk). To finish this FB, start MC_Stop (Forced Stop).

Velocity initial value selection

Set the speed initial value when switching control mode from csp (cyclic synchronous position mode) to csv (cyclic synchronous velocity mode) to Velocity initial value selection (Options (Options): Bit 16, 17).

- The csp (cyclic synchronous position mode)→The csv (cyclic synchronous velocity mode)

Setting value	Description
0: Set velocity	The velocity during command (Set Velocity (<u>AxisName</u> .Md.SetVelocity)) is used as the velocity commanded to the drive unit immediately after switching.
1: Actual velocity	Motor speed (Object Data_VelActualValue (<u>AxisName</u> .Md.Io_VelActualValue)) received from the drive unit at switching is used.*1
2: Automatic selection	The lower velocity between "0: Set velocity" and "1: Actual velocity" is used as the velocity commanded to the drive unit immediately after switching.*2

*1 When the object assigned to "Velocity actual value (606CH)" is not mapped to PDO, motor speed received from the drive unit at switching is not used. (Speed initial value selection becomes "0.0".)

*2 When the object assigned to "Velocity actual value (606CH)" is not mapped to PDO, velocity commanded to the drive unit immediately after switching becomes "0: Set velocity".

Operation at stop cause occurrence

The following shows stop causes during the csv (cyclic synchronous velocity mode) and the process when each cause occurs.

Cause No.	Stop cause	Axis Status (<u>AxisName</u> .Md.AxisStatus)		Stop process
		During deceleration stop	After stop	
1	"Forced stop input" is OFF	—	1: Stopping on error (ErrorStop)	Immediate stop ^{*1}
2	Drive unit power supply is OFF	—	1: Stopping on error (ErrorStop)	Immediate stop ^{*1}
	Drive unit network disconnection detection			
	Drive unit			
	Forced stop input to the drive unit			
	Enable (Enable) of MC_Power (Operation Available) is FALSE			
	Servo ON request (ServoON) of MC_Power (Operation Available) is FALSE (When Process Selection at Servo OFF Command During Operation (<u>AxisName</u> .Pr.StopMode_ServoOff) is "4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)") ^{*2}			
3	Hardware stroke limit upper/lower limit error occurrence	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/Immediate stop (Follows Stop Selection at Hardware Stroke Limit Error Occurrence (<u>AxisName</u> .Pr.StopMode_HwStrokeLimit)) After stopping, switch to the csp (cyclic synchronous position mode).
4	CPU module moderate/major error occurrence	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/Immediate stop (Follows Stop Selection at All Axes Stop Cause Occurrence (System.Pr.StopMode_All)) After stopping, switch to the csp (cyclic synchronous position mode).
	PLC READY is OFF			
	Moderate error or major error of the motion system occurs			
	Cycle over error occurrence			
5	Software stroke limit upper/lower limit error occurrence	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/Immediate stop (Follows Stop Selection at Software Stroke Limit Error Occurrence (<u>AxisName</u> .Pr.StopMode_SwStrokeLimit)) After stopping, switch to the csp (cyclic synchronous position mode).
6	Axis error detection ^{*3}	1: Stopping on error (ErrorStop)	1: Stopping on error (ErrorStop)	Deceleration stop/Immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxisName</u> .Pr.StopMode_General)) After stopping, switch to the csp (cyclic synchronous position mode).
7	Execute command (Execute) of MC_Stop (Forced Stop) is TRUE	2: Decelerating to stop (Stopping)	2: Decelerating to stop (Stopping) ^{*4}	Deceleration stop (Follows the deceleration speed set in the FB) After stopping, switch to the csp (cyclic synchronous position mode).
8	"Stop signal (STOP)" of external input signal is TRUE	No change	4: Standby (Standstill)	Deceleration stop/Immediate stop (Follows Stop Selection at Stop Cause Occurrence (<u>AxisName</u> .Pr.StopMode_General)) After stopping, switch to the csp (cyclic synchronous position mode).

^{*1} The servo turns OFF on the drive unit side and immediate stop is performed, and also the motion system side command is stopped.

^{*2} Operation differs depending on the setting value selected in Process Selection at Servo OFF Command During Operation (AxisName.Pr.StopMode_ServoOff). For details, refer to the following.

☞ Page 164 Relevant variables

^{*3} If an axis error (the error that transits the state into the "1: Stopping on error (ErrorStop)" status) occurs in the buffering FB, immediate stop will be performed from the error occurrence.


^{*4} When Execute command (Execute) of MC_Stop (Forced Stop) is FALSE at stop completion, Axis Status (AxisName.Md.AxisStatus) after stop will be "4: Standby (Standstill)".

Buffer mode (BufferMode)

When starting this FB during another instruction execution


■Single axis position control (FB1) → Velocity control (FB2)

- 0: Aborting (mcAborting)
1. Input variables are analyzed, and a control mode switching request for switching to csv (cyclic synchronous velocity) is issued to the drive unit.
 2. Until the drive unit is switched, the axis is operated at the previous velocity with the velocity control including the position loop.
 3. When the drive unit switches to csv (cyclic synchronous velocity), Target Velocity (TargetVelocity) is obtained based on the actual velocity and the acceleration/deceleration processing is started again.



- 1: Buffered (mcBuffered)

1. Input variables are analyzed, and the axis waits until the previous instruction is completed.
2. When the previous instruction is completed, a control mode switching request for switching to csv (cyclic synchronous velocity) is issued to the drive unit.
3. When the drive unit switches to csv (cyclic synchronous velocity), the acceleration/deceleration processing is started based on the settings of FB2.



When starting another instruction during this FB execution

While this FB is executed, only Aborting and Buffered are supported.


■Velocity control → Operation at positioning start

1. A control mode switching request for switching to csp (cyclic synchronous position mode) is issued to the drive unit.
2. Started positioning control FB is analyzed, and the axis waits until the drive unit control mode switches to csp (cyclic synchronous position mode). (Even if the axis issues the control mode switching request for switching to csp (cyclic synchronous position mode) during operation, switching may not be carried out depending on the drive unit specifications. If switching to csp (cyclic synchronous position mode) is not completed within 1 [s], "Control Mode Switching Error" (error code: 1A1DH) occurs for the timeout, and the axis stops.)
3. While waiting, velocity control is continued with the set velocity when Execute command (Execute) of FB2 is TRUE.
4. When the drive unit switches to csp (cyclic synchronous position mode), the positioning control starts.


Point

- The deceleration distance may not be secured and the target position may be overrun depending on the travel distance till switching from the csv (cyclic synchronous velocity mode) to the csp (cyclic synchronous position mode). In this case, the axis operates based on Operation Setting at Overrun (AxisName.Pr.OverrunOperation). For operation at the overrun occurrence, refer to the following.
 Page 134 Multiple Start (Buffer Mode)
- At the overrun occurrence while waiting for switching, regardless of Operation Setting at Overrun (AxisName.Pr.OverrunOperation), "Overrun Error" (error code: 1A7EH) will occur immediately after switching to csp (cyclic synchronous position mode) and immediately stop the operation.


- 0: Aborting (mcAborting)



- 1: Buffered (mcBuffered)




■Velocity control → Stop instruction (MC_Stop (Forced Stop))




■ Velocity control → Torque control

1. Control mode switching request for switching to the cst (cyclic synchronous torque mode) is executed to the drive unit.
2. Started torque control is analyzed, and the axis waits until the drive unit switches to the cst (cyclic synchronous torque mode).

- 0: Aborting (mcAborting)



- 1: Buffered (mcBuffered)



When the operation direction is reversed

When starting this FB and operation direction is reversed during another instruction execution, a deceleration stop is performed once.

After the deceleration stop is completed, operation is started to the changed direction.

Precautions

- Velocity Override Factor (AxisName.Cd.VelocityOverride) and Acceleration Override Factor (AxisName.Cd.AccelerationOverride) are valid.
- The set position and the machine feed value are updated by follow up.
- Switching time to the control mode depends on the specifications of the drive unit.
- When the stop cause occurs during the control mode switching, the axis will stop immediately.
- Do not start the positioning control FB during the control mode switching. Start the positioning control FB after confirming that Driver Control Mode (AxisName.Md.Driver_Mode) is switched to "9: Cyclic synchronous velocity mode(csv)".
- On the occasion that the control mode switches from the csp (cyclic synchronous position mode) to the csv (cyclic synchronous velocity mode), if the stop cause (axis error detection) occurs before control mode switching, the follow up may be executed, with the control mode left in the csp (cyclic synchronous position mode), until achieving the zero speed status.
- When switching from the csp (cyclic synchronous position mode) to the csv (cyclic synchronous velocity mode) or from the csv (cyclic synchronous velocity mode) to the csp (cyclic synchronous position mode) without waiting for stop of the motor by using the MR-J5(W)-G, note the following.
 - Set "ZSP disabled selection at control switching (PC76.1)" of the servo parameter (extension setting) to "1: Disabled" and disable monitoring of zero speed status. However, note that it may cause vibration or impact at control mode switching.
 - For the setting value of the servo parameter "Electronic gear numerator (PA06)" and "Electronic gear denominator (PA07)", refer to the following.
 - ☞ Page 725 Setting methods

Relevant object

Functions subject to errors and restrictions under the following conditions will be shown below.

- No object data set
- No PDO mapping
- No object for the device station

Refer to the following for details of object data setting.

☞ Page 60 Object data settings

■PDO

◎: PDO mapping required, ○: PDO mapping recommended

Motion control FB/ function	Required object data	Object necessary or not	Operation when no object is set
MC_MoveVelocity (Speed Control)	Target velocity (60FFH)	◎	"Necessary Object Data Unset" (error code: 1AA8H) will occur.
	Velocity actual value (606CH)	○	Refer to the following. ☞ Page 295 Velocity initial value selection

■SDO

Not applicable

7.2 Torque Control

In torque control, the drive unit control mode is switched to cst (cyclic synchronous torque mode) and the control is carried out.

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	details
SetVelocity	Set Velocity	Stores the velocity calculated from the difference of the set position updated by the follow up.
SetAcceleration	Set Acceleration	Stores a value calculated from the difference of the set velocity.
TargetVelocity	Target Velocity	<ul style="list-style-type: none">• Stores actual limit velocity in consideration of override for the limit velocity (LimitVelocity), which is "0" or more regardless of movement directions.• Stores "0" upon control completion.
ActualVelocity	Actual Velocity	Stores the actual velocity (same as positioning control).
Cst_SetTorque	Set Torque at cst/ct	Stores set torque at the cyclic synchronous torque mode (cst)/continuous operation to torque control mode (ct). (Unit: %)
Cst_TargetTorque	Target Torque at cst/ct	Stores target torque at the cyclic synchronous torque mode (cst)/continuous operation to torque control mode (ct). (Unit: %)
Cst_SetLimitVelocity	Set Limit Velocity at cst/ct/cspr	Stores set limit velocity at the cyclic synchronous torque mode (cst)/continuous operation to torque control mode (ct)/cyclic synchronous pressure mode (cspr).
Io_TorqueActualValue	Object Data_TorqueActualValue	Displays the value of object data "Torque actual value (6077H)".*1 (The actual torque which is received from device stations)
Io_VelActualValue	Object Data_VelActualValue	Displays the value of object data "Velocity actual value (606CH)".*1 (Feedback of the velocity which is received from device stations)
InVelocity	Target Velocity Reached	Stores FALSE (Not reached) at the cyclic synchronous torque mode (cst)/continuous operation to torque control mode (ct).

*1 For the details on object data, refer to the following.

 Page 62 Object data list

Relevant FB

For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_TorqueControl	Torque Control	The drive unit control mode is switched to the cst (cyclic synchronous torque mode), and the torque control is executed based on the specified target torque.

Control details

MC_TorqueControl (Torque Control) switches the drive unit control mode to the cst (cyclic synchronous torque mode) and executes control. This function controls the set torque based on the specified Torque positive direction ramp (TorquePositiveRamp) and Torque negative ramp (TorqueNegativeRamp). To finish this FB, start MC_Stop (Forced Stop).

Relation between torque generation direction of servo motor and set torque

When using the MR-J5(W)-G, it differs based on the settings of the servo parameter "Movement direction selection (PA14)" and "Torque POL reflection selection (PC29.3)".


- When the servo parameter (extension setting) "Torque POL reflection selection (PC29.3)" is set to "0: Enabled"

Setting value of "Travel direction selection (PA14)"	Set torque	Torque generation direction of servo motor
0: Positioning address increasing CCW rotation	Positive value (positive direction)	CCW direction*1
	Negative value (negative direction)	CW direction*1
1: Positioning address increasing CW rotation	Positive value (positive direction)	CW direction*1
	Negative value (negative direction)	CCW direction*1

- When the servo parameter (extension setting) "Torque POL reflection selection (PC29.3)" is set to "1: Disabled" (Initial value)

Setting value of "Travel direction selection (PA14)"	Set torque	Torque generation direction of servo motor
0: Positioning address increasing CCW rotation	Positive value (positive direction)	CCW direction*1
	Negative value (negative direction)	CW direction*1
1: Positioning address increasing CW rotation	Positive value (positive direction)	CCW direction*1
	Negative value (negative direction)	CW direction*1

*1 For details, refer to the following illustration.



Torque ramp function selection (Options (Options): Bit 16, 17)


Set the method from set torque until the target torque is reached.

Torque positive direction ramp (TorquePositiveRamp) and Torque negative ramp (TorqueNegativeRamp) differs depending on the setting values.

■For "0: Ramp method"

Specify the ramp from the current set torque until the target torque is reached.

Setting range
0.0 to 1000.0 [%/s]




■For "1: Time constant method"

Set Torque positive direction ramp (TorquePositiveRamp) to the time until set torque reaches the positive torque limit value from 0.

Set Torque negative ramp (TorqueNegativeRamp) to the time until set torque reaches 0 from the negative torque limit value.


Setting range
0.0 to 8400.0 [s]



■For "2: Fixed time method"

Set the time from the current set torque until the target torque is reached.

Setting range
0.0 to 8400.0 [s]



When the output torque direction is changed due to the target torque change, the set torque becomes 0 based on the setting value of the torque negative direction ramp. After that, it becomes the target torque based on the setting value of the torque positive direction.

When the torque positive direction ramp and the torque negative direction ramp are specified to 0.0, the value reaches the target torque in 1 operation cycle.

Torque initial value selection (Options (Options): Bit 18)

Set the torque initial value when switching to the cst (cyclic synchronous torque mode) or at multiple start.

Setting value	Description
0: Target torque	Target torque (Torque) value is set as the set torque .
1: Actual torque	Torque actual value is set as the set torque.* ¹

*¹ If the object assigned to the object data "Torque actual value (6077H)" is not mapped to PDO, the torque initial value is "Target torque" regardless of the setting of Torque initial value selection.

Point

Normally, set "0: Target torque" to this bit. Set "1: Actual torque" only when switching the control mode immediately after the command to the motor is completed without waiting for the servo motor to stop.

Operation at stop cause occurrence

The following shows stop causes during the cst (cyclic synchronous torque mode) and the process when each cause occurs.

Cause No.	Stop cause	Axis Status (<u>AxisName</u> .Md.AxisStatus)	Stop process
		After stop	
1	"Forced stop input" is OFF	1: Stopping on error (ErrorStop)	Immediate stop ^{*1}
2	Drive unit power supply is OFF	1: Stopping on error (ErrorStop)	Immediate stop ^{*1}
	Drive unit network disconnection detection		
	Drive unit		
	Forced stop input to the drive unit		
	Enable (Enable) of MC_Power (Operation Available) is FALSE		
	Servo ON request (ServoON) of MC_Power (Operation Available) is FALSE (When Process Selection at Servo OFF Command During Operation (<u>AxisName</u> .Pr.StopMode_ServoOff) is "4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)", "5: Servo OFF After Deceleration to Stop (ServoOffAfterDecelStop)") ^{*2}		
3	Hardware stroke limit upper/lower limit error occurrence	1: Stopping on error (ErrorStop)	The limit velocity is changed to 0, and an immediate stop is performed. ^{*5}
4	CPU module moderate/major error occurrence	1: Stopping on error (ErrorStop)	After the stop, the control mode is changed to csp (cyclic synchronous position mode).
	PLC READY is OFF		
	Moderate error or major error of the motion system occurs		
	Cycle over error occurrence		
5	Software stroke limit upper/lower limit error occurrence	1: Stopping on error (ErrorStop)	
6	Axis error detection ^{*3}	1: Stopping on error (ErrorStop)	
7	Execute command (Execute) of MC_Stop (Forced Stop) is TRUE	2: Decelerating to stop (Stopping) ^{*4}	The limit velocity is changed to 0, and an immediate stop is performed. ^{*5} After the stop, the control mode is changed to csp (cyclic synchronous position mode). (Not based on the deceleration of MC_Stop (Forced Stop))
8	"Stop signal (STOP)" of external input signal is TRUE	4: Standby (Standstill)	The limit velocity is changed to 0, and an immediate stop is performed. ^{*5} After the stop, the control mode is changed to csp (cyclic synchronous position mode).

*1 The servo turns OFF on the drive unit side and immediate stop is performed, and also the motion system side command is stopped.

*2 Operation differs depending on the setting value selected in Process Selection at Servo OFF Command During Operation (AxisName.Pr.StopMode_ServoOff). For details, refer to the following.

☞ Page 164 Relevant variables

*3 If an axis error (the error that transits the state into the "1: Stopping on error (ErrorStop)" status) occurs in the buffering FB, immediate stop will be performed from the error occurrence.

*4 When "Execute command (Execute)" of MC_Stop (Forced Stop) is FALSE at stop completion, Axis Status (AxisName.Md.AxisStatus) after stop will be "4: Standby (Standstill)".

*5 The set torque value is not changed. Note that it may take time to reach velocity 0 depending on the torque command value that is currently specified.

Buffer mode (BufferMode)


When starting this FB during another instruction execution

While this FB is executed, only Aborting and Buffered are supported.

■ Position control (FB1) → Torque control (FB2)


- 0: Aborting (mcAborting)

1. A control mode switching request for switching to cst (cyclic synchronous torque mode) is issued to the drive unit.
2. Until the drive unit is switched, the axis is operated at the previous velocity with the velocity control including the position loop.
3. When the drive unit switches to cst (cyclic synchronous torque mode), the torque increase/decrease starts from the current actual torque, and the acceleration/deceleration processing of velocity limit value starts from the current set velocity.




- 1: Buffered (mcBuffered)

1. Upon completing the first command, a control mode switching request for switching to cst (cyclic synchronous torque mode) is issued to the drive unit.
2. When the drive unit switches to the cst (cyclic synchronous torque mode), the acceleration/deceleration processing of the torque and the velocity starts from the current actual torque and the set velocity.




■Velocity control (FB1) → Torque control (FB2)

1. A control mode switching request for switching to cst (cyclic synchronous torque mode) is issued to the drive unit.
 2. While waiting for change, csv (cyclic synchronous velocity mode) is continued.
 3. When the drive unit switches to cst (cyclic synchronous torque mode), the torque increase/decrease starts from the current actual torque, and the acceleration/deceleration processing of the velocity starts from the set velocity.
- 0: Aborting (mcAborting)




- 1: Buffered (mcBuffered)



When starting another instruction during this FB execution

■Torque control → Stop instruction (MC_Stop (Forced Stop))




■Torque control → Positioning (Absolute value/Relative value positioning)

1. A control mode switching request for switching to csp (cyclic synchronous position mode) is issued to the drive unit.
2. Started positioning control FB is analyzed, and the axis waits until the drive unit switches to the csp (cyclic synchronous position mode). (Even if the axis requests the control mode for switching to the csp (cyclic synchronous position mode) during operation, switching may not be carried out depending on the drive unit specifications. If switching to the csp (cyclic synchronous position mode) is not completed within 1 [s], "Control Mode Switching Error" (error code: 1A1DH) occurs due to a timeout and the axis stops.)
3. While waiting for switching, torque control is continued with the torque and the limit velocity at switching.
4. When the drive unit switches to the csp (cyclic synchronous position mode), the positioning control starts.


Point

- The deceleration distance may not be secured and the target position may be overrun depending on the travel distance till switching from the cst (cyclic synchronous torque mode) to the csp (cyclic synchronous position mode). In this case, the axis operates based on Operation Setting at Overrun (AxisName.Pr.OverrunOperation). For operation at the overrun occurrence, refer to the following.
 Page 134 Multiple Start (Buffer Mode)
- At the overrun occurrence while waiting for switching, regardless of Operation Setting at Overrun (AxisName.Pr.OverrunOperation), "Overrun Error" (error code: 1A7EH) will occur immediately after switching to csp (cyclic synchronous position mode) and immediately stop the operation.

• 0: Aborting (mcAborting)




- 1: Buffered (mcBuffered)




■ Torque control (FB1) → Velocity control (FB2)

1. A control mode switching request for switching to csv (cyclic synchronous velocity mode) is issued to the drive unit.
 2. Started positioning control FB is analyzed, and the axis waits until the drive unit switches to the csv (cyclic synchronous velocity mode). (Even if the axis issues the control mode switching request for switching to the csv (cyclic synchronous velocity mode) during operation, switching may not be carried out depending on the drive unit specifications. If switching to the csv (cyclic synchronous velocity mode) is not completed within 1 [s], "Control Mode Switching Error" (error code: 1A1DH) occurs due to a timeout, and the axis will stop.)
 3. While waiting for switching, torque control is continued with the torque and the limit velocity at switching.
 4. When the drive unit switches to the csv (cyclic synchronous velocity mode), velocity control is started.
- 0: Aborting (mcAborting)



- 1: Buffered (mcBuffered)



When the operation direction is reversed

When starting this FB and operation direction is reversed during another instruction execution, reverse the set torque according to the torque positive direction ramp and the torque negative direction ramp.

When starting FB operated in csp (cyclic synchronous position mode) mode and operation direction is reversed during this instruction execution, set velocity at csp (cyclic synchronous position mode) mode switching is set to "0.0". After that the operation starts to the changed direction.

Precautions

- Velocity Override Factor (AxisName.Cd.VelocityOverride) and Acceleration Override Factor (AxisName.Cd.AccelerationOverride) are valid.
- The set position and the machine feed value are updated by follow up.
- Time until the control mode is switched depends on the specifications of the drive unit.
- When the stop cause occurs during the control mode switching, the axis will stop immediately.
- Do not start the positioning control FB during the control mode switching. Start the positioning control FB after confirming that Driver Control Mode (AxisName.Md.Driver_Mode) is switched to "10: cst (cyclic synchronous torque mode)".
- On the occasion that the control mode switches from the csp (cyclic synchronous position mode) to the cst (cyclic synchronous torque mode), if the stop cause (axis error detection) occurs before control mode switching, the follow up may be executed, with the control mode left in the csp (cyclic synchronous position mode), until achieving the zero speed status.
- When switching from the csp (cyclic synchronous position mode) to the cst (cyclic synchronous torque mode) or from the cst (cyclic synchronous torque mode) to the csp (cyclic synchronous position mode) without waiting for stop of the motor by using the MR-J5(W)-G, note the followings.
 - Set "ZSP disabled selection at control switching (PC76.1)" of the servo parameter (extension setting) to "1: Disabled" and disable monitoring of zero speed status. However, note that it may cause vibration or impact at control mode switching.
 - For the setting value of the servo parameter "Electronic gear numerator (PA06)" and "Electronic gear denominator (PA07)", refer to the following.
 Page 725 Setting methods

Torque limit change during the cst (cyclic synchronous torque mode)

At restart or continuous update, if the target torque is changed to a value bigger than the torque limit value (Positive Direction Torque Limit Value (AxisName.Md.TorqueLimit_Positive), Negative Direction Torque Limit Value (AxisName.Md.TorqueLimit_Negative)), "Torque Limit Value Over Warning" (warning code: 0D12H) will occur and the axis operates at the value before change.

During torque control, if Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative) are changed to a value smaller than the target torque, the target torque will be changed to the torque limit value. In this case, the set torque is changed at 1 cycle.

Relevant object

Functions subject to errors and restrictions under the following conditions will be shown below.

- No object data set
- No PDO mapping
- No object for the device station

Refer to the following for details of object data setting.

 Page 60 Object data settings

■PDO

◎: PDO mapping required, ○: PDO mapping recommended

Motion control FB/function	Required object data	Object necessary or not	Operation when no object is set
MC_TorqueControl (Torque Control) (selecting "0: cst (cyclic synchronous torque mode)" in Control mode switching selection (Options (Options): Bit 19))	Target torque (6071H)	◎	"Necessary Object Data Unset" (error code: 1AA8H) will occur.
	Velocity limit value (2D20H)	○	Velocity limit during the cst (cyclic synchronous torque mode) with limit velocity (LimitVelocity) will not be allowed.
	Torque actual value (6077H)	○	Refer to the following.  Page 309 Torque initial value selection (Options (Options): Bit 18)

Motion control FB/function	Required object data	Object necessary or not	Operation when no object is set
MC_TorqueControl (Torque Control) (selecting "1: ct (continuous operation to torque control mode)" in Control mode switching selection (Options (Options): Bit 19))	Target torque (6071H)	◎	"Necessary Object Data Unset" (error code: 1AA8H) will occur.
	Velocity limit value (2D20H)	◎	"Necessary Object Data Unset" (error code: 1AA8H) will occur.
	Torque actual value (6077H)	○	Refer to the following. ☞ Page 309 Torque initial value selection (Options (Options): Bit 18)
	Velocity actual value (606CH)	○	Refer to the following. ☞ Page 295 Velocity initial value selection

■SDO

Not applicable

7.3 Pressure Control

In pressure control, the drive unit control mode is switched to the cspr (cyclic synchronous pressure mode) for control operation.

Values of the pressure sensor (load cell) are controlled by a pressure control-compatible drive unit.

By applying the pressure ramp function and the acceleration/deceleration function for limit velocity, the values are sent to the drive unit with a ramp of set pressure and commanded limit velocity adjusted. For pressure control, use a drive unit supporting the cspr (cyclic synchronous pressure mode). The available drive unit and the firmware version are as follows.

Engineering tool	Version
MR-J5-G-LL	"F0" or later

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
ActualPosition	Actual Position	Stores the actual position (same as positioning control).
ActualVelocity	Actual Velocity	Stores the actual velocity (same as positioning control).
Cst_SetLimitVelocity	Set Limit Velocity at cst/ct/cspr	Stores set limit velocity at the cyclic synchronous torque mode (cst)/continuous operation to torque control mode (ct)/cyclic synchronous pressure mode (cspr).
Cspr_SetPressure	Set Pressure at cspr	Stores set pressure at the cyclic synchronous pressure mode (cspr).
Cspr_ForwardSidePosition	Forward-side Position at cspr	Stores forward-side position at the cyclic synchronous pressure mode (cspr).
Io_PressureActualValue	Object Data_PressureActualValue	Displays the value of object data "Pressure actual value (2E52H)." ^{*1}
TargetVelocity	Target Velocity	<ul style="list-style-type: none">• Stores actual limit velocity in consideration of override for the limit velocity (LimitVelocity), which is "0" or more regardless of movement directions.• Stores "0" upon control completion.
InVelocity	Target Velocity Reached	Stores FALSE (Not reached) at the cyclic synchronous pressure mode (cspr).

^{*1} For the details on object data, refer to the following.

 Page 62 Object data list

Relevant FB


For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_PressureControl	Pressure Control	Switches the drive unit control mode to cspr (cyclic synchronous pressure mode) to execute pressure control according to the specified pressure.

Overall block diagram

The relation between pressure control and other functions are shown below.



*1 Initial value for real drive axis

Control details

MCv_PressureControl (Pressure Control) switches the drive unit control mode to the cspr (cyclic synchronous pressure mode) and executes pressure control.

To finish this FB, multiple start MC_Stop (Forced Stop) or input the axis stop signal. Alternatively, multiple start another motion FB so as to switch to csp (cyclic synchronous position mode).

Relation between increase/decrease in set pressure and movement direction of servo motor

When using MR-J5-G-LL, it differs depending on settings for "Selection of pressure increasing direction for positioning address (PW12.1)" and "Travel direction selection (PA14)" of the servo parameters.

- When "Selection of pressure increasing direction for positioning address (PW12.1)" is "0: The pressure increases as the positioning address decreases."

Setting value of "Travel direction selection (PA14)"	Set pressure	Travel direction of servo motor
0: Positioning address increasing CCW rotation	Increase	CW direction
	Decrease	CCW direction
1: Positioning address increasing CW rotation	Increase	CCW direction
	Decrease	CW direction


- When "Selection of pressure increasing direction for positioning address (PW12.1)" is "1: The pressure increases as the positioning address increases."

Setting value of "Travel direction selection (PA14)"	Set pressure	Travel direction of servo motor
0: Positioning address increasing CCW rotation	Increase	CCW direction
	Decrease	CW direction
1: Positioning address increasing CW rotation	Increase	CW direction
	Decrease	CCW direction

Driver control mode switching

The operation for setting the driver control mode to the cspr (cyclic synchronous pressure mode) is described below.

1. When starting operation, a control mode switching request for switching to the cspr (cyclic synchronous pressure mode) is issued to the drive unit.
2. Standby velocity "0" is continued and the commanded position is stopped until the drive unit control mode switches. Moreover, the set pressure and the set limit value become initial values set respectively in Set pressure initial value selection (Options (Options): Bit 16) and Set limit value initial value selection (Options (Options): Bit 18, 19).
3. After the drive unit control mode switches, pressure ramp and acceleration/deceleration processing start at each set value.



Operations at stop cause occurrence

Stop causes that occur during the cspr (cyclic synchronous pressure mode) and stopping process when each cause occurs are shown below.

Cause No.	Stop cause	Axis Status (<u>AxisName</u> .Md.AxisStatus)	Stop process
		After stop	
1	"Forced stop input" is OFF	1: Stopping on error (ErrorStop)	Immediate stop ^{*1}
2	Drive unit power supply is OFF	1: Stopping on error (ErrorStop)	Immediate stop ^{*1}
	Drive unit network disconnection detection		
	Drive unit error		
	Forced stop input to the drive unit		
	Enable (Enable) of MC_Power (Operation Available) is FALSE		
	Servo ON request (ServoON) of MC_Power (Operation Available) is FALSE (When Process Selection at Servo OFF Command During Operation (<u>AxisName</u> .Pr.StopMode_ServoOff) is "4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)", "5: Servo OFF After Deceleration to Stop (ServoOffAfterDecelStop)") ^{*2}		
Drive unit control mode has switched to the control mode which the motion system axis control is not supported.			
3	Hardware stroke limit upper/lower limit error occurrence	1: Stopping on error (ErrorStop)	Immediate stop at set limit velocity 0. ^{*5} Switches to csp (cyclic synchronous position mode) after stop.
4	CPU module moderate/major error occurrence	1: Stopping on error (ErrorStop)	
	PLC READY is OFF		
	Motion system moderate error or major error occurrence		
	Cycle over error occurrence		
5	Software stroke limit upper/lower limit error occurrence	1: Stopping on error (ErrorStop)	
6	Axis error detection ^{*3}	1: Stopping on error (ErrorStop)	
7	Execute command (Execute) of MC_Stop (Forced Stop) is TRUE	2: Decelerating to stop (Stopping) ^{*4}	Immediate stop at set limit velocity 0. ^{*5} Switches to csp (cyclic synchronous position mode) after stop. (Not based on the deceleration of MC_Stop (Forced Stop))
8	"Stop signal (STOP) " of external input signal is TRUE	4: Standby (Standstill)	Immediate stop at set limit velocity 0. ^{*5} Switches to csp (cyclic synchronous position mode) after stop.

*1 The servo turns OFF on the drive unit side and immediate stop is performed, and also the motion system side command is stopped.

*2 Operation differs depending on the setting value selected in Process Selection at Servo OFF Command During Operation (AxisName.Pr.StopMode_ServoOff). For details, refer to the following.

☞ Page 164 Relevant variables


*3 If an axis error (the error that transits the state into the "1: Stopping on error (ErrorStop)" status) occurs in the buffering FB, immediate stop will be performed from the error occurrence.

*4 When Execute command (Execute) of MC_Stop (Forced Stop) is FALSE at stop completion, Axis Status (AxisName.Md.AxisStatus) after stop will be "4: Standby (Standstill)".

*5 Set pressure value is not changed. Note that it may take some time to reach velocity 0 depending on the set pressure at stop cause occurrence.

Pressure ramp function

- Adjusts the ramp of set pressure sent to the drive unit.
- Generates the set pressure based on pressure (Pressure) and pressure ramp (PressureRamp).



- If the generated result is not an integer, a value rounded down to the nearest whole number is set as the set pressure.
- When the pressure ramp (PressureRamp) is set to "0.0", the commanded pressure is reached in one control cycle.
- When switching the control mode from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode) by start and multiple start, this function operates at a set pressure set in Set pressure initial value selection (Options) (Options): Bit 16) as the initial value. Refer to the following for details on start and multiple start.

➞ Page 325 Driver control mode switching

Set pressure initial value selection (Options (Options): Bit 16)

Sets the initial value of set pressure when switching the control mode from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode).

Setting value	Description
0: Commanded pressure	Set pressure initial value is pressure (Pressure).
1: Actual pressure	Set pressure initial value is the actual pressure (Object Data_PressureActualValue (AxisName.Md.Io_PressureActualValue)). When the value of actual pressure is negative, it becomes "0". When it is beyond "30000", it becomes "30000".*1

*1 If the object assigned to the object data "Pressure actual value (2E52H)" is not mapped to PDO, it will not be the actual pressure. (The initial pressure value is "0".)

Precautions

- Time to reach the pressure (Pressure) from the set pressure is limited to 8400 [s]. Limit applies to the pressure (Pressure), the pressure ramp (PressureRamp time) and the pressure ramp time calculated from the set pressure. Set the pressure (Pressure) and the pressure ramp (PressureRamp) so that the pressure ramp time does not exceed 8400 [s].
- How to calculate pressure ramp time is as follows.

Type	Item	Abbreviation	Description	Calculation formula
Specified value	Pressure (Pressure)	P	Sets commanded pressure.	—
	Pressure ramp (PressureRamp)	PR	Sets the ramp to reach the pressure (Pressure) from the set pressure.	
Set value	Set pressure	Pnow	Set value of the pressure	P - Pnow ÷ PR
Calculated value	Pressure ramp time	—	Time to reach the pressure (Pressure) from the set pressure	

- At start or FB switching by multiple start, if the set pressure has not reached the pressure (Pressure) and the pressure ramp time exceeds 8400 [s], "Ramp time over" (error code: 1B02H) will occur.
- When the pressure (Pressure) or the pressure ramp (PressureRamp) is changed by retrigger/continuous update, if the set pressure has not reached the pressure (Pressure) and the pressure ramp time exceeds 8400 [s], the changed value is ignored and the operation continues at the value before change. At the time of change, "Ramp time over warning" (warning code: 0D51H) will occur.

Acceleration/deceleration processing function for limit velocity

- Adjusts the ramp of set limit velocity sent to the drive unit.
- Generates the set limit velocity based on the limit velocity (LimitVelocity), the acceleration (Acceleration), the deceleration (Deceleration) and Acceleration/deceleration method setting (Options (Options): Bit 0 to 2). For details, refer to the following. (Note that Velocity (Velocity) should be read as the limit velocity (LimitVelocity).)
 Page 358 Acceleration/deceleration Processing Function
- When switching the control mode from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode) by start and multiple start, this function operates at a set limit velocity set in Set limit velocity initial value selection (Options (Options): Bit 18, 19) as the initial value. Refer to the following for details on start and multiple start.
 Page 325 Driver control mode switching

Set limit velocity initial value selection (Options (Options): Bit 18, 19)

Sets the initial value of set limit velocity at start or multiple start.

Sets the initial value of set limit velocity when switching the control mode from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode).

Setting value	Description
0: Set velocity	The absolute value of the set limit velocity (<u>AxisName</u> .Md.SetVelocity) is used as the Initial value of the set limit velocity. Accelerates/decelerates toward the limit velocity (LimitVelocity) after switching.
1: Commanded limit velocity	The limit velocity (LimitVelocity) is used as the Initial value of the set limit velocity.
2: Automatic selection	The lower velocity between "0: Set velocity" and "1: Commanded velocity" is used as the initial value of the set limit velocity. Accelerates/decelerates toward the limit velocity (LimitVelocity) after switching if "0: Set velocity" is lower.

When switching from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode) during axis movement, vibration and shock can be suppressed by setting Set limit velocity initial value selection (Options (Options): Bit 18, 19) and the limit velocity (LimitVelocity) in either one of the ways as shown below.

- Set limit velocity initial value selection (Options (Options): Bit 18, 19) is set to "0: Set velocity".
- Set limit velocity initial value selection is set to "1: Commanded limit velocity" while setting the limit velocity (LimitVelocity) to a value less than or equal to the set velocity at switching.

Precautions

- The override function for the set limit velocity and its acceleration/deceleration is enabled. For details of the override function, refer to the following. (Note that "target velocity" should be read as "set limit velocity".)
 Page 392 Override Function
- When multiple starting with "0" specified for the acceleration (Acceleration) or the deceleration (Deceleration), the target acceleration or deceleration of the previous FB is not taken over. It will be the same operation as at start.

Pressure control process


- Pressure control includes the processes of feed, dwell and pressure release. MCv_PressureControl (Pressure Control) is used to create a user program that executes the following in each process.

Pressure control process (Process)	Description	Operating procedure
0: Feed (Feed)	The process to put the tip of a machine for pressing and applying pressure into contact with a workpiece and to gradually move the tip to the dwell start position.	<ol style="list-style-type: none"> The tip of the machine moves closer to the workpiece at a low velocity. The tip of the machine comes in contact with the workpiece. After the contact, the load cell pressure (actual pressure) starts increasing. Specifies the limit velocity and pressure, whereby the tip moves gradually to the dwell start position. Switches to the dwell operation.
1: Dwell (Dwell)	The process to apply pressure to the workpiece.	<ol style="list-style-type: none"> Specifies the pressure and applies a variety of pressure to the workpiece. <Example> low pressure → high pressure → middle pressure
2: Pressure release (Release)	Release pressure from the workpiece	<ol style="list-style-type: none"> Specifies the pressure or the last position and lowers the pressure applied to the workpiece. This allows the actual pressure to start decreasing. Ends the pressure release when the actual pressure is sufficiently decreased.

- The pressure control process is sent to the drive unit by setting the pressure control process (Process). When MR-J5-G-LL is used, enable/disable the pressure model adaptive control for dwell or pressure release by the servo parameter "Pressure model adaptive control selection (PW34.0)" .

Setting valued for Pressure model adaptive control selection (PW34.0)	Pressure control process	
	Dwell	Pressure release
0	Disabled	Disabled
1	Enabled	
2	Disabled	Enabled
3	Enabled	

- When the servo parameter "Pressure model adaptive control selection (PW34.0)" is set to a value other than "0" to enable the pressure model adaptive control for dwell or pressure release, set the pressure control process (Process) according to what is executed in the user program. If the pressure model adaptive control is not enabled, the pressure control process (Process) does not need to be set, left at the initial value (0: Feed (Feed)). For details on the pressure model adaptive control, refer to the MR-J5-G manual.
- For transmission to the drive unit, use "Bit 13 (C_ATHO): Pressure control Dwelling command" and "Bit 14 (C_ATRE): Pressure control Depressurization command" under the object data "Control DI 5 (2D05H)". To check the drive unit process, monitor with "Bit 11 (S_ATHO): Pressure control Dwelling in progress" and "Bit 12 (S_ATRE): Pressure control Depressurization in progress" under the slave-labeled object data "Status DO 5 (2D15H)".





Precautions

- If the actual velocity at the start of feed does not reach the limit velocity, increase the set pressure at the start of feed. (The set pressure at the start of dwell does not need to be changed.)
- If the actual pressure overshoots when switching from feed to dwell, set the acceleration (Acceleration) and the deceleration (Deceleration) so that the acceleration/deceleration is small at the start of dwell.

Limit position/last position (forward-side position)

The following table shows operations for each pressure control process according to the setting of the forward-side position (ForwardSidePosition).

Pressure control process	Operation
Feed/dwell	<p>Limits the range where an axis can move in the pressure increase direction. Sets the limit position to the forward-side position (ForwardSidePosition).</p>  <p>The graph shows Pressure on the vertical axis and Position on the horizontal axis. A horizontal line represents constant pressure until the 'Position where pressure begins to be applied in contact with workpiece'. After this, the pressure increases linearly. A vertical dashed line marks the 'Limit position'. An arrow indicates the 'Pressure increase direction'. A callout box states: 'When the actual position exceeds the limit position, a torque is generated in the direction of the drive unit returning to the limit position.'</p>
Pressure release	<p>Specifies the final position at which the actual pressure drops and operates the pressure release. Sets the final position to the forward-side position (ForwardSidePosition).</p>  <p>The graph shows Pressure on the vertical axis and Position on the horizontal axis. A horizontal line represents constant pressure until the 'Position at the start of pressure release'. After this, the pressure drops to zero. A vertical dashed line marks the 'Last position'. An arrow indicates the 'Pressure increase direction'. A callout box states: 'Until the actual position returns to the last position, torque is generated in the direction in which the drive unit returns to the final position.'</p>

- MCv_PressureControl (Pressure Control) executes drive unit conversion for the forward-side position (ForwardSidePosition) and generates the forward-side position to be transmitted to the drive unit. For transmission to the drive unit, use the object data "Forward-side stop function (2E56H)".
- The forward-side position (AxisName.Md.Cspr_ForwardSidePosition) at cspr allows one to check the forward-side position to be transmitted to the drive unit in position command unit.
- In any pressure control process, due to the forward-side stop function of the drive unit, torque is generated in the direction back to the forward-side position when the current position exceeds the limit/last position (forward-side position) in the pressure increasing direction.

Precautions

- There are restrictions on the valid range and movement range during control of the forward-side position (ForwardSidePosition). Use this variable within the restricted range. The upper limit of the range is as follows.

Upper limit of range

$(2147483648^{*1} - 10 \times \text{Encoder resolution}^{*2} / \text{Electric gear}^{*3}) \times \text{Driver unit conversion denominator} / \text{Driver unit conversion numerator}$

*1 "2147483648" = "2³¹".

*2 Encoder resolution obtained from the drive unit (object data "Encoder increments (608FH)").

*3 Electric gear obtained from the drive unit (Gear ratio). When using MR-J5-G-LL, the values reflects the servo parameters "Electric gear numerator (PA06)" and "Electric gear denominator (PA07)".

■Valid range of the forward-side position (ForwardSidePosition)

Restrictions	Timing	Processing when out of range
Using the set position (<u>AxisName.Md.SetPosition</u>) at control mode switching request for switching to cspr (cyclic synchronous pressure mode)* ¹ as the reference position, sets the forward-side position (ForwardSidePosition) so that the absolute value of the difference from the reference position does not exceed the upper limit.	At the start of control	"Forward-side position Incorrect" (error code: 1B01H) will occur.
Using the set position (<u>AxisName.Md.SetPosition</u>) at switching request for switching to cspr (cyclic synchronous pressure mode)* ¹ as the reference position, sets the forward-side position (ForwardSidePosition) so that the absolute value of the difference from the reference position does not exceed the upper limit.	At control change	Ignores the changed value and continues operation with the value before change. "Forward-side position Incorrect Warning" (warning code: 0D4FH)" will occur.
Changes the forward-side position (ForwardSidePosition) so that the absolute value of the difference from the forward-side position (<u>AxisName.Md.Cspr_ForwardSidePosition</u>) at cspr does not exceed the upper limit.		

*1 Same as at the rising edge of Controlling (Active) when calling a pressure control FB from a program at the same cycle as the axis control cycle.

■Movement range during control

Restrictions	Timing	Processing when out of range
Uses so that the absolute value of the difference between the set position (<u>AxisName.Md.SetPosition</u>) and the forward-side position (<u>AxisName.Md.Cspr_ForwardSidePosition</u>) at cspr does not exceed the upper limit.	During control	"Forward-side position Exceeded" (error code: 1B03H) will occur.

- By setting the electronic gear and driver unit conversion so that the encoder resolution in the driver unit is reduced, the valid range of the forward-side position (ForwardSidePosition) and the movement range during control can be extended. For details on the electronic gear setting for the drive unit, refer to the following.

☞ Page 725 Connection Method for MELSERVO

Ex.

When executing pressure control with MR-J5-G-LL and a rotary servo motor

Setting A and Setting B have the same relation in units between the motion system and the servo motor side.

If the restriction range poses a problem in Setting A, the range can be extended by changing to Setting B while maintaining the relation in units between the motion system and the servo motor side.

■Setting

- Motion system

Setting item	Setting value	
	Setting A	Setting B
Position Command Unit (<u>AxisName.Pr.Unit_Position</u>)	HFA010000 (μm)	
Driver Unit Conversion Numerator (<u>AxisName.Pr.Drive_UnitConvRatioNum</u>)	67108864 [pulse]	4194304 [pulse]
Driver Unit Conversion Denominator (<u>AxisName.Pr.Drive_UnitConvRatioDen</u>)	20000 [μm]	

- MR-J5-G-LL

Setting item	Setting value	
	Setting A	Setting B
Electric gear numerator (PA06)	1	16
Electric gear denominator (PA07)	1	
Motor encoder resolution	67108864 [pulse/rev]	


■Upper limit of range

$(2^{31} - 10 \times \text{Encoder resolution} / \text{Electric gear}) \times \text{Driver unit conversion denominator} / \text{Driver unit conversion numerator}$

$= (2^{31} - 10 \times \text{Encoder resolution} / (\text{Electric gear numerator (PA06)} / \text{Electric gear denominator (PA07)})) \times \text{Driver unit conversion denominator} / \text{Driver unit conversion numerator}$


Setting	Upper limit of range
Setting A	$(2147483648 - 10 \times 67108864 / (1 / 1)) \times 20000 / 67108864 = 440000 \text{ [μm]}$
Setting B	$(2147483648 - 10 \times 67108864 / (16 / 1)) \times 20000 / 4194304 = 10040000 \text{ [μm]}$

- When starting a pressure control FB with the set position (AxisName.Md.SetPosition) at "-10000 [μm]", the valid range of "the forward-side position (ForwardSidePosition) at operation start" is as follows.



(1) Set position (AxisName.Md.SetPosition) at operation start


- After starting a pressure control FB with the set position (AxisName.Md.SetPosition) at "-10000 [μm]", if the forward-side position (AxisName.Md.Cspr_ForwardSidePosition) at cspr is at "-200000 [μm]", the valid range of the forward-side position (ForwardSidePosition) at control change is as follows.



(1) Set position (AxisName.Md.SetPosition) at operation start

(2) Forward-side position (AxisName.Md.Cspr_ForwardSidePosition) at cspr

- The movement range of pressure control FBs during control with the forward-side position (AxisName.Md.Cspr_ForwardSidePosition) at cspr "-200000 [μm]" as follows.



(1) Forward-side position (AxisName.Md.Cspr_ForwardSidePosition) at cspr

- In order to enable the limit/final position, map the object assigned to the object data "Forward-side stop function (2E56H)" to PDO. If not mapped to PDO, the setting of forward-side position (ForwardSidePosition) is ignored to disable the limit position/last position.

When using MR-J5-G-LL, it is recommended to set PDO mapping and servo parameters as follows.

Limit position/last position	Setting of PDO mapping for objects assigned to object data "Forward-side stop function (2E56H)"	Setting of the servo parameter "Forward/reverse-side stop function (PW12.2)"
Enabled	PDO mapping	1h (Forward-side stop: Enabled, Reverse-side stop: Disabled)
Disabled *1	No PDO mapping *2	2h (Forward-side stop: Disabled, Reverse-side stop: Disabled)

*1 The forward-side stop function is disabled. Set the software stroke limit in order to limit the range where an axis can move in the increasing pressure direction.

*2 Set "Forward-side stop function (2E56H)" so as not to be mapped to PDO, or set the object data (AxisName.PrConst.SlaveObject.vCspr_ForwardSideStopFunction) to "" (a character string of length 0).

- When pressure control is performed with the limit position/last position enabled, enable the software stroke limit function. If the software stroke limit function is disabled, "Start when Software Stroke Limit is Disabled" (error code: 1B00H) occurs at FB execution.

Multiple start (Buffer mode)

When pressure control FB is multiple started during previous motion FB control

■csp (cyclic synchronous position mode) → cspr (cyclic synchronous pressure mode)


1. At FB switching by multiple start, a switching request for switching to the cspr (cyclic synchronous pressure mode) is issued to the drive unit.
2. Until the drive unit control mode is switched, position control continues at the velocity of the previous motion FB. The set pressure and set limit velocity are set to the initial values ^{*1}.

^{*1} The initial values of set pressure and set limit velocity are set in the following options.

- Set pressure initial value selection (Options (Options): Bit 16)
- Set limit velocity initial value selection (Options (Options): Bit 18, 19)

3. After the drive unit control mode is switched, start pressure ramp and acceleration/deceleration processing at each set value.

- 0: Aborting (mcAborting)



■When the previous motion FB is a pressure control FB

Refer to the following for cases where the previous motion FB is a pressure control FB.

☞ Page 336 When multiple starting another pressure control FB during pressure control FB control


When the next motion FB is multiple started during pressure control FB control

■ cspr (cyclic synchronous pressure mode) → csp (cyclic synchronous position mode)

- When the next motion FB is MC_Stop (Forced Stop)

1. At FB switching by multiple start, a control mode switching request for switching to the csp (cyclic synchronous position mode) is issued to the drive unit. Further, the set limit velocity is set to "0".
2. Until the drive unit control mode is switched, the pressure control continues at a set limit velocity of "0" and at the set pressure when the request is issued.
3. Upon switching the drive unit control mode, MC_Stop (Forced Stop) is completed.


- 0: Aborting (mcAborting) of MC_Stop (Forced Stop)



- When the next motion FB is not MC_Stop (Forced Stop)

1. At FB switching by multiple start, a switching request for switching to the csp (cyclic synchronous position mode) is issued to the drive unit.
2. Until the drive unit control mode is switched, the pressure control continues at the set pressure and the set limit velocity when the request is issued.
3. Upon switching the drive unit control mode, MC_Stop (Forced Stop) is completed.

- 0: Aborting (mcAborting) of Positioning control FB



- *1 When the operation direction differs between the pressure control FB and the next motion FB, the set velocity is set to "0" immediately after switching to the csp (cyclic synchronous position mode). After that, positioning control is started toward the operation direction for the next motion FB.



When the next motion FB is a positioning FB, the deceleration distance may not be secured depending on a travel distance until the drive unit control mode finishes switching, and thus the target position may be overrun. In this case, the axis operates based on Operation Setting at Overrun (AxisName.Pr.OverrunOperation) immediately after switching to the csp (cyclic synchronous position mode). For the operation when overrun occurs, refer to the following.

📖 Page 134 Multiple Start (Buffer Mode)

However, if the overrun occurs while waiting for switching, "Overrun Error" (error code: 1A7EH) occurs regardless of Operation Setting at Overrun (AxisName.Pr.OverrunOperation) immediately after switching to the csp (cyclic synchronous position mode), and the axis stops immediately.

■When the next motion FB is a pressure control FB

Refer to the following for the case where the next motion FB is a pressure control FB.

📖 Page 336 When multiple starting another pressure control FB during pressure control FB control

When multiple starting another pressure control FB during pressure control FB control

Do not multiple start another pressure control FB during pressure control FB control.

If multiple start one, "BufferMode Specification Disabled" (error code: 1A80H) will occur.

Precautions

- Follow up is executed during the cspr (cyclic synchronous pressure mode). For details on follow up, refer to the following.
 Page 89 Follow Up
- The time until the control mode is switched depends on drive unit specifications.
- Do not multiple start the positioning control FB until the control mode is switched from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode). After confirming that the driver control mode (AxisName.Md.Driver_Mode) is switched to "-111: Cyclic synchronous pressure mode (cspr)", multiple start the positioning control FB.
- An actual motor velocity may not reach the limit velocity depending on machine load conditions during the cspr (cyclic synchronous pressure mode).
- When switching the control mode from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode), or from the cspr (cyclic synchronous pressure mode) to the csp (cyclic synchronous position mode), it is recommended to do so after putting the motor into stop status (zero speed status). The zero speed status can be monitored by labeling Status DO2 (2D12h) to the slave label.
- When switching the control mode from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode), if a stop cause (axis error detection) occurs before control mode switching, the follow up may be executed, with the control mode left in the csp (cyclic synchronous position mode), until achieving the zero speed status.
- When switching from the csp (cyclic synchronous position mode) to the cspr (cyclic synchronous pressure mode), or from the cspr (cyclic synchronous pressure mode) to the csp (cyclic synchronous position mode) without awaiting motor stop, set servo parameter "ZSP disabled selection at control switching (PC76.1)" to "1: Disabled" and then set zero speed status monitor disabled. Note that it may cause vibration or impact at control mode switching.
- Driver command discard detection is not executed during the cspr (cyclic synchronous pressure mode) regardless of the setting of Driver Command Discard Detection Setting (AxisName.Pr.StopOption_DriverTargetIgnored). When executing limit detection on the drive unit side with servo parameter "Limit switch enabled status selection (PD41.2)" set to "0: Limit switch always enabled", switch the control mode to the csp (cyclic synchronous position mode) by means of MC_Stop (Forced Stop) or the axis stop signal at stop due to limit detection.
- Wire the load cell servo amplifier output to the analog input of the drive unit. For details, refer to the manuals of connected devices.
- For functions of the drive unit unusable during the cspr (cyclic synchronous pressure mode), refer to the manuals of connected devices.
- An abnormality of the load cell detector, etc. or variation of the load cell pressure during pressure control may lead to a situation where the axis keeps moving backward. Set a software stroke limit.
- To limit the set pressure, change object data "Positive pressure limit value (2E5BH)" by either of the following methods. For details on "Positive pressure limit value (2E5BH)", refer to the manuals of connected devices to be used.
 - Change "Positive pressure limit value (2E5BH)" with MC_WriteParameter (Parameter Write). For details on MC_WriteParameter (Parameter Write), refer to the following.
 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)
 - Map object data "Positive pressure limit value (2E5BH)" to RPDO, thereby labeling to the slave label. Change the value of the said label. For details on slave labels and PDO mapping settings, refer to the following.
 Page 718 How to use the slave label

Relevant object

Functions subject to errors and restrictions under the following conditions will be shown below.

- No object data set
- No PDO mapping
- No object for the device station

Refer to the following for details of object data setting.

☞ Page 60 Object data settings

■PDO

◎: PDO mapping required, ○: PDO mapping recommended

Motion control FB/function	Required object data	Mapping availability	Operation when no object is set
MCv_PressureControl (Pressure Control)	Control DI 5 (2D05H)	◎	At start or multiple start, "Necessary Object Data Unset" (error code: 1AA8H) will occur.
	Velocity limit value (2D20H)		
	Target pressure (2E50H)		
	Forward-side stop function (2E56H)	○	Refer to "Precautions" found under the following subsection. ☞ Page 330 Limit position/last position (forward-side position)
	Pressure actual value (2E52H)		Refer to the following. ☞ Page 327 Set pressure initial value selection (Options (Options): Bit 16)

■SDO

Not applicable

Relevant add-ons

The following add-ons are required to use this function.

- Axis
- MotionEngine
- MotionControl_General
- NetworkDriver_CCIETSN*¹
- ServoDriver_CANopen*¹

*¹ When using the real axis

Combination of the version

The version of the engineering tool which is compatible with this function is as follows.

Engineering tool	Version
Motion control setting function	"1.065T" or later

8 FUNCTIONS RELEVANT TO POSITION

8.1 Current Position Change Function

- This function executes control to change the set position and the cumulative current position to an arbitrary address. The current position change method includes a method of changing the set position at control execution. (MC_SetPosition (Current Position Change)) (The machine feed value is not changed.)
- The "absolute position set" and the "relative position set" can be specified in the address to change.
- This function can be executed only while Axis Status (`AxisName.Md.AxisStatus`) is "4: Standby (Standstill)".
- A current position change to outside the ring counter range and outside the software stroke limit range cannot be executed.
- For operation when executing a current position change to the synchronous control master axis, refer to the following.

☞ Page 464 SYNCHRONOUS CONTROL

Point

When a current position change is completed, that "the current position change is executed" is recorded in the event history.

Targets to be changed and corresponding FBs

Target to be changed			Corresponding FB
Position	Current value		MC_SetPosition (Current Position Change)
	Limit value (Software stroke limit)		—*1
	Limit value (Software stroke limit)	Maximum value of the limit value	—*2

*1 Axis parameters can be changed by MC_WriteParameter (Parameter Write). However, it cannot be changed during control.

*2 The maximum value of the limit value cannot be changed.

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_SetPosition	Current Position Change	Changes the current position of the specified axis (set position, actual position).

Current position change


The control details of current position change are shown below.

Execution when the axis stops

The current position change operation starts at rising edge detection of Execute command (Execute) of MC_SetPosition (Current Position Change).
In the current position change, the set position and the cumulative current position are changed to the position specified in Target position (Position).
Target position (Position) is "Relative position set" when Relative position selection (Relative) is TRUE, and it is "Absolute position set" when Relative position selection (Relative) is FALSE.

Ex.

When executing the current position change to 90.0 while the axis stops with the ring counter lower limit value of 0.0, the ring counter upper limit value of 360.0, and the set position of 180.0 (the cumulative current position of 540.0).



Execution during axis operation


■Execute at Completion of Previous One

When "1: Execute at Completion of Previous One (mcQueued)" is set in Execution mode (ExecutionMode), this FB is executed after the on-going FB is completed.

Executing (Busy) turns TRUE by rising edge detection of Execute command (Execute), and this FB waits until Axis Status (AxisName.Md.AxisStatus) turns "4: Standby (Standstill)".

As soon as Axis Status (AxisName.Md.AxisStatus) turns "4: Standby (Standstill)", the current position change operation will start.


Ex.



■ Speculative execution

When "3: Execute Speculatively (mcSpeculatively)" is specified to Execution mode (ExecutionMode), the current position change can be performed only when Axis Status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)" at the rising edge detection of Execute command (Execute). If Axis status (AxisName.Md.AxisStatus) of relevant axis is not "4: Standby (Standstill)", or FB instruction is being executed, "MC_SetPosition Instruction Error" (error code: 344EH) occurs, and the current position change is not performed.

Ex.




Cancel

Current position change that is in the standby status can be canceled after FB execution.

- To enable cancel, execute the FB with the status of "Cancel accepted after FB start" (Options (Options): Bit 16) set to "1: Allow".
- Cancel is started at falling edge detection of Execute command (Execute).
- Cancel is accepted only when Executing (Busy) of the output pin is TRUE.
- When FB accepts cancel, Cancel acceptance (CancelAccepted) of the output pin becomes TRUE.
- When cancel is completed, Abortion of execution (CommandAborted) of the output pin becomes TRUE.
- When cancel was carried out, the set position is not changed.

Ex.

When canceling while Axis Status (AxisName.Md.AxisStatus) is waiting for switching to "4: Standby (Standstill)" after starting MC_SetPosition (Current Position Change) with "1: Execute at Completion of Previous One (mcQueued)" in Execution mode (ExecutionMode)



8.2 Command In-position

The command in-position function checks the remaining distance to the target position, and changes the command in-position flag to TRUE.

This flag is called the "command in-position flag". The command in-position flag is used as a front-loading signal indicating beforehand the completion of the control.

The command in-position function is valid to all control that requires commanded address specification.

It changes Command In-position (AxisName.Md.CmdInPos) to TRUE when the remaining distance to the target position became Command In-position Width (AxisName.Md.CmdInPos_Width) or less.

It changes Command In-position (AxisName.Md.CmdInPos) to FALSE when the axis starts and when the FB is switched by multiple start.

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
CmdInPos_Width	Command In-position Width	Sets the command in-position width. <ul style="list-style-type: none">• 0.0: Function disabled• 0.000000001 to 10,000,000,000.0: Function enabled^{*1}

^{*1} If positive numbers less than 0.000000001 are set, it imports 0.0

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
CmdInPos_Width	Command In-position Width	Displays the command in-position width. <ul style="list-style-type: none">• The value imports the setting value of Command In-position Width (<u>AxisName</u>.Pr.CmdInPos_Width).• When Command In-position Width (<u>AxisName</u>.Md.CmdInPos_Width) is 0.0, the command in-position function of the axis is disabled.
CmdInPos	Command In-position	Displays whether the remaining distance to the target position is Command In-position Width (<u>AxisName</u> .Md.CmdInPos_Width) or less. <ul style="list-style-type: none">• FALSE: More than Command in-position width• TRUE: Less than Command in-position width

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
CmdInPos_Width	Command In-position Width	Sets the command in-position width on the composite axis of the axes group. <ul style="list-style-type: none">• 0.0: Function disabled• 0.000000001 to 10,000,000,000.0: Function enabled^{*1}

^{*1} If positive numbers less than 0.000000001 are set, it imports 0.0

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
CmdInPos_Width	Command In-position Width	Displays the command in-position width on the composite axis of the axes group. <ul style="list-style-type: none">• The value imports the setting value of Command In-position Width (<u>AxesGroupName</u>.Pr.CmdInPos_Width).• When Command In-position Width (<u>AxesGroupName</u>.Md.CmdInPos_Width) is 0.0, the command in-position function of the axes group is disabled.
CmdInPos	Command In-position	Displays whether the remaining distance to the target position on the composite axis is Command In-position Width (<u>AxesGroupName</u> .Pr.CmdInPos_Width) or less. <ul style="list-style-type: none">• FALSE: More than Command in-position width• TRUE: Less than Command in-position width

Command in-position width check


A command in-position width check is carried out every operation cycle.

However, while the axis stops, Command In-position (AxisName.Md.CmdInPos) is not refreshed.

When Command In-position Width (AxisName.Md.CmdInPos_Width) is 0.0, a command in-position width check is not carried out.

For an axes group, the remaining distance on the composite axis (line/arc) is checked based on Command In-position Width (AxesGroupName.Md.CmdInPos_Width). When the long axis velocity specification and the reference axis speed specification are specified on the linear interpolation control, the remaining distance on the long axis and the reference axis are checked. The flag is stored in Command In-position (AxesGroupName.Md.CmdInPos).

During axes group operation, the command in-position function of the configuration axes is disabled. Command In-position (AxisName.Md.CmdInPos) of the configuration axes is not changed to TRUE during axes group operation. (It is changed to FALSE when the axes group is started.)



- (the remaining distance) $\leq$ (Command in-position width (AxisName.Md.CmdInPos_Width))

8.3 Software Stroke Limit

In the "software stroke limit function", an address is set as the movable range. Even if a movement command to the address outside the setting range is issued, the command will not be executed. By not executing the command outside the movable area, even if an incorrect command or unexpected operation occurs, the system will not operate out of the movable area and damage to the machine can be prevented.

In the motion system, the "set position" and "machine feed value" are used as the addresses indicating the current value. However, in the "software stroke limit function", which address is used to carry out the limit check is designated in Software Stroke Limit Target (AxisName.Pr.SwStrokeLimit_Target).

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
SwStrokeLimit_Upper	Software Stroke Limit Upper Value	Sets the software stroke limit upper value. <ul style="list-style-type: none">• -10000000000.0 to 10000000000.0
SwStrokeLimit_Lower	Software Stroke Limit Lower Value	Sets the software stroke limit lower value. <ul style="list-style-type: none">• -10000000000.0 to 10000000000.0
SwStrokeLimit_Target	Software Stroke Limit Target	Sets the software stroke limit target. <ul style="list-style-type: none">• -1: Disabled (Invalid)• 1: Set position (SetPosition)• 3: Feed machine position (FeedMachinePosition)

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
SwStrokeLimit_Upper	Software Stroke Limit Upper Value	Displays the software stroke limit upper value.
SwStrokeLimit_Lower	Software Stroke Limit Lower Value	Displays the software stroke limit lower value.
SwStrokeLimit_Target	Software Stroke Limit Target	Displays the software stroke limit target.
SwStrokeLimit_Override	Software Stroke Limit Override	Displays the software stroke limit valid/invalid status. <ul style="list-style-type: none">• DISABLE: Check disabled• ONLY_INSIDE: Disables the check only for movement toward the setting range.• Other than the above: Check enabled (no disable request)


Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
SwStrokeLimit_Override	Software Stroke Limit Override	Temporarily switches enabled/disabled of the software stroke limit. <ul style="list-style-type: none">• DISABLE: Check disabled• ONLY_INSIDE: Disables the check only for movement toward the setting range.• Other than the above: Check enabled (no disable request)

Definition of movable range

Movable range differences by selection of set position and machine feed value

The following drawing shows the movable range of the workpiece when the software stroke limit function is used.




The set position or the machine feed value can be specified in the software stroke limit. (The cumulative current position cannot be specified.)

The following drawing shows the differences in the operation when the set position is used or when the machine feed value is used in the movable range limit check.

Ex.

When assuming the current value is 2000, and Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) is set to "5000".



• Current value changing

When the current value is changed by a new current value command from 2000 to 1000, the set position will change to 1000, but the machine feed value will stay the same at 2000.

Setting	Description
When the machine feed value is set at the limit	<p>The set position of 4000 (machine feed value: 5000) becomes the upper stroke limit.</p> <p>The diagram shows a horizontal axis with a 'Movable range' indicated by a dashed line and an arrow. A solid dot on the axis is labeled 'Set position' with the value '1000' below it. Another solid dot further to the right is labeled 'Machine feed value' with the value '2000' below it. An arrow points from the 'Machine feed value' dot down to the text 'Stop position'. A third solid dot at the far right of the axis is labeled 'Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper)' with the value '5000' below it.</p>
When the set position is set at the limit	<p>The set position of 5000 (machine feed value: 6000) becomes the upper stroke limit.</p> <p>The diagram shows a horizontal axis with a 'Movable range' indicated by a dashed line and an arrow. A solid dot on the axis is labeled 'Set position' with the value '2000' below it. Another solid dot further to the right is labeled 'Machine feed value' with the value '2000' below it. An arrow points from the 'Machine feed value' dot down to the text 'Stop position'. A third solid dot at the far right of the axis is labeled 'Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper)' with the value '5000' below it.</p>

When "3: Machine Feed Value (FeedMachinePosition)" is set in Software Stroke Limit Target (AxisName.Pr.SwStrokeLimit_Target), the movable range becomes an absolute range referenced on the home position. When "1: Set Position (SetPosition)" is set, the movable range becomes the relative range from the set position.

■ When selecting the set position when the ring counter is valid


- Set position

The storing range of the set position is shown below.

Monitor data	Range
Set Position (<u>AxisName.Md.SetPosition</u>)	Ring counter lower value ≤ Set position < Ring counter upper value

Ex.

When the ring counter lower limit value is "0.0" and the ring counter upper limit value is "360.0", the set position address becomes the ring address of "0.0 to 359.999...".



- Setting the software stroke limit

The setting range of the software stroke limit upper/lower value is shown below.



Parameter	Setting range
Software Stroke Limit Upper Value (<u>AxisName.Pr.SwStrokeLimit_Upper</u>)	Ring counter lower value < Setting value ≤ Ring counter upper value
Software Stroke Limit Lower Value (<u>AxisName.Pr.SwStrokeLimit_Lower</u>)	Ring counter lower value ≤ Setting value < Ring counter upper value

Movable range: Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower) ≤ Set position < Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper)

- Details of the movable range

The movable range varies as shown below depending on the relationship between Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) and Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower).

Movable range	Description
Software Stroke Limit Upper Value (<u>AxisName.Pr.SwStrokeLimit_Upper</u>) > Software Stroke Limit Lower Value (<u>AxisName.Pr.SwStrokeLimit_Lower</u>)	<p>Ring counter upper limit</p> <p>Ring counter lower limit</p> <p>Movable range</p> <p>Software Stroke Limit Upper Value (<u>AxisName.Pr.SwStrokeLimit_Upper</u>)</p> <p>Software Stroke Limit Lower Value (<u>AxisName.Pr.SwStrokeLimit_Lower</u>)</p>

Movable range	Description
Software Stroke Limit Upper Value (<u>AxisName</u> .Pr.SwStrokeLimit_Upper) < Software Stroke Limit Lower Value (<u>AxisName</u> .Pr.SwStrokeLimit_Lower)	 <p>Ring counter upper limit</p> <p>Ring counter lower limit</p> <p>Software Stroke Limit Lower Value (<u>AxisName</u>.Pr.SwStrokeLimit_Lower)</p> <p>Software Stroke Limit Upper Value (<u>AxisName</u>.Pr.SwStrokeLimit_Upper)</p>
Software Stroke Limit Upper Value (<u>AxisName</u> .Pr.SwStrokeLimit_Upper) = Software Stroke Limit Lower Value (<u>AxisName</u> .Pr.SwStrokeLimit_Lower)	 <p>Ring counter upper limit</p> <p>Ring counter lower limit</p> <p>Software Stroke Limit Upper Value (<u>AxisName</u>.Pr.SwStrokeLimit_Upper)</p> <p>Software Stroke Limit Lower Value (<u>AxisName</u>.Pr.SwStrokeLimit_Lower)</p> <p>Positioning which exceeds the value set to Software Stroke Limit Upper Value (<u>AxisName</u>.Pr.SwStrokeLimit_Upper) and Software Stroke Limit Lower Value (<u>AxisName</u>.Pr.SwStrokeLimit_Lower) cannot be executed.</p> <p>• In the case of "Set position = Software Stroke Limit Upper Value (<u>AxisName</u>.Pr.SwStrokeLimit_Upper) = Software Stroke Limit Lower Value (<u>AxisName</u>.Pr.SwStrokeLimit_Lower), the operation within "movable range" shown in the above figure is possible on the judgment that the set position is at the software stroke limit lower value (position A in the above figure).</p>

■When selecting the set position or the machine feed value when the ring counter is invalid

- Machine feed value

The storing range of the machine feed value is shown below.

Monitor data	Storing range
Machine Feed Value (<u>AxisName</u> .Md.FeedMachinePosition)	$-10000000000.0 \leq \text{Machine feed value} < 10000000000.0$

- Setting the software stroke limit

The setting range of the software stroke limit upper/lower value is shown below.

Parameter	Setting range
Software Stroke Limit Upper Value (<u>AxisName</u> .Pr.SwStrokeLimit_Upper)	Software Stroke Limit Lower Value (<u>AxisName</u> .Pr.SwStrokeLimit_Lower) < Setting range ≤ 10000000000.0
Software Stroke Limit Lower Value (<u>AxisName</u> .Pr.SwStrokeLimit_Lower)	$-10000000000.0 \leq \text{Setting range} < \text{Software Stroke Limit Upper Value } (\text{AxisName.Pr.SwStrokeLimit_Upper})$

Movable range: Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower) $\leq$ Machine feed value < Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper)

Invalidating the software stroke limit

To invalidate the software stroke limit, set "-1: Invalid" in Software Stroke Limit Target (AxisName.Pr.SwStrokeLimit_Target). By setting "-1: Invalid (Invalid)", the software stroke limit check is not executed in all controls regardless of the setting values of Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) and Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower).

Returning from outside the software stroke limit range

The axis cannot start outside the software stroke limit range while the software stroke limit is valid.

After setting ONLY_INSIDE (Check disabled for movement returning to the range) or DISABLE (Check disabled) in Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override), execute the axis operation to return to the movable range. Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) is case-sensitive

Point


- In Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override), the software stroke limit can be temporarily disabled without changing the settings of Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) and Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower).
- In Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override), only the check in the returning enable direction can be disabled from outside the software stroke limit range. By disabling it only in the returning enable direction to the movable range, a motion to unexpected directions can be prevented.
- If a start or multiple start occurs while the software stroke limit is disabled by Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override), "Start when SW Stroke Limit is Disabled" (event code: 07F5) is recorded in the event history.

■Returning enable direction to the movable range


- When setting ONLY_INSIDE (Check disabled for movement returning to the range) in Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override), movement in the returning enable direction from outside the software stroke limit range to the movable range is allowed.
- The returning enable direction from outside the software stroke limit range means the direction in which the axis can return to the movable range without exceeding the ring counter value.
- If the axis operates to the direction to exceed the ring counter value from outside the software stroke limit range, "Software Stroke Limit Over (start Position)" (error code: 1A01H) or "Software Stroke Limit Over (Target Position)" (error code: 1A00H) will occur, and the axis will not start.
- Also, even if it is the returning enable direction, when an address which is outside the software stroke limit range exceeding the movable range is specified as the target position, "Software Stroke Limit Over (Target Position)" (error code: 1A00H) will be detected, and the axis will not start.
- To return to the movable range ignoring the returning enable direction, set DISABLE (Check disabled) in Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override) and carry out a move to the movable range.

■Returning enable direction when setting ONLY_INSIDE (Check disabled for movement returning to the range) in Software Stroke Limit Override (AxisName.Cd.SwStrokeLimit_Override)

- Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) > Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower)



- Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) < Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower)



Checking the software stroke limit enabled/disabled

- In the monitor Software Stroke Limit Override (AxisName.Md.SwStrokeLimit_Override), the software stroke limit check enabled/disabled status can be checked.
- Software Stroke Limit Override (AxisName.Md.SwHwStrokeLimit_Override) imports setting values of Software Stroke Limit Override (AxisName.Md.SwStrokeLimit_Override) at PLC READY from OFF to ON, at start, and at multiple start, and updates as in the table below.

Software Stroke Limit Target (<u>AxisName</u> .Pr.SwStrokeLimit_Target)	Software Stroke Limit Override (<u>AxisName</u> .Cd.SwStrokeLimit_Override)	Software Stroke Limit Override (<u>AxisName</u> .Md.SwStrokeLimit_Override)
-1: Invalid (Invalid)	—	DISABLE: Check disabled
1: Set position (SetPosition) 3: Machine feed value (FeedMachinePosition)	Other than the following: No disable request DISABLE: Check disabled ONLY_INSIDE: Check disabled for movement returning to the range	Display is blank: No disable request DISABLE: Check disabled ONLY_INSIDE: Check disabled for movement returning to the range

Specifications of the software stroke limit check

The software stroke limit check is carried out at executing the motion FB and during control.

The following table shows the check details of the software stroke limit.

Check details	Check timing	Processing when an error occurs
An error shall occur if the target address is outside the software stroke limit range.	When executing the motion FB which has the "target address"	"Software Stroke Limit Over (Target Position)" (error code: 1A00H) is output and the axis does not start.
An error shall occur if the start address is outside the software stroke limit range.	When executing the motion FB	"Software Stroke Limit Over (Start Position)" (error code: 1A01H) is output and the axis does not start.
An error shall occur if the current value is outside the software stroke limit range during control.	During control	"Software Stroke Limit Over (Forward Direction)" (error code: 1A03H) or "Software Stroke Limit Over (Reverse Direction)" (error code: 1A04H) is output and the stop processing is executed.*1

*1 The error occurs when detecting a command to the address outside the software stroke limit range, and the stop processing is executed. To stop within the software stroke limit range, set to immediately stop.

The checking details of the following functions are different from the above.

- Homing control ( Page 203 Precautions)
- Multiple axes positioning data operation ( Page 262 Software stroke limit)

Precautions

- Homing must be executed beforehand for the software stroke limit function to function properly.
- If Software Stroke Limit Upper Value (AxisName.Pr.SwStrokeLimit_Upper) or Software Stroke Limit Lower Value (AxisName.Pr.SwStrokeLimit_Lower) is outside the setting range, "Out of Parameter Range" (error code: 1D80H) will be detected.
- During interpolation control, the software stroke limit check is executed to all current values of the interpolation axes. When an error occurs in any axis, all axes will not start.
- When "3: Machine Feed Value (FeedMachinePosition)" is set as the setting value of Software Stroke Limit Target (AxisName.Pr.SwStrokeLimit_Target) to the axis type which does not have Machine Feed Value (AxisName.Md.FeedMachinePosition), "Out of Parameter Range" (error code: 1D80H) will be detected.

8.4 Hardware Stroke Limit

In the "hardware stroke limit function", limit switches are set at the upper/lower limit of the physical movable range, and the control is stopped by the input of a signal from the limit switch.

Damage to the machine can be prevented by stopping the control before the upper/lower limit of the physical movable range is reached.

WARNING

- The negative logic (b-contact) is recommended for wiring the hardware stroke limit. If the positive logic (a-contact) is used, a serious accident may occur when disconnection or sensor failure occurs.
- To use the hardware stroke limit function, the add-on ExternalSignal must be valid. In case the add-on is not installed or invalid, the axis does not stop nor an error is not outputted even if the signal is inputted.

For details on the signals that can be used in the hardware stroke limit, refer to the following.

 Page 424 External Signal Selection

Operation of this function for each system status

○: Possible, △: Possible (restricted)

Status	Operation availability
STOP	○
RUN	○
Moderate error	△ ^{*1}
Major error	△ ^{*1}

^{*1} Depending on the error, it may not be possible to send the FLS/RLS signal.

When a moderate or major error occurs, the motion system notifies the device station that an error has been detected in the CPU operating status. For details on the operation of the device station when an error is detected, refer to each device station manual.

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
HwStrokeLimit_FlsSignal	Upper Limit Signal	<p>Sets a signal using the upper limit signal (FLS). Upper limit signal (HwStrokeLimit_FlsSignal) is the structure of SIGNAL_SELECT type. The fetch timing of the label is at the system start, and the detection timing of the signal is the axis operation cycle. For details on SIGNAL_SELECT type, refer to the following.  Page 426 SIGNAL_SELECT structure The specific setting and the operation of this signal are shown below.</p> <p>■I/O Number (StartIO) Ignores the input value.</p> <p>■Target (Target) If the target is unspecified, it is regarded as invalid signal and it is always in the signal undetection status. Further, Hardware Stroke Limit Override (<u>AxisName</u>.Md.HwStrokeLimit_Override) is not imported. Only [VAR], [DEV], and [CONST] can be specified for the data type. *: When unavailable data is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■Signal Detection Method (Detection) The specification is allowed at the following level detection only.</p> <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel) <p>*: When a value outside the range set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■Compensation Time (CompensationTime) Ignores the input value.</p> <p>■Filter Time (FilterTime) Setting range is 0.0 to +5.0 [s]. *: When a value outside the range is set, "Out of Filter Time Setting Range of Each Axis Signal Warning" ("warning code: 0D24H) occurs, and operates at the filter time 0.0.</p>
HwStrokeLimit_RlsSignal	Lower Limit Signal	<p>Sets a signal using the lower limit signal (RLS). Lower limit signal (HwStrokeLimit_RlsSignal) is the structure of SIGNAL_SELECT type. The fetch timing of the label is at the system start, and the detection timing of the signal is the axis operation cycle. For details on SIGNAL_SELECT type, refer to the following.  Page 426 SIGNAL_SELECT structure The specific setting and the operation of this signal are shown below.</p> <p>■I/O Number (StartIO) Ignores the input value.</p> <p>■Target (Target) If the target is unspecified, it is regarded as invalid signal and it is always in the signal undetection status. Further, Hardware Stroke Limit Override (<u>AxisName</u>.Md.HwStrokeLimit_Override) is not imported. Only [VAR], [DEV], and [CONST] can be specified for the data type. *: When unavailable data is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■Signal Detection Method (Detection) The specification is allowed at the following level detection only.</p> <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel) <p>*: When edge detection specification is set, "Out of Parameter Range (Axis)" (error code: 1D80H) occurs.</p> <p>■Compensation Time (CompensationTime) Ignores the input value.</p> <p>■Filter Time (FilterTime) Setting range is 0.0 to +5.0 [s]. *: When a value outside the range is set, "Out of Filter Time Setting Range of Each Axis Signal Warning" (warning code: 0D24H) occurs, and operates at the filter time 0.0.</p>

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
HwStrokeLimit_FlsStatus	Upper Limit Signal Status	Displays the detection status of the upper limit signal (FLS). <ul style="list-style-type: none">• FALSE: Detecting the upper limit signal (FLS)• TRUE: Not detecting the upper limit signal (FLS) *: Displays the detection state which reflects the signal detection method or the filter time but not the signal input state.
HwStrokeLimit_RlsStatus	Lower Limit Signal Status	Displays the detection status of the lower limit signal (RLS). <ul style="list-style-type: none">• FALSE: Detecting the lower limit signal (RLS)• TRUE: Not detecting the lower limit signal (RLS) *: Displays the detection state which reflects the signal detection method or the filter time but not the signal input state.
HwStrokeLimit_Override	Hardware Stroke Limit Override	Displays the acceptance status of the enabled/disabled switching command of the hardware stroke limit. <ul style="list-style-type: none">• DISABLE: Check disabled• ONLY_INSIDE: Disables the check only for movement toward the setting range.• Other than the above: Check enabled (no disable request)

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
HwStrokeLimit_Override	Hardware Stroke Limit Override	Switches the enabled/disabled of the hardware stroke limit. <ul style="list-style-type: none">• DISABLE: Check disabled• ONLY_INSIDE: Disables the check only for movement toward the setting range.• Other than the above: Check enabled (no disable request)


Hardware stroke limit check details

The check of hardware stroke limit range is carried out during executing and controlling the motion FB.

The following table shows the check details of the hardware stroke limit.

Check details	Check timing	Processing when an error occurs
Signal input from the upper limit signal (FLS) is detected at start.	At start	"FLS Signal Detection (at Start)" (error code: 1A2DH) occurs and the axis does not start.
Signal input from the lower limit signal (RLS) is detected at start.	At start	"RLS Signal Detection (at Start)" (error code: 1A2EH) occurs and the axis does not start.
Signal input from the upper limit signal (FLS) is detected during control.	During control	"FLS Signal Detection (Controlling)" (error code: 1A2FH) occurs and the axis stops.* ¹
Signal input from the lower limit signal (RLS) is detected during control	During control	"RLS Signal Detection (Controlling)" (error code: 1A30H) occurs and the axis stops.* ¹

*¹ The axis stops according to the stop processing.



Point

While the limit switch is detected, the operation cannot be performed regardless of the detection direction/ movement direction.

Returning from outside the hardware stroke limit range

While the limit switch is detected, the operation cannot be performed regardless of the detection direction.

After setting ONLY_INSIDE (Check disabled for movement returning to the range) or DISABLE (Check disabled) in Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override), execute the axis operation to return to the controllable range.

Point

- When setting an item other than ONLY_INSIDE (Check disabled for movement returning to the range) and DISABLE (Check disabled) in Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override), the axis operates with "No disable request".

Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) is case-sensitive.


- If a start or multiple start occurs while the hardware stroke limit is disabled by Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override), "Start when HW Stroke Limit is Disabled" (event code: 07F6) is recorded in the event history.

Precautions

Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) is valid only in the hardware stroke limit processing on the Motion module side. The stroke limit processing on the drive unit side is not affected by Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override).

When setting ONLY_INSIDE (Check disabled for movement returning to the range)

The axis can start to the direction in which the limit switch has not been detected.



When setting DISABLE (Check disabled)

The axis can start regardless of the limit switch detection status.

Checking the hardware stroke limit enabled/disabled

- In Hardware Stroke Limit Override (AxisName.Md.HwStrokeLimit_Override), the hardware stroke limit check enabled/disabled status can be checked.
- Hardware Stroke Limit Override (AxisName.Md.HwStrokeLimit_Override) imports the setting value of Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override) at start and at multiple start, and updates as in the table below.

Hardware Stroke Limit Override (<u>AxisName</u> .Cd.HwStrokeLimit_Override)	Hardware Stroke Limit Override (<u>AxisName</u> .Md.HwStrokeLimit_Override)
DISABLE (Check disabled)	DISABLE (Disabling hardware stroke limit check)
ONLY_INSIDE (Check disabled for movement returning to the range)	ONLY_INSIDE (Disabling hardware stroke limit check, only the movement toward the range.)
Other than the above	No display (No disabling request. Hardware stroke limit check is enabled.)

Precautions

- Install the upper limit signal (FLS) in the direction in which the set position increases, and install the lower limit signal (RLS) in the direction in which the set position decreases. If inverting the install positions of the upper limit signal (FLS)/lower limit signal (RLS), hardware stroke limit function cannot be operated properly.
- The upper limit signal (FLS)/lower limit signal (RLS) detected on the Motion module can be sent to the servo amplifier. For details on the setting method at connecting MR-J5(W)-G, refer to the following.

☞ Page 732 Using methods

Point

- The Motion module sends the signals as "FALSE: Detecting the signal", "TRUE: Not detecting the signal" to the servo amplifier. Therefore, the servo amplifier side must be set by using "the negative logic (b-contact)" to receive the signal.
- When labeling the data sent from the Motion module, the sent data is overwritten with the label value and the detection state cannot be sent to the servo amplifier. To send the data to the servo amplifier, do not label the data.

- The LSP/LSN signal input to the servo amplifier when connecting to MR-J5(W)-G can be set as the hardware stroke limit signal. For details on the setting method, refer to the following.
- ☞ Page 732 Using methods
- Depending on the setting of "Limit switch enabled status selection" (PD41.2) of the servo parameter "Function selection D-4(PD41)" when connecting to MR-J5(W)-G, the operation differs at LSP/FLS or LSN/RLS signal detection.

Setting	Operation
When "0: Limit switch always enabled"	The drive unit side executes the stop processing, and then turns to servo-lock status (Statusword Bit12: OFF) and the drive unit will ignore the motion system command. The motion system can stop the command by enabling Driver Command Discard Detection Setting (<u>AxisName</u> .Pr.StopOption_DriverTargetIgnored).
When "1: Enabled only for homing mode" or the drive unit is in the Homing mode	The stop processing will be executed on the drive unit side. When the drive unit is in other than the Homing mode, the signal will be ignored so set it to stop by motion system using hardware stroke limit function.


- When "Limit switch enabled status selection (PD41.2)" of servo parameter "Function selection D-4 (PD41)" is "0: Limit switch always enabled", the stop will be executed ignoring the command from the motion system at limit switch detection. So when using MR-J5(W)-G, it is recommended to set "1: Enabled only for homing mode", and "Sensor input method selection (PD41.3)" to "1: Input from controller".

When setting "0: Limit switch always enabled", the command on the Motion module side needs to be stopped, be sure to enable Driver Command Discard Detection Setting (AxisName.Pr.StopOption_DriverTargetIgnored).

The following shows an operation example.

Ex.

When detecting a limit signal at the drive unit side



- *1 When the LSP/FLS or LSN/RLS signal is detected, the stop process is executed by the drive unit. When Driver Command Discard Detection Setting (AxisName.Pr.StopOption_DriverTargetIgnored) is enabled, the motion system will detect "Driver Command Discard Detection" (error code: 1AE6H) and execute the command stop. For details on the setting, refer to the following.
 ☞ Page 163 Stop
- *2 After completion of the stop process on the motion system side, it stops with the status when Actual Position (AxisName.Md.ActualPosition) deviates from Set Position (AxisName.Md.SetPosition). (The position command from the motion system to the outside of the stroke limit is ignored in the drive unit.)
- *3 After stopped and when axis control is performed to the direction toward the inside of the stroke limit, the position command (the set position and machine feed value) and set velocity of the motion system are updated. However, the servo motor does not operate.
- *4 When the position command from the motion system becomes "the command position where the LSP/FLS or LSN/RLS signal is detected", the servo motor starts the operation to the inside of the stroke limit.

Point

- To stop holding the relation between the master axis and the slave axis of the axes group and the synchronous control when detecting the stroke limit of the drive unit, set "Limit switch enabled status selection (PD41.2)" of the servo parameter "Function selection D-4 (PD41)" to "1: Enabled only for homing mode".
- When the signal is turned ON (limit signal OFF) in the status when the actual position deviates from the position command with the stop by the stroke limit detection of the drive unit, the motor makes rapid movement to the position command of the motion system. Restore the deviation between the actual position and the position command by axis control to the inside of the stroke limit. (Set the servo OFF status, so that restoring the position command to the actual position by follow up is possible. After the restoration, set the servo ON again and move the motor to the inside of the stroke limit with the axis control.)
- When the command position of the motion system stops at the stroke limit side closer than the actual position by the stroke limit detection of the drive unit and the axis control is performed to the inside of the stroke limit, the operation of the actual position follows the command position from the motion system.

9 FUNCTIONS RELEVANT TO VELOCITY

9.1 Acceleration/deceleration Processing Function

The acceleration/deceleration processing function adjusts the acceleration/deceleration of each motion control to the acceleration/deceleration curve suitable for device.


Acceleration/deceleration method

The following methods can be selected for the acceleration/deceleration method. When a value outside the range is set in the acceleration/deceleration method, "Out of Acceleration/Deceleration Method Range" (error code: 1AA9H) will occur and the axis will not start.

Acceleration/deceleration method	Description
Acceleration/deceleration specification method (Default)	An acceleration/deceleration method using Acceleration (Acceleration), Deceleration (Deceleration), and Jerk (Jerk) specified in the FB.
Acceleration/deceleration time-fixed method	An acceleration/deceleration method using the acceleration/deceleration time specified in the FB regardless of the velocity.


■Trapezoidal acceleration/deceleration

When "0.0" is set in the jerk, the curve is called the trapezoidal acceleration/deceleration. The velocity shows a trapezoidal waveform.




■Jerk acceleration/deceleration

When a value other than "0.0" is set in the jerk, the curve is called the jerk acceleration/deceleration. The velocity shows a S-shaped waveform.



Jerk

Jerk is the temporal change ratio of the acceleration or deceleration. The unit is "command unit (U)/s³". When the jerk is set, since the velocity waveform shows a S-shape and the axis can smoothly accelerate and decelerate at the start and the end of acceleration and deceleration, it can reduce the burden on the motor and impact on the machine.



■Jerk applying time/Jerk applying ratio

The sum of the time required to reach the target acceleration after startup and the time from the target acceleration to the acceleration 0 at the end of acceleration is called the jerk applying time. The ratio of jerk applying time to acceleration (deceleration) time is called the jerk applying ratio.


The jerk applying time and the jerk applying ratio can be calculated with the following formula.

- Jerk applying time

$$\text{Jerk applying time} = 2 \times \text{Target acceleration} \div \text{Jerk}$$

- Jerk applying ratio

$$\text{Jerk applying ratio} = (\text{Jerk applying time} \div \text{Acceleration time}) \times 100 [\%]$$



Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
VelocityLimit_Positive	Positive Direction Velocity Limit Value	Sets the positive direction velocity limit value. For details, refer to the following.  Page 388 Velocity Limit
VelocityLimit_Negative	Negative Direction Velocity Limit Value	Sets the negative direction velocity limit value. For details, refer to the following.  Page 388 Velocity Limit
VelocityLimit_OverOperation	Operation Setting at Velocity Limit Value Exceeded	Sets the operation at velocity limit value exceeded. For details, refer to the following.  Page 388 Velocity Limit
AccelerationLimit	Acceleration Limit Value	Sets the acceleration limit value. • 0.0000, positive numbers from 0.0001 to 2147483647.0 U/s ² * *: When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it doesn't limit the acceleration. *: When "0.0000" is set, it does not limit the acceleration.
DecelerationLimit	Deceleration Limit Value	Sets the deceleration limit value. • 0.0000, positive numbers from 0.0001 to 2147483647.0 U/s ² * *: When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it doesn't limit the deceleration. *: When "0.0000" is set, it does not limit the deceleration.
JerkLimit	Jerk Limit Value	Sets the jerk limit value. • 0.0000, positive numbers from 0.0001 to 2147483647.0 U/s ³ * *: When "0.0000" is set, it does not limit the jerk.
AccelerationZeroBehavior	Operation Selection at Start Acceleration/Deceleration 0	Selects behavior when "0.0" is set as the acceleration, the deceleration, or the acceleration/deceleration time at start. • -1: Error (Not Started) (ACCErrror) • 1: Maximum Acceleration/Deceleration (MaximumAcceleration)
OverrunOperation	Operation Setting at Overrun	Sets the operation performed when the target position is exceeded during positioning operation. • 1: Immediate Stop (ImmediateStop) • 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)
VelocityBias	Velocity Bias Value	Sets the velocity bias value for each axis. • 0.0000, 0.0001 to 2500000000.0 *: When "0.0000" is set, the velocity bias is disabled.

*1 When a real number less than 0.0001 is set, the value is imported as "0.0000".

Axis monitor data (AxisName.Md)

Variable/Structure name	Name	Details
CommandedAcceleration	Commanded Acceleration	Stores the acceleration specified by users. (Unit: U/s ²) When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it stores the specified acceleration/deceleration time. (Unit: s) During axes group operation, stores "0.0" in Commanded Acceleration (<u>AxisName.Md.CommandedAcceleration</u>) of the configuration axis.
CommandedDeceleration	Commanded Deceleration	Stores the deceleration specified by users. (Unit: U/s ²) When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it is an illegal value. During axes group operation, stores "0.0" in Commanded Deceleration (<u>AxisName.Md.CommandedDeceleration</u>) of the configuration axis.
TargetAcceleration	Target Acceleration	Stores the acceleration that is maximum during acceleration. (Unit: U/s ²) During axes group operation, stores "0.0" in Target Acceleration (<u>AxisName.Md.TargetAcceleration</u>) of the configuration axis.
TargetDeceleration	Target Deceleration	Stores the deceleration that is maximum during deceleration. (Unit: U/s ²) During axes group operation, stores "0.0" in Target Deceleration (<u>AxisName.Md.TargetDeceleration</u>) of the configuration axis.
SetAcceleration	Set Acceleration	Stores the command output acceleration. It is the acceleration/deceleration calculated from the difference of set velocity. (Unit: U/s ²)* ¹ The status of acceleration/deceleration varies depending on the movement direction and the value of the set acceleration (<u>AxisName.Md.SetAcceleration</u>).* ² "0.0" is stored when the target velocity is reached. During axes group operation, stores the set acceleration of the configuration axis.

Variable/Structure name	Name	Details
CommandedJerk	Commanded Jerk	Stores the jerk specified by users. (Unit: U/s ³) During axes group operation, stores "0.0" in Commanded Jerk (<u>AxisName</u> .Md.CommandedJerk) of the configuration axis.
InVelocity	Target Velocity Reached	Displays whether the set velocity has reached the target velocity or not. During axes group operation, stores FALSE in Target Velocity Reached (<u>AxisName</u> .Md.InVelocity) of the configuration axis. • FALSE: Not reached • TRUE: Reached
AutoDeceleration	Automatically Decelerating	Displays the status of auto deceleration processing. TRUE is stored while the auto deceleration processing is executed. When the multiple start is executed, TRUE is set while the auto deceleration processing is executed during the last positioning point execution. FALSE is set when the control change is performed. During axes group operation, stores FALSE in Automatically Decelerating (<u>AxisName</u> .Md.AutoDeceleration) of the configuration axis. • FALSE: Not during auto deceleration • TRUE: During auto deceleration
VelocityBias	Velocity Bias Value	Stores the setting value of the velocity bias value (<u>AxisName</u> .Pr.VelocityBias) imported at READY ON.

*1 The Values to be stored include the error, because the floating point type error occurs.

*2 The status of acceleration/deceleration depending on the movement direction and the value of the set acceleration (AxisName.Md.SetAcceleration) is shown below.

Movement direction	Set acceleration (<u>AxisName</u> .Md.SetAcceleration)	Status of acceleration/deceleration
Positive direction (Address increase direction)	0.0	Stop, or at a fixed speed
	Positive value	During acceleration
	Negative value	During deceleration
Negative direction (Address decrease direction)	0.0	Stop, or at a fixed speed
	Positive value	During deceleration
	Negative value	During acceleration

Axes group parameter (AxesGroupName.Pr)

Variable/Structure name	Name	Details
VelocityLimit	Velocity Limit Value	Sets the velocity limit value. For details, refer to the following.  Page 388 Velocity Limit
AccelerationLimit	Acceleration Limit Value	Sets the acceleration limit value. • 0.0000, positive numbers from 0.0001 to 2147483647.0 U/s ² *1 *: When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it limits the acceleration calculated from the specified acceleration/deceleration time. *: When "0.0000" is set, it does not limit the acceleration.
DecelerationLimit	Deceleration Limit Value	Sets the deceleration limit value. • 0.0000, positive numbers from 0.0001 to 2147483647.0 U/s ² *1 *: When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it limits the deceleration calculated from the specified acceleration/deceleration time. *: When "0.0000" is set, it does not limit the acceleration.
JerkLimit	Jerk Limit Value	Sets the jerk limit value. • 0.0000, positive numbers from 0.0001 to 2147483647.0 U/s ³ *1 • When "0.0000" is set, it does not limit the jerk.
AccelerationZeroBehavior	Operation Selection at Start Acceleration/Deceleration 0	Selects the operation when "0.0" is set as the acceleration, the deceleration, or the acceleration/deceleration time at start. • -1: Error (Not Started) (ACCErrror) • 1: Maximum Acceleration/Deceleration (MaximumAcceleration)
OverrunOperation	Operation Setting at Overrun	Sets the operation performed when the target position is exceeded during operation. • 1: Immediate Stop (ImmediateStop)
VelocityBias	Velocity Bias Value	Sets the velocity bias value for each axis. • 0.0000, 0.0001 to 2500000000.0 *: When "0.0000" is set, the velocity bias is disabled.

*1 When a real number less than 0.0001 is set, the value is imported as "0.0000".

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
CommandedAcceleration	Commanded Acceleration	Stores the acceleration specified by users. (Unit: U/s ²) When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it stores the acceleration/deceleration time.
CommandedDeceleration	Commanded Deceleration	Stores the deceleration specified by users. (Unit: U/s ²) When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is set in the acceleration/deceleration method, it is an illegal value.
TargetAcceleration	Target Acceleration	Stores the acceleration that is maximum during acceleration. (Unit: U/s ²)
TargetDeceleration	Target Deceleration	Stores the deceleration that is maximum during deceleration. (Unit: U/s ²)
SetAcceleration	Set Acceleration	Stores the command output acceleration. It is the acceleration/deceleration calculated from the difference of set velocity. (Unit: U/s ²)* ¹ The value is positive when acceleration changes to the positive direction (Address increase direction), and the value is negative when acceleration changes to the negative direction (Address decrease direction).
CommandedJerk	Commanded Jerk	Stores the jerk specified by users. (Unit: U/s ³)
InVelocity	Target Velocity Reached	Displays whether the set velocity has reached the target velocity or not. <ul style="list-style-type: none"> • FALSE: Not reached • TRUE: Reached
AutoDeceleration	Automatically Decelerating	Displays the status of auto deceleration processing. "TRUE" is stored while the auto deceleration processing is executed. When the multiple start is executed, TRUE is set while the auto deceleration processing is executed during the last positioning point execution. FALSE is set when the control change is performed. <ul style="list-style-type: none"> • FALSE: Not automatically decelerating • TRUE: Automatically decelerating
VelocityBias	Velocity Bias Value	Stores the setting value of the velocity bias value (AxesGroupName.Pr.VelocityBias) imported at READY ON.

*1 The Values to be stored include the error, because the floating point type error occurs.

Settings of motion FB

The acceleration/deceleration method can be selected in "bit0 to 2" of Options (Options) of the motion FB.

The details of the bits are shown below.

Bit	Function description
0 to 2	Acceleration/deceleration method setting <ul style="list-style-type: none"> • 0: Acceleration/deceleration specification method (mcAccDec) • 1: Acceleration/deceleration time-fixed method (mcFixedTime) For details, refer to the following.  Page 358 Acceleration/deceleration Processing Function
3 to 31	The function differs depending on the FB.

Whether a method can be selected or not differs depending on the FB. For details, refer to the following.


 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Acceleration/deceleration method

Acceleration/deceleration specification method

When "0: Acceleration/deceleration specification method (mcAccDec)" is selected in the Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, the acceleration, the deceleration, and the jerk can be set.

■Trapezoidal acceleration/deceleration



○: Operation possible, ×: Operation not possible

Section		Process description	Operation	
			Accelera tion	Decelera tion
A	Acceleration section	Accelerates at the target acceleration.	○	×
B	Fixed speed section	Controls at the target velocity. (Acceleration = 0.0)	×	×
C	Deceleration section	Decelerates at the target deceleration.	×	○


• Acceleration/deceleration time parameter calculation

○: Operation possible, ×: Operation not possible

Type	Item	Abbreviation	Description	Calculation formula	Operation	
					Accelera tion	Decelera tion
Specified value	Target velocity	V	—	—	○	○
	Target acceleration	A	—	—	○	×
	Target deceleration	Dec	—	—	×	○
Calculated value	Acceleration section time	AT	Time from the velocity 0.0 to the target velocity	$V \div A^{*1}$	○	×
	Deceleration section time	DT	Time to decelerate from the target velocity to the velocity 0.0	$V \div Dec^{*1}$	×	○

*1 This is the calculation formula when unit of V is [U/s]. When other than [U/s], calculate by converting into [U/s].


■ Jerk acceleration/deceleration



○: Operation possible, ×: Operation not possible

Section		Process description	Operation	
			Accelera tion	Decelera tion
A	Acceleration section 1	Accelerates by changing (increasing) the acceleration with the specified jerk from acceleration start to target acceleration.	○	×
B	Maximum acceleration section	Accelerates at the target acceleration.	○	×
C	Acceleration section 2	At the end of acceleration, accelerates by changing (decreasing) the acceleration by jerk specified from the target acceleration to acceleration 0.	○	×
D	Fixed speed section	Controls at the target velocity. (Acceleration = 0.0)	×	×
E	Deceleration section 1	Decelerates by changing (increasing) the deceleration with the specified jerk from deceleration start to the target deceleration.	×	○
F	Maximum deceleration section	Decelerates at the target deceleration.	×	○
G	Deceleration section 2	At the end of deceleration, decelerates by changing (decreasing) the deceleration by jerk specified from the target deceleration to deceleration 0.	×	○

• Acceleration/deceleration time parameter calculation



○: Operation possible, ×: Operation not possible

Section	Item	Abbreviation	Description	Calculation formula	Operation	
					Acceleration	Deceleration
Specified value	Target velocity	V	—	—	○	○
	Target acceleration*1	A	—	—	○	×
	Target deceleration*1	Dec	—	—	×	○
	Jerk	J	—	—	○	○
Calculated value	Acceleration section 1 time	A1T	Time obtained by dividing the jerk applying time of the acceleration section by 2	$A \div J$	○	×
	Acceleration section 2 time	A2T	Time obtained by dividing the jerk applying time of the acceleration section by 2	$A \div J$	○	×
	Maximum acceleration section time	A3T	Time of the maximum acceleration section.	$(V \div A) - (A \div J)^3$	○	×
	Acceleration time*2	AT	Time from velocity 0.0 to the target velocity	$A1T + A2T + A3T = (V \div A) + (A \div J)^3$	○	×
	Deceleration section 1 time	D1T	Time obtained by dividing the jerk applying time of the deceleration section by 2	$Dec \div J$	×	○
	Deceleration section 2 time	D2T	Time obtained by dividing the jerk applying time of the deceleration section by 2	$Dec \div J$	×	○
	Maximum deceleration section time	D3T	Time of the maximum deceleration section.	$(V \div Dec) - (Dec \div J)^3$	×	○
	Deceleration time*2	DT	Time to decelerate from the target velocity to velocity 0.0	$D1T + D2T + D3T = (V \div Dec) + (Dec \div J)^3$	×	○

*1 Target acceleration/target deceleration may be adjusted by acceleration/deceleration waveform adjustment. For details, refer to the following.

☞ Page 370 Acceleration/deceleration waveform adjustment when specifying jerk

*2 Acceleration time and deceleration time may be limited. For details, refer to the following.

☞ Page 375 Limit of acceleration time/deceleration time


*3 This is the calculation formula when unit of V is [s]. When other than [U/s], calculate by converting into [U/s].

- Jerk calculation

When the velocity and the acceleration of operation are fixed, the jerk can be calculated with the following formula by specifying the jerk applying ratio.

$$\text{Jerk (J)} = \frac{(2 - \text{Jerk applying ratio}) \times (\text{the square of acceleration (A)})}{\text{Jerk applying ratio} \times \text{Speed (V)}}$$

The acceleration section jerk applying ratio is the ratio of the jerk applying time to the acceleration time. The jerk applying time is the sum of the acceleration section 1 time and the acceleration section 2 time.



Ex.

When calculating the jerk with the following values set.


Item	Setting value
Velocity	7500 [mm/s]
Acceleration	10000 [mm/s ²]
Jerk applying ratio	0.5 (50%)

$$\text{Jerk (J)} = \frac{(2 - 0.5) \times 10000^2}{0.5 \times 7500} = 40000 \text{ [mm/s}^3\text{]}$$


The acceleration time can be calculated when the velocity, the acceleration, and the jerk are fixed. For details, refer to the following.

Page 364 Jerk acceleration/deceleration

$$\text{Acceleration time (AT)} = \frac{\text{Speed (AT)}}{\text{Acceleration (A)}} + \frac{\text{Acceleration (A)}}{\text{Jerk (J)}} = \frac{7500}{10000} + \frac{10000}{40000} = 1 \text{ [s]}$$



When the jerk applying ratio is big or the jerk is small, the acceleration time (deceleration time) becomes longer than that of the trapezoidal acceleration/deceleration. When the jerk applying ratio is 100%, the acceleration time (deceleration time) becomes doubled compared with the trapezoidal acceleration/deceleration. When setting the jerk, pay attention to the acceleration time (deceleration time).



Point

Since the velocity calculation is based on a given jerk, when the acceleration (deceleration) at FB execution and the target velocity are different from the acceleration (deceleration) used at calculating the jerk, the final acceleration time/deceleration time of control are calculated according to the calculation formula of the acceleration/deceleration time parameter.

If the jerk applying ratio exceeds 100% due to the acceleration (deceleration) or the target velocity at FB execution, the target velocity may be reached before the target acceleration is reached.


For details, refer to the following.

☞ Page 370 Acceleration/deceleration waveform adjustment when specifying jerk

Acceleration/deceleration time-fixed method

When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is selected in the Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, the acceleration/deceleration time is set in Acceleration (Acceleration), Deceleration (Deceleration), and Jerk (Jerk) are not used.

Calculates acceleration and deceleration from the acceleration/deceleration time at acceleration/deceleration. When a value smaller than one operation cycle other than 0.0000 is set as the acceleration/deceleration time, the target velocity is reached within one operation cycle.



○: Operation possible, ×: Operation not possible

Section		Process description	Operation	
			Accelera tion	Decelera tion
A	Acceleration section	Accelerates the acceleration time from the set velocity to the target velocity to be the acceleration/deceleration time.	○	×
B	Fixed speed section	Controls at the target velocity. (Acceleration = 0.0)	×	×
C	Deceleration section	Decelerates the deceleration time from the set velocity to the target velocity to be the acceleration/deceleration time.	×	○

• Acceleration/deceleration parameter calculation

○: Operation possible, ×: Operation impossible

Section	Item	Abbreviation	Description	Calculation formula	Operation	
					Acceleration	Deceleration
Specified value	Target velocity	V	—	—	○	○
	Acceleration/deceleration time ^{*1}	ADT	—	—	○	○
Calculated value	Current velocity	Vnow	The set velocity at target acceleration and target deceleration calculation	—	○	○
	Target acceleration ^{*2}	A	Acceleration from the current velocity to the target velocity ^{*3}	$(V - Vnow) \div ADT^{*4}$	○	×
	Target deceleration ^{*2}	Dec	Deceleration to decelerate from the current velocity to the target velocity ^{*3}	$(V - Vnow) \div ADT^{*4}$	×	○

*1 The deceleration time at automatic deceleration may be longer than the specified acceleration/deceleration time (ADT) due to the compensation of the remaining distance.

*2 It may exceed the acceleration limit value or the deceleration limit value. For details, refer to the following. If it exceeds the acceleration/deceleration range, it will be the upper limit value of the acceleration/deceleration.


☞ Page 373 Acceleration limit value/deceleration limit value

*3 The target velocity will be "0.0" at stop.

*4 This is the calculation formula when unit of V is [m/s]. When other than [m/s], calculate by converting into [m/s].

When the movement amount which cannot be accelerated up to the target velocity is specified at positioning operation, deceleration stop starts to the target position during acceleration by automatic deceleration. In this case, deceleration is recalculated with the velocity at automatic deceleration start.

Set acceleration/deceleration specification method to set time-fixed acceleration/deceleration at acceleration/deceleration.



Acceleration/deceleration waveform adjustment when specifying jerk


When the jerk acceleration/deceleration ($J \neq 0.0$) is specified, the acceleration waveform and the deceleration waveform are adjusted whether the values of the target velocity (V), the target acceleration (A), the target deceleration (Dec), and the jerk (J) satisfy the following condition or not.

Acceleration/deceleration	Condition
For acceleration	$V \geq \frac{A^2}{J}$
For deceleration	$V \geq \frac{Dec^2}{J}$

When the condition is satisfied

The target acceleration (deceleration) can be reached.
The maximum acceleration section time and the maximum deceleration section time are adjusted by the velocity, the acceleration, the deceleration, and the jerk, and the waveform changes to reach the target velocity at the end of acceleration.
For the acceleration time and the deceleration time, refer to the following.

 Page 363 Acceleration/deceleration method




When the condition is not satisfied

When accelerating to the target acceleration, the velocity exceeds the target velocity during acceleration. Therefore, the acceleration is adjusted to reach the target velocity at the end of acceleration. (The velocity does not reach the specified target acceleration (deceleration).)

When the acceleration is adjusted, there is no maximum acceleration section, and the acceleration waveform becomes a triangle. Also, the same adjustment is applied to the deceleration.

Term	Abbreviation	Description
Target acceleration before adjustment	A	Target acceleration before acceleration adjustment
Target acceleration	A'	Target acceleration after acceleration adjustment
Target deceleration before adjustment	Dec	Target deceleration before deceleration adjustment
Target deceleration	Dec'	Target deceleration after deceleration adjustment



The target acceleration (A') and the target deceleration (Dec') can be calculated with the following formula.

$$A' = \sqrt{V \times J}$$

$$\text{Dec}' = \sqrt{V \times J}$$

The target acceleration (A') and the target deceleration (Dec') after adjustment become smaller than the target acceleration (A) and the target deceleration (Dec) before adjustment.

The acceleration time and the deceleration time can be calculated with the following formula.

$$\text{Acceleration time (AT)} = (V \div A') + (A' \div J)$$

$$\text{Deceleration time (DT)} = (V \div \text{Dec}') + (\text{Dec}' \div J)$$

Operation when specifying acceleration/deceleration 0

When "0.0" is specified for the acceleration/deceleration, the operation differs at startup and the rest.

When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is selected in Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, the operation is the operation when "0.0" is specified for the acceleration/deceleration time. The operation is the same as specifying "0.0" for acceleration/deceleration.

Specifying "0.0" at start


Select the operation when "0.0" is specified for the acceleration and the deceleration in Operation Selection at Start Acceleration/Deceleration 0 (AxisName.Pr.AccelerationZeroBehavior). To operate by the vector velocity at interpolation control, follow Operation Selection at Start Acceleration/Deceleration 0 (AxesGroupName.Pr.AccelerationZeroBehavior).

■When selecting "-1: Error (Not Started) (ACCError)"

"Acceleration/Deceleration 0 Specified Operation Error at Start" (error code: 1A0CH) occurs, and the axis does not start.

■When selecting "1: Maximum Acceleration/Deceleration (MaximumAcceleration)"

If "0.0" is specified for the acceleration or the deceleration, an error will not occur. For acceleration, even if the jerk is set, trapezoidal acceleration/deceleration is operated and the acceleration/deceleration is performed in one operation cycle. In these cases, acceleration/deceleration is performed exceeding the acceleration limit value and deceleration limit value.



Precautions

Pay full attention when setting "1: Maximum Acceleration/Deceleration (MaximumAcceleration)", because operation is rapid motion.

Point

Operation when specifying acceleration/deceleration 0 is applied to acceleration/deceleration after override.

Specifying "0.0" other than at start

■At the acceleration change/At the deceleration change

When "0.0" is specified at the acceleration change or the deceleration change, "Out of Acceleration Range Warning" (warning code: 0D17H) or "Out of Deceleration Range Warning" (warning code: 0D18H) will occur, and thus no change will be accepted. The operation is continued at the target acceleration or the target deceleration before change.

■At multiple start

When "0.0" is specified for the acceleration or the deceleration in the multiple started FB, the target acceleration or the target deceleration of the previous FB is taken over.

Specifying "0.0" at stop processing

In MC_Stop (Forced Stop)/MC_GroupStop (Group Forced Stop) and the deceleration at stop setting, when "0.0" is specified for the deceleration, the axis immediately stops without an acceleration/deceleration.

Acceleration limit value/deceleration limit value

When "0: Acceleration/deceleration specification method (mcAccDec)" is selected in Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, acceleration/deceleration is limited by the acceleration/deceleration limit value.

When "1: Acceleration/deceleration time-fixed method (mcFixedTime)" is selected in Options of the FB, it is not limited. When "0.0" is specified for the acceleration/deceleration limit value, it is not limited as well.

Specify acceleration limit value and deceleration limit value in Acceleration Limit Value (AxisName.Pr.AccelerationLimit) and Deceleration Limit Value (AxisName.Pr.DecelerationLimit). To operate by the vector velocity at interpolation control, follow Acceleration Limit Value (AxesGroupName.Pr.AccelerationLimit) and Deceleration Limit Value (AxesGroupName.Pr.DecelerationLimit).

Operation

This operation is for the FB which has Acceleration (Acceleration) and Deceleration (Deceleration) of input variables. Acceleration/deceleration is limited at the following timing.

■At start

If exceeding the acceleration limit value or the deceleration limit value, "Acceleration Limit Value Over" (error code: 1A38H) or the "Deceleration Limit Value Over" (error code: 1A39H) will occur, and the axis will not start.

■At acceleration change/At deceleration change

If exceeding the acceleration limit value or the deceleration limit value by changing the acceleration or the deceleration, "Acceleration Limit Value Over Warning" (warning code: 0D06H) or "Deceleration Limit Value Over Warning" (warning code: 0D07H) will occur, and the change will not be accepted. The acceleration/deceleration operation before change will be continued.

■At multiple start

If the acceleration or the deceleration of the multiple started FB has exceeded the acceleration limit value or the deceleration limit value, "Acceleration Limit Value Over" (error code: 1A38H) or "Deceleration Limit Value Over" (error code: 1A39H) will occur, and the under-control FB will be interrupted and stopped. For details, refer to the following.

 Page 161 Precautions

■At stop processing

- When decelerating stop by MC_Stop (Forced Stop)/MC_GroupStop (Group Forced Stop)
When exceeding the deceleration limit value, "Deceleration Limit Value Over" (error code: 1A39H) occurs and the axis stops according to Stop Selection at Stop Cause Occurrence (AxisName(AxesGroupName).Pr.StopMode_General).
- When decelerating stop by stop cause other than MC_Stop (Forced Stop)/MC_GroupStop (Group Forced Stop)
When exceeding the deceleration limit value, "Deceleration Limit Value Over Warning" (warning code: 0D07H) occurs and the target deceleration becomes the deceleration limit value.

Jerk limit value

When the jerk acceleration/deceleration is ($J \neq 0.0$), Jerk is limited by a value specified in Jerk limit value (JerkLimit). When "0.0" is specified for the jerk limit value, the jerk is not limited.

Specify the jerk limit value in Jerk Limit Value (AxisName.Pr.JerkLimit). To operate by the vector velocity at interpolation control, follow Jerk Limit Value (AxesGroupName.Pr.JerkLimit).

Operation

This operation is for the FB which has Jerk (Jerk) of input variables. Jerk is limited at the following timing.

■At start

If the specified jerk at start exceed the jerk limit value, "Jerk Limit Value Over" (error code: 1A3AH) will occur, and the axis will not start.

■At multiple start

If the specified jerk in the multiple started FB has exceeded the jerk limit value, "Jerk Limit Value Over" (error code: 1A3AH) will occur, and the under-control FB will be interrupted and the axis will stop. For details, refer to the following.

☞ Page 161 Precautions

Limit of acceleration time/deceleration time

The acceleration time and the deceleration time are limited by 8400.0 [s].

When "0: Acceleration/deceleration specification method (mcAccDec)" is selected in Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, the acceleration time and the deceleration time calculated from the acceleration and the deceleration are limited. For a method of calculating the acceleration time and the deceleration time, refer to the following.

☞ Page 363 Acceleration/deceleration specification method

Operation

■At start

The operation at start with Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) is as follows.

- When "0: Acceleration/deceleration specification method (mcAccDec)"
If the acceleration time or the deceleration time exceeds 8400.0 [s], "Acceleration Time Over at Start" (error code: 1A0FH) or "Deceleration Time Over at Start" (error code: 1A10H) will occur, and the axis will not start.
- When "1: Acceleration/deceleration time-fixed method (mcFixedTime)"
When acceleration time and deceleration time exceeding 8400.0 [s] are specified, "Out of Acceleration/Deceleration Time Range" (error code: 1A0DH) occurs, and the axis will not start.

■At control change

Limits time from the issuance of the control change instruction until Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) as follows.

- When "1: Acceleration/deceleration time-fixed method (mcFixedTime)"
Carrying out a velocity change, an acceleration change, or a deceleration change may exceed 8400.0 [s]. In this case, "Acceleration Time Limit Over Warning" (warning code: 0D04H) or "Deceleration Time Limit Over Warning" (warning code: 0D05H) occurs, and operates as below.

Warning	Operation
Acceleration Time Limit Over Warning (warning code: 0D04H)	changes to the velocity and deceleration are not accepted. It keeps operating with the previous velocity and deceleration.
Deceleration Time Limit Over Warning (warning code: 0D05H)	changes to the velocity and deceleration are not accepted. It keeps operating with the previous velocity and deceleration.

- When "1: Acceleration/deceleration time-fixed method (mcFixedTime)"
When the acceleration/deceleration time change exceeding 8400.0 [s] is performed, "Out of Acceleration/Deceleration Time Range Warning" (warning code: 0D19H) occurs, and the axis will not accept the acceleration/deceleration time change. When the velocity change is performed at the same time, the axis operates with previous acceleration time and deceleration time. If the velocity change is not performed at the same time, the axis keeps the current acceleration/deceleration operation during accelerating/decelerating.


■When the acceleration time/deceleration time is within one operation cycle

When the acceleration time or the deceleration time is less than one operation cycle due to the specified velocity, acceleration, deceleration, and jerk, the velocity reaches the target velocity within one operation cycle regardless of the jerk.

Automatic deceleration

Decelerating to a velocity of "0.0" to stop at the specified target position is called automatic deceleration. During automatic deceleration, Automatically Decelerating (AxisName.Md.AutoDeceleration) is TRUE. When automatic deceleration is performed, the deceleration may go ahead of or behind the target deceleration. Therefore, Set Acceleration (AxisName.Md.SetAcceleration) may exceed Target Deceleration (AxisName.Md.TargetDeceleration). Besides, the current velocity may be continued due to the compensation of the remaining distance during automatic deceleration of the trapezoidal acceleration/deceleration and at acceleration/deceleration time-fixed method. In this case, Set Acceleration (AxisName.Md.SetAcceleration) will be "0.0".

Item	Description
Deceleration stop distance	Distance required to a deceleration stop to the target position
Total movement amount	Movement amount from start of the FB to reaching the target position
Cumulative movement amount	Movement amount from start of the FB to the current position
Next Δ movement amount	Movement amount in the next operation cycle



Automatic deceleration starts when the following condition is satisfied.


Deceleration stop distance > Total movement amount - Cumulative movement amount - Next Δ movement amount

- When a multiple start is in execution, automatic deceleration processing is performed when decelerating to the target position during execution of the final positioning point.
- The automatic deceleration flag turns OFF at the deceleration caused by the stop command or the stop cause occurrence.

Changing control of jerk acceleration/deceleration

Acceleration/deceleration operation at changing control immediately changes the acceleration and the deceleration for the trapezoidal acceleration/deceleration ($J = 0.0$).

For the jerk acceleration/deceleration ($J \neq 0.0$), when a control change is carried out during acceleration or deceleration, acceleration/deceleration will be performed taking over the previous acceleration (deceleration). Therefore, if a control change that causes the deceleration operation is executed during acceleration, the operation will continue to accelerate until the acceleration becomes 0 without decelerating immediately.



Item	Description
Velocity change	Indicates the following operations <ul style="list-style-type: none"> • For retrigger/continuous update the velocity input variables • For executing the velocity override factor change
Acceleration change	Indicates the following operations <ul style="list-style-type: none"> • For retrigger/continuous update the acceleration input variables • For executing the acceleration override factor change
Deceleration change	Indicates the following operations <ul style="list-style-type: none"> • For retrigger/continuous update the deceleration input variables • For executing the acceleration override factor change

The following shows the specific operation of the jerk acceleration/deceleration during control change.

Target position change

The specific acceleration/deceleration operation of jerk acceleration/deceleration is shown below. For the basic control description, refer to the following.


Page 419 Target position/movement distance change

Item	Abbreviation	Description
Current position	Pnow	The position when a target position change instruction is issued
Target position before change	P	The target position before the target position is changed
Target position	P'	The target position after the target position was changed

■When the operation direction is reversed

When the target position after change is specified in the front of the current position, the operation direction is reversed. The axis accelerates to the acceleration of 0, then decelerates to the velocity 0. When the velocity reaches 0, the operation direction is reversed and acceleration/deceleration is performed to the target position.

■For the acceleration/deceleration specification method



Velocity change

The specific acceleration/deceleration operation of jerk acceleration/deceleration is shown below. For the basic control description, refer to the following.

☞ Page 422 Set velocity change

Item	Abbreviation	Description
Current velocity	Vnow	The velocity when changing the velocity
Target velocity	V	The target velocity before the velocity is changed
Target velocity after change	V'	The target velocity after the velocity was changed

In jerk acceleration/deceleration, in order to smooth acceleration at velocity change, velocity change is carried out taking over the current acceleration before change.

■When not reaching the target acceleration

If the target velocity decreases due to velocity change, the target acceleration may not be reached. Adjust the target acceleration not to exceed the target velocity. For details, refer to the following.


☞ Page 370 Acceleration/deceleration waveform adjustment when specifying jerk

■When exceeding the target acceleration

If velocity is changed to a value smaller than the target velocity before change during acceleration, the target velocity may be exceeded. The axis accelerates to acceleration 0 after the velocity change instruction is issued but overrides the target velocity. After reaching the acceleration 0, it accelerates to the target velocity.

■Acceleration/deceleration specification method

After reaching the acceleration 0 due to velocity change during acceleration, the target deceleration may not be reached when decelerating to the target velocity.



■When a target velocity change is performed during automatic deceleration

The velocity change is accepted, however operation in execution is not changed. The target velocity after change is used when re-acceleration is performed by target position change.

Acceleration change

When "0: Acceleration/deceleration specification method (mcAccDec)" is selected in Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, acceleration change is performed.

Item	Abbreviation	Description
Current acceleration	Anow	The acceleration when changing the acceleration
Target acceleration before change	A	Target acceleration before acceleration is changed
Target acceleration	A'	Target acceleration after acceleration was changed

■When the target velocity is not reached

When the target acceleration increases by acceleration change and the target velocity is exceeded at the specified acceleration, the target acceleration will not be reached because the target velocity is given priority. For details, refer to the following.

☞ Page 370 Acceleration/deceleration waveform adjustment when specifying jerk

Also, when velocity change and acceleration change are simultaneously performed, the target acceleration may not be reached because the target velocity is given priority.


■Acceleration change

The acceleration change pattern can be classified based on the operation status when acceleration change is performed.


- When executing acceleration change in the acceleration section 1

Acceleration is increased or decreased to the target acceleration after change by using jerk, and taking over the velocity and the acceleration immediately before the acceleration change.

■When the target acceleration is increased




■When the target acceleration is decreased




- When executing acceleration change in the maximum acceleration section

Acceleration is increased or decreased to the target acceleration after change by using jerk, and taking over the velocity and the acceleration immediately before the acceleration change.

■When the target acceleration is increased




■When the target acceleration is decreased



- When executing acceleration change in the acceleration section 2 or during fixed-speed, deceleration, and automatic deceleration

The acceleration change is accepted although acceleration operation during execution does not change. When re-acceleration is performed by velocity change etc., the axis accelerates with the acceleration after change.



Deceleration change

When "0: Acceleration/deceleration specification method (mcAccDec)" is selected in Acceleration/deceleration method setting (Options (Options): Bit 0 to 2) of the FB, deceleration change can be performed.

Item	Abbreviation	Description
Current deceleration	DecNow	The deceleration when changing the deceleration
Target deceleration before change	Dec	Target deceleration before deceleration is changed
Target deceleration after change	Dec'	Target deceleration after deceleration was changed

When deceleration change is performed during operation, the target position may be overrun by decreasing the deceleration. In this case, the axis is controlled based on Operation Setting at Overrun (AxisName(AxesGroupName).Pr.OverrunOperation).

- When executing deceleration change in the acceleration section or fixed-speed section
The deceleration change is accepted, however the operation during execution does not change. When deceleration is performed, the axis decelerates with the deceleration after change.
- When executing deceleration change in deceleration other than the automatic deceleration
The basic operation is the same as the acceleration change. For details, Refer to the following.
[Page 380 Acceleration change](#)
- When executing deceleration change in the automatic deceleration
The deceleration change is accepted, however the operation during execution does not change. When re-deceleration is performed after the axis re-accelerates by target velocity change, the axis decelerates with the deceleration after change.

Acceleration/deceleration method and multiple start

This section describes the acceleration/deceleration operation specific to the acceleration/deceleration method. For the basic operation of the buffer mode, refer to the following.

☞ Page 134 Multiple Start (Buffer Mode)

Acceleration/deceleration operation

■When the acceleration/deceleration methods are different between the under-control FB and the next FB


"Acceleration/Deceleration Method Mismatched" (error code: 1A0EH) occurs and the axis stops. Specify the same acceleration/deceleration method in the FBs.

■When the acceleration/deceleration methods are the same between the under-control FB and the next FB

- When switching "from the jerk acceleration/deceleration to the another jerk acceleration/deceleration"

The axis accelerates/decelerates taking over the velocity and the acceleration (deceleration) at the switching point.


However, when the jerk setting values are different between the under-control FB and the next FB, the jerk of the next FB will be the same as the jerk of the under-control FB. Also, after reaching the switching point during acceleration (deceleration), the on-going velocity waveform continues in case all settings of the target velocity, the acceleration, the deceleration, and the jerk are the same between the under-control FB and the next FB. If there is a different setting in any of those, the velocity change is performed to the target velocity of the next FB.



- Switching from other than "the jerk acceleration/deceleration to the another jerk acceleration/deceleration"

In the following case, the acceleration (deceleration) is not taken over at the switching point.


- Switching from the jerk acceleration/deceleration to the trapezoidal acceleration/deceleration
- Switching from the trapezoidal acceleration/deceleration to the another trapezoidal acceleration/deceleration
- Switching from the trapezoidal acceleration/deceleration to the jerk acceleration/deceleration



Velocity bias

The velocity bias is the function to set any command speed when the axis starts and stops. When using a stepping motor, the motor can be started and stopped smoothly by setting a velocity speed suitable for the motor to the velocity bias value. This function is enabled when the acceleration/deceleration method is set to the acceleration/deceleration specification method or the acceleration/deceleration time-fixed method during the following operations.

- Single axis positioning control
- Single axis speed control
- Single axis manual control
- Multiple axes positioning control
- Multiple axes positioning data operation
- Direct control (velocity control)
- Speed to positioning move control



Setting method

- Set the velocity bias value (AxisName(AxesGroupName).Pr.VelocityBias) for each axis.
- When using the velocity bias in linear interpolation control, the velocity bias value to be used varies depending on the velocity mode setting. If the velocity mode is set to the long axis velocity or the reference axis velocity, the velocity bias value for the relevant axis parameter is used. When the velocity mode is set to the vector speed, the velocity bias value of the axis group parameter is used.
- When the velocity bias is used in the circular interpolation control, the velocity bias value of the axis group parameter is used.
- If the velocity bias is not used, the velocity bias value (AxisName(AxesGroupName).Pr.VelocityBias) is set to "0".
- Set the velocity bias value to the positive direction velocity limit value (AxisName.Pr.VelocityLimit_Positive), the negative direction velocity limit value (AxisName.Pr.VelocityLimit_Negative), and a value equal to or less than the velocity limit value (AxesGroupName.Pr.VelocityLimit). If a value larger than the velocity limit value is set, "Speed Bias Value Speed Limit Over" (error code: 1AFCH) occurs when the PLC READY turns ON, and the READY does not turn ON.
- Set the velocity and the velocity override factor so that the target velocity is equal to or greater than the velocity bias value. If the target velocity is set to a value other than 0 or less than the velocity bias value when the axis starts, "Error Below Speed Bias Value" (error code: 1AFDH) occurs, and the axis does not start.
- If the target velocity becomes other than 0 and less than the velocity bias value due to multiple start, velocity change, or the change of velocity override factor, "Below Speed Bias Value Warning" (warning code: 0D4BH) occurs. In this case, the target velocity after the change operates with the velocity bias value.
- The velocity bias is valid only for the trapezoidal acceleration/deceleration. If an operation with a jerk set to other than 0 is started for an axis with a velocity bias value other than 0, "Speed Bias Function Combination Not Supported Warning" (warning code: 0D4AH) occurs. In this case, the velocity bias is started as invalid.
- When acceleration/deceleration is performed by the acceleration/deceleration time-fixed method, the time from the velocity bias value to the completion of acceleration is the acceleration time, and the time decelerated to the velocity bias value is the deceleration time when the operation is performed.

Precautions

- When using a motor other than a stepping motor, set the velocity bias value to "0". Setting a value other than 0 may cause vibration or shock.
- When performing multiple axes positioning operation by specifying an axis or an axis group for which the velocity bias is valid, an axis other than the axis specified in the velocity mode may suddenly accelerate or decelerate when starting or stopping.
- Set the velocity bias value according to the specifications of the stepping motor driver. Settings outside the stepping motor driver specifications may cause rapid velocity changes or overloads, resulting in errors or maladjustment.
- When the velocity bias is in valid operation, the target velocity cannot be changed to a value less than the velocity bias value. To stop the operation temporarily, change the velocity override factor or the command speed so that the target velocity becomes "0".
- When a value equal to or less than the velocity bias value is specified for the target velocity in the acceleration/deceleration time-fixed method, the acceleration/deceleration velocity becomes 0. In this case, if "-1: Error (Not Started) (ACCError)" is set in the operation selection at the operation selection at start acceleration/deceleration 0 (AxisName(AxesGroupName).Pr.AccelerationZeroBehavior), "Acceleration/Deceleration 0 Specified Operation Error at Start" (error code: 1A0CH) occurs, and the axis does not start.
- The velocity bias does not support homing. For details on the operation and settings while the driver homing method is performed, refer to the manual of the drive unit.
- The velocity bias value (AxisName(AxesGroupName).Pr.VelocityBias) cannot be set when the version of the motion control setting function is "1.050C" or earlier. In this case, this function is disabled.

Precautions

Precautions when the range is exceeded

Precautions for when the acceleration/deceleration calculated from the acceleration/deceleration and the acceleration time/deceleration time after acceleration override exceeds the range are shown below.

■When the acceleration calculated from the acceleration and the acceleration time after acceleration override exceeds the range of 0.0000 or 0.0001 to 2147483647.0 [U/s²]

"Out of Acceleration Range Clamping Warning" (warning code: 0D35H) occurs, and the acceleration will be as follows.

- When "acceleration after acceleration override > 2147483647.0 [U/s²]"

The acceleration will be 2147483647.0 [U/s²].

- When "0.0000 < acceleration after acceleration override < 0.0001"

The acceleration will be "0.0000". For operation, refer to the following.

☞ Page 372 Operation when specifying acceleration/deceleration 0

■When the deceleration calculated from the deceleration and the deceleration time after acceleration override exceeds the range of 0.0000 or 0.0001 to 2147483647.0 [U/s²]

"Out of Deceleration Range Clamping Warning" (warning code: 0D36H) occurs, and the deceleration will be as follows.

- When "deceleration after acceleration override > 2147483647.0 [U/s²]"

The deceleration clamps at 2147483647.0 [U/s²].

- When "0.0000 < deceleration after acceleration override < 0.0001"

The deceleration will be "0.0000". For operation, refer to the following.

☞ Page 372 Operation when specifying acceleration/deceleration 0

■When the acceleration time (deceleration time) after acceleration override exceeds 8400.0 [s]

"Out of Acceleration/Deceleration Time Range Clamping Warning" (warning code: 0D37H) occurs and the acceleration time (deceleration time) will be 8400.0 [s].

Restrictions of commanded acceleration, commanded deceleration, and commanded jerk lower limit values

To perform floating-point operation, the lower limit value of commanded acceleration, commanded deceleration, and commanded jerk are limited by the following restrictions.

■ Lower limit restrictions of acceleration/deceleration

The set velocity may not change as information error occurs if the values of calculation cycle converted velocity and acceleration differ greatly. Therefore, the values of velocity and acceleration need to be set staying within a valid digit (approximately 15 digits) of a number of floating-points (64 bit).

When the calculation cycle converted acceleration is smaller than the set velocity, "Out of Operation Cycle Converted Acceleration Range Warning" (warning code: 0D38H) occurs. Similarly, "Out of Operation Cycle Converted Deceleration Range Warning" (warning code: 0D39H) occurs for deceleration. Check the set velocity. If it is not changed, either increasing the acceleration and deceleration or extending the operation cycle is needed.

Ex.

When control change is performed with the following settings during fixed-speed and velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) is "HFD000300 [/ms]", operation cycle is "0.125 [ms]" and velocity "2499999999.9"

- Velocity (Velocity): 2500000000.0
 - Acceleration (Acceleration): 62.0
- *: Acceleration/deceleration specification method (Trapezoidal acceleration/deceleration)

Calculation cycle converted velocity upper limit value = $2500000000.0 \text{ [pulse/ms]} \times 0.125 \text{ [ms]} = 312500000.0 \text{ [pulse]}$

Calculation cycle converted acceleration = $62.0 \text{ [pulse/s}^2\text{]} \times (0.125 \text{ [ms]} \div 1000)^2 = 9.6875\text{E-}07 \text{ [pulse]}$

In above case, "Out of Operation Cycle Converted Acceleration Range Warning" (warning code: 0D38H) occurs because the calculation cycle converted acceleration lower limit value is $1\text{E-}06 \text{ [pulse]}$.

■ Lower limit restriction of jerk

The set velocity or set acceleration may not change as information error occurs if the value of jerk to the values of calculation cycle converted velocity and acceleration differ greatly. Therefore, the value of jerk needs to be set staying within a valid digit (approximately 15 digits) of a number of floating-points (64 bit).

When the calculation cycle converted jerk is smaller than the velocity and the acceleration, "Out of Operation Cycle Converted Jerk Range Warning" (warning code: 0D3AH) occurs. Check the set velocity or set acceleration. If they are not changed, either increasing the jerk or extending the operation cycle is needed.

Ex.

When started with the following settings and Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) is "HFD000300 [ms]" and operation cycle is "0.125 [ms]"

- Velocity (Velocity): 100000.0
- Acceleration (Acceleration): 30000.0
- Deceleration (Deceleration): 30000.0
- Jerk (Jerk): 20.0

*: The acceleration/deceleration method (jerk acceleration/deceleration)

Calculation cycle converted velocity upper limit value = $100000.0 \text{ [pulse/ms]} \times 0.125 \text{ [ms]} = 12500.0 \text{ [pulse]}$

Calculation cycle converted acceleration = $30000.0 \text{ [pulse/s}^2\text{]} \times (0.125 \text{ [ms]} \div 1000)^2 = 0.00046875 \text{ [pulse]}$

Calculation cycle converted jerk = $20.0 \text{ [pulse/s}^3\text{]} \times (0.125 \text{ [ms]} \div 1000)^3 = 3.90625\text{E-11 [pulse]}$

In above case, the calculation cycle converted acceleration lower limit value will be "4.0E-11 [pulse]". Also, "Out of Operation Cycle Converted Jerk Range Warning" (warning code: 0D3AH) occurs because the calculation cycle converted jerk lower limit value will be the same value "4.0E-11 [pulse]".

When the calculation cycle converted jerk is too small, "Jerk Acceleration/Deceleration Disabled Warning" (warning code: 0D3BH) occurs and operates as Trapezoidal acceleration/deceleration.

Ex.

When started with the following settings and Velocity Command Unit (AxisName(AxesGroupName).Pr.Unit_Velocity) is "H00000300 [s]" and operation cycle is "31.25 [μs]"

- Velocity (Velocity): 0.4
- Acceleration (Acceleration): 0.005
- Deceleration (Deceleration): 0.005

In above case, "Jerk Acceleration/Deceleration Disabled Warning" (warning code: 0D3BH) occurs because the calculation cycle converted jerk is "3.05176E-18".

9.2 Velocity Limit

The "velocity limit function" limits the set velocity to a value within the velocity limit value setting range when the set velocity during control exceeds the velocity limit value. By limiting the set velocity within the preset velocity limit value setting range, even if an incorrect command or unexpected operation occurs, damage to the machine can be prevented.

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
VelocityLimit_Positive	Positive Direction Velocity Limit Value	Sets the address increasing direction velocity limit value for each axis.
VelocityLimit_Negative	Negative Direction Velocity Limit Value	Sets the address decreasing direction velocity limit value for each axis.
VelocityLimit_OverOperation	Operation Setting at Velocity Limit Value Exceeded	Sets the operation when the velocity limit value during control is exceeded. <ul style="list-style-type: none">• 0: Ignore (Ignore)• 3: Immediate Stop (ImmediateStop)

Axes group parameter (AxesGroupName.Pr.)

Variable/Structure name	Name	Details
VelocityLimit	Velocity Limit Value	Sets the velocity limit value of the axes group.

How to set the velocity limit function

Velocity limit value for each axis

Set Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) and Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative), for each axis.

Setting item	Setting range	Setting details
Positive Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Positive)	$0.0001 \leq \text{Setting value} \leq 2500000000.0$	Sets the velocity limit value (the maximum velocity during control) for the positive direction operation.
Negative Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Negative)		Sets the velocity limit value (the maximum velocity during control) for the negative direction operation.

Velocity limit value for each axes group

Set Velocity Limit Value (AxesGroupName.Pr.VelocityLimit), for each axes group.

Setting item	Setting range	Setting details
Velocity Limit Value (<u>AxesGroupName</u> .Pr.VelocityLimit)	$0.0001 \leq \text{Setting value} \leq 2500000000.0$	Sets the velocity limit value (the maximum velocity during control) of the axes group.

Operation when the velocity limit value is exceeded

The operation when specifying the velocity exceeding the velocity limit value differs depending on single axis control, single axis synchronous control and interpolation control.

For single axis operation

Executes the velocity limit to the actual target velocity whose override, etc. are considered for the commanded velocity.

■At start

If the target velocity at start exceeds the velocity limit value (Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) for the positive direction and Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) for the negative direction) of each axis, "Velocity Limit Value Over" (error code: 1A07H) will occur, and the axis will not start.

■During control

The velocity limit is not executed.

■During control (At velocity change)

If exceeding the velocity limit value of each axis is specified by the override function and input label change in execution, "Velocity Limit Value Over Warning" (warning code: 0D03H) will occur, and the operation continues at the velocity before change.

For details on the override function and input label change in execution, refer to the following.

☞ Page 392 Override Function

☞ Page 418 Input Variable Change in Execution

For single axis synchronous control

Executes the velocity limit to the set velocity of the slave axis.

■At start

The velocity limit is not executed.

■During control

If the set velocity exceeds the velocity limit value (Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) for the positive direction and Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) for the negative direction) of each axis, follow Operation Setting at Velocity Limit Value Exceeded (AxisName.Pr.VelocityLimit_OverOperation).

If the absolute value of the set velocity exceeds the maximum velocity, "Velocity Range Over during Controlling" (error code: 1AE8H) will occur and stop the operation.

For interpolation control

For the velocity limit at the interpolation control, Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive), Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative), and Velocity Limit Value (AxesGroupName.Pr.VelocityLimit) are used.

The operation when the target velocity exceeds the velocity limit value is as follows.

■At start

Variable to be used	Linear interpolation control			Circular interpolation control
	Vector velocity specification	Long axis velocity specification	Reference axis velocity specification	
Positive Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Positive) or Negative Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Negative)* ¹	Velocity is not restricted.	Long axis velocity is restricted by velocity limit value of long axis.* ²	Reference axis velocity is restricted by velocity limit value of reference axis.* ²	Velocity is not restricted.
Velocity Limit Value (<u>AxesGroupName</u> .Pr.VelocityLimit)	Velocity is restricted for vector velocity.* ²	Velocity is not restricted.	Velocity is not restricted.	Velocity is restricted for vector velocity.* ²

*¹ About either Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) or Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) is restricted according to the movement direction at the limit value check.

*² When the velocity limit value is exceeded, it will not start. "Velocity Limit Value Over" (error code: 1A07H) is output.

■During control

Variable to be used	Linear interpolation control			Circular interpolation control
	Vector velocity specification	Long axis velocity specification	Reference axis velocity specification	
Positive Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Positive) or Negative Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Negative)* ¹	Velocity is restricted for set velocity of each configuration axis. When the velocity limit value is exceeded, it follows Operation Setting at Velocity Limit Value Exceeded (<u>AxisName</u> .Pr.VelocityLimit_OverOperation).			
Velocity Limit Value (<u>AxesGroupName</u> .Pr.VelocityLimit)	Velocity is not restricted.			

*¹ About either Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) or Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) is restricted according to the movement direction at the limit value check.

■During control (At velocity change)

Variable to be used	Linear interpolation control			Circular interpolation control
	Vector velocity specification	Long axis velocity specification	Reference axis velocity specification	
Positive Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Positive) or Negative Direction Velocity Limit Value (<u>AxisName</u> .Pr.VelocityLimit_Negative)* ¹	Velocity is not restricted.	Long axis velocity is restricted by velocity limit value of long axis.* ²	Reference axis velocity is restricted by velocity limit value of reference axis.* ²	Velocity is not restricted.
Velocity Limit Value (<u>AxesGroupName</u> .Pr.VelocityLimit)	Velocity is restricted for vector velocity.* ²	Velocity is not restricted.	Velocity is not restricted.	Velocity is restricted for vector velocity.* ²

*¹ About either Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) or Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) is restricted according to the movement direction at the limit value check.

*² When the velocity limit value is exceeded, the velocity change will not be accepted. "Velocity Limit Value Over Warning" (warning code: 0D03H) is output.

Operation setting at velocity limit value exceeded

The operation when the velocity of any axis exceeds the velocity limit value during control can be specified in Operation Setting at Velocity Limit Value Exceeded (AxisName.Pr.VelocityLimit_OverOperation).

The following two types can be selected for the operation when the velocity exceeds the velocity limit value.

- 0: Ignore (Ignore)
- 3: Immediate Stop (ImmediateStop)

When the multiple axes exceed the limit value, the priority is "3: Immediate Stop (ImmediateStop)" > "0: Ignore (Ignore)".

Control continuation

When "0: Ignore (Ignore)" is specified in Operation Setting at Velocity Limit Value Exceeded

(AxisName.Pr.VelocityLimit_OverOperation), "Velocity Limit Value Over Warning" (warning code: 0D03) occurs at the time of detecting the set velocity exceeding the velocity limit value, and the command exceeding the velocity limit value is output as it is.

Control stop

When "3: Immediate Stop (ImmediateStop)" is specified in Operation Setting at Velocity Limit Value Exceeded

(AxisName.Pr.VelocityLimit_OverOperation), "Velocity Limit Value Over during Controlling" (error code: 1A36H) occurs at the time of detecting the set velocity exceeding the velocity limit value, and the positioning control in execution stops.

9.3 Override Function

- This function sets the factor for the velocity and performs the control to change the target velocity.
- This function sets the factor for the acceleration/deceleration and performs the control to change the target acceleration/target deceleration. (The ratio to the acceleration/deceleration time cannot be set.)
- This function is invalid when using the control without the target velocity and the target acceleration. (Ex. Cam operation of the positioning control)
- When the velocity and the acceleration/deceleration are changed by retrigger or continuous update, the override factor will be added to changed velocity and the acceleration/deceleration.
- There are two methods of changing the override factor, the method using the dedicated FB and the method using the control data.

Change method	Description
Change using a dedicated FB	MC_SetOverride (Override Value Setting), MC_GroupSetOverride (Axes Group Override Value Setting)
Change using control data	Velocity Override Factor (<u>AxisName</u> .Cd.VelocityOverride), Velocity Override Factor (<u>AxesGroupName</u> .Cd.VelocityOverride), etc.

- The override factor can be set in the axis control data and the axes group control data respectively. Only the override factor set in the axis control data is valid for single axis control, and only the override factor set in the axes group control data is valid for axes group control
- The override factor does not reflect immediately during deceleration stop after stop causes occur. It reflects at the timing which causes other stop causes.

Targets to be changed and corresponding FBs, control data

Targets to be changed		Corresponding FB	Corresponding control data
Velocity	Current value	Motion control FB having the velocity (Velocity) as an input variable. MC_SetOverride (Override Value Setting) MC_GroupSetOverride (Axes Group Override Value Setting)	Velocity Override Factor (<u>AxisName</u> .Cd.VelocityOverride), Velocity Override Factor (<u>AxesGroupName</u> .Cd.VelocityOverride)
	Limit value	—*1	—*1
	Limit value	Maximum value of the limit value	—*2

*1 Axis parameters can be changed by MC_WriteParameter (Parameter Write). However, it cannot be changed during control.

*2 The maximum value of the limit value cannot be changed.

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
VelocityOverride	Velocity Override Factor	Sets the velocity override factor.
AccelerationOverride	Acceleration Override Factor	Sets the acceleration override factor.

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
VelocityOverride	Velocity Override Factor	Sets the velocity override factor.
AccelerationOverride	Acceleration Override Factor	Sets the acceleration override factor.

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
VelocityOverride	Velocity Override Factor	Sets the velocity override factor.
AccelerationOverride	Acceleration Override Factor	Sets the acceleration override factor.

Axes group control data (AxesGroupName.Cd.)

Variable/Structure name	Name	Details
VelocityOverride	Velocity Override Factor	Sets the velocity override factor.
AccelerationOverride	Acceleration Override Factor	Sets the acceleration override factor.

Relevant FBs

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_SetOverride	Override Value Setting	Changes the target velocity, the target acceleration and the target deceleration of the specified axis.
MC_GroupSetOverride	Axes Group Override Value Setting	Changes the target velocity, the target acceleration and the target deceleration of the specified axes group.

How to change control data

Override factor setting range

The following shows each override factor setting range.

■Axis control data

Control data	Setting range
VelocityOverride (<u>AxisName</u> .Cd.VelocityOverride)* ¹	0.00 (0%) ≤ Setting value ≤ 10.0 (1000%)
AccelerationOverride (<u>AxisName</u> .Cd.AccelerationOverride)* ²	0.01 (1%) ≤ Setting value ≤ 10.0 (1000%)

*1 Registers "velocity override "0.00" in the event history when "0" is set to velocity override.

*2 Even if the acceleration/deceleration method specifying the acceleration/deceleration time, the override factor will be used to the acceleration/deceleration.

■Axes group control data

Control data	Setting range
VelocityOverride (<u>AxesGroupName</u> .Cd.VelocityOverride)* ¹	0.00 (0%) ≤ Setting value ≤ 10.0 (1000%)
AccelerationOverride (<u>AxesGroupName</u> .Cd.AccelerationOverride)* ²	0.01 (1%) ≤ Setting value ≤ 10.0 (1000%)


*1 Registers "velocity override "0.00" in the event history when "0" is set to velocity override.

*2 Even if the acceleration/deceleration method specifying the acceleration/deceleration time, the override factor will be used to the acceleration/deceleration.

Operation when the velocity override factor is changed

Change the velocity by changing Velocity Override Factor (AxisName(AxesGroupName).Cd.VelocityOverride).


When "0.00" is set in Velocity Override Factor (AxisName(AxesGroupName).Cd.VelocityOverride), the axis is stopped without moving to the "4: Standby (Standstill)" status.




Operation when the acceleration override factor is changed

Change the acceleration/deceleration by changing Acceleration Override Factor
(AxisName(AxesGroupName).Cd.AccelerationOverride).

■Acceleration/deceleration method specifying acceleration/deceleration




■Acceleration/deceleration method specifying acceleration/deceleration time



Operation when a value outside the override factor setting range is set


If a value outside the setting range is set in each override factor, the following warnings occur, and the override factor will remain unchanged from the previous value.

- "Out of Velocity Override Factor Range Warning" (warning code: 0D0BH)
- "Out of Acceleration Override Factor Range Warning" (warning code: 0D0CH)




Operation at velocity/acceleration/deceleration limit value over by override

- When velocity limit value over occurs by velocity override, velocity over will occur during control execution and the velocity will not change.




- When acceleration override factor is changed, the acceleration and deceleration will change. In this case, when acceleration limit value over occurs, the acceleration over will occur and the acceleration will change. When deceleration limit value over occurs, the deceleration over will occur and the deceleration will not change as well. (An error does not occur by a control data change, and the override factor is changed.)



■When velocity/acceleration/deceleration limit value over occurs at switching of FB by buffer mode

- The control change of buffering FB is executed at switching of FB.
- When the control is changed at switching of FB, velocity/acceleration/deceleration limit value over may occur. When velocity/acceleration/deceleration limit value over occurs, velocity/acceleration/deceleration and override factor at multiple start are used to control.
- Also when velocity/acceleration/deceleration limit value over occurs at switching of FB, the import of override factor is executed. If the limit value is not exceeded at the next control change, the override factor after change will be operated.



Override change operation by Motion control FB

The override factor can be changed by using the MC_SetOverride (Override Value Setting)/MC_GroupSetOverride (Axes Group Override Value Setting) Motion control FBs.

For details of Motion control FB operations, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Precautions

- Do not arrange two or more MC_SetOverride (Override Value Setting) and MC_GroupSetOverride (Axes Group Override Value Setting) in the same axis or the same axes group. Operation is not guaranteed when two or more of the FBs are arranged.
- In the single axis control, only the override factor set with the axis control data affects. In the axes group control, only the override factor set with the axes group control data affects.
- Do not operate Velocity Override Factor (AxisName.Cd.VelocityOverride) or Acceleration Override Factor (AxisName.Cd.AccelerationOverride) directly during performing MC_SetOverride (Override Value Setting).
- Do not operate Velocity Override Factor (AxesGroupName.Cd.VelocityOverride) or Acceleration Override Factor (AxesGroupName.Cd.AccelerationOverride) directly during performing MC_GroupSetOverride (Axes Group Override Value Setting).
- When the velocity after the velocity override is out of the range, refer to the following.
 - ☞ Page 84 Velocity Range
- When the acceleration, deceleration, acceleration time, and deceleration time after the acceleration override are out of the range, refer to the following.
 - ☞ Page 358 Acceleration/deceleration Processing Function
- When switching the driver control mode, changes to override coefficient will not be accepted during switching. Changes will be accepted after switching.

10 FUNCTIONS RELEVANT TO TORQUE

10.1 Torque Limit

The "torque limit function" limits the generated torque to a value within the torque limit value range when the torque generated in the servo motor exceeds the torque limit value.

It controls the operation so that unnecessary force is not applied to the load and machine by limiting the generated torque.

- Set the positive direction (address increment direction) torque limit value and the negative direction (address decrement direction) torque limit value for each axis.
- The torque limit value is used in the "setting of the torque limit value used in the drive unit" and the "control to suppress the command torque in MC_TorqueControl (Torque Control), etc."
- The torque limit value can be changed by changing the values of Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative).
When changing the torque limit value, specifies a value less than or equal to Torque Limit Maximum Value (AxisName.PrConst.TorqueLimit_Max) setting value. For details, refer to the following.

 Page 401 Torque Limit Value Change Function

- The torque limit value that is currently valid can be checked with Positive Direction Torque Limit Value (AxisName.Md.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Md.TorqueLimit_Negative).
- The torque limit value when connecting a drive unit, Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative) are set.

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
TorqueLimit_Max	Torque Limit Maximum Value	Sets the maximum value that can be specified as the torque limit value. (Common in the positive direction and the negative direction)
TorqueLimit_PositiveInitial	Positive Direction Torque Limit Initial Value	Sets the initial value of Positive Direction Torque Limit Value (<u>AxisName.Cd.TorqueLimit_Positive</u>).
TorqueLimit_NegativeInitial	Negative Direction Torque Limit Initial Value	Sets the initial value of Negative Direction Torque Limit Value (<u>AxisName.Cd.TorqueLimit_Negative</u>).

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
TorqueLimit_Positive	Positive Direction Torque Limit Value	Displays the positive direction torque limit value that is currently valid.
TorqueLimit_Negative	Negative Direction Torque Limit Value	Displays the negative direction torque limit value that is currently valid.

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
TorqueLimit_Positive	Positive Direction Torque Limit Value	Sets the positive direction torque limit value.
TorqueLimit_Negative	Negative Direction Torque Limit Value	Sets the negative direction torque limit value.

Object data setting

When using the torque limit function in the "setting of the torque limit value used in the drive unit", assign the following objects to the object data setting. For details on the object data setting, refer to the following.

☞ Page 66 Axes Group

- SDO

○: SDO mapping recommended

Required object data	Object necessary or not	Operation when no object is set
Positive torque limit value (60E0H)	○	Torque limit value is imported in the same unit as the command torque.
Negative torque limit value (60E1H)		

Point

- The number of significant digits after the decimal point differs depending on the ID assigned to the object data setting. Values less than the number of significant digits are truncated.
- If the torque limit object has not been assigned to the object data setting, the torque limit value is imported in the same unit as the command torque, because it is used only in the "control to suppress the command torque in MC_TorqueControl (Torque Control), etc.". Since the torque limit value will not be sent to the drive unit, refer to each drive unit manual for the torque limit value used by the drive unit.

For MR-J5(W)-G: MR-J5 User's Manual (Function)

Torque limit value setting range

Set the settings of Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative) for each axis.

The setting values are used in the "setting of the torque limit value used in the drive unit" and the "control to suppress the command torque in MC_TorqueControl (Torque Control), etc.".

The torque limit value can be changed by changing the setting values. For details, refer to the following.

☞ Page 401 Torque Limit Value Change Function

When the power supply turns ON, the setting values of Positive Direction Torque Limit Initial Value

(AxisName.PrConst.TorqueLimit_PositiveInitial) and Negative Direction Torque Limit Initial Value

(AxisName.PrConst.TorqueLimit_NegativeInitial) are stored. In this time, if Positive Direction Torque Limit Initial Value

(AxisName.PrConst.TorqueLimit_PositiveInitial) and Negative Direction Torque Limit Initial Value

(AxisName.PrConst.TorqueLimit_NegativeInitial) are set with the larger value than Torque Limit Maximum Value

(AxisName.PrConst.TorqueLimit_Max), "Out of Forward Direction Torque Limit Value Specification Range" (error code:

1A79H) or "Out of Reverse Direction Torque Limit Value Specification Range" (error code: 1A7AH) will occur.

If a value outside the range is set during control execution, "Out of Forward Direction Torque Limit Value Specification Range Warning" (warning code: 0D09H) or "Out of Reverse Direction Torque Limit Value Specification Range Warning" (warning code: 0D0AH) will occur.

Control data	Setting range
Positive Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Positive)	0.0 (0%) ≤ Setting value ≤ Torque Limit Maximum Value (<u>AxisName</u> .PrConst.TorqueLimit_Max)
Negative Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Negative)	

Torque limit maximum value setting range

Set the settings of Torque Limit Maximum Value (AxisName.PrConst.TorqueLimit_Max) for each axis. The torque limit maximum value is used as the upper limit value of the torque limit.

Even if a big value is input erroneously when changing the torque limit value, the change will not be accepted, and erroneous input is prevented. If a value outside the range is set, "Out of Parameter Range (Axis)" (error code: 1D80H) will occur.

Parameter	Setting range
Torque Limit Maximum Value (<u>AxisName</u> .PrConst.TorqueLimit_Max)	0.0 (0%) ≤ Setting value ≤ 1000.0 (1000%)



Set the upper limit value of the torque limit specified in the drive unit as the torque limit maximum value.

Both the positive direction torque limit value and the negative direction torque limit value are limited by Torque Limit Maximum Value (AxisName.PrConst.TorqueLimit_Max).

Precautions

When the axis control is stopped by torque limiting, the droop pulse will remain in the deviation counter. If the load torque is eliminated, operation for the amount of droop pulses will be carried out. Note that the movement might start rapidly as soon as the load torque is eliminated.

10.2 Torque Limit Value Change Function

- To change a torque limit value, there are a method of using the dedicated FB and a method of using control data.

Change method	Description
Change using a dedicated FB	MCv_SetTorqueLimit (Torque Limit Value)
Change using control data	Positive Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Positive) Negative Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Negative)

- The number of significant digits after the decimal point differs depending on the ID assigned to the object data setting.
- In a torque limit value change, a value cannot be changed to a torque limit value that exceeds Torque Limit Maximum Value (AxisName.PrConst.TorqueLimit_Max).

Targets to be changed and corresponding FBs, control data

Target to be changed		Corresponding FB	Corresponding control data
Torque	Current value	Motion control FB having the target torque (Torque) as an input variable.	—
	Limit value	MCv_SetTorqueLimit (Torque Limit Value)	Positive Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Positive) Negative Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Negative)
	Limit value Maximum value of the limit value	—*1	—

*1 Axis parameters can be changed by MC_WriteParameter (Parameter Write). However, it cannot be changed during control.

Relevant variables

For variables used in a method of changing control data, refer to the following.

 Page 398 Relevant variables

Relevant FB

For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_SetTorqueLimit	Torque Limit Value	Executes a torque limit value change.

How to change control data

Positive/Negative direction torque limit value setting range

The setting range of Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative) is as the following table.

Control data	Setting range
Positive Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Positive)	$0.0 (0\%) \leq \text{Setting value} \leq \text{Torque Limit Maximum Value}$
Negative Direction Torque Limit Value (<u>AxisName</u> .Cd.TorqueLimit_Negative)	(<u>AxisName</u> .PrConst.TorqueLimit_Max)

Torque limit value change timing


A torque limit value can be changed by changing Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative).

If a value outside the setting range is set, "Out of Forward Direction Torque Limit Value Specification Range Warning" (warning code: 0D09H) or "Out of Reverse Direction Torque Limit Value Specification Range Warning" (warning code: 0D0AH) will occur, and the torque limit value will remain unchanged from the previous value.

When the real drive axis is not connected, "Warning Changing Torque Limit Value for Unconnected Axis" (warning code: 0D23H) will occur. At this time, the torque limit value changed when connecting the real drive axis will be enabled because Positive Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Positive) and Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative) are changed.

Ex.

When a warning occurs after Negative Direction Torque Limit Value (AxisName.Cd.TorqueLimit_Negative) changes from "300.0" to "800.0" in the status when Torque Limit Maximum Value (AxisName.PrConst.TorqueLimit_Max) = "500.0" is set



Torque limit value change by Motion control FB

When changing the limit values of positive direction torque/negative direction torque at the same time, use the "MCv_SetTorqueLimit (Torque Limit Value)" Motion control FB.

For details of Motion control FB operations, refer to the following.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

11 CONTROL SUB FUNCTIONS

11.1 Compensation Function

Compensation function includes the driver unit conversion function, which can be executed by the parameter settings.

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
Drive_UnitConvRatioNum	Driver Unit Conversion Numerator	Sets the numerator to convert from the command unit of the motion system to the command unit of the drive unit. Set in units of the driver command. • 1 to 2147483647
Drive_UnitConvRatioDen	Driver Unit Conversion Denominator	Sets the denominator to convert from the command unit of the motion system to the command unit of the drive unit. • 1 to 2147483647

Driver unit conversion function

- Real drive axis


This function converts the machine feed value to the driver command value and pass it to the target position (Target position). Also, it converts the current position (Position actual value) of the drive unit and calculates the actual position. The conversion formulas are shown below.

Target position = Machine feed value (Motion system command value) × Driver unit conversion numerator / Denominator

Actual position = Current position × Driver unit conversion denominator / Numerator

Point

When the drive unit has the electronic gear, it is recommended to set the ratio to 1:1.




*1 According to the system configuration, if the resolution should be adjusted in the drive unit side, setting with the electronic gear of the drive unit side is possible.

When using the real drive axis in the following function, a driver unit conversion other than the above one is executed.

Function	Details on driver unit conversion	Reference
Direct control (Pressure Control)	Converts the mechanical coordinate value of the forward-side position to the driver unit and sends it to "Forward-side stop function (2E56H)" of the object data.	Page 322 Pressure Control

- Real encoder axis/Virtual encoder axis

Executes the driver unit conversion to the synchronous encoder output value and calculate the cumulative current position.



Control details

Set Driver Unit Conversion Numerator (AxisName.Pr.Drive_UnitConvRatioNum) and Driver Unit Conversion Denominator (AxisName.Pr.Drive_UnitConvRatioDen) in order to output the command value to the drive unit according to the specified movement amount.

The setting examples are shown below.

■For a ball screw

Ex.

For the following settings

Setting item	Setting value
Ball screw pitch	20 [mm]
Controller command unit	[mm]
Drive unit command unit	[pulse]
Motor encoder resolution	67108864 [pulse/rev]

Set the number of pulses required to rotate a motor once (the encoder resolution) in Driver Unit Conversion Numerator (AxisName.Pr.Drive_UnitConvRatioNum), and set the transfer distance of the machine per motor rotation in Driver Unit Conversion Denominator (AxisName.Pr.Drive_UnitConvRatioDen).

- Driver Unit Conversion Numerator (AxisName.Pr.Drive_UnitConvRatioNum) = 67108864 [pulses]
- Driver Unit Conversion Denominator (AxisName.Pr.Drive_UnitConvRatioDen) = 20 [mm]

In this example, the movement amount per pulse is "0.000000298 [mm]".

For instance, when the movement amount of "22 [mm]" is set, the command will be "73819750.4 [pulses]" and a fraction of 0.4 [pulses] will appear. In this case, the movement amount of "67108864 [pulses]" is output to the drive unit, and the fraction is memorized inside the motion system, and positioning is performed by adding this fraction to the movement amount at the next positioning.

■For a linear servo motor

Ex.

When the controller command unit is [μ m] and the drive unit command unit is [pulse]

The number of pulses of the linear encoder is calculated with the driver unit conversion numerator and the movement amount is calculated with the driver unit conversion denominator.

$$\text{Linear encoder resolution} = \frac{\text{Number of pulses (driver unit conversion numerator)}}{\text{Movement amount (driver unit conversion denominator)}}$$

Linear encoder resolution: 0.05 [μ m]

$$\frac{\text{Number of pulses [pulse]}}{\text{Movement amount } [\mu\text{m}]} = \frac{1}{0.05} = \frac{20}{1.0}$$

- Driver Unit Conversion Numerator (AxisName.Pr.Drive_UnitConvRatioNum) = 20 [pulses]
- Driver Unit Conversion Denominator (AxisName.Pr.Drive_UnitConvRatioDen) = 1 [μ m]

- Set the driver unit conversion multiplying factor within the following range.

$$|\text{The range upper limit of the controller command value} \times (\text{Driver unit conversion numerator} / \text{denominator})| < 8000000000000000000$$

For the range upper limit of the controller command value, refer to the following.

 Page 81 Positioning Range

If setting a value outside the range, "Driver Unit Conversion Magnification Upper Over" (error code: 1AA4H) will occur.
- A change of the driver unit conversion parameter is also imported when the PLC READY is turned ON. Turning ON it in the following status, otherwise, "Driver Unit Conversion Numerator/Denominator Change Timing Incorrect" (error code: 1AA5H) will occur, and the system will be operated with the set value before turning ON the PLC READY.
 - Axis Status (AxisName.Md.AxisStatus) is "0: Axis disabled (Disabled)"
 - Follow-up Disabled (AxisName.Md.FollowupDisable) is FALSE

Precautions

- Values less than one which could not be output during machine movement are managed in the motion system, and the cumulated values will be output when the value reaches one pulse or more.
- When machine homing is completed, the function clears the cumulative values of less than one pulse which could not be output to "0".
- When the driver unit conversion numerator/denominator is changed, the homing request flag becomes TRUE.
- Double-precision floating-point type variables are used for calculation of the cumulative current value and the target position that is sent to the drive unit. Therefore, values that cannot be expressed within the effective digits of the double precision floating point format (the range of the mantissa part 53 bits) include errors due to rounding processing.
- The target position is calculated by a formula, "cumulative machine position from home position $\times$ driver unit conversion numerator / driver unit conversion denominator". Set so that the integral part of the calculation result does not exceed the effective digits range.
 Since the target position sends a value which is obtained by truncating the fractional part of the operation result, errors due to rounding processing is truncated when it is less than or equal to the decimal point. However, when the integer part becomes larger than the effective digit, the command value actually output will also contain rounding error.
- When the cumulative current value per pulse after the driver unit conversion (" $1 \times$ driver unit conversion denominator / driver unit conversion numerator") is a small value less than effective digits to the present cumulative current value, the correct command cannot be sent in units of 1 [pulse].
- When the error size is a problem, reduce the multiplying factor of "driver unit conversion numerator / driver unit conversion denominator".

For example, when setting 20 [mm] to the machine movement amount per motor rotation, set "20000" in Driver Unit Conversion Denominator (AxisName.Pr.Drive_UnitConvRatioDen), and set [μ m] in Position Command Unit (AxisName.Pr.Unit_Position). (20.0 [mm] $\rightarrow$ 20000.0 [μ m])

11.2 Command Filter

Command filter can perform specified filter processing to inputs of the master axis, and output the result to the slave axis. For example, when setting a virtual drive axis to the master axis and a real drive axis to the slave axis, the result of filter processing to input of the virtual drive axis can be output to the real drive axis.

The types of command filters are shown below.

Filter type	Overview
Smoothing filter	<ul style="list-style-type: none">• Filter function that is used to suppress load-side vibration, such as work-side vibration and base shake.• Frequencies higher than the set frequency can be removed.
Moving direction restriction filter	<ul style="list-style-type: none">• Filter function that is used to limit the travel direction of the axis.• The input movement amount from the master axis can be restricted to one direction.• This helps to avoid reverse operation caused by machine vibration, etc.
Speed limit filter	<ul style="list-style-type: none">• Filter function that is used to limit the speed of the axis.• The speed input by the master axis can be limited to the specific speed and output.
Backlash compensation filter	<ul style="list-style-type: none">• Filter function that is used to compensate for the backlash amount in the machine system.• Whenever the travel direction changes, outputs the extra commands equivalent to the set up backlash compensation amount.

The command filter control FB is Enable (Enable) type of synchronous control FB and has Filter disable (FilterDisable) and Filter cumulated value (FilterPool).

Operation of this function for each system status

○: Possible, ×: Not possible

System status	Function operation
STOP	×
RUN	○
Moderate error	×
Major error	×

Relevant FBs


For details on Motion control FBs, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_SmoothingFilter	Smoothing Filter	Executes filter processing based on the specified frequency.
MCv_DirectionFilter	Moving Direction Restriction Filter	Executes filter processing to the travel direction set up to restrict traveling.
MCv_SpeedLimitFilter	Speed Limit Filter	Executes filter processing to restrict to the speed of set up limit value.
MCv_BacklashCompensationFilter	Backlash Compensation Filter	Following the movement direction, executes filter processing to compensate the backlash amount in the machine system.

Smoothing filter

- Smoothing filter removes frequencies higher than the set Frequency (Frequency), and the entire waveform higher than the setting value becomes a smooth acceleration/deceleration waveform.
- Smoothing filter outputs the result of filter processing that executed to the Master axis (Master value) set in Master axis data source selection (MasterValueSource) to Slave axis (Slave).
- Axis Status (AxisName.Md.AxisStatus) of Slave axis (Slave) is "7: During synchronous operation (SynchronizedMotion)" during smoothing filter execution.
- The time constant of smoothing is $1/\text{Frequency}$ (Frequency) [s], and the acceleration time and deceleration time become longer by the smoothing time constant. When Frequency (Frequency) is "10 [Hz]", the smoothing time constant is "0.1 [s] = 100 [ms]".




- If a smoothing filter is started while Slave axis (Slave) is in another operation instruction, the start request will be ignored, and "Start Not Possible" (error code: 1AADH) will occur. Start it when Axis Status (AxisName.Md.AxisStatus) of Slave axis (Slave) is "4: Standby (Standstill)".
- MC_Stop (Forced Stop) is the only function block that can be multiple started during smoothing filter execution.

Program examples


An example program to turn the trapezoidal acceleration/deceleration into smooth acceleration/deceleration waveform is shown below.

Sequence program



Operation

As Frequency (Frequency) is set to "10.0", the smoothing time constant will be "0.1 [s]".



Precautions

- An operation load increases in smoothing filter as the filter level increases. A rough standard of operation load when the filter level is 5000 is as follows.
 - RD78G: Approximately 380 [μ s]
 - RD78GH: Approximately 240 [μ s]
- Filter level can be calculated by the following formula. After the decimal point is rounded up/down to the nearest integer. However when the result is 0, the operation is carried out as 1 level.
"Filter level = (1 / frequency [Hz]) / operation cycle [s]"
- The smoothing filter secures the memory to use for filter processing at start. The memory usage can be calculated by the following formula. If memory is insufficient, change maximum RAM size
(System.PrConst.Addon_MotionControl_AxisFilter.RamSizeMax) of Addon MotionControl_AxisFilter parameter
"Memory usage = Filter level x 8 bytes"
- The operation error may increase when the movement amount of the master axis or the slave axis is large and the following case applies. Confirm the unit setting of the master axis and the slave axis and decrease the movement range. If the error increases, clear the synchronization status or change the current value change of absolute position specification.
When the total sum of the movement amount (following formula) equivalent to filter level at control exceeds the number of significant digits which can be represented by double-precision floating-point (approximately 15 digits).

$$\sum_{i=0}^{\text{Filter level} - 1} (i \text{ the position of master axis before operation cycle} - \text{the position of master axis at starting control})$$

- When the master axis operates in the positive and negative direction alternately every operation cycle, underflow occurs during internal operation and the position error of the master axis and the slave axis may occur.

Necessary object data

For details, refer to the following.

 Page 467 Required Object Data


Moving direction restriction filter

- The moving direction restriction filter, to the master axis movement, restricts the movement of the slave axis to one direction.
- The moving direction restriction filter, outputs the result of filter processing that executed to the Master value set in Master axis data source selection (MasterValueSource) to Slave.
- Axis Status (AxisName.Md.AxisStatus) of Slave axis (Slave) will be "7: During synchronous operation (SynchronizedMotion)" during moving direction restriction filter execution.
- If a moving direction restriction filter is started while the slave axis is in another operation instruction, the start request will be ignored, and "Start Not Possible" (error code: 1AADH) will occur. Start when Axis Status (AxisName.Md.AxisStatus) of Slave axis (Slave) is "4: Standby (Standstill)".
- MC_Stop (Forced Stop) is the only function block that can be multiple started during moving direction restriction filter execution.
- When turning Enable (Enable) to FALSE, execute while the slave axis is in stop status. If Enable (Enable) is turned to FALSE during the slave axis in operation, the slave axis will stop immediately.

Program examples


An example program for cam operation direction restriction is shown below.

Sequence program



Operation

When MCv_DirectionFilter (Moving Direction Restriction Filter) Master axis (Master) moves to the negative direction, Slave axis (Slave) does not move to the negative direction.



Necessary slave object

For details, refer to the following.

☞ Page 467 Required Object Data

Speed limit filter


- The speed limit filter, to the input velocity of the master axis, sets a specified control value, and outputs the speed of the set control value to the slave axis.
- The speed limit filter, outputs the result of filter processing that executed to the Master axis (Master) value set in Master axis data source selection (MasterValueSource) to Slave axis (Slave).
- Axis Status (AxisName.Md.AxisStatus) of Slave axis (Slave) will be "7: During synchronous operation (SynchronizedMotion)" during speed limit filter execution.
- If a speed limit filter is started while the slave axis is in another operation instruction, the start request will be ignored, and "Start Not Possible" (error code: 1AADH) will occur. Start when Axis Status (AxisName.Md.AxisStatus) of Slave axis (Slave) is "4: Standby (Standstill)".
- MC_Stop (Forced Stop) is the only function block that can be multiple started during speed limit filter execution.
- When turning Enable (Enable) to FALSE, execute while the slave axis is in stop status. If Enable (Enable) is turned to FALSE during the slave axis in operation, the slave axis will stop immediately.

Program examples


An example program for synchronous encoder speed limit is shown below.

Sequence program

The axis 1 sets the synchronous encoder.



Operation




Necessary object data

For details, refer to the following.

 Page 467 Required Object Data


Backlash compensation filter

Backlash compensation filter is used to compensate the backlash amount in the machine system.



When the movement direction of Master axis (Master) is the same as Backlash compensation direction (BacklashDirection), Slave axis (Slave) synchronizes to the position equivalent to the Master axis (Master) current position shifted in the Backlash direction (BacklashDirection) by the value of Backlash amount (BacklashAmount).

When the movement direction of Master axis (Master) is the reverse of Backlash compensation direction (BacklashDirection), Slave axis (Slave) synchronizes to the Master axis (Master) current position. Whenever the Master axis (Master) movement direction changes, backlash compensation is performed with the Slave axis (Slave) extra movement amount limited to only the value of Backlash amount (BacklashAmount).




• Stop operation

For details of the stop operation, refer to the following.

➡ Page 467 Start and Stop Operation


This section describes the specific operation of the backlash compensation filter.

When stop factor occurs to Slave axis (Slave), Slave axis (Slave) starts the stop operation from the synchronous position. The movement amount (Filter cumulated value (FilterPool) value) by the compensation will not be restored.



- Operation at Filter disabled (At Enable (Enable) falling edge)

Slave axis (Slave) stops immediately at the synchronous position when Enable (Enable) falling edge. The travel amount (Filter cumulated value (FilterPool) value) by the compensation will not be restored.




Procedure to enable the backlash compensation filter

Execute after the machine position is established by homing, or restart the backlash compensation filter after cancelling midway.


Example of the use procedure

1. Move the real drive axis by homing or JOG operation etc., and maintain the status so that the backlash of the machine system is generated in only one direction as shown in the correct example below.

■ Correct example



■ Incorrect example




2. Match the Master axis (Master) set position with the real drive axis set position by using the current position change, etc.
3. Set Backlash compensation direction (BacklashDirection) so that it is the reverse direction of the direction that the real drive axis was moved to in Step 1., then start the backlash compensation filter. In addition, start any back part function blocks that are present.

Program example


An example program for the backlash compensation filter in the program is shown below.

The example program is configured so the backlash compensation filter back part is connected with the speed limit filter.



Axis	Axis name for the program example	Comment
Virtual drive axis (1)	Axis0001	<ul style="list-style-type: none"> • Executes the motion control such as positioning control, and generates the command to output to the drive device. • Indicates the load-side position (before speed limit).
Virtual drive axis (2)	Axis0002	<ul style="list-style-type: none"> • When the backlash of the machine and the motor side should be compensated by the backlash compensation filter, it will indicate the motor side position (before speed limit).
Real drive axis	Axis0003	<ul style="list-style-type: none"> • Indicates the motor side position (after speed limit). • Outputs the command to the drive device.

Sequence program



The following should be defined by users.

- executeMoveRelative1
- enableBacklashCompensation1
- enableSpeedLimit1


■Structured text (ST language)

```
MC_MoveRelative_1.Axis := Axis0001.AxisRef;
MC_MoveRelative_1.Execute := executeMoveRelative1;
MC_MoveRelative_1.Distance := LREAL#100.0;
MC_MoveRelative_1.Velocity := LREAL#20.0;
MC_MoveRelative_1.Acceleration := LREAL#300.0;
MC_MoveRelative_1.Deceleration := LREAL#400.0;
MC_MoveRelative_1();
MCv_BacklashCompensationFilter_1.Master := MC_MoveRelative_1.Axis;
MCv_BacklashCompensationFilter_1.Slave := Axis0002.AxisRef;
MCv_BacklashCompensationFilter_1.Enable := enableBacklashCompensation1;
MCv_BacklashCompensationFilter_1.FilterDisable := FALSE;
MCv_BacklashCompensationFilter_1.BacklashAmount := LREAL#1.0;
MCv_BacklashCompensationFilter_1.BacklashDirection := INT#1;
MCv_BacklashCompensationFilter_1.MasterValueSource := INT#1;
MCv_BacklashCompensationFilter_1.Options := UDINT#0;
MCv_BacklashCompensationFilter_1();
MCv_SpeedLimitFilter_1.Master := MCv_BacklashCompensationFilter_1.Slave;
MCv_SpeedLimitFilter_1.Slave := Axis0003.AxisRef;
MCv_SpeedLimitFilter_1.Enable := enableSpeedLimit1;
MCv_SpeedLimitFilter_1.PositiveLimit := LREAL#100.0;
MCv_SpeedLimitFilter_1.NegativeLimit := LREAL#100.0;
MCv_SpeedLimitFilter_1.PositiveFilter := INT#4;
MCv_SpeedLimitFilter_1.NegativeFilter := INT#4;
MCv_SpeedLimitFilter_1();
```

The following should be defined by users.

- executeMoveRelative1
- enableBacklashCompensation1
- enableSpeedLimit1

■Timing chart



Precautions

- The backlash compensation is a function which the command direction and the backlash status should not change from the external force etc. The correct compensation will not be executed when used as follows.
 - A machine which always weighed by external force unidirectionally such as upper and lower axis.
 - A mechanism (such as rack and pinion mechanism) which the backlash amount changes depending on the machine position.
- Only Slave axis (Slave) Backlash amount (BacklashAmount) moves by one operation cycle at the time of Master axis (Master) movement direction changes. Depending on the value, it may exceed the command frequency that the velocity limit value and the drive unit can accept, connect the speed limit filter or the smoothing filter to the backlash compensation filter back part.
- Slave axis (Slave) current position (such as set position, machine feed value etc.) will be the position that Backlash amount (BacklashAmount) compensation is added. Backlash amount (BacklashAmount) compensation will not be added to the Master axis (Master) current position.

Necessary object data

For details, refer to the following.

 Page 467 Required Object Data

Precautions

- Note that if Filter disable (FilterDisable) is switched during operation, Slave axis (Slave) velocity may change rapidly.
- After enabling the command filter, when Master axis (Master) command is not transmitted to Slave axis (Slave) or the back part synchronous control FB by stop factor occurs to Slave axis (Slave) etc., the synchronous position relation deviates. Before enabling the command filter again, execute the synchronous positioning as needed.

11.3 Input Variable Change in Execution

In the control whose start condition is Execute command (Execute), data such as Target position (Position) and Velocity (Velocity) can be re-imported without interrupting the operation by Execute command (Execute) retrigger.

When ContinuousUpdate is TRUE at start, data such as Target position (Position) and Velocity (Velocity) are imported at each execution cycle during operation.

This section describes the operation when changing the following input variables as a typical example of input variable change.

- Target position/movement distance
- Set velocity
- Acceleration/deceleration, Acceleration/deceleration time

For details on input variables that can be changed and the operation when changing input variables other than the above, refer to details on each FB.

Relevant variables

Axis parameter (AxisName.Pr.)

Variable/Structure name	Name	Details
OverrunOperation	Operation Setting at Overrun	Sets operation when an overrun occurs during operation. <ul style="list-style-type: none">• 1: Immediate Stop (ImmediateStop)• 2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)

Axes group parameter (AxesGroupName.Pr.)


Variable/Structure name	Name	Details
OverrunOperation	Operation Setting at Overrun	Sets operation when an overrun occurs during operation. <ul style="list-style-type: none">• 1: Immediate Stop (ImmediateStop)

Target position/movement distance change

This function changes the target position and the movement distance.

Target position change

The target position is changed.




When Direction selection (Direction) can be set, the operation when changing the target position differs depending on the setting value.

■For the positive direction/negative direction/current direction

When the target position is changed, the target position will be calculated not from the set position at the change but from the start position and the direction specified by Direction selection (Direction).

When the target position is changed to between "start position and the set position at the target position change", the operation will be reversed to the target position after change, and the control will be performed according to the selection when having reverse rotation permission selection (Options (Options): Bit 5).




■For the shortest path

When the target position is changed, the operation will be performed in the close direction from the set position at change to the target position after change.

Movement distance change

The movement distance from the start position is changed.

The movement distance after change is calculated not based on the set position at change but based on the start position.



If the movement distance after change is shorter than the moved distance at movement distance change execution, the operation will be reversed, and the control will be performed according to the selection when having reverse rotation permission selection (Options (Options): Bit 5).


The deceleration distance is not kept by the target position/movement distance change

The control is performed according to the selection when having Operation Setting at Overrun

(AxisName(AxesGroupName).Pr.OverrunOperation) and reverse rotation permission selection (Options (Options): Bit 5).

■When the reverse rotation is allowed

When "0: Allow" is set to the reverse rotation permission selection (Options (Options): Bit 5), a deceleration stop is performed once regardless of the Operation Setting at Overrun (AxisName.Pr.OverrunOperation) setting. After the deceleration stop is completed, operation is started to the changed target position.




■When the reverse rotation is not allowed

When "1: Do not allow" is set to the reverse rotation permission selection (Options (Options): Bit 5), the axis operates according to the Operation Setting at Overrun (AxisName.Pr.OverrunOperation) setting.


- When "1: Immediate Stop (ImmediateStop)" is set

Deceleration is started, and the axis immediately stops after "Overrun Warning" (warning code: 0D10H) occurs when it reaches the stop address.



- When "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" is set

The deceleration is started, and the axis exceeds the stop address and stops. When the axis exceeds the stop address, "Overrun Error" (error code: 1A7EH) occurs. However, the operation stops according to the setting of Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General) when the error occurs. To stop the operation with the address which exceeds the stop address, set "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" in Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).




When an operation is reversed by changing the target position/movement distance

When an operation is reversed by changing the target position/movement distance, the axis is controlled according to the selection when having reverse rotation permission selection (Options (Options): Bit 5).

■When the reverse rotation is allowed

When "0: Allow" is set to the reverse rotation permission selection (Options (Options): Bit 5), a deceleration stop is performed once. After the deceleration stop is completed, operation is started to the changed target position.




■When the reverse rotation is not allowed

When "1: Do not allow" is set to the reverse rotation permission selection (Options (Options): Bit 5), the axis operates following the Operation Setting at Overrun (AxisName.Pr.OverrunOperation) setting. When the target position/movement distance is changed, "Overrun Error" (error code: 1A7EH) is detected.


- When setting "1: Immediate Stop (ImmediateStop)"

When changing the target position/movement distance, "Overrun Error" (error code: 1A7EH) occurs, and immediately stops.




- When setting "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)"

When changing the target position/movement distance, "Overrun Error" (error code: 1A7EH) occurs, and stops the operation following the Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General) setting. To perform deceleration stop by current deceleration, set "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)" to Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General).




Set velocity change

The set velocity is changed according to the acceleration/deceleration.



Set velocity sign inversion during speed control

The negative speed can be set in the speed control.
When the sign of set velocity is reversed, the reverse operation starts after a deceleration stop is completed.




If a warning occurs when a control is changed^{*1} during a deceleration stop for reverse rotation due to velocity change, the control change is not accepted. After the deceleration stop is completed, acceleration is restarted at the value before the control change.
However, if any of the control changed variables is Acceleration (Acceleration), Deceleration (Deceleration), Velocity Override Factor (VelFactor), and Acceleration Override Factor (AccFactor), a warning may occur during re-acceleration after stop, and the velocity may remain at 0.

For re-acceleration, remove the cause of the warning, and change Velocity (Velocity) to apply velocity change.

^{*1} When any of the following parameters Velocity (Velocity), Acceleration (Acceleration), Deceleration (Deceleration), Velocity Override Factor (VelFactor), and Acceleration Override Factor (AccFactor) is changed.

Combination with override

The velocity override factor also affects when the speed is changed.
The speed is changed to the speed obtained by adding the velocity override factor to the change speed.




Operation during interpolation control

When the set velocity is changed during the interpolation control, the set velocity is changed according to the acceleration/deceleration method or the acceleration.

Each axis speed is changed according to the velocity mode.

Ex.

When the vector velocity is set in the velocity mode



Acceleration/deceleration and acceleration/deceleration time change

This function changes the acceleration/deceleration and the acceleration/deceleration time.

An overrun may occur by changing the acceleration/deceleration and the acceleration/deceleration time.

When an overrun is occurring, the axis is controlled according to Operation Setting at Overrun

(AxisName(AxesGroupName).Pr.OverrunOperation).

For operation when changing the acceleration/deceleration and the acceleration/deceleration time, refer to the following.

 Page 358 Acceleration/deceleration Processing Function

Precautions

- Maintain the previous value for the input values that are not changed.
- Even if input variables that cannot be changed are changed, any error or warning will not occur, and the change will be ignored and the control will be continued. For input variables that can be changed, refer to details on each FB.
- When switching the driver control mode, changes to override coefficient will not be accepted during switching. Changes will be accepted after switching.

12 COMMON FUNCTIONS

12.1 External Signal Selection

This section describes a setting method of I/O signals which are used in each control.
The following indicates the functions that use external signal selection.

- Page 190 Forced Stop
- Page 351 Hardware Stroke Limit

Operation of this function for each system status


○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○


Overall block diagram

The relationship between an external signal selection and function is shown below.

Signal input



Signal output



Relevant variables

I/O signals are expressed by the TARGET_REF structure. Another structure which has the TARGET_REF structure as a member may be defined depending on the function that uses I/O signals. For example, the MC_TRIGGER_REF structure has the SIGNAL_SELECT structure that indicates the bit I/O data as a member, and furthermore, the SIGNAL_SELECT structure includes the TARGET_REF structure.

MC_TRIGGER_REF		
Variable/Structure name	Name	Details
Signal	Trigger Signal	Sets the trigger signal. Trigger signal (Signal) is a SIGNAL_SELECT structure.

MC_INPUT_REF		
Variable/Structure name	Name	Details
Signal	Input Signal	Sets the input signal. Input signal (Signal) is a SIGNAL_SELECT structure.

MC_OUTPUT_REF		
Variable/Structure name	Name	Details
Signal	Output Signal	Sets the output signal. Output signal (Signal) is a SIGNAL_SELECT structure.

For the configuration of each structure, refer to the following.
 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

The SIGNAL_SELECT structure and the TARGET_REF structure which are structures common for each function, are described below.

SIGNAL_SELECT structure

This section describes SIGNAL_SELECT structure.

- SIGNAL_SELECT (Signal Select)

Variable/Structure name	Name	Details
Source	Signal	Sets BOOL type signals used in control.
Detection	Signal detection method	Sets the signal logic.
CompensationTime	Compensation time	Sets the compensation time of the I/O signal in units of seconds.
FilterTime	Filter time	Sets the filter time for removing chattering of the input signal in units of seconds.

The settings of the BOOL type I/O signals which are used in control are expressed by the SIGNAL_SELECT type structure variables.

Details of the SIGNAL_SELECT type structure are described below.

Signal (Source)

- Specify BOOL type signals which are used in control with the TARGET_REF structure. The following data types can be used.

Data types
<ul style="list-style-type: none">• [VAR]• [DEV]• [CONST]• [OBJ] (mapped to cyclic communication)

- For details of the TARGET_REF structure, refer to the following.
👉 Page 428 TARGET_REF structure
- For operation when a signal which cannot be used is set, refer to each function.

Signal detection method (Detection)

- Specify the signal logic with the MC_SIGNAL_LOGIC enumeration type. For details, refer to the following.

■Bit input signals

Setting	Operation
0: Detection at TRUE (HighLevel)	When the corresponding signal is in the TRUE status, it operates as a signal input status. Input signal 
1: Detection at FALSE (LowLevel)	When the corresponding signal is in the FALSE status, it operates as a signal input status. Input signal 
2: Detection at FALSE → TRUE (Rising Edge) (RisingEdge)	When the corresponding signal is the FALSE to TRUE rising edge, it operates as a signal input timing. Input signal 
3: Detection at TRUE → FALSE (Falling Edge) (FallingEdge)	When the corresponding signal is the TRUE to FALSE falling edge, it operates as a signal input timing. Input signal 
4: Detection at Rising Edge/Falling Edge (BothEdges)	When the corresponding signal is the FALSE to TRUE rising edge and the TRUE to FALSE falling edge, it operates as a signal input timing. Input signal 

- Selectable logics vary depending on the function. For details, refer to each function.

■Bit output signals

No signal logic is selectable. Any selected signal logic will be ignored. The following operation will be always applied.

Operation

When the output command is TRUE, the corresponding signal is turned to TRUE.

Output command

Output signal



Compensation time (CompensationTime)

- Specify the compensation time in seconds to compensate progress or delay of the I/O signals.
- Unavailability of the compensation time and the operation when a value is set depend on the function. For details, refer to each function.

Filter time (FilterTime)

- Specifies the filter time in seconds to remove chattering of the input signal. During the time that the signal status specifies, it is reflected to the input/output only when the same value is continued. The timing of input/output is delayed for the filter time.
- The availability of the filter time differs according to functions. For details, refer to each function.

TARGET_REF structure

This section describes the TARGET_REF structure.

- TARGET_REF (Input Signal)

Variable/Structure name	Name	Details
StartIO	IO Number	Sets the I/O Number
Target	Target	<p>This variable sets the signal used in control with the following character string formats.</p> <ul style="list-style-type: none"> *: The setting is not case-sensitive. In addition, spaces are ignored. *: Up to 63 characters can be stored in Target (Target). <p>■[Classification](Type)Data name.Bit position@Target modification</p> <ul style="list-style-type: none"> • [Classification] ( Page 428 [Classification] / data name) • (Type) ( Page 429 (Type)) • Data name ( Page 428 [Classification] / data name) • .Bit position ( Page 430 .Bit position) • @Target modification ( Page 430 @Target modification) <p>■[Classification](Data type)WSTRING type label^</p> <ul style="list-style-type: none"> • [Classification] ( Page 428 [Classification] / data name) • (Data type) ( Page 429 (Type)) • WSTRING type label^*1

- *1 When specifying more than 63 characters string format, use the WSTRING type label and specify with the following method.
- (1) Declare the WSTRING type global label in the motion system, and store the part of Data name.Bit position@Target modification.
 - (2) Specify the label name of (1) as the WSTRING type label of TARGET_REF. (To the end, add "^" that indicates reference.)

[Classification] / data name

Specify the data type in [Classification] and the target data in Data name. The specifying method of the data name varies depending on the classification.

Classifi- cation	Target	Specifying method of data name		Setting example
		Format	Description	
[OBJ]	CANopen object of the device station (mapped to cyclic communication)	[OBJ]0x□□□□**##	<p>Sets the index, subindex, and size of the object.</p> <ul style="list-style-type: none"> • □□□□: Index • **: Subindex • ##: Size (in bits) <p>*: Specifying the target device may be required in @Target modification. Check the specification of the function.</p> <p>*: For use with non-BOOL types, match the specified type with the object size.</p> <p>*: Some objects are available as the high-accuracy input. For details, refer to the following.</p> <p> Page 431 External signal high-accuracy input</p> <p>*: An object whose size is 1 bytes is not available.</p>	<p>[OBJ](DINT)0x607A0020</p> <p>*: MR-J5(W)-G Target position (Obj. 607Ah: 00h) For 4-byte object (20H)</p>
[VAR]	Label of the motion system	[VAR]Label name	<p>Specify a label in the motion system includes in Label name.</p> <p>The following labels are available as read only by specifying the member names (S: Contact, C: Coil, and N: Current value).</p> <ul style="list-style-type: none"> • Timer type • Retentive timer type • Long timer type • Long retentive timer type • Counter type • Long counter type <p>*: When specifying the local label, specify the POU*1 name in @Target modification.</p> <p>*: For whether the local label can be set or not and the conditions that the setting is enabled, check the specification of the function.</p> <p>*: Digit specification of bit-type array labels is not available.</p>	<p>[VAR]ADunit10.OutputEnable</p> <p>[VAR]Label_w1.S</p> <p>[VAR]TestLabel[0,0]</p>

Classification	Target	Specifying method of data name		Setting example
		Format	Description	
[AXIS]	Axis data	[AXIS] <u>MC_SOURCE</u>	Specify a MC_SOURCE enumeration type enumerator in <u>MC_SOURCE</u> . Only the data type "LREAL" can be specified. • 1: Set value (mcSetValue) • 2: Actual value (mcActualValue) • 101: Latest set value (mcLatestSetValue) • 102: Latest actual value (mcLatestActualValue) *: Specifying the target data may be required in <u>@Target modification</u> . *: This data cannot be written. *: Check the specification of the function.	[AXIS]mcSetValue
[DEV]	Device in the motion system (Including buffer memory and link device of the module itself)* ²	[DEV] <u>Device name</u>	Specify a device in the module itself in <u>Device name</u> . Following devices can be set. • Buffer memory (G) • Remote input (RX) • Remote output (RY) • Remote register (RWw, RWr) • Link relay (LB) • Link register (LW) • Link special relay (SB) • Link special register (SW) *: <u>@Target modification</u> cannot be specified. (It is ignored.)	[DEV]RWr10.5 [DEV]G11500000.1
[CONST]	Constant	[CONST] <u>Constant</u> [CONST]0x <u>Constant</u>	Specify <u>Constant</u> as floating decimal (E format is also available)/decimal integer/hexadecimal integer. The value can be changed for each cycle by specifying the <u>@Target modification</u> . *: This data cannot be written.	[CONST]1000 [CONST]0x100

*1 POU: Program Organization Unit

*2 For restrictions when using devices, refer to "Direct access from motion built-in program to link devices" under "Cyclic Transmission" in the following manual.

 MELSEC iQ-R Motion Module User's Manual (Network)

(Type)

It is written when explicitly specifying the data type. For whether the type specification can be used or not, handling when the type is omitted, and type conversion rules, refer to the specifications of the function.

The following types can be specified.

When the type of data by itself specified at [Classification] specifies (BOOL) to the data other than BOOL type, it will be handled as bit position .0 is omitted if it is not specifically specified in each function description.

Type	Description
(BOOL)	Bit
(INT)	Word [signed]
(DINT)	Double word [signed]
(WORD)	Word [unsigned]/bit string [16-bit]
(DWORD)	Double word [unsigned]/bit string [32-bit]
(REAL)	Single-precision real number
(LREAL)	Double-precision real number

Ex.

For [DEV](BOOL)G11500000

Handled as [DEV](BOOL)G11500000.0.

.Bit position

When .Bit position is added to the data whose [Classification] is as follows, the data is dealt with as BOOL type data. From 0 to F can be used for the bit position.

When (Type) and .Bit position are simultaneously specified, the (Type) specification is ignored and the data becomes BOOL type data.

Type	Bit position setting range
[OBJ]	0 to F
[VAR](Only WORD type, DWARD type, INT type, DINT type)	
[DEV]	

@Target modification

Specify auxiliary information for specifying data. The details differ depending on [Classification].

Be sure to specify it depending on the function that uses signals. When specifying the target modification for data types and function that do not require it, the specification will be ignored.

Classification	Target modification		Setting example
	Format	Description	
[OBJ]	@Station address	Specify the station address (IP address information to distinguish device stations.) Like multi-axis drive unit, when one station includes multiple logic axes, specify the No. in order to distinguish logic axes. <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> @192.168.3.10#2 <div style="display: flex; justify-content: space-between; width: 100px;"> <div style="border-top: 1px solid black; width: 40%;"></div> <div style="border-top: 1px solid black; width: 40%;"></div> </div> </div> <div> Multi-drop No. IP address </div> </div> *: The multi-drop No. is set as "# + No. (decimal)". #0: A-axis #1: B-axis #2: C-axis *: Multidrop No. can be omitted. When it is omitted, the device is regarded as a single axis device (for a multiple axes device, it is regarded as specifying 0 in multidrop No.).	@192.168.3.10 @192.168.3.10#2
[VAR]	@POU name ^{*1}	Use it when specifying the local label. When @POU is not written, the data is handled as a global label regardless of the setting which uses the same label name for a global label and a local label.	
[AXIS]	@Position @CumulativePos	Specify the target data (position). @Position and @CumulativePos are set with the MC_SOURCE type enumerator set in "Data name". ^{*2}	@Position @CumulativePos
[DEV]	—	The target modification cannot be set. It is ignored if set.	
[CONST]	@+adding value @-subtracting value	Each time referring the value, it is used to change the read value. When the data type is REAL or LREAL, this setting is invalid.	[CONST](INT)0@-10 ^{*3} [CONST](BOOL)0x00.3@+1 ^{*4}

*1 POU: Program Organization Unit

*2 The enumerators that can be specified are shown below.

○: Can be specified, ×: Cannot be specified

MC_SOURCE type enumerators	Target	Modification	
		@Position	@CumulativePos
1: Set Value (mcSetValue)	Set value of previous operation cycle	○	○
2: Actual Value (mcActualValue)	Actual value of previous operation cycle	○	×
101: Latest Set Value (mcLatestSetValue)	Set value of latest operation cycle	○	○
102: Latest Actual Value (mcLatestActualValue)	Actual value of latest operation cycle	○	×

*3 The referred value will be as "0, -10, -20, -30,".
Specifying [CONST] bit can be used from 0 to 7.

*4 The referred value set as [CONST] (BOOL) 0 x 00.3 @ + 1 switches between TRUE and FALSE every eight (23) cycle. (1 byte value + 1 will be added in every cycle and retrieves bit 3 status)
Specifying [CONST] bit can be used from 0 to 7.

External signal high-accuracy input

For some functions that have external signal inputs such as touch probe and advanced synchronous control, when signals compatible with the external signal high-accuracy input are used for functions which have Trigger input signal (TriggerInput) as an input, high-accuracy control using signal detection time of input devices can be performed.

Signal types other than [OBJ] cannot be used for the external signal high-accuracy input.

Signals that can be used for external signal high-accuracy input differ depending on device stations to be used. Also, their behaviors when an error occurs differ depending on functions. Refer to the specifications of each function.

Device station	Signal name	Description	When used with functions incompatible with high-accuracy input
MR-J5(W)-G series	[OBJ]0x60B90010.6	Toggle status for latch completion at the rising edge of touch probe 1	Operates with the same accuracy as normal signals.
	[OBJ]0x60B90010.7	Toggle status for latch completion at the falling edge of touch probe 1	
	[OBJ]0x60B90010.E	Toggle status for latch completion at the rising edge of touch probe 2	
	[OBJ]0x60B90010.F	Toggle status for latch completion at the falling edge of touch probe 2	
	[OBJ]0x2DE90010.6	Toggle status for latch completion at the rising edge of touch probe 3	
	[OBJ]0x2DE90010.7	Toggle status for latch completion at the falling edge of touch probe 3	

For the setting and program example, refer to the functions compatible with external signal high-accuracy input.

For the settings of each device station, refer to the following.

 Page 767 External signal high-accuracy input

List of functions compatible with the external signal high-accuracy input

- Touch probe
- Advanced synchronous control
- Speed to positioning move

Precautions

- When using [OBJ] as an output destination of a function, do not label the object and link device used as the output destination.
- If a signal used for control is unavailable due to disconnection to equipment, the signal status will not be refreshed. Create an interlock in the user program as necessary.

Relevant add-ons

The following add-on is required to use this function.

- SignalIO
- Axis^{*1}
- ServoDriver_CANopen^{*2}

^{*1} When using [AXIS] as the signal type

^{*2} When using [OBJ] as the signal type

12.2 Touch Probe

This function records (latches) arbitrary data at trigger input signal detection.


Operation of this function for each system status

○: Possible, ×: Not possible

System Status	Operation availability
STOP	×
RUN	○
Moderate error	×
Major error	×

Overall block diagram

The relationship between the touch probe function and other functions is shown below.



Relevant FBs

For details on Motion control FBs, refer to the following.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_TouchProbe	Touch Probe Enabled	Optional data will be recorded due to the trigger event occurrence.
MC_AbortTrigger	Touch Probe Disabled	Disables the latch in execution.

Touch probe valid

This is a function that arbitrary data is recorded (latch) at the timing of detecting the trigger input signal.

It is possible to latch only the data within the range by setting the data range to latch.

When this function is used, execute MC_TouchProbe (Touch Probe Enabled). To stop this function, execute MC_AbortTrigger (Touch Probe Disabled).

Control details

The operation for when a trigger event occurs is shown below.

- Calculations for the latched data are estimated at rising edge/falling edge/both direction of the signal set in Trigger input signal (TriggerInput) (indicate trigger input signal as follows).
- When Enabled window (WindowOnly) is TRUE, whether the latch data at trigger event occurrence is within the range or not is confirmed. Data outside the range are not latched.
- The latch data is stored to the storage location specified Latch position (RecordedPosition) and Storage location of latch data (OutputBuffer) according to Latch mode (RecordMode), and Number of latch times (RecordedCounter) is updated.

■Estimated calculation

The probe data during operation cycle interval is calculated by estimation. The value calculated by estimation at the timing inputted Trigger input signal (TriggerInput) is the latch data. The value is calculated as the figure below.

- When the probe data is the WORD type


■When using the external signal high-accuracy input

Trigger input timing is when the signals are detected at the device station.

For the accuracy of signal detection time, refer to the manual of the device station to be used.


For setting method of high-accuracy input of the external signal selection, refer to the following.

☞ Page 431 External signal high-accuracy input



■When the external signal high-accuracy input is not used

The trigger input timing is operation cycle.




■ Timing chart

- When the FB is normally completed

The following shows examples of latch operation by Latch mode (RecordMode).

Ex.


When Latch mode (RecordMode) is "0: One Shot Mode (OneShot)"



Ex.

When Latch mode (RecordMode) is "1: Frequency Specified Mode (RecordCount)"


Number of latch times (RecordedCounter): 2



Ex.

When Latch mode (RecordMode) is "2: Ring Buffer Mode (RingBuffer)"

Number of latches: 2



- When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Precaution

- Refresh of the Motion control FB I/O argument is carried out at the timing the FB is called, however, the control is executed by using operation cycle regardless of the FB call task (normal/fixed cycle).
- This FB is executed even if the target axis is not connected or an error occurs.
- If the operation cycle over occurs after Executing (Busy) of MC_TouchProbe (Touch Probe Enabled) is TRUE, accuracy of estimated calculation may deteriorate.
- Delay time peculiar to the system occurs to Probe data (ProbeData) set in the touch probe. The delay can be compensated by setting Compensation time (CompensationTime) of the touch probe. The delay time varies depending on the data set in Probe data (ProbeData). Refer to the table below for setting the delay compensation time.

<A rough standard for the delay compensation time peculiar to the system>

Type	Data	Motion Synchronization Station Send/Receive Data Refresh Method (System.PrConst.Link_MotionStationRefreshType)	
		0: Response preferred method (EmphasisResponse)	1: Operation cycle preferred method (EmphasisOperationCycle)
OBJ	0x60640020 (Position actual value)	Operation cycle × 2	Operation cycle × 3
VAR	Axis.Md.SetPosition	Operation cycle × 1	
	Axis.Md.ActualPosition	Operation cycle × 3	Operation cycle × 4
	Axis.Md.lo_TargetPos	Operation cycle × 1	
	Axis.Md.lo_PosActualValue	Operation cycle × 3	Operation cycle × 4
	MR_J5_XXX_PositionActualValue*1	Operation cycle × 2	Operation cycle × 3
AXIS	mcLatestSetValue	0	
	mcSetValue	Operation cycle × 1	
	mcLatestActualValue	Operation cycle × 2	Operation cycle × 3
	mcActualValue	Operation cycle × 3	Operation cycle × 4

*1 The device label name varies depending on the model. Set the data according to the created device label name.

Touch probe invalid

Touch probe is invalidated.

Control details

MC_TouchProbe (Touch Probe Enabled) which is specified in Touch probe ID (TouchProbeID) is invalidated. When MC_AbortTrigger (Touch Probe Disabled) is executed, if the specified MC_TouchProbe (Touch Probe Enabled) specified Touch probe ID (TouchProbeID) is not running, the FB will immediately become Execution completion (Done) is TRUE.


Axis information (Axis) and Trigger input signal (TriggerInput) can be omitted, because those are ignored.

■Timing chart

- When the FB is normally completed

Ex.

When Latch mode (RecordMode) is "2: Ring Buffer Mode (RingBuffer)"



*1 Execution completion (Done) may turn on immediately depending on the execution timing of a program.

- When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Precautions

Relevant add-ons

The following add-on is required to use this function.

- MotionControl_General
- SignalIO
- Axis^{*1}
- NetworkDriver_CCIETSN^{*2}
- ServoDriver_CANopen^{*2}

^{*1} For using the signal type [AXIS] of the external signals

^{*2} For using the signal type [OBJ] of the external signals

System memory capacity

■RAM Usage

Memory capacity of MC_TouchProbe (Touch Probe Enabled) differs depending on Compensation time (CompensationTime).

For details, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Backup RAM Usage

Backup RAM is not used.

Example programs

Example programs when using TPR1 of MR-J5-G-RJ (station address: 192.168.3.1) as Trigger input signal (TriggerInput) of MC_TouchProbe (Touch Probe Enabled) at the rising edge detection are shown below.

Setting of MR-J5-G-RJ

1. Set the connector pin to which TPR1 of the input device to be used is assigned.
Set "2Ch(TPR1)" to "Device selection (PD38.0-1)". (Assign TPR1 to the connector pin CN3-10.)

Setting of the Motion system

1. Set the following objects to TPDO of PDO mapping. For the method of mapping, refer to "CC-Link IE TSN Configuration" Window of the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Network)

Index	SubIndex	Object name
60B9h	00h	Touch probe status 1
60D1h	00h	Touch probe time stamp 1 positive value

2. Create a label to be used as Trigger input signal (TriggerInput) of MC_TouchProbe (Touch Probe Enabled).
Create a new data of the MC_TRIGGER_REF type and set Toggle status (Touch probe status 1 (Bit6)) for latch completion of TPR1 to Target (Target).


Data name	Setting of MC_TRIGGER_REF type data			
	Target (Target)	Signal Detection Method (Detection)	Compensation Time (CompensationTime)	Filter Time (FilterTime)
SignalData0001	[OBJ]0x60B90010.6@192.168.3.1	4: Detection at Rising Edge/ Falling Edge (BothEdges)	0.0	0.0

3. Create a label to be used as Probe data (ProbeData) of MC_TouchProbe (Touch Probe Enabled).
Create a new data of the TARGET_REF type and set Probe data (ProbeData). As an example, the case of setting axis data is shown below.

Data name	Setting of TARGET_REF type data
	Target (Target)
SignalData0002	[AXIS]mcSetValue@Position

4. As the correction value for setting compensation time according to the data set in Probe data (ProbeData) changes depending on actual equipment configurations, make adjustments based on "Settings of the delay compensation time peculiar to the system" below.

Page 435 Precaution



Ex.

Compensation time settings

Setting item	Setting value
Communication period interval setting	1000 [μs]
Operation Cycle Setting (System.PrConst.OperationCycle[1])	0: Synchronizes with the basic cycle of network
Motion Synchronization Station Send/Receive Data Refresh Method (System.PrConst.Link_MotionStationRefreshType)	1: Operation cycle preferred method (EmphasisOperationCycle)
Target (MC_TouchProbe.ProbeData.Target)	[AXIS] mcLatestActualValue@Position

With the above setting, Compensation time (CompensationTime) is as follows.

Setting item	Setting value
Compensation time (MC_TouchProbe.CompensationTime)	-0.003 [s] (-0.001 [s] (operation cycle) × 3)

5. Enable the touch probe function of MR-J5-G-RJ by ST program and start MC_TouchProbe (Touch Probe Enabled).

ST program

```
// Enable the touch probe of MR-J5-G-RJ.
// writeValue is a label of DINT.
// writeParameterExecute, writeParameterDone, and touchProbeExecute are labels of BOOL type.
writeValue := DINT#16#00000013; //Set Bit0, 1, 4.
MC_WriteParameter_1(
  Axis:= Axis0001.AxisRef ,
  Execute:= writeParameterExecute ,
  ParameterNumber:= UDINT#16#60B80010 , //Touch probe function 1
  Value:= DINT_TO_LREAL( writeValue ) ,
  ExecutionMode:= 0 ,
  Options:= UDINT#16#000000010000, //Set the setting value of integer data to the integer value without a sign.
  Done => writeParameterDone);

// Obtain the status of touch probe of MR-J5-G-RJ.
// readValue is a label of LREAL. tempValue is a label of INT.
// readParameterEnable and readParameterValid are labels of BOOL type.
MC_ReadParameter_1(
  Axis:= Axis0001.AxisRef ,
  Enable:= readParameterEnable ,
  ParameterNumber:= UDINT#16#60B90010 , //Touch probe status 1
  Options:= UDINT#16#000000010000, //Set the setting value of integer data to the integer value without a sign.
  Valid => readParameterValid,
  Value => readValue );

tempValue := LREAL_TO_INT(readValue); // When touch probe of MR-J5-G-RJ is enabled
IF tempValue.0 THEN
  touchProbeExecute := TRUE; //Set TRUE to Execute of MC_TouchProbe.
  readParameterEnable := FALSE; //Stop readParameter.
END_IF;

// Set external signal high-accuracy input to TriggerInput of MC_TouchProbe.
// Latch the data set to ProbeData at the rising edge of TPR1 of MR-J5-G-RJ.
// touchProbeRecordedPos is a label of LREAL.
MC_TouchProbe_1(
  Axis:= Axis0001.AxisRef ,
  Execute := touchProbeExecute,
  TriggerInput := SignalData0001 ,
  ProbeData := SignalData0002 ,
  RecordedPosition => touchProbeRecordedPos);
```

12.3 Axis Emulation

Axis emulate function controls axes on the real axis without connecting to the device station.

When using emulate function, even if the device station is not connected, the axis can be operated virtually (regarded as it is connected). This function enables to debug the user program at the start-up of the device or verify the positioning operation. Emulate function can be used on real drive axes.

Emulate function simulates the cyclic communication and the transient communication of the device station. The operations unique to the device station can be simulated by installing emulate models corresponding to each device station as add-ons.

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
SlaveEmulate_Enable	Axis Emulation Enabled	Sets whether the axis is used as an emulate axis. <ul style="list-style-type: none">• FALSE: Invalid• TRUE: Valid

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
SlaveEmulate_Enable	Axis Emulating	Becomes TRUE when driver emulate operation is in execution. <ul style="list-style-type: none">• FALSE: Invalid• TRUE: Valid

Setting procedures

This section describes the procedures to carry out the emulate setting of the real drive axis.

1. Set the real drive axis in the engineering tool, and start up the motion system.
2. Set the real drive axis to use it as the emulate axis in the engineering tool.

Operation during emulate function

The emulate function operation follows the axis parameter setting. The values of the set position and the machine feed value at connection depending on the Absolute Position Control Setting (AxisName.PrConst.PosRestoration_AbsPosEnable) setting are as shown below.

Absolute Position Control Setting (<u>AxisName.PrConst.PosRestoration_AbsPosEnable</u>)	Values of the set position and the machine feed value at connection
-1: Automatic Setting (Acquire from Connected Device) (Auto)	Both the cumulative current position and the machine feed value are "0.0". (The set position is according to the ring counter setting)
0: Disable Absolute Position System (ABSDisabled)	
1: Enable Absolute Position System (Enabled)	When the home position has been established, those are the address when the module power was disconnected most recently. When the home position has not been established, both the cumulative current position and the machine feed value are "0.0". (The set position is according to the ring counter setting) When a drive unit other than MELSERVO is used, if the axis emulation enabled (<u>AxisName.PrConst.SlaveEmulate_Enable</u>) is switched, the absolute position is erased at the system start.

Specification of the emulated device station

While the emulate function is valid, following type of the servo amplifier and servo motor are tentatively connected.

Servo amplifier type	Servo motor type
MR-J5-10G	HK-KT13W

Specification of the emulated MR-J5(W)-G is as follows.

Function	Support	Description
Reception check	×	Check of reception WDC (the controller → the device station) is not carried out.
PDO-related	○	Simulates feedback of MR-J5(W)-G. For details, refer to the following. Page 441 Feedback data specification
	×	When the emulate function is valid, the default mapping of MR-J5(W)-G is used. For the default mapping, refer to MR-J5(W)-G manuals.
SLPM-related	×	SLMP communication simulation is not supported.
Servo alarm-related	○	Simulates servo alarm [AL. 035 Command frequency error] detection
	○	Simulates alarm reset. (A delay to deactivate the alarm does not occur. The alarm is deactivated immediately.)
Motor type	○	Standard motor of MR-J5 (HK-KT13W) is available. A speed unit of the servo amplifier is fixed to 0.01 [r/min].
Operation mode	○	Position control operation by csp (cyclic synchronous position mode) is available.
	○	Velocity control operation by csv (cyclic synchronous velocity mode) is available.
	○	Torque control operation by cst (cyclic synchronous torque mode) is available.
	○	Homing by hm (homing mode) is available. The homing method supports the driver homing method (data set method) only.
	○	Continuous operation to torque control by ct (continuous operation to torque control mode) is available. (The operation is the same as cst.)
	×	Pressure control by cspr (cyclic synchronous pressure mode) is not available.
External signal-related	○	<ul style="list-style-type: none"> Input via the controller is only available. (Stop operation of the device station when the FLS is OFF is not simulated. By FLS detection, the command from the controller stops and then the servo motor stops as well. In the case of input via the servo amplifier, the input value is always OFF.
	○	<ul style="list-style-type: none"> Input via the controller is only available. (Stop operation of the device station when the RLS is OFF is not simulated. By RLS detection, the command from the controller stops and then the servo motor stops as well. In the case of input via the servo amplifier, the input value is always OFF.

Feedback data specification

No.	Object name	Object detail	Support	Remark
1	1D02h/01h: Watch dog counter UL	—	○	—
2	6061h/00h: Modes of operation display	—	○	—
3	6064h/00h: Position actual value	—	○	The value is always the same as the value of Target position (607AH).
4	606Ch/00h: Velocity actual value	—	○	—
5	60F4h/00h: Following error actual value	—	○	The value is always 0.
6	6041h/00h: Statusword	—	○	—
7	6077h/00h: Torque actual value	—	○	<ul style="list-style-type: none"> The value is always 0 when set to a mode other than cst (cyclic synchronous torque mode) or ct (continuous operation to torque control mode). The value is always the same as the value of Target position (6071H).
8	2A41h/00h: Current alarm	—	○	—

Precaution

- When executing the all axes emulate switching, it takes time to complete.
- If a motor is rotated when the device station which is connected actually is set to emulation enabled, as it is switched to disabled, the position information is restored as the axis is recognized as it moves from the position which the axis moves during emulate enabled to the position of the connected device station during power-OFF.
- In the emulation being disabled, when the device station is used with the setting that Absolute Position Control Setting (AxisName.PrConst.PosRestoration_AbsPosEnable) is "-1: Automatic Setting (Acquire from Connected Device) (Auto)" and the connected device is used in the setting of Use Absolute Position System, change the setting to "1: Enable Absolute Position System (Enabled)" before switching emulation to enabled. When the emulation is enabled, "-1: Automatic Setting (Acquire from Connected Device) (Auto)" becomes "0: Disable Absolute Position System (ABSDisabled)", therefore the absolute position is erased next time, the emulation is switched to disabled.
- In the state which the add-on ServoDriver_CANopen is enabled, the axis always starts with the emulation enabled state if the add-on NetworkDriver_CCIETSN is disabled.

12.4 Inter-Module Synchronization Function

The inter-module synchronization function can synchronize the control timings among multiple modules on the same base.

Operation of this function for each system status

■System operation status

○: Possible, △: Possible (restricted), ×: Not possible

Status	Operation availability
STOP	△*1
RUN	○
Moderate error	△*1
Major error	×

*1 Operation is possible when the CPU module is RUN.

■Interrupt operation status

○: Possible, △: Possible (limited)

Status	Operation availability
STOP	△*1
RUN	○

*1 The inter-module synchronous interrupt program is not possible.

Control details

This function can synchronize the inter-module synchronous interrupt program (I44) execution cycle of the CPU module and the operation cycle of the Motion module.

For the parameter setting of the inter-module synchronization, refer to "CC-Link IE TSN Network Synchronous Communication Function" in the following,

📖 MELSEC iQ-R Motion Module User's Manual (Network)

or refer to the following.

📖 MELSEC iQ-R Inter-Module Synchronization Function Reference Manual

Point

When using the inter-module synchronous function, the EI instruction must be executed on the CPU module to enable the inter-module synchronous interrupt program (I44). When the status is changed to RUN while the inter-module synchronous interrupt program (I44) is disabled, the buffer memory refresh task is not executed. "Cycle Over" (error code: 320CH) may occur.

Operation using the multiple Motion module


When the multiple Motion module is the synchronous target, execution timing of a fixed cycle program can be synchronized among modules.*1

Note that the synchronization is applied only when the fixed scan interval setting of fixed cycle program is as follows.

Communication cycle $\times 2^n$ (Up to 128ms interval)*2

Other fixed cycle programs of the fixed scan interval setting may not be synchronized the execution timing among modules.

- *1 Even if the Motion control FBs is started in the fixed cycle program, start timing differs from each module because analysis complete timing of the instruction is different. For the method to synchronize the start timing among multiple modules, refer to the following.
[Page 445 Synchronization of positioning control start timing using the function](#)
- *2 After enabling the interrupt program (after executing the EI instruction), the first execution of the fixed cycle program should needs to match among the modules so that the execution is performed after the cycle set in the fixed scan interval setting. (Up to 128 [ms])



Synchronization of positioning control start timing using the function

The timing of positioning start can be synchronized among different modules. After the positioning is started, each Motion module operates independently. The setting and procedure are shown below.

■Setting

1. Set the Motion module which is synchronized the timing of positioning start as the synchronous target module.

For the parameter setting of the inter-module synchronization, refer to "CC-Link IE TSN Network Synchronous Communication Function" in the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Network)

2. Set the same cycle between the inter-module synchronous cycle of the CPU module and the operation cycle of the Motion module. If not, the synchronization of the timing cannot be assured.


■Procedure example

1. Set the velocity override factor "0.00" in the arbitrary buffer memory (user setting area).
2. Perform positioning start after setting the setting value of the buffer memory written in Step 1 to Velocity Override Factor (AxisName.Cd.VelocityOverride, AxesGroupName.Cd.VelocityOverride) by the fixed cycle program of the Motion module.*1
3. Confirm Controlling (Active) of all Motion control FBs becomes ON, and set the velocity override factor "10.00" in the buffer memory used in Step 1 within the same inter-module synchronous cycle while the inter-module synchronous interrupt program (I44) is performed.
4. Set the one-tenth value of the buffer memory setting value written in Step 3 to Velocity Override Factor (AxisName.Cd.VelocityOverride, AxesGroupName.Cd.VelocityOverride) by the fixed cycle program of the Motion module.*2

*1 When using the time-fixed method, set "1: Maximum Acceleration/Deceleration (MaximumAcceleration)" to Operation Selection at Start Acceleration/Deceleration 0 (AxisName.Pr.AccelerationZeroBehavior, AxesGroupName.Pr.AccelerationZeroBehavior). When setting "1: Error (Not Started) (ACCErrror)", if Velocity Override Factor (AxisName.Cd.VelocityOverride) is set to "0.00", "Acceleration/Deceleration 0 Specified Operation Error at Start" (error code: 1A0CH) occurs and the axis will not start.

*2 The processing time of operation cycle temporarily increases because the velocity of all axes is changed at the same time. Take actions such as reducing the number of the target axis, when the operation cycle is exceeded.

■Operation example



Synchronous control using inter-module synchronization

The synchronized operation synchronizing with the same input axis among different modules can be performed. The setting and procedure are shown below.

■Setting


1. Set the Motion module used for the synchronized control as the inter-module synchronous target.
For the parameter setting of the inter-module synchronization, refer to "CC-Link IE TSN Network Synchronous Communication Function" in the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Network)

2. Set the same cycle between the inter-module synchronous cycle of the CPU module and the operation cycle of the Motion module. If not, the simultaneous start cannot be assured.


■Procedure example

1. Prepare the synchronous control FB set the virtual encoder axis as the master axis for each module.
2. Set Connection Command (AxisName.Cd.Encoder_Connect) and Connection Status (AxisName.Md.Encoder_Connected) as public labels.*¹
3. Set Connection Command (AxisName.Cd.Encoder_Connect) of each module to TRUE. Confirm whether the virtual encoder axis of all modules is connected completely by checking Connection Status (AxisName.Md.Encoder_Connected).
4. Start the synchronous control FB of all modules.
5. Write arbitrary values (position data of the virtual encoder) into arbitrary buffer memory (user setting area) in the inter-module synchronous interrupt program (I44).
6. Write the setting values of the buffer memory written in Step 5 into Encoder Input Value (AxisName.Cd.Encoder_InputValue) by the fixed cycle program of the Motion module.



*¹ The public label is refreshed at END except executing the inter-module synchronous interrupt program (I44) so that the things which are communicated by synchronizing with the inter-module synchronous cycle cannot be used as public labels, but the things which are not communicated in inter-module synchronous cycle can be used as public labels.

■Operation example



Program example

Simultaneous start with multiple modules

■ Scan program [CPU module]

ST program

```
// PLC READY ON
Y10 := TRUE;
Y40 := TRUE;

// Interruption enabled
EI(TRUE);

// Confirm that Ready and Synchronization flag becomes ON
IF (X10 = TRUE) AND (X11 = TRUE) AND (X40 = TRUE) AND (X41 = TRUE) THEN
    // Servo ON
    MCv_AllPower_1.Enable := TRUE;
    MCv_AllPower_1.ServoON := TRUE;
    MCv_AllPower_2.Enable := TRUE;
    MCv_AllPower_2.ServoON := TRUE;
END_IF;

// Axes group enabled
IF (RD78_0040.Axis0001.Md.AxisStatus = 4) AND (RD78_0040.Axis0002.Md.AxisStatus = 4) THEN
    MC_GroupEnable_1.Execute := TRUE;
END_IF;

// Set the velocity override factor 0 to arbitrary buffer memory (user setting area)
IF (RD78_0010.Axis0001.Md.AxisStatus = 4) AND (RD78_0040.AxesGroup001.Md.GroupStatus = 4) AND (G_bAxisStart = FALSE) THEN
    U1#G11500000 := 0;
    U4#G11500000 := 0;
END_IF;

// Confirm that the velocity override factor is 0 and then execute the positioning start
IF (RD78_0010.Axis0001.Md.VelocityOverride = 0.0) AND (RD78_0040.AxesGroup001.Md.VelocityOverride = 0.0) THEN
    MC_MoveAbsolute_1.Execute := TRUE;
    MCv_MoveLinearInterpolateAbsolute_1.Execute := TRUE;
END_IF;

// Confirm that Active of all Motion control FBs becomes ON
IF (MC_MoveAbsolute_1.Active = TRUE) AND (MCv_MoveLinearInterpolateAbsolute_1.Active = TRUE) THEN
    G_bAxisStart := TRUE; // Set global labels of BOOL type to TRUE
END_IF;

// FB setting of the programmable controller
MCv_AllPower_1(
    Axis:= RD78_0010.Axis0001.AxisRef );
MCv_AllPower_2(
    Axis:= RD78_0040.Axis0001.AxisRef );
MC_GroupEnable_1(
    AxesGroup:= RD78_0040.AxesGroup001.AxesGroupRef );
MC_MoveAbsolute_1(
    Axis:= RD78_0010.Axis0001.AxisRef ,
    Position:= 10000.0 ,
    Velocity:= 1000.0 ,
    Acceleration:= 1000.0 ,
    Deceleration:= 1000.0 ,
    Direction:= 1 );
MCv_MoveLinearInterpolateAbsolute_1.LinearAxes[0] := 1;
MCv_MoveLinearInterpolateAbsolute_1.LinearAxes[1] := 2;
MCv_MoveLinearInterpolateAbsolute_1.Position[0] := 10000.0;
MCv_MoveLinearInterpolateAbsolute_1.Position[1] := 10000.0;
MCv_MoveLinearInterpolateAbsolute_1.Direction[0] := 1;
MCv_MoveLinearInterpolateAbsolute_1.Direction[1] := 1;
MCv_MoveLinearInterpolateAbsolute_1(
    AxesGroup:= RD78_0040.AxesGroup001.AxesGroupRef ,
    Velocity:= 1000.0 ,
    Acceleration:= 1000.0 ,
    Deceleration:= 1000.0 );
```

■Event (Inter-module synchronous interrupt program (I44)) [CPU module]

ST program

```
// Set the velocity override factor 10 to arbitrary buffer memory (user setting area)
IF G_bAxisStart = TRUE THEN
  // Actual setting value becomes one-tenth
  U1#G11500000 := 10;
  U4#G11500000 := 10;
END_IF;
```

■Normal execution type program [Motion module 1] [Motion module 2]

ST program

```
// Interruption enabled
bElout := EI(TRUE);
```

■Fixed scan execution type program [Motion module 1]

ST program

```
// Set the one-tenth value of the arbitrary buffer memory (user setting area) setting value to the velocity override factor
wVelocityOverride_10 := G11500000;
leVelocityOverride_10 := INT_TO_LREAL( wVelocityOverride_10 );
leVelocityOverride := leVelocityOverride_10 / 10.0;
Axis0001.Cd.VelocityOverride := leVelocityOverride;
```

■Fixed scan execution type program [Motion module 2]

ST program

```
// Set the one-tenth value of the arbitrary buffer memory (user setting area) setting value to the velocity override factor
wVelocityOverride_10 := G11500000;
leVelocityOverride_10 := INT_TO_LREAL( wVelocityOverride_10 );
leVelocityOverride := leVelocityOverride_10 / 10.0;
AxesGroup001.Cd.VelocityOverride := leVelocityOverride;
```

Simultaneous control with multiple modules

■ Scan program [CPU module]

ST program

```
// PLC READY ON
Y10 := TRUE;
Y40 := TRUE;

// Interruption enabled
EI(TRUE);

// Confirm that Ready and Synchronization flag becomes ON
IF (X10 = TRUE) AND (X11 = TRUE) AND (X40 = TRUE) AND (X41 = TRUE) THEN
  // Servo ON
  MCv_AllPower_1.Enable := TRUE;
  MCv_AllPower_1.ServoON := TRUE;
  MCv_AllPower_2.Enable := TRUE;
  MCv_AllPower_2.ServoON := TRUE;
END_IF;

// Set AxisName.Cd.Encoder_Connect to TRUE
RD78_0010.Axis0001.Cd.Encoder_Connect := TRUE;
RD78_0040.Axis0001.Cd.Encoder_Connect := TRUE;

// Start the synchronous control FB of all modules after AxisName.Md.Encoder_Connected becomes ON
IF (RD78_0010.Axis0001.Md.Encoder_Connected = TRUE) AND
  (RD78_0040.Axis0001.Md.Encoder_Connected = TRUE) AND
  (RD78_0010.Axis0001.Md.AxisStatus = 4) AND
  (RD78_0040.Axis0001.Md.AxisStatus = 4) AND
  (RD78_0010.Axis0002.Md.AxisStatus = 4) AND
  (RD78_0040.Axis0002.Md.AxisStatus = 4) THEN
  MC_CamIn_1.Execute := TRUE;
  MC_CamIn_2.Execute := TRUE;
END_IF;

// Confirm that Active and InSync of synchronous control FB of all modules become ON
IF (MC_CamIn_1.Active = TRUE) AND (MC_CamIn_1.InSync = TRUE) AND
  (MC_CamIn_2.Active = TRUE) AND (MC_CamIn_2.InSync = TRUE) THEN
  G_bAxisStart := TRUE; // Set global labels of BOOL type to TRUE
END_IF;

// FB of the programmable controller
MCv_AllPower_1( Axis:= RD78_0010.Axis0001.AxisRef );
MCv_AllPower_2( Axis:= RD78_0040.Axis0001.AxisRef );
MC_CamIn_1.CamTableID.ProfileID.Number := 1;
MC_CamIn_1(
  Master:= RD78_0010.Axis0001.AxisRef,
  Slave:= RD78_0010.Axis0002.AxisRef );
MC_CamIn_2.CamTableID.ProfileID.Number := 1;
MC_CamIn_2(
  Master:= RD78_0040.Axis0001.AxisRef,
  Slave:= RD78_0040.Axis0002.AxisRef );
```

■ Event (Inter-module synchronous interrupt program (I44)) [CPU module]

ST program

```
// Write arbitrary values (position data of the virtual encoder) into arbitrary buffer memory (user setting area)
IF G_bAxisStart = TRUE THEN
  IF dEncoderInputValue < 10000 THEN
    dEncoderInputValue := dEncoderInputValue + 1;
    U1\G11500000:D := dEncoderInputValue;
    U4\G11500000:D := dEncoderInputValue;
  END_IF;
END_IF;
```

■ Normal execution type program [Motion module 1] [Motion module 2]

ST program

```
// Interruption enabled
bElout := EI(TRUE);
```


■Fixed scan execution type program [Motion module 1] [Motion module 2]

ST program

```
// Write the setting value of arbitrary buffer memory (user setting area) into Encoder Input Value
Axis0001.Cd.Encoder_InputValue := G11500000:D;
```

Precautions

- When performing the simultaneous start using the inter-module synchronization, note that the inter-module synchronous cycle needs to be the same as the buffer memory refresh cycle.
When the inter-module synchronous cycle is different from the buffer memory refresh cycle, the data might be inconsistent. Perform mutual exclusion in a sequence program and a motion program.
- The maximum cycle is 128ms assured by the inter-module synchronization. When using the instruction or the fixed cycle program which are operated in the cycle exceeded 128ms, the synchronization among the modules are not assured.
- When using the inter-module synchronization in the multiple Motion module, even if PLC READY is changed OFF to ON at the same timing, the number of axis to used and required time to analyze the program so that READY does not become ON simultaneously. When performing the simultaneous start using the inter-module synchronization, execute the positioning start after READY becomes ON in the all modules performing the simultaneous start.
- When the CPU module status is changed from RUN to STOP, the buffer memory may not be updated for few cycles.
- When the inter-module synchronization is enabled, the public labels are refreshed at END except executing the inter-module synchronous interrupt program (I44). The refresh setting of the module parameter (Motion module) is disabled.

Relevant add-ons and versions

The following add-on is required to use this function.

- baseSystem (version "1.16" or later)

The following boot software programs are required to use this function.

- Network boot software: version "7" or later
- Boot software: version "7" or later

When the Motion module installed with earlier versions of add-ons and boot software is the target of the inter-module synchronization, an error occurs on the CPU modules.

Combination of the version

The version of the engineering tool which is compatible with this function is as follows.

Engineering tool	Version
GX Works3	"1.075D" or later

Combination of the network modules

The network modules which are compatible with this function are as follows.

○: Supported, ×: Not supported

Inter-module synchronous master	Inter-module synchronous slave	Support information	Remark
RD78G(H)	RD78G(H)	○	—
	RJ71GN11-T2	×	"Inter-module Synchronization Master Setting Error" (error code: 3603H) occurs on the inter-module synchronous slave.
RJ71GN11-T2	RD78G(H)	○	—

12.5 Master-Slave Operation

Using the "master-slave operation function" of the servo amplifier, the "master-slave operation function" controls the master axis with the motion system, while the slave axes are controlled by data communication between servo amplifiers (driver communication) without using the motion system.

The master axis is specified from one of the real drive axes.

The slave axis is specified from a motion control station for which axes are not assigned.

One master axis can control up to eight slave axes.

To use the master-slave operation function, refer to the following combinations of model and version.

Item	Model	Version
Motion module	<ul style="list-style-type: none"> RD78G_ RD78GHV RD78GHW 	Add-on baseSystem version "1.28" or later
Servo amplifier	<ul style="list-style-type: none"> MR-J5-_G_(-RJ) MR-J5D1-_G_ 	"D0" or later*1

*1 When a servo amplifier model that does not support master-slave operation or a servo amplifier installed with a version that does not support master-slave operation is used mistakenly, the servo alarm [AL. 037.1 _Parameter setting range error] will occur in the servo amplifier.

The following shows the number of axes that can be set when the maximum number of master axes are set for each communication period interval.

Communication period interval setting*1	Driver communication cycle*2	Motion control station		Number of standard stations*4	Total number of stations*5
		Number of master axes*3	Number of slave axes		
31.25 [μ s]*6	Not supported	—	—	—	—
62.50 [μ s]*6		—	—	—	—
125.00 [μ s]	125.00 [μ s]	1	1	0	2
250.00 [μ s]		3	3	0	6
500.00 [μ s]		5	5	0	10
1000.00 [μ s]	250.00 [μ s]	7	7	5	19
2000.00 [μ s]		12	12	6	30
4000.00 [μ s]		13	14	6	33
8000.00 [μ s]*6	Not supported	—	—	—	—

*1 For operation cycles which can be set for the system configuration to be used, refer to the following.

☞ Page 458 Communication period setting

*2 This is the communication period of master-slave operation. For details, refer to the following.

☞ Page 458 Communication period setting

*3 This is based on "A rough standard for the number of axes and the operation cycle settings when using the positioning control".

(☞ Page 109 A rough standard for the number of axes and the operation cycle settings when using the positioning control)

*4 This is calculated based on the remote I/O module (model: NZ2GN12A42-16DTE, RX: 16 points, RY: 16 points, RW: 4 points, RWw: 4 points).

*5 This is the number of stations when the communication mode is set to "unicast mode", communication speed is set to "1Gbps", and MR-J5-G is connected without using an industrial switch (CC-Link IE TSN Class certified). If this exceeds the standard number of stations, the connection becomes unstable. (For example, errors such as cyclic transfer failure occur.)

*6 If this value is set to "Communication Period Interval Setting" under "Basic Settings" of the module parameter, "Driver Communication Period Interval Setting Error" (error code: 3236H) occurs.

Operation of this function for each system status

○: Possible, ×: Not possible

System status	Operation availability
STOP	×
RUN	○
Moderate error	×
Major error	×

Relevant variables

Axis parameter constant (AxisName.PrConst.)

Variable/Structure name	Name	Details
MasterSlave_Setting	Master-slave Operation Setting	Sets the station address of the slave axis to be used in master-slave operation. Master-slave operation setting (MasterSlave_Setting) is the structure of MASTER_SLAVE_SETTING type.

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
MasterSlave_ReadyOnGroup	Master-slave Operation - Axes Group Ready	TRUE is stored for each group when the NMT state of the master-slave operation axes have all changed to Operational. Always becomes FALSE when "Master-slave Operation Setting" is set to "Not used" in module parameter (Motion) of GX Works3, or the axis emulate function is enabled. <ul style="list-style-type: none">• FALSE: Not READY• TRUE: READY

System monitor data (System.Md.)

Variable/Structure name	Name	Details
MasterSlave_AxisSearching	Master-slave Operation - Searching for Axes	Indicates whether the master-slave operation axis search for the entire system is complete or not. Always becomes FALSE when "Master-slave Operation Setting" is set to "Not used" in module parameter (Motion) of GX Works3. <ul style="list-style-type: none">• FALSE: Axis searching complete• TRUE: Searching for axes

Point

If all axes set to master-slave operation are not detected at the start of communication with the servo amplifier, all connected axes, including normal axes cannot be operated. (The LED display of the servo amplifier remains "b__" or "H__".)

When failing to connect to the servo amplifier and Master-slave operation - searching for axes (System.Md.MasterSlave_AxisSearching) is searching for axes, check that all axes that are set to master-slave operation are connected.


MASTER_SLAVE_SETTING

Variable/Structure name	Name	Details
AddressOfStation[1..8]	Slave Axis Station Address Setting	Sets the station address (IP address) of a slave axis of master-slave operation with a character string. <Example> 192.168.3.10

Control details

The servo amplifier set as the master axis receives commands (positioning command, speed command, torque command) from the motion system, and sends the control data to the servo amplifier set as slave axis by driver communication between servo amplifiers.

The servo amplifier set as the slave axis is controlled by the control data transmitted from the master axis by driver communication between servo amplifiers. Each control of the motion system is executed in the master axis.



■ Master axis

- Operates according to received positioning command/speed command/torque command from the motion system.
- Sends control data to the slave axes.

■ Slave axis

- Operates according to the received control data from the master axis by driver communication.
- Sends control status to the master axis. (Applicable only when the servo parameter "Master axis 1 control slave axis No. setting when the slave for driver communication is set (PD23.1)" is set)

Restriction

- The inter-module synchronization function cannot be used when master-slave operation is enabled. When this function is used, "Driver Communication Setting Error 2" (error code: 3231H) occurs.
- The master-slave operation is not applicable to network configurations including device stations incompatible with mixed communication cycles. Refer to the manuals for the device stations to be used to determine whether they support mixed communication cycles.

Point

- There is no restriction on the connection order.
- Make settings to the master axis that allow it to control the slave axis so that the master axis can detect errors on the slave axis and stop control. (Set the servo parameter "Driver communication setting - slave - master axis 1 - control slave axis No. setting (PD23.1)" to "1 to 8 (Master axis control station)").
- Use this function when multiple motors are used to drive one mechanism. The master axis and slave axis should be coupled to prevent slippage.
- When slippage occurs and there is a risk of excessive movement of the slave axis, wire the upper limit signal (FLS) and the lower limit signal (RLS) to the master axis to make sure that the slave axis stops completely.

Master-slave operation control method

■Checking that preparations for master-slave operation have been completed


Check if the master-slave operation control can be started.

After preparation, execute servo ON of the master axis and slave axis, and start the control of the master axis.

Check if the master-slave operation is ready with Master-slave operation - axes group ready

(AxisName.Md.MasterSlave_ReadyOnGroup) of the master axis.

The procedure from connection to master-slave operation start is shown below.



Point

Only at system start, if data link is not enabled for all axes set to master-slave operation, all connected axes, including normal axes cannot be operated. (The LED display of the servo amplifier remains "b__".)

■Servo ON

Since the master axis is a real drive axis, execute servo ON with MC_Power (Operation Available) or MCv_AllPower (All Axes Operation Available).

The slave axis executes servo ON in the user program by referring to the slave labels. For details on the user program, refer to the following.

☞ Page 775 Master-slave operation

■Master axis control

The Motion control FB is used to control the master axis.

■Slave axis monitoring

The slave axis performs monitoring in the motion system by referring to the slave labels.

■Error reset

Since the master axis is a real drive axis, execute the error reset with MC_Reset (Axis Error Reset).

The slave axis executes the error reset in the Motion system by referring to the slave labels. For details on the user program, refer to the following.

☞ Page 775 Master-slave operation

Point

- Set the slave axis as a control slave axis (set the servo parameter "Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting (PD23.1)" set to "1 to 8") to enable the master-slave operation simultaneous stop function. If the slave axis is not set as a control slave axis, the master-slave operation simultaneous stop function will not be enabled when an error occurs.
- If a forced stop occurs during positioning operation of the master axis, the master axis stops according to the forced stop method. The slave axis stops by the master-slave operation simultaneous stop function. For details, refer to "Master-slave operation function" of the following manual.

📖 MR-J5-G/MR-J5W-G User's Manual (Communication Function)

Slave axis operation mode

When the master-slave operation is enabled, the slave axis control mode operation is fixed as slave axis torque mode (slt). Therefore, the "Modes of operation display (6061H)" object data for the slave axis is fixed to "-110 (slave axis torque mode)". For objects used in the slave axis torque mode, refer to "Master-slave operation function" of the following manual.

 MR-J5-G/MR-J5W-G User's Manual (Communication Function)

Parameter setting

This section describes the parameters to be set in GX Works3 to perform master-slave operation.

Setting procedure

The setting procedure of the parameters is shown below.

Set the following in module parameter (Network).

For details of the parameters, refer to the following.

 Page 456 Module parameter (Motion)

 Page 457 Module parameter (Network)

 Page 461 Module extended parameter

In addition, refer to the following when using an industrial switch (CC-Link IE TSN Class certified).

 Page 775 Master-slave operation

Operating procedure

1. Set [Module operation setting] ⇒ [Master-slave operation setting] under "Module Parameter (Motion)" to "Used".
2. Set the network configuration in the "CC-Link IE TSN Configuration" screen under [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting] of "Module Parameter (Network)".
3. In the "CC-Link IE TSN Configuration" screen, set the servo parameters to be automatically set to the servo amplifier. (Set the parameters related to the master-slave operation of the servo amplifier.)
4. Set parameters such as communication period settings for master-slave operation in [Basic Settings] and [Application Settings] of "Module Parameter (Network)".
5. With "Module Extended Parameter" ⇒ [Motion control setting function] ⇒ [Axis] ⇒ [Add New Data], generate a real drive axis for the servo amplifier specified as the master axis. No axis is generated for the slave axis.
When generating an axis, do not specify the station address of the slave axis in Station address setting (AxisName.PrConst.AddressOfStation).
6. With "Module Extended Parameter" ⇒ [Motion control setting function] ⇒ [Axis] ⇒ [Real Drive Axis] ⇒ [Axis Parameter Setting], set the master-slave operation parameter settings.
7. Write the project to the CPU module and the motion system, and restart the system.
8. After the system restart, the servo parameters are automatically distributed to the servo amplifier. After the automatic parameter distribution to the servo amplifier, "Power Not Turned ON After Parameter Distribution" (error code: 1C4CH) occurs, however this is a normal operation.
9. Restart the system.

Module parameter (Motion)

Set the following parameters in module parameter (Motion) of GX Works3 to perform master-slave operation. (This section only describes the parameters to be set.)

 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Parameter (Motion)] ⇒ "Parameter editor" screen

Item		Setting details
Module operation setting	Master-slave operation setting	Set whether to use the master-slave operation function or not.

Module parameter (Network)

Set the following parameters in module parameter (Network) of GX Works3 to perform master-slave operation. (This section only describes the parameters to be set.)

 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen

Item			Setting details
Basic settings	Network configuration settings	Motion control station	<p>■ When setting as the master axis Set to motion control station.</p> <p>■ When setting as the slave axis Set to motion control station.</p>
		Parameter automatic setting	<p>Set the servo parameters to be distributed from the motion system to the servo amplifier. For details, refer to the following.  Page 459 Parameter automatic setting</p>
		PDO mapping setting	<p>Set the PDO mapping. For details on objects to be mapped to the slave axis, refer to the following.  Page 460 Object data that require mapping for the slave axis</p>
		Communication period setting	<p>Set the communication period. *: When setting as the master axis or the slave axis, set to "Basic Period".</p>
		CC-Link IE TSN Class	<p>Set "CC-Link IE TSN Class B" for the station set to the master axis or the slave axis.</p>
	Communication period setting	Basic period setting	Setting in units of 1μs
			Communication period interval setting (Do not set it in units of 1μs)
			Communication period interval setting (Set it in units of 1μs)
			System reservation time
			Cyclic transmission time
			Transient transmission time
		Multiple period setting	Normal-speed
			Low-speed
	Connection device information	TSN HUB setting	
Application settings	Communication speed	Communication speed	

■Communication period setting

Set the communication period interval setting and the cyclic transmission time as below when using master-slave operation.

• Communication period interval setting

When using the master-slave operation, set a value equal to or more than the following formula for the communication period interval setting.

When a value smaller than the formula value is set for the communication period interval setting, "Driver Communication Period Interval Setting Error" (error code: 3236H) occurs. When an error occurs, change the communication period interval setting according to the corrective action on the module diagnostic window.

Formula

Cyclic transmission time $[\mu\text{s}]^{*1} \times \text{Driver communication magnification (basic)}^{*2} + \text{Cyclic processing time other than driver communication } [\mu\text{s}]^{*3} + (\text{Number of valid axes for driver communication}^{*4} \times 1.39 [\mu\text{s}])$

- *1 Indicates the cyclic transmission time set in the basic communication period setting.
- *2 Indicates the value obtained by dividing the communication period interval time setting by the driver communication cycle. For details on the driver communication cycle, refer to "Driver communication cycle" in this section.
- *3 For the calculation method of the cyclic processing time other than the driver communication, refer to the following.
 MELSEC iQ-R Motion Module User's Manual (Network)
- *4 Indicates the total number of stations set as the master axis and the slave axis.

• Cyclic transmission time

When using master-slave operation, set the cyclic transmission time to a value equal to or more than the value obtained by the following formula, and equal to or less than 216.00 $[\mu\text{s}]$.

When a value outside the range is set for the cyclic transmission time, "Driver Communication Cyclic Transmission Time Setting Error" (error code: 3235H) occurs. When an error occurs, change the cyclic transmission time according to the corrective action on the module diagnostic window.

Formula

Cyclic processing time other than driver communication $[\mu\text{s}]^{*1} + (\text{Number of valid axes for driver communication} \times 2.715 [\mu\text{s}])$

- *1 The cyclic processing time other than driver communication is displayed under "Cyclic Transmission Time (Min.)" (1) in the "CC-Link IE TSN Configuration" window.
 For the calculation method of the cyclic transmission time (minimum value), refer to the following.
 MELSEC iQ-R Motion Module User's Manual (Network)

(1) →

- Driver communication cycle

The communication period (driver communication cycle) for master-slave operation is automatically set to 125 [μs] or 250 [μs] by "Communication period interval setting" in "Basic period setting".

Communication period setting	Driver communication period	Driver communication magnification (Basic)
125 [μs]	125 [μs]	1
250 [μs]	125 [μs]	2
500 [μs]	125 [μs]	4
1000 [μs]	250 [μs]	4
2000 [μs]	250 [μs]	8
4000 [μs]	250 [μs]	16

- Check the operating status of the current master-slave operation with the following link special registers (SW).

No.	Name
SW04C0	Driver communication cycle interval [μs]
SW04C1	Driver communication cycle system reservation time [μs]
SW04C2	Driver communication cycle cyclic transmission time [μs]
SW04C3	Driver communication cycle transient transmission time [μs]
SW04C4	Driver communication magnification (basic)
SW04C5	Driver communication magnification (medium-speed)
SW04C6	Driver communication magnification (low-speed)

■Parameter automatic setting

Set the servo parameters for each master-slave operation station by the parameter automatic setting of GX Works3.

For the setting details, refer to the following.

📖MR-J5-G/MR-J5W-G User's Manual (Parameters)

- Driver communication operation setting

No.	Name	Setting details	Setting target	Setting example			
				Axis 1	Axis 2	Axis 3	Axis 4
PD15.0	Master axis operation selection	<ul style="list-style-type: none"> Set the master axis. 0: Disabled (master-slave operation function is not used) 1: Enabled (set this servo amplifier for the master axis)	Master	1 (Master axis)	0	0	0
PD15.1	Slave axis operation selection	<ul style="list-style-type: none"> Set the slave axis. 0: Disabled (master-slave operation function is not used) 1: Enabled (set this servo amplifier for the slave axis)	Slave	0	1 (Slave axis)	1 (Slave axis)	1 (Slave axis)

- Driver communication slave axis setting (network setting)

No.	Name	Setting details	Setting target	Setting example			
				Axis 1	Axis 2	Axis 3	Axis 4
PD22	Driver communication setting - Slave - Master axis 1 - Station No. setting	<ul style="list-style-type: none"> Set the station No. of the master axis to which the slave axis belongs. 0: Disabled 1 to 255: Master axis station No.	Slave	0 (Disabled)	1 (Axis 1)	1 (Axis 1)	1 (Axis 1)
PD23.1	Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting	<ul style="list-style-type: none"> Set the identifier (control slave axis No.) of the own slave axis for the slave axis. Set identifiers in order from 1 in a driver communication group (master axis to which the slave axis belongs). 0: Disabled 1 to 8: Control slave axis No.	Slave	0 (Disabled)	1 (Slave axis No.1)	2 (Slave axis No.2)	3 (Slave axis No.3)

- Driver communication slave axis setting (master-slave operation setting)

No.	Name	Setting details	Setting target	Setting example			
				Axis 1	Axis 2	Axis 3	Axis 4
PD30	Master-slave operation - Slave-side torque command coefficient	Set the command torque coefficient of the slave axis for the output torque of the master axis.	Slave	0 (Disabled)	100 [%]	100 [%]	100 [%]
PD31	Master-slave operation - Slave-side speed limit coefficient	Set the velocity limit value coefficient of the slave axis for the velocity limit value of the master axis.	Slave	0 (Disabled)	100 [%]	100 [%]	100 [%]
PD32	Master-slave operation - Slave-side speed limit adjusted value ^{*1}	Set a minimum value for velocity limit value of the slave axis.	Slave	0.00 (Disabled)	0.00 [r/min]	0.00 [r/min]	0.00 [r/min]
PV33	Master-slave operation - Speed limit adjusted value extension setting ^{*2}	Set a minimum value for velocity limit value of the slave axis.	Slave	0 (Disabled)	0	0	0

*1 This setting is valid only when the "Speed/acceleration/deceleration unit selection (PT01.1)" is set to "0".

*2 This setting is valid only when the "Speed/acceleration/deceleration unit selection (PT01.1)" is set to "1".
The unit of this parameter varies depending on the setting value of "Unit for position data (PT01.2)".

Point

- The servo parameters are transferred from the motion system to the servo amplifier after the system restart.
- The servo parameters for driver communication setting (PD15, PD22, PD23) are enabled by turning OFF to ON the power supply of the servo amplifier. After performing the above processes, turn OFF to ON the power supply of the servo amplifier, and then turn ON the power supply of the system again, or reset the CPU module.
- In the master-slave operation function, the torque generation direction for a slave axis can also be set in the servo parameter "Travel direction selection (PA14)".

■Object data that require mapping for the slave axis

Set the PDO mapping for each master-slave operation station in the PDO mapping setting of GX Works3.

When using master-slave operation, map the following objects in the slave axis PDO. These objects are used for servo ON, alarm reset, etc.

- TPDO(RW_r)

Index	Sub-index	Entry name
6041H	00H	Statusword

- RPDO(RW_w)

Index	Sub-index	Entry name
6040H	00H	Controlword

The above objects are mapped to PDO as part of the default mapping pattern when [Batch Setting of PDO Mapping] is used from the [CC-Link IE TSN Configuration] menu of the "CC-Link IE TSN Configuration" screen.

Module extended parameter

The GX Works3 motion control setting function sets the following parameters. (This section only describes the parameters to be used.)

■Axis parameters

 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Extended Parameter] ⇒ [Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ [Target axis] ⇒ "Axis Parameter Setting" screen

Item		Setting details
Axis parameter constant	Station address setting	Set the station address of the real drive axis set as the master axis. *: When a station address for other than the master axis is set in the network configuration setting, "Driver Communication Setting Error 1" (error code: 3230H) occurs. *: When generating an axis, do not specify the station address of the slave axis in Station address setting (AxisName.PrConst.AddressOfStation). If the station address of the slave axis is set, "Slave Axis Specification Error" (error code: 1C51H) occurs.
	Master-slave operation setting	Slave axis station address setting [1]
		Slave axis station address setting [2]
		Slave axis station address setting [3]
		Slave axis station address setting [4]
		Slave axis station address setting [5]
		Slave axis station address setting [6]
		Slave axis station address setting [7]
		Slave axis station address setting [8]
	Axis emulate enabled	Set to "Disabled" when using the master-slave operation function. Operates as a normal axis when set to "Enabled".

■Network I/O

On the network I/O screen, generate the slave labels to be used from the program.

 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Extended Parameter] ⇒ [Motion Control Setting Function] ⇒ Navigation window ⇒ [Network I/O] ⇒ "Network I/O" screen

The following slave axis objects are set as targets for slave label generation.

- Statusword
- Controlword

These objects are used for servo ON, alarm reset, etc. of the slave axis.

For program example of the procedure for servo ON or alarm reset of the slave axis, refer to the following.

 Page 775 Master-slave operation

In addition, when the following objects are mapped to PDO of the slave axis, set them as targets for slave label generation.

- Positive torque limit value
- Negative torque limit value

If no slave labels are generated for these objects of the slave axis, the torque limit value is fixed to 0%. Set an arbitrary torque limit value for the slave label generated on the program.

Also set other slave labels used for controlling and monitoring the slave axis as targets for slave label generation as required.

Communication period setting of industrial switch (CC-Link IE TSN Class certified)

When using an industrial switch (CC-Link IE TSN Class certified), set the communication period interval and time for each timeslot by referring to the following values of the link special register (SW) when the driver communication parameters are set correctly.

No.	Name
SW04C0	Driver communication cycle interval [μs]
SW04C1	Driver communication cycle system reservation time [μs]
SW04C2	Driver communication cycle cyclic transmission time [μs]
SW04C3	Driver communication cycle transient transmission time [μs]

Precautions

Servo amplifier

- For the axes where master-slave operation is executed, use a servo amplifier that supports master-slave operation.
- Slave axes have restrictions when an axis is not assigned. Refer to the following for restrictions when an axis is not assigned.
 Page 72 Precautions
- When any axis used for master-slave operation is disconnected, disconnect all axes in the group of the master-slave operation to which the disconnected axis belongs in order to reconnect the axis, and then reconnect the axis.

■Disconnection operation

Disconnection can be executed by either of the following methods.

- Disconnect the Ethernet cable from the Ethernet cable connector of a servo amplifier.
- Select the servo amplifier to be disconnected and execute a remote reset on the "CC-Link IE TSN/CC-Link IE Field Diagnostics" screen of GX Works3.

■Reconnection operation

Reconnection can be executed by the following method:

- Reconnect the slave axis (execute servo ON again) in the user program^{*1}.

^{*1} For details on the user program, refer to the following.

 Page 775 Master-slave operation

Point

- When communication fails due to a failure of a servo amplifier, communication with the servo amplifiers after the failed servo amplifier cannot be executed. For this reason, build the system using a star or ring topology using an industrial switch (CC-Link IE TSN Class certified) to minimize the effects.
- To stop operating when an error occurs, enable the master-slave operation simultaneous stop function, and set the slave axis as a control slave axis (set the servo parameter "Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting (PD23.1)" to "1 to 8").
- If a forced stop occurs during positioning operation of the master axis, the master axis stops according to the forced stop method. The slave axis stops by the master-slave operation simultaneous stop function.

Software reboot

When executing reset after changing the slave axis station address determined at power ON, "Driver Communication Setting Error 1" (error code: 3230H) occurs.

Motion control FB

When the master axis switches to continuous operation to torque control mode (ct) using MC_TorqueControl (Torque Control), "Control Mode Switching Disabled Warning" (warning code: 0D31H) occurs and the master axis operates in the current control mode.

Relevant add-ons

The following add-ons are required to use this function.

- NetworkDriver_CCIETSN
- ServoDriver_CANopen
- Axis
- baseSystem

Combination of the version

For details on the version, refer to the following.

 Page 982 Compatible versions for each Motion module function

13 SYNCHRONOUS CONTROL

13.1 Overview of Single Axis Synchronization Control FBs

Single axis synchronization control FBs enable to control mechanical systems such as gear, speed change gear, and cam with a software by transmitting the position information (command) of Slave axis (Slave) that is synchronized with Master axis (Master).

FB	Control details
MC_CamIn (Cam Operation Start)	Executes cam operation.
MC_GearIn (Gear Operation Start)	Sets the speed ratio between the master axis and the slave axis, and enters gear operation.
MC_CombineAxes (Addition/Subtraction Positioning)	Combines operations of two axes by a selectable combination method, and outputs it to the third axis.
MCv_ChangeCycle (Current Value Change per Cycle)	Changes the current value per cycle to the specified value during MC_CamIn (Cam Operation Start) control. It is used to interpolate the current value per cycle into an arbitrary value.
MCv_BacklashCompensationFilter (Backlash Compensation Filter)	Carries out the specific filter processing to input of Master axis (Master), and outputs the result to Slave axis (Slave).  Page 406 Command Filter
MCv_SmoothingFilter (Smoothing Filter)	
MCv_DirectionFilter (Moving Direction Restriction Filter)	
MCv_SpeedLimitFilter (Speed Limit Filter)	
MCv_AdvancedSync (Advanced Synchronous Control)	Starts synchronous control based on the specified advanced synchronous control settings.  Page 555 ADVANCED SYNCHRONOUS CONTROL

13.2 Axis Configuration

The following shows axes that can be specified to Master axis (Master) and Slave axis (Slave) in the single axis synchronization control FBs. For the specifications of each axis type, refer to the following.

☞ Page 30 Axis


☞ Page 57 Axis Assignment

Axis type		Used for Master axis (Master)	Used for Slave axis (Slave)	Remark
Real axis	Real drive axis	○	○	When control for Motion FB is required, create a configuration that executes function blocks for each virtual linked axis and transmits the result (command) to the real drive axis.
	Real encoder axis	○	×	It is used as Master axis (Master). When it is used as Slave axis (Slave), "Necessary Object Data Unset" (error code: 1AA8H) occurs and it does not start.
Virtual axis	Virtual drive axis	○	○	Commands can be mainly created by positioning control, etc.
	Virtual encoder axis	○	×	It is used as Master axis (Master). When it is used as Slave axis (Slave), "Necessary Object Data Unset" (error code: 1AA8H) occurs and it does not start.
	Virtual linked axis	○	○	It is used as an intermediate axis to transmit a command to the real drive axis. When using multiple motion FBs such as gear, assign virtual linked axes.

To combine and execute controls such as gear and cam, use the virtual linked axis like the following example.

Ex.

To process gear following the instruction of the real drive axis and perform cam control adding the instruction from the virtual encoder



Position command unit of the master axis and the slave axis

Settings of position command unit of the master axis and the slave axis (Position Command Unit (AxisName.Pr.Unit_Position) and Position Command Unit String (AxisName.Pr.Unit_PositionString)) do not affect the control. The result of the calculation performed to the position information of the master axis which has no unit information is used as an instruction of the slave axis.

Ex.

To add each master axis by gear ratio 1 : 1 using MC_CombineAxes (Addition/Subtraction Positioning)

The slave axis operates 3.0 [degree] with the following settings of position command unit of each axis when the master axis 1 is moved 1.0 [pulse] and the master axis 2 is moved 2.0 [mm].

- Position command unit of the master axis 1: pulse
- Position command unit of the master axis 2: mm
- Position command unit of the slave axis: degree

Current position change of the master axis

The set position of the slave axis does not change even when the current position change of the master axis is performed.

13.3 Master Axis Data Source Selection


In the single axis synchronization control FB, a position type of the master axis whose the slave axis executes the single axis synchronous control can be selected by Master axis data source selection (MasterValueSource) of each FB.

When the actual position is specified for virtual axis (axis which does not have Actual Position (AxisName.Md.ActualPosition)), the FB operates by the value as the same with set value.

"101: Latest Set Value (mcLatestSetValue)" and "102: Latest Actual Value (mcLatestActualValue)" uses a position of the master axis in the same operation cycle, and the others use a position of the master axis in the previous operation cycle. Using "101: Latest Set Value (mcLatestSetValue)" and "102: Latest Actual Value (mcLatestActualValue)" can transmit the multiple Motion control FB command in the same operation cycle. In this case, set the first call order and linking order of the linked Motion control FB to be the same.

Ex.

When transmitting movement amount of the real drive axis and the virtual drive axis to cam to control in the same operation cycle.



When using the above combination of the single synchronous control FB (linked order), set the first call order as follows.

- First call order
 1. Motion control FB which moves the master axis (real drive axis) of MC_GearIn (Gear Operation Start)
 2. MC_GearIn (Gear Operation Start)
 3. MC_CombineAxes (Addition/Subtraction Positioning)
 4. MC_CamIn (Cam Operation Start)
- Master axis data source selection (MasterValueSource) of each single synchronous control FB
 - "101: Latest Set Value (mcLatestSetValue)"

Point

When Master axis data source selection (MasterValueSource) is set to "1: Set Value (mcSetValue)" or "101: Latest Set Value (mcLatestSetValue)" and the master axis becomes servo OFF by a servo alarm or forced stop, the amount of the value change may be too large. This can be prevented by setting Master axis data source selection (MasterValueSource) to "2: Actual Value (mcActualValue)" or "102: Latest Actual Value (mcLatestActualValue)".

Master axis data source selection (MasterValueSource)	Description
1: Set Value (mcSetValue)	Uses the commanded position of the master axis in the previous operation cycle.
2: Actual Value (mcActualValue)	Uses the actual position of the master axis in the previous operation cycle.
101: Latest Set Value (mcLatestSetValue)	Uses the commanded position of the master axis in the current operation cycle.
102: Latest Actual Value (mcLatestActualValue)	Uses the actual position of the master axis in the current operation cycle.

13.4 Start and Stop Operation

Slave axis (Slave) continues to control with the command transmitted by Master axis (Master) even if a stop cause occurs during execution of the synchronous control function blocks. The axis status of the slave axis does not change.


When a stop cause occurs to the slave axis, the axis status transits and the slave axis immediately stops or stops with deceleration according to the stop cause and its stop process. For axis control when a stop cause occurs, refer to the following.

☞ Page 168 Stop causes during axis operation

The master axis is not affected even when the stop cause occurs to the slave axis.

Ex.

When a stop cause (MC_Stop (Forced Stop)) occurs during execution of the synchronous control FB



Point

When the master axis becomes servo OFF by the servo alarm or forced stop, stopping the operation of the synchronous control FB by using MC_Stop (Forced stop) is recommended because the slave axis may cause unexpected operation.

13.5 Required Object Data

The following shows the starting availability condition with or without PDO mapping when using it as Slave axis (Slave) of the synchronous control FB.

PDO mapping necessary/not necessary		Starting availability
Target position	Position actual value	
Necessary	Not required	Starting is possible
Not necessary	Necessary	Starting is not possible ^{*1}
Not necessary	Not necessary	Starting is possible

^{*1} "Necessary Object Data Unset" (error code: 1AA8H) occurs and it will not start.

13.6 Restrictions

- When Master axis (Master) and Slave axis (Slave) are specified to the same axis, "Master Axis and Slave Axis No. Duplicated" (error code: 1A3EH) will occur.
- When connecting multiple axes in the synchronous control FB, if the master axis is specified to Slave axis (Slave) of the latter function block or more than 257 synchronous control FBs are linked, "Master Axis and Slave Axis Cyclic Reference" (error code: 1A3FH) will occur.

13.7 Cam Operation

This function operates by synchronizing the slave axis with the master axis based on cam table.

Before using this function, it is necessary to open the cam table to the open area and set to a state where it can be controlled.

For the open method to the open area, and for data types that can be controlled in cam operation, refer to the following.

📖 Page 533 Operating operation profile

📖 Page 504 Operation profile types

Relevant variable

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
ProfileID	Execution Profile ID No.	<p>Stores the executing Cam tableID (CamTableID).</p> <p>The update timing is as follows.</p> <p>■ Stores the specified Cam tableID (CamTableID)</p> <ul style="list-style-type: none">• When executing MC_CamIn (Cam Operation Start) (at the timing when the slave axis status becomes "7: During synchronous operation (SynchronizedMotion)")• When changing Cam tableID (CamTableID) <p>The timing differs depending on the setting value of Start mode (StartMode).</p> <p>■ Cleared to "0"</p> <ul style="list-style-type: none">• When Cam cycle completion (EndOfProfile) becomes TRUE with the setting that Periodic (Periodic) is "FALSE: Non periodic" and Specifying operation after one cycle operation (Options (Options): Bit 16) is "0: Complete"• When stop cause occurs

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_CamIn	Cam Operation Start	Cam operation starts operation according to the specified cam table.

Control details

MC_CamIn (Cam Operation Start) sets Master axis offset (MasterOffset), Slave axis offset (SlaveOffset), Master axis scaling (MasterScaling), Slave axis scaling (SlaveScaling), Master axis follow-up distance (MasterStartDistance), Master axis synchronization start position (MasterSyncPosition), Start mode (StartMode), Master axis data source selection (MasterValueSource), Cam tableID (CamTableID), and Buffer mode (BufferMode) and then executes the cam operation. To stop the operation, execute MC_Stop (Forced Stop).

Starting cam operation

Synchronous timing of the cam operation and reflection timing of the cam control data can be selected by setting of Start mode (StartMode).

Start mode (StartMode) has the following setting values, each of which is applied to the following usages.

Start mode (StartMode)	Usage	Reference
0: Immediate (mcImmediate)	<ul style="list-style-type: none"> When executing MC_CamIn (Cam Operation Start) after initial positioning. When detailed positioning is not considered, such as in the case of a linear cam. When executing MC_CamIn (Cam Operation Start) with multiple start (buffering). 	☞ Page 470 When Start mode (StartMode) is "0: Immediate (mcImmediate)"
1: Absolute (mcAbsolute)	<ul style="list-style-type: none"> When executing MC_CamIn (Cam Operation Start) from the position of the specified master axis. When switching cam table IDs during control by MC_CamIn (Cam Operation Start). 	☞ Page 475 When Start mode (StartMode) is "1: Absolute (mcAbsolute)"
2: Relative (mcRelative)	<ul style="list-style-type: none"> When restarting from the current position of the slave axis while synchronous control is stopped with no collapse in the synchronous position relation^{*1}. 	☞ Page 479 When Start mode (StartMode) is "2: Relative (mcRelative)"
3: Ramp-in (mcRampIn)	<ul style="list-style-type: none"> When executing MC_CamIn (Cam Operation Start) after automatic initial positioning^{*2}. When restarting upon automatic initial positioning when the equipment immediately stops with collapse in the synchronous position relation.^{*2} 	☞ Page 482 When Start mode (StartMode) is "3: Ramp-in (mcRampIn)"

^{*1} If a cam operation is started while the synchronous position relation is in collapse, the slave axis may move abruptly to the initial stroke position of the cam and thus give a shock to the machine.

^{*2} The slave axis is controlled toward the slave axis position at the start of synchronization.

☞ Page 482 When Start mode (StartMode) is "3: Ramp-in (mcRampIn)"

■Cam operation synchronous timing

Settings of Start mode (StartMode), Master axis synchronization start position (MasterSyncPosition), and Master axis follow-up distance (MasterStartDistance)) decide the synchronous start timing of Current value per cycle (InputPerCycle), Reference value (Reference), and Output value (OutputData) as follows.

Start mode (StartMode)	Synchronous start timing		
	Current value per cycle (InputPerCycle)	Reference value (Reference)	Output value (OutputData)
0: Immediate (mcImmediate)	When executing MC_CamIn (Cam Operation Start). Ignores Master axis synchronization start position (MasterSyncPosition) and Master axis follow-up distance (MasterStartDistance).		
1: Absolute (mcAbsolute)	When the position ^{*1} of master axis passes ^{*2} Master axis synchronization start position (MasterSyncPosition). Ignores Master axis follow-up distance (MasterStartDistance).		
2: Relative (mcRelative)	Synchronization starts when the master axis position ^{*1} passes ^{*2} Master axis synchronization start position (MasterSyncPosition).		Synchronization starts when the master axis position ^{*1} passes ^{*2} "Master axis synchronization start position (MasterSyncPosition) + Master axis follow-up distance (MasterStartDistance)" after passing Master axis synchronization start position (MasterSyncPosition).
3: Ramp-in (mcRampIn)			Synchronization starts when the master axis position ^{*1} passes ^{*2} "Master axis synchronization start position (MasterSyncPosition) + Master axis follow-up distance (MasterStartDistance)" after passing Master axis synchronization start position (MasterSyncPosition). ^{*3}

^{*1} Set the position data to be used based on Specifying target of Master axis synchronization start position pass check (Option (Options): Bit 21) of MC_CamIn (Cam Operation Start).

^{*2} The position of the Master axis has crossed over Master axis synchronization start position (MasterSyncPosition)(or, the Master axis synchronization start position (MasterSyncPosition) + Master axis follow-up distance (MasterStartDistance)). When these values are the same, the Master axis is considered to have not passed, and should the Master axis move from this value, it will be considered to have passed.

^{*3} The slave axis is controlled toward the slave axis position at the start of synchronization until the position of the Master axis passes "Master axis synchronization start position (MasterSyncPosition) + Master axis follow-up distance (MasterStartDistance)" after passing Master axis synchronization start position (MasterSyncPosition).For details, refer to the following.


☞ Page 482 When Start mode (StartMode) is "3: Ramp-in (mcRampIn)"

After MC_CamIn (Cam Operation Start) is executed, Controlling (Active) becomes TRUE after Current value per cycle (InputPerCycle) is synchronized, and then In synchronization (InSync) becomes TRUE after Output value (OutputData) is synchronized.

■When Start mode (StartMode) is "0: Immediate (mclmmediate)"

The slave axis starts moving after start of Execute command (Execute).

The cam operation is as follows depending on Slave axis absolute coordinate (SlaveAbsolute) set in MC_CamTableSelect (Cam Table Selection).




- An example program when executing MC_CamIn (Cam Operation Start) is shown below.

Ex.

When executing MC_CamIn (Cam Operation Start) after initial positioning

■Operation



■Axis

Axis No.	Label name	Data type	Comment
1	Axis0001	AXIS_REF	Axis 1
2	Axis0002	AXIS_REF	Axis 2

■Operation profile

Profile ID	Label name	Data type	Comment
1	ProfileData0001	MC_CAM_REF	Cam data 1

- Operation profile (cam data) setting

Item		ProfileData0001
Interpolation method specification		Spline Interpolation
Periodic		Enable
Input absolute coordinate		Disable (Relative Coordinate)
Output absolute coordinate		Disable (Relative Coordinate)
Resolution		256
Length per cycle setting	Unit	degree
	Length per cycle	360.0
Stroke amount setting	Unit	pulse
	Stroke amount	10000.0
Initial stroke		0.0

- ProfileData0001

Section No.	Start point [degree]	End point [degree]	Stroke [pulse]
1	0.0	90.0	10000.0
2	90.0	180.0	5000.0
3	180.0	270.0	2500.0
4	270.0	0.0	5000.0

■Local label

Label name	Data type	Comment
bMC_CamIn_Start	Bit	Execution control for "Cam operation start control"
MC_CamIn_1	MC_CamIn	Cam operation start FB
MCv_Jog_1	MCv_Jog	JOG operation FB

■Example program

ST program


```
//-----Cam operation start control-----
IF bMC_CamIn_Start THEN
  IF MC_CamIn_1.Execute = FALSE THEN
    MC_CamIn_1.Execute:= TRUE;
    MC_CamIn_1.CamTableID.ProfileID:= ProfileData0001.ProfileData.ID;
    MC_CamIn_1.StartMode:= MC_START_MODE__mclmmediate;
  END_IF;
  //Move Master axis upon MC_CamIn completion
  IF MC_CamIn_1.Busy AND Axis0002.Md.AxisStatus = MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward:= TRUE;
  END_IF;
END_IF;

//-----Function block call-----
MCv_Jog_1(Axis:= Axis0001.AxisRef, Velocity:= 100.0, Acceleration:= 10.0, Deceleration:= 10.0, Jerk:= 0.0);
MC_CamIn_1(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);
```

Ex.

When executing MC_CamIn (Cam Operation Start) with multiple start (buffering)

■Operation



*1: As MC_CamIn (Cam Operation Start) switches at the timing of the end of the next 1 cycle, the multiple start (buffering) of MC_CamIn (Cam Operation Start) can be performed at any timing as long as it is during one cycle of the cam to be switched.

■Axis

Axis No.	Label name	Data type	Comment
1	Axis0001	AXIS_REF	Axis 1
2	Axis0002	AXIS_REF	Axis 2

■Operation profile

Profile ID	Label name	Data type	Comment
1	ProfileData0001	MC_CAM_REF	Cam data 1
2	ProfileData0002	MC_CAM_REF	Cam data 2
3	ProfileData0003	MC_CAM_REF	Cam data 3

• Operation profile (cam data) setting

Item	ProfileData0001	ProfileData0002	ProfileData0003
Interpolation method specification	Section interpolation	Linear interpolation	Section interpolation
Periodic	Enable	Enable	Disable
Input absolute coordinate	Disable (Relative Coordinate)	Disable (Relative Coordinate)	Disable (Relative Coordinate)
Output absolute coordinate	Disable (Relative Coordinate)	Disable (Relative Coordinate)	Disable (Relative Coordinate)
Resolution/coordinate number	256	2	256
Length per cycle setting	Unit	degree	degree
	1 cycle length	360.0	360.0
Stroke amount setting	Unit	pulse	pulse
	Stroke amount	10000.0	10000.0
Initial stroke	0.0	—	0.0
Cam minimum value per cycle	—	0.0	—
Cam maximum value per cycle	—	360.0	—

• ProfileData0001

Section No.	Start point [degree]	End point [degree]	Stroke [pulse]	Cam curve type	Curve applicable range	
					P1	P2
1	0.0	0.0	5000.0	Constant acceleration	0.00	0.50

• ProfileData0002

Point No.	Input value [degree]	Output value [pulse]
1	0.0	0.0
2	360.0	10000.0

• ProfileData0003

Section No.	Start point [degree]	End point [degree]	Stroke [pulse]	Cam curve type	Curve applicable range	
					P1	P2
1	0.0	0.0	5000.0	Constant acceleration	0.50	1.00

■Local label

Label name	Data type	Comment
bMC_CamIn_Start	Bit	Execution control for "Cam operation start control"
bMC_CamIn_Stop	Bit	Execution control for "Cam operation stop control"
MC_CamIn_1	MC_CamIn	Cam operation start FB (for cam synchronization start)
MC_CamIn_2	MC_CamIn	Cam operation start FB (for control)
MC_CamIn_3	MC_CamIn	Cam operation start FB (for cam synchronization end)
MCv_Jog_1	MCv_Jog	JOG operation FB

ST program

```
//-----Cam operation start control-----
IF bMC_CamIn_Start THEN
  IF MC_CamIn_1.Execute = FALSE THEN
    MC_CamIn_1.Execute:= TRUE;
    MC_CamIn_1.CamTableID.ProfileID:= ProfileData0001.ProfileData.ID;
    MC_CamIn_1.StartMode:= MC_START_MODE__mcAbsolute;
    MC_CamIn_1.MasterSyncPosition:= 270.0;
  END_IF;
  //Move Master axis upon MC_CamIn completion
  IF MC_CamIn_1.Busy AND Axis0002.Md.AxisStatus = MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward:= TRUE;
    //Multiple start (buffering) MC_CamIn for control
    MC_CamIn_2.Execute:= TRUE;
    MC_CamIn_2.CamTableID.ProfileID:= ProfileData0002.ProfileData.ID;
    MC_CamIn_2.StartMode:= MC_START_MODE__mcImmediate;
    MC_CamIn_2.BufferMode:= MC_BUFFER_MODE__mcBuffered;
  END_IF;
END_IF;

//-----Cam operation stop control-----
IF bMC_CamIn_Stop THEN
  bMC_CamIn_Start:= FALSE;
  IF MC_CamIn_2.Active THEN
    //Multiple start (buffering) MC_CamIn for cam synchronization end
    MC_CamIn_3.Execute:= TRUE;
    MC_CamIn_3.CamTableID.ProfileID:= ProfileData0003.ProfileData.ID;
    MC_CamIn_3.StartMode:= MC_START_MODE__mcImmediate;
    MC_CamIn_3.BufferMode:= MC_BUFFER_MODE__mcBuffered;
  END_IF;

  //Stop Master axis when slave axis is no longer under synchronous control
  IF Axis0002.Md.AxisStatus <> MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward:= FALSE;
  END_IF;
END_IF;


//-----Function block call-----
MCv_Jog_1(Axis:= Axis0001.AxisRef, Velocity:= 100.0, Acceleration:= 10.0, Deceleration:= 10.0, Jerk:= 0.0);
MC_CamIn_1(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);
MC_CamIn_2(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);
MC_CamIn_3(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);
```


■When Start mode (StartMode) is "1: Absolute (mcAbsolute)"

After start of Execute command (Execute), the slave axis starts moving after the cumulative current position of the master axis passes Master axis synchronization start position (MasterSyncPosition).

Checking of whether the Master axis cumulative current position has passed the Master axis synchronization start position (MasterSyncPosition) begins at the point when the Slave axis status becomes "7: During synchronous operation (SynchronizedMotion)".

The cam operation is as follows depending on Slave axis absolute coordinate (SlaveAbsolute) set in MC_CamTableSelect (Cam Table Selection).




- An example program when executing MC_CamIn (Cam Operation Start) is shown below.

Ex.

When executing MC_CamIn (Cam Operation Start) from the position of the specified master axis.

■Operation



■Axis

Axis No.	Label name	Data type	Comment
1	Axis0001	AXIS_REF	Axis 1
2	Axis0002	AXIS_REF	Axis 2

■Operation profile

Profile ID	Label name	Data type	Comment
1	ProfileData0001	MC_CAM_REF	Cam data 1

• Operation profile (cam data) setting

Item		ProfileData0001
Interpolation method specification		Spline Interpolation
Periodic		Enable
Input absolute coordinate		Disable (Relative Coordinate)
Output absolute coordinate		Disable (Relative Coordinate)
Resolution		256
Length per cycle setting	Unit	degree
	1 cycle length	360.0
Stroke amount setting	Unit	pulse
	Stroke amount	10000.0
Initial stroke		0.0

• ProfileData0001

Section No.	Start point [degree]	End point [degree]	Stroke [pulse]
1	0.0	90.0	10000.0
2	90.0	180.0	5000.0
3	180.0	270.0	2500.0
4	270.0	0.0	5000.0

■Local label

Label name	Data type	Comment
bMC_CamIn_Start	Bit	Execution control for "Cam operation start control"
MC_CamIn_1	MC_CamIn	Cam operation start FB
MCv_Jog_1	MCv_Jog	JOG operation FB


■Example program

ST program
<pre>//-----Cam operation start control----- IF bMC_CamIn_Start THEN IF MC_CamIn_1.Execute = FALSE THEN MC_CamIn_1.Execute:= TRUE; MC_CamIn_1.CamTableID.ProfileID:= ProfileData0001.ProfileData.ID; MC_CamIn_1.StartMode:= MC_START_MODE__mcAbsolute; MC_CamIn_1.MasterSyncPosition:= 270.0; //Position where Master axis starts cam operation END_IF; //Move Master axis upon completing MC_CamIn start IF MC_CamIn_1.Busy AND Axis0002.Md.AxisStatus = MC_AXIS_STATUS__SynchronizedMotion THEN MCv_Jog_1.JogForward:= TRUE; END_IF; END_IF; //-----Function block call----- MCv_Jog_1(Axis:= Axis0001.AxisRef, Velocity:= 100.0, Acceleration:= 10.0, Deceleration:= 10.0, Jerk:= 0.0); MC_CamIn_1(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);</pre>

Ex.

When switching cam table IDs during control by MC_CamIn (Cam Operation Start)

■ Operation



*1: Cam data switches at the timing of the end of one cycle, cam table IDs can be switched at any timing as long as it is during one cycle of the cam to be switched. If an invalid cam table ID is specified, "Synchronous Control Variable Out-of-Range Warning" (warning code: 0D49H) or "No Cam Table Warning" (warning code: 0D44H) will occur, so that the control continues with the cam table ID before the change.

■ Axis

Axis No.	Label name	Data type	Comment
1	Axis0001	AXIS_REF	Axis 1
2	Axis0002	AXIS_REF	Axis 2

■ Operation profile

Profile ID	Label name	Data type	Comment
1	ProfileData0001	MC_CAM_REF	Cam data 1
2	ProfileData0002	MC_CAM_REF	Cam data 2
3	ProfileData0003	MC_CAM_REF	Cam data 3
4	ProfileData0004	MC_CAM_REF	Cam data 4

• Operation profile (cam data) setting

Item	ProfileData0001	ProfileData0002	ProfileData0003	ProfileData0004
Interpolation method specification	Linear interpolation	Spline Interpolation	Linear interpolation	Linear interpolation
Periodic	Enable	Enable	Enable	Disable
Input absolute coordinate	Disable (Relative Coordinate)	Disable (Relative Coordinate)	Disable (Relative Coordinate)	Disable (Relative Coordinate)
Output absolute coordinate	Enable (Relative Coordinate)	Enable (Relative Coordinate)	Enable (Relative Coordinate)	Enable (Relative Coordinate)
Resolution/coordinate number	2	256	2	2
Length per cycle setting	Unit	degree	degree	degree
	1 cycle length	360.0	360.0	360.0
Stroke amount setting	Unit	pulse	pulse	pulse
	Stroke amount	10000.0	10000.0	10000.0
Initial stroke	—	5000.0	—	—
Cam minimum value per cycle	0.0	—	0.0	0.0
Cam maximum value per cycle	360.0	—	360.0	360.0

• ProfileData0001

Point No.	Input value [degree]	Output value [pulse]
1	0.0	0.0
2	360.0	5000.0

• ProfileData0002

Section No.	Start point [degree]	End point [degree]	Stroke [pulse]
1	0.0	90.0	10000.0
2	90.0	180.0	5000.0
3	180.0	270.0	2500.0
4	270.0	0.0	5000.0

• ProfileData0003

Point No.	Input value [degree]	Output value [pulse]
1	0.0	5000.0
2	360.0	0.0

• ProfileData0004

Point No.	Input value [degree]	Output value [pulse]
1	0.0	0.0
2	360.0	0.0

■Local label

Label name	Data type	Comment
bMC_CamIn_Start	Bit	Execution control for "Cam operation start control"
bMC_CamIn_Stop	Bit	Execution control for "Cam operation stop control"
MC_CamIn_1	MC_CamIn	Cam operation start FB
MCv_Jog_1	MCv_Jog	JOG operation FB

■Example program

ST program

```
//-----Cam operation start control (Cam synchronization start control)-----
IF bMC_CamIn_Start THEN
  IF MC_CamIn_1.Execute = FALSE THEN
    MC_CamIn_1.Execute := TRUE;
    MC_CamIn_1.CamTableID.ProfileID := ProfileData0001.ProfileData.ID;
    MC_CamIn_1.StartMode := MC_START_MODE__mcAbsolute;
    MC_CamIn_1.MasterSyncPosition := 270.0; //Position where Master axis starts cam operation
    MC_CamIn_1.ContinuousUpdate := TRUE; //Continuous update: Enable
  END_IF;
  //Move Master axis upon completing MC_CamIn start
  IF MC_CamIn_1.Busy AND Axis0002.Md.AxisStatus = MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward := TRUE;
    //Set cam data for control (at an application timing of next cycle end)
    MC_CamIn_1.CamTableID.ProfileID := ProfileData0002.ProfileData.ID;
  END_IF;
END_IF;

//-----Cam operation stop control (cam synchronization end control)-----
IF bMC_CamIn_Stop THEN
  bMC_CamIn_Start := FALSE;
  IF MC_CamIn_1.Active THEN
    IF Axis0002.Md.ProfileID = ProfileData0002.ProfileData.ID.Number THEN
      //When cam data during slave axis control is cam data for control, set cam data for cam synchronization end
      MC_CamIn_1.CamTableID.ProfileID := ProfileData0003.ProfileData.ID;
    ELSE
      //In other cases, set cam data for stop (Periodic: Disable)
      MC_CamIn_1.CamTableID.ProfileID := ProfileData0004.ProfileData.ID;
    END_IF;
  END_IF;
  //Stop Master axis when slave axis is no longer under synchronous control
  IF Axis0002.Md.AxisStatus <> MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward := FALSE;
  END_IF;
END_IF;


//-----Function block call-----
MCv_Jog_1(Axis := Axis0001.AxisRef, Velocity := 100.0, Acceleration := 10.0, Deceleration := 10.0, Jerk := 0.0);
MC_CamIn_1(Master := Axis0001.AxisRef, Slave := Axis0002.AxisRef);
```

■When Start mode (StartMode) is "2: Relative (mcRelative)"

After Execute command (Execute) is started, the current value per cycle (InputPerCycle) is updated after the master axis cumulative current position passes Master axis synchronization start position (MasterSyncPosition). Starting here, the master axis cumulative current position moves by Master axis follow-up distance (MasterStartDistance), and then the slave axis starts moving according to the cam data.

Checking of whether the master axis cumulative current position has passed Master axis synchronization start position (MasterSyncPosition) begins at the point when the slave axis status becomes "7: During synchronous operation (SynchronizedMotion)".

The cam operation is as follows depending on Slave axis absolute coordinate (SlaveAbsolute) set in MC_CamTableSelect (Cam Table Selection).




- An example program when executing MC_CamIn (Cam Operation Start) is shown below.

Ex.

When restarting from the current position of the slave axis while synchronous control is stopped with no collapse in the synchronous position relation

■Operation



*: Specify the absolute coordinate for output absolute coordinate.

■Axis

Axis No.	Label name	Data type	Comment
1	Axis0001	AXIS_REF	Axis 1
2	Axis0002	AXIS_REF	Axis 2

■Operation profile

Profile ID	Label name	Data type	Comment
1	ProfileData0001	MC_CAM_REF	Cam data 1

- Operation profile (cam data) setting

Item		ProfileData0001
Interpolation method specification		Spline Interpolation
Periodic		Enable
Input absolute coordinate		Disable (Relative Coordinate)
Output absolute coordinate		Enable (Relative Coordinate)
Resolution		256
Length per cycle setting	Unit	degree
	1 cycle length	360.0
Stroke amount setting	Unit	pulse
	Stroke length	10000.0
Initial stroke		5000.0

- ProfileData0001

Section No.	Start point [degree]	Start point [degree]	Stroke [pulse]
1	0.0	90.0	10000.0
2	90.0	180.0	5000.0
3	180.0	270.0	2500.0
4	270.0	0.0	5000.0

■Local label

Label name	Data type	Comment
bMC_CamIn_Start	Bit	Execution control for "Cam operation start control"
bMC_CamIn_Stop	Bit	Execution control for "Cam operation stop control"
MC_CamIn_1	MC_CamIn	Cam operation start FB
MCv_Jog_1	MCv_Jog	JOG operation FB
MC_Stop_1	MC_Stop	Forced stop FB

■Example program

ST program

```
//-----Cam operation start control-----
IF bMC_CamIn_Start THEN
  IF MC_CamIn_1.Execute = FALSE THEN
    MC_CamIn_1.Execute:= TRUE;
    MC_CamIn_1.CamTableID.ProfileID:= ProfileData0001.ProfileData.ID;
    MC_CamIn_1.StartMode:= MC_START_MODE__mcRelative;
    MC_CamIn_1.MasterSyncPosition:= Axis0001.Md.CumulativePosition;
    MC_CamIn_1.MasterStartDistance:= MC_CamIn_1.InputPerCycle; //Specify current value per cycle at stop
  END_IF;
  //Move Master axis upon completing MC_CamIn start
  IF MC_CamIn_1.Busy AND Axis0002.Md.AxisStatus = MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward:= TRUE;
  END_IF;
END_IF;

//-----Cam operation stop control-----
IF bMC_CamIn_Stop THEN
  bMC_CamIn_Start:= FALSE;
  MCv_Jog_1.JogForward:= FALSE;
  //Stop MC_CamIn control at Master axis stop
  IF MCv_Jog_1.Done THEN
    MC_Stop_1.Execute:= TRUE;
  END_IF;
  //Set execution flag to OFF at MC_CamIn stop completion
  IF MC_Stop_1.Done AND MC_CamIn_1.CommandAborted THEN
    MC_CamIn_1.Execute:= FALSE;
    MC_Stop_1.Execute:= FALSE;
    bMC_CamIn_Stop:= FALSE;
  END_IF;
END_IF;

//-----Function block call-----
stroke position
MCv_Jog_1(Axis:= Axis0001.AxisRef, Velocity:= 100.0, Acceleration:= 10.0, Deceleration:= 10.0, Jerk:= 0.0);
MC_CamIn_1(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);
MC_Stop_1(Axis:= Axis0002.AxisRef, Deceleration:= 10.0, Jerk:= 0.0);
```


■When Start mode (StartMode) is "3: Ramp-in (mcRampIn)"

After Execute command (Execute) is started, the slave axis moves toward the slave axis position at the time of synchronization start upon update of Current value per cycle (InputPerCycle) after the master axis cumulative current position passes Master axis synchronization start position (MasterSyncPosition).

Starting here, the master axis cumulative current position moves by Master axis follow-up distance (MasterStartDistance), and then the slave axis starts moving according to the cam data.

Checking of whether the master axis cumulative current position has passed Master axis synchronization start position (MasterSyncPosition) begins at the point when the slave axis status becomes "7: During synchronous operation (SynchronizedMotion)".

The cam operation is as follows depending on Slave axis absolute coordinate (SlaveAbsolute) set in MC_CamTableSelect (Cam Table Selection).




- An example program when executing MC_CamIn (Cam Operation Start) is shown below.

Ex.

When executing MC_CamIn (Cam Operation Start) after automatic initial positioning

■Operation



■Axis

Axis No.	Label name	Data type	Comment
1	Axis0001	AXIS_REF	Axis 1
2	Axis0002	AXIS_REF	Axis 2

■Operation profile

Profile ID	Label name	Data type	Comment
1	ProfileData0001	MC_CAM_REF	Cam data 1

• Operation profile (cam data) setting

Item		ProfileData0001
Interpolation method specification		Spline Interpolation
Periodic		Enable
Input absolute coordinate		Disable (Relative Coordinate)
Output absolute coordinate		Enable (Relative Coordinate)
Resolution		256
Length per cycle setting	Unit	degree
	1 cycle length	360.0
Stroke amount setting	Unit	pulse
	Stroke amount	10000.0
Initial stroke		5000.0

• ProfileData0001

Section No.	Start point [degree]	End point [degree]	Stroke [pulse]
1	0.0	90.0	10000.0
2	90.0	180.0	5000.0
3	180.0	270.0	2500.0
4	270.0	0.0	5000.0

■Local label

Label name	Data type	Comment
bMC_CamIn_Start	Bit	Execution control for "Cam operation start control"
bMC_CamIn_Stop	Bit	Execution control for "Cam operation stop control"
MC_CamIn_1	MC_CamIn	Cam operation start FB
MCv_Jog_1	MCv_Jog	JOG operation FB
MC_Stop_1	MC_Stop	Forced stop FB

ST program

```
//-----Cam operation start control-----
IF bMC_CamIn_Start THEN
  IF MC_CamIn_1.Execute = FALSE THEN
    MC_CamIn_1.Execute:= TRUE;
    MC_CamIn_1.CamTableID.ProfileID:= ProfileData0001.ProfileData.ID;
    MC_CamIn_1.StartMode:= MC_START_MODE__mcRampIn;
    MC_CamIn_1.MasterSyncPosition:= Axis0001.Md.CumulativePosition;
    MC_CamIn_1.MasterStartDistance:= 360.0; //Specify cam length per cycle
  END_IF;
  //Move Master axis upon completing MC_CamIn start
  IF MC_CamIn_1.Busy AND Axis0002.Md.AxisStatus = MC_AXIS_STATUS__SynchronizedMotion THEN
    MCv_Jog_1.JogForward:= TRUE;
  END_IF;
END_IF;

//-----Cam operation stop control-----
IF bMC_CamIn_Stop THEN
  bMC_CamIn_Start:= FALSE;
  MCv_Jog_1.JogForward:= FALSE;
  //Stop MC_CamIn operation at Master axis stop
  IF MCv_Jog_1.Done THEN
    MC_Stop_1.Execute:= TRUE;
  END_IF;
  //Set execution flag to OFF at MC_CamIn stop completion
  IF MC_Stop_1.Done AND MC_CamIn_1.CommandAborted THEN
    MC_CamIn_1.Execute:= FALSE;
    MC_Stop_1.Execute:= FALSE;
    bMC_CamIn_Stop:= FALSE;
  END_IF;
END_IF;

//-----Function block call-----
MCv_Jog_1(Axis:= Axis0001.AxisRef, Velocity:= 100.0, Acceleration:= 10.0, Deceleration:= 10.0, Jerk:= 0.0);
MC_CamIn_1(Master:= Axis0001.AxisRef, Slave:= Axis0002.AxisRef);
MC_Stop_1(Axis:= Axis0002.AxisRef, Deceleration:= 10.0, Jerk:= 0.0);
```

■Timing of control change by FB retrigger/continuous update

Timing of reflecting changed parameters by FB retrigger/continuous update onto the control vary depending on Start Mode (StartMode) like the following.

Start Mode (StartMode)	Timing for reflecting parameters
0: Immediate (mcImmediate)	Immediate
1: Absolute (mcAbsolute)	When the current value per cycle (InputPerCycle) passes the first point on the CamTable
2: Relative (mcRelative)	
3: Ramp-in (mcRampln)	

When the changed values exceed the range, the warning is output and the control is maintained by keeping the value before.

Parameter	Warning
Master axis offset (MasterOffset)	Out of spindle offset range (Synchronous Control Variable Out-of-Range Warning (warning code: 0D49H (detail code: 0001H)))
Slave axis offset (SlaveOffset)	Out of the follow shaft offset range (Synchronous Control Variable Out-of-Range Warning (warning code: 0D49H (detail code: 0002H)))
Master axis scaling (MasterScaling)	Out of spindle coefficient range (Synchronous Control Variable Out-of-Range Warning (warning code: 0D49H (detail code: 0003H)))
Slave axis scaling (SlaveScaling)	Out of the dependent coefficient range (Synchronous Control Variable Out-of-Range Warning (warning code: 0D49H (detail code: 0004H)))
Cam tableID (CamTableID)	<p>■When the CamTableID (Cam tableID) numerical values are outside the range Out of cam table ID range (Synchronous Control Variable Out-of-Range Warning (warning code: 0D49H (detail code: 0005H)))</p> <p>■When there is no CamTableID (Cam tableID) open area No Cam Table Warning (warning code: 0D44H)</p>

Cam table

This section describes the cam data and the cam operation when MC_CamIn (Cam Operation Start) is executed.

○: Used in control, ×: Not used in control

Name	Variable name	Interpolation Method Specification (Interpolate)			Remark
		0: Linear Interpolation	1: Section Interpolation	2: Spline Interpolation	
Periodic	Periodic	○	○		The item set in the expand setting of the operation profile or set in input variables of MC_CamTableSelect (Cam Table Selection) on the engineering tool
Input absolute coordinate	MasterAbsolute	○	○		
Output absolute coordinate	SlaveAbsolute	○	○		
Interpolation method specification	Interpolate	○	○		The item related to control among the data expanded to open area from the operation profile of cam data format/rotary cutter format
Length per cycle	CycleLength	○	○		
Stroke amount	Stroke	○	○		
Start point	StartPoint	×	×		
Initial stroke amount	StartStroke	×	○		

■Periodic

Periodic (Periodic) can set the operation after one cycle operation with "FALSE: Non periodic" and "TRUE: Periodic (Periodic)". The following describes the operation when executing MC_CamIn (Cam Operation Start).

- FALSE: Non periodic

Only one cycle operation is carried out after Controlling (Active) becomes TRUE. The next operation is specified in Specifying operation after one cycle operation (Options (Options): Bit 16).

Specifying operation after one cycle operation (Options (Options): Bit 16)	Operation after cycle operation				Reference value (Reference), Output value (OutputData) at restart
	Executing (Busy)	Controlling (Active)	In synchronization (InSync)	Axis Status (AxisName.Md.AxisStatus)	
0: Complete	FALSE			"4: Standby (Standstill)"	Initialized*1
1: Wait for restart	TRUE			Maintains "7: During synchronous operation (SynchronizedMotion)"	Maintained


*1 Refer to the following for how to calculate the initial value of each monitor data.

Page 493 Monitor data during cam operation

■When Specifying operation after one cycle operation (Options (Options): Bit 16) is "0: Complete"

Synchronization status is canceled after one cycle.

Restarting Execute command (Execute) results in synchronization status to start controlling MC_CamIn (Cam Operation Start).



■When Specifying operation after one cycle operation (Options (Options): Bit 16) is "1: Wait for restart"

Synchronization status is maintained after one cycle.


When Execute command (Execute) is restarted, Current value per cycle (InputPerCycle), Reference value (Reference), and Output value (OutputData) start to be updated regardless of the settings of Start mode (StartMode).

Input stop cause to the slave axis to cancel synchronization status.

During a restart after one cycle is completed, even when values of input labels where continuous update is possible are changed, any input information will not be imported until Start mode (StartMode) is restarted.

While waiting for a restart after one cycle is completed, if a change to the current value per cycle is executed, this will be valid from the next cycle.


The operation while waiting for a restart after one cycle is completed is as follows.




- TRUE: Periodic

Cam table execution is repeated continuously. When the positions of Slave axis (Slave) at the cam table start point are the same each time by repeating, cam is operated as a two-way cam. When the set positions at the start point and the end point are different, cam is operated as a feed cam.


■ Two-way cam operation



■ Feed cam operation



The operation of the periodic is as follows.



■ Master axis absolute coordinate

The following describes the operation at Master axis absolute coordinate (MasterAbsolute) set by MC_CamTableSelect (Cam Table Selection).


- "0: Relative coordinate" is specified to the master axis absolute coordinate

Master axis synchronization start position (MasterSyncPosition) becomes the start point of the cam table. When In synchronization (InSync) becomes TRUE, cam operation is executed corresponding to the relative movement amount of Master axis (Master). Cam operation is executed continuously, even when ring counters of Master axis (Master) and cam table are not matched.

Ex.

For the following settings.

- Master axis: Ring counter of the current value: 0.0000 to 360.0000 [degree]
- Master axis synchronization start position (MasterSyncPosition): 180.0000 [degree]
- Cam: Cam length per cycle: 540.0000 [degree]




■ Slave axis absolute coordinate

The following describes the operation at Slave axis absolute coordinate (SlaveAbsolute) set by MC_CamTableSelect (Cam Table Selection).

- "FALSE: relative coordinate" is specified to Slave axis absolute coordinate (SlaveAbsolute)

When In synchronization (InSync) becomes TRUE, the slave axis starts the operation of the cam table from the current position (set position).

When Periodic (Periodic) of the cam table is set to "TRUE: Periodic", the next cycle starts from the stroke position (set position) where the last cycle completed.



- "TRUE: absolute coordinate" is specified to Slave axis absolute coordinate (SlaveAbsolute)

The cam is operated within the ring counter range including current values of Slave axis (Slave) at the point when In synchronization (InSync) becomes TRUE.

Command is output per operation cycle to return the set position of Slave axis (Slave) to the start point of the cam table when In synchronization (InSync) and Cam cycle completion (EndOfProfile) become TRUE. If the command at this time is too large, the position command and velocity command to the drive unit also become too large, causing the servo error [AL. 035_Command frequency error] for the MR-J5(W)-G. The set position of Slave axis (Slave) will not output any values outside the ring counter range.

Status	Operation
When the stroke range is within the ring counter range of slave axis	
When the stroke range is within the ring counter range of slave axis (Cam started on the 2nd cycle)	
When the stroke range is outside the ring counter range of the slave axis*1	
When current value per cycle is changed	

*1 If the version of add-on ProfileControl is earlier than "1.15", command values outside of the ring counter range will also be output. Values outside of the ring counter range will be rounded so that they are within the range.

Length per cycle

Set the input amount that is required for one cycle. For details, refer to the following.

☞ Page 493 Current value per cycle (InputPerCycle)

Stroke amount

Set the stroke amount corresponding to its ratio 100%. For details, refer to the following.

☞ Page 496 Output value (MC_CamIn.OutputData)

Start point and Initial stroke amount


Start Point used for cam operation and the Initial stroke amount will differ depending on the interpolation method specification.

Interpolation Method Specification (Interpolate)	Cam operation Start Point	Initial stroke amount for cam operation
0: Linear Interpolation	Input value of the cam table start point	Output value of the cam table start point
1: Section Interpolation	Start Point (StartPoint) of the cam table start point	Initial stroke amount (StartStroke) of the cam table
2: Spline Interpolation		

Cam operation start point

Operates so that Current value per cycle (InputPerCycle) is "0.0".


- Cam table (Cam operation Start Point "0.0")



- Interpolation method specification: Section interpolation
- Length per cycle: 360.0
- Start Point: 0.0
- Initial stroke amount: 0.0

Cam operation


The cam operation in the following is performed.




- Cam operation initial stroke amount.

Operates so that it becomes the Output value (OutputData) at the start of synchronization. Because the initial stroke amount of the cam operation stops the slave axis from operating, the initial stroke amount from Reference value (Reference) is decreased.

■When Initial stroke amount of cam operation is "0.0"



■Initial stroke amount of cam operation is "25.0"



Monitor data during cam operation

During control in MC_CamIn (Cam Operation Start), the current value per cycle, the reference value, and the output value can monitor in Current value per cycle (InputPerCycle), Reference value (Reference), and Output value (OutputData).

Name	Variable name	Data type	Refresh cycle
Current value per cycle	InputPerCycle	LREAL	Execution cycle of POU which calls FB (program component)
Reference value	Reference	LREAL	
Output value	OutputData	LREAL	
Instance ID	InstanceID	WORD(UINT)	

■Current value per cycle (InputPerCycle)

The initial value is "0.0".

The movement amount of Master axis (Master) is reflected after Controlling (Active) turns to TRUE as follows.

Current value per cycle = (Cumulative movement amount of the master axis - Master axis offset + Current value per cycle change value) MOD Length per cycle

The monitor value range is "0.0 ≤ Current value per cycle (MC_CamIn.InputPerCycle) < (One cycle length × Master axis scaling)"


■Reference value (Reference)

When MC_CamIn (Cam Operation Start) is started to operate, cam reference value is calculated by the cam position for start (current value per cycle) based on set position where In synchronization (InSync) becomes TRUE. The formula for initial value is as follows because the Initial stroke amount during cam table is subtracted.

Slave axis absolute coordinate (SlaveAbsolute)	Calculation formula
FALSE: Relative coordinate	<p>■Add-on ProfileControl version is "1.15" or later Reference value = Slave axis position when synchronization starts - (Stroke value based on the cam position (current value per cycle) when In Synchronization (InSync) changes to TRUE + the initial stroke amount + slave axis offset) × Slave axis scaling</p> <p>■Add-on ProfileControl version is earlier than "1.15" Reference value = 0 - (Stroke value based on the cam position (current value per cycle) when In synchronization (InSync) changes to TRUE + the initial stroke amount + slave axis offset) × Slave axis scaling</p>
TRUE: Absolute coordinate	Reference value = The set position corresponding to the cumulative current position being 0 when In synchronization (In Sync) changes to TRUE.

When two-way cam operation, or Slave axis absolute coordinate (SlaveAbsolute) is "TRUE: Absolute coordinate", the reference value is not updated. When Feed cam operation, as well as Slave axis absolute coordinate (SlaveAbsolute) are "FALSE: Relative coordinate", the reference value is calculated as shown below.

Calculation formula
Reference value = Original reference value + (Stroke value at the last point - Stroke value at the 1st point) × Slave axis scaling



Reference value is updated at the following timing

Update timing	The calculation formula of reference value
When Current value per cycle (InputsPerCycle) passes the last point of cam table	Original reference value + (Stroke value at the last point - Stroke value at the 1st point × Slave axis scaling)
When Current value per cycle (InputPerCycle) going in the address decreasing direction passes the first point of the cam table	Original reference value - ((Stroke value at the last point - Stroke value at the 1st point) × Slave axis scaling)
When changing current value per cycle (MCv_ChangeCycle (Current Value per Cycle) completion (Done) is TRUE)	Original reference value - (Stroke value corresponding to current value per cycle after change × Slave axis scaling)


For the reference value error

Any of the following operation may cause the error of reference value.

- Condition 1: When the number of output TRUE of Cam cycle completion (EndOfProfile) after the feed cam and In synchronization (InSync) becomes TRUE exceeds the permissible value for the positioning range exceeded count.

Although the error does not occur unless positioning range exceeded count exceeds the permissible value for the positioning range exceeded count, if the value exceeds the permissible value, the error may occur.

(The operation is maintained regardless of the operation error occurrence or not.)



- Condition 2: When the feed cam and the following control parameter includes decimal
 - Stroke value at the last point - Stroke value at the 1st point
 - Slave axis coefficient
- Condition 3: When changing current value per cycle is repeated in relative specification

When the reference value error becomes too large, clear the synchronization status or reset it by executing current value change of absolute position specification.

For the error, refer to the following.

☞ Page 81 Positioning Range

The permissible value of the number of exceeding from maximum to minimum is a variable value calculated with the following formula.

The permissible value of the number of exceeding from maximum to minimum = the limit value of the number of exceeding from maximum to minimum / ((output value at the last point - output value at the 1st point) / the slave axis coefficient)

*: The limit value of the number of exceeding from maximum to minimum is "10000000000" as the upper limit value of the positioning range.

(Example)

When the output value at the 1st point is "0", the output value at the last point is "1000000", and the output coefficient is "10", the permissible value of the number of exceeding from maximum to minimum becomes "100000".

The monitor value range differs depending on add-on ProfileControl version.

Add-on ProfileControl version	Monitor value range
"1.15" or later	Ring counter lower limit value of the slave axis ≤ Reference value < Ring counter upper limit value of the slave axis
Earlier than "1.15"	Lower limit value of the positioning range ≤ Reference value < Upper limit value of the positioning range

■Output value (MC_CamIn.OutputData)

Reference value is the initial stroke amount during cam table. For details, refer to the following.

☞ Page 492 Start point and Initial stroke amount

While In synchronization (InSync) is TRUE, calculate as shown below.

Timing to update and how to calculate Output value (OutputData) are as follows.

Update timing	Calculation formula
During Controlling (Active) is TRUE, and In synchronization (InSync) is FALSE	Reference value+ (Initial stroke amount during cam table + Slave axis offset) × Slave axis scaling When Start mode (StartMode) is "3: Ramp-in (mcRampln)", the output value is calculated from the above position toward the slave axis position at the start of synchronization. For details, refer to the following. ☞ Page 482 When Start mode (StartMode) is "3: Ramp-in (mcRampln)"
During In synchronization (InSync) is TRUE	■When interpolation method is "1: Section Interpolation" or "2: Spline Interpolation" Reference value + ((Stroke amount × Stroke ratio corresponding to the current value per cycle) + Slave axis offset) × Slave axis scaling ■When interpolation method is "0: Linear Interpolation" Reference value + (Output value corresponding to the current value per cycle) + Slave axis offset) × Slave axis scaling

The monitor value range differs depending on add-on ProfileControl version.

Add-on ProfileControl version	Monitor value range
"1.15" or later	Ring counter lower limit value of the slave axis ≤ Output value < Ring counter upper limit value of the slave axis
Earlier than "1.15"	Lower limit value of the positioning range ≤ Output value < Upper limit value of the positioning range

Precautions

- Changing Master axis offset (MasterOffset), Slave axis offset (SlaveOffset), Master axis scaling (MasterScaling), and Slave axis scaling (SlaveScaling) may give impact to the machine because the slave axis moves suddenly at the start of control or at control change. It is important to carefully check the setting values and the change timing.
- When monitoring the axis being cam controlled with the engineering tool, the position, velocity, etc. is based on the unit setting of the axis. Units for the cycle length, stroke amount, etc. set in the operation profile are not used.

13.8 Gear Operation

This function sets the speed ratio between the master axis and the slave axis, and starts gear operation.

Relevant FB

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)


Motion control FB	Name	Description
MC_GearIn	Gear Operation Start	Gear operation starts operation according to the specified gear ratio.

Control details

In the MC_GearIn (Gear Operation Start), Gear ratio numerator (RatioNumerator), Gear ratio denominator (RatioDenominator), Master axis data source selection (MasterValueSource), Acceleration (Acceleration), Deceleration (Deceleration), Jerk (Jerk), and Buffer mode (BufferMode) are set and the gear operation starts.


To stop the operation, execute the MC_Stop (Forced Stop).

After executing this FB, Slave axis (Slave) performs acceleration/deceleration until reaching the gear synchronization speed, the value of which is the velocity of Master axis (Master) converted by the gear ratio. After reaching the gear synchronization speed, Gear ratio reached (InGear) becomes TRUE, and Slave axis (Slave) is controlled using a velocity equal to the velocity of Master axis (Master) converted by the gear ratio.



*1 This is axis state of Slave axis (Slave).

- When the speed of Master axis (Master) is changed during acceleration/deceleration, the gear synchronization speed is also updated.



Acceleration/deceleration until reaching the gear synchronization speed

- The acceleration/deceleration method for MC_GearIn (Gear Operation Start) is the acceleration/deceleration specification method.

For details of operation of the acceleration/deceleration specification method, refer to the following.

☞ Page 358 Acceleration/deceleration Processing Function

- Depending on the velocity of Slave axis (Slave) and the gear synchronization speed at operation start, one of the following four types of acceleration/deceleration is performed.

The type of acceleration/deceleration will not change even if the gear synchronization speed is updated during the acceleration/deceleration.

Velocity of Slave axis (Slave) and gear synchronization speed	Acceleration/deceleration operation
Velocity of Slave axis (Slave) < 0 < Gear synchronization speed or Velocity of Slave axis (Slave) > 0 > Gear synchronization speed	<p>Deceleration is performed to velocity 0, then acceleration is performed from velocity 0 to the gear synchronization speed.</p>
Velocity of Slave axis (Slave) (Absolute value) < Gear synchronization speed (Absolute value)	<p>Acceleration is performed until reaching the gear synchronization speed.</p>
Velocity of Slave axis (Slave) (Absolute value) > Gear synchronization speed (Absolute value)	<p>Deceleration is performed until reaching the gear synchronization speed.</p>
Velocity of Slave axis (Slave) = Gear synchronization speed	<p>Acceleration/deceleration is not performed. After operation is started, Gear ratio reached (InGear) becomes TRUE immediately and Slave axis (Slave) is controlled using a velocity equal to the velocity of Master axis (Master) converted by the gear ratio.</p>

Precautions

- When the gear ratio is changed, the speed of the slave axis is changed directly. To smooth the speed change, use with `MCv_SmoothingFilter` (Smoothing Filter).
- When Master axis (Master) speed after conversion exceeds the acceleration/deceleration upper limit value during acceleration/deceleration operation, "Acceleration Time Limit Over Warning" (warning code: 0D04H) or "Deceleration Time Limit Over Warning" (warning code: 0D05H) will occur and stops the acceleration/deceleration operation, and continues the operation with the speed when the warning was detected.

When the above warning occurred, adjust and set Master axis (Master) speed after conversion, Acceleration (Acceleration) or Deceleration (Deceleration) to not exceed the acceleration/deceleration upper limit value, and restart the acceleration/deceleration operation.

13.9 Addition/Subtraction Positioning

This function combines the movement amount of 2 axes and transmits.

Relevant FB

For details on Motion control FBs, refer to the following.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_CombineAxes	Addition/Subtraction Positioning	Added or subtracted value which the movement amount of the specified master axis 2-axis is set as the commanded position, and the positioning is executed.

Control details

In MC_CombineAxes (Addition/Subtraction Positioning), Addition/subtraction method selection (CombineMode), Master axis 1 gear ratio numerator (GearRatioNumeratorM1), Master axis 1 gear ratio denominator (GearRatioDenominatorM1), Master axis 2 gear ratio numerator (GearRatioNumeratorM2), and Master axis 2 gear ratio denominator (GearRatioDenominatorM2), Master axis 1 data source (MasterValueSourceM1), Master axis 2 data source (MasterValueSourceM2), and Buffer mode (BufferMode) are set and the addition/subtraction positioning is executed.


To stop the operation, execute MC_Stop (Forced Stop).

The movement amount of Master axis 1 (Master1) and Master axis 2 (Master2) are combined. Also, gear ratio can be set to each master axis.

Combining the movement amount calculates adding/subtracting regardless of the unit of Master axis 1 (Master1) and Master axis 2 (Master2).

When "0: mcAddAxes" is set to CombineMode


Movement amount of Slave axis (Slave) = Master axis 1 (Master1) + Movement amount of Master axis 2 (Master2)



*1 This is axis state of Slave axis (Slave).

When "1: mcSubAxes" is set to CombineMode

Movement amount of Slave axis (Slave) = Master axis 1 (Master1) - Movement amount of Master axis 2 (Master2)



*1 This is axis state of Slave axis (Slave).

13.10 Precautions

Relevant add-ons

The following add-ons are required to use the synchronous control function.

- ProfileControl
- MotionControl_Sync
- MotionEngine
- Axis
- MotionControl_General

14 OPERATION PROFILE FUNCTION

14.1 Operation Profile

Waveform data used for control is collectively called operation profile.
This section describes creating and using methods of operation profile.


Operation of this function for each system status

○: Possible, ×: Not possible

System status	Operation availability
STOP	×
RUN	○
Moderate error	×
Major error	×

Overall block diagram

The following diagram shows the relevancy between the data from creating to using of operation profile and the Motion control FB about operation profile used in various functions (e.g. the cam of single axis synchronous control).



Relevant variables

PROFILE_DATA

Variable/Structure name	Name	Details
Location	Operation Profile Storage Location	Sets the file name and storage location of the operation profile. FILE_LOCATION type
ID	Profile ID	Sets the number for the profile ID of the operation profile. PROFILE_ID type

FILE_LOCATION

Variable/Structure name	Name	Details
FileName	File Name	Specifies a file name. (Up to 63 characters including the extension can be set.)*1
Path	Folder Specification	Specifies the folder path in which the file is stored. (Up to 63 characters can be set.)*1

*1 Set a total of up to 127 characters (including Null string) for File name (FileName) and Folder specification (Path).

Point

- Make sure the folder path does not exceed the maximum number of characters for the folder path.
- Make sure the file name does not exceed the maximum number of characters for the file name.

14

PROFILE_ID

Variable/Structure name	Name	Details
Number	Profile ID No.	Sets the Profile ID No. • 0 to 60000

INSTANCE_ID

Variable/Structure name	Name	Details
Number	Instance ID No.	Sets the number for the instance ID

Relevant FBs

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_CamTableSelect	Cam Table selection	Stores specified operation profile (cam data) in the open area.
MCv_ReadProfileData	Profile Read	Reads the specified operation profile from the open area or the file.
MCv_WriteProfileData	Profile Write	Writes the specified operation profile from the open area or the file.
MCv_ChangeCycle	Current Value Change per Cycle	Changes the current value per cycle of the specified operation profile control FB.

Operation profile types

For the function to use operation profile, there is an operation profile format that supports the corresponding function. The following shows operation profile format and I/O data that can be used to each function.

Function (Operation profile control)	Operation profile format	Input data	Output data	Operation profile open
Cam operation (MC_CamIn (Cam Operation Start))	Cam data	Master axis position (selected with MC_SOURCE)	Slave axis position	Auto expand ^{*1} Write operation profile ^{*2} MC_CamTableSelect (Cam Table Selection)
	Rotary cutter			
Advanced synchronous control (MCv_AdvancedSync)	Cam data	Master axis position, sub input axis, auxiliary shaft position (selected with MC_SOURCE)		
	Rotary cutter			
Advanced synchronous control current position per cycle calculation (MCv_AdvPositionPerCycleCalc)	Cam data	<ul style="list-style-type: none"> Ring counter upper limit Cam starting point Length per cycle Stroke amount Current position per cycle Cam reference position Cam set position 	Current position per cycle	
	Rotary cutter			
Advanced synchronous control cam set position calculation (MCv_AdvCamSetPositionCalc)	Cam data		Cam set position	
	Rotary cutter			
Multiple axes positioning data operation (MCv_MovePositioningData)	Multiple axes positioning data	Positioning data No.	Set position of axes group configuration axis	Auto expand ^{*1} Write operation profile ^{*2}

*1 When "Auto Expand" is set to "Yes".

*2 After executing MCv_ReadProfileData (Profile Read) (set the destination (Target) to "1: File"), execute MCv_WriteProfileData (Profile Write) (set the destination (Target) to "2: Open area (motion service processing)") and open.

Cam data

The relationship of output values (slave axis position) to input values (master axis position) is defined as the cam data. The following interpolation method can be selected as the cam data.

Interpolation Method Specification (Interpolate)	Description
0: Linear Interpolation	Create cam data that specifies the input value (master axis position) of each point and the output position (slave axis position) and interpolates each point with straight lines.
1: Section Interpolation	Create cam data that specifies the input value (master axis position), stroke, and cam curve type of each point and interpolates with curve lines specified each point.
2: Spline Interpolation	Create cam data that specifies the input value (master axis position) and stroke and performs spline interpolation of each point.

Required data for the setting differs depending on the selected interpolation method. Refer to the following table.

◎: Necessary, ○: Optional, —: Unnecessary

Setting items	Interpolation Method Specification (Interpolate)		
	0: Linear Interpolation	1: Section Interpolation	2: Spline Interpolation
Profile ID	○	○	○
Interpolation method specification	◎	◎	◎
Resolution/coordinate number	◎	◎	◎
Input unit character string	○	○	○
Output unit character string	○	○	○
Start point	—	◎	◎
Initial stroke amount	—	◎	◎
Initial velocity	—	○	—
Initial acceleration	—	○	—
I/O data	◎	—	—

Setting items		Interpolation Method Specification (Interpolate)		
		0: Linear Interpolation	1: Section Interpolation	2: Spline Interpolation
Parameter	Cam curve types	—	⊙	—
	End point	—	⊙	⊙
	Stroke	—	⊙	⊙
	Curve applicable range	—	○	—
	Acceleration/ deceleration range compensation	—	○	—
	End point velocity	—	○	—
	End point acceleration	—	○	—
Length per cycle		—	⊙	⊙
Minimum value per cycle		⊙	—	—
Maximum value per cycle		⊙	—	—
Time per cycle		—	○	—
Stroke amount		⊙	⊙	⊙

■Profile ID

It is a unique ID assigned by an open instruction.


The ID opened by the MC_CamTableSelect (Cam Table Selection) can be used in the control instruction (MC_CamIn (Cam Operation Start)) as the MC_CAM_ID type. ID can be specified with an arbitrary No.

■Interpolation Method Specification (Interpolate)

Set the interpolation method of cam data.

• 0: Linear Interpolation

The stroke data of each point data that is defined for a cam curve per cycle with two or more points (a pair data of current value per cycle and stroke) is opened in the open area.




- 1: Section Interpolation

Gaps between the points are interpolated with the specified curve, and the stroke data that is defined after equally dividing a cam curve per cycle by points of the cam resolution is opened in the open area. (a pair data of current value per cycle and stroke)

Ex.

Resolution: 100



Point

If the number of I/O data is not enough for the set resolution, cam data that is equally divided after interpolating the data in shortage according to the line set by the curve designation will be created.

- 2: Spline Interpolation

Gaps between the points are spline interpolated, and the stroke data that is defined after equally dividing a cam curve per cycle by points of the cam resolution is opened in the open area. (a pair data of current value per cycle and stroke)

Resolution/coordinate number

Set the number of divisions for one cam curve.

Set the number of data including the 0th point.

Input/output unit character string

Set a unit of the input/output data with an arbitrary character string.

It is handled as a [pulse] when it is omitted. Also, when "%" is specified in the output unit character string, the control that the cam stroke amount is 100% is carried out.

Point

When a unit other than "%" is specified, it is not be used in the control. It is used only in monitoring.

Start point

Set "0.0".

If other than "0.0" is set, "Operation Profile Data Incorrect" (error code: 3410H) occurs.

Not applicable when the Interpolation Method Specification (Interpolate) is set to "0: Linear Interpolation".

Initial stroke amount

Set the stroke amount for the start point.

When the output unit character string is "%", it will be a value corresponding to the 100% of stroke ratio.

Not applicable when the Interpolation Method Specification (Interpolate) is set to "0: Linear Interpolation".

■Initial velocity/End point velocity

Set the velocity at the start point/end point.

Use when cam curve type is set to 5th Curve (Adj.).

The unit for setting value is [pulse/s] when output unit string is [pulse].

The unit for setting value is [output unit character string/min] when output unit string is other than [pulse].

Ex.

The unit for setting value is [degree/min] when output unit string is [degree].

■Initial acceleration/End acceleration

Set the acceleration at the start point/end point.

Use when cam curve type is set to 5th Curve (Adj.).

The unit for setting value is [pulse/s] when output unit string is [pulse/s²].

The unit for setting value is [output unit string/min²] when output unit string is other than [pulse].

Ex.

The unit for setting value is [degree/min²] when output unit string is [degree].

■I/O data

Set the I/O data.

The input data should be set in ascending order.

■Length per cycle

Set the input amount that is required for one cycle.

Not applicable when the Interpolation Method Specification (Interpolate) is set to "0: Linear Interpolation".

The control that the difference between maximum value per cycle and minimum value per cycle is length per cycle is carried out.



■Maximum value per cycle/Minimum value per cycle

Set the maximum/minimum value per cycle.

It is valid only when Interpolation Method Specification (Interpolate) is "0: Linear Interpolation".

Set "0.0" to minimum value per cycle. If other than "0.0" is set to minimum value per cycle, "Operation Profile Data Incorrect" (error code: 3410H) occurs.

When Interpolation Method Specification (Interpolate) is "0: Linear Interpolation", the operation profile is as follows depending on the coordinate data.

Coordinate data	Description
"Minimum value per cycle < Minimum value of input" "Maximum value of input < Maximum value per cycle"	<p>The control is performed with a line segment created from the coordinates of the nearest two points.</p> <p><Example> When resolution is "100"</p> 
"Minimum value of input < Minimum value per cycle" "Maximum value per cycle < Maximum value of input"	<p>Ignores the coordinate data of outside range of minimum value per cycle to maximum value per cycle</p> <p><Example> When the number of point data is "100"</p> 

■Time per cycle

Set time that is required for one cycle.

Use when cam curve type is set to 5th Curve (Adj.).

■Stroke amount

Set the stroke amount.

When the output unit character string is "%", it will be a value corresponding to the 100% of stroke ratio.

■End point

Set the end point of each section.










End point should be set in ascending order.





■Stroke

Set the stroke of each section.

■Cam curve types

A cam curve can be selected from the following curves.

Cam curve type (MC_CAM_CURVE_TYPE)			Acceleration curve shape*1	Curve applicable range (P1 to P2)	Acceleration/ deceleration range compensation (): Default value		End point velocity	End point acceleration
Setting value	Cam curve name				Range L1	Range L2		
ConstantSpeed(0)	Constant velocity	Discontinuous		0.0 to 1.0	—	—	—	—
ConstantAcceleration(1)	Constant acceleration			0.0 to 1.0	—	—	—	—
DistortedTrapezoid(2)	Distorted trapezoid	Two-dwelling symmetrical		0.0 to 1.0	$0.0001 \leq L1 < 0.2500$ (0.125)	—	—	—
DistortedSine(3)	Distorted sine			0.0 to 1.0	$0.0001 \leq L1 < 0.5000$ (0.125)	—	—	—
DistortedConstantSpeed(4)	Distorted constant velocity			0.0 to 1.0	$0.0001 \leq L1 < 0.1250$ (0.0625)	$0.0001 < L2 < 0.5000$ (0.25)	—	—
Cycloid(5)	Cycloid			0.0 to 1.0	—	—	—	—
FifthCurve(6)	5th Curve			0.0 to 1.0	—	—	—	—
Trapezoid(7)	Trapezoid	Two-dwelling asymmetrical		0.0 to 1.0	$0.0001 \leq L1 < 0.2500$ (0.125)	—	—	—
ReverseTrapezoid(8)	Reverse trapezoid			0.0 to 1.0	$0.0001 \leq L1 < 0.2500$ (0.125)	—	—	—

Cam curve type (MC_CAM_CURVE_TYPE)			Acceleration curve shape*1	Curve applicable range (P1 to P2)	Acceleration/ deceleration range compensation (): Default value		End point velocity	End point acceleration
Setting value	Cam curve name				Range L1	Range L2		
DoubleHy potenuse(9)	Double hypotenuse	One-dwelling		0.0 to 1.0	—	—	—	—
ReverseD oubleHypo tenuse(10)	Reverse double hypotenuse			0.0 to 1.0	—	—	—	—
Single Hypotenuse(11)	Single hypotenuse	Non-dwelling curve		0.0 to 1.0	—	—	—	—
FifthCurve _SpeedDe signation(12)	5th Curve (Adj.)	Two-dwelling symmetrical		0.0 to 1.0	—	—	-2500000000.0 to 2500000000.0	-2147483647.0 to 2147483647.0

*1 ---- : Stroke ratio — : Acceleration  : Range L1  : Range L2


■Read/write data structure

This section describes read data 1/write data 1 (Data1) and read data 2/write data 2 (Data2) specified by MCv_ReadProfileData (Profile Read)/MCv_WriteProfileData (Profile Write) when executing read/write operation profile.

- Read data 1/Write data 1 (Data 1)

Specify the PROFILE_CAM_DATA type structure.

PROFILE_CAM_DATA			Device offset (Total size: 108 points)	Description
Variable name	Name	Data type		
Interpolate	Interpolation method specification	INT	+0	Set the interpolation method specification of the cam data. • 0: Linear Interpolation • 1: Section Interpolation • 2: Spline Interpolation
Resolution	Resolution/ number of coordinates	DWORD(UDINT)	+2	Set the resolution. Linear interpolation/section interpolation/spline interpolation • 8 to 65535
InputUnitString	Input unit character string	WSTRING(31)	+4	Sets the unit for input data with a character string.
OutputUnitString	Output unit character string	WSTRING(31)	+36	Sets the unit for output data with a character string.
StartPoint	Start point*1	LREAL	+68	Set the start point. *: Set "0.0".
StartStroke	Initial stroke amount*1	LREAL	+72	Set the stroke amount for the start point. (Stroke amount (Stroke) ≤ Initial stroke amount (StartStroke) ≤ Stroke amount (Stroke))
StartVelocity	Initial velocity*2	LREAL	+76	Set the velocity for the start point. (-2500000000.0 ≤ Initial velocity (StartVelocity) ≤ 2500000000.0)
StartAcceleration	Initial acceleration*2	LREAL	+80	Set the acceleration for the start point. (-2147483647.0 ≤ Initial acceleration (StartAcceleration) ≤ 2147483647.0)
CycleLength	Length per cycle*1	LREAL	+84	Set the input amount that is required for one cycle. (0.00000000000001 ≤ Length per cycle (CycleLength) ≤ 10000000000.0)
CycleMin	Minimum value per cycle	LREAL	+88	Set the minimum value per cycle. *: Set "0.0".

PROFILE_CAM_DATA			Device offset (Total size: 108 points)	Description
Variable name	Name	Data type		
CycleMax	Maximum value per cycle	LREAL	+92	Set the maximum value per cycle. (Minimum value per cycle (CycleMin) < Maximum value per cycle (CycleMax) ≤ 10000000000.0)
CycleTime	Time per cycle ^{*2}	LREAL	+96	Set time per cycle. (0.001 < Time per cycle (CycleTime) ≤ 100000.0)
Stroke	Stroke amount	LREAL	+100	Set the stroke amount. (0.00000000000001 ≤ Stroke amount (Stroke) ≤ 10000000000.0)
NumberOfSections	Number of sections ^{*1}	DWORD(UDINT)	+104	Sets the number of sections ■ When set to "1: Section Interpolation" • 1 to 360 ■ When set to "2: Spline Interpolation" • 3 to 360
Options	Options	DWORD(HEX)	+106	Specify options.  ■ Periodic (bit 0) • 0: Non periodic • 1: Periodic For details, refer to the following. ☞ Page 486 Periodic ■ Master axis (input) absolute coordinate (bit 1) • 0: Relative coordinate • 1: Setting not possible ^{*3} For details, refer to the following. ☞ Page 490 Master axis absolute coordinate ■ Slave axis (output) absolute coordinate (bit 2) • 0: Relative coordinate • 1: Absolute coordinate For details, refer to the following. ☞ Page 490 Slave axis absolute coordinate *: For bit 3 to 31, specify "0". ^{*4}

*1 It is not used in the cam data format (Interpolation Method Specification (Interpolate) is "0: Linear Interpolation"). (It is ignored.)

*2 Used only when cam curve is 5th Curve (Adj.). (Ignore for other curve)

*3 When "1" is set, "Out of MasterAbsolute Range" (error code: 341DH) occurs, and the FB will not start.

*4 When specifying other than "0", "Out of Options Range" (error code: 1A4EH) occurs, and the FB will not start.

Ex.

Setting example of Target (TARGET_REF.Target)

· [DEV](PROFILE_CAM_DATA)G11500000

· [VAR]CamData1 (CamData1 is PROFILE_CAM_DATA type label)

- Read data 2 (Data2)/Write data 2 (Data2)

The structure to be specified differs depending on the setting of Read destination (Target)/Write destination (Target) and Interpolation Method Specification (Interpolate) of the target cam data.

For details, refer to the following table.

○: Supported, —: Not supported

FB	Read destination/Write destination (Target)	Structure specified in Read data 2/Write data 2 (Data2)	Interpolation Method Specification (Interpolate)		
			0: Linear Interpolation	1: Section Interpolation	2: Spline Interpolation
MCv_ReadProfileData (Profile Read)	0: Open area	LREAL[]	○	○*1	○*1
	1: File	LREAL[]	○	—	—
		PROFILE_CAM_ELEMENT[]	—	○	○*2
	2: Open area (motion service processing)	LREAL[]	○	○*1	○*1
MCv_WriteProfileData (Profile Write)	0: Open area	LREAL[]	○	—	—
		PROFILE_CAM_ELEMENT[]	—	○	○*2
	1: File	LREAL[]	○	—	—
		PROFILE_CAM_ELEMENT[]	—	○	○*2
	2: Open area (motion service processing)	LREAL[]	○	—	—
		PROFILE_CAM_ELEMENT[]	—	○	○*2

- *1 Read as the stroke data (a pair data of current value per cycle and stroke) expanded to the open area.
X of the 1st point data is the value set in start point and Y of the 1st point data is the value set in initial stroke amount.
The data of 2nd point or later is the stroke data divided by resolution.
Therefore, read/write point in open area is resolution + 1
- *2 Used only by end point and Stroke amount (Stroke)

The following occurs depending on the version of add-on ProfileControl used.

Add-on ProfileControl version	Description
Earlier than Version "1.19"	If the specified number of array elements does not match the resolution + 1/number of coordinates, "Number of Read/Write Data Mismatch" (error code: 3464H) occurs.
Version "1.19" or later	If the number of the elements of the specified array is smaller than the resolution+1/number of coordinates when reading/writing the entire operation profile, "Number of Read/Write Data Mismatch" (error code: 3464H) occurs.

The structures specified by read data 2/write data 2 (Data2) are shown below.

- LREAL type

Specify LREAL type two-dimensional array as follows.

LREAL[m..n, o..p]

Item	Description
The number of elements (n - m + 1)	Set the array elements so that they are greater than the number of points that are to be read. When reading/writing entire operation profile (Offset and Points are "0"), set it to be the resolution + 1/number of coordinates of the target cam data or more. However, an area larger than the resolution +1/number of coordinates read by Data1 is not updated when using MCv_ReadProfileData (Profile Read). An area larger than the resolution +1/number of coordinates specified by Data1 is not used when using MCv_WriteProfileData (Profile Write). If the add-on ProfileControl version is "earlier than Ver.1.19", it is necessary to match the number of elements of the specified array to the target resolution +1/number of coordinates.
The number of dimensions (p - o + 1)	Read/Write current value per cycle and stroke of each point. Set the array elements to be "2". If the array element is set to "3" or more, a read/write is possible, but as the intended result of the read/write may not be obtained due to data being moved forward, make sure to set the array element to "2".

Ex.

When setting LREAL type with Interpolation Method Specification (Interpolate)

· The following shows examples of setting the two-dimensional device/label coordinate number "100" to Target (Target) of the TARGET_REF structure.

Interpolation Method Specification (Interpolate)	Specification method	Setting example
0: Linear Interpolation	Buffer memory	TARGET_REF.Target := "[DEV](LREAL[1..100,1..2])G1150000"
	Label	TARGET_REF.Target := "[VAR]CamData2" *: CamData2 declares the "LREAL[1..100,1..2]" label to data type and label name of the global label to "CamData2", and specifies the character string for Target (Target).Reading/Writing data is as follows. · CamData2[n,1]: Nth point current position per cycle · CamData2[n,2]: Nth point stroke
1: Section Interpolation 2: Spline Interpolation	Buffer memory	TARGET_REF.Target := "[DEV](LREAL[1..101,1..2])G1150000"
	Label	TARGET_REF.Target := "[VAR]CamData2" *: CamData2 declares the "LREAL[1..100,1..2]" label to data type and label name of the global label to "CamData2", and specifies the character string for Target (Target).Reading/Writing data is as follows. · CamData2[1,1]: Value set for the start point · CamData2[1,2]: Value set for the initial stroke amount · CamData2[n + 1,1]: Nth point current position per cycle · CamData2[n + 1,2]: Nth point stroke *: When specifying labels, local labels can also be set. However, when setting the local label, specify the POU name to "@target modification". For details, refer to the following. ☞ Page 428 TARGET_REF structure

Point

When executing MCv_WriteProfileData (Profile Write) whose Target (Target) is "1: File" in the LREAL type array, Interpolation Method Specification (Interpolate) of the cam data format is output to the file as "0: Linear Interpolation".

- PROFILE_CAM_ELEMENT type

Specify PROFILE_CAM_ELEMENT type structure array as follows.

PROFILE_CAM_ELEMENT[m..n]

Item	Description
The number of elements (n - m + 1)	<p>Set the array elements so that they are greater than the number of points that are to be read.</p> <p>When reading/writing entire operation profile (Offset and Points are set to 0), set this to be Number of Sections (PROFILE_CAM_DATA.NumberOfSections) of the target cam data or more.</p> <p>However, an area larger than Number of Sections (PROFILE_CAM_DATA.NumberOfSections) read by Data1 is not updated when using MCv_ReadProfileData (Profile Read).</p> <p>An area larger than Number of Sections (PROFILE_CAM_DATA.NumberOfSections) specified by Data1 is not used when using MCv_WriteProfileData (Profile Write).</p> <p>If the add-on ProfileControl version is earlier than "1.19", it is necessary to match the number of elements of the specified array to Number of Sections (PROFILE_CAM_DATA.NumberOfSections) of the target cam data.</p>

Specify the following PROFILE_CAM_ELEMENT type structures.

PROFILE_CAM_ELEMENT			Device offset (Total size: 36 points)	Description
Variable name	Name	Data type		
CurveType	Cam curve type	MC_CAM_CURVE_TYPE	+0	<p>Set the cam curve. (When End point (EndPoint) is 0, it is invalid.)</p> <ul style="list-style-type: none"> • 0: Constant Velocity (ConstantSpeed) • 1: Constant Acceleration (ConstantAcceleration) • 2: Distorted Trapezoid (DistortedTrapezoid) • 3: Distorted Sine (DistortedSine) • 4: Distorted Constant Velocity (DistortedConstantSpeed) • 5: Cycloid (Cycloid) • 6: 5th curve (FifthCurve) • 7: Trapezoid (Trapezoid) • 8: Reverse Trapezoid (ReverseTrapezoid) • 9: Double Hypotenuse (DoubleHypotenuse) • 10: Reverse Double Hypotenuse (ReverseDoubleHypotenuse) • 11: Single Hypotenuse (SingleHypotenuse) • 12: 5th Curve (Adj.) (FifthCurve_SpeedDesignation)
EndPoint	End point ^{*1}	LREAL	+4	<p>Set the position to the length per cycle (the current value per cycle). (0.0 < End point (EndPoint) ≤ Length per cycle)</p>
Stroke	Stroke	LREAL	+8	<p>Set the stroke position. (The absolute value of Stroke amount (Stroke) ≤ Stroke amount)</p>
RangeP1	Curve applicable range (P1)	LREAL	+12	<p>Set the curve applicable range (start point: P1, end point: P2) for the cam curve.</p> <ul style="list-style-type: none"> • 0.0 to 1.0 <p>Set within the range of "P1 < P2". However, for "P1 = P2 = 0", "P1 = 0" and "P2 = 1" are applied.</p>
RangeP2	Curve applicable range (P2)	LREAL	+16	
RangeL1	Acceleration/ deceleration range compensation (Range L1)	LREAL	+20	<p>Set the acceleration/deceleration range (L1, L2) of the cam curve. (0.0001 < L1, L2 < 1.0000)</p> <p>The range that can be set differs depending on the cam curve. For "L1 = L2 = 0.0000", the default value for each cam curve is applied. On the curve that does not use L1 or L2, the setting value is ignored.</p>
RangeL2	Acceleration/ deceleration range compensation (Range L2)	LREAL	+24	
EndVelocity	End point velocity ^{*2}	LREAL	+28	<p>Set the end point velocity of the cam curve. (-2500000000.0 < End point velocity (EndVelocity) < 2500000000.0)</p>
EndAcceleration	End point acceleration ^{*2}	LREAL	+32	<p>Set the end point acceleration of the cam curve. (2147483647.0 < End point acceleration (EndAcceleration) < 2147483647.0)</p>

*1 When the end point exceeds the length per cycle before reaching the final section, the section number at the time is determined as the final section number and the end point is overwritten with the length per cycle.

*2 Setting items used for read/write differ depending on Interpolation Method Specification (Interpolate) of the operation profile. For details, refer to the following.

📖 Page 504 Cam data

Ex.

For PROFILE_CAM_ELEMENT type

The following shows examples of setting the device/label Number of sections "10" to Target (Target) of the TARGET_REF structure.

Specification method	Setting example
Buffer memory	TARGET_REF.Target := "[DEV](PROFILE_CAM_ELEMENT[1..10])G1150000"
Label	TARGET_REF.Target := "[VAR]CamData2" *: CamData2 declares the "PROFILE_CAM_ELEMENT[1..10]" label to data type and label name of the global label to "CamData2", and specifies the character string for Target (Target).Reading/Writing data is as follows. *: When specifying labels, local labels can also be set. However, when setting the local label, specify the POU name to "@target modification". For details, refer to the following. Page 428 TARGET_REF structure


Rotary cutter

Generate cam data of the rotary cutter. The stroke data that is defined after equally dividing a cam pattern per cycle of rotary cutter by points of the resolution is opened in the open area.







When using this operation profile format, install add-on PackagingApp.


The equipment and operation of the rotary cutter are described below.

- Equipment of rotary cutter



• Operation of rotary cutter

No.	Operation	Description
1	Start position of master axis (sheet) (= start position of cam data) Asynchronous constant section of master axis (sheet) (first) 	The master axis (sheet) and the slave axis (synchronous axis) move at constant velocity at different velocities until the start position of the acceleration/deceleration section of the master axis (sheet). Each velocity is automatically calculated from the setting value.
2	Acceleration/deceleration section of mater axis (sheet) (first) 	The slave axis (synchronous axis) accelerates (or decelerates) to the end position of the acceleration/deceleration section of the master axis (sheet). The acceleration of the slave axis (synchronous) is determined by the acceleration/deceleration method and the ratio of the length of the master axis (sheet length) to the length of the slave (synchronous) axis. <ul style="list-style-type: none"> • Master axis > Slave axis : Acceleration • Master axis = Slave axis : Constant velocity (same velocity) • Master axis < Slave axis : Deceleration
3	From start of synchronous section of master axis (sheet) to center 	From the start position of the synchronous section of the master axis (sheet) to the center of the synchronous section, the master axis (sheet) and the slave axis (synchronous axis) move at the same velocity.
4	From center of synchronous section of master axis (sheet) to end position 	The cutter of the slave axis (synchronous axis) is at the bottom and cuts the sheet. After that, the master axis (sheet) and the slave axis (synchronous axis) move at the same velocity until the end position of the synchronous section.
5	Acceleration/deceleration section of mater axis (sheet) (second) 	The slave axis (synchronous axis) decelerates (or accelerates) to the end position of the acceleration/deceleration section of the master axis (sheet). The acceleration of the slave axis (synchronous) is determined by the acceleration/deceleration method and the ratio of the length of the master axis (sheet length) to the length of the slave (synchronous) axis. <ul style="list-style-type: none"> • Master axis > Slave axis : Deceleration • Master axis = Slave axis : Constant velocity (same velocity) • Master axis < Slave axis : Acceleration
6	Asynchronous constant section of master axis (sheet) (second) 	The master axis (sheet) and the slave axis (synchronous axis) move at constant velocity at different velocities until the end position of the master axis (sheet). Each velocity is automatically calculated from the setting value.

No.	Operation	Description
7	End position of master axis (sheet) (= end position of cam data) 	When the master axis (sheet) has moved by the length of the sheet, the slave axis (synchronous axis) completes one cycle of operation. The next one cycle starts. (Returns to No. 1.)

For a necessary definition as cam data for the rotary cutter, refer to the following table.

◎: Necessary, ○: Optional, —: Unnecessary

Setting item		Cam data for rotary cutter
Profile ID		○
Interpolation method specification		—
Resolution/coordinate number		◎
Input unit character string		○
Output unit character string		—
Start point		—
Initial stroke amount		—
Initial velocity		—
Initial acceleration		—
Parameter	Auto-generation options	◎
	Synchronous section acceleration ratio	◎
	Sheet length	◎
	Sheet synchronization width	◎
	Synchronous axis length	◎
	Synchronous position adjustment	◎
	Acceleration/deceleration width	◎
	Number of cutter	◎
Length per cycle		—
Minimum value per cycle		—
Maximum value per cycle		—
Time per cycle		—
Stroke amount		— (Fixed with 360)

■Profile ID

It is a unique ID assigned by an open instruction.

ID can be specified with an arbitrary No.

■Resolution/coordinate number

Set the resolution for generating the cam.

■Input unit character string



Set a unit of the input with an arbitrary character string.

■Auto-generation options

Specify the auto-generation options.

- Acceleration/deceleration method

Set the acceleration/deceleration method for the acceleration/deceleration section. The velocity changes under the acceleration/deceleration method as follows.

Acceleration/deceleration method	Description
0: Trapezoidal acceleration/deceleration	
1: S-curve acceleration/deceleration	

- Synchronous axis length setting




Set the synchronous axis length from "0: Diameter" or "1: Cycle length". For details on the setting method, refer to the following.

👉 Page 519 Synchronous axis length

■Synchronous section acceleration ratio

Set when the synchronous speed in the synchronous section needs to be adjusted.

The speed is "Synchronous speed × (100% + Acceleration ratio)" in the synchronous section.

Acceleration ratio	Description
-50.0%	
0.0%	
50.0%	

■Sheet length

Set the sheet length.



■Sheet synchronization width

Set the sheet synchronization width (seal width).

When the synchronous speed section for retracting operation is required in front of and behind the sheet synchronization width, add the retracting width.

■Synchronous axis length




Set the rotary cutter axis length. Set as follows according to the setting of the synchronous axis length of auto-generation options.

Synchronous axis length setting	Description	Calculation formula
0: Diameter		Cycle length = setting value × pi (π)
1: Cycle length		Cycle length = setting value

■Synchronous position adjustment

Set the position adjustment of the synchronous section. Set the value within 1/2 of the sheet length.

If the synchronous section includes the synchronous speed section for retracting operation, adjust the width for retracting.

Synchronous position adjustment	Description
Negative value (negative direction)	<p>The synchronous section is adjusted to the sheet start side.</p> 
0	<p>The center of the sheet is in the synchronous section.</p> 
Positive value (positive direction)	<p>The synchronous section is adjusted to the sheet end side.</p> 

■Acceleration/deceleration width

Set the sheet width (one side) of the acceleration/deceleration area.

When a negative value is set to the acceleration/deceleration area, the acceleration/deceleration width is automatically calculated to be the maximum.

■Number of cutters

Set the number of cutters of the rotary cutter.



If the number of cutters is set to 2 or more, the length per cutter becomes shorter. In this case, adjust the stroke amount of the output axis.

- For cam operation (MC_CamIn)

Set the slave axis scaling (SlaveScaling) to " $1 \div \text{number of cutters}$ ".

- For advanced synchronous control (MCv_AdvancedSync)

Set the cam stroke amount (AdvOutPutName.Pr.Cam.StrokeAmount) of the output axis to " $\text{Cycle length} \div \text{number of cutters}$ ".

Number of cutters	Description
1	 <p>Length of slave axis (synchronous axis)</p> <p>Length of master axis (sheet)</p>
2	 <p>The length of slave axis (synchronous axis) does not change.</p> <p>The length per cutter among the slave axes (synchronous axes) is shortened.</p> <p>Length of master axis (sheet)</p> <p>The length of master axis (sheet) does not change.</p>

■Read/write data structure

This section describes read data 1/write data 1 (Data1) specified by MCv_ReadProfileData (Profile Read)/MCv_WriteProfileData (Profile Write) when executing read/write operation profile.

Read data 2/Write data 2 (Data2) is not used when executing read/write operation profile of rotary cutter.



However, when reading the expanded cam data by using the cam data for rotary cutter from the open area again, the cam data format (Interpolation Method Specification (Interpolate): "0: Linear Interpolation") should be specified. For details of the data structure for read/write specified with cam data format, refer to the following.

☞ Page 510 Read/write data structure

■Rotary cutter (Specifying a double-precision real number)

- Read data 1/Write data 1 (Data1)

Specify the PROFILE_ROTARY_CUTTER type structure.

PROFILE_ROTARY_CUTTER			Device offset (Total size: 68 points)	Description
Variable name	Name	Data type		
Resolution	Resolution	DWORD(UDINT)	+0	Sets the resolution for generating the cam. • 8 to 32768
InputUnitString	Input unit character string	WSTRING(31)	+2	Sets the input unit character string.
Options	Options	DWORD(HEX)	+34	<p>Specify Options.</p>  <p>■Periodic (bit0)</p> <ul style="list-style-type: none"> • 0: Non periodic • 1: Periodic <p>For details, refer to the following.</p> <p>☞ Page 486 Periodic</p> <p>■Master axis (input) absolute coordinate (bit1)</p> <ul style="list-style-type: none"> • 0: Relative coordinate • 1: Setting not possible^{*1} <p>For details, refer to the following.</p> <p>☞ Page 490 Master axis absolute coordinate</p> <p>■Slave axis (output) absolute coordinate (bit2)</p> <ul style="list-style-type: none"> • 0: Relative coordinate • 1: Absolute coordinate <p>For details, refer to the following.</p> <p>☞ Page 490 Slave axis absolute coordinate</p> <p>*: For bit 3 to 31, specify "0".^{*2}</p>
AutoGeneration Options	Auto-generation options	WORD(HEX)	+36	<p>Sets the auto-generation options with bit specification.</p>  <p>■Acceleration/deceleration method (bit0)</p> <ul style="list-style-type: none"> • 0: Trapezoidal acceleration/deceleration • 1: S-curve acceleration/deceleration <p>■Synchronous axis length setting (bit1)</p> <ul style="list-style-type: none"> • 0: Diameter • 1: Cycle length <p>*: Set bits 2 to 15 to "0".</p>
NumberOfCutter	Number of cutter	WORD(UINT)	+37	Set the number of cutter. • 1 to 256
SyncSectionAcc Ratio	Synchronous section acceleration ratio	LREAL	+40	Set when the synchronous speed in the synchronous section needs to be adjusted. The speed is "Synchronous speed × (100% + Acceleration ratio)" in the synchronous section. • -5000.0 to 5000.0 [in units of 0.01%]
SheetLength	Sheet length	LREAL	+44	Set the sheet length. (0.0 < Sheet length (SheetLength) ≤ 10000000000.0)
SheetSyncWidth	Sheet synchronization width	LREAL	+48	Set the sheet synchronization width (seal width). When the synchronous speed section for retracting operation is required in front of and behind the sheet synchronization width, add the retracting width. (0.0 < Sheet synchronization width (SheetSyncWidth) < Sheet length (SheetLength)) (0.0 < Sheet synchronization width (SheetSyncWidth) < Cycle length /Number of cutter (NumberOfCutter))

PROFILE_ROTARY_CUTTER			Device offset (Total size: 68 points)	Description
Variable name	Name	Data type		
SyncAxisLength	Synchronous axis length	LREAL	+52	<ul style="list-style-type: none"> Set the rotary cutter axis length. ■When the auto-generation options is set to "0: Diameter" it is calculated as "Cycle length = setting value $\times \pi$". ■When the auto-generation options is set to "1: Cycle length" it is calculated as "Cycle length = setting value". (0.0 < Cycle length < 10000000000.0)
SyncPositionAdjustment	Synchronous position adjustment	LREAL	+56	Set the position adjustment of the synchronous section. <ul style="list-style-type: none"> Negative value: The synchronous section is adjusted to the sheet start side. 0: The center of the sheet is in the synchronous section. Positive value: The synchronous section is adjusted to the sheet end side. (The absolute value of Synchronous position tuning (SyncPositionAdjustment) < Sheet synchronization width (SheetLength) / 2)
AccDecWidth	Acceleration/deceleration width	LREAL	+60	Set the sheet width (one side) of the acceleration/deceleration area. When a negative value is set, the acceleration/deceleration width is calculated to be the maximum. $(2 \times \text{Acceleration/deceleration width (AccDecWidth)} \leq \text{Sheet length (SheetLength)} - \text{Sheet synchronization width (SheetSyncWidth)})$
AsyncSpd	Asynchronous velocity result	LREAL	+64	When the auto-generation is successfully completed, the asynchronous speed is stored as the ratio of the synchronous speed.

*1 When "1" is set, "Out of MasterAbsolute Range" (error code: 341DH) occurs and the FB will not start.

*2 When specifying other than "0", "Out of Options Range" (error code: 1A4EH) occurs and the FB will not start.

- Read data 2/Write data 2 (Data2)
Specifying is not required. (It is ignored.)

Multiple axes positioning data

For a necessary definition as positioning data, refer to the following table.

◎: Necessary, ○: Optional, —: Unnecessary

Setting item		Multiple axes positioning data
Profile ID		○
Periodic		—
Input absolute coordinate		—
Output absolute coordinate		—
Operation profile format		◎
Profile data type		◎
Interpolation method specification		—
Resolution/coordinate number		—
Start point		—
Initial stroke amount		—
Initial velocity		—
Initial acceleration		—
Options		○
Number of positioning data settings		○
Total number of positioning data		◎
Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10)	IO Number (StartIO)	—
	Target (Target)	○
	Signal detection method (Detection)	○
	Compensation time (CompensationTime)	○
	Filter time (FilterTime)	○
Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10)	IO Number (StartIO)	—
	Target (Target)	○
	Signal detection method (Detection)	○
	Compensation time (CompensationTime)	○
	Filter time (FilterTime)	○
Positioning data	Positioning data No. (DataNo)	◎
	Operation pattern (OperationPattern)	○*1
	Control method (ControlMethod)	◎
	Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4)	○*1
	Circular interpolation mode (CircMode)	○*1
	Path selection (CircPathChoice)	○*1
	Target position/movement amount/end point 1 to Target position/movement amount/end point 4 (Position1 to Position4)	○*1
	Direction selection 1 to Direction selection 2 (Direction1 to Direction4)	○*1
	Sub point 1 to Sub point 4 (CircAuxPoint1 to CircAuxPoint4)	○*1
	Velocity mode (VelocityMode)	○*1
	Velocity (Velocity)	○*1
	Acceleration (Acceleration)	○*1
	Deceleration (Deceleration)	○*1
	Jerk (Jerk)	○*1
	Circular interpolation error tolerance (CircErrorTolerance)	○*1
	Positioning data options (DataOptions)	○*1
	Dwell time (DwellTime)	○*1
	M code (Mcode)	○*1
	M code output timing override (McodeOutput_Override)	○*1
	JUMP destination positioning data No. (JumpDestinationDataNo)	○*1
	Condition signal No. (ConditionSignalNo)	○*1
	Number of LOOP to LEND repetitions (LoopCount)	○*1

Setting item		Multiple axes positioning data
Positioning data	Skip signal No. (SkipSignalNo)	○*1
	Pitch (Pitch)	—
Length per cycle		—
Length per cycle unit setting		—
Length per cycle unit character string		—
Minimum value per cycle		—
Maximum value per cycle		—
Time per cycle		—
Stroke amount		—
Stroke amount unit setting		—
Stroke amount unit character string		—

*1 The items required to be set differ depending on the Control method (ControlMethod). For details, refer to the following.

☞ Page 245 Setting positioning data

■Profile ID

It is a unique ID assigned by an open instruction.

ID can be specified with an arbitrary No.

■Operation profile format

When using the operation profile format, set to "Multiple axes positioning data format".

■Profile data type

When using the profile data type, set to "Multiple axes positioning data".

■Number of positioning data settings

Specify the number of positioning data to be set.

Set the number of positioning data settings less than the total number of positioning data.

When executing write, the motion system automatically calculates the number of positioning data settings. Therefore, no setting is required.

When the value is out of setting range, or exceeding the total number of positioning data, "Operation Profile Data Incorrect" (error code: 3410H) occurs when opening.

- Setting range: 0 to 5000

■Total number of positioning data

It is the total number of positioning data.

Specify the maximum value of Positioning data No. to be set by open and write.

When the value is out of setting range, "Operation Profile Data Incorrect" (error code: 3410H) occurs when opening.

- Setting range: 1 to 5000



The larger the total number of positioning data is, the more positioning data can be set. However, the data size increases accordingly. For details on data size, refer to the following.

☞ Page 534 Capacity of operation profile

■Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10)

When the Control method (ControlMethod) is set to "0082H: JUMP(JUMP)", set the execution conditions for JUMP. When the setting of each item is omitted, the value becomes the following initial value.

For details and setting range of each item, refer to the following.

☞ Page 270 Condition signal setting

Item	Initial value
I/O Number (StartIO)	0
Target (Target)	"" (a character string of length 0)
Signal detection method (Detection)	0: Detection at TRUE (HighLevel)
Compensation time (CompensationTime)	0.0
Filter time (FilterTime)	0.0

■Skip signal (SkipSignal1 to SkipSignal10)

Set the skip signals to be used with operation profile control.

For details and the setting range of each item, refer to the following.

☞ Page 271 Skip signal setting

Item	Initial value
IO Number (StartIO)	0
Target (Target)	"" (a character string of length 0)
Signal detection method (Detection)	0: Detection at TRUE (HighLevel)
Compensation time (CompensationTime)	0.0
Filter time (FilterTime)	0.0

Set as follows depending on the version of add-on ProfileControl used.

Add-on ProfileControl version	Description
"1.33" or later	Refer to the following for the setting contents and range of each item. ☞ Page 271 Skip signal setting
"1.31" or earlier	Not used in Motion control FBs. Omit the setting or use the initial value.

■Positioning data

Set the interpolation operation to be executed with operation profile control. When the setting of each item is omitted, the value becomes the following initial value.

For details and the setting range of each item, refer to the following.

☞ Page 245 Setting positioning data

Item	Initial value
Positioning data No. (DataNo)	Omission not possible
Operation pattern (OperationPattern)	0: Positioning complete (PositioningComplete)
Control method (ControlMethod)	Omission not possible
Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4)	0
Circular interpolation mode (CircMode)	0: Border point specification (mcBorder)
Path selection (CircPathChoice)	0: CW (mcCW)
Target position/movement amount/end point 1 to Target position/movement amount/end point 4 (Position1 to Position4)	0.0
Direction selection 1 to Direction selection 2 (Direction1 to Direction4)	0
Sub point 1 to Sub point 4 (CircAuxPoint1 to CircAuxPoint4)	0.0
Velocity mode (VelocityMode)	0: Vector velocity (VectorSpeed)
Velocity (Velocity)	0.0
Acceleration (Acceleration)	0.0
Deceleration (Deceleration)	0.0
Jerk (Jerk)	0.0
Circular interpolation error tolerance (CircErrorTolerance)	100.0
Positioning data options (DataOptions)	00000000H
Dwell time (DwellTime)	0.0

Item	Initial value
M code (Mcode)	0
M code output timing override (McodeOutput_Override)	0: Use FB options (UseFbOptions)
JUMP destination positioning data No. (JumpDestinationDataNo)	0
Condition signal No. (ConditionSignalNo)	0
Number of LOOP to LEND repetitions (LoopCount)	0
Skip signal No. (SkipSignalNo)	0
Pitch (Pitch)	0

■Read/write data structure

This section describes read data 1/write data 1 (Data1) and read data 2/write data 2 (Data2) specified by MCv_ReadProfileData (Profile Read)/MCv_WriteProfileData (Profile Write) when executing read/write operation profile.

- Read data 1/Write data 1 (Data 1)

For Read data 1/Write data 1 (Data 1), specify the PROFILE_POSITIONING_DATA type structure.

PROFILE_POSITIONING_DATA			Device offset (Total size: 4 points)	Description
Variable name	Name	Data type		
NumberOfDataSettings	Number of positioning data settings	WORD(UINT)	+0	Sets the number of positioning data to be set.*1 • 0 to 5000
TotalNumberOfData	Total number of positioning data points	WORD(UINT)	+1	Sets the total number of positioning data points.*2 • 1 to 5000
Options	Options	DWORD(HEX)	+2	Sets the options. *: Set to "00000000H".

*1 When executing MCv_WriteProfileData (Profile Write), the motion system automatically calculates the Number of positioning data settings (NumberOfDataSettings). Therefore, no setting is required.

*2 When specifying a profile ID which has been opened/written, and overwriting it with MCv_WriteProfileData (Profile Write), the original open data will be discarded if the Total number of positioning data (TotalNumberOfData) does not match.

When setting the Number of write data (Points) to other than "0", and partially overwriting it with MCv_WriteProfileData (Profile Write), make the setting so that the Total number of positioning data (TotalNumberOfData) matches.

Ex.

When setting device and label

Specification method	Setting example
Buffer memory	Data1.Target := "[DEV](PROFILE_POSITIONING_DATA)G11500000";
Label*1	Data1.Target := "[VAR]G_stPositioningData";

*1 Declare the following label in the global label.

Label name	Data type
G_stPositioningData	PROFILE_POSITIONING_DATA

- Read data 2/write data 2 (Data2)

Specify the structure type as follows for the structure specified in Read data 2/write data 2 (Data2).

Structure	Description
PROFILE_POSITIONING_DATA_ELEMENT	<ul style="list-style-type: none"> • Specify when reading/writing the positioning data. • Condition signals and skip signals are not read/written.*1
PROFILE_POSITIONING_DATA_EXTENDED	<ul style="list-style-type: none"> • Specify when reading/writing condition signals, skip signals, and the positioning data. • Reading/writing condition signals or skip signals can be omitted when specified.*1 • Condition signals and skip signals can be read/written, but the processing time increases accordingly.

*1 When a profile ID that is already opened/written is specified and overwritten by MCv_WriteProfileData (Profile Write), if the total number of positioning data is the same as the original opened data, the data not written is maintained. (If the total number of positioning data is different, the data is discarded.)

■PROFILE_POSITIONING_DATA_ELEMENT type

- Specify the PROFILE_POSITIONING_DATA_ELEMENT(m..n) type structure.
- Set the number of elements (n – m + 1) of the specified array so that it is equal to or more than the number of points that are to be read/written. When reading/writing the entire operation profile (Offset and Points are "0"), set the number of array elements so that it equal to or more than Total Number of Positioning Data (PROFILE_POSITIONING_DATA.TotalNumberOfData). If the number of the array elements is less, "Number of Read/Write Data Mismatch" (error code: 3464H) occurs.

PROFILE_POSITIONING_DATA_ELEMENT[m..n]			Device offset (Total size: 88 points)	Description
Variable name	Name	Data type		
DataNo	Positioning data No.	WORD(UINT)	+0	Indicates the index No. of the positioning data. • 1 to total number of positioning data
OperationPattern	Operation Pattern	MC_OPERATION_PATTERN	+1	Sets the operation pattern.* ¹ • 0: Positioning complete (PositioningComplete) • 1: Continuous positioning (ContinuousPositioning) • 2: Continuous path (BlendingLow) (ContinuousBlendingLow) • 3: Continuous path (BlendingPrevious) (ContinuousBlendingPrevious) • 4: Continuous path (BlendingNext) (ContinuousBlendingNext) • 5: Continuous path (BlendingHigh) (ContinuousBlendingHigh)
ControlMethod	Control method	MC_CONTROL_METHOD	+2	Sets the control method.* ¹ • 0080H: NOP(NOP) • 0082H: JUMP(JUMP) • 0083H: LOOP(LOOP) • 0084H: LEND(LEND) • 0101H: Absolute value linear interpolation (LinearAbsolute) • 0102H: Relative value linear interpolation (LinearRelative) • 0103H: Absolute value circular interpolation (CircularAbsolute) • 0104H: Relative value circular interpolation (CircularRelative)
InterpolationAxis1	Interpolation axes 1	WORD(UINT)	+3	Sets the linear interpolation axes for linear interpolation, or the circular interpolation axes for circular interpolation depending on the setting of the control method (ControlMethod).* ¹  Page 256 Interpolation axes 1 to Interpolation axes 4 (InterpolationAxis1 to InterpolationAxis4)
InterpolationAxis2	Interpolation axes 2	WORD(UINT)	+4	
InterpolationAxis3	Interpolation axes 3	WORD(UINT)	+5	
InterpolationAxis4	Interpolation axes 4	WORD(UINT)	+6	
CircMode	Circular interpolation mode	MC_CIRC_MODE	+7	Set the specification method for circular interpolation.* ¹ • 0: Border point specification (mcBorder) • 1: Center point specification (mcCenter) • 2: Radius specification (mcRadius)
CircPathChoice	Path selection	MC_CIRC_PATHCHOICE	+8	Sets the rotation direction of the circular interpolation.* ¹ • 0: CW (mcCW) • 1: CCW (mcCCW) • 2: Shortcut (mcShortWay) • 3: Detour (mcLongWay) • 4: CW Detour (mcCWLongWay) • 5: CCW Detour (mcCCWLongWay)
Reserve1[0..2]	Reserve 1	WORD(UINT)	+9	Not used. (For offset adjustment)
Position1	Target position/ movement amount/ end point 1	LREAL	+12	Set the target position, movement amount, and end point depending on the settings of Control method (ControlMethod).* ¹  Page 257 Target position/movement amount/end point 1 to target position/movement amount/end point 4 (Position1 to Position4)
Position2	Target position/ movement amount/ end point 2	LREAL	+16	
Position3	Target position/ movement amount/ end point 3	LREAL	+20	
Position4	Target position/ movement amount/ end point 4	LREAL	+24	
Direction1	Direction selection 1	MC_DIRECTION	+28	For linear interpolation control, this sets the direction used to move from the current position to the target position.* ¹ • 1: Positive direction (mcPositiveDirection) • 2: Negative direction (mcNegativeDirection) • 3: Shortest path (mcShortestWay)
Direction2	Direction selection 2	MC_DIRECTION	+29	
Direction3	Direction selection 3	MC_DIRECTION	+30	
Direction4	Direction selection 4	MC_DIRECTION	+31	

PROFILE_POSITIONING_DATA_ELEMENT[m..n]			Device offset (Total size: 88 points)	Description
Variable name	Name	Data type		
CircAuxPoint1	Sub point 1	LREAL	+32	For circular interpolation control, this sets the position from the current position at start to the border point and center point. ^{*1} ■For "0: Border point specification (mcBorder)" and "1: Center point specification (mcCenter)" -10000000000.0 to 10000000000.0 ■For "2: Radius specification (mcRadius)" 0.000001 to 2147483647.0
CircAuxPoint2	Sub point 2	LREAL	+36	
CircAuxPoint3	Sub point 3	LREAL	+40	
CircAuxPoint4	Sub point 4	LREAL	+44	
VelocityMode	Velocity mode	MC_INTERPOLATE_SPEED_MODE	+48	Sets the velocity mode for linear interpolation control. ^{*1} • 0: Vector velocity specification (VectorSpeed) • 1: Long axis velocity specification (LongAxisSpeed) • 2: Reference axis velocity specification (ReferenceAxisSpeed)
Reserve2[0..2]	Reserve 2	WORD(UINT)	+49	Not used. (For offset adjustment)
Velocity	Velocity	LREAL	+52	Sets the positioning speed of the multiple axes interpolation. ^{*1} • 0.0, 0.0001 to 2500000000.0
Acceleration	Acceleration	LREAL	+56	Sets the acceleration for multiple axes interpolation. ^{*1} • 0.0000, 0.0001 to 2147483647.0
Deceleration	Deceleration	LREAL	+60	Sets the deceleration for the multiple axes interpolation. ^{*1} • 0.0000, 0.0001 to 2147483647.0
Jerk	Jerk	LREAL	+64	Sets the jerk for the multiple axes positioning control. ^{*1} • 0.0000, 0.0001 to 2147483647.0
CircErrorTolerance	Circular interpolation error tolerance	LREAL	+68	Set the allowable range of a circular interpolation error. ^{*1} • 0.000001 to 100000.0
DataOptions	Positioning data options	DWORD(HEX)	+72	Sets the linear interpolation or the circular interpolation options. ^{*1}  Page 259 Positioning data options (DataOptions)
Reserve3[0..1]	Reserve 3	WORD(UINT)	+74	Not used. (For offset adjustment)
DwellTime	Dwell time	LREAL	+76	Sets the dwell time. ^{*1} • 0.0 [s]: Dwell function disabled • 0.000001 [s] to 8400.0 [s]: Dwell function enabled
Mcode	M code	WORD(UINT)	+80	Sets the M code. ^{*1} • 0 to 65535 *: Set "0" when not using the M code.
McodeOutput_Override	M code output timing override	MC_MCODE_OUTPUT_OVERRIDE	+81	M code output timing override. ^{*1} • 0: Use FB options (UseFbOptions) • 1: WITH mode (WithMode) • 2: AFTER mode (AfterMode)
JumpDestinationDataNo	JUMP destination positioning data No.	WORD(UINT)	+82	Sets the positioning data No. of the jump destination. ^{*1} • 1 to Total number of positioning data (5000)
ConditionSignalNo	Condition signal No.	WORD(UINT)	+83	Set the condition signal No. ^{*1} • 0 to 10 *: Set "0" when not using the condition signal.
LoopCount	LOOP to LEND loop count	WORD(UINT)	+84	Sets the number of repetitions for loop control. ^{*1} • 1 to 65535
SkipSignalNo	Skip signal No.	WORD(UINT)	+85	Set the skip signal No. ^{*1} • 0 to 10 *: Set "0" when not using the skip signal.
Pitch	Pitch	WORD(UINT)	+86	Not used. *: Set to "0" at writing.
Reserve4	Reserve 4	WORD(UINT)	+87	Not used. (For offset adjustment)

^{*1} Errors caused by setting values do not occur at writing. When the written open area is used by the operation profile control FB, an error will occur when the setting value is out of the setting range.

Ex.

When setting the device/label of the number of elements "10" to "Data2.Target"

Specification method	Setting example
Buffer memory	Data2.Target := "[DEV](PROFILE_POSITIONING_DATA_ELEMENT[1..10])G11501000";
Label ^{*1}	Data2.Target := "[VAR]G_st10PositioningDataElem"; *: When specifying labels, local labels can also be set. For details, refer to the following. ☞ Page 428 TARGET_REF structure

*1 Declare the following label in the global label.

Label name	Data type
G_st10PositioningDataElem	PROFILE_POSITIONING_DATA_ELEMENT[1..10] ^{*2}

*2 Read/write data is as follows.

G_st10PositioningDataElem[n]: nth positioning data (PROFILE_POSITIONING_DATA_ELEMENT type)

■PROFILE_POSITIONING_DATA_EXTENDED type

- Specify the PROFILE_POSITIONING_DATA_EXTENDED type structure. Also, specify variables that store condition signals, skip signals, and positioning data for each member (WSTRING type). Condition signals (ConditionSignal), skip signals (SkipSignal), and the positioning data of the specified destination are read/write targets.
- The target of the section to be read/written specified by Offset (Offset) and Number of read data/ Number of write data (Points) is the positioning data (PositioningData).

PROFILE_POSITIONING_DATA_EXTENDED			Device offset (Total size: 192 points)	Description
Variable name	Name	Data type		
ConditionSignal ^{*1}	Condition signal	WSTRING(63)	+0	Set the condition signal as the character string of TARGET_REF type. For details, refer to the following. ☞ Page 428 TARGET_REF structure The setting range of the character string is as follows. ^{*2} ■Data type • [VAR] • [DEV] ■Type • PROFILE_SIGNAL_SELECT_ELEMENT *: When "" (no setting), read/write is not performed.
SkipSignal ^{*1}	Skip signal	WSTRING(63)	+64	Set the skip signal as the character string of TARGET_REF type. For details, refer to the following. ☞ Page 428 TARGET_REF structure The setting range of the character string is as follows. ^{*2} ■Data type • [VAR] • [DEV] ■Type • PROFILE_SIGNAL_SELECT_ELEMENT *: When "" (no setting), read/write is not performed.
PositioningData	Positioning data	WSTRING(63)	+128	Set the positioning data as the character string of TARGET_REF type. For details, refer to the following. ☞ Page 428 TARGET_REF structure The setting range of the character string is as follows. ■Data type • [VAR] • [DEV] ■Type • PROFILE_POSITIONING_DATA_ELEMENT *: When "" (no setting), "Read/Write Data Type Incorrect" (error code: 3462H) occurs.

*1 For the member condition signal (ConditionSignal) and the skip signal (SkipSignal) of the PROFILE_POSITIONING_DATA_EXTENDED type, specify the PROFILE_SIGNAL_SELECT_ELEMENT[o..p] type structure. Starting with the element with the start No. "0", read/write is performed for Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) or Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10).

*2 If the specified type does not meet the requirements for each structure member, "Read/Write Data Type Incorrect" (error code: 3462H) occurs. Also, if the specified data type does not meet the requirements for each structure member, "Read/Write Data Data Type Incorrect" (error code: 3460H) occurs.

■PROFILE_SIGNAL_SELECT_ELEMENT[o..p]^{*1} type

PROFILE_SIGNAL_SELECT_ELEMENT[o..p] ^{*1}			Device offset (Total size: 76 points)	Description ^{*2}
Variable name	Name	Data type		
StartIO	I/O Number	WORD(HEX)	+0	Not used. Ignore the setting.
Reserve1	Reserve 1	WORD(UINT)	+1	Not used. (For offset adjustment)
Target	Target	WSTRING(63)	+2	Set the signal to be used as a string. For details, refer to the following. <div>  Page 428 TARGET_REF structure </div> The setting range of the string is as follows. <ul style="list-style-type: none"> • ""^{*3} ■Data type <ul style="list-style-type: none"> • [OBJ]^{*4} • [VAR] • [DEV] ■Type <ul style="list-style-type: none"> • BOOL
Detection	Signal Detection Method	MC_SIGNAL_LO GIC	+66	Specify the signal logic. <ul style="list-style-type: none"> • 0: Detection at TRUE (HighLevel) • 1: Detection at FALSE (LowLevel)
Reserve2	Reserve 2	WORD(UINT)	+67	Not used. (For offset adjustment)
CompensationTime	Compensation Time	LREAL	+68	Set "0.0".
FilterTime	Filter Time	LREAL	+72	Set the filter time for removing chattering of the input signal in units of seconds. <ul style="list-style-type: none"> • 0.0 to 5.0 [s]

*1 If the number of elements (p-o+1) is less than 10, read/write is performed only for the number of elements.

If the number of elements in the specified variable is greater than 10, the 11th and subsequent elements are not used.

*2 Errors caused by setting values do not occur at writing. When the written open area is used by the operation profile control FB, an error will occur when the setting value is out of the setting range.

*3 When Target (Target) is "" (a character string of length 0), the corresponding condition signal is treated as not set.

*4 When [OBJ] is set as the data type, the target modification cannot be omitted. If the setting is omitted, "Operation Profile Data Control Profile ID Setting Incorrect" (error code: 1AFAH) will occur.

Ex.

When setting "Data2.Target" to device/label of condition signals (ConditionSignal), skip signals (SkipSignal), and the positioning data (PositioningData) (20 points).

Specification method	Setting example
Buffer memory ^{*1}	G_stPositioningDataExt.ConditionSignal := "[DEV](PROFILE_SIGNAL_SELECT_ELEMENT[1..10])G11501000"; G_stPositioningDataExt.SkipSignal := "[DEV](PROFILE_SIGNAL_SELECT_ELEMENT[1..10])G11502000"; G_stPositioningDataExt.PositioningData := "[DEV](PROFILE_POSITIONING_DATA_ELEMENT[1..20])G11503000"; Data2.Target := "[VAR]G_stPositioningDataExt";
Label ^{*1}	G_stPositioningDataExt.ConditionSignal := "[VAR]G_st10ConditionSignal"; G_stPositioningDataExt.SkipSignal := "[VAR]G_st10SkipSignal"; G_stPositioningDataExt.PositioningData := "[VAR]G_st20PositioningDataElem"; Data2.Target := "[VAR]G_stPositioningDataExt"; *: When specifying labels, local labels can also be set. For details, refer to the following. <div>  Page 428 TARGET_REF structure </div>

*1 Declare the following label in the global label.

Label name	Data type
G_stPositioningDataExt	PROFILE_POSITIONING_DATA_EXTENDED
G_st10SkipSignal	PROFILE_SIGNAL_SELECT_ELEMENT[1..10] ^{*2}
G_st10ConditionSignal	PROFILE_SIGNAL_SELECT_ELEMENT[1..10] ^{*2}
G_st20PositioningDataElem	PROFILE_POSITIONING_DATA_ELEMENT[1..20] ^{*2}

*2 Read/write data is as follows.

- G_st10ConditionSignal[n]: nth condition signal (PROFILE_SIGNAL_SELECT_ELEMENT type)
- G_st10SkipSignal[n]: nth skip signal (PROFILE_SIGNAL_SELECT_ELEMENT type)
- G_st20PositioningDataElem[n]: nth positioning data (PROFILE_POSITIONING_DATA_ELEMENT type)

Precautions

- When the add-on ProfileControl version is "1.31" or earlier, read/write of the condition signals and the skip signals cannot be performed by using MCv_ReadProfileData (Profile Read)/MCv_WriteProfileData (Profile Write). When using the condition signals and the skip signals in the operation profile control FB, use only auto expand for the operation profile operation.
- When reading/writing condition signals and skip signals, use the add-on ProfileControl version "1.33" or later.

Creating operation profile

This section describes storage format and creating method of the operation profile.

Storage format

The following storage format can be used as the operation profile in the motion system.

Storage format	Details	Characteristics
Standard text format	Stores the operation profile as a standard text file (csv file).	The data created in the engineering tool can be stored in this format.

Creating method when not using the engineering tool

When using the operation profile in the control without using the engineering tool, execute the following procedures.

■When creating the operation profile by a program

1. Store data (read/write data structure for each type) corresponding to the operation profile format that will be created on the variables (labels and devices).
2. Set the profile data type (standard/function specific) label as needed. (When storing created operation profile in the file, set the storage location in Operation profile storage location (Location).)
3. When executing the operation profile write FB, the control ID can be obtained in the profile ID type (standard/function specific) label.
4. Execute the control FB by using the profile ID type (standard/function specific) label.

■When using the operation profile created outside

1. Store the operation profile in an arbitrary place such as a user drive and an SD memory card.
2. Set the storage location in Operation profile storage location (Location) of the profile data type (standard/function specific) label.
3. When executing the open FB, the control ID can be obtained in the profile ID type (standard/function specific) label.
4. Execute the control FB by using the profile ID type (standard/function specific) label.

Creating method when using the engineering tool

When the operation profile is created in the engineering tool, the profile data type global label whose label name is the operation profile name is automatically added, and it can be used in the program. The set description (storage location and ID) is reflected as the label initial value.

When the profile data type includes the profile ID type of "function specific type" in the member, the set description is also reflected as the initial value in the profile ID type of "function specific type".

Ex.

When creating an operation profile with "Name: ProfileData0001", "Format: Cam data", and "Profile ID: 1"

The initial value of ProfileData0001.CamID.ProfileID becomes "1". (Same as the initial value of ProfileData0001.ProfileData.ID.Number.)

The profile ID type of "function specific type" can be used as the I/O of operation profile control FB or input parameter.

Point

- Profile data type labels created by the engineering tool cannot be edited on the global label editor. Be sure to create and edit it on the operation profile create window.
- The default write destination of the operation profile created by the engineering tool is "%PROJECT_ROOT%/calc_profile/", and the storage location is set at Operation profile storage location (PROFILE_DATA.Location). Files within this folder (including the sub folders) may be overwritten or deleted by the engineering tool operation, so the operation profile created by the program, store in location other than the folder above (including the sub folder).

Operating operation profile

Operation profile uses files and open areas, and performs operation profile manipulation and operation profile controls.

Operation profile related function		Description
Operation profile manipulation	Operation profile open	Performs open of operation profile from "File" to "Open area".
	Operation profile read/write	Performs read/write of operation profile of "File" and "Open area". Uses read/write data structure.
Operation profile control		Performs control by using operation profile of "Open area".

Data type of operation profile

The profile data type and the profile ID type can be used as the data type to perform operation profile manipulation/operation profile controls.

- "File" is managed by the profile data type labels.

Specify the file path and file name in Operation profile storage location (PROFILE_DATA.Location).

- "Open area" is managed by the profile ID type labels.

When writing operation profile in the open area by the operation profile manipulation (open/write), the ID is assigned in the open area by specifying arbitrary ID for Profile ID No. (PROFILE_ID.Number).

- Control can be carried out by specifying the label of profile ID type at the operation profile controls.

Entity of operation profile	Description	Data type for operation/control	Remark
File	Written by the following operation. <ul style="list-style-type: none"> • Write from the engineering tool • Operation profile write FB execution (The write destination is "File") 	Profile data type <ul style="list-style-type: none"> • General type (PROFILE_DATA type) • Function specific type (MC_CAM_REF type, etc.) 	Data is preserved even when the power turns OFF.
Open area	Written by the following operation. <ul style="list-style-type: none"> • Operation profile expand execution (Auto expand/operation profile expand FB execution) • Operation profile write FB execution (The write destination is "Open area") 	Profile ID type <ul style="list-style-type: none"> • General type (PROFILE_ID type) • Function specific type (MC_CAM_ID type, etc.) 	Data actually used in the control is stored. The data is deleted when the power turns OFF.

Point

To hold the change, write file by MCv_WriteProfileData (Profile Write) (file specification). Because the change is deleted when the power turns OFF, even if the data is changed in open area by MCv_WriteProfileData (Profile Write) (open area specification) during operation.

■Details of profile data type/profile ID type

The profile data type structure and the profile ID type structure include "general-purpose type" which does not limit functions and "function specific type" which is used for the specific functions (FB). "Function specific type" includes "general-purpose type" in the member. Create instances of variable corresponding to the FB argument type to use.

Type name	General-purpose type	Function specific type	Remark
Profile data type	PROFILE_DATA	<ul style="list-style-type: none"> MC_CAM_REF MC_POSITIONING_DATA_REF 	Indicates the operation profile with the following configurations. <ul style="list-style-type: none"> Operation profile storage location (Location) Profile ID (ID)
Profile ID type	PROFILE_ID	<ul style="list-style-type: none"> MC_CAM_ID MC_POSITIONING_DATA_ID 	Data type to specify the operation profile to use in the operation profile control FB (MC_CamIn (Cam Operation Start), etc.). A unique identifiable No. is given by the operation profile expand FB (MC_CamTableSelect (Cam Table Selection) , etc.). <ul style="list-style-type: none"> Profile ID No. (Number)

The table shows data type and open FBs that can be used to each function.

Function	Profile data type	Profile ID type	Open FB
Cam Operation Start (MC_CamIn)	MC_CAM_REF	MC_CAM_ID	MC_CamTableSelect (Cam Table Selection)
Advanced synchronous control (MCv_AdvancedSync)			
Advanced synchronous control current position per cycle calculation (MCv_AdvPositionPerCycleCalc)			
Advanced synchronous control cam set position calculation (MCv_AdvCamSetPositionCalc)			
Multiple axes positioning data operation (MCv_MovePositioningData)	MC_POSITIONING_DATA_REF	MC_POSITIONING_DATA_ID	—

■Operation profile operation in the engineering tool

When operating from the engineering tool, set operation profile file reads/writes to files. Operation profile file cannot read/write to the open area.

■Capacity of operation profile

Data size that created operation profile file uses is as shown below.

Operation method	Operation profile format	Open area
Create with the engineering tool/ Create with operation profile manipulation function	Cam data	■When Interpolation Method Specification (Interpolate) is "0: Linear Interpolation" Management information (1k bytes) + Coordinate number $\times 8 \times 2$ (byte) ■When Interpolation Method Specification (Interpolate) is "1: Section Interpolation" or "2: Spline Interpolation" Management information (1k bytes) + Resolution $\times 8$ (byte)
	Rotary cutter	Management information (1k bytes) + Resolution $\times 8$ (byte)
	Multiple axes positioning data	Management information (1k bytes) + 3200 (byte) + Total number of positioning data $\times 176$ (byte)

In operation profile open processing, temporarily twice the data size memory of open area will be used for cam data (Interpolation Method Specification (Interpolate) is "1: Section Interpolation" and "2: Spline Interpolation") and rotary cutter, and the same data size memory of open area will be used for other than the above.

Operation profile expansion

This section describes auto expand and expand.

Operation profile created by "File" should be expanded to "Open area" because operation profile of "Open area" is used for operation profile control.

The method to expand to "Open area" has the following two types.

- Auto expand
- Operation profile expand FB execution

■Auto expand of operation profile

Create on the engineering tool and the operation profile set to auto expand is expanded automatically at power ON so that it can be used for operation profile control without executing operation profile expand FB.

The operation profile satisfying the following all conditions can be used for its control without executing operation profile expand FB because it is also expanded automatically at power ON.

- Other than "0" is specified to the initial value of Profile ID No. (PROFILE_DATA.ID.Number).
- The operation profile is stored in %PROJECT_ROOT%/calc_profile/auto_open, or %PROJECT_ROOT_DRIVE%/calc_profile/auto_open.
- No error such as out of the setting range in the data to be expanded.

The operation profile for automatic expansion will be searched for in both "%PROJECT_ROOT%/calc_profile/auto_open" and "%PROJECT_ROOT_DRIVE%/calc_profile/auto_open".

When both paths contain an operation profile with the same ID, the operation profile stored in "%PROJECT_ROOT_DRIVE%/calc_profile/auto_open" is prioritized.

The status does not become RUN until all the operation profiles are automatically expanded. If there are many operation profiles, it may take time to reach the RUN status.

Point

- When setting auto expand, Profile ID (PROFILE_DATA.ID.Number), Periodic (Periodic), Master axis absolute coordinate (MasterAbsolute), and Slave axis absolute coordinate (SlaveAbsolute) open the same parameters in the csv file which can be specified in operation profile expand FB.
- When there is an operation profile which does not meet the requirement above during auto expand, Details of the error are registered in the event history without expanding automatically the profile data. In this case, the operation continues until automatically expanding the remaining operation profile, without ending because of error.

■Expand operation profile

Expands "File" specified in Operation Profile Storage Location (PROFILE_DATA.Location) to "Open area" by using MC_CamTableSelect (Cam Table Selection).

- Expanded data to "Open area" is assigned profile IDs expressed in the profile ID type.
- An operation profile expand FB that can be executed differs depending on the defined profile data type. For details, refer to the following.

 Page 504 Operation profile types

- When an operation profile expand FB that does not support the profile data type is executed, "Operation Profile Data Incorrect" (error code: 3410H) occurs.
- When an error has occurred while expanding the operation profile, "Open area" in processing is discarded.

- Expansion process of the operation profile is carried out with motion service processing. It may take time to open depending on the processing details and the operation profile.
- When PROFILE_DATA.ID.Number (ProfileID), Periodic (Periodic), Master axis absolute coordinate (MasterAbsolute), and Slave axis absolute coordinate (SlaveAbsolute) are present as input arguments for the operation profile expand FB, the value set in "File" is ignored and the expansion is performed while referencing the input argument settings.
(The setting value of "File" is not overwritten.)

Precautions

When rewriting "Open area" during control, the stroke value changes rapidly, and shock may be applied to the machine depending on the waveform pattern. Create operation profile so that the waveform before and after change does not become discontinuous.

Read/write operation profile

Operates data read/write of operation profile.

Operates data read/write of file an operation profile in open area by using MCv_ReadProfileData (Profile Read)/MCv_WriteProfileData (Profile Write) according to data structure for read/write.

Operation profile format to which the data structure for read/write is defined can operates read/write operation. For details on the data structure for read/write of each operation profile format, refer to the following.

 Page 504 Operation profile types

When an error has occurred while writing operation profile, the open area and the file in processing is discarded.

The number of data points that can be read/written at the same time are limited. If read/write is not completed in one time FB execution, carry out it in several times.

■Read operation profile

Operation profile can be read by using the MCv_ReadProfileData (Profile Read).

- The file specified in Profile data (ProfileData) and Read destination (Target), or the operation profile in open area are read for the number of points specified in Number of read data (Points) from data specified with Offset (Offset).
- To read the whole operation profile, specify "0" in both Offset (Offset) and Number of read data (Points).
- Read data is stored in variables specified in Read data 1 (Data1) and Write data 1 (Data 1).

■Write operation profile

Executes write operation of operation profile.

Operation profile can be written by using the MCv_WriteProfileData (Profile Write).

- The file specified in Profile data (ProfileData) and Write destination (Target), or the operation profile in open area are written for the number of points specified in Write destination (Points) from data specified with Offset (Offset).
- To write the whole operation profile, specify "0" in both Offset (Offset) and Write destination (Points).
- Read data is stored in variables specified in Read data 1 (Data1) and Write data 1 (Data 1).

Precautions

When the operation profile is written in the open area or file area using MCv_WriteProfileData (Profile Write) with the add-on ProfileControl version being "1.9" or earlier, the setting values of Periodic (Periodic), Master axis absolute coordinate (MasterAbsolute) and Slave axis absolute coordinate (SlaveAbsolute) will become FALSE.

When changing setting values, follow the procedures below.

1. Write the operation profile to the file area.
2. Specify the file written in step 1 in MC_CamTableSelect (Cam Table Selection), and set Periodic (Periodic), Master axis absolute coordinate (MasterAbsolute), and Slave axis absolute coordinate (SlaveAbsolute).

Control of operation profile

Operation profile is used to control of each function.

Control details

The input data of operation profile control FB is the PROFILE_ID type and the control is executed based on the specified operation profile. Before executing operation profile control, open the operation profile corresponding to each operation profile control FB in the open area to enable this control.

For the operation profile expand FB corresponding to each operation profile, refer to the following.

Operation profile format	Operation profile expand FB	Detail
Cam data	<ul style="list-style-type: none"> MC_CamIn (Cam Operation Start) MCv_AdvancedSync (Advanced Synchronous Control) MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation) MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation) 	For details, refer to the following. IMELSEC iQ-R Programming Manual (Motion Control Function Blocks)
Rotary cutter		
Multiple axes positioning data		
	Multiple Axes Positioning Data Operation (MCv_MovePositioningData)	

Start mode

The following table shows the operation when simultaneously executing various FBs (open, write, read, control) that access to open areas of operation profile to the same profile ID.

Execution mode (ExecutionMode)

For the operation profile expand FB and the operation profile write FB, the operation for simultaneous execution can be specified with Execution mode (ExecutionMode).



When no FB is in execution, the FB is executed immediately regardless of specification of Execution mode (ExecutionMode).

While the FB (open, write, read, control) that accesses open areas is in execution, Executing (Busy) of various FBs are TRUE. To give priority to the FB execution order based on the execution time of the FB (open, write, read), use this signal to the interlock.

○: Execution possible, ×: Error

On-going FB	FB to be executed			
	Open/Write			Read/Control
	0: Execute Immediately (mcImmediately)	1: Execute at Completion of Previous One (mcQueued)	3: Execute Speculatively (mcSpeculatively)	
Open/Write	○	○	×	×
Read/Control	○	○	×	○

■0: Execute Immediately (mcImmediately)

The description in the open area is immediately changed by an open FB and a write FB. The change may affect the control in execution.

However, when executing open/write during FB execution (open, write, read, control), "Operation Profile Data Being Operated" (error code: 3411H) will occur in the following cases.

- The format of the operation profile for executing open/write does not match the operation profile format of the open area.
- The capacity of the operation profile for executing open/write does not match the capacity of the open area^{*1}.

^{*1} For the capacity of the open area, refer to the following.

 Page 534 Capacity of operation profile

■1: Execute at Completion of Previous One (mcQueued)

Waits execution completion of on-going FB. When multiple FBs are waiting, the FBs will be executed in high priority task. For the same priority, the FBs will be executed in the order of the start.

The status of execution completion of each FB is shown below.

FB	Status
MC_CamTableSelect (Cam Table Selection)	Execution completion (Done) = TRUE
MCv_ReadProfileData (Profile Read)	Execution completion (Done) = TRUE
MCv_WriteProfileData (Profile Write)	Execution completion (Done) = TRUE
MC_CamIn (Cam Operation Start)	Periodic (MC_CamTableSelect.Periodic) = TRUE : Abortion of execution (MC_CamIn.CommandAborted) = TRUE Periodic (MC_CamTableSelect.Periodic) = FALSE : Abortion of execution (MC_CamIn.CommandAborted) = TRUE, Cam cycle completion (MC_CamIn.EndOfProfile) = TRUE
MCv_AdvancedSync (Advanced Synchronous Control)	Executing (Busy) = FALSE
MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation)	Executing (Busy) = FALSE
MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation)	Executing (Busy) = FALSE
MCv_MovePositioningData (Multiple Axes Positioning Data Operation)	Executing (Busy) = FALSE, and the Profile No. being executed (CurrentProfileNo) of MCv_MovePositioningData (Multiple Axes Positioning Data Operation) = 0

■3: Execute Speculatively (mcSpeculatively)

"Operation Profile Data Being Operated" (error code: 3411H) occurs, and the open area is not changed.

Sub function of operation profile

Current value per cycle change function

Change the current value per cycle of an operation profile control FB to an arbitrary value.

- Sets Instance ID (MC_CamIn.InstanceID) of corresponding to the operation profile control FB (hereinafter called to as MC_CamIn) to Instance ID (InstanceID) of MCv_ChangeCycle (Current Value Change per Cycle).
- Public variables of MC_CamIn are shown below when current value per cycle change is performed.

Public variable	Updating value	Remark
Current value per cycle (InputsPerCycle)	Value specified in Current value per cycle (Cycle[])	—
Reference value (Reference)	Stroke value equivalent to Current value per cycle (Cycle[])	Reference value (<u>MC_CamIn</u> .Reference) is refreshed to fix Output value (<u>MC_CamIn</u> .OutputData).
Output value (OutputData)	Not updated	—

Point

Even if Slave axis absolute coordinate (MC_CamTableSelect.SlaveAbsolute) is TRUE (absolute coordinate), Reference value (Reference) is refreshed to fix Output value (OutputData) if current value per cycle change is performed.

14

- The method for current value per cycle change is as follows.

Method	Description
MCv_ChangeCycle (Current Value Change per Cycle)	Change it to the specified value at control execution.

- For specification of the current value per cycle to be changed, "absolute specification" or "relative specification" can be selected by Relative position selection (Relative).
- The current value per cycle of the following operation profile control FB can be changed. When the current value per cycle of other operation profile control FBs are changed "Current Value per Cycle Change Unsupported" (error code: 3467H) occurs.
 - MC_CamIn (Cam Operation Start)

■Current value per cycle change

Uses Current value per cycle (MCv_ChangeCycle).

Changes the current value per cycle of the specified operation profile control FB.


Executes current value per cycle change at rising edge detection of Execute command (Execute).

- For "0: Execute Immediately (mclmmediately)"

Executed immediately at rising edge detection of Execute command (Execute) with Executing (MC_CamIn.Busy) = TRUE.

Ex.


Sets Current value per cycle (Cycle) = 100.0 when Executing (MC_CamIn.Busy) = TRUE, and when executing current value per cycle change. (Current value of Master axis (Master) of MC_CamIn (Operation Available) shall not change.)



*1 This is axis state of Slave axis (Slave).

*2 Does not change because the master axis does not move.

- Current value per cycle change timing by each value



*1 "MCv_ChangeCycle Instruction Error" (error code: 3497H (detail code: 000AH)) occurs.

*2 "MCv_ChangeCycle Instruction Error" (error code: 3497H (detail code: 0002H)) occurs.

Status of FB of current value per cycle change target		Condition of state transition (Status change of the slave axis)		Operation of current value per cycle change
		Before transition	After transition	
Status 1	FB is not started	—(Initial status)	4: Standby (Standstill)	Current value per cycle change cannot be executed regardless of Execution mode (ExecutionMode). "MCv_ChangeCycle Instruction Error" (error code: 3497H (detail code: 000AH)) occurs.
Status 2	FB is starting	4: Standby (Standstill)	7: During synchronous operation (SynchronizedMotion)	Depending on Execution mode (ExecutionMode), the timing is as follows ■0: Execute Immediately (mclImmediately) Current value per cycle change can be executed. The execution cycle of target FB is reflected. ■1: Execute at Completion of Previous One (mcQueued) "MCv_ChangeCycle Instruction Error" (error code: 3497H (detail code: 0002H)) occurs. ■3: Execute Speculatively (mcSpeculatively) "MCv_ChangeCycle Instruction Error" (error code: 3497H (detail code: 0002H)) occurs.
Status 3	FB after the control completed	7: During synchronous operation (SynchronizedMotion)	4: Standby (Standstill)	Current value per cycle change cannot be executed regardless of Execution mode (ExecutionMode). "MCv_ChangeCycle Instruction Error" (error code: 3497H (detail code: 000AH)) occurs.
Status 4	FB after restarting	4: Standby (Standstill)	7: During synchronous operation (SynchronizedMotion)	The operation is the same as Status 2. Repeats after that as Status 4 (Status 2) → Status 3 → ... Current value per cycle change operation is not affected even Execute command (Execute) has TRUE/FALSE differences in Status 2 and Status 4.

Precautions

Relevant add-ons

The following add-ons are required to use this function.

- ProfileControl
- PackagingApp (when using the rotary cutter)

System memory capacity

■RAM usage

Refer to the following.

 Page 534 Capacity of operation profile

■Backup RAM usage

Backup RAM is not used.

14.2 Operation Profile Format

This section describes csv file format of operation profile.

Point

- "/" comment lines are not counted among line Nos.
- 8 byte specification data is imported as the double-precision real number type.

Operation profile details

The basic configuration of profile data is as the following table.

Line No.	Description
1	Common header
2	Open information
3	Operation profile format
4	Resolution/coordinate number
5	Start point, initial stroke amount, options
6	Number of sections
7 or later	Defined for each operation profile format
N-2*1	Length per cycle
N-1*1	Stroke amount
N*1	Common footer (EOF)
N+1*1	Common footer (CRC)

*1 "N" is calculated as shown below by the operation profile format and Interpolation method specification (Interpolate).

Operation profile format	Interpolation method specification (Interpolate)	N
Cam data format	0: Linear interpolation	7 (start row of previous step) + (coordinate number × 2) + 2 (length per cycle, stroke amount)
	1: Section interpolation	7 (start row of previous step) + Number of sections + 2 (length per cycle, stroke amount)
	2: Spline interpolation	
Multiple axes positioning data format	—	7 (start row of previous step) + 1 (row: total number of positioning data) + 1 (row: condition signal) + 1 (row: skip signal) + Number of sections + 2 (length per cycle, stroke amount)

Common items

The common items as operation profile are shown below.

○: Omission possible, ×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
1	1	Header tag	×	[HEADER]	Character string	Fixed character string.	0x0103
	2	File version	×	0x0103	Unsigned integer	Fixed value.	0x0103
	3	For manufacturer 1	×	Arbitrary	Unsigned integer	Sets "0" when creating a csv file externally.	0x0103
	4	For manufacturer 2	×	Arbitrary	Character string		0x0103
	5	For manufacturer 3	×	Arbitrary	Unsigned integer		0x0103
	6	For manufacturer 4	×	Arbitrary	Unsigned integer		0x0103
	7	For manufacturer 5	×	Arbitrary	Unsigned integer		0x0103
2	1	Profile ID	×	 Page 502 Operation Profile • Initial value: 0 (= automatic apply)	Unsigned integer	Specifies Profile ID. (Use only when carrying out automatic open when the power turns ON.)	0x0103
	2	Periodic	○	 Page 502 Operation Profile	Integer	Specifies periodic.	0x0103
	3	Input absolute coordinate	○	 Page 502 Operation Profile	Integer	Specifies input absolute coordinate.	0x0103
	4	Output absolute coordinate	○	 Page 502 Operation Profile	Integer	Specifies output absolute coordinate.	0x0103
3	1	Operation profile format	×	99: Cam data format 123: Cam data format for rotary cutter (double precision specification) 1000: Multiple axes positioning data format	Integer	Specifies operation profile format.	0x0103
	2	Profile data type	○	0: General profile data 1: Cam data 6: Digital output data 200: Multiple axes positioning data • Initial value: 0	Integer	Specifies the profile data type.  Page 502 Operation Profile	0x0103
	3	Interpolation method specification	○	0: Linear Interpolation 1: Section Interpolation 2: Spline Interpolation • Initial value: 0	Integer	Specifies the interpolation method between data.	0x0103
4	1	Resolution/coordinate number	×	 Page 502 Operation Profile • Initial value: 0	Unsigned integer	Sets the resolution or the number of coordinates.	0x0103

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
5	1	Start point	○	*1 99: Valid for the cam data format (section interpolation, spline interpolation) • Initial value: 0	Real number	Specifies the start point.	0x0103
	2	Initial stroke amount	○	*1 99: Valid for the cam data format (section interpolation, spline interpolation) • Initial value: 0	Real number	Specifies the initial stroke amount.	0x0103
	3	Initial velocity	○	*1 99: Valid for the cam data format (section interpolation) • Initial value: 0	Real number	Specifies the initial velocity	0x0103
	4	Initial acceleration	○	*1 99: Valid for the cam data format (section interpolation) • Initial value: 0	Real number	Specifies the initial acceleration	0x0103
	5	Options	○	*2 • Initial value: 0	Unsigned integer	Defines for each operation profile format.	0x0103
6	1	Number of sections	×	*2 • Initial value: 0	Unsigned integer	Specifies the number of sections for the data format that requires it. Specify "0" for the data format that does not require it.	0x0103

*1 Differs depending on the data format.

*2 Depends on the operation profile format.

■(N-2)th line: Length per cycle

○: Omission possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
N-2	1	Length per cycle	○	0 or more*1	Real number	Specifies the length per cycle. Specify "0" for the data format that does not require it.	0x0103
	2	Unit setting	○	F: An arbitrary unit • Initial value: 0x0F *: For settable units, refer to the following. ☞ Page 75 Technical Units	Unsigned integer	Specifies the unit of the length per cycle. Units that can be specified differ depending on the profile data type. ☞ Page 502 Operation Profile	0x0103
	3	Unit character string	○	Up to 31 characters • Initial value: "" ☞ Page 75 Technical Units	Character string	Specifies an arbitrary character string when "an arbitrary unit" is set to the unit setting.	0x0103
	4	Minimum value per cycle	○	*2	Real number	Specifies the minimum value of length per cycle. Specify "0" for the data format that does not require it.	0x0103
	5	Maximum value per cycle	○	*2	Real number	Specifies the maximum value of length per cycle. Specify "0" for the data format that does not require it.	0x0103
	6	Time per cycle	○	0 or more*1	Real number	Specifies the time per cycle. Specify "0" for the data format that does not require it.	0x0103

*1 The maximum value differs depending on the data format.

*2 Differs depending on the data format.

■(N-1)th line: Stroke amount (Stroke)

○: Omission possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
N-1	1	Stroke amount	○	*1	Real number	Specifies the stroke amount. Specify "0" for the data format that does not require it.	0x0103
	2	Unit setting	○	F: An arbitrary unit • Initial value: 0x0F *: For settable units, refer to the following. ☞ Page 75 Technical Units	Unsigned integer	Specifies the unit of stroke amount. Units that can be specified differ depending on the profile data type. ☞ Page 502 Operation Profile	0x0103
	3	Unit character string	○	Up to 31 characters • Initial value: "" ☞ Page 75 Technical Units	Character string	Specifies an arbitrary character string when "an arbitrary unit" is set to the unit setting.	0x0103

*1 Differs depending on the data format.

■(N)th line: Common footer (EOF)

×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
N	1	Final line tag	×	EOF: 3 characters	Character string	Fixed character string.	0x0103

■(N+1)th line: Common footer (CRC)

○: Omission possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
N+1	1	File CRC	○	Arbitrary	Unsigned integer	Indicates the file CRC. Omit this line when creating a csv file externally.	0x0103

Cam data format (Interpolation method specification: "0: Linear Interpolation")

The following shows a case for specifying setting value below.

Line No.	Column No.	Item	Setting value
3	1	Operation profile format	99: Cam data format
	3	Interpolation Method Specification (Interpolate)	0: Linear Interpolation

■6th line: Number of sections

Specify "0".

■7th line or later: I/O data

×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
7	1	Input value (0th point)	×	 Page 81 Positioning Range	Real number	 Page 504 Cam data	0x0103
8	1	Output value (0th point)	×		Real number		0x0103
9	1	Input value (1st point)	×		Real number		0x0103
⋮							
For the number of coordinates × 2	1	Output value (nth point) (For the number of coordinates)	×	 Page 81 Positioning Range	Real number	 Page 504 Cam data	0x0103

Cam data format (Interpolation method specification: "1: Section Interpolation")

The following shows a case for specifying setting value below.

Line No.	Column No.	Item	Setting value
3	1	Operation profile format	99: Cam data format
	3	Interpolation Method Specification (Interpolate)	1: Section Interpolation

■6th line: Number of sections

Specify the number of sections.

■7th line or later: Parameter

○: Omission possible, ×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
7	1	Cam curve types	×	Sets the cam curve with a value. For settable curves, refer to the following. ☞ Page 504 Cam data	Integer	☞ Page 504 Cam data	0x0103
	2	End point	×	☞ Page 504 Cam data	Real number		0x0103
	3	Stroke	×		Real number		0x0103
	4	Curve applicable range (P1)	○		Real number		0x0103
	5	Curve applicable range (P2)	○		Real number		0x0103
	6	Acceleration/ deceleration range compensation (Range L1)	○		Real number		0x0103
	7	Acceleration/ deceleration range compensation (Range L2)	○		Real number		0x0103
	8	End point velocity	○		Real number		0x0103
	9	End point acceleration	○		Real number		0x0103
8	1-7	Same as line No.7					

⋮

(For the number of sections)

Cam data format (Interpolation method specification: "2: Spline Interpolation")

The following shows a case for specifying setting value below.

Line No.	Column No.	Item	Setting value
3	1	Operation profile format	99: Cam data format
	3	Interpolation Method Specification (Interpolate)	2: Spline Interpolation

■6th line: Number of sections

Specify the number of sections.

■7th line or later: Parameter

×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
7	1	End point	×	 Page 504 Cam data	Real number	 Page 504 Cam data	0x0103
	2	Stroke	×		Real number		0x0103
8	1-2	Same as line No.7					
⋮							
(For the number of sections)							

Cam data format for rotary cutter (double precision specification)

The following shows a case for specifying setting value below.

Line No.	Column No.	Item	Setting value
3	1	Operation profile format	123: Cam data format for rotary cutter (double precision specification)

■6th line: Number of sections

Specify "0".

■7th line: Parameter

×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
7	1	Auto-generation options	×	☞ Page 515 Rotary cutter	Unsigned integer	☞ Page 515 Rotary cutter	0x0103
	2	Synchronous section acceleration ratio	×		Real number		0x0103
	3	Sheet length	×		Real number	☞ Page 515 Rotary cutter *: The current value per cycle is ignored.	0x0103
	4	Sheet synchronization width	×		Real number		0x0103
	5	Synchronous axis length	×		Real number	☞ Page 515 Rotary cutter	0x0103
	6	Synchronous position adjustment	×		Real number		0x0103
	7	Acceleration/ deceleration width	×		Real number		0x0103
	8	Number of cutter	×		Unsigned integer		0x0103

Multiple axes positioning data format

The following shows a case for specifying setting value below.

Line No.	Column No.	Item	Setting value
3	1	Operation profile format	1000: Multiple axes positioning data format

■6th line: Number of sections

×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
6	1	Number of sections	×	0 to (total number of positioning data)	Unsigned integer	Specifies the number of positioning data settings.  Page 523 Multiple axes positioning data	0x0103

■7th line: Parameter

×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
7	1	Total number of positioning data	×	1 to 5000	Unsigned integer	 Page 523 Multiple axes positioning data	0x0103

■8th line: Condition signal

○: Omission possible

Line No.	Column No.	Item		Omission	Setting range (Initial value)	Setting format	Description	Supported file version	
8 ^{*1}	1	Condition signal 1 (Condition Signal1)	I/O Number (StartIO)	○ ^{*2}	— ^{*3}	Unsigned integer	 Page 523 Multiple axes positioning data	0x0103	
	2		Target (Target)	○ ^{*2}	— ^{*3} Up to 63 characters	Character string		0x0103	
	3		Signal Detection Method (Detection)	○ ^{*2}	— ^{*3}	Integer		0x0103	
	4		Compensation Time (CompensationTime)	○ ^{*2}	— ^{*3}	Real number		0x0103	
	5		Filter Time (FilterTime)	○ ^{*2}	— ^{*3}	Real number		0x0103	
	6	Condition signal 2 (Condition Signal2)	Same as Column No.1 to No.5						
	⋮								
	10								
	11	Condition signal 3 (Condition Signal3)	Same as Column No.1 to No.5						
	⋮								
	15								
	16	Condition signal 4 (Condition Signal4)	Same as Column No.1 to No.5						
	⋮								
	20								
	21	Condition signal 5 (Condition Signal5)	Same as Column No.1 to No.5						
	⋮								
	25								
	26	Condition signal 6 (Condition Signal6)	Same as Column No.1 to No.5						
	⋮								
	30								
	31	Condition signal 7 (Condition Signal7)	Same as Column No.1 to No.5						
	⋮								
	35								
	36	Condition signal 8 (Condition Signal8)	Same as Column No.1 to No.5						
	⋮								
	40								
	41	Condition signal 9 (Condition Signal9)	Same as Column No.1 to No.5						
	⋮								
	45								
	46	Condition signal 10 (Condition Signal10)	Same as Column No.1 to No.5						
	⋮								
	50								

*1 If the setting of none of the columns is required, specify " " (a character string of length 0) to the line.

*2 This item cannot be omitted when setting the columns hereafter.
When the setting of the corresponding column itself is not required, specify " " (a character string of length 0).

*3 An arbitrary value can be set. Errors caused by setting values do not occur at operation profile opening.
However, there are setting ranges according to the operation profile control FB to be used. For details, refer to the following.
 Page 270 Condition signal setting

■9th line: Skip signal

○: Omission possible

Line No.	Column No.	Item		Omission	Setting range (Initial value)	Setting format	Description	Supported file version	
9 ^{*1}	1	Skip signal 1 (SkipSignal1)	I/O Number (StartIO)	○ ^{*2}	— ^{*3}	Unsigned integer	 Page 523 Multiple axes positioning data	0x0103	
	2		Target (Target)	○ ^{*2}	— ^{*3} Max. 63 characters	Character string		0x0103	
	3		Signal Detection Method (Detection)	○ ^{*2}	— ^{*3}	Integer		0x0103	
	4		Compensation Time (CompensationTime)	○ ^{*2}	— ^{*3}	Real number		0x0103	
	5		Filter Time (FilterTime)	○ ^{*2}	— ^{*3}	Real number		0x0103	
	6	Skip signal 2 (SkipSignal2)	Same as Column No.1 to No.5						
	⋮								
	10								
	11	Skip signal 3 (SkipSignal3)	Same as Column No.1 to No.5						
	⋮								
	15								
	16	Skip signal 4 (SkipSignal4)	Same as Column No.1 to No.5						
	⋮								
	20								
	21	Skip signal 5 (SkipSignal5)	Same as Column No.1 to No.5						
	⋮								
	25								
	26	Skip signal 6 (SkipSignal6)	Same as Column No.1 to No.5						
	⋮								
	30								
	31	Skip signal 7 (SkipSignal7)	Same as Column No.1 to No.5						
	⋮								
	35								
36	Skip signal 8 (SkipSignal8)	Same as Column No.1 to No.5							
⋮									
40									
41	Skip signal 9 (SkipSignal9)	Same as Column No.1 to No.5							
⋮									
45									
46	Skip signal 10 (SkipSignal10)	Same as Column No.1 to No.5							
⋮									
50									

*1 If the setting of none of the columns is required, specify " " (a character string of length 0) to the line.

*2 This item cannot be omitted when setting the columns hereafter.

When the setting of the corresponding column itself is not required, specify " " (a character string of length 0).

*3 An arbitrary value can be set. Errors caused by setting values do not occur at operation profile opening.

However, there are setting ranges according to the operation profile control FB to be used. For details, refer to the following.

Page 271 Skip signal setting

■10th line or later: Positioning data

○: Omission possible, ×: Omission not possible

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
10	1	Positioning data No. (DataNo)	×	1 to (Total number of positioning data)	Unsigned integer	 Page 523 Multiple axes positioning data	0x0103
	2	Operation pattern (OperationPattern)	○*1	—*2	Integer		0x0103
	3	Control method (ControlMethod)	×	—*2	Integer		0x0103
	4	Interpolation Axes 1 (InterpolationAxis1)	○*1	—*2	Integer		0x0103
	5	Interpolation Axes 2 (InterpolationAxis2)	○*1	—*2	Integer		0x0103
	6	Interpolation Axes 3 (InterpolationAxis3)	○*1	—*2	Integer		0x0103
	7	Interpolation Axes 4 (InterpolationAxis4)	○*1	—*2	Integer		0x0103
	8	Circular interpolation mode (CircMode)	○*1	—*2	Integer		0x0103
	9	Path selection (CircPathChoice)	○*1	—*2	Integer		0x0103
	10	Target position/ movement amount/ end point 1 (Position1)	○*1	—*2	Real number		0x0103
	11	Target position/ movement amount/ end point 2 (Position2)	○*1	—*2	Real number		0x0103
	12	Target position/ movement amount/ end point 3 (Position3)	○*1	—*2	Real number		0x0103
	13	Target position/ movement amount/ end point 4 (Position4)	○*1	—*2	Real number		0x0103
	14	Direction selection 1 (Direction1)	○*1	—*2	Integer		0x0103
	15	Direction selection 2 (Direction2)	○*1	—*2	Integer		0x0103
	16	Direction selection 3 (Direction3)	○*1	—*2	Integer		0x0103
	17	Direction selection 4 (Direction4)	○*1	—*2	Integer		0x0103
	18	Sub point 1 (CircAuxPoint1)	○*1	—*2	Real number		0x0103
	19	Sub point 2 (CircAuxPoint2)	○*1	—*2	Real number		0x0103
	20	Sub point 3 (CircAuxPoint3)	○*1	—*2	Real number		0x0103
	21	Sub point 4 (CircAuxPoint4)	○*1	—*2	Real number		0x0103
	22	Velocity mode (VelocityMode)	○*1	—*2	Integer		0x0103
	23	Velocity (Velocity)	○*1	—*2	Real number		0x0103
	24	Acceleration (Acceleration)	○*1	—*2	Real number		0x0103

Line No.	Column No.	Item	Omission	Setting range (Initial value)	Setting format	Description	Supported file version
10	25	Deceleration (Deceleration)	○*1	—*2	Real number	 Page 523 Multiple axes positioning data	0x0103
	26	Jerk (Jerk)	○*1	—*2	Real number		0x0103
	27	Circular interpolation error tolerance (CircErrorTolerance)	○*1	—*2	Real number		0x0103
	28	Positioning data options (DataOptions)	○*1	—*2	Unsigned integer		0x0103
	29	Dwell time (DwellTime)	○*1	—*2	Real number		0x0103
	30	M codes (Mcode)	○*1	—*2	Unsigned integer		0x0103
	31	M code output timing override (McodeOutput_Override)	○*1	—*2	Integer		0x0103
	32	JUMP destination positioning data No. (JumpDestinationDataNo)	○*1	—*2	Unsigned integer		0x0103
	33	Condition signal No. (ConditionSignalNo)	○*1	—*2	Unsigned integer		0x0103
	34	Number of LOOP to LEND repetitions (LoopCount)	○*1	—*2	Unsigned integer		0x0103
	35	Skip signal No. (SkipSignalNo)	○*1	—*2	Unsigned integer		0x0103
	36	Pitch (Pitch)	○*1	0	Unsigned integer	Not used. *: Omit or specify "0".	0x0103
11	1-36	Same as Line No. 10.					

:

(For the number of sections)

*1 This item cannot be omitted when setting the columns hereafter. When the setting of the corresponding column itself is not required, specify " " (a character string of length 0).

*2 An arbitrary value can be set. Errors caused by setting values do not occur at operation profile opening. However, there are setting ranges according to the operation profile control FB to be used. For details, refer to the following.

 Page 245 Setting positioning data

The following is an example of writing a csv file for setting positioning data.

Ex.

When executing 2 axes absolute value circular interpolation control

- Positioning data

Line No.	Column No.	Item	Setting value
10	1	Positioning data No. (DataNo)	1
	2	Operation pattern (OperationPattern)	1: Continuous positioning (ContinuousPositioning)
	3	Control method (ControlMethod)	0103h: Absolute value circular interpolation (CircularAbsolute)
	4	Interpolation axes 1 (InterpolationAxis1)	Configuration axis 2
	5	Interpolation axes 2 (InterpolationAxis2)	Configuration axis 3
	8	Circular interpolation mode (CircMode)	1: Center point specification (mcCenter)
	9	Path selection (CircPathChoice)	0: CW (mcCW)
	10	Target position/movement amount/end point 1 (Position1)	Configuration axis 2: 100.0
	11	Target position/movement amount/end point 2 (Position2)	Configuration axis 3: 100.0
	18	Sub point 1 (CircAuxPoint1)	Configuration axis 2: 50.0
	19	Sub point 2 (CircAuxPoint2)	Configuration axis 3: 50.0
	23	Velocity (Velocity)	10.0
	24	Acceleration (Acceleration)	1.0
	25	Deceleration (Deceleration)	1.0
	26	Jerk (Jerk)	2.0
	27	Circular interpolation error tolerance (CircErrorTolerance)	100.0
	28	Positioning data options (DataOptions)	0
	29	Dwell time (DwellTime)	100.0

- csv file (delimiters: comma (,))

Writing
1,1,0x0103,2,3,,,1,0,100.0,100.0,,,,,50.0,50.0,,,,10.0,1.0,1.0,2.0,100.0,0,100.0

Ex.

When making data No. 10 NOP

- csv file (delimiters: comma (,))

Writing
10,,0x0080

Notation for different setting formats

The following shows the notation for different setting formats.

Type		Notation	Example
Integer	Decimal	Directly enter a signed or unsigned decimal number.	123 +123 -123
	Hexadecimal	Add "0x" or "0X" before a hexadecimal number.	0xFF 0XEAD
Real number	Decimal notation	Directly enter a signed or unsigned real number with a decimal.	2.34 +2.34 -2.34
	Exponential notation	Add "e" or "E", and a signed or unsigned exponent (decimal) at the end of the real number.	1.0e6 1.0E-6
Character string		Directly enter a character string.	ABC

15 ADVANCED SYNCHRONOUS CONTROL


15.1 Overview of Advanced Synchronous Control

Advanced synchronous control can be achieved using software instead of controlling mechanically with gears, clutches, speed change gears or cams etc.

Advanced synchronous control synchronizes control with the input axis by setting parameters for advanced synchronous control and starting MCv_AdvancedSync (Advanced Synchronous Control) on each output axis.

Set the input axes for advanced synchronous control and the filter settings using the input axis parameters.

Set the output axis for advanced synchronous control using the output axis parameters. The setting of the auxiliary axes and sub input axes, as well as the settings for gears, clutches, speed change gears, and cams are included under the output axis parameters.



*1 For details of input axes, refer to the following.

☞ Page 576 Input Axis Function

*2 For details of output axes, refer to the following.

☞ Page 585 Output Axis Function

*3 For details of cams, refer to the following.

☞ Page 628 Output axis module

Relevant variables

Input axis (AdvInputName.)

Variable name	Name	Reference
LabelID	Axis label ID	📖 Page 578 Input axis (AdvInputName.)
Axis	Axis information	
PrConst.	Input axis parameter constant	📖 Page 556 Input axis parameters constant (AdvInputName.PrConst.)
Pr.	Input axis parameter	📖 Page 556 Input axis parameters (AdvInputName.Pr.)
Md.	Input axis monitor data	📖 Page 556 Input axis monitor data (AdvInputName.Md.)

■ Input axis parameters constant (AdvInputName.PrConst.)

Variable name	Name	Reference
SourceValue	Data source selection	📖 Page 579 Input axis parameter constant (AdvInputName.PrConst.)
SmoothingTimeConstant	Smoothing time constant	
PhaseCompensationTimeConstant	Phase compensation time constant	
DirectionRestriction	Moving direction restriction	

■ Input axis parameters (AdvInputName.Pr.)

Variable name	Name	Reference
PhaseCompAdvanceTime	Phase compensation advance time	📖 Page 581 Input axis parameter (AdvInputName.Pr.)

■ Input axis monitor data (AdvInputName.Md.)

Variable name	Name	Reference
ActiveStatus	Active status	📖 Page 582 Input axis monitor data (AdvInputName.Md.)
CumulativePosition	Cumulative current position	
SetVelocity	Set velocity	
PhaseCompensationAmount	Phase Compensation Amount	
DirectionRestrictionAmount	Moving direction restriction amount	

Output axis (AdvOutputName.)

Variable name	Name	Reference
LabelID	Axis label ID	📖 Page 586 Output axis (AdvOutputName.)
Axis	Axis information	
PrConst.	Output axis parameter constant	📖 Page 557 Output axis parameters constant (AdvOutPutName.PrConst.)
Pr.	Output axis parameter	📖 Page 557 Output axis parameters (AdvOutPutName.Pr.)
Md.	Output axis monitor data	📖 Page 559 Output axis monitor data (AdvOutPutName.Md.)
Cd.	Output axis control data	📖 Page 560 Output axis control data (AdvOutPutName.Cd.)

■Output axis parameters constant (AdvOutPutName.PrConst.)

Variable name	Name	Reference
SmoothingTimeConstant	Output axis smoothing time constant	☞ Page 587 Output axis parameters constant (AdvOutPutName.PrConst.)
MasterClutchSmoothingTimeConstant	Main shaft clutch smoothing time constant	☞ Page 591 Output axis parameter constant (AdvOutPutName.PrConst.)
AuxClutchSmoothingTimeConstant	Auxiliary shaft clutch smoothing time constant	☞ Page 602 Output axis parameters constant (AdvOutPutName.PrConst.)
MasterSpeedChangeGearSmoothingTimeConstant	Main shaft speed change gear smoothing time constant	☞ Page 626 Output axis parameters constant (AdvOutPutName.PrConst.)
AuxSpeedChangeGearSmoothingTimeConstant	Auxiliary shaft speed change gear smoothing time constant	
OutSpeedChangeGearSmoothingTimeConstant	Output axis speed change gear smoothing time constant	

■Output axis parameters (AdvOutPutName.Pr.)

Variable name	Name	Reference
SubAxis	Sub input axis object	☞ Page 587 Output axis parameter (AdvOutPutName.Pr.)
AuxAxis	Auxiliary shaft object	
MasterOnClutchSignal	Main shaft clutch ON signal setting	☞ Page 591 Output axis parameters (AdvOutPutName.Pr.)
MasterOffClutchSignal	Main shaft clutch OFF signal setting	
AuxOnClutchSignal	Auxiliary shaft clutch ON signal setting	☞ Page 602 Output axis parameters (AdvOutPutName.Pr.)
AuxOffClutchSignal	Auxiliary shaft clutch OFF signal setting	
Gear.	Gear parameter	*1
Clutch.	Clutch parameter	*2
SpeedChangeGear.	Speed change gear parameter	*3
Cam.	Cam parameter	*4
Restore.	Synchronous control initial position parameter	*5

*1 Gear parameter (AdvOutPutName.Pr.Gear.)

Variable name	Name	Reference
MasterCompositeGear	Composite main shaft gear	☞ Page 590 Gear parameter of output axis parameters (AdvOutPutName.Pr.Gear.)
MasterNumerator	Main shaft gear: Numerator	
MasterDenominator	Main shaft gear: Denominator	
AuxCompositeGear	Composite auxiliary shaft gear	☞ Page 601 Gear parameter of output axis parameters (AdvOutPutName.Pr.Gear.)
AuxNumerator	Auxiliary shaft gear: Numerator	
AuxDenominator	Auxiliary shaft gear: Denominator	

*2 Clutch parameter (AdvOutPutName.Pr.Clutch.)

Variable name	Name	Reference
MasterOnControl	Main shaft clutch ON control setting	☞ Page 593 Clutch parameter of output axis parameters (AdvOutputName.Pr.Clutch.)
MasterOffControl	Main shaft clutch OFF control setting	
MasterReference	Main shaft clutch reference address setting	
MasterOnAddress	Main shaft clutch ON address	
MasterMovementAmountBeforeOn	Movement amount before main shaft clutch ON	
MasterOffAddress	Main shaft clutch OFF address	
MasterMovementAmountBeforeOff	Movement amount before main shaft clutch OFF	
MasterSmoothingMethod	Main shaft clutch smoothing method	
MasterOnSlippageAmount	Slippage amount at main shaft clutch ON	
MasterOffSlippageAmount	Slippage amount at main shaft clutch OFF	
AuxOnControl	Auxiliary shaft clutch ON control setting	☞ Page 604 Clutch parameter of output axis parameters (AdvOutputName.Pr.Clutch.)
AuxOffControl	Auxiliary shaft clutch OFF control setting	
AuxReference	Auxiliary shaft clutch reference address setting	
AuxOnAddress	Auxiliary shaft clutch ON address	
AuxMovementAmountBeforeOn	Movement amount before auxiliary shaft clutch ON	
AuxOffAddress	Auxiliary shaft clutch OFF address	
AuxMovementAmountBeforeOff	Movement amount before auxiliary shaft clutch OFF	
AuxSmoothingMethod	Auxiliary shaft clutch smoothing method	
AuxOnSlippageAmount	Slippage amount at auxiliary shaft clutch ON	
AuxOffSlippageAmount	Slippage amount at auxiliary shaft clutch OFF	

*3 Speed change gear parameter (AdvOutPutName.Pr.SpeedChangeGear.)

Variable name	Name	Reference
MasterGearIn	Main shaft speed change gear valid setting	☞ Page 625 Speed change gear parameter of output axis parameters (AdvOutPutName.Pr.SpeedChangeGear.)
MasterRatioNumerator	Main shaft speed change ratio: Numerator	
MasterRatioDenominator	Main shaft speed change ratio: Denominator	
AuxGearIn	Auxiliary shaft speed change gear valid setting	
AuxRatioNumerator	Auxiliary shaft speed change ratio: Numerator	
AuxRatioDenominator	Auxiliary shaft speed change ratio: Denominator	
OutGearIn	Output axis speed change gear valid setting	
OutRatioNumerator	Output axis speed change ratio: Numerator	
OutRatioDenominator	Output axis speed change ratio: Denominator	

*4 Cam parameter (AdvOutPutName.Pr.Cam.)

Variable name	Name	Reference
LengthPerCycle	Length per cycle	☞ Page 629 Cam parameter of output axis parameters (AdvOutputName.Pr.Cam.)
StrokeAmount	Cam stroke amount	
CamNo.	Cam No.	
StartingPoint	Cam starting point	
LengthPerCycleChange	Length per cycle change setting	
PhaseCompensationAdvancedTime	Phase compensation advance time	
PhaseCompensationTimeConstant	Phase compensation time constant	

*5 Synchronous control initial position parameter (AdvOutPutName.Pr.Restore.)

Variable name	Name	Reference
MasterGearPositionPerCycleMethod	Setting method of current position per cycle after main shaft gear	 Page 668 Synchronous control initial position parameter (<u>AdvOutPutName.Pr.Restore.</u>)
MasterGearInitialPositionPerCycle	Current position per cycle after main shaft gear (initial setting)	
AuxGearPositionPerCycleMethod	Setting method of current position per cycle after auxiliary shaft gear	
AuxGearInitialPositionPerCycle	Current position per cycle after auxiliary shaft gear (initial setting)	
PositionRestorationObject	Cam axis position restoration object	
ReferenceSetPositionMethod	Setting method of cam reference position	
PositionPerCycleMethod	Setting method of current position per cycle	
InitialReferenceSetPosition	Cam reference position (initial setting)	
InitialPositionPerCycle	Current position per cycle (initial setting)	
RestorationAllowablePosition	Cam set position restoration: Allowable movement amount setting	

■ **Output axis monitor data (AdvOutPutName.Md.)**

Variable name	Name	Reference
SyncStatus	Synchronization status	 Page 588 Output axis monitor (<u>AdvOutputName.Md.</u>)
MasterAxisNo	Main shaft	
SubAxisNo	Sub input axis	
AuxAxisNo	Auxiliary shaft	
Clutch.	Clutch monitor	*1
Cam.	Cam monitor	*2

*1 Clutch monitor (AdvOutputName.Md.Clutch.)

Variable name	Name	Reference
MasterOnOffStatus	Main shaft clutch ON/OFF status	 Page 597 Clutch monitor of output axis monitor data (<u>AdvOutputName.Md.Clutch.</u>)
MasterSmoothingStatus	Main shaft clutch smoothing status	
MasterCumulativeSlippage	Main shaft clutch slippage (accumulative)	
AuxOnOffStatus	Auxiliary shaft clutch ON/OFF status	 Page 609 Clutch monitor of output axis monitor data (<u>AdvOutputName.Md.Clutch.</u>)
AuxSmoothingStatus	Auxiliary shaft clutch smoothing status	
AuxCumulativeSlippage	Auxiliary shaft clutch slippage (accumulative)	

*2 Cam monitor (AdvOutputName.Md.Cam.)

Variable name	Name	Reference
MasterCompositeGearSetPosition	Current position after composite main shaft gear	 Page 633 Cam monitor of output axis monitor data (<u>AdvOutputName.Md.Cam.</u>)
MasterGearPositionPerCycle	Current position per cycle after main shaft gear	
AuxGearPositionPerCycle	Current position per cycle after auxiliary shaft gear	
PhaseCompensationAmount	Phase compensation amount	
PositionPerCycle	Current position per cycle	
ReferenceSetPosition	Cam reference position	
SetPosition	Cam set position	
CamNo	Execution profile No.	
StrokeAmount	Execution cam stroke amount	
LengthPerCycle	Execution length per cycle	
StartingPoint	Execution starting point	
SyncControlChangeStatus	Synchronous control change status	 Page 648 Cam monitor of output axis parameters (<u>AdvOutputName.Md.Cam.</u>)

■Output axis control data (AdvOutputName.Cd.)

Variable name	Name	Reference
Clutch.	Clutch control data	*1
SpeedChangeGear.	Speed change gear control data	*2
Cam.	Cam control data	*3

*1 Clutch control data (AdvOutputName.Cd.Clutch.)

Variable name	Name	Reference
MasterCommand	Main shaft clutch command	☞ Page 598 Clutch control data of output axis control data (<u>AdvOutputName.Cd.Clutch.</u>)
MasterInvalidCommand	Main shaft clutch control invalid command	
MasterForcedOff	Main shaft clutch forced OFF command	
MasterClutchSmoothingTimeConstant	Main shaft clutch smoothing time constant change value	
AuxCommand	Auxiliary shaft clutch command	☞ Page 610 Clutch control data of output axis monitor data (<u>AdvOutputName.Cd.Clutch.</u>)
AuxInvalidCommand	Auxiliary shaft clutch control invalid command	
AuxForcedOff	Auxiliary shaft clutch forced OFF command	
AuxClutchSmoothingTimeConstant	Auxiliary shaft clutch smoothing time constant change value	

*2 Speed change gear control data (AdvOutputName.Cd.SpeedChangeGear.)

Variable name	Name	Reference
MasterSmoothingTimeConstant	Main shaft speed change gear smoothing time constant change value	☞ Page 626 Speed change gear control data of output axis parameters (<u>AdvOutputName.Cd.SpeedChangeGear.</u>)
AuxSmoothingTimeConstant	Auxiliary shaft speed change gear smoothing time constant change value	
OutSmoothingTimeConstant	Output axis speed change gear smoothing time constant change value	

*3 Cam control data (AdvOutputName.Cd.Cam.)

Variable name	Name	Reference
OutSmoothingTimeConstant	Output axis smoothing time constant change value	☞ Page 635 Cam control data of output axis parameters (<u>AdvOutputName.Cd.Cam.</u>)
SyncControlChangeRequest	Synchronous control change request	☞ Page 649 Cam control data of output axis parameters (<u>AdvOutputName.Cd.Cam.</u>)
SyncControlChangeCommand	Synchronous control change command	
SyncControlChange	Synchronous control change value	
SyncControlReflectionTime	Synchronous control reflection time	

Relevant FBs


For details on Motion control FBs, refer to the following.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_AdvancedSync	Advanced Synchronous Control	Starts synchronization control according to the set advanced synchronous control setting.
MCv_AdvPositionPerCycleCalc	Advanced Synchronous Control Current Position per Cycle Calculation	Calculates Current Position per Cycle based on the set cam data.
MCv_AdvCamSetPositionCalc	Advanced Synchronous Control Cam Set Position Calculation	Calculates Cam Set Position based on the set cam data.

15.2 Control Details for Advanced Synchronous Control

This section describes the procedure for conducting advanced synchronous control.



Procedure for executing advanced synchronous control

This section describes the details of the procedure for conducting advanced synchronous control.

1. Generate the axes to be set as the input axis and output axis for advanced synchronous control.

In order to use advanced synchronous control, the axes to be set as the input axis and output axis must be generated.

Axes that can be set as an input axis and output axis are shown in the following table. For the specifications of each axis type, refer to the following.

☞ Page 30 Axis

☞ Page 57 Axis Assignment

○: Settable, ×: Not settable

Axis type		Input axis	Output axis	Remark
Real axis	Real drive axis	○	○	When control for multiple FBs is required, execute each FB with a virtual linked axis, and configure the axes to transmit the results (command) to the real drive axis.
	Real encoder axis	○	×	Use as Master axis (Master). When it is used as Slave axis (Slave), "Necessary Object Data Unset" (error code: 1AA8H) occurs and it does not start.
Virtual axis	Virtual drive axis	○	○	Commands can be generated mainly with positioning control.
	Virtual linked axis	○	○	Use as an intermediary axis to transmit a command to the real drive axis. When using multiple FBs, assign them to virtual linked axes.
	Virtual encoder axis	○	×	Use as Master axis (Master). When it is used as Slave axis (Slave), "Necessary Object Data Unset" (error code: 1AA8H) occurs and it does not start.

Generating the advanced synchronous control input axis and output axis will consume memory per each setting. Adjust the maximum RAM size (MotionControl_AdvancedSync_System.PrConst.RamSizeMax) supported to match the system structure. For memory usage, refer to the following.

☞ Page 575 System memory usage

Also, if the axes set as an input axis or output axis are using an absolute position system, backup RAM will be consumed. For backup RAM usage for each setting, refer to the following.

☞ Page 654 Backup data management for advanced synchronous control

2. Set the input axis parameters


The GX Works3 motion control setting function generates an input axis from "Input Setting" (1) under "Advanced Synchronous Control". When an input axis is generated, ADV_INPUT type labels are generated in global label "Adv+Global" (2).^{*1}

Set the axis to be used as an input axis in the Axis information (AdvInputName.Axis) of the input axis under input settings. It is not possible to set the same axis to the axis information of different axes. For details of settable axis types, refer to step 1. For details on input settings, refer to the following.

☞ Page 576 Input Axis Function

*1 ADV_INPUT type labels defined in local label cannot be used in advanced synchronous control.

☞ Navigation window ⇒ "Add-on Data" ⇒ "Advanced Synchronous Control" ⇒ "Input Setting"



3. Set the cam data

Set the cam data from the operation profile.

Set this when using a cam whose slave axis synchronizes it's position with the master axis according to the cam data and input settings.

Before using the cam function, the cam table must be transmitted to the open area and made controllable. For details on transmitting a cam table to the open area and data types that can be controlled by the cam operation, refer to the following.

☞ Page 628 Output axis module

☞ Page 636 Cam function

☞ Page 502 OPERATION PROFILE FUNCTION

Set the set operation profile to the output setting Cam No. (AdvOutputName.Pr.Cam.CamNo).

When using a Cam No. other than "0", it is required to install the add-on "ProfileControl" in advance.

If MCv_AdvancedSync (Advanced Synchronous Control), MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation), MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation) is started without "ProfileControl" installed, the following errors occur.

Motion control FB	Error code
MCv_AdvancedSync (Advanced Synchronous Control)	"Add-on Acquisition Failure" (error code: 1AF6H)
MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation)	"Add-on Acquisition Failure" (error code: 34ABH)
MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation)	

4. Set the output axis

The GX Works3 motion control setting function generates an output axis from "Output Setting" (3) under "Advanced Synchronous Control". When an output axis is generated, ADV_OUTPUT type labels are generated in global label "Adv+Global" (2).^{*1}

Set the axis to be used as an output axis in the Axis information (AdvOutputName.Axis) of the output axis under output settings. It is not possible to set the same axis to the axis information of different axes.

By setting the input axis set in step 1 to the Auxiliary shaft object (AdvOutputName.Pr.AuxAxis) and Sub input axis object (AdvOutputName.Pr.SubAxis), the auxiliary shaft and sub input axis inputs can be combined to the main shaft.

For details on output settings, refer to the following.

☞ Page 585 Output Axis Function


If parameters are not supported, the function name will be displayed in the setting image, but the parameters will not be displayed in the setting item.

For details on the supported version for each parameter, refer to the following.

☞ Page 575 Combining versions

*1 ADV_OUTPUT type labels defined in local label cannot be used in advanced synchronous control.

🗐 Navigation window ⇒ "Add-on Data" ⇒ "Advanced Synchronous Control" ⇒ "Output Setting"



5. Start synchronous control

Set the input axis and output axis set in steps 1. to 3. to the MCv_AdvancedSync (Advanced Synchronous Control) input/output variables.

- Input axis: Master axis (Master)
- Output axis: Slave axis (Slave)

If using analysis mode, set the following input variables.

- Synchronous control analysis mode setting (Options (Options): Bit 16)

Start synchronous control by starting MCv_AdvancedSync (Advanced Synchronous Control). For details on starting and confirmation during synchronization, refer to the following.

☞ Page 566 Starting/stopping for advanced synchronous control

6. Change the synchronous control monitor and control

Monitors such as the advanced synchronous control position per cycle can be confirmed in the Output axis monitor data (AdvOutputName.Md.).

The advanced synchronous control gear, clutch, speed change gear, and synchronous control change function can be used in the output axis control data (AdvOutputName.Cd) and the output axis parameters (AdvOutputName.Pr) of the output axis while MCv_AdvancedSync (Advanced Synchronous Control) is running.

For details on output axis functions, refer to the following.

 Page 585 Output Axis Function

7. Stop synchronous control

To stop the operation, use the following method.

- Change MCv_AdvancedSync (Advanced Synchronous Control) Enable (Enable) from TRUE to FALSE.
- Start MC_Stop (Forced Stop).

Advanced synchronous control can be ended even while the input axis is in operation. However, as the output axis loses synchronization while the input axis is stopped, it is recommended to stop the operation of the input axis before ending.

For details on stopping advanced synchronous control, refer to the following.

 Page 566 Starting/stopping for advanced synchronous control

Starting/stopping for advanced synchronous control

This section describes how to start and stop the operation for advanced synchronous control.


Operation when starting

To start advanced synchronous control, set MCv_AdvancedSync (Advanced Synchronous Control) Enable (Enable) to TRUE. Synchronous control can only be started when the slave axis Axis status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)".

Upon starting advanced synchronous control, the slave axis Axis status (AxisName.Md.AxisStatus) changes to "7: During synchronous operation (SynchronizedMotion)". When starting synchronous control, if the status is not "4: Standby (Standstill)", the slave axis Axis status (AxisName.Md.AxisStatus) will change to "1: Stopping on error (ErrorStop)" and "Start Not Possible" (error code: 1AADH) occurs.

The Input axis monitor data (AdvInputName.Md.□) will continuously update regardless of whether synchronous control has started.

The Output axis monitor data (AdvOutputName.Md.□) will update after the slave axis Axis status (AxisName.Md.AxisStatus) changes to "7: During synchronous operation (SynchronizedMotion)".



Stop operation

When MCv_AdvancedSync (Advanced Synchronous Control) Enable (Enable) is set to FALSE, or if a stop cause occurred in the axis set in axis information of the output axis, the Slave axis (Slave) immediately stops or decelerates to a stop according to the stop cause and stopping process.

Stop causes that occur during axis operation and the stopping process when each cause occurs are shown below.

Stop cause ^{*1}	Stopped axis	Axis status (<u>AxisName</u> .Md.AxisStatus)		Stopping process ^{*2}
		During deceleration stop	After stopping	
Enable (Enable) is set to FALSE during synchronous control by MCv_AdvancedSync (Advanced Synchronous Control)	Each axis	7: During synchronous operation (SynchronizedMotion)	4: Standby (Standstill)	Deceleration stop/Immediate stop (according to Stop Selection at Stop Cause Occurrence (<u>AxisName</u> .Pr.StopMode_General))

*1 For other stop causes, refer to the following.

☞ Page 168 Stop causes during axis operation

*2 For each operation of stopping processes, refer to the following.

☞ Page 170 Stop processes for single axis


After the stop cause occurs, the Input axis monitor data (AdvInputName.Md.□) update will not stop, but the Output axis monitor data (AdvOutputName.Md.□) will stop updating and will retain the values the moment when the stop cause occurred. The Output axis monitor data (AdvOutputName.Md.□) will update the next time MCv_AdvancedSync (Advanced Synchronous Control) is executed.

Time charts showing what happens when a stop cause occurs are shown below.

Point

To stop using the deceleration set in Deceleration (Deceleration) under MCv_AdvancedSync (Advanced Synchronous Control), set the Stop Selection at Stop Cause Occurrence (AxisName.Pr.StopMode_General) to "2: Keep Current Acceleration/Deceleration (KeepCurrentAcc)".


■When MCv_AdvancedSync (Advanced Synchronous Control) Enable (Enable) is set to FALSE during advanced synchronous control



*1 Slave axis (Slave) axis status.


*2 If Immediate stop is selected, only one scan will be TRUE.

■When a slave axis stop signal is detected during advanced synchronous control




*1 Slave axis (Slave) axis status.

■ When stop cause (MC_Stop (Forced Stop) execution/stop signal detection) occurs during advanced synchronous control



*1 Slave axis (Slave) axis status.

■ When a stop cause (Slave axis error, Forced stop) occurs during advanced synchronous control



*1 Slave axis (Slave) axis status.

Precaution

- During execution of MCv_AdvancedSync (Advanced Synchronous Control), if a stop case occurs in the axes set in the input axis information of the Master axis (Master), Auxiliary shaft object (AdvOutputName.Pr.AuxAxis), and Sub input axis object (AdvOutputName.Pr.SubAxis), the Slave axis (Slave) will continue control using commands transmitted from the input axis. The Slave axis (Slave) axis status will not change. Also, if a stop cause occurs in the axis is set in the output axis Axis information (AdvOutputName.Axis) it will not affect the axis is set in the input axis Axis information (AdvInputName.Axis).
- When linking multiple axes with MCv_AdvancedSync (Advanced Synchronous Control), do not set the Master axis (Master) to a Slave axis (Slave) of a single axis synchronization control FB afterwards. The operation when set to a function block afterwards cannot be guaranteed.
- When the Master axis (Master), Auxiliary shaft object (AdvOutputName.Pr.AuxAxis), and Sub input axis object (AdvOutputName.Pr.SubAxis) changes to servo OFF due to a servo alarm or a forced stop, stopping the operation of MCv_AdvancedSync (Advanced Synchronous Control) using MC_Stop (Forced Stop) is recommended because the Slave axis (Slave) may cause an unexpected operation.
- If an input axis is operated during the analyzing of MCv_AdvancedSync (Advanced Synchronous Control) startup (until the Slave axis (Slave) axis status (AxisName.Md.AxisStatus) becomes "7: During synchronous operation (SynchronizedMotion)"), the change amount based on current value change and the movement amount of the input axis during analyzing is reflected immediately after synchronous control starts. As the output axis may suddenly accelerate depending on the change amount and movement amount of the input axis, start the operation of the input axis after confirming synchronous control is in operation.
- If the member variable setting value of ADV_INPUT or ADV_OUTPUT that imported setting values during synchronous control are changed to a value out of range while MCv_AdvancedSync (Advanced Synchronous Control) is being executed, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs, and control will continue using the setting values before the change. If the member variable setting value of ADV_INPUT or ADV_OUTPUT is out of range when MCv_AdvancedSync is started, "Out of Parameter Range (Advanced Synchronous Control Input Axis)" (error code: 1D85H) or "Out of Parameter Range (Advanced Synchronous Control Output Axis)" (error code: 1D86H) occurs, and advanced synchronous control will not start.

Advanced synchronous control precautions

This section describes precautions when using advanced synchronous control.

When using public labels

When setting the parameters of input axes and output axes to public labels, set to the public label only the parameters that need to be changed using the CPU module side program.

Parameters set to the public labels will initially be "0" regardless of the values set using the engineering tool. Set these values using the CPU module side program before starting the advanced synchronous control FB.

Decimal points

- The decimal point range guaranteed for the input axis and output axis together is up to 5 decimal places. When setting the units, set the appropriate unit for the system to the Position command unit (AxisName.Pr.Unit_Position).
To accurately control values below the decimal point of "0.00001" in control, set the position command unit to " $\times 10^{-3}$ degree" or " $\times 10^{-6}$ degree" instead of "degree". As a result, the value of "0.00001" can be handled as "10.0", or in other words, can be controlled accurately in terms of control.

Ex.

Setting in degree units

Accuracy required for system	Value set for axis parameter*1			Monitor display
	(1) Position command unit (<u>AxisName.Pr.Unit_Position</u>)	(2) Driver Unit Numerator (<u>AxisName.Pr.Drive_UnitConvRatioNum</u>)	(3) Driver Unit Denominator (<u>AxisName.Pr.Drive_UnitConvRatioDen</u>)	
360.00000 [degree]	H00410000 └─┬─┘ degree └─┬─┘ $\times 10^{-0}$	67108864 (Resolution of servo motor)	360	360.00000...[degree]
360.00000000 [degree]	HFD410000 └─┬─┘ degree └─┬─┘ $\times 10^{-3}$		360000	360000.00000...[10 ⁻³ degree]
360.00000000000 [degree]	HFA410000 └─┬─┘ degree └─┬─┘ $\times 10^{-6}$		360000000	360000000.00000...[10 ⁻⁶ degree]

*1 Set axis parameters in the "Electronic Gear Settings" window displayed by clicking [Motion Control Setting Function] ⇒ navigation window ⇒ [Axis] ⇒ [Target Axis] ⇒ [Axis Parameters] ⇒ [Position Command Unit] ⇒ the [...] button.

Electronic Gear Setting Axis0001

Entry

Select the machine components, and enter the machine data to automatically set the axis parameters (position command unit, driver unit conversion numerator and driver unit conversion denominator).

Machine Components : Rotary Table

(1) Position Command Unit $\times 10^{-3}$ degree

(3) One Revolution 360000.0000 [10⁻³ degree]


Reduction Ratio (NL/NM) = 1 / 1

☒ Calculate reduction ratio by teeth or diameters Reduction Ratio Setting

(2) Encoder Resolution 67108864 [pulse/rev]

Setting Range

Calculate Axis Parameters



Calculation Result

Axis Parameters	Position Command Unit	$\times 10^{-3}$ degree
	Driver Unit Conversion Numerator	67108864
	Driver Unit Conversion Denominator	360000

Movement Amount per Driver Unit Command

* The electronic gear on driver side is calculated as 1:1.

As a result of calculation, no error occurs in the movement amount.

Applying the calculation result above,

the error for every 0.0 [10⁻³ degree] (movement amount) you perform is about 0.0 [10⁻³ degree]

Click OK to reflect to the axis parameters.

OK Cancel

- If the position command unit of the axis specified as an output axis has been set to " $\times 10^{-6}$ degree", in addition to operating the slave axis by synchronous control restoration, it is possible to go over the velocity limit value with the axis set as the output axis. If going over the velocity limit value occurs, move the set current position of the axis set as the output axis in advance to a position close to the restoration position, or change the position command unit to a large unit such as " $\times 10^{-3}$ degree".
- As the guaranteed range for decimals is up to 5 decimal places, the numbers of the current position of the axis set as the input axis are truncated after the 5th decimal place. In addition, if a value with more than 5 decimal places is set for a parameter or control data variable with a double-precision real number data type, the values after the 5th decimal place are ignored.
- If double-precision real numbers are monitored with the engineering tool, any values after the 5th decimal place may differ from the actual values.

Ex.

If the current position per cycle is in "180.00000" position
The monitor may display this as "179.99999...".

Smoothing

■Import timing

The smoothing time constant becomes enabled when the system is started. To reflect any changed values, a system restart is required.

■Smoothing time constant setting value and operation cycle setting

When the smoothing time constant is set to maximum value (5000 [ms]), in addition to the operation cycle being less than or equal to 125 [μ s], there will be restriction on the movement amount that can be processed per operation cycle. The relationships between the operation cycle and movement amount is shown in the following table.

Operation cycle [μ s]	Movement amount per operation cycle when the smoothing time constant is 5000 [ms]
62.5	-536870912.0 to 536870911.0
125	-1073741824.0 to 1073741823.0
More than 250	-2147483648.0 to 2147483647.0

If a value larger than the movement amount corresponding to the operation cycles in the above table is input into one operation cycle, "Advanced Synchronization Control Operation Overflow" (error code: 1AF1H) occurs.

- The filter level can be calculated by the following formula. Any decimal values rounded to the nearest integer. However, if the result is rounded to "0", the filter level will operate using level 1.

$$\text{Filter level} = (\text{smoothing time [ms]} \div \text{operation cycle [ms]})$$

■Smoothing function memory usage

- When using the smoothing function, the longer the total of the smoothing time constant used by advanced synchronized control, the more system memory the add-on MotionControl_AdvancedSync consumes. The overall smoothing time is calculated using the following formula.

$$\begin{aligned} \text{Total smoothing time} = & \text{Total Output axis smoothing time constant (AdvOutputName.PrConst.SmoothingTimeConstant)} + \\ & \text{Total Main shaft clutch smoothing time constant (AdvOutputName.PrConst.MasterClutchSmoothingTimeConstant)} + \text{Total} \\ & \text{Auxiliary shaft clutch smoothing time constant (AdvOutputName.PrConst.AuxClutchSmoothingTimeConstant)} + \text{Total Main} \\ & \text{shaft speed change gear smoothing time constant} \\ & \text{(AdvOutputName.PrConst.MasterSpeedChangeGearSmoothingTimeConstant)} + \text{Total auxiliary shaft speed change gear} \\ & \text{smoothing time constant (AdvOutputName.PrConst.AuxSpeedChangeGearSmoothingTimeConstant)} + \text{Total Output axis} \\ & \text{speed change gear smoothing time constant (AdvOutputName.PrConst.OutSpeedChangeGearSmoothingTimeConstant)} \end{aligned}$$

- The smoothing function secures memory used by the smoothing process at power ON. Memory usage can be calculated using the following formula.

$$\text{Memory usage} = \text{Filter level} \times 8 \text{ bytes}$$

- Operation when smoothing memory is insufficient.

Depending on the smoothing time constant setting, "Advanced Synchronous Control Smoothing Memory Shortage" (error code: 1C9CH), or "Advance Synchronous Control Add-on Memory Shortage" (error code: 1C9BH) will occur at startup. If an error occurs, reduce the smoothing time constant used by advanced synchronous control, or set the add-on MotionControl_AdvancedSync parameter (MotionControl_AdvancedSync_System.PrConst.AddonMemory) to satisfy the required memory amount.

Combination with other functions

■Touch probe

When latching the Input axis variables (AdvInputName.□) and Output axis variables (AdvOutputName.□) using MC_TouchProbe (Touch Probe Enabled), latch is possible by specifying the data type to [VAR]. However, the latch data stores a value delayed by one operation cycle.

In addition, latch data estimations do not take into account any values exceeding the permissible value.

■Synchronous control function

The following Motion control FBs cannot be combined with advanced synchronous control.

To change the cam reference position, the current position per cycle, and current position per cycle after main shaft/auxiliary shaft gear during synchronous control, use the synchronous control change function.

- MCv_ChangeCycle (Current Value Change per Cycle)

Related add-ons

Using this function requires the following add-ons.

Item	Add-on
Required	<ul style="list-style-type: none"> • baseSystem • Axis • MotionEngine • MotionControl_General • MotionControl_AdvancedSync
When using synchronous control initial position function	AbsSystem
When using operation profile	ProfileControl
When using a clutch with an external input signal	SignalIO



To use this function, it is recommended to disable the following add-ons.

- SimpleMotion

System memory usage

■RAM usage

- When there are no input settings, output settings, and Motion control FBs, 270k bytes of memory will be used. The memory usage for input settings and output settings and each Motion control FB is shown below. Change the add-on MotionControl_AdvancedSync parameter (MotionControl_AdvancedSync_System.PrConst.AddonMemory) where necessary.

Data type	RAM usage
Input axis	2.7k bytes
Output axis	17.7k bytes
MCv_AdvancedSync (Advanced Synchronous Control)	0.9k bytes

- For memory usage when using smoothing, refer to the following.
 Page 573 Smoothing function memory usage
- Memory usage when using an external input signal
 When using an external input signal with a variable such as Main shaft clutch ON signal setting (AdvOutputName.Pr.MasterOnClutchSignal), 1.8k bytes of add-on "SignalIO" memory are used for each setting. Change the Maximum RAM size (System.PrConst.Addon_SignalIO.RamSizeMax) in accordance with the number settings used for the external input signal.

■When the add-on memory capacity is insufficient

When the memory used for add-ons is insufficient, "Insufficient Add-on System Memory (RAM)" (error code: 3209H) occurs. When an error occurs, set the add-on MotionControl_AdvancedSync parameter (MotionControl_AdvancedSync_System.PrConst.AddonMemory) to satisfy the required amount of memory. The usage for add-on memory and filter functions can be checked with the following variable.

- System Memory Usage (MotionControl_AdvancedSync_System.Md.AddonMemory)

■Backup RAM usage

For backup RAM usage, refer to the following.

 Page 654 Backup data management for advanced synchronous control

Combining versions

The engineering tool version that supports this function is shown below.

Engineering tool	Version
Motion control setting function	"1.040S" or later

Buffer mode

For the buffer modes that can be specified with MCv_AdvancedSync (Advanced Synchronous Control), refer to the following.

 Page 148 Buffer mode that can be set

15.3 Input Axis Function

The motion control setting function of GX Works3 is used to configure the input settings for advanced synchronous control and generate and initialize the input axes necessary for advanced synchronous control. Any set axes will be assigned to the global label data as an input axis variable.

Input axes are defined as an axis variable consisting of monitor information such as parameter information and current positions.

As the input axis settings are enabled after power ON, the status of input axes can be monitored even when MCv_AdvancedSync (Advanced Synchronous Control) has not been started.

When a warning or error occurs in the input axis, the warning or error is stored in the axis set in the input axis Axis information (AdvInputName.Axis).

The input axis functions are shown below.


Function	Description	Application
Type setting	Sets the axis and data source used for the input axis.	Set the axis to transmit to the advanced synchronous control output axis and its input values.
Smoothing	Smoothing processing will be conducted for the input value of the axis set in type setting.	It is possible to suppress the velocity change by smoothing processing when "Actual value" or "Latest actual value" is set as the input value in the data source. However, the input response is delayed by the set time due to the smoothing process.
Phase compensation	Phase compensation processing will be conducted for the input values of the axis set in type setting.	When an real drive axis or real encoder axis is set to the input axis, a phase delay occurs between the input axis and the motor axis end of the output axis. The phase compensation function is used to prevent phase deviation. For phase compensation of the input axis delay time, set the delay time peculiar to the system to the input axis Phase compensation advance time (<u>AdvInputName.Pr.PhaseCompAdvanceTime</u>)*1.
Moving direction restriction	Moving direction restriction filter will be conducted for the input values of the axis set in type setting.	When "Actual value" or "Latest actual value" is set as the input value in the data source, it is possible to prevent reverse operation due to mechanical vibration, etc.
Monitor	Monitors the input axis. Input axis monitor values are stored in the following monitor data. <ul style="list-style-type: none"> • Active status (<u>AdvInputName.Md.ActiveStatus</u>) • Cumulative current position (<u>AdvInputName.Md.CumulativePosition</u>) • Set velocity (<u>AdvInputName.Md.SetVelocity</u>) • Phase compensation amount (<u>AdvInputName.Md.PhaseCompensationAmount</u>) • Moving direction restriction amount (<u>AdvInputName.Md.DirectionRestrictionAmount</u>) 	When the status of the input axis is monitored, this is described on the program.

*1 For the delay time peculiar to the system, refer to the following.

 Page 679 Phase compensation function

After the input axis is generated, specify the input axis Axis information (AdvInputName.Axis) to the Master axis (Master) of the MCV_AdvancedSync (Advanced Synchronous Control). If using an auxiliary shaft and a sub input axis, specify the input axis Axis information (AdvInputName.Axis) to the Auxiliary shaft object (AdvOutputName.Pr.AuxAxis) and the Sub input axis object (AdvOutputName.Pr.SubAxis).

The relationship between the axis current position set in the input axis Axis information (AdvInputName.Axis) and each input axis function is shown below.



Input axis initialization timing

The input axis variables are initialized at the following timing.

Timing	Process
Power ON CPU module reset	Refers to the global label data, and initializes all set input axis variables.
PLC READY OFF → ON	<div>■Uninitialized axes Refers to the global label data and initializes all axis variables.</div> <div>■Initialized axes When the parameter error occurs at loading, the axis is not deleted. In this case, the READY does not turn to ON. For the label initialization processing when the PLC READY turns OFF to ON, refer to "Label initialization function" in the following manual.</div> <div>📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)</div>

Input axis position command unit

The input axis position command unit is the Position command unit (AxisName.Pr.Unit_Position) and the Position command unit string (AxisName.Pr.Unit_PositionString) of the axis set in the input axis Axis information (AdvInputName.Axis).

In addition, the position command unit of the input axis and output axis during synchronized control will not affect control.

The result of the calculation performed for the position information of the input axis which has no unit information is used as the command of the output axis.

Refer to the explanation of each monitor data for details on input axis monitor display units.

Input axis positioning range

Regardless of the Ring counter upper limit value (AxisName.PrConst.RingCount_UpperValue) or Ring counter lower limit value (AxisName.PrConst.RingCount_LowerValue) of the axis positioning range set in the input axis Axis information (AdvInputName.Axis), the input axis Cumulative current position (AdvInputName.Md.CumulativePosition) will be within the following range.

Positioning Range

$-10000000000.0 \leq \text{Positioning range} < 10000000000.0$

Input axis relevant variables

Input axis (AdvInputName.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
LabelID	Axis label ID	At system start	WORD(UINT)	1 to 256	0
Axis	Axis information		AXIS_REF	—	—

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Axis label ID(AdvInputName.LabelID)

Sets the label ID of the input axis.

The setting range is from 1 to 256.

■Axis information (AdvInputName.Axis)

- Sets the Axis information (AxisName.AxisRef) of the axis that will be the input axis for advanced synchronous control. Up to 256 input axes can be generated.
It is not possible to set the same axis to the axis information of different input axes. If it is set, "Advanced Synchronous Control Input Axis Incorrect" (error code: 1C9DH) will occur.
- Do not set the Axis information (AxisName.AxisRef) of an axis defined in local labels. If it is set, input axes cannot be generated.

Input axis parameter constant (AdvInputName.PrConst.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
SourceValue	Data source selection	At system start	INT (MC_SOURCE)	1: Set Value (mcSetValue) 2: Actual Value (mcActualValue) 101: Latest Set Value (mcLatestSetValue) 102: Latest Actual Value (mcLatestActualValue)	1: Set Value (mcSetValue)
SoothingTimeConstant	Soothing time constant		WORD(UINT)	0 to 5000 [ms]	0 [ms]
PhaseCompensationTimeConstant	Phase compensation time constant		WORD(UINT)	0 to 65535 [ms]	10 [ms]
DirectionRestriction	Moving direction restriction		INT (MC_INPUT_DIRECTION)	0: Without moving direction restriction (NoDirectionRestriction) 1: Enable only for current position increase direction (mcPositiveDirection) 2: Enable only for current position decrease direction (mcNegativeDirection)	0: Without moving direction restriction (NoDirectionRestriction)

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Data source selection (AdvInputName.PrConst.SourceValue)


Set the input axis data source to be referenced in advanced synchronous control.

Setting value	Description
1: Set Value (mcSetValue)	Uses the set position of the axis specified to the input axis in the previous operation cycle.
2: Actual Value (mcActualValue)	Uses the actual position of the axis specified to the input axis in the previous operation cycle.
101: Latest Set Value (mcLatestSetValue)	Uses the set position of the axis specified to the input axis in the current operation cycle.
102: Latest Actual Value (mcLatestActualValue)	Uses the actual position of the axis specified to the input axis in the current operation cycle.

- If using "101: Latest set value (mcLatestSetValue)" and "102: Latest actual value (mcLatestActualValue)", the commands of multiple Motion control FBs can be transmitted in the same operation cycle. In this case, make the first calling order and the linking order of linked Motion control FBs the same.
- When Data source selection (AdvInputName.PrConst.SourceValue) is set to "1: Set value (mcSetValue)" or "101: Latest set value (mcLatestSetValue)" and the master axis is disconnected or changes to servo OFF due to a servo alarm or forced stop, the change in values may become large. This can be prevented by setting Data source selection (AdvInputName.PrConst.SourceValue) to "101: Latest set value (mcLatestSetValue)" or "102: Latest actual value (mcLatestActualValue)".
- When actual value is specified for an axis (virtual drive axis, virtual linked axis, virtual encoder axis) that does not have an Actual position (AxisName.Md.ActualPosition), the axis operates by the value that is the same as Set Position (AxisName.Md.SetPosition).
- For real encoder axes, since the set position is calculated from the actual position, operation will be the same regardless of the set value.

■Smoothing time constant (AdvInputName.PrConst.SmoothingTimeConstant)

Set the averaged time for the smoothing process of the input movement amount from the input axis. The smoothing process can moderate velocity change when "Actual value" or "Latest actual value" is set to the input value. However, the input response is delayed by the set time due to the smoothing process.




■Phase compensation time constant

(AdvInputName.PrConst.PhaseCompensationTimeConstant)

Set the time constant for reflecting the phase compensation amount for the first order delay.

63% of the phase compensation amount is reflected in the specified time constant.



■Moving direction restriction (AdvInputName.PrConst.DirectionRestriction)

Set this parameter to restrict the input movement amount from the input axis to one direction.


Setting value	Description
0: Without movement direction restriction (NoDirectionRestriction)	Moving direction restriction is not executed.
1: Enable only for current position increase direction (mcPositiveDirection)	Enable only the input travel value in a positive direction of the input axis cumulative current position.
2: Enable only for current position decrease direction (mcNegativeDirection)	Enable only the input travel value in a negative direction of the input axis cumulative current position.

The input movement amounts of the enable direction and opposite direction are accumulated as a moving direction restriction amount, and is reflected when the input movement amount moves in the enable direction. As such, even when reverse operations are repeated, there will be no deviation in the input axis cumulative current position.

When the following operations are conducted for the input axis, the movement amount will be cleared to 0.

- When a servo amplifier is connected
- When homing is executed
- When the current position is changed

When "1: Enable only for current position increase direction (mcPositiveDirection)" is set to Moving direction restriction amount (AdvInputName.Md.DirectionRestrictionAmount).



Input axis parameter (AdvInputName.Pr.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
PhaseCompensationAdvanceTime	Phase compensation advance time	Operation cycle	DINT	-100000000 to 100000000 [μs]	0

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Phase compensation advance time (AdvInputName.Pr.PhaseCompAdvanceTime)

Sets the time to advance or delay the phase (input response) of the input axis.

Setting value	Description
1 to 100000000 [μs]	Advance the phase (input response) according to the setting time.
0 [μs]	Do not execute phase compensation.
-100000000 to -1 [μs]	Delay the phase (input response) according to the setting time.

If the setting time is too long, the system experiences overshoot or undershoot at acceleration/deceleration of the input speed. In this case, set longer time to reflect the phase compensation amount in Phase compensation in time constant (AdvInputName.PrConst.PhaseCompensationTimeConstant).

Input axis monitor data (AdvInputName.Md.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Stored value
ActiveStatus	Active status	Immediate	INT	<ul style="list-style-type: none"> • -1: Disabled • 0: Not connected • 1: Input axis enabled
CumulativePosition	Cumulative current position	Operation cycle	LREAL	-10000000000.0 ≤ Input axis cumulative current position < 10000000000.0 [Position command unit of the axis set as the input axis]
SetVelocity	Set velocity		LREAL	-2500000000.0 to 2500000000.0 [Position command unit of the axis set as the input axis]
PhaseCompensationAmount	Phase compensation amount		LREAL	-2147483648.0 to 2147483647.0 [Position command unit of the axis set as the input axis]
DirectionRestrictionAmount	Direction restriction amount		LREAL	-2147483648.0 to 2147483647.0 [Position command unit of the axis set as the input axis]

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Active status (AdvInputName.Md.ActiveStatus)

Stores the status of the input axis.

Setting value	Description
-1: Disabled	Input axis generation has failed due to being parameters being outside the possible range.
0: Not connected	The initial processing of the axis set as an input axis has not been completed, such as when a servo amplifier is not connected.
1: Input axis enabled	The input axis can be used for synchronous control.

■Cumulative current position (AdvInputName.Md.CumulativePosition)

The cumulative current position of the input axis is stored in the position units of the axis set in the input axis Axis information (AdvInputName.Axis) as shown below.

The current position of the input axis is the value after smoothing, phase compensation, and movement direction restriction processes.

Data source selection (<u>AdvInputName.PrConst.SourceValue</u>) setting value	Description
1: Set value (mcSetValue)	<ul style="list-style-type: none"> • The set position of the axis set in the input axis Axis information (<u>AdvInputName.Axis</u>) in the previous operation cycle is stored. • When the set current position or the actual current position is changed by homing or current position change, it will be changed to the current position after change.
2: Actual value (mcActualValue)	<ul style="list-style-type: none"> • The value calculated using the position address returned by the device station of the axis set in the input axis Axis information (<u>AdvInputName.Axis</u>) in the previous operation cycle is stored.
101: Latest set value (mcLatestSetValue)	<ul style="list-style-type: none"> • The set position of the axis set in the input axis Axis information (<u>AdvInputName.Axis</u>) in this operation cycle is stored. • When the set current position or the actual current position is changed by homing or current position change, it will be changed to the current position after change.
102: Latest actual value (mcLatestActualValue)	<ul style="list-style-type: none"> • The value calculated using the position address returned by the device station of the axis set in the input axis Axis information (<u>AdvInputName.Axis</u>) in this operation cycle is stored.

■Set velocity (AdvInputName.Md.SetVelocity)

The speed of the input axis is stored in speed units of the axis set in the input axis Axis information (AdvInputName.Axis).

The speed of the input axis is the value after smoothing, phase compensation, and moving direction restriction processes.



Depending on the movement amount per input axis operation cycle, the range of "-2500000000.0 to 2500000000.0" may be exceeded.

■Phase compensation amount (AdvInputName.Md.PhaseCompensationAmount)

The phase compensation amount of the input axis is stored in position command units of the axis set in the input axis Axis information (AdvInputName.Axis).

The phase compensation amount of the input axis is the value after smoothing and phase compensation processes.

■Moving direction restriction amount (AdvInputName.Md.DirectionRestrictionAmount)

During moving direction restriction of the input axis, the cumulative value of the enabled direction and opposite input movement amount is stored as shown below in position units of the axis specified as the input axis.

Moving direction restriction (<u>AdvInputName</u> .PrConst.DirectionRestriction) setting value	Description
1: Enable only for current position increase direction	A negative accumulation is stored during moving direction restriction. "0.0" is stored if there is no restriction.
2: Enable only for current position decrease direction	Stores positive cumulative values during moving direction restriction. "0.0" is stored if there is no restriction.

Since the moving direction restriction is processed after the phase compensation process, if an undershoot occurs due to phase compensation during a deceleration stop, the moving direction restriction amount may remain.

Precautions

The following are precautions for using an input axis.

Advanced synchronous control operation overflow warning

When the driver conversion numerator/driver conversion denominator setting value of the axis set in the input axis Axis information (AdvInputName.Axis) or the input axis speed is significantly large, an overflow in the internal operation of the input axis will occur, and "Advanced Synchronous Control Operation Overflow Warning" (warning code: 0D3EH) error may occur. When a warning occurs, the synchronized position of the input axis and output axis may shift out of position. In this case, fix the setting values of the driver conversion numerator/driver conversion denominator or reduce the speed of the input axis.


Advanced synchronous control linking order

The Latest Set Value (mcLatestSetValue) and Latest actual value (mcLatestActualValue) of the Data Source Selection (AdvInputName.PrConst.SourceValue) use a position of the master axis in the same operation cycle, and the others use a position of the master axis in the previous operation cycle.

Using the Latest set value (mcLatestSetValue) and Latest Actual Value (mcLatestActualValue) can transmit the multiple Motion control FB command in the same operation cycle. In this case, set the first call order and linking order of the linked Motion control FB to be the same.

Ex.

When transmitting movement of the real drive axis, the virtual encoder axis and advanced synchronous control to MC_CamIn (Cam Operation Start) control in the same operation cycle



When using the above combination of MCv_AdvancedSync (Advanced Synchronous Control) and single synchronous control (linked order), set the first call order as follows.

- First call order
 - 1. Motion control FB which moves the real drive axis set as a Master axis (Master) of MC_GearIn (Gear Operation Start)
 - 2. MC_GearIn (Gear Operation Start)
 - 3. MCv_AdvancedSync (Advanced Synchronous Control)
 - 4. MC_CombineAxes (Addition/Subtraction Positioning)
 - 5. MC_CamIn (Cam Operation Start)
- Master axis data source selection (MasterValueSource) of each single synchronous control FB and advanced synchronous control data source selection (AdvInputName.PrConst.PosSource) setting:
101: Latest Set Value (mcLatestSetValue)

15.4 Output Axis Function

The GX Works3 motion control setting function is used to configure output settings and for generating and initializing the output axes necessary for advanced synchronous control.


Output axes are defined as the output axis variables consisting of parameter information, control data, and monitor information such as current positions.

Any generated output axes are specified in the output axis Axis information (AdvOutPutName.Axis) of the Slave Axis (Slave) of MCv_AdvancedSync (Advanced Synchronous Control).

When an error or warning occurs in the output axis, the warning or error is stored in the axis set in the output axis Axis information (AdvOutPutName.Axis).

This section describes the parameters, control data, and monitor data of the "Main shaft module", "Auxiliary shaft module", and "Output axis module" of advanced synchronous control.

The "Main shaft module", "Auxiliary shaft module" and "Output axis module" are defined as shown in the following figure.



The arrangement and number of modules in advanced synchronous control are fixed.

Output axis initialization timing

The output axis variables are initialized at the following timings.

Timing	Processing
Power ON CPU module reset	Refers to the global label data, and initializes all set output axis variables.
PLC READY OFF → ON	<div>■Uninitialized axes</div> <div>Refers to the global label data and initializes all output axis variables.</div> <div>■Initialized axes</div> <div>Refer to the global label data for the output axis parameter data (<u>AdvOutPutName.Pr.□</u>) and reload again. When the parameter error occurs at loading, the axis is not deleted. In this case, the READY does not turn to ON.</div> <div>For the label initialization processing when the PLC READY turns OFF to ON, refer to "Label initialization function" in the following manual.</div> <div>📖JMESEC iQ-R Programming Manual (Motion Control Function Blocks)</div>

Output axis positioning range

- Set the Ring counter lower limit value (AxisName.PrConst.RingCount_LowerValue) and Ring counter upper limit value (AxisName.PrConst.RingCount_UpperValue) to the values below. If any other values are set, an "Out of Advanced Synchronous Control Output Axis Ring Counter Range" (error code: 1AF4H) error will occur at system start.

Setting range	
Ring counter lower limit value (<u>AxisName</u> .PrConst.RingCount_LowerValue)	Ring counter upper limit value (<u>AxisName</u> .PrConst.RingCount_UpperValue)
0.0	$0.0 < \text{Setting value} \leq 2147483647.0$
-10000000000.0	10000000000.0

- Do not set the Ring counter lower limit value (AxisName.PrConst.RingCount_LowerValue) and Ring counter upper limit value (AxisName.PrConst.RingCount_UpperValue) of the axis positioning range of the axis set in the output axis Axis information (AdvOutputName.Axis) to a decimal number. If set, an error will occur with the value output to the slave axis and the Set position (AxisName.Md.SetPosition) of the axis set to the output axis in synchronous control when the maximum permissible value is exceeded.

Output axis relevant variables

Output axis (AdvOutputName.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting axis	Initial value
LabelID	Axis label ID	At system start	WORD(UINT)	1 to 256	0
Axis	Axis information		AXIS_REF	—	—

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Axis label ID (AdvOutputName.LabelID)

Sets the label ID of the output axis.

The setting range is from 1 to 256.

■ Axis information (AdvOutputName.Axis)

- Sets the Axis information (AxisName.AxisRef) of the axis that will be the output axis for advanced synchronous control. Up to 256 output axes can be generated. It is not possible to set the same axes to the axis information of different output axes.
- Do not set the Axis information of an axis (AxisName.AxisRef) defined in local labels. If it is set, output axes cannot be generated.
- Settable axis types to the output axis are shown below.

○: Settable, ×: Not settable

Axis type		Output axis setting possible
Real axis	Real drive axis	○
	Real encoder axis	× ^{*1}
Virtual axis	Virtual drive axis	○
	Virtual encoder axis	× ^{*1}
	Virtual linked axis	○

^{*1} If set, "Advanced Synchronous Control Output Axis Incorrect" (error code: 1C9EH) will occur.

Output axis parameters constant (AdvOutPutName.PrConst.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
SmoothingTimeConstant	Output axis smoothing time constant	At system start	WORD(UINT)	0 to 5000 [ms]	0 [ms]

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Output axis smoothing time constant (AdvOutPutName.PrConst.SmoothingTimeConstant)

Set the averaging time to execute a smoothing process for the movement amount to the output axis after cam conversion.

The smoothing process can moderate rapid velocity changes on the cam, etc. of cam data (linear interpolation).

The output response is delayed depending on the time corresponding to the setting by smoothing process setting.

Output axis parameter (AdvOutPutName.Pr.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
SubAxis	Sub input axis object	At start	AXIS_REF	—	—
AuxAxis	Auxiliary axis object		AXIS_REF	—	—

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Sub input axis object (AdvOutPutName.Pr.SubAxis)

Set the sub input axis object axis. This variable will be disabled when set to "0".

When an axis that has not been assigned input settings is set, "Advanced Synchronization Control Axis Unset" (error code: 1AF0H) will occur.

■Auxiliary shaft object (AdvOutPutName.Pr.AuxAxis)

Set the auxiliary axis object axis. This variable will be disabled when set to "0".

When an axis that has not been assigned input settings is set, "Advanced Synchronization Control Axis Unset" (error code: 1AF0H) will occur.

Output axis monitor (AdvOutputName.Md.)

Structure/Variable name	Name	Import ^{*1}	Data type ^{*1}	Stored value
Synchronous status	SyncStatus	At start	INT	-1: Disabled 0: Not synchronizing 1: In synchronization
Master shaft	MasterAxisNo		WORD(UINT)	0 to 10000
Sub input axis	SubAxisNo		WORD(UINT)	0 to 10000
Auxiliary axis	AuxAxisNo		WORD(UINT)	0 to 10000

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Synchronization status (AdvOutputName.Md.SyncStatus)

The synchronization status of the output axis is stored.

Setting value	Description
-1: Disabled	The output axis cannot be used in this status due to being in initial processing or because of out of range parameters.
0: Not synchronizing	The output axis is not synchronized with the input axis by MCv_AdvancedSync (Advanced Synchronous Control).
1: In synchronization	The output axis is synchronized with the input axis by MCv_AdvancedSync (Advanced Synchronous Control).

■ Main shaft (AdvOutputName.Md.MasterAxisNo)

The axis number of the main shaft set in the input axis Axis information (AdvInputName.Axis) in synchronization with the output axis is stored.

"0" is stored when a main shaft is not connected.

■ Sub input axis (AdvOutputName.Md.SubAxisNo)

The axis number of the sub input axis set in the input axis Axis information (AdvInputName.Axis) in synchronization with the output axis is stored.

"0" is stored when a sub input axis is not connected.

■ Auxiliary shaft (AdvOutputName.Md.AuxAxisNo)

The axis number of the auxiliary shaft set in the input axis Axis information (AdvInputName.Axis) in synchronization with the output axis is stored.

"0" is stored when an auxiliary shaft is not connected.

Main shaft module

The main shaft control modules transmit the movement amount inputted from an input axis to the output axis.

The functions for a main shaft module include gears, clutches, and speed change gears.


The main shaft module corresponds to the axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control).

Refer to the following for the setting items for gears, clutches, and speed change gears of the main shaft module.

Function	Member	Variable	Reference
Gear	Output axis parameter (AdvOutPutName.Pr.)	Gear parameter (Gear.)	Page 590 Gear parameter of output axis parameters (AdvOutPutName.Pr.Gear.)
Clutch	Output axis parameter constant (AdvOutPutName.PrConst.)	—	Page 591 Output axis parameter constant (AdvOutPutName.PrConst.)
	Output axis parameter (AdvOutPutName.Pr.)	—	Page 591 Output axis parameters (AdvOutPutName.Pr.)
		Clutch parameter (Clutch.)	Page 593 Clutch parameter of output axis parameters (AdvOutPutName.Pr.Clutch.)
	Output axis monitor data (AdvOutPutName.Md.)	Clutch monitor (Clutch.)	Page 597 Clutch monitor of output axis monitor data (AdvOutPutName.Md.Clutch.)
Speed change gear	Output axis control data (AdvOutPutName.Cd.)	Clutch control data (Clutch.)	Page 598 Clutch control data of output axis control data (AdvOutPutName.Cd.Clutch.)
	Output axis parameter constant (AdvOutPutName.PrConst.)	—	Page 626 Output axis parameters constant (AdvOutPutName.PrConst.)
	Speed change gear parameter of output axis parameters (AdvOutPutName.Pr.SpeedChangeGear.)	Speed change gear parameter (SpeedChangeGear.)	Page 625 Speed change gear parameter of output axis parameters (AdvOutPutName.Pr.SpeedChangeGear.)
	Speed change gear control data of output axis parameters (AdvOutPutName.Cd.SpeedChangeGear.)	Speed change gear control data (SpeedChangeGear.)	Page 626 Speed change gear control data of output axis parameters (AdvOutPutName.Cd.SpeedChangeGear.)

• Main shaft module

The input value is generated as a composite value from two input axes (the main shaft and sub input axis) through the composite main shaft gear. The composite input value can be converted by the main shaft gear to a value taking into account the deceleration ratio, rotation direction, etc. for the machine system.



*1 Clutch (Page 611 Clutch)

*2 Speed change gear (Page 624 Speed change gear)

Gear parameter of output axis parameters (AdvOutputName.Pr.Gear.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterCompositeGear	Composite main shaft gear	Operation cycle (FB is starting)	WORD(HEX)	<div> <div>H□□□□</div> <div> Main shaft input method 0: No input 1: Input + 2: Input - </div> <div> Sub input method 0: No input 1: Input + 2: Input - </div> </div>	0001H
MasterNumerator	Main shaft gear: Numerator	At start	DINT	-2147483647 to 2147483647	1
MasterDenominator	Main shaft gear: Denominator		DWORD(UDINT)	1 to 2147483647	1

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Composite main shaft gear (AdvOutputName.Pr.Gear.MasterCompositeGear)

Set the composite method for the current positions from the main shaft and sub input axis.

Setting value	Description
0: No input	The input value from the input axis is calculated as 0.
1: Input +	The input value from the input axis is calculated as it is.
2: Input -	The input value from the input axis is calculated with its opposite sign.

Operation assumes "0: No input" if the value is set out of the range from 0 to 2.



The composite method for the composite main shaft gear can be changed during synchronous control. It can also be used as a clutch to switch input values of the main shaft and auxiliary shafts.

■Main shaft gear: Numerator (AdvOutputName.Pr.Gear.MasterNumerator)

Set the numerator for the main shaft gear input value conversion.

The input value is converted as follows.

$$\text{Input value after conversion} = \text{Input value before conversion} \times \frac{\text{Main shaft gear: Numerator}}{\text{Main shaft gear: Denominator}}$$

The input value direction can be reversed by setting a negative value in Main shaft gear: Numerator.



Setting a reduced fraction is recommended for "Main shaft gear: Numerator/Main shaft gear: Denominator".

■Main shaft gear: Denominator (AdvOutputName.Pr.Gear.MasterDenominator)

Set the denominator for the main shaft input value conversion.

Set together with Main shaft gear: Numerator.

Output axis parameter constant (AdvOutPutName.PrConst.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterClutchSmoothingTimeConstant	Main shaft clutch smoothing time constant	At system start	WORD(UINT)	0 to 5000 [ms]	0 [ms]

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Main shaft clutch smoothing time constant

(AdvOutPutName.PrConst.MasterClutchSmoothingTimeConstant)

Set a time constant when the time constant method is set to "1: Time constant method (Exponent) (TimeConstantExponent)" or "2: Time constant method (Linear) (TimeConstantLinear)" in the Main shaft clutch smoothing method

(AdvOutputName.Pr.Clutch.MasterSmoothingMethod).

The time constant setting applies for both clutch ON/OFF.

Output axis parameters (AdvOutPutName.Pr.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterOnClutchSignal	Main shaft clutch ON signal setting	At system start	SIGNAL_SELECT	—	—
MasterOffClutchSignal	Main shaft clutch OFF signal setting			—	—

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Main shaft clutch ON signal setting (AdvOutPutName.Pr.MasterOnClutchSignal)

Set the variable and device used as the clutch external signal in SIGNAL_SELECT structure when the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) is set to "15: I/O data specification (ClutchSignal)".

For SIGNAL_SELECT structure, refer to the following.

Page 426 SIGNAL_SELECT structure

The following shows the settings peculiar to Main shaft clutch ON signal setting (AdvOutPutName.Pr.MasterOnClutchSignal).

Structure	Variable name	Type	Setting range
SIGNAL_SELECT (Signal Select)	Source (Signal)	TARGET_REF	■Type <ul style="list-style-type: none"> • BOOL ■Data type <ul style="list-style-type: none"> • [OBJ] • [VAR] • [DEV]
	Detection (Signal detection method)	INT (MC_SIGNAL_LOGIC)	<ul style="list-style-type: none"> • 2:Detection at FALSE → TRUE (rising edge) (RisingEdge) • 3:Detection at TRUE → FALSE (falling edge) (FallingEdge) • 4:Detection at rising edge/falling edge (BothEdges)
	CompensationTime (Compensation time)	LREAL	-5.0 to 5.0 [s]
	FilterTime (Filter time)	LREAL	0.0 [s]



When setting [OBJ] for Target (Source.Target), start MCv_AdvancedSync (Advanced Synchronous Control) after the communication with device stations is established. If the communication is not established, "External Signal String Incorrect" (error code: 1AB6H) occurs.

■Main shaft clutch OFF signal setting(AdvOutPutName.Pr.MasterOffClutchSignal)

Set the variable and device used as the clutch external signal in SIGNAL_SELECT structure when the Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl) is set to "15: I/O data specification (ClutchSignal)".

For SIGNAL_SELECT structure, refer to the following.

📖 Page 426 SIGNAL_SELECT structure

The following shows the settings peculiar to Main shaft clutch OFF signal setting

(AdvOutPutName.Pr.MasterOnClutchSignal).

Structure	Variable name	Type	Setting range
SIGNAL_SELECT (Signal Select)	Source (Signal)	TARGET_REF	■Type • BOOL ■Data type • [OBJ] • [VAR] • [DEV]
	Detection (Signal detection method)	INT (MC_SIGNAL_LOGIC)	• 2: Detection at FALSE → TRUE (rising edge) (RisingEdge) • 3: Detection at TRUE → FALSE (falling edge) (FallingEdge) • 4: Detection at rising edge/falling edge (BothEdges)
	CompensationTime (Compensation time)	LREAL	-5.0 to 5.0 [s]
	FilterTime (Filter time)	LREAL	0.0 [s]

Point

When setting [OBJ] for Target (Source.Target), start MCv_AdvancedSync (Advanced Synchronous Control) after the communication with device stations is established. If the communication is not established, "External Signal String Incorrect" (error code: 1AB6H) occurs.

Clutch parameter of output axis parameters (AdvOutputName.Pr.Clutch.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterOnControl	Main shaft clutch ON control setting	Operation cycle (FB is starting)	INT (MC_CLUTCH_METHOD)	0: Invalid (NoClutch)(Direct coupled operation) 1: Clutch command (ClutchCommand) 2: Clutch command leading edge (ClutchLeadingEdge) 3: Clutch command trailing edge (ClutchTrailingEdge) 4: Address mode (ClutchAddress) 15: I/O data specification (ClutchSignal)	0: Invalid (NoClutch)
MasterOffControl	Main shaft clutch OFF control setting		INT (MC_CLUTCH_METHOD)	0: Invalid (NoClutch)(OFF control invalid) 1: Clutch command (ClutchCommand) (One-shot operation) 2: Clutch command leading edge (ClutchLeadingEdge) 3: Clutch command trailing edge (ClutchTrailingEdge) 4: Address mode (ClutchAddress) 15: I/O data specification (ClutchSignal)	0: Invalid (NoClutch)
MasterReference	Main shaft clutch reference address setting	At start	INT (MC_CLUTCH_REFERENCE)	0: Current position before gear (GearFrontPosition) 1: Current position per cycle after gear (GearPositionPerCycle)	0: Current position before gear (GearFrontPosition)
MasterOnAddress	Main shaft clutch ON address	Operation cycle (FB is starting)	LREAL	-10000000000.0 to 10000000000.0	0.0
MasterMovementAmountBeforeOn	Movement amount before main shaft clutch ON	At completing clutch ON condition	LREAL	-2147483648.0 to 2147483647.0	0.0
MasterOffAddress	Main shaft clutch OFF address	Operation cycle (FB is starting)	LREAL	-10000000000.0 to 10000000000.0	0.0
MasterMovementAmountBeforeOff	Movement amount before main shaft clutch OFF	At completing clutch ON condition	LREAL	-2147483648.0 to 2147483647.0	0.0
MasterSmoothingMethod	Main shaft clutch smoothing method	At start	INT (MC_CLUTCH_SMOOTHING_METHOD)	0: Direct (ClutchSmoothingDisabled) 1: Time constant method (Exponent) (TimeConstantExponent) 2: Time constant method (Linear) (TimeConstantLinear) 3: Slippage method (Exponent) (SlippageExponent) 4: Slippage method (Linear) (SlippageLinear) 5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)	0: Direct (ClutchSmoothingDisabled)
MasterOnSlippageAmount	Slippage amount at main shaft clutch ON	At turning clutch ON	LREAL	0.0 to 2147483647.0	0.0
MasterOffSlippageAmount	Slippage amount at main shaft clutch OFF	At turning clutch OFF	LREAL	0.0 to 2147483647.0	0.0

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl)

Set the control method for main shaft clutch ON.

The Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) can be changed during synchronous control. However, changes from settings other than "0: Invalid (NoClutch)" to "0: Invalid (NoClutch)" are not possible.

Setting value	Description
0: Invalid (NoClutch) (Direct coupled operation)	Execute direct coupled operation without clutch control.
1: Clutch command (ClutchCommand)	The clutch is turned ON/OFF by the operations of the Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>) TRUE/FALSE. (Setting in the Main shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.MasterOffControl</u>) is not applicable in the clutch command ON/OFF mode.)
2: Clutch command leading edge (ClutchLeadingEdge)	The clutch is turned ON when the Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>) passes the leading edge (from FALSE to TRUE).
3: Clutch command trailing edge (ClutchTrailingEdge)	The clutch is turned ON when the Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>) passes the trailing edge (from TRUE to FALSE).
4: Address mode (ClutchAddress)	The clutch is turned ON when the reference address (the current position after composite main shaft gear or the current position per cycle after main shaft gear) reaches the Main shaft clutch ON address (<u>AdvOutputName.Pr.Clutch.MasterOnAddress</u>). The movement amount after passing through the ON address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
15: I/O data specification (ClutchSignal)	The clutch is turned ON when the external input signal set in the Main shaft clutch ON signal setting (<u>AdvOutputName.Pr.MasterOnClutchSignal</u>) is detected.

Point

- Other clutch parameters are not applicable during direct coupled operation by setting the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) to "0: Invalid (NoClutch)". The Main shaft clutch forced OFF command (AdvOutputName.Cd.Clutch.MasterForcedOff) and the change of the clutch control setting are ignored during direct coupled operation.
- Changes from settings other than "0: Invalid (NoClutch)" to "0: Invalid (NoClutch)" are not possible. If the setting is changed in that manner, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs.

■Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl)

Set the control method for main shaft clutch OFF.

Setting value	Description
0: Invalid (NoClutch) (OFF control invalid)	Clutch OFF control is not used. This setting is applicable only for execution with clutch ON control.
1: Clutch command (ClutchCommand) (One-shot operation)	The clutch is turned OFF after moving the distance set in the Movement amount before main shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOff</u>) (One-shot operation) after the Main shaft clutch ON/OFF status turns ON. If the Movement amount before main shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOff</u>) is "0.0", the Main shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.MasterOnOffStatus</u>) does not turn to "TRUE (Clutch ON status)" in order to turn back OFF immediately.
2: Clutch command leading edge (ClutchLeadingEdge)	The clutch is turned OFF when the Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>) passes the leading edge (from FALSE to TRUE).
3: Clutch command trailing edge (ClutchTrailingEdge)	The clutch is turned OFF when the Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>) passes the trailing edge (from TRUE to FALSE).
4: Address mode (ClutchAddress)	The clutch is turned OFF when the reference address (the current position after composite main shaft gear or the current position per cycle after main shaft gear) reaches the Main shaft clutch OFF address (<u>AdvOutputName.Pr.Clutch.MasterOffAddress</u>). The movement amount after passing through the OFF address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
15: I/O data specification (ClutchSignal)	The clutch is turned OFF when the external input signal set in the Main shaft clutch OFF signal setting (<u>AdvOutputName.Pr.MasterOffClutchSignal</u>) is detected.

■Main shaft clutch reference address setting (AdvOutputName.Pr.Clutch.MasterReference)

Select the address type to be used as the reference address for clutch control.

Note that the processing order of gears and clutches varies by the reference address.

Setting value	Description
0: Current position before gear (GearFrontPosition)	The clutch is controlled by using the current position after composite main shaft gear, which is before the main shaft gear conversion. The movement amount after the clutch control is converted then output through the main shaft gear. *: The clutch processing is performed for the current position after composite main shaft gear. The current position after composite main shaft gear is used as the reference address when the Main shaft clutch ON control setting (<u>AdvOutputName.Pr.Clutch.MasterOnControl</u>) is set to "4: Address mode (ClutchAddress)".
1: Current position per cycle after gear (GearPositionPerCycle)	The clutch is controlled by using the current position per cycle after main shaft gear. Output after the main shaft clutch control is movement amount without conversion. *: The clutch processing is performed for the current position per cycle after main shaft gear. The current position per cycle after main shaft gear is used as the reference address when the Main shaft clutch ON control setting (<u>AdvOutputName.Pr.Clutch.MasterOnControl</u>) is set to "4: Address mode (ClutchAddress)".

The unit settings of the following parameters are in position command units of the main shaft.

- Main shaft clutch ON address (AdvOutputName.Pr.Clutch.MasterOnAddress)
- Main shaft clutch OFF address (AdvOutputName.Pr.Clutch.MasterOffAddress)
- Movement amount before main shaft clutch ON (AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOn)
- Movement amount before main shaft clutch OFF (AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOff)
- Slippage amount at main shaft clutch ON (AdvOutputName.Pr.Clutch.MasterOnSlippageAmount)
- Slippage amount at main shaft clutch OFF (AdvOutputName.Pr.Clutch.MasterOffSlippageAmount)

■Main shaft clutch ON address (AdvOutputName.Pr.Clutch.MasterOnAddress)

Set the clutch ON address when "4: Address mode (ClutchAddress)" is set in the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl).

When "1: Current position per cycle after gear (GearPositionPerCycle)" is set in the Main shaft clutch reference address setting (AdvOutputName.Pr.Clutch.MasterReference), the setting address is converted for control within the range from "0.0 to (length per cycle - 0.00001)".

Setting value
-10000000000.0 ≤ Main shaft clutch ON address (<u>AdvOutputName.Pr.Clutch.MasterOnAddress</u>) < 10000000000.0

Ex.

Length per cycle: 20000.0


The ON address is controlled as "19000.0" when the setting value is "-1000.0".

■Movement amount before main shaft clutch ON

(AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOn)

Set the movement amount for the reference address with a signed number for the distance between the main shaft clutch ON condition completing and the clutch closing.

Setting value	Description
0.00001 to 2147483647.0 (Positive value)	Used when the reference address is increasing in direction.
0.0	No movement (The clutch is immediately turned ON with the clutch ON condition completing.)
-2147483648.0 to -0.00001 (Negative value)	Used when the reference address is decreasing in direction.



■Main shaft clutch OFF address (AdvOutputName.Pr.Clutch.MasterOffAddress)

Set the clutch OFF address when "4: Address mode (ClutchAddress)" is set in the Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl).

When "1: Current position per cycle after gear (GearPositionPerCycle)" is set in the Main shaft clutch reference address setting (AdvOutputName.Pr.Clutch.MasterReference), the setting address is converted for control within the range from "0.0 to (length per cycle - 0.00001)".

Setting value
-10000000000.0 ≤ Main shaft clutch OFF address (<u>AdvOutputName.Pr.Clutch.MasterOffAddress</u>) < 10000000000.0

Ex.

Length per cycle: 20000.0

The OFF address is controlled as "60.0" when the setting value is "40060.0".

■Movement amount before main shaft clutch OFF

(AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOff)

Set the movement amount for the reference address with a signed number for the distance between the clutch OFF condition completing and the clutch opening.


Setting value	Description
0.00001 to 2147483647.0 (Positive value)	Used when the reference address is increasing in direction.
0.0	No movement (The clutch is immediately turned OFF with the clutch OFF condition completing.)
-2147483648.0 to -0.00001 (Negative value)	Used when the reference address is decreasing in direction.

At completing clutch OFF condition
(Example: Main shaft clutch command
(AdvOutputName.Cd.Clutch.MasterCommand): OFF)

Main shaft clutch ON/OFF status
(AdvOutputName.Md.Clutch.MasterOnOffStatus)

Current position after composite main shaft gear
(AdvOutputName.Md.Cam.MasterCompositeGearSetPosition)
or
Current position per cycle after main shaft gear
(AdvOutputName.Md.Cam.MasterGearPositionPerCycle)

Movement amount after clutch



■Main shaft clutch smoothing method (AdvOutputName.Pr.Clutch.MasterSmoothingMethod)

Set the smoothing method for clutch ON/OFF.

Setting value	Description
0: Direct (ClutchSmoothingDisabled)	No smoothing.
1: Time constant method (Exponent) (TimeConstantExponent)	Smoothing with an exponential curve based on the time constant setting.
2: Time constant method (Linear) (TimeConstantLinear)	Smoothing with linear acceleration/deceleration based on the time constant setting.
3: Slippage method (Exponent) (SlippageExponent)	Smoothing with an exponential curve based on the slippage amount setting.
4: Slippage method (Linear) (SlippageLinear)	Smoothing with linear acceleration/deceleration based on the slippage amount setting.
5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)	Smoothing with linear acceleration/deceleration (input value follow up) based on the slippage amount setting.

■Slippage amount at main shaft clutch ON

(AdvOutputName.Pr.Clutch.MasterOnSlippageAmount)

Set the slippage amount at clutch ON when any of the following is set in the Main shaft clutch smoothing method (AdvOutputName.Pr.Clutch.MasterSmoothingMethod).

- "3: Slippage method (Exponent) (SlippageExponent)"
- "4: Slippage method (Linear) (SlippageLinear) (SlippageLinear)"
- "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)"

The slippage amount is set in units based on the setting in the Main shaft clutch reference address setting (AdvOutputName.Pr.Clutch.MasterReference).

If the set amount is negative, slippage amount at clutch ON is controlled as 0 (direct).

Point

Do not set digits after the decimal point when "3: Slippage method (Exponent) (SlippageExponent)" is set in the Main shaft clutch smoothing method (AdvOutputName.Pr.Clutch.MasterSmoothingMethod). If set, smoothing is performed with the digits after the decimal point ignored.

■Slippage amount at main shaft clutch OFF

(AdvOutputName.Pr.Clutch.MasterOffSlippageAmount)

Set the slippage amount at clutch OFF when any of the following is set in the Main shaft clutch smoothing method (AdvOutputName.Pr.Clutch.MasterSmoothingMethod).

- "3: Slippage method (Exponent) (SlippageExponent)"
- "4: Slippage method (Linear) (SlippageLinear)"
- "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)"

The slippage amount is set in units based on the setting in the Main shaft clutch reference address setting (AdvOutputName.Pr.Clutch.MasterReference).

If the set amount is negative, slippage amount at clutch ON is controlled as 0 (direct).

Point

Do not set digits after the decimal point when "3: Slippage method (Exponent) (SlippageExponent)" is set in the Main shaft clutch smoothing method (AdvOutputName.Pr.Clutch.MasterSmoothingMethod). If set, smoothing is performed with the digits after the decimal point ignored.

Clutch monitor of output axis monitor data (AdvOutputName.Md.Clutch.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Monitor value
MasterOnOffStatus	Main shaft clutch ON/OFF status	Operation cycle (FB is starting)	BOOL	FALSE: Clutch OFF status TRUE: Clutch ON status
MasterSmoothingStatus	Main shaft clutch smoothing status		BOOL	FALSE: Not on clutch smoothing TRUE: On clutch smoothing
MasterCumulativeSlippage	Main shaft clutch slippage (accumulative)		LREAL	-2147483648.0 to 2147483647.0

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

■ MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Main shaft clutch ON/OFF status (AdvOutputName.Md.Clutch.MasterOnOffStatus)

The main shaft clutch ON/OFF status is stored.

■Main shaft clutch smoothing status (AdvOutputName.Md.Clutch.MasterSmoothingStatus)

The smoothing status of the main shaft clutch is stored.

The status is updated by the Main shaft clutch smoothing method (AdvOutputName.Pr.Clutch.MasterSmoothingMethod).

Method	Description
Time constant method	The status is always "TRUE: On clutch smoothing" during the clutch ON status. The status will be "FALSE: Not on clutch smoothing" when the clutch is turned OFF and smoothing is completed.
Slippage method	The status is "TRUE: On clutch smoothing" till the clutch accumulative slippage amount reaches the slippage at clutch ON when the clutch is turned ON. The status will change to "FALSE: Not on clutch smoothing" when the clutch accumulative slippage amount reaches the slippage at clutch ON. The status is "TRUE: On clutch smoothing" till the clutch accumulative slippage amount reaches 0 when the clutch is turned OFF. The status will change to "FALSE: Not on clutch smoothing" when the clutch accumulative slippage amount reaches 0.

■Main shaft clutch slippage (accumulative) (AdvOutputName.Md.Clutch.MasterCumulativeSlippage)

The accumulative slippage amount with the slippage method is stored as a signed value.

The absolute value of the accumulative slippage increases to reach the slippage at clutch ON during clutch ON.

The absolute value of the accumulative slippage decreases to reach "0.0" during clutch OFF.

Monitoring of the accumulative slippage is used to check the smoothing progress with the slippage method.

Clutch control data of output axis control data (AdvOutputName.Cd.Clutch.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterCommand	Main shaft clutch command	Operation cycle (FB is starting)	BOOL	FALSE: Clutch command OFF TRUE: Clutch command ON	FALSE
MasterInvalidCommand	Main shaft clutch control invalid command		BOOL	FALSE: Clutch control valid TRUE: Clutch control invalid	FALSE
MasterForcedOff	Main shaft clutch forced OFF command		BOOL	FALSE: Clutch normal control TRUE: Clutch forced OFF	FALSE
MasterClutchSmoothing TimeConstant	Main shaft clutch smoothing time constant change value	At start	INT	0 to 5000 [ms]	0

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Main shaft clutch command (AdvOutputName.Cd.Clutch.MasterCommand)

Sets ON/OFF for the main shaft clutch command.

This command is used when any of the following is set in the Main shaft clutch ON control setting

(AdvOutputName.Pr.Clutch.MasterOnControl).

- 1: Clutch command (ClutchCommand)
- 2: Clutch command leading edge (ClutchLeadingEdge)
- 3: Clutch command trailing edge (ClutchTrailingEdge)

Status is considered as clutch command OFF just before starting synchronous control. If synchronous control is started while the clutch command is ON, the condition is established just after starting synchronous control, by setting "2: Clutch command leading edge (ClutchLeadingEdge)". The condition is not established just after starting, by setting "3: Clutch command trailing edge (ClutchTrailingEdge)".

■Main shaft clutch control invalid command (AdvOutputName.Cd.Clutch.MasterInvalidCommand)

The main shaft clutch control is invalid if "TRUE: Clutch control invalid" is set. The previous clutch ON/OFF status remains before clutch control becomes invalid.

Clutch control will not become invalid during movement before clutch ON and during movement before clutch OFF. Instead, clutch control will become invalid after movement is completed.

■Main shaft clutch forced OFF command (AdvOutputName.Cd.Clutch.MasterForcedOff)

Set "TRUE: Clutch forced OFF" to force the clutch OFF. The output value from the clutch becomes "0" immediately, even during clutch smoothing. The slippage (accumulative) amount is set to 0 if smoothing with a slippage method.

Reset to "FALSE: Clutch normal control" to restart the clutch control from the clutch OFF status after using the clutch forced OFF command.

■Main shaft clutch smoothing time constant change value (AdvOutputName.Cd.Clutch.MasterClutchSmoothingTimeConstant)

The smoothing time constant of the main shaft clutch is changed. The setting is imported when MCv_AdvancedSync (Advanced Synchronous Control) is started.

Setting value	Description
When a negative value is set	No smoothing.
When 0 is set	Smoothing based on the setting value of the Main shaft clutch smoothing time constant (<u>AdvOutPutName.PrConst.MasterClutchSmoothingTimeConstant</u>).
When a positive value is set	Smoothing based on the setting value of the Main shaft clutch smoothing time constant change value (<u>AdvOutPutName.Cd.Clutch.MasterClutchSmoothingTimeConstant</u>).

Set within the following setting range.

If the set value exceeds the range below, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs, and smoothing is executed based on the setting value of the Main shaft clutch smoothing time constant (AdvOutPutName.PrConst.MasterClutchSmoothingTimeConstant).

Setting range
Main shaft clutch smoothing time constant (<u>AdvOutPutName.PrConst.MasterClutchSmoothingTimeConstant</u>) > Main shaft clutch smoothing time constant change value (<u>AdvOutPutName.Cd.Clutch.MasterClutchSmoothingTimeConstant</u>)

Auxiliary shaft module

The auxiliary shaft modules transmit the movement amount inputted from an input axis to the output axis.

The functions for an auxiliary shaft module include gears, clutches, and speed change gears.


The auxiliary shaft module corresponds to the axis set in Auxiliary shaft object (AdvOutputName.Pr.AuxAxis).

Refer to the following for the setting items for gears, clutches, and speed change gears of the auxiliary shaft module.

Function	Member	Variable	Reference
Gear	Output axis parameters (<u>AdvOutputName.Pr.</u>)	Gear parameter (Gear.)	☞ Page 601 Gear parameter of output axis parameters (<u>AdvOutputName.Pr.Gear.</u>)
Clutch	Output axis parameters constant (<u>AdvOutputName.PrConst.</u>)	—	☞ Page 602 Output axis parameters constant (<u>AdvOutputName.PrConst.</u>)
	Output axis parameters (<u>AdvOutputName.Pr.</u>)	—	☞ Page 602 Output axis parameters (<u>AdvOutputName.Pr.</u>)
		Clutch parameter (Clutch.)	☞ Page 604 Clutch parameter of output axis parameters (<u>AdvOutputName.Pr.Clutch.</u>)
	Output axis monitor data (<u>AdvOutputName.Md.</u>)	Clutch monitor (Clutch.)	☞ Page 609 Clutch monitor of output axis monitor data (<u>AdvOutputName.Md.Clutch.</u>)
	Output axis control data (<u>AdvOutputName.Cd.</u>)	Clutch control data (Clutch.)	☞ Page 610 Clutch control data of output axis monitor data (<u>AdvOutputName.Cd.Clutch.</u>)
Speed change gear	Output axis parameters constant (<u>AdvOutputName.PrConst.</u>)	—	☞ Page 626 Output axis parameters constant (<u>AdvOutputName.PrConst.</u>)
	Speed change gear parameter of output axis parameters (<u>AdvOutputName.Pr.SpeedChangeGear.</u>)	Speed change gear parameter (SpeedChangeGear.)	☞ Page 625 Speed change gear parameter of output axis parameters (<u>AdvOutputName.Pr.SpeedChangeGear.</u>)
	Speed change gear control data of output axis parameters (<u>AdvOutputName.Cd.SpeedChangeGear.</u>)	Speed change gear control data (SpeedChangeGear.)	☞ Page 626 Speed change gear control data of output axis parameters (<u>AdvOutputName.Cd.SpeedChangeGear.</u>)

• Auxiliary shaft module

The input value is generated from the auxiliary shaft. The input value can be converted by the auxiliary shaft gear to a value taking into account the deceleration ratio, rotation direction, etc. for the machine system.



*1 Clutch (☞ Page 611 Clutch)

*2 Speed change gear (☞ Page 624 Speed change gear)

Gear parameter of output axis parameters (AdvOutputName.Pr.Gear.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
AuxCompositeGear	Composite auxiliary shaft gear	Operation cycle (FB is starting)	WORD(HEX)	<div> <div>H□□□□</div> <div> → Main shaft input method 0: No input 1: Input + 2: Input - </div> <div> → Auxiliary shaft input method 0: No input 1: Input + 2: Input - </div> </div>	0001H
AuxNumerator	Auxiliary shaft gear: Numerator	At start	DINT	-2147483647 to 2147483647	1
AuxDenominator	Auxiliary shaft gear: Denominator		DWORD(UDINT)	1 to 2147483647	1

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Composite auxiliary shaft gear (AdvOutputName.Pr.Gear.AuxCompositeGear)

Set the composite method for the current position after the main shaft and sub input axis composition and the current position of the auxiliary shaft.

Setting value	Description
0: No input	The input value from the input axis is calculated as 0.
1: Input +	The input value from the input axis is calculated as it is.
2: Input -	The input value from the input axis is calculated with its opposite sign.

Operation assumes "0: No input" if the value is set out of the range from 0 to 2.



The composite method for the composite auxiliary shaft gear can be changed during synchronous control. It can also be used as a clutch to switch input values of the main shaft and auxiliary shafts.

■Auxiliary shaft gear: Numerator (AdvOutputName.Pr.Gear.AuxNumerator)

Set the numerator for the auxiliary shaft gear input value conversion.

The input value is converted as follows.

$$\text{Input value after conversion} = \text{Input value before conversion} \times \frac{\text{Auxiliary shaft gear: Numerator}}{\text{Auxiliary shaft gear: Denominator}}$$

The input value direction can be reversed by setting a negative value in Auxiliary shaft gear: Numerator.



Setting a reduced fraction is recommended for "Auxiliary shaft gear: Numerator/Auxiliary shaft gear: Denominator".

■Auxiliary shaft gear: Denominator (AdvOutputName.Pr.Gear.AuxDenominator)

Set the denominator for the auxiliary shaft input value conversion.

Set together with Auxiliary shaft gear: Numerator.

Output axis parameters constant (AdvOutputName.PrConst.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
AuxClutchSmoothingTimeConstant	Auxiliary shaft clutch smoothing time constant	At system start	WORD(UINT)	0 to 5000 [ms]	0 [ms]

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Auxiliary shaft clutch smoothing time constant

(AdvOutputName.PrConst.AuxClutchSmoothingTimeConstant)

Set a time constant when the time constant method is set to "1: Time constant method (Exponent) (TimeConstantExponent)" or "2: Time constant method (Linear) (TimeConstantLinear)" in the Auxiliary shaft clutch smoothing method

(AdvOutputName.Pr.Clutch.AuxSmoothingMethod).

The time constant setting applies for both clutch ON/ OFF.

Output axis parameters (AdvOutputName.Pr.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
AuxOnClutchSignal	Auxiliary shaft clutch ON signal setting	At system start	SIGNAL_SELECT	—	—
AuxOffClutchSignal	Auxiliary shaft clutch OFF signal setting			—	—

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Auxiliary shaft clutch ON signal setting (AdvOutputName.Pr.AuxOnClutchSignal)

Set the variable and device used as the clutch external signal in SIGNAL_SELECT structure when the Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl) is set to "15: I/O data specification (ClutchSignal)".

For SIGNAL_SELECT structure, refer to the following.

Page 426 SIGNAL_SELECT structure

The following shows the settings peculiar to Auxiliary shaft clutch ON signal setting (AdvOutputName.Pr.AuxOnClutchSignal).

Structure	Variable name	Type	Setting range
SIGNAL_SELECT (Signal Select)	Source (Signal)	TARGET_REF	■Type • BOOL ■Data type • [OBJ] • [VAR] • [DEV]
	Detection (Signal detection method)	INT (MC_SIGNAL_LOGIC)	• 2: Detection at FALSE → TRUE (rising edge) (RisingEdge) • 3: Detection at TRUE → FALSE (falling edge) (FallingEdge) • 4: Detection at rising edge/falling edge (BothEdges)
	CompensationTime (Compensation time)	LREAL	-5.0 to 5.0 [s]
	FilterTime (Filter time)	LREAL	0.0 [s]



When setting [OBJ] for Target (Source.Target), start MCv_AdvancedSync (Advanced Synchronous Control) after the communication with device stations is established. If the communication is not established, "External Signal String Incorrect" (error code: 1AB6H) occurs.

■Auxiliary shaft clutch OFF signal setting (AdvOutputName.Pr.AuxOffClutchSignal)

Set the variable and device used as the clutch external signal in SIGNAL_SELECT structure when the Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl) is set to "15: I/O data specification (ClutchSignal)".

For SIGNAL_SELECT structure, refer to the following.

🔑 Page 426 SIGNAL_SELECT structure

The following shows the settings peculiar to Auxiliary shaft clutch OFF signal setting (AdvOutputName.Pr.AuxOffClutchSignal).

Structure	Variable name	Type	Setting range
SIGNAL_SELECT (Signal Select)	Source (Signal)	TARGET_REF	■Type • BOOL ■Data type • [OBJ] • [VAR] • [DEV]
	Detection (Signal detection method)	INT (MC_SIGNAL_LOGIC)	• 2: Detection at FALSE → TRUE (rising edge) (RisingEdge) • 3: Detection at TRUE → FALSE (falling edge) (FallingEdge) • 4: Detection at rising edge/falling edge (BothEdges)
	CompensationTime (Compensation time)	LREAL	-5.0 to 5.0 [s]
	FilterTime (Filter time)	LREAL	0.0 [s]

Point

When setting [OBJ] for Target (Source.Target), start MCv_AdvancedSync (Advanced Synchronous Control) after the communication with device stations is established. If the communication is not established, "External Signal String Incorrect" (error code: 1AB6H) occurs.

Clutch parameter of output axis parameters (AdvOutputName.Pr.Clutch.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
AuxOnControl	Auxiliary shaft clutch ON control setting	Operation cycle (FB is starting)	INT (MC_CLUTCH_METHOD)	0: Invalid (NoClutch) (Direct coupled operation) 1: Clutch command (ClutchCommand) 2: Clutch command leading edge (ClutchLeadingEdge) 3: Clutch command trailing edge (ClutchTrailingEdge) 4: Address mode (ClutchAddress) 15: I/O data specification (ClutchSignal)	0: Invalid (NoClutch)
AuxOffControl	Auxiliary shaft clutch OFF control setting		INT (MC_CLUTCH_METHOD)	0: Invalid (NoClutch) (OFF control invalid) 1: Clutch command (ClutchCommand) (One-shot operation) 2: Clutch command leading edge (ClutchLeadingEdge) 3: Clutch command trailing edge (ClutchTrailingEdge) 4: Address mode (ClutchAddress) 15: I/O data specification (ClutchSignal)	0: Invalid (NoClutch)
AuxReference	Auxiliary shaft clutch reference address setting	At start	INT (MC_CLUTCH_REFERENCE)	0: Current position before gear (GearFrontPosition) 1: Current position per cycle after gear (GearPositionPerCycle)	0: Current position before gear (GearFrontPosition)
AuxOnAddress	Auxiliary shaft clutch ON address	Operation cycle (FB is starting)	LREAL	-10000000000.0 to 10000000000.0	0.0
AuxMovementAmountBeforeOn	Movement amount before auxiliary shaft clutch ON	At completing clutch ON condition	LREAL	-2147483648.0 to 2147483647.0	0.0
AuxOffAddress	Auxiliary shaft clutch OFF address	Operation cycle (FB is starting)	LREAL	-10000000000.0 to 10000000000.0	0.0
AuxMovementAmountBeforeOff	Movement amount before auxiliary shaft clutch OFF	At completing clutch ON condition	LREAL	-2147483648.0 to 2147483647.0	0.0
AuxSmoothingMethod	Auxiliary shaft clutch smoothing method	At start	INT (MC_CLUTCH_SMOOTHING_METHOD)	0: Direct (ClutchSmoothingDisabled) 1: Time constant method (Exponent) (TimeConstantExponent) 2: Time constant method (Linear) (TimeConstantLinear) 3: Slippage method (Exponent) (SlippageExponent) 4: Slippage method (Linear) (SlippageLinear) 5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)	0: Direct (ClutchSmoothingDisabled)
AuxOnSlippageAmount	Slippage amount at auxiliary shaft clutch ON	At turning clutch ON	LREAL	0.0 to 2147483647.0	0.0
AuxOffSlippageAmount	Slippage amount at auxiliary shaft clutch OFF	At turning clutch OFF	LREAL	0.0 to 2147483647.0	0.0

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl)

Set the control method for auxiliary shaft clutch ON.

The Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl) can be changed during synchronous control. However, changes from settings other than "0: Invalid (NoClutch)" to "0: Invalid (NoClutch)" are not possible.

Setting value	Description
0: Invalid (NoClutch) (Direct coupled operation)	Execute direct coupled operation without clutch control.
1: Clutch command (ClutchCommand)	The clutch is turned ON/OFF by the operations of the Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>) TRUE/FALSE. (Setting in the Auxiliary shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.AuxOffControl</u>) is not applicable in the clutch command ON/OFF mode.)
2: Clutch command leading edge (ClutchLeadingEdge)	The clutch is turned ON when the Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>) passes the leading edge (from FALSE to TRUE).
3: Clutch command trailing edge (ClutchTrailingEdge)	The clutch is turned ON when the Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>) passes the trailing edge (from TRUE to FALSE).
4: Address mode (ClutchAddress)	The clutch is turned ON when the reference address (the cumulative current position of the auxiliary shaft or the current position per cycle after auxiliary shaft gear) reaches the Auxiliary shaft clutch ON address (<u>AdvOutputName.Pr.Clutch.AuxOnAddress</u>). The movement amount after passing through the ON address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
15: I/O data specification (ClutchSignal)	The clutch is turned ON when the external input signal set in the Auxiliary shaft clutch ON signal setting (<u>AdvOutputName.Pr.AuxOnClutchSignal</u>) is detected.

Point

- Other clutch parameters are not applicable during direct coupled operation by setting the Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl) to "0: Invalid (NoClutch)".
The Auxiliary shaft clutch forced OFF command (AdvOutputName.Cd.Clutch.AuxForcedOff) and the change of the clutch control setting are ignored during direct coupled operation.
- Changes from settings other than "0: Invalid (NoClutch)" to "0: Invalid (NoClutch)" are not possible.
If the setting is changed in that manner, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs.

■Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl)

Set the control method for auxiliary shaft clutch OFF.

Setting value	Description
0: Invalid (NoClutch) (OFF control invalid)	Clutch OFF control is not used. This setting is applicable only for execution with clutch ON control.
1: Clutch command (ClutchCommand) (One-shot operation)	The clutch is turned OFF after moving the distance set in the Movement amount before auxiliary shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOff</u>) (One-shot operation) after the Auxiliary shaft clutch ON/OFF status turns ON. If the Movement amount before auxiliary shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOff</u>) is "0.0", the Auxiliary shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.AuxOnOffStatus</u>) does not turn to "TRUE (Clutch ON status)" in order to turn back OFF immediately.
2: Clutch command leading edge (ClutchLeadingEdge)	The clutch is turned OFF when the Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>) passes the leading edge (from FALSE to TRUE).
3: Clutch command trailing edge (ClutchTrailingEdge)	The clutch is turned OFF when the Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>) passes the trailing edge (from TRUE to FALSE).
4: Address mode (ClutchAddress)	The clutch is turned OFF when the reference address (the cumulative current position of the auxiliary shaft or the current position per cycle after auxiliary shaft gear) reaches the Auxiliary shaft clutch OFF address (<u>AdvOutputName.Pr.Clutch.AuxOffAddress</u>). The movement amount after passing through the OFF address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
15: I/O data specification (ClutchSignal)	The clutch is turned OFF when the external input signal set in the Auxiliary shaft clutch OFF signal setting (<u>AdvOutputName.Pr.AuxOffClutchSignal</u>) is detected.

■Auxiliary shaft clutch reference address setting (AdvOutputName.Pr.Clutch.AuxReference)

Select the address type to be used as the reference address for clutch control.

Note that the processing order of gears and clutches varies by the reference address.

Setting value	Description
0: Current position before gear (GearFrontPosition)	The clutch is controlled by using the input axis cumulative current position set in auxiliary shaft, which is before the auxiliary shaft gear conversion. The movement amount after the clutch control is converted then output through the auxiliary shaft gear. *: The clutch processing is performed for the current position of auxiliary shaft. The current position of auxiliary shaft is used as the reference address when the Auxiliary shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.AuxOffControl</u>) is set to "4: Address mode (ClutchAddress)".
1: Current position per cycle after gear (GearPositionPerCycle)	The clutch is controlled by using the current position per cycle after auxiliary shaft gear. Output after the auxiliary shaft clutch control is movement amount without conversion. *: The clutch processing is performed for the current position per cycle after auxiliary shaft gear. The current position per cycle after auxiliary shaft gear is used as the reference address when the Auxiliary shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.AuxOffControl</u>) is set to "4: Address mode (ClutchAddress)".

The unit settings of the following parameters are in position command units of the auxiliary shaft.

- Auxiliary shaft clutch ON address (AdvOutputName.Pr.Clutch.AuxOnAddress)
- Auxiliary shaft clutch OFF address (AdvOutputName.Pr.Clutch.AuxOffAddress)
- Movement amount before auxiliary shaft clutch ON (AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOn)
- Movement amount before auxiliary shaft clutch OFF (AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOff)
- Slippage amount at auxiliary shaft clutch ON (AdvOutputName.Pr.Clutch.AuxOnSlippageAmount)
- Slippage amount at auxiliary shaft clutch OFF (AdvOutputName.Pr.Clutch.AuxOffSlippageAmount)

■Auxiliary shaft clutch ON address (AdvOutputName.Pr.Clutch.AuxOnAddress)

Set the clutch ON address when "4: Address mode (ClutchAddress)" is set in the Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl).

When "1: Current position per cycle after gear (GearPositionPerCycle)" is set in the Auxiliary shaft clutch reference address setting (AdvOutputName.Pr.Clutch.AuxReference), the setting address is converted for control within the range from 0.0 to (length per cycle - 0.00001).

Setting value
-10000000000.0 ≤ Auxiliary shaft clutch ON address (<u>AdvOutputName.Pr.Clutch.AuxOnAddress</u>) < 10000000000.0

Ex.


Length per cycle: 20000.0

The ON address is controlled as "19000.0" when the setting value is "-1000.0".

■ Movement amount before auxiliary shaft clutch ON (AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOn)

Set the movement amount for the reference address with a signed number for the distance between the clutch ON condition completing and the clutch closing.

Setting value	Description
0.00001 to 2147483647.0 (Positive value)	Used when the reference address is increasing in direction.
0.0	No movement (The clutch is immediately turned ON with the clutch ON condition completing.)
-2147483648.0 to -0.00001 (Negative value)	Used when the reference address is decreasing in direction.



■ Auxiliary shaft clutch OFF address (AdvOutputName.Pr.Clutch.AuxOffAddress)

Set the clutch OFF address when "4: Address mode (ClutchAddress)" is set in the Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl).

When "1: Current position per cycle after gear (GearPositionPerCycle)" is set in the Auxiliary shaft clutch reference address setting (AdvOutputName.Pr.Clutch.AuxReference), the setting address is converted for control within the range from "0.0 to (length per cycle - 0.00001)".

Setting value
$-10000000000.0 \leq \text{Auxiliary shaft clutch OFF address } (\text{AdvOutputName.Pr.Clutch.AuxOffAddress}) < 10000000000.0$

Ex.


Length per cycle: 20000.0

The OFF address is controlled as "60.0" when the setting value is "40060.0".

■ Movement amount before auxiliary shaft clutch OFF (AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOff)

Set the movement amount for the reference address with a signed number for the distance between the clutch OFF condition completing and the clutch opening.

Setting value	Description
0.00001 to 2147483647.0 (Positive value)	Used when the reference address is increasing in direction.
0.0	No movement (The clutch is immediately turned OFF with the clutch OFF condition completing.)
-2147483648.0 to -0.00001 (Negative value)	Used when the reference address is decreasing in direction.



■Auxiliary shaft clutch smoothing method (AdvOutputName.Pr.Clutch.AuxSmoothingMethod)

Set the smoothing method for clutch ON/OFF.

Setting value	Description
0: Direct (ClutchSmoothingDisabled)	No smoothing.
1: Time constant method (Exponent) (TimeConstantExponent)	Smoothing with an exponential curve based on the time constant setting.
2: Time constant method (Linear) (TimeConstantLinear)	Smoothing with linear acceleration/deceleration based on the time constant setting.
3: Slippage method (Exponent) (SlippageExponent)	Smoothing with an exponential curve based on the slippage amount setting.
4: Slippage method (Linear) (SlippageLinear)	Smoothing with linear acceleration/deceleration based on the slippage amount setting.
5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)	Smoothing with linear acceleration/deceleration (input value follow up) based on the slippage amount setting.

■Slippage amount at auxiliary shaft clutch ON (AdvOutputName.Pr.Clutch.AuxOnSlippageAmount)

Set the slippage amount at clutch ON when any of the following is set in the Auxiliary shaft clutch smoothing method (AdvOutputName.Pr.Clutch.AuxSmoothingMethod).

- "3: Slippage method (Exponent) (SlippageExponent)"
- "4: Slippage method (Linear) (SlippageLinear) (SlippageLinear)"
- "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)"

The slippage amount is set in units based on the setting in the Auxiliary shaft clutch reference address setting (AdvOutputName.Pr.Clutch.AuxReference).

If the set amount is negative, slippage amount at clutch ON is controlled as 0 (direct).

Point

Do not set digits after the decimal point when "3: Slippage method (Exponent) (SlippageExponent)" is set in the Auxiliary shaft clutch smoothing method (AdvOutputName.Pr.Clutch.AuxSmoothingMethod).
If set, smoothing is performed with the digits after the decimal point ignored.

■Slippage amount at auxiliary shaft clutch OFF (AdvOutputName.Pr.Clutch.AuxOffSlippageAmount)

Set the slippage amount at clutch OFF when any of the following is set in the Auxiliary shaft clutch smoothing method (AdvOutputName.Pr.Clutch.AuxSmoothingMethod).

- "3: Slippage method (Exponent) (SlippageExponent)"
- "4: Slippage method (Linear) (SlippageLinear) (SlippageLinear)"
- "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)"

The slippage amount is set in units based on the setting in the Auxiliary shaft clutch reference address setting (AdvOutputName.Pr.Clutch.AuxReference).

If the set amount is negative, slippage amount at clutch ON is controlled as 0 (direct).

Point

Do not set digits after the decimal point when "3: Slippage method (Exponent) (SlippageExponent)" is set in the Auxiliary shaft clutch smoothing method (AdvOutputName.Pr.Clutch.AuxSmoothingMethod).
If set, smoothing is performed with the digits after the decimal point ignored.

Clutch monitor of output axis monitor data (AdvOutputName.Md.Clutch.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value
AuxOnOffStatus	Auxiliary shaft clutch ON/OFF status	Operation cycle (FB is starting)	BOOL	FALSE: Clutch OFF status TRUE: Clutch ON status
AuxSmoothingStatus	Auxiliary shaft clutch smoothing status		BOOL	FALSE: Not on clutch smoothing TRUE: On clutch smoothing
AuxCumulativeSlippage	Auxiliary shaft clutch slippage (accumulative)		LREAL	-2147483648.0 to 2147483647.0

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Auxiliary shaft clutch ON/OFF status (AdvOutputName.Md.Clutch.AuxOnOffStatus)

The auxiliary shaft clutch ON/OFF status is stored.

■Auxiliary shaft clutch smoothing status (AdvOutputName.Md.Clutch.AuxSmoothingStatus)

The smoothing status of the auxiliary shaft clutch is stored.

The status is updated by the Auxiliary shaft clutch smoothing method (AdvOutputName.Pr.Clutch.AuxSmoothingMethod).

Method	Description
Time constant method	The status is always "TRUE: On clutch smoothing" during the clutch ON status. The status will be "FALSE: Not on clutch smoothing" when the clutch is turned OFF and smoothing is completed.
Slippage method	The status is "TRUE: On clutch smoothing" till the clutch accumulative slippage amount reaches the slippage at clutch ON when the clutch is turned ON. The status will change to "FALSE: Not on clutch smoothing" when the clutch accumulative slippage amount reaches the slippage at clutch ON. The status is "TRUE: On clutch smoothing" till the clutch accumulative slippage amount reaches 0 when the clutch is turned OFF. The status will change to "FALSE: Not on clutch smoothing" when the clutch accumulative slippage amount reaches 0.

■Auxiliary shaft clutch slippage (accumulative) (AdvOutputName.Md.Clutch.AuxCumulativeSlippage)

The accumulative slippage amount with the slippage method is stored as a signed value.

The absolute value of the accumulative slippage increases to reach the slippage at clutch ON during clutch ON.

The absolute value of the accumulative slippage decreases to reach "0.0" during clutch OFF.

Monitoring of the accumulative slippage is used to check the smoothing progress with the slippage method.

Clutch control data of output axis monitor data (AdvOutputName.Cd.Clutch.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
AuxCommand	Auxiliary shaft clutch command	Operation cycle (FB is starting)	BOOL	FALSE: Clutch command OFF TRUE: Clutch command ON	FALSE
AuxInvalidCommand	Auxiliary shaft clutch control invalid command		BOOL	FALSE: Clutch control valid TRUE: Clutch control invalid	FALSE
AuxForcedOff	Auxiliary shaft clutch forced OFF command		BOOL	FALSE: Clutch normal control TRUE: Clutch forced OFF	FALSE
AuxClutchSmoothingTimeConstant	Auxiliary shaft clutch smoothing time constant change value	At start	INT	0 to 5000 [ms]	0

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Auxiliary shaft clutch command (AdvOutputName.Cd.Clutch.AuxCommand)

Sets ON/OFF for the auxiliary shaft clutch command.

This command is used when any of the following is set in the Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl).

- 1: Clutch command (ClutchCommand)
- 2: Clutch command leading edge (ClutchLeadingEdge)
- 3: Clutch command trailing edge (ClutchTrailingEdge)

Status is considered as clutch command OFF just before starting synchronous control. If synchronous control is started while the clutch command is ON, the condition is established just after starting synchronous control, by setting "2: Clutch command leading edge (ClutchLeadingEdge)". The condition is not established just after starting, by setting "3: Clutch command trailing edge (ClutchTrailingEdge)".

■Auxiliary shaft clutch control invalid command (AdvOutputName.Cd.Clutch.AuxInvalidCommand)

The auxiliary shaft clutch control is invalid if "TRUE: Clutch control invalid" is set. The previous clutch ON/OFF status remains before clutch control becomes invalid.

Clutch control will not become invalid during movement before clutch ON and during movement before clutch OFF. Instead, clutch control will become invalid after movement is completed.

■Auxiliary shaft clutch forced OFF command (AdvOutputName.Cd.Clutch.AuxForcedOff)

Set "TRUE: Clutch forced OFF" to force the clutch OFF. The output value from the clutch becomes "0" immediately, even during clutch smoothing. The slippage (accumulative) amount is set to 0 if smoothing with a slippage method.

Reset to "FALSE: Clutch normal control" to restart the clutch control from the clutch OFF status after using the clutch forced OFF command.

■Auxiliary shaft clutch smoothing time constant change value (AdvOutputName.Cd.Clutch.AuxClutchSmoothingTimeConstant)

The smoothing time constant of the auxiliary shaft clutch is changed. The setting is imported when MCv_AdvancedSync (Advanced Synchronous Control) is started.

Setting value	Description
When a negative value is set	No smoothing.
When 0 is set	Smoothing based on the setting value of the Auxiliary shaft clutch smoothing time constant (<u>AdvOutputName.PrConst.AuxClutchSmoothingTimeConstant</u>).
When a positive value is set	Smoothing based on the setting value of the Auxiliary shaft clutch smoothing time constant change value (<u>AdvOutputName.Cd.Clutch.AuxClutchSmoothingTimeConstant</u>).

Set within the following setting range.


If the set value exceeds the range below, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs, and smoothing is executed based on the setting value of the Auxiliary shaft clutch smoothing time constant (AdvOutputName.PrConst.AuxClutchSmoothingTimeConstant).

Setting range
Auxiliary shaft clutch smoothing time constant (<u>AdvOutputName.PrConst.AuxClutchSmoothingTimeConstant</u>) > Auxiliary shaft clutch smoothing time constant change value (<u>AdvOutputName.Cd.Clutch.AuxClutchSmoothingTimeConstant</u>)

Clutch

The clutch is used to transmit/disengage command pulses from the main/auxiliary shaft input through turning the clutch ON/OFF, which controls the operation/stop of the output axis.

A clutch can be configured for the main and auxiliary shafts.



The clutch status is changed from FALSE to TRUE based on the conditions set in the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) and Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl), and changed from TRUE to FALSE based on the conditions of the Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl) and Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl).

The current position of the input axis is transmitted to the output axis at the timing of the clutch ON/OFF status changing to TRUE.

The input and output axes are disengaged at the timing of the clutch ON/OFF status turning to FALSE.

The following describes the operations of clutch ON/OFF.

Ex.


When the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) is set to "1: Clutch command (ClutchCommand)"

Main shaft clutch command
(AdvOutputName.Cd.Clutch.MasterCommand)

Main shaft clutch ON/OFF status
(AdvOutputName.Md.Clutch.MasterOnOffStatus)

Current value before clutch

Movement amount after clutch



The movement amount of the output axis before clutch ON and OFF can be adjusted with parameters of the movement amount before clutch ON or the movement amount before clutch OFF.

The smoothing time constant can be set to smooth the operation of the output axis before and after clutch ON/OFF.

Clutch control setting

Set the clutch ON and OFF control methods separately. Set the ON control methods in Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) and Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl), and the clutch OFF control methods in Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl) and Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl).

The clutch control setting can be changed during synchronous control. However, changes from settings other than "0: Invalid (NoClutch) (Direct coupled operation)" to "0: Invalid (NoClutch) (Direct coupled operation)" are not possible in the ON control mode.

Item	Setting item		Setting value
	Main shaft clutch	Auxiliary shaft clutch	
Clutch ON control setting	Main shaft clutch ON control setting (<u>AdvOutputName.Pr.Clutch.MasterOnControl</u>)	Auxiliary shaft clutch ON control setting (<u>AdvOutputName.Pr.Clutch.AuxOnControl</u>)	0: Invalid (NoClutch) (Direct coupled operation) 1: Clutch command (ClutchCommand) 2: Clutch command leading edge (ClutchLeadingEdge) 3: Clutch command trailing edge (ClutchTrailingEdge) 4: Address mode (ClutchAddress) 15: I/O data specification (ClutchSignal)
Clutch OFF control setting	Main shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.MasterOffControl</u>)	Auxiliary shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.AuxOffControl</u>)	0: Invalid (NoClutch) (OFF control invalid) 1: Clutch command (ClutchCommand) (One-shot operation) 2: Clutch command leading edge (ClutchLeadingEdge) 3: Clutch command trailing edge (ClutchTrailingEdge) 4: Address mode (ClutchAddress) 15: I/O data specification (ClutchSignal)

When the clutch ON condition and the clutch OFF condition are completed simultaneously within one operation cycle, both clutch ON and OFF processing are executed within one operation cycle. Therefore, the clutch changes from OFF to ON and again to OFF at the clutch OFF status, and changes from ON to OFF and again to ON at the clutch ON status.

The clutch ON/OFF operations for clutch ON and OFF control settings are shown below.

■Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl)/Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl)


- Invalid (Direct coupled operation)
Execute direct coupled operation without clutch control.

Point

- Other clutch parameters are not applicable during direct coupled operation by setting the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) and the Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl) to "0: Invalid (NoClutch) (Direct coupled operation)". The "clutch forced OFF command" and the change of the clutch control setting are ignored during direct coupled operation.
- Changes from settings other than "0: Invalid (NoClutch) (Direct coupled operation)" to "0: Invalid (NoClutch) (Direct coupled operation)" are not possible. If the setting is changed in that manner, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs.

- Clutch command


The clutch is turned ON/OFF by the TRUE/FALSE operation of "clutch command". (When "1: Clutch command (ClutchCommand)" is set in the Main shaft clutch ON control setting (AdvOutputName.Pr.Clutch.MasterOnControl) and the Auxiliary shaft clutch ON control setting (AdvOutputName.Pr.Clutch.AuxOnControl), the settings of the Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl) and the Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl) are not applicable.)



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch command	Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>)	Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>)
Clutch ON/OFF status	Main shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.MasterOnOffStatus</u>)	Auxiliary shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.AuxOnOffStatus</u>)


- Clutch command leading edge

The clutch is turned ON when the "clutch command" passes the leading edge (from FALSE to TRUE).




- Clutch command trailing edge

The clutch is turned ON when the "clutch command" passes the trailing edge (from TRUE to FALSE).



- Address mode

The clutch is turned ON when the "reference address" reaches "Clutch ON address". The movement amount after passing through the ON address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.




Item	Main shaft clutch	Auxiliary shaft clutch
Reference address	The current position specified in the Main shaft clutch reference address setting (<u>AdvOutputName.Pr.Clutch.MasterReference</u>) <ul style="list-style-type: none"> • 0: Current position before gear (<u>GearFrontPosition</u>)*¹ • 1: Current position per cycle after gear (<u>GearPositionPerCycle</u>)*² 	The current position specified in the Auxiliary shaft clutch reference address setting (<u>AdvOutputName.Pr.Clutch.AuxReference</u>) <ul style="list-style-type: none"> • 0: Current position before gear (<u>GearFrontPosition</u>)*³ • 1: Current position per cycle after gear (<u>GearPositionPerCycle</u>)*⁴
Clutch ON address	Main shaft clutch ON address (<u>AdvOutputName.Pr.Clutch.MasterOnAddress</u>)	Auxiliary shaft clutch ON address (<u>AdvOutputName.Pr.Clutch.AuxOnAddress</u>)
Clutch ON/OFF status	Main shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.MasterOnOffStatus</u>)	Auxiliary shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.AuxOnOffStatus</u>)

- *1 As a monitor, the Current position after composite main shaft gear (AdvOutputName.Md.Cam.MasterCompositeGearSetPosition) is referred to.
- *2 As a monitor, the Current position per cycle after main shaft gear (AdvOutputName.Md.Cam.MasterGearPositionPerCycle) is referred to.
- *3 As a monitor, the cumulative current position of the auxiliary shaft (the Cumulative current position (AdvOutputName.Md.CumulativePosition) of the input axis set in the auxiliary shaft) is referred to.
- *4 As a monitor, the Current position per cycle after auxiliary shaft gear (AdvOutputName.Md.Cam.AuxGearPositionPerCycle) is referred to.

- I/O data specification

The clutch is turned ON at an input signal detection.



When using an external signal, set the following clutch ON signal settings.

Item	Main shaft	Auxiliary shaft
Clutch ON signal setting	Main shaft clutch ON signal setting (<u>AdvOutputName.Pr.MasterOnClutchSignal</u>)	Auxiliary shaft clutch ON signal setting (<u>AdvOutputName.Pr.AuxOnClutchSignal</u>)

The type for the clutch ON signal setting is SIGNAL_SELECT (Signal Select). The setting range of the clutch ON signal setting is as follows.

Structure	Variable name	Type	Setting range ^{*1}
SIGNAL_SELECT (Signal Select)	Source (Signal). Target (Target)	TARGET_REF	■Type • BOOL ■Data type • [OBJ] ^{*2,3} • [VAR] • [DEV]
	Detection (Signal detection method)	INT (MC_SIGNAL_LOGIC)	• 2: Detection at FALSE → TRUE (rising edge) (RisingEdge) • 3: Detection at TRUE → FALSE (falling edge) (FallingEdge) • 4: Detection at rising edge/falling edge (BothEdges)
	CompensationTime (Compensation time) ^{*4}	LREAL	-5.0 to 5.0 [s]
	FilterTime (Filter time)	LREAL	0.0 [s]

*1 In the following cases, "Out of Parameter Range (Advanced Synchronous Control Output Axis)" (error code: 1D86H) occurs.

- The target modification is omitted when [OBJ] is specified as data type
- Source.Target is omitted or the target does not exist
- The set value in the Signal detection method (Detection), the Compensation time (CompensationTime), or the Filter time (FilterTime) out of range

*2 When the referred station has the axis emulate function enabled and also has a set station address, the emulating object will be referred.

*3 The external signal high-accuracy input is available. When using the external high-accuracy input, set the Detection (Signal detection method) to "4: Detection at rising edge/falling edge (BothEdges)". For details, refer to the following.

☞ Page 424 External Signal Selection


For the signals that can be used for external signal high-accuracy input, refer to the following.

☞ Page 431 External signal high-accuracy input

For the setting of the device stations for external signal high-accuracy input, refer to the following.

☞ Page 767 External signal high-accuracy input

*4 The detection time of an input signal can be compensated by setting the Compensation time (CompensationTime). Set a positive value to compensate the delay of the input signal, and set a negative value to compensate the lead. As shown below, the clutch ON/OFF status varies depending on the compensation time setting. When delay is compensated with the Compensation time (CompensationTime), the movement amount after clutch may change rapidly. Adjust so that the movement amount changes gradually with the smoothing function of the clutch and output axis.



■Main shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.MasterOffControl)/Auxiliary shaft clutch OFF control setting (AdvOutputName.Pr.Clutch.AuxOffControl)


- Invalid (OFF control invalid)

Clutch OFF control is not used. This setting is applicable only for execution with clutch ON control.

- Clutch command (One-shot operation)

The clutch is turned OFF after moving the distance "Movement amount before clutch OFF" after the "clutch ON/OFF status" changes from FALSE to TRUE.


If the "Movement amount before clutch OFF" is "0.0", the "Clutch ON/OFF status" does not turn ON in order to turn back OFF immediately.



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch command	Main shaft clutch command (<u>AdvOutputName.Cd.Clutch.MasterCommand</u>)	Auxiliary shaft clutch command (<u>AdvOutputName.Cd.Clutch.AuxCommand</u>)
Clutch ON/OFF status	Main shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.MasterOnOffStatus</u>)	Auxiliary shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.AuxOnOffStatus</u>)
Movement amount before clutch OFF	Movement amount before main shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOff</u>)	Movement amount before auxiliary shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.AuxMovementAmountBeforeOff</u>)


- Clutch command leading edge

The clutch is turned OFF when the "clutch command" passes the leading edge (from FALSE to TRUE).




- Clutch command trailing edge

The clutch is turned OFF when the "clutch command" passes the trailing edge (from TRUE to FALSE).



- Address mode

The clutch is turned OFF when the "reference address" reaches "Clutch OFF address". The movement amount before passing through the OFF address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.




Item	Main shaft clutch	Auxiliary shaft clutch
Reference address	The current position specified in the Main shaft clutch reference address setting (<u>AdvOutputName.Pr.Clutch.MasterReference</u>) <ul style="list-style-type: none"> • 0: Current position before gear (<u>GearFrontPosition</u>)*¹ • 1: Current position per cycle after gear (<u>GearPositionPerCycle</u>)*² 	The current position specified in the Auxiliary shaft clutch reference address setting (<u>AdvOutputName.Pr.Clutch.AuxReference</u>) <ul style="list-style-type: none"> • 0: Current position before gear (<u>GearFrontPosition</u>)*³ • 1: Current position per cycle after gear (<u>GearPositionPerCycle</u>)*⁴
Clutch OFF address	Main shaft clutch OFF address (<u>AdvOutputName.Pr.Clutch.MasterOffAddress</u>)	Auxiliary shaft clutch OFF address (<u>AdvOutputName.Pr.Clutch.AuxOffAddress</u>)
Clutch ON/OFF status	Main shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.MasterOnOffStatus</u>)	Auxiliary shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.AuxOnOffStatus</u>)

- *1 As a monitor, the Current position after composite main shaft gear (AdvOutputName.Md.Cam.MasterCompositeGearSetPosition) is referred to.
- *2 As a monitor, the Current position per cycle after main shaft gear (AdvOutputName.Md.Cam.MasterGearPositionPerCycle) is referred to.
- *3 As a monitor, the cumulative current position of the auxiliary shaft (the Cumulative current position (AdvInputName.Md.CumulativePosition) of the input axis set in the auxiliary shaft) is referred to.
- *4 As a monitor, the Current position per cycle after auxiliary shaft gear (AdvOutputName.Md.Cam.AuxGearPositionPerCycle) is referred to.

- I/O data specification

The clutch is turned OFF at an input signal detection.




When using an external signal for I/O data specification, set the following clutch OFF signal settings

Item	Main shaft clutch	Auxiliary shaft clutch
Clutch OFF signal setting	Main shaft clutch OFF signal setting (<u>AdvOutputName.PrConst.MasterOffClutchSignal</u>)	Auxiliary shaft clutch OFF signal setting (<u>AdvOutputName.PrConst.AuxOffClutchSignal</u>)

The type for the OFF clutch signal setting is SIGNAL_SELECT (Signal select). The setting range of the clutch signal setting is as follows.

Structure	Variable name	Type	Setting range ^{*1}
SIGNAL_SELECT (Signal Select)	Source (Signal)	TARGET_REF	■Type • BOOL ■Data type • [OBJ] ^{*2,3} • [VAR] • [DEV]
	Detection (Signal detection method)	INT (MC_SIGNAL_LOGIC)	• 2: Detection at FALSE → TRUE (rising edge) (RisingEdge) • 3: Detection at TRUE → FALSE (falling edge) (FallingEdge) • 4: Detection at rising edge/falling edge (BothEdges)
	CompensationTime (Compensation time) ^{*4}	LREAL	-5.0 to 5.0 [s]
	FilterTime (Filter time)	LREAL	0.0 [s]

- *1 In the following cases, "Out of Parameter Range (Advanced Synchronous Control Output Axis)" (error code: 1D86H) occurs.
- The target modification is omitted when [OBJ] is specified as data type
 - Source.Target is omitted or the target does not exist
 - The set value in the Signal detection method (Detection), the Compensation time (CompensationTime), or the Filter time (FilterTime) is out of range
- *2 When the referred station has the axis emulate function enabled and also has a set station address, the emulating object will be referred.
- *3 The external signal high-accuracy input is available. When using the external high-accuracy input, set the Detection (Signal detection method) to "4: Detection at rising edge/falling edge (BothEdges)". For details, refer to the following.
- ☞ Page 424 External Signal Selection
- For the high-accuracy input setting, refer to the following.
- ☞ Page 718 CONNECTABLE DEVICE to CC-Link IE TSN
- *4 The detection time of an input signal can be compensated by setting the Compensation time (CompensationTime). Set a positive value to compensate the delay of the input signal, and set a negative value to compensate the lead. As shown below, the clutch ON/OFF status varies depending on the compensation time setting. When delay is compensated with the Compensation time (CompensationTime), the movement amount after clutch may change rapidly. Adjust so that the movement amount changes gradually with the smoothing function of the clutch and output axis.



Smoothing method for clutch

Set the clutch smoothing method in Main shaft clutch smoothing method

(AdvOutputName.Pr.Clutch.MasterSmoothingMethod) and "Auxiliary shaft clutch smoothing method

(AdvOutputName.Pr.Clutch.AuxSmoothingMethod)".

The following two types of clutch smoothing are available.

- Time constant method smoothing
- Slippage method smoothing

When not using clutch smoothing, set "0: Direct" in the clutch smoothing method.

Item	Setting item		Setting value
	Main shaft clutch	Auxiliary shaft clutch	
Clutch smoothing method	Main shaft clutch smoothing method (<u>AdvOutputName.Pr.Clutch.MasterSmoothingMethod</u>)	Auxiliary shaft clutch smoothing method (<u>AdvOutputName.Pr.Clutch.AuxSmoothingMethod</u>)	0: Direct (ClutchSmoothingDisabled) 1: Time constant method (Exponent) (TimeConstantExponent) 2: Time constant method (Linear) (TimeConstantLinear) 3: Slippage method (Exponent) (SlippageExponent) 4: Slippage method (Linear) (SlippageLinear) 5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)

The operation of each smoothing method is shown below.

■Time constant method smoothing

Smoothing is executed with the time constant set in "smoothing time constant" at clutch ON/OFF. After clutch ON smoothing is complete, smoothing is executed with the time constant when the speed of the input value changes.


As shown below, the movement amount while the clutch changes from ON to OFF does not change after clutch smoothing.

Movement amount after clutch smoothing = Movement amount before clutch smoothing

Item	Setting item		Setting value
	Main shaft clutch	Auxiliary shaft clutch	
Clutch smoothing time constant	Main shaft clutch smoothing time constant (<u>AdvOutputName.PrConst.MasterClutchSmoothingTimeConstant</u>)	Auxiliary shaft clutch smoothing time constant (<u>AdvOutputName.PrConst.AuxClutchSmoothingTimeConstant</u>)	0 to 5000 [ms]

- Time constant method exponential curve smoothing


Set "1: Time constant method (Exponential) (TimeConstantExponent)" in the "clutch smoothing method".



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch ON/OFF status	Main shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.MasterOnOffStatus</u>)	Auxiliary shaft clutch ON/OFF status (<u>AdvOutputName.Md.Clutch.AuxOnOffStatus</u>)
Clutch smoothing status	Main shaft clutch smoothing status (<u>AdvOutputName.Md.Clutch.MasterSmoothingStatus</u>)	Auxiliary shaft clutch smoothing status (<u>AdvOutputName.Md.Clutch.AuxSmoothingStatus</u>)

- Time constant method linear acceleration/deceleration smoothing

Set "2: Time constant method (Linear) (TimeConstantLinear)" in the "clutch smoothing method".



■Slippage method smoothing

Smoothing is executed with the value in "slippage at clutch ON" when the clutch turns ON, and with "slippage at clutch OFF" when the clutch turns OFF.

Because smoothing is still executed with the set slippage amount when the input speed to the clutch changes, the position of clutch ON/OFF is not affected by speed changes and thus can be controlled.

A direct operation follows after completing clutch ON smoothing.

The movement amount while the clutch changes from ON to OFF is as follows after clutch smoothing.

Movement amount after clutch smoothing = Movement amount before clutch smoothing + (Slippage amount at OFF - Slippage amount at ON)


Item	Setting item		Setting value
	Main shaft clutch	Auxiliary shaft clutch	
Slippage amount at clutch ON	Slippage amount at main shaft clutch ON (AdvOutPutName.Pr.Clutch.MasterOnSlippageAmount)	Slippage amount at auxiliary shaft clutch ON (AdvOutPutName.Pr.Clutch.AuxOnSlippageAmount)	0 to 2147483647 [Main shaft position command units ^{*1} /auxiliary shaft position command units ^{*2}]
Slippage amount at clutch OFF	Slippage amount at main shaft clutch OFF (AdvOutPutName.Pr.Clutch.MasterOffSlippageAmount)	Slippage amount at auxiliary shaft clutch OFF (AdvOutPutName.Pr.Clutch.AuxOffSlippageAmount)	

*1 The position command unit of the axis set as the Auxiliary shaft object (AdvOutPutName.Pr.AuxAxis).

*2 position command unit of the axis set as the Auxiliary shaft object (AdvOutPutName.Pr.AuxAxis).

- Slippage method exponential curve smoothing

Set "3: Slippage method (Exponential) (SlippageExponent)" in the "clutch smoothing method".




Item	Main shaft clutch	Auxiliary shaft clutch
Clutch ON/OFF status	Main shaft clutch ON/OFF status (AdvOutPutName.Md.Clutch.MasterOnOffStatus)	Auxiliary shaft clutch ON/OFF status (AdvOutPutName.Md.Clutch.AuxOnOffStatus)
Clutch smoothing status	Main shaft clutch smoothing status (AdvOutPutName.Md.Clutch.MasterSmoothingStatus)	Auxiliary shaft clutch smoothing status (AdvOutPutName.Md.Clutch.AuxSmoothingStatus)

- Slippage method linear acceleration/deceleration smoothing
Set "4: Slippage method (Linear) (SlippageLinear)", or "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)" in the "clutch smoothing method".


Input speed during smoothing	Smoothing method	
	4: Slippage method (Linear) (SlippageLinear)	5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)
When input speed is fixed	No difference	
When there is a continuous small fluctuation in the input speed	The smoothing sections change.	The smoothing section is fixed.
When input speed has a large fluctuation	The change in the output speed is small. (The average speed may rise higher than before the start of smoothing)	The output speed changes with the input speed. (When re-accelerating after the input speed drops, a sudden acceleration may occur)

■When input speed is fixed
The operation for "4: Slippage method (Linear) (SlippageLinear)" and "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)" is the same.




■When there is a continuous small fluctuation in the input speed


- When "4: Slippage method (Linear) (SlippageLinear)" is set
The clutch smoothing status TRUE section changes with the fluctuation of the input speed.
- When the clutch smoothing status TRUE section is extended



- When the clutch smoothing status TRUE section is shortened




- When "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)" is set
The clutch smoothing status TRUE section is fixed.



■ When input speed has a large fluctuation


- When "4: Slippage method (Linear) SlippageLinear)" is set

The fluctuation in the output speed is smaller compared to the fluctuation in the input speed. (The average speed may rise higher than before the start of smoothing)




- When "5: Slippage method (Linear: Input value follow up) (SlippageLinearFollow)" is set

The output speed fluctuates with the input speed. (When re-accelerating after the input speed drops, a sudden acceleration may occur)



■Operation at input speed deceleration during slippage method smoothing

When the speed before clutch processing decreases, the speed after clutch smoothing is controlled to keep it from exceeding the speed before clutch processing. If slippage amount remains when the speed before clutch processing becomes "0.0", the smoothing process will continue. When the speed before clutch processing gets faster than the speed after clutch smoothing again, clutch smoothing will be executed for the remainder slippage amount.



Example of clutch use

For an example of clutch use, refer to the following.

☞ Page 681 Flying cutter

Speed change gear

A speed change gear is used to change the input speed from the main shaft, auxiliary shaft, composite auxiliary shaft gear during operation. One speed change gear can be set to a main shaft module, an auxiliary shaft module, and an output axis module respectively.

When not using a speed change gear, set "FALSE (Without speed change gear)".

Speed changes from a speed change gear are executed as linear acceleration/deceleration using the time set for the speed change gear smoothing time constant.

[Main shaft]

- Main shaft speed change gear valid setting (AdvOutPutName.Pr.SpeedChangeGear.MasterGearIn)
- Main shaft speed change gear smoothing time constant (AdvOutPutName.Pr.Const.MasterSpeedChangeGearSmoothingTimeConstant)
- Main shaft speed change ratio: Numerator (AdvOutPutName.Pr.SpeedChangeGear.MasterRatioNumerator)
- Main shaft speed change ratio: Denominator (AdvOutPutName.Pr.SpeedChangeGear.MasterRatioDenominator)


[Auxiliary shaft]

- Auxiliary shaft speed change gear valid setting (AdvOutPutName.Pr.SpeedChangeGear.AuxGearIn)
- Auxiliary shaft speed change gear smoothing time constant (AdvOutPutName.Pr.Const.AuxSpeedChangeGearSmoothingTimeConstant)
- Auxiliary shaft speed change ratio: Numerator (AdvOutPutName.Pr.SpeedChangeGear.AuxRatioNumerator)
- Auxiliary shaft speed change ratio: Denominator (AdvOutPutName.Pr.SpeedChangeGear.AuxRatioDenominator)


[Output axis]

- Output axis speed change gear valid setting (AdvOutPutName.Pr.SpeedChangeGear.OutGearIn)
- Output axis speed change gear smoothing time constant (AdvOutPutName.Pr.Const.OutSpeedChangeGearSmoothingTimeConstant)
- Output axis speed change ratio: Numerator (AdvOutPutName.Pr.SpeedChangeGear.OutRatioNumerator)
- Output axis speed change ratio: Denominator (AdvOutPutName.Pr.SpeedChangeGear.OutRatioDenominator)

Input value




Output value



Input values for speed change are processed as follows.

$$\text{Input value after conversion} = \text{Input value before conversion} \times \frac{\text{Speed change ratio: Numerator}}{\text{Speed change ratio: Denominator}}$$



Speed change gear parameter of output axis parameters (AdvOutputName.Pr.SpeedChangeGear.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterGearIn	Main shaft speed change gear valid setting	At start	BOOL	FALSE: Without speed change gear TRUE: With speed change gear	FALSE
MasterRatioNumerator	Main shaft speed change ratio: Numerator	Operation cycle (FB is starting)	DINT	-2147483647 to 2147483647	1
MasterRatioDenominator	Main shaft speed change ratio: Denominator		DWORD(UDINT)	1 to 2147483647	1
AuxGearIn	Auxiliary shaft speed change gear valid setting	At start	BOOL	FALSE: Without speed change gear TRUE: With speed change gear	FALSE
AuxRatioNumerator	Auxiliary shaft speed change ratio: Numerator	Operation cycle (FB is starting)	DINT	-2147483647 to 2147483647	1
AuxRatioDenominator	Auxiliary shaft speed change ratio: Denominator		DWORD(UDINT)	1 to 2147483647	1
OutGearIn	Output axis speed change gear valid setting	At start	BOOL	FALSE: Without speed change gear TRUE: With speed change gear	FALSE
OutRatioNumerator	Output axis speed change ratio: Numerator	Operation cycle (FB is starting)	DINT	-2147483647 to 2147483647	1
OutRatioDenominator	Output axis speed change ratio: Denominator		DWORD(UDINT)	1 to 2147483647	1

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Main shaft speed change gear valid setting

(AdvOutputName.Pr.SpeedChangeGear.MasterGearIn)/Auxiliary shaft speed change gear valid setting (AdvOutputName.Pr.SpeedChangeGear.AuxGearIn)/Output axis speed change gear valid setting (AdvOutputName.Pr.SpeedChangeGear.OutGearIn)

Set to whether to use or not use a speed change gear for each axis.

Setting value	Description
FALSE (Without speed change gear)	Speed change is not processed, and the input value is transmitted without conversion.
TRUE (With speed change gear)	Speed change is processed for the input value based on the speed change ratio settings.

■ Main shaft speed change ratio: Numerator

(AdvOutputName.Pr.SpeedChangeGear.MasterRatioNumerator)/Auxiliary shaft speed change ratio: Numerator (AdvOutputName.Pr.SpeedChangeGear.AuxRatioNumerator)/Output axis speed change ratio: Numerator (AdvOutputName.Pr.SpeedChangeGear.OutRatioNumerator)

Set the numerator for the speed change ratio for each axis.

Speed change ratio: Numerator can be changed anytime during synchronous control.

Input values for speed change are processed as follows.

$$\text{Input value after conversion} = \text{Input value before conversion} \times \frac{\text{Speed change ratio: Numerator}}{\text{Speed change ratio: Denominator}}$$

The input speed direction can be reversed by setting a negative value in Speed change ratio: Numerator.



Setting a reduced fraction is recommend for "Main shaft speed change ratio: Numerator/Main shaft Speed change ratio: Denominator", "Auxiliary shaft speed change ratio: Numerator/Auxiliary shaft Speed change ratio: Denominator", and "Output axis speed change ratio: Numerator/Output axis speed change ratio: Denominator".

■Main shaft Speed change ratio: Denominator

(AdvOutputName.Pr.SpeedChangeGear.MasterRatioDenominator)/Auxiliary shaft Speed change ratio: Denominator (AdvOutputName.Pr.SpeedChangeGear.AuxRatioDenominator)/Output axis speed change ratio: Denominator (AdvOutputName.Pr.SpeedChangeGear.OutRatioDenominator)

Set the denominator for the speed change ratio for each axis.

Speed change ratio: Denominator can be changed anytime during synchronous control.

Set together with Speed change ratio: Numerator.

Speed change ratio: Denominator is set within the range from "1 to 2147483647".

Output axis parameters constant (AdvOutputName.PrConst.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterSpeedChangeGearSmoothingTimeConstant	Main shaft speed change gear smoothing time constant	At system start	WORD(UNIT)	0 to 5000 [ms]	0 [ms]
AuxSpeedChangeGearSmoothingTimeConstant	Auxiliary shaft speed change gear smoothing time constant		WORD(UNIT)	0 to 5000 [ms]	0 [ms]
OutSpeedChangeGearSmoothingTimeConstant	Output axis speed change gear smoothing time constant		WORD(UNIT)	0 to 5000 [ms]	0 [ms]

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Main shaft speed change gear smoothing time constant

(AdvOutputName.PrConst.MasterSpeedChangeGearSmoothingTimeConstant)/Auxiliary shaft speed change gear smoothing time constant (AdvOutputName.PrConst.AuxSpeedChangeGearSmoothingTimeConstant)/Output axis speed change gear smoothing time constant (AdvOutputName.PrConst.OutSpeedChangeGearSmoothingTimeConstant)

Set the averaging time to execute a smoothing process for the speed change for the speed change gear.

The input value transmission is delayed depending on the time corresponding to the speed change gear smoothing time constant.

Speed is changed directly when "0" is set.

Speed change gear control data of output axis parameters (AdvOutputName.Cd.SpeedChangeGear.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterSmoothingTimeConstant	Main shaft speed change gear smoothing time constant change value	At start	INT	0 to 5000 [ms]	0 [ms]
AuxSmoothingTimeConstant	Auxiliary shaft speed change gear smoothing time constant change value		INT	0 to 5000 [ms]	0 [ms]
OutSmoothingTimeConstant	Output axis speed change gear smoothing time constant change value		INT	0 to 5000 [ms]	0 [ms]

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Main shaft speed change gear smoothing time constant change value

(AdvOutPutName.Cd.SpeedChangeGear.MasterSmoothingTimeConstant)/Auxiliary shaft speed change gear smoothing time constant change value

(AdvOutPutName.Cd.SpeedChangeGear.AuxSmoothingTimeConstant)/Output axis speed change gear smoothing time constant change value

(AdvOutPutName.Cd.SpeedChangeGear.OutSmoothingTimeConstant)

The speed change gear smoothing time constant of each shaft/axis is changed.

The setting is imported when MCv_AdvancedSync (Advanced Synchronous Control) is started.

Set as follows.

Setting value	Description
When a negative value is set	No smoothing.
When 0 is set	Smoothing based on the setting value of the speed change gear smoothing time constant ^{*1} .
When a positive value is set	Smoothing based on the setting value of the speed change gear smoothing time constant change value ^{*2} . Set within the following setting range. Speed change gear smoothing time constant ^{*1} > Speed change gear smoothing time constant change value ^{*2} *: If the set value exceeds the range above, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs, and smoothing is executed based on the setting value of the speed change gear smoothing time constant ^{*1} .

*1 The speed change gear smoothing time constant is as follows.

Axis	Variables
Main shaft	Main shaft speed change gear smoothing time constant (<u>AdvOutPutName.PrConst.MasterSpeedChangeGearSmoothingTimeConstant</u>)
Auxiliary shaft	Auxiliary shaft speed change gear smoothing time constant (<u>AdvOutPutName.PrConst.AuxSpeedChangeGearSmoothingTimeConstant</u>)
Output Axis	Output axis speed change gear smoothing time constant (<u>AdvOutPutName.PrConst.OutSpeedChangeGearSmoothingTimeConstant</u>)


*2 The speed change gear smoothing time constant change value is as follows.

Axis	Variables
Main shaft	Main shaft speed change gear smoothing time constant change value (<u>AdvOutPutName.Cd.SpeedChangeGear.MasterSmoothingTimeConstant</u>)
Auxiliary shaft	Auxiliary shaft speed change gear smoothing time constant change value (<u>AdvOutPutName.Cd.SpeedChangeGear.AuxSmoothingTimeConstant</u>)
Output Axis	Output axis speed change gear smoothing time constant change value (<u>AdvOutPutName.Cd.SpeedChangeGear.OutSmoothingTimeConstant</u>)

Output axis module

For the output axis module, the current position per cycle is calculated based on the input value (the cam set position based on the current position after auxiliary shaft gear after speed change gear processing), which is then converted based on the cam data settings and output to the slave axes as the set position.


In addition, smoothing and phase compensation can be set for the output command.



*1 Speed change gear ( Page 624 Speed change gear)

*2 Cam function processing

The parameters and monitor data related to the cam function processing are shown below.



Cam parameter of output axis parameters (AdvOutputName.Pr.Cam.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
LengthPerCycle	Length per cycle	At start/ At passing through the 0th point of cam data	LREAL	1.0 to 2147483647.0	1000000.0
StrokeAmount	Cam stroke amount		LREAL	-2147483648.0 to 2147483647.0	1000000.0
CamNo	Cam No.		WORD(UINT)	0 to 60000	0
StartingPoint	Cam starting point		DWORD(UDINT)	0 to 65535	0
LengthPerCycleChange	Length per cycle change setting	At start	INT (MC_LENGTH_PER_CYCLE_CHANGE)	0: Invalid (LengthChangeInvalid) 1: Valid (LengthChangeValid)	0: Invalid (LengthChangeInvalid)
PhaseCompensationAdvancedTime	Phase compensation advance time	At start/ Operation cycle (FB is starting)	DINT	-100000000 to 100000000 [μs]	0 [μs]
PhaseCompensationTimeConstant	Phase compensation time constant	At start	WORD(UINT)	0 to 65535 [ms]	10 [ms]

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

■ MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle)

Set the length per cycle of the cam axis to generate the current position per cycle.

The unit settings are in units of the input axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control).

Set a value within the range from "1.0 to 2147483647.0".

The length per cycle can be changed during synchronous control by setting Length per cycle change setting (AdvOutputName.Pr.Cam.LengthPerCycleChange) to "1: Valid (LengthChangeValid)". When the current position per cycle passes through the 0th point of cam data, or is at the 0th point of cam data, the value of the Length per cycle (LengthPerCycle) is imported.

When cam data is set, the waveform after the length per cycle is changed varies by the cam data format.

- For cam data (section interpolation)/cam data (spline interpolation)

The waveform is shortened/extended so that the one cycle set in the operation profile is equal to the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle). The maximum value of the stroke amount does not vary with the change of the length per cycle.


An example of using cam data (section interpolation), and changing the length per cycle during synchronous control is shown below.

Ex.

A setting example of cam data (section interpolation)

- Length per cycle: 4194304.0
- Cam stroke amount: ± 4194304.0
- Stroke ratio data

Section No.	Start point [pulse]	End point [pulse]	Stroke [%]
1	0.0	2097152.0	100.0
2	297152.0	4194304.0	0.0



- For cam data (linear interpolation)


When the input value of the final coordinate is less than the length per cycle, it is controlled using a line segment calculated from the nearest two coordinates. An example of using cam data (linear interpolation), and changing the length per cycle to a value that exceeds the input value of cam data final coordinate during synchronous control is shown below.

Ex.

A setting example of cam data (linear interpolation)

- Length per cycle: 4194304.0
- Cam stroke amount: ± 4194304.0
- Coordinate data

Point	Input value	Cam set position
1	0.0	0.0
2	2097152.0	4194304.0
3	4194304.0	0.0



*1 Because the coordinate where "input value = length per cycle" does not exist, the final coordinate is calculated from the line segment between the nearest two coordinates.

Point

- Do not set digits after the decimal point. If set, the errors will be accumulated every time the current position per cycle permissible value is exceeded.
- When cam data change and length per cycle change are executed simultaneously, the length per cycle will not be changed if cam data change fails.

Cam stroke amount (AdvOutputName.Pr.Cam.StrokeAmount)

When the Interpolation method specification (Interpolate) of the operation profile is set to "1: Section interpolation" or "2: Spline interpolation", or the data format is set to "Rotary cutter", set the cam stroke amount corresponding to a 100% stroke ratio in position units of the axis set in the output axis Axis information (AdvOutputName.Axis).

The cam stroke amount can be changed during synchronous control.

The value of Cam stroke amount (AdvOutputName.Pr.Cam.StrokeAmount) is imported when the current position per cycle passes through the 0th point of cam data, or is on the 0th point.

Point

- Do not set digits after the decimal point. If set, the errors will be accumulated every time the current position per cycle permissible value is exceeded.

■Cam No. (AdvOutputName.Pr.Cam.CamNo)

Set the cam No. used for cam control.

■Cam starting point (AdvOutputName.Pr.Cam.StartingPoint)


Set the starting point of cam data in resolutions.

This setting is valid only when the Interpolation method specification (Interpolate) of the operation profile is set to "1: Section interpolation" or "2:

Spline interpolation", or the data format is set to "Rotary cutter".

The initial value of the Cam starting point (AdvOutputName.Pr.Cam.StartingPoint) is "0". (The cam axis is controlled with cam data starting from the 0th point (stroke ratio 0%).)

When a value other than "0" is set, cam control is started from a stroke ratio other than 0%.



Point

- The cam reference position is the cam set position at the 0th point of cam data.
- The Cam starting point (AdvOutputName.Pr.Cam.StartingPoint) is imported when cam data switches. When a value exceeding the cam data resolution is set in the Cam starting point (AdvOutputName.Pr.Cam.StartingPoint), control is performed using the cam data and cam starting point before the change.

■Length per cycle change setting (AdvOutputName.Pr.Cam.StartingPoint)

Set this when changing the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle) during synchronous control.

This can change the length per cycle in cam No.0 (linear cam), cam data (linear interpolation), or cam data (section interpolation). However, this cannot change the length per cycle in cam data (section interpolation) that uses cam data with starting point other than 0.

Setting value	Description
0: Invalid (LengthChangeInvalid)	Cannot change the length per cycle during synchronous control.
1: Valid (LengthChangeValid)	Imports the value of the Length per cycle (<u>AdvOutputName.Pr.Cam.LengthPerCycle</u>) when the current position per cycle passes through the 0th point of cam data, or is on the 0th point.

■Phase compensation advance time

(AdvOutputName.Pr.Cam.PhaseCompensationAdvancedTime)

Set the time to advance or delay the phase of the current position per cycle in the cam control.

Setting value	Description
1 to 100000000 [μ s]	Advance the phase according to the setting time.
0 [μ s]	Do not execute phase compensation.
-100000000 to -1 [μ s]	Delay the phase according to the setting time.


If the setting time is too long, the system experiences overshoot or undershoot at acceleration/deceleration of the input movement amount to the output axis. In this case, set a longer time to reflect the phase compensation amount in the Phase compensation time constant (AdvOutputName.Pr.Cam.PhaseCompensationTimeConstant).

■Phase compensation time constant

(AdvOutputName.Pr.Cam.PhaseCompensationTimeConstant)

Set the time constant for reflecting the phase compensation amount for the first order delay.

63% of the phase compensation amount is reflected in the specified time constant.



Cam monitor of output axis monitor data (AdvOutputName.Md.Cam.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Monitor value
MasterCompositeGearSetPosition	Current position after composite main shaft gear	Operation cycle (FB is starting)	LREAL	-10000000000.0 to 10000000000.0
MasterGearPositionPerCycle	Current position per cycle after main shaft gear		LREAL	0.0 to (length per cycle - 0.00001)
AuxGearPositionPerCycle	Current position per cycle after auxiliary shaft gear		LREAL	0.0 to (length per cycle - 0.00001)
PhaseCompensationAmount	Phase compensation amount		LREAL	-2147483648.0 to 2147483647.0
PositionPerCycle	Length per cycle change setting		LREAL	0.0 to (length per cycle - 0.00001)
ReferenceSetPosition	Cam reference position		LREAL	-10000000000.0 to 10000000000.0
SetPosition	Cam set position		LREAL	-10000000000.0 to 10000000000.0
CamNo	Execution profile No.		WORD(UINT)	0 to 60000
StrokeAmount	Execution cam stroke amount		LREAL	-2147483648.0 to 2147483647.0
LengthPerCycle	Execution length per cycle		LREAL	1.0 to 2147483647.0
StartingPoint	Execution starting point		DWORD(UDINT)	0 to 65535

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Current position after composite main shaft gear (AdvOutputName.Md.Cam.MasterCompositeGearSetPosition)

The current position after the composite main shaft gear combines the values from the main shaft and the sub input axis is stored as an accumulative value.

The unit settings are in units of the input axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control).

The Current position after composite main shaft gear (AdvOutputName.Md.Cam.MasterCompositeGearSetPosition) is backed up. For details, refer to the following.

Page 653 Synchronous Control Initial Position

■Current position per cycle after main shaft gear (AdvOutputName.Md.Cam.MasterGearPositionPerCycle)

The input movement amount after the main shaft gear is stored within the range from "0.0 to (length per cycle - 0.00001)".

The unit settings are in units of the input axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control). The Current position per cycle after main shaft gear (AdvOutputName.Md.Cam.MasterGearPositionPerCycle) is backed up. For details, refer to the following.

Page 653 Synchronous Control Initial Position

■Current position per cycle after auxiliary shaft gear (AdvOutputName.Md.Cam.AuxGearPositionPerCycle)

The input movement amount after the auxiliary shaft gear is stored within the range from "0.0 to (length per cycle - 0.00001)".

The unit settings are in units of the input axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control).

The Current position per cycle after auxiliary shaft gear (AdvOutputName.Md.Cam.AuxGearPositionPerCycle) is backed up. For details, refer to the following.

Page 653 Synchronous Control Initial Position

■Phase compensation amount (AdvOutputName.Md.Cam.PhaseCompensationAmount)

The phase compensation amount after smoothing processing with the Phase compensation time constant (AdvOutputName.Pr.Cam.PhaseCompensationTimeConstant) is stored.

The unit settings of phase compensation amount are in units of the input axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control).

Page 653 Synchronous Control Initial Position

■Current position per cycle (AdvOutputName.Md.Cam.PositionPerCycle)

The current position per cycle is stored within the range from "0.0 to (length per cycle - 0.00001)".

The current position after phase compensation processing can be monitored. The unit settings are in units of the input axis set as the Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control).

The Current position per cycle (AdvOutputName.Md.Cam.PositionPerCycle) is backed up. For details, refer to the following.

☞ Page 653 Synchronous Control Initial Position

■Cam reference position (AdvOutputName.Md.Cam.ReferenceSetPosition)

The set position is stored as the cam reference position of the cam operation. The unit settings are in position units of the axis set in the output axis Axis information (AdvOutputName.Axis).

The cam reference position range is the positioning range of the axis assigned as the output axis.

The Cam reference position (AdvOutputName.Md.Cam.ReferenceSetPosition) is backed up. For details, refer to the following.

☞ Page 653 Synchronous Control Initial Position

■Cam set position (AdvOutputName.Md.Cam.SetPosition)

- The set position of the cam axis is stored. The unit settings are in position units of the axis set in the output axis Axis information (AdvOutputName.Axis).
- When the Output axis smoothing time constant (AdvOutputName.PrConst.SmoothingTimeConstant) is "0" during the execution of synchronous control, the value of the Set position (AxisName.Md.SetPosition) of the axis set in the output axis Axis information (AdvOutputName.Axis) is equal to the value of the Cam set position (AdvOutputName.Md.Cam.SetPosition).
- When the Output axis smoothing time constant (AdvOutputName.PrConst.SmoothingTimeConstant) is other than "0" during the execution of synchronous control, the value of the Set position (AxisName.Md.SetPosition) of the axis set in the output axis Axis information (AdvOutputName.Axis) becomes equal to the value of the Cam set position (AdvOutputName.Md.Cam.SetPosition) after the smoothing is completed.
- The Cam set position (AdvOutputName.Md.Cam.SetPosition) is backed up. For details, refer to the following.

☞ Page 653 Synchronous Control Initial Position

■Execution profile No. (AdvOutputName.Md.Cam.CamNo)

The executing cam No. is stored.

When the Cam No. (AdvOutputName.Pr.Cam.CamNo) is changed during synchronous control, this is updated when the controlling cam No. switches.

The same value of the Execution profile No. (AdvOutputName.Md.Cam.CamNo) is stored to the Execution profile ID (AxisName.Md.ProfileID).

■Execution cam stroke amount (AdvOutputName.Md.Cam.StrokeAmount)

The executing cam stroke amount is stored.

When the Cam stroke amount (AdvOutputName.Pr.Cam.StrokeAmount) is changed during synchronous control, this is updated when the controlling cam stroke amount switches.

■Execution length per cycle (AdvOutputName.Md.Cam.LengthPerCycle)

The executing cam length per cycle is stored.

When the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle) is changed during synchronous control, this is updated when the controlling length per cycle switches.

■Execution starting point (AdvOutputName.Md.Cam.StartingPoint)

The executing cam starting point is stored.

When the Cam starting point (AdvOutputName.Pr.Cam.StartingPoint) is changed during synchronous control, this is updated when the cam switches.

Cam control data of output axis parameters (AdvOutputName.Cd.Cam.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
OutSmoothingTimeConstant	Output axis smoothing time constant change value	At start	INT	0 to 5000 [ms]	0

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Output axis smoothing time constant change value (AdvOutputName.Cd.Cam.OutSmoothingTimeConstant)

The output axis smoothing time constant is changed. The setting is imported when MCv_AdvancedSync (Advanced Synchronous Control) is started.


Setting value	Description
When a negative value is set	No smoothing.
When 0 is set	Smoothing based on the setting value of the Output axis smoothing time constant (<u>AdvOutPutName.PrConst.SmoothingTimeConstant</u>).
When a positive value is set	<p>Smoothing based on the setting value of the Output axis smoothing time constant change value (<u>AdvOutPutName.Cd.Cam.OutSmoothingTimeConstant</u>).</p> <p>Set within the following setting range.</p> <p>Output axis smoothing time constant (<u>AdvOutPutName.PrConst.SmoothingTimeConstant</u>) > Output axis smoothing time constant change value (<u>AdvOutPutName.Cd.Cam.OutSmoothingTimeConstant</u>)</p> <p>*: If the set value exceeds the range above, "Out of Advanced Synchronous Control Variable Range Warning" (warning code: 0D3FH) occurs, and smoothing is executed based on the setting value of the Output axis smoothing time constant (<u>AdvOutPutName.PrConst.SmoothingTimeConstant</u>).</p>

Cam function

Cam data sets the cam ID to Cam No. (AdvOutputName.Pr.Cam.CamNo).

To use the operation profile, set auto expand in the expand setting beforehand, or use MC_CamTableSelect (Cam Table Selection) to open the profile in cam open area.

Timing chart during cam operation



*1 When a value other than 0 is set to the cam data starting point, it becomes TRUE at the set cam data starting point.


Cam data operation

Cam data for advanced synchronous control performs the following operations.

■Linear cam

A linear operation in the cycle as the stroke ratio is 100%.


A linear operation occurs when Cam No. (AdvOutputName.Pr.Cam.CamNo) is set to "0".



■Two-way cam

A reciprocating cam operation with a constant cam strokes range.


A two-way operation occurs when "start point = end point" for the cam data created with the operation profile.



■Feed cam

A cam operation where the cam reference position is updated every cycle.

A feed cam operation occurs when "start point $\neq$ end point" for the cam data created with the operation profile.




Cam control by operation profile

When using cam control in advanced synchronous control, the data transmitted to the open area varies depending on the interpolation method specification of the operation profile and the data format.

■When the Interpolation method specification (Interpolate) of the operation profile is "1: Section interpolation" or "2: Spline interpolation", or the data format is set to "Rotary cutter"

The cam data is defined in equal divisions for one cam cycle based on the cam resolution, and configured with stroke ratio data from points within the cam resolution.


For the relation between the operation profile in this setting and Advanced synchronous control, refer to the following.



*1 Calculates the stroke ratio for Current position per cycle (AdvOutputName.Md.Cam.PositionPerCycle) using the stroke ratio and resolution of the profile open area and Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).

Ex.

When cam resolution is 512



• Timing of applying cam control data


If Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle) or Cam No. (AdvOutputName.Pr.Cam.CamNo), or Cam stroke amount (AdvOutputName.Pr.Cam.StrokeAmount) is changed, the new value is imported and applied when the Current position per cycle (AdvOutputName.Pr.Cam.PositionPerCycle) passes through the 0th point of cam data, or is on the 0th point. For "Cam starting point = 0", the cam reference position is updated when the current position per cycle exceeds the maximum permissible value. For "Cam starting point ≠ 0", the cam reference position is updated when the current position per cycle passes through the 0th point of cam data.

■When the Interpolation method specification (Interpolate) of the operation profile is set to "0: Linear interpolation"

The cam data defines a cam curve in two or more points of coordinate data for one cycle. The coordinate data is expressed as "(input value, output value)", with "input value = axis current position per cycle", and "output value = stroke amount from cam reference position".

The Cam stroke amount (AdvOutputName.Pr.Cam.StrokeAmount) of output axis parameter is ignored, and the output value of the I/O data becomes cam stroke amount.

For the relation between the operation profile in this setting and Advanced synchronous control, refer to the following.




*1 The output value corresponding to the Current position per cycle (AdvOutputName.Md.Cam.PositionPerCycle) is calculated based on the input value and output value of the open area. In addition, the result of the calculation is truncated after the 5th decimal place.

Ex.

Setting example 1


When the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle) is equivalent to the setting value of the length per cycle setting in the operation profile



Ex.

Setting example 2

When "input value = 0" and "input value = length per cycle" coordinates do not exist in the coordinate data, control is performed using a line segment calculated from the nearest two coordinates.




Ex.

Setting example 3

If the input value exceeds the maximum value (2147483647.0) of the Length per cycle

(AdvOutputName.Pr.Cam.LengthPerCycle), the control is performed using a line segment calculated from the nearest two coordinates to the maximum value of the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).

In this case, the input value X at the last point of the coordinates is equivalent to the maximum value of the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).



*: Xmax=2147483647.0

- Reflection timing of the cam control data

If the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle) or the Cam No. (AdvOutputName.Pr.Cam.CamNo) is changed during synchronous control, the new value is imported and reflected when the Current position per cycle (AdvOutputName.Pr.Cam.PositionPerCycle) passes through "0.0", or is on the position of "0.0". The cam reference position is updated when the current position per cycle passes through "0.0".

■Setting list for using the operation profile in advanced synchronous control

The settings for using the operation profile in advanced synchronous control are shown below.

When specifying setting values, set the specified value, or a value within the range. When a specified value or a value within the range is not set, an error, or an unintended operation may occur.

Setting item*1		Interpolation Method Specification (Interpolate)	
		1: Section Interpolation/2: Spline Interpolation	0: Linear Interpolation
Periodic (Options (Options): Bit 0)		Set to "1: Periodic". When set to other than "1: Periodic", "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur at FB start.	
Master axis (input) absolute coordinate (Options (Options): Bit 1)		Set to "0: Relative coordinate". When set to other than "0: Relative coordinate", "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur at FB start.	
Slave axis (output) absolute coordinate ((Options (Options): Bit 2)		Set to "0: Relative coordinate". When set to other than "0: Relative coordinate", "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur at FB start.	
Profile ID		Set to any value within the range of 1 to 60000.	
Interpolation Method Specification (Interpolate)		Set to "1: Section Interpolation", or "2: Spline Interpolation".	Set to "0: Linear Interpolation".
Resolution/coordinate number (Resolution)		Set the number of divisions for one cam curve.	Set the number of coordinate points in one cam cycle. The 0th point is included in the number of coordinate points.
Input unit character string (InputUnitString)		Set the unit of the axis to be set as the main shaft.	
Output unit character string (OutputUnitString)		Set the unit of the stroke amount.	Set the unit of the axis to be set as the output axis.
Start point (StartPoint)		Set to "0.0". When set to other than "0.0", "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur at FB start. When setting the cam data starting point in advanced synchronous control, set the Cam starting point (<u>AdvOutputName.Pr.Cam.StartingPoint</u>) of the output axis parameters.	
Initial stroke amount (StartStroke)		Set to "0.0". When set to other than "0.0", "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur at FB start.	
Initial velocity (StartVelocity)		Set this variable in the case of "1: Section Interpolation". Set the velocity at the start point/end point. Use when the Cam curve type (CurveType) is set to "12: 5th curve (Adj.) (FifthCurve_SpeedDesignation)".	It is not used in the coordinate data format.
Initial acceleration (StartAcceleration)		Set this variable in the case of "1: Section Interpolation". Set the acceleration at the start point/end point. Use when the Cam curve type (CurveType) is set to "12: 5th curve (Adj.) (FifthCurve_SpeedDesignation)".	
I/O data	Input value	Do not set this item in the case of "1: Section Interpolation" or "2: Spline Interpolation".	<ul style="list-style-type: none"> Set the input value at each point No. Set the input value within the range of "0.0 to 2147483647.0". When an input value exceeding "2147483647.0" is set, the control is performed using a line segment calculated from the nearest two coordinates to the maximum value of the Length per cycle (<u>AdvOutputName.Pr.Cam.LengthPerCycle</u>).
	Output value		<ul style="list-style-type: none"> Set the output value corresponding with the input value at each point No. Set the output value within the range of "-2147483648.0 to 2147483647.0". If a value outside the range is set, "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur.

Setting item*1		Interpolation Method Specification (Interpolate)	
		1: Section Interpolation/2: Spline Interpolation	0: Linear Interpolation
Parameter	Cam curve type (CurveType)	Set to any type to match the cam data to be created.	It is not used in the coordinate data format.
	End point (EndPoint)	Set the end point of each section.	
	Stroke (Stroke)	Set the stroke of each section.	
	Curve applicable range (RangeP1/RangeP2)	Set the curve applicable range (start point: P1, end point: P2) for the cam curve. (0.0 to 1.0) Set "P1 < P2". However, for "P1 = P2 = 0", "P1 = 0" and "P2 = 1" are applied. For curve applicable range, the setting can be omitted.	
	Acceleration/ deceleration range compensation (RangeL1)	Set the acceleration/deceleration range (L1, L2) of the cam curve. (0.0001 < L1, L2 < 1.0000) The range that can be set differs depending on the cam curve. For "L1 = L2 = 0.0000", the default value for each cam curve is applied. On the curve that does not use L1 or L2, the setting value is ignored.	
	End point velocity (EndVelocity)	Set the end point velocity of the cam curve.	
	End point acceleration (EndAcceleration)	Set the end point acceleration of the cam curve.	
Length per cycle (CycleLength)		Although the setting is ignored in advanced synchronous control, set the same value to the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle). The setting value of the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle) is used for actual control.	
Minimum value per cycle (CycleMin)		Do not set this item in the case of "1: Section Interpolation" or "2: Spline Interpolation".	Set to "0.0". Set this variable when the Interpolation method specification (Interpolate) is set to "0: Linear Interpolation".
Maximum value per cycle (CycleMax)			Set the setting value of Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle). Set this item when the Interpolation method specification (Interpolate) is set to "0: Linear Interpolation".
Time per cycle (CycleTime)		Set the time that is required for one cycle. Use when the cam curve type (CurveType) is set to "12: 5th curve (Adj.) (FifthCurve_SpeedDesignation)".	Not used in "0: Linear Interpolation".
Stroke amount (Stroke)		When the unit is "%", the setting is ignored. When the unit is other than "%", set to 100 % stroke amount. <Example> If the stroke amount is set to "200.0" when the unit is "mm", the cam data will have "200.0" as the 100% stroke ratio.	Set to a value equal to or more than the maximum value of the output value in the I/O data.
Number of sections (NumberOfSections)		Set to a value within the following ranges depending on the interpolation method specification (Interpolate). ■"1: Section Interpolation" 1 to 360 ■"2: Spline Interpolation" 3 to 360	It is not used in the coordinate data format.

*1 The variable inside the () is the member name of the PROFILE_CAM_DATA data type, or the PROFILE_CAM_ELEMENT data type.


When the data format is "rotary cutter", refer to the following.

Page 515 Rotary cutter

Setting method of operation profile

This section describes the setting method for using an operation profile in advanced synchronous control.

1. In "Motion Control Setting Function", right-click Navigation window ⇒ [Operation Profile Data] (1), and select [Add New Data] (2).




2. On the "New Data" window, configure the basic setting and detailed setting, and click the [OK] button.

Setting item			Setting
Basic setting	Data type		Set "Operation Profile Data".
	Data name		Set any data name.
Detailed setting	Data format	Type	Set the type of data to be created. • Cam data • Rotary cutter
		Interpolation method specification	Set the interpolation method specification to match the cam to be created. • Linear interpolation • Section interpolation • Spline interpolation
	Expand setting	Auto expand	To expand the operation profile automatically, set to "Yes". When set to "No", operation profile must be stored in the open area by MC_CamTableSelect (Cam Table Selection) to use the operation profile in the control.
		Profile ID	Set to any value within the range of 1 to 60000.
		Repetitive operation	Set to "Enable".
		Input absolute coordinate	Set to "Disable (Relative Coordinate)".
		Output absolute coordinate	Set to "Disable (Relative Coordinate)".

3. Set the operation profile. Set as follows according to match the set type, and the interpolation method specification.

• Cam data

■Section interpolation




- 1 Set the resolution to match the cam data to be created.
- 2 Set to the same unit as that of the main shaft.*1
- 3 Set to the same value as that set in the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).*1
- 4 Set to any unit.
- 5 When the unit is other than "%", set to 100% stroke amount.
- 6 Use when cam curve type is set to "5th Curve (Adj.)".
- 7 Click the [Display] button of the point data to check the stroke data of the open area.
- 8 Set to "0.0".
- 9 Set the input value and the output value to match the cam data to be created.*2
- 10 Set the detailed settings to match the cam data to be created.*2

*1 Although the setting is ignored in advanced synchronous control, setting this item is recommended in order to match the setting window of the motion control setting function and the actual cam operation.

*2 For details, refer to the following.

📖 Page 504 Cam data

■ Spline interpolation




- ① Set the resolution to match the cam data to be created.
- ② Set to the same unit as that of the main shaft.*1
- ③ Set to the same value as that set in the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).^{*1}
- ④ Set to any unit.
- ⑤ When the unit is other than "%", set to 100 % stroke amount.
- ⑥ Click the [Display] button of the point data to check the stroke data of the open area.
- ⑦ Set to "0.0".
- ⑧ Set the input value and the output value to match the cam data to be created.^{*2}
- ⑨ Set the detailed settings to match the cam data to be created.

*1 Although the setting is ignored in advanced synchronous control, setting this item is recommended in order to match the setting window of the motion control setting function, and the actual cam operation.

*2 For details, refer to the following.


📖 Page 504 Cam data

■ Linear Interpolation



- ① Set to the same unit of the axis which is set as the main shaft.
- ② Set to the same value as that set in the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).
- ③ Set to the same unit of the axis which is set as the output axis.
- ④ Set to a value equal to or more than the maximum value of the output value in the I/O data.
- ⑤ Set the input value and the output value to match the cam data to be created.
- ⑥ Set to "0.0".
- ⑦ Set to the setting value of the Length per cycle (AdvOutputName.Pr.Cam.LengthPerCycle).

• Rotary cutter



- ① Set the parameters to match the cam data to be created.
- ② Click the [Display] button of the point data to check the stroke data of the open area.

Precautions

- When rewriting the open area during control by using the Profile Write (MCv_WriteProfileData), depending on the waveform pattern the stroke value may change rapidly, causing an impact to be applied to the machine. Create operation profile so that the waveform before and after the change does not become discontinued.
- For operation profile format that can be used in the advanced synchronous control, refer to the following. If an incorrect profile data format is used in the advanced synchronous control, "Operation Profile Data Settings Incorrect Under Advanced Synchronous Control" (error code: 1AF8H) will occur.

 Page 504 Operation profile types

- If the Cam No. (AdvOutputName.Pr.Cam.CamNo) is changed during advanced synchronous control in the following cases, a warning occurs, and control continues with the cam data before the change.

Description	Warning code
A value out of range for Cam No. (<u>AdvOutputName</u> .Pr.Cam.CamNo) was set.	Out of Advanced Synchronous Control Variable Range Warning (warning code: 0D3FH)
The cam table does not exist.	No Cam Table Warning (warning code: 0D44H)
A value that cannot be used in advanced synchronous control was set in the operation profile.	Operation Profile Data Settings Incorrect Under Advanced Synchronous Control Warning (warning code: 0D46H)
A value which exceeds the resolution was set to the cam starting point.	Operation Profile Data Settings Incorrect Under Advanced Synchronous Control Warning (warning code: 0D46H)
Failed to acquire the add-on ProfileControl.	Add-on Acquisition Failure Warning (warning code: 0D47H)

Synchronous control change function

While MCv_AdvancedSync (Advanced Synchronous Control) is activated, this function can be used to change the cam reference position, the cam axis current value per cycle and the current value per cycle after the main/auxiliary shaft gear during the synchronous control. The following five methods exist for the synchronous control change function. ( Page 649 Synchronous control change command (AdvOutputName.Cd.Cam.SyncControlChangeCommand))

Synchronous control change command	Application	Output axis operation
Cam reference position movement	Adjust the cam reference position by the movement amount.	Operated
Change current position per cycle	Change the current position per cycle.	None
Change current position per cycle after main shaft gear	Change the current position per cycle after main shaft gear.	None
Change current position per cycle after auxiliary shaft gear	Change the current position per cycle after auxiliary shaft gear.	None
Current position per cycle movement	Adjust the phase of the cam set position by the movement amount.	Operated

Cam monitor of output axis parameters (AdvOutputName.Md.Cam.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Monitor value
SyncControlChangeStatus	Synchronous control change status	Operation cycle (FB is starting)	INT	-1: Synchronous control change failure 0: Synchronous control change not requested 1: Synchronous control change in progress 2: Synchronous control change complete

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Synchronous control change status (AdvOutputName.Md.Cam.SyncControlChangeStatus)

- When Synchronous control change request (AdvOutputName.Cd.Cam.SyncControlChangeRequest) is set to "TRUE (Synchronous control change requested)", "1: Synchronous control change in progress" is stored to Synchronous control change status (AdvOutputName.Md.Cam.SyncControlChangeStatus) during synchronous control change processing, and "2: Synchronous control change complete" is stored after processing.
- Synchronous control change status (AdvOutputName.Md.Cam.SyncControlChangeStatus) is "0: Synchronous control change not requested" according to the following conditions.
 - Synchronous control change request (AdvOutputName.Cd.Cam.SyncControlChangeRequest) is set to "FALSE (Synchronous control change not requested)".
 - Advanced synchronous control is stopped.
- When Synchronous control change command (AdvOutputName.Cd.Cam.SyncControlChangeCommand) and Synchronous control change value (AdvOutputName.Cd.Cam.SyncControlChange) are set out of range, and Synchronous control change request (AdvOutputName.Cd.Cam.SyncControlChangeRequest) is set to "TRUE (Synchronous control change requested)", "-1: Synchronous control change failure" is stored.

Cam control data of output axis parameters (AdvOutputName.Cd.Cam.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
SyncControlChange Request	Synchronous control change request	Operation cycle (FB is starting)	BOOL	FALSE: Synchronous control change not requested TRUE: Synchronous control change requested	FALSE
SyncControlChange Command	Synchronous control change command		INT (MC_SYNC_CHANGE_COMMAND)	0: Cam reference position movement (ReferenceSetPositionMovement) 1: Change current position per cycle (ChangeCurrentPositionPerCycle) 2: Change current position per cycle after main shaft gear (ChangeMasterGearPositionPerCycle) 3: Change current position per cycle after auxiliary shaft gear (ChangeAuxGearPositionPerCycle) 4: Current position per cycle movement (PositionPerCycleMovement)	0: Cam reference position movement (ReferenceSetPositionMovement)
SyncControlChange	Synchronous control change value		LREAL	-2147483648.0 to 2147483647.0	0.0
SyncControlReflectionTime	Synchronous control reflection time		WORD(UINT)	0 to 65535 [ms]	0 [ms]

*1 For details on importing and data types, refer to "List of Variables" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■ Synchronous control change request (AdvOutputName.Cd.Cam.SyncControlChangeRequest)

The synchronous control change is requested.

When set to "TRUE (Synchronous control change requested)", Synchronous control change command (AdvOutputName.Cd.Cam.SyncControlChangeCommand) is executed.

■ Synchronous control change command (AdvOutputName.Cd.Cam.SyncControlChangeCommand)

Set the synchronous control change command.

Synchronous control change command	Description
0: Cam reference position movement (ReferenceSetPositionMovement)	<p>This command is executed to move the cam reference position through adding the setting movement amount of Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>).</p> <p>The movement amount to be added is averaged in Synchronous control reflection time (<u>AdvOutputName.Cd.Cam.SyncControlReflectionTime</u>) for its output.</p> <p>Set a long reflection time when a large movement amount is used since the cam set position moves with the movement amount.</p> <p>Current position per cycle (<u>AdvOutputName.Md.Cam.PositionPerCycle</u>)</p> <p>Cam set position (<u>AdvOutputName.Md.Cam.SetPosition</u>) (Set position of the slave axis)</p> <p>Synchronous control change request (<u>AdvOutputName.Cd.Cam.SyncControlChangeRequest</u>)</p> <p>Synchronous control change command (<u>AdvOutputName.Cd.Cam.SyncControlChangeCommand</u>)</p> <p>0: Cam reference position movement</p> <p>Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>)</p> <p>Synchronous control reflection time (<u>AdvOutputName.Cd.Cam.SyncControlReflectionTime</u>)</p> <p>Cam reference position (<u>AdvOutputName.Md.Cam.ReferenceSetPosition</u>)</p> <ul style="list-style-type: none"> When Synchronous control change request (<u>AdvOutputName.Cd.Cam.SyncControlChangeRequest</u>) is reset to "FALSE (Synchronous control change not requested)" while executing the cam reference position movement, operation is stopped midway. If the cam reference position movement command is executed again, the remainder movement amount is not reflected, and the operation starts with Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>) to be used again. If synchronous control is ended while the cam reference position movement is being executed, operation stops midway. If synchronous control is restarted, the remainder movement amount is not reflected.
1: Change current position per cycle (ChangeCurrentPositionPerCycle)	<p>The current position per cycle is changed to Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>).</p> <p>The cam reference position will be also changed to correspond to the changed current position per cycle.</p> <p>This operation is completed within one operation cycle.</p>

Synchronous control change command	Description
2: Change current position per cycle after main shaft gear (ChangeMasterGearPositionPerCycle)	<p>The current position per cycle after main shaft gear is changed to the value set in Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>).</p> <p>This operation is completed within one operation cycle.</p> <p>Clutch control is not executed if the current position per cycle after main shaft gear (the position before being changed and after being changed) has already passed through the ON/OFF address in address mode.</p>
3: Change current position per cycle after auxiliary shaft gear (ChangeAuxGearPositionPerCycle)	<p>The current position per cycle after auxiliary shaft gear is changed to the value set in Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>).</p> <p>This operation is completed within one operation cycle.</p> <p>Clutch control is not executed if the current position per cycle after auxiliary shaft gear (the position before being changed and after being changed) has already passed through the ON/OFF address in address mode.</p>
4: Current position per cycle movement (PositionPerCycleMovement)	<p>This command is executed to move the current value per cycle through adding the setting movement amount of Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>).</p> <p>The movement amount to be added is averaged in Synchronous control reflection time (<u>AdvOutputName.Cd.Cam.SyncControlReflectionTime</u>) for its output. Set a long reflection time when a large movement amount is used since the cam set position moves with the movement amount.</p> <p>Current position per cycle (<u>AdvOutputName.Cd.Cam.PositionPerCycle</u>)</p> <p>Cam set position (<u>AdvOutputName.Cd.Cam.SetPosition</u>) (Set position of the slave axis)</p> <p>Cam reference position (<u>AdvOutputName.Cd.Cam.ReferenceSetPosition</u>)</p> <p>Synchronous control change request (<u>AdvOutputName.Cd.Cam.SyncControlChangeRequest</u>)</p> <p>Synchronous control change command (<u>AdvOutputName.Cd.Cam.SyncControlChangeCommand</u>)</p> <p>4: Cam current position per cycle movement</p>

■Synchronous control change value (AdvOutputName.Cd.Cam.SyncControlChange)

Set the change value for synchronous control change processing.

Synchronous control change command (<u>AdvOutputName.Cd.Cam.SyncControlChangeCommand</u>)	Synchronous control change value (<u>AdvOutputName.Cd.Cam.SyncControlChange</u>)		
	Setting range	Unit	Setting details
0: Cam reference position movement (ReferenceSetPositionMovement)	-2147483648.0 to 2147483647.0	Position units of the axis set in the output axis	<ul style="list-style-type: none"> Set the movement amount of the cam reference position. It moves within the range from -2147483648.0 to 2147483647.0.
1: Change current position per cycle (ChangeCurrentPositionPerCycle)			<ul style="list-style-type: none"> Set the change current position per cycle. The setting value is converted within the range from "0.0 to (length per cycle - 0.00001)".
2: Change current position per cycle after main shaft gear)". (ChangeMasterGearPositionPerCycle)			
3: Change current position per cycle after auxiliary shaft gear (ChangeAuxGearPositionPerCycle)			
4: Current position per cycle movement (PositionPerCycleMovement)			<ul style="list-style-type: none"> Set the movement amount of the current position per cycle. It moves within the range from -2147483648 to 2147483647.

■ Synchronous control reflection time (AdvOutputName.Cd.Cam.SyncControlReflectionTime)

Set the reflection time for synchronous control change processing.

Synchronous control change command (<u>AdvOutputName.Cd.Cam.SyncControlChangeCommand</u>)	Setting details for Synchronous control reflection time (<u>AdvOutputName.Cd.Cam.SyncControlReflectionTime</u>)
0: Cam reference position movement (ReferenceSetPositionMovement)	The time to reflect the movement amount to the cam reference position.
1: Change current position per cycle (ChangeCurrentPositionPerCycle)	Setting not required.
2: Change current position per cycle after main shaft gear. (ChangeMasterGearPositionPerCycle)	
3: Change current position per cycle after auxiliary shaft gear (ChangeAuxGearPositionPerCycle)	
4: Current position per cycle movement (PositionPerCycleMovement)	The time to reflect the movement amount to the current position per cycle.

Precautions

The following are precautions when operating an output axis.

- Do not set the Ring counter lower limit value (AxisName.PrConst.RingCount_LowerValue) and Ring counter upper limit value (AxisName.PrConst.RingCount_UpperValue) of the axis positioning range of the axis set in the output axis Axis information (AdvOutputName.Axis) to a decimal number. If set, an error will occur with the value output to the slave axis and the Set position (AxisName.Md.SetPosition) of the axis set to the output axis in synchronous control when the maximum permissible value is exceeded.
- When the intermediate result of the movement amount calculated by each module exceeds the range of "-2147483648.0 to 2147483647.0", "Advanced Synchronization Control Operation Overflow" (error code: 1AF1H) occurs. The function of the module in which the overflow occurred is confirmed by the detail code. The detail code of "Advanced Synchronous Control Calculation Overflow" (error code: 1AF1H) are shown below.

Function of the module in which the overflow occurred	Detail code	Action
Composite main shaft gear	0001H	Reduce the speed of the main shaft main input axis and the main shaft sub input axis.
Main shaft gear	0002H	Reduce the gear ratio (gear numerator/gear denominator).
Main shaft clutch	0003H	Reduce the speed of the input axis when a clutch is used.
Main shaft module speed change gear	0004H	Reduce the speed change ratio (speed change ratio numerator/speed change ratio denominator).
Auxiliary shaft	0005H	Reduce the command set velocity of the axis set as the auxiliary shaft.
Auxiliary shaft gear	0006H	Reduce the gear ratio (gear numerator/gear denominator).
Auxiliary shaft clutch	0007H	Reduce the speed of the input axis when a clutch is used.
Auxiliary shaft module speed change gear	0008H	Reduce the speed change ratio (speed change ratio numerator/speed change ratio denominator).
Composite auxiliary shaft gear	0009H	Reduce the input value of the main shaft and the auxiliary shaft.
Output axis speed change gear	000AH	Reduce the speed change ratio (speed change ratio numerator/speed change ratio denominator).
Output axis phase compensation	000BH	Reduce the value of phase compensation advance time or set a longer time for the phase compensation time constant.
Output axis smoothing	000CH	Review the setting value of the time constant so that the number of smoothing steps reduce or increase the setting value of the operation cycle.
Output axis synchronous control change	000DH	Reduce the synchronous control change value or set a longer time for the synchronous control reflection time.
Output axis cam calculation	000EH	Review the cam waveform so that the stroke does not vary rapidly.

Required object data

The following shows the starting availability condition with or without PDO mapping when using it as the Output axis (AdvOutPutName.Axis) of MCv_AdvancedSync (Advanced Synchronous Control).

PDO mapping necessary/not necessary	
Target position	Position actual value
Necessary	Not required
Not necessary	Necessary
Not necessary	Not necessary


15.5 Synchronous Control Initial Position

The synchronous control monitor data can be aligned to a set position when starting MCv_AdvancedSync (Advanced Synchronous Control), as the initial position for synchronous control. Restoration is executed when MCv_AdvancedSync (Advanced Synchronous Control) is started. The alignment to a synchronous control initial position is useful for restoring a system based on the last control status along with restarting synchronous control after cancelling midway. The following monitor data are restored to a synchronous control initial position. To restore the data, the axes set in the axis information of the input axis and output axis must be set to absolute position detection system.

Synchronous control monitor data		The position when starting synchronous control
Name	Variable name	
Current position after composite main shaft gear	<code>AdvOutputName.Md.Cam.MasterCompositeGearSetPosition</code>	Restored to a position based on the current position of the input axis of the main shaft.
Current position per cycle after main shaft gear	<code>AdvOutputName.Md.Cam.MasterGearPositionPerCycle</code>	Restored according to the Setting method of current position per cycle after main shaft gear (<code>AdvOutputName.Pr.Restore.MasterGearPositionPerCycleMethod</code>).
Current position per cycle after auxiliary shaft gear	<code>AdvOutputName.Md.Cam.AuxGearPositionPerCycle</code>	Restored according to the Setting method of current position per cycle after auxiliary shaft gear (<code>AdvOutputName.Pr.Restore.AuxGearPositionPerCycleMethod</code>).
Current position per cycle	<code>AdvOutputName.Md.Cam.PositionPerCycle</code>	Restored according to the Cam axis position restoration object (<code>AdvOutputName.Pr.Restore.PositionRestorationObject</code>).
Cam reference position	<code>AdvOutputName.Md.Cam.ReferenceSetPosition</code>	
Cam set position*1	<code>AdvOutputName.Md.Cam.SetPosition</code>	


*1 The Set position (`AxisName.Md.SetPosition`) of the axis set as the output axis of the advanced synchronous control is calculated based on the cam set position.

The relationship between each module, the monitor data to be restored, and the setting values referred for restoration is shown below.



Restoration processing method

The restoration processing method is shown below. Restoration is executed in the following order: restoration analysis, monitor restoration, and restoration processing.



Backup data management for advanced synchronous control

For advanced synchronous control, the initial value of synchronous control monitor data and the data used to calculate and restore the synchronous control initial position are periodically saved to the latch drive as "abs_advsync.bin" file.

In order to back up data, the add-on AbsSystem must be valid.

When the axes set in the axis information of the output axis and input axis are not set to absolute position system, backup data is not generated. An "abs_advsync.bin" file of size up to the size specified in the Maximum backup RAM size (MotionControl_AdvancedSync_System.PrConst.AddonMemory.BackupRamSizeMax) can be saved. If the total size of the backup data exceeds the limit for backup data when adding the input axis and output axis, the variable that exceeds the limit will not be added.

When the total size of the backup data exceeds the limit, "Advanced Synchronous Control Backup Memory Insufficient Warning" (warning code: 0F18H) occurs.

The backup data size for an input axis and an output axis is shown below.

Axis type	Backup data size (k byte)
Input axis	0.1
Output axis	0.1

When turning the system power ON again after setting a smaller value set in the Maximum backup RAM size (MotionControl_AdvancedSync_System.PrConst.AddonMemory.BackupRamSizeMax) than the last time the system was powered ON, the "abs_advsync.bin" file will be regenerated, and all backup data will be cleared.


As the backup data is linked to the label IDs of the input axis and output axis, when the target axis No. specified in the output axis labels and input axis labels are changed before/after the system is powered ON again, restoration cannot be performed correctly because the links are broken. If restoration cannot be performed correctly, "Advanced Synchronous Control Restoration Incorrect Warning" (warning code: 0D40H) occurs.

Restoration method for current position after composite main shaft gear, current position per cycle after main shaft gear, and current position per cycle after auxiliary shaft gear at start of synchronous control

The initial position alignment and restoration of the current position after composite main shaft gear, the current position per cycle after main shaft gear, and the current position per cycle after auxiliary shaft gear are executed when MCv_AdvancedSync (Advanced Synchronous Control) is started.

Ex.

When the current position per cycle after main shaft gear is restored



15

Restoration method

The current position after composite main shaft gear, the current position per cycle after main shaft gear, and the current position per cycle after auxiliary shaft gear are restored as follows according to the operations executed on the axes assigned to the main shaft or auxiliary shaft before starting MCv_AdvancedSync (Advanced Synchronous Control).

Operation of the axes assigned to the main shaft and auxiliary shaft (before starting MCv_AdvancedSync (Advanced Synchronous Control))	Absolute position management setting (<u>AxisName.PrConst.PosRestoration_AbsPosEnable</u>) of the axes set in the axis	
	Absolute position detection system valid	Absolute position detection system invalid
Execution of MC_Home (OPR)	Restoration method (1)	
Execution of MC_SetPosition (Current Position Change)	Restoration method (1)	
Transition of the Active status (<u>AdvInputName.Md.ActiveStatus</u>) of input axis from "0: Not connected" to "1: Input axis enabled".	Restoration method (2)	Restoration method (1)
Others	Restoration method (2)	

Precautions

- The input axis value is rounded to a value within the positioning range, and the difference between this value and the current position of the input axis when synchronous control was last conducted is used as the change amount in "Restoration method (2)".
- When the input axis movement since synchronous control was last conducted exceeds "±10000000000.0 [input axis unit]" before synchronous control starts, the change amount cannot be calculated correctly.

■Restoration method (1)

Setting item	Restoration method	Calculation formula
Current position after composite main shaft gear	The new current position after composite main shaft gear is calculated based on the input axis cumulative current position of the main shaft.	Input direction ^{*1} of composite main shaft gear × Cumulative current position of the input axis (main shaft)
Current position per cycle after main shaft gear	The new current position per cycle after main shaft gear is calculated based on the current position after composite main shaft gear.	Main shaft gear ratio ^{*2} × Current position after composite main shaft gear
Current position per cycle after auxiliary shaft gear	The new current position per cycle after auxiliary shaft gear is calculated based on the input axis cumulative current position of the auxiliary shaft.	Auxiliary shaft gear ratio ^{*2} × Cumulative current position of the input axis (auxiliary shaft)

*1 The "Input direction of composite main shaft gear" value in the formula is as follows according to the Composite main shaft gear (AdvOutputName.Pr.Gear.MasterCompositeGear).

Composite main shaft gear (<u>AdvOutputName.Pr.Gear.MasterCompositeGear</u>)	Setting value for "Input direction of composite main shaft gear"
No input (H□□□0)	0
Input + (H□□□1)	1
Input - (H□□□2)	-1

*2 The gear ratio of the main and auxiliary shafts is calculated by the following formula.

Item	Calculation formula
Main shaft gear ratio	$\frac{\text{Main shaft gear: Numerator } (\text{AdvOutputName.Pr.Gear.MasterNumerator})}{\text{Main shaft gear: Denominator } (\text{AdvOutputName.Pr.Gear.MasterDenominator})}$
Auxiliary shaft gear ratio	$\frac{\text{Auxiliary shaft gear: Numerator } (\text{AdvOutputName.Pr.Gear.AuxNumerator})}{\text{Auxiliary shaft gear: Denominator } (\text{AdvOutputName.Pr.Gear.AuxDenominator})}$

■Restoration method (2)

The movement amount of the main shaft, sub input axis, or auxiliary shaft from the last synchronous control session is reflected to the current position after composite main shaft gear, the current position per cycle after main shaft gear, and the current position per cycle after auxiliary shaft gear.

Setting item	Restoration method	Calculation formula
Current position after composite main shaft gear	The movement amount of the main shaft from the last synchronous control session is reflected to the current position after composite main shaft gear.	Current position after composite main shaft gear at the last synchronous control session + Input direction of composite main shaft gear × Amount of change in the cumulative current position of input axis (main shaft) from the last synchronous control session
Current position per cycle after main shaft gear	The movement amount from the last synchronous control session is reflected to the current position per cycle after main shaft gear. The movement amount of the main shaft from the last synchronous control session is reflected to the current position after composite main shaft gear and the current position per cycle after main shaft gear.	Current position per cycle after main shaft gear at the last synchronous control session + Main shaft gear ratio × Amount of change in the current position after composite main shaft gear from the last synchronous control session
Current position per cycle after auxiliary shaft gear	The movement amount from the last synchronous control session is reflected to the current position per cycle after auxiliary shaft gear. The movement amount of the auxiliary shaft from the last synchronous control session is reflected to the current position per cycle after auxiliary shaft gear.	Current position per cycle after auxiliary shaft gear at the last synchronous control session + Auxiliary shaft gear ratio × Amount of change in the cumulative current position of input axis (auxiliary shaft) from the last synchronous control session

"The last synchronous control session" indicates the status immediately before MCv_AdvancedSync (Advanced Synchronous Control) is stopped and the Synchronization status (AdvOutputName.Md.SyncStatus) is changed to "0: Not synchronizing" as follows.

- Immediately before MCv_AdvancedSync (Advanced Synchronous Control) is stopped by a stop command, error, etc.
 - Immediately before the power supply of the Motion system is turned OFF
-

Cam axis position at synchronous control start

The cam axis position is composed of the relationship of the three positions "Current position per cycle", "Cam reference position", and "Cam set position". The remaining position can be restored by determining two positions when starting MCv_AdvancedSync (Advanced Synchronous Control).

Determine which position to restore by selecting one of the three settings below in the Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject).

- 0: Current position per cycle restoration (RestorePositionPerCycle)
- 1: Cam reference position restoration (RestoreReferenceSetPosition)
- 2: Cam set position restoration (RestoreCamSetPosition)


The parameters that need to be set for the cam axis position restoration are shown below. (For details of the settings, refer to synchronous control initial position parameter.) (Page 668 Variables related to synchronous control initial position)

○: Required, △: Required when using initial setting value, —: Not required


Cam axis position restoration object (<u>AdvOutputName.Pr.Restore.PositionRestorationObject</u>)	Setting method of cam reference position (<u>AdvOutputName.Pr.Restore.ReferenceSetPositionMethod</u>)	Cam reference position (initial setting) (<u>AdvOutputName.Pr.Restore.InitialReferenceSetPosition</u>)	Setting method of current position per cycle (<u>AdvOutputName.Pr.Restore.PositionPerCycleMethod</u>)	Current position per cycle (initial setting) (<u>AdvOutputName.Pr.Restore.InitialPositionPerCycle</u>)	Restoration processing details
0: Current position per cycle restoration (RestorePositionPerCycle)	○	△	—	○ (Used as search starting position)	Restores "current position per cycle" based on "cam reference position" and "cam set position".
1: Cam reference position restoration (RestoreReferenceSetPosition)	—	—	○	△	Restores "cam reference position" based on "current position per cycle" and "cam set position".
2: Cam set position restoration (RestoreCamSetPosition)	○	△	○	△	Restores "cam set position" based on "current position per cycle" and "cam reference position".

The initial position alignment and restoration of the cam axis position are executed when MCv_AdvancedSync (Advanced Synchronous Control) is started.

- A timing chart when cam restoration is normally executed



- A timing chart when an error occurs in cam output axis restoration




Current position per cycle restoration

If Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject) is set to "0: Current position per cycle restoration (RestorePositionPerCycle)" when starting synchronous control, the current position per cycle is restored based on the cam reference position and the cam set position, and MCv_AdvancedSync (Advanced Synchronous Control) starts.

Set the cam reference position to be used for restoration with a parameter. The cam set position uses the set position of the output axis set to the slave axis when MCv_AdvancedSync (Advanced Synchronous Control) starts.

The current position per cycle restoration is calculated by searching from the beginning to the end of the cam pattern for the corresponding current position per cycle. The starting position for searching the cam pattern is set with the Current position per cycle (initial setting) (AdvOutputName.Pr.Restore.InitialPositionPerCycle). (It is also possible to search the return path in a two-way cam pattern operation.)




- With two-way cam pattern operation, if the corresponding current position per cycle is not found, "Advanced Synchronous Control Restoration Disabled" (error code: 1AF2H) occurs, and MCv_AdvancedSync (Advanced Synchronous Control) cannot start.
- With a feed operation cam pattern, if the corresponding current position per cycle is not found on the first cycle, the cam reference position is changed automatically and the pattern is searched again.
- If the cam resolution is large, search processing may take a long time when starting synchronous control. For an approximate guide of the searching time, refer to the following.
 ➞ Page 671 Restoration time of the current position per cycle
- When the Ring counter lower limit value (AxisName.Pr.Const.RingCount_LowerValue) of the output axis positioning range is "0.0", the current position is not restored in a cam stroke range that crosses over "0.0", and "Advanced Synchronous Control Restoration Disabled" (error code: 1AF2H) occurs. Execute the current position per cycle restoration within a cam stroke range between 0 and the Ring counter upper limit value (AxisName.Pr.Const.RingCount_UpperValue) of the positioning range.
- When the difference between the cam reference position and the cam set position exceeds "1000000000.0" at restoration, the current position per cycle cannot be restored correctly. Adjust the values so that the difference between the cam reference position and the cam set position is smaller than "1000000000.0" for restoration.


The following shows details of the current position per cycle restoration operation.

■ Current position per cycle restoration operation with a "two-way cam pattern operation"


- Search from "Current position per cycle = 0" (Cam starting point = 0)



- Search from the middle of the current position per cycle (Cam starting point = 0)




- Search from the middle of the current position per cycle (Cam starting point ≠ 0)




- The search fails


- When a matching cam set position is not found



- When the current position restoration is executed in a cam stroke range that crosses over "0.0" (the positioning range is "0.0 to 360.0 degrees")




- In the case above, execute current position restoration within a cam stroke range of the positioning range (0.0 to 360.0 degrees).




■ Current position per cycle restoration operation with a "feed operation cam pattern"


- Search from "Current position per cycle = 0" (Cam starting point = 0)




- Search from the middle of the current position per cycle (Cam starting point = 0)



- Search from the middle of the current position per cycle (Cam starting point $\neq 0$)



- The first search fails and a search begins for the second time




Point

If the first search fails, a second search may not be processed on the next cycle for a cam pattern with a feed stroke that is smaller than 100% of the stroke as above.

The intended current position per cycle can be found in the first search, by setting or positioning the cam reference position in advance.

Cam reference position restoration



If Cam axis position restoration object (AdvOutputName.Pr.Restore. PositionRestorationObject) is set to "1: Cam reference position restoration (RestorePositionPerCycle)" when starting synchronous control, the cam reference position is restored based on the current position per cycle and the cam command set position.
Set the current position per cycle to be used for restoration with the parameter.



Cam set position restoration

If Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject) is set to "2: Cam set position restoration (RestoreCamSetPosition)" when starting synchronous control, the cam set position is restored based on the current position per cycle and the cam reference position.

Set the current position per cycle and cam reference position to be used for restoration with the parameter.



*1 The cam set position indicated by is restored.

15

Point

The cam moves to its restored cam set position immediately after starting synchronous control when the restored cam set position is different from the set position at synchronous control start.

Cam set position restoration allowable movement setting value

When MCv_AdvancedSync (Advanced Synchronous Control) is started, if the difference between the restored cam set position and the set position of the slave axis is larger than the cam set position restoration allowable movement setting value, "Advanced Synchronous Control Restoration Disabled" (error code: 1AF2H) occurs, and synchronous control cannot start. When using cam set position restoration, before starting MCv_AdvancedSync (Advanced Synchronous Control) calculate the corresponding cam set position with MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation) or with MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation) or with synchronous control analysis mode. Start synchronous control after positioning to the correct cam set position.

Synchronous control analysis mode

With synchronous control analysis mode, synchronous control restoration is only analyzed when there is a command to start MCv_AdvancedSync (Advanced Synchronous Control). This mode is used to confirm the synchronous positions of the output axes in order to align axes with position control before starting MCv_AdvancedSync (Advanced Synchronous Control).

After starting MCv_AdvancedSync (Advanced Synchronous Control), when synchronous control analysis mode setting (Options (Options): Bit 16) of MCv_AdvancedSync (Advanced Synchronous Control) is "TRUE (Enabled)", operation enters synchronous control analysis mode.


When analysis is completed, Execution completion (Done) of MCv_AdvancedSync (Advanced Synchronous Control) turns to "TRUE", and the Output axis monitor data (AdvOutputName.Md.□) that are not synchronized in Synchronization status (AdvOutputName.Md.SyncStatus) are all updated. The following Output axis monitor data (AdvOutputName.Md.□) are also updated to the restored values. In this case, synchronous control analysis mode setting (Options (Options): Bit 16) of MCv_AdvancedSync (Advanced Synchronous Control) will not turn to "FALSE (Disabled)". When starting synchronous control without using the synchronous control analysis mode, turn synchronous control analysis mode setting (Options (Options): Bit 16) of MCv_AdvancedSync (Advanced Synchronous Control) to "FALSE (Disabled)".

Output axis monitor data (AdvOutputName.Md.□)

- Current position after composite main shaft gear (AdvOutputName.Md.Cam.MasterCompositeGearSetPosition)
- Current position per cycle after main shaft gear (AdvOutputName.Md.Cam.MasterGearPositionPerCycle)
- Current position per cycle after auxiliary shaft gear (AdvOutputName.Md.Cam.AuxGearPositionPerCycle)
- Current position per cycle (AdvOutputName.Md.Cam.PositionPerCycle)
- Cam reference position (AdvOutputName.Md.ReferenceSetPosition)
- Cam set position (AdvOutputName.Md.Cam.SetPosition)

Processing in synchronous control analysis mode


In synchronous control analysis mode, unlike normal restoration, processing is executed until monitor restoration.



Synchronous control analysis mode will not operate if the Axis status (AxisName.Md.AxisStatus) of the Slave axis (Slave) of MCv_AdvancedSync (Advanced synchronous control) is other than "4: Standby (Standstill)".

When MCv_AdvancedSync (Advanced synchronous control) is started in synchronous control analysis mode, if the cam current position per cycle cannot be restored, "Advanced Synchronous Control Restoration Disabled" (error code: 1AF2H) occurs.

Timing chart of synchronous control analysis mode



*1 Synchronization status (`AdvOutputName.Md.SyncStatus`) of the Output axis monitor data remains "0: Not synchronizing" and is not updated.

Variables related to synchronous control initial position

Synchronous control initial position parameter (AdvOutputName.Pr.Restore.)

Variable name	Name	Import ^{*1}	Data type ^{*1}	Setting value	Initial value
MasterGearPositionPerCycleMethod	Setting method of current position per cycle after main shaft gear	At start	INT (MC_GEAR_RESTORE_METHOD)	0: Previous value (PreviousPosition) 1: Current position per cycle after main shaft gear (initial setting) (InitialGearPositionPerCycle) 2: Calculate from input axis (CalculateFromInputAxis)	0: Previous value (PreviousPosition)
AuxGearPositionPerCycleMethod	Setting method of current position per cycle after auxiliary shaft gear		INT (MC_GEAR_RESTORE_METHOD)	0: Previous value (PreviousPosition) 1: Current position per cycle after auxiliary shaft gear (initial setting) (InitialGearPositionPerCycle) 2: Calculate from input axis (CalculateFromInputAxis)	0: Previous value (PreviousPosition)
PositionRestorationObject	Cam axis position restoration object		INT (MC_CAM_RESTORE_METHOD)	0: Current position per cycle restoration (RestorePositionPerCycle) 1: Cam reference position restoration (RestoreReferenceSetPosition) 2: Cam set position restoration (RestoreCamSetPosition)	0: Current position per cycle restoration (RestorePositionPerCycle)
ReferenceSetPositionMethod	Setting method of cam reference position		INT (MC_CAM_REFERENCE_METHOD)	0: Previous value (PreviousPosition) 1: Cam reference position (initial setting) (InitialReferenceSetPosition) 2: Set position (CamSetPosition)	0: Previous value (PreviousPosition)
PositionPerCycleMethod	Setting method of current position per cycle		INT (MC_CAM_CYCLE_METHOD)	0: Previous value (PreviousPosition) 1: Current position per cycle (initial setting) (InitialPositionPerCycle) 2: Current position per cycle after main shaft gear (MasterGearPositionPerCycle) 3: Current position per cycle after auxiliary shaft gear (AuxGearPositionPerCycle)	0: Previous value (PreviousPosition)
MasterGearInitialPositionPerCycle	Current position per cycle after main shaft gear (initial setting)		LREAL	0.0 to 2147483647.0	0.0
AuxGearInitialPositionPerCycle	Current position per cycle after auxiliary shaft gear (initial setting)		LREAL	0.0 to 2147483647.0	0.0
InitialReferenceSetPosition	Cam reference position (initial setting)		LREAL	-10000000000.0 to 10000000000.0	0.0
InitialPositionPerCycle	Current position per cycle (initial setting)		LREAL	0.0 to 2147483646.0	0.0
RestorationAllowablePosition	Cam set position restoration: Allowable movement amount setting		DWORD(UDINT)	0 to 2147483647 [pulse]	25600

^{*1} For details on importing and data types, refer to "List of Variables" in the following manual.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Setting method of current position per cycle after main shaft gear (AdvOutputName.Pr.Restore.MasterGearPositionPerCycleMethod)

Select the Setting method of current position per cycle after main shaft gear

(AdvOutputName.Md.Cam.MasterGearPositionPerCycle) when starting MCv_AdvancedSync (Advanced Synchronous Control).

Setting value	Description
0: Previous value (PreviousPosition)	The current position per cycle after main shaft gear from the previous synchronous control is stored.
1: Current position per cycle after main shaft gear (initial setting) (InitialGearPositionPerCycle)	The value set in Current position per cycle after main shaft gear (initial setting) (<u>AdvOutputName.Pr.Restore.MasterGearInitialPositionPerCycle</u>) is stored.
2: Calculate from input axis (CalculateFromInputAxis)	The value calculated based on the current position after composite main shaft gear is stored.

■Setting method of current position per cycle after auxiliary shaft gear (AdvOutputName.Pr.Restore.AuxGearPositionPerCycleMethod)

Select the Setting method of current position per cycle after auxiliary shaft gear

(AdvOutputName.Md.Cam.AuxGearPositionPerCycle) when starting MCv_AdvancedSync (Advanced Synchronous Control).

Setting value	Description
0: Previous value (PreviousPosition)	The current position per cycle after auxiliary shaft gear from the previous synchronous control is stored.
1: Current position per cycle after auxiliary shaft gear (initial setting) (InitialGearPositionPerCycle)	The value set in Current position per cycle after auxiliary shaft gear (initial setting) (<u>AdvOutputName.Pr.Restore.AuxGearInitialPositionPerCycle</u>) is stored.
2: Calculate from input axis (CalculateFromInputAxis)	The value calculated based on the current position of the auxiliary shaft is stored.

■Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject)

Select the restoration object from "Current position per cycle" or "Cam reference position" or "Cam set position" when starting synchronous control.

Setting value	Description
0: Current position per cycle restoration (RestorePositionPerCycle)	The current position per cycle from "Cam reference position" and "Cam set position" is restored.
1: Cam reference position restoration (RestoreReferenceSetPosition)	The cam reference position from "Current position per cycle" and "Cam set position" is restored.
2: Cam set position restoration (RestoreCamSetPosition)	The cam set position from "Current position per cycle" and "Cam reference position" is restored.

■Setting method of cam reference position

(AdvOutputName.Pr.Restore.ReferenceSetPositionMethod)

Select the setting method for the cam reference position to be used for restoration when Cam axis position restoration object

(AdvOutputName.Pr.Restore.PositionRestorationObject) is set to "0: Current position per cycle restoration (RestorePositionPerCycle)" or "2: Cam set position restoration (RestoreCamSetPosition)."

Setting value	Description
0: Previous value (PreviousPosition)	The cam reference position from the previous synchronous control is stored. The set position is stored when the cam reference position from the previous synchronous control is not saved.
1: Cam reference position (initial setting) (InitialReferenceSetPosition)	The value set in Cam reference position (initial setting) (<u>AdvOutputName.Pr.Restore.InitialReferenceSetPosition</u>) is stored.
2: Set position (CamSetPosition)	The value set in Set position (<u>AxisName.Md.SetPosition</u>) of the slave axis is stored.

■Setting method of current position per cycle

(AdvOutputName.Pr.Restore.PositionPerCycleMethod)

Set the setting method for the current position per cycle to be used for restoration when Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject) is set to "1: Cam reference position restoration (RestorePositionPerCycle)" or "2: Cam set position restoration (RestoreCamSetPosition)".

Setting value	Description
0: Previous value (PreviousPosition)	The current position per cycle from the previous synchronous control is stored as is.
1: Current position per cycle (initial setting) (InitialPositionPerCycle)	The value set in Current position per cycle (initial setting) (AdvOutputName.Pr.Restore.InitialPositionPerCycle) is stored.
2: Current position per cycle after main shaft gear (MasterGearPositionPerCycle)	Current position per cycle after main shaft gear (AdvOutputName.Md.Cam.MasterGearPositionPerCycle) is stored.
3: Current position per cycle after auxiliary shaft gear (AuxGearPositionPerCycle)	Current position per cycle after auxiliary shaft gear (AdvOutputName.Md.Cam.AuxGearPositionPerCycle) is stored.

■Current position per cycle after main shaft gear (initial setting)

(AdvOutputName.Pr.Restore.MasterGearInitialPositionPerCycle)

Set the initial setting value of the current position per cycle after main shaft gear when Setting method of current position per cycle after main shaft gear (AdvOutputName.Pr.Restore.MasterGearPositionPerCycleMethod) is set to "1: Current position per cycle after gear (Initial setting) (InitialGearPositionPerCycle)".

The setting unit is the unit of the input axis set to Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control). Set within the range from "0.0 to (Length per cycle - 0.00001)".

■Current position per cycle after auxiliary shaft gear (initial setting)

(AdvOutputName.Pr.Restore.AuxGearInitialPositionPerCycle)

Set the initial setting value of the current position per cycle after auxiliary shaft gear when Setting method of current position per cycle after auxiliary shaft gear (AdvOutputName.Pr.Restore.AuxGearPositionPerCycleMethod) is set to "1: Current position per cycle after gear (initial setting) (InitialGearPositionPerCycle)".

The setting unit is the unit of the input axis set to Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control). Set within the range from "0.0 to (Length per cycle - 0.00001)".

■Cam reference position(initial setting)

(AdvOutputName.Pr.Restore.InitialReferenceSetPosition)

Set the initial value of the cam reference position in the units of the axis set to the output axis Axis information (AdvOutputName.Pr.Restore.ReferenceSetPositionMethod) is set to "1: Cam reference position (initial setting) (InitialReferenceSetPosition)".

■Current position per cycle (initial setting)

(AdvOutputName.Pr.Restore.InitialPositionPerCycle)

Set a value according to the setting for Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject).

The setting unit is the unit of the input axis set to Master axis (Master) of MCv_AdvancedSync (Advanced Synchronous Control). Set within the range from "0.0 to (Length per cycle - 0.00001)".

Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject)	Description
0: Current position per cycle restoration (RestorePositionPerCycle)	Set the starting point for search processing to restore the current position per cycle. Set to restore the position on the return path of a two-way operation cam pattern. For details on search processing, refer to the following.  Page 660 Current position per cycle restoration
1: Cam reference position restoration (RestoreReferenceSetPosition)	Set the initial setting value for the current position per cycle when Setting method of current position per cycle (AdvOutputName.Pr.Restore.PositionPerCycleMethod) is set to "1: Current position per cycle (initial setting) (InitialPositionPerCycle)".
2: Cam set position restoration (RestoreCamSetPosition)	

■Cam set position restoration: Allowable movement amount setting (AdvOutputName.Pr.Restore.RestorationAllowablePosition)

Set the allowable value of the difference between the restored cam set position and the set position in units of the servo command value of the output axis when Cam axis position restoration object (AdvOutputName.Pr.Restore.PositionRestorationObject) is set to "2: Cam set position restoration (RestoreCamSetPosition)". If the setting value is large, a rapid operation may occur when starting synchronous control.



The MR-J5(W)-G servo parameter "In-position range (PA10)" initial value (25600) is set as the initial value.

Precautions

Accuracy at restoration

Since accuracy of the advanced synchronous control output axis is guaranteed for up to 5 decimal places, the calculations during restoration are also performed with this accuracy.

Therefore, depending on the position of the output axis, the fourth decimal place of the current position of the output axis may move slightly, but this does not result in position displacement.

Depending on parameter settings and programs, the axis may move significantly at restoration. For safety reasons, check the movement amount by restoration in synchronous control analysis mode before starting synchronous control.

Current position per cycle restoration for coordinate data

- When the final point of cam data is larger than the length per cycle, the entire range of cam data is searched regardless of the set value of the length per cycle, which may result in restoration to a position different from the path of synchronous control.
- When the final point of cam data is smaller than the length per cycle, the current position per cycle may become larger than the length per cycle depending on the relation between the cam set position and the cam reference position.
- When using the coordinate data, it is recommended to match the final point of cam data with the length per cycle.

Restoration time of the current position per cycle

The current position per cycle restoration completion time varies depending on the resolution, coordinate number, and the restoration settings.

An approximate guide of the restoration time is shown below.

■Cam data (section interpolation/spline interpolation)/rotary cutter

Resolution/Coordinate number	256			65535		
Operation cycle [ms]	0.25	0.5	1.0	0.25	0.5	1.0
Restoration time [ms]	0.4	0.3	0.4	5.2	4.7	4.5

■Cam data (section interpolation)

Resolution/Coordinate number	256			65535		
Operation cycle [ms]	0.25	0.5	1.0	0.25	0.5	1.0
Restoration time [ms]	0.4	0.3	0.4	5.8	4.7	4.9

Method to restart synchronous control

The relationship of the synchronous position for synchronous control is always saved in the Motion module. Synchronous control can be restarted without returning all axes to their starting points by restoring the synchronized relationship through the synchronous control initial position parameters. (Page 668 Synchronous control initial position parameter (AdvOutputName.Pr.Restore.))

For an example, refer to the following.

Page 695 Filling machine

15.6 Cam Position Calculation Function

The cam position calculation function calculates the current position per cycle and the cam set position with the following Motion control FBs.

- MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation)
- MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation)

This function is used to calculate the synchronous position of the output axis for the synchronous position alignment before starting advanced synchronous control.

With the synchronous control analysis mode, the output axis whose position is to be calculated must be in the standby status (the Axis status (AxisName.Md.AxisStatus) is "4: Standby (Standstill)"). However, with the cam position calculation function, the cam position calculation can be executed regardless of the output axis status, thus it is used to calculate the synchronous position of the next control in advance while the output axis is operating.

Control details

Setting the ring counter

Set the Ring counter upper limit value (AxisName.PrConst.RingCount_UpperValue) of the output axis to the Ring counter upper limit (RingCountUpperValue) of MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation) or MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation). When a value other than "0.0" is set to Ring counter upper limit (RingCountUpperValue), the ring counter lower limit is calculated as "0.0".

Setting the cam starting point

- Set the cam position calculation Cam starting point (StartingPoint) of MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Cam Set Position Calculation) or MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation) when taking into account the cam starting point for calculations.
- The cam position calculation Cam starting point (StartingPoint) sets the position to start cam data in resolution. This is valid only in the following cases.
 - When the Interpolation method specification (Interpolate) of the operation profile is "1: Section interpolation" or "2: Spline interpolation"
 - When the data type is set to "Rotary cutter"

Current position per cycle calculation (MCv_AdvPositionPerCycleCalc)


When the Execute command (Execute) is changed from FALSE to TRUE, the current position per cycle is calculated based on the cam position calculation Cam reference position (ReferenceSetPosition) and the cam position calculation Cam set position (SetPosition) from the cam data. The calculation result is outputted to the Calculation result (CalculationResult).

■When the ring counter upper limit is set

The cam position calculation cam reference position and the cam position calculation cam set position are rounded to the ring counter upper limit and then calculated when the cam position calculation Ring counter upper limit (RingCountUpperValue) is set.

■When the cam starting point is set

The cam starting point is taken into account for the current position per cycle calculation when the cam position calculation Cam starting point (StartingPoint) is set.



■Searching the current position per cycle

When calculating the current position per cycle from the cam data, the position corresponding to the cam position calculation cam set position is searched from the cam data based on the position set in the cam position calculation Current position per cycle (PositionPerCycle).

The cam position calculation cam set position is searched with the following procedure.

- Cam data (when the Interpolation method specification (Interpolate) of the operation profile is "1: Section interpolation" or "2: Spline interpolation", or when the data type is set to "Rotary cutter")

■When "nth point of cam data ≤ Cam position calculation Current position per cycle (PositionPerCycle) < Cam data n + First point"

- The position corresponding to the cam position calculation Cam set position (SetPosition) is searched from the nth point of cam data.

■When the cam position calculation current position per cycle (PositionPerCycle) is in the middle of cam data and there is no corresponding position until the last point of cam data


- The search returns to the 0th point of cam data and searches to the position where the search started.

■When there is no corresponding position after searching the entire range of cam data

- For a two-way cam, "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs.
- For a feed cam, the cam position calculation Cam set position (SetPosition) is calculated from the stroke difference, and the entire range is searched from the 0th point. When there is no corresponding position after researching, "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs.


<Example 1>

When the cam position calculation Current position per cycle (PositionPerCycle) corresponds to the 0th point of cam data



<Example 2>


When the cam position calculation Current position per cycle (PositionPerCycle) corresponds to the 128th point of cam data



- Cam data (when the Interpolation method specification (Interpolate) of the operation profile is "0: Linear interpolation")
 - Range before the first point of cam data
 - When the first point of cam data is larger than 0 and "Cam position calculation Current position per cycle (PositionPerCycle) < First point of cam data" is satisfied, the position corresponding to the cam position calculation Cam set position (SetPosition) is searched from the range before the first point of cam data.
 - When there is no corresponding position in range (1), range (2) is searched. When there is also no corresponding position in range (2), range (3) is searched.
 - When there is no corresponding position after searching range (1) to (3), "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs for a two-way cam.
 - For a feed cam, the cam position calculation Cam set position (SetPosition) is calculated from the stroke difference, and the entire range is searched from the 0th point. When there is no corresponding position even after researching, "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs.

<Example>

When the cam position calculation current position per cycle is before the first point of cam data



*: Search from range (1).


*: When there is no corresponding position in range (1), search in order from the first point of cam data in range (2).

■ Within the cam data range

- When "Cam position calculation Current position per cycle (PositionPerCycle) < Last point of cam data" is satisfied, the position corresponding to the cam position calculation Cam set position (SetPosition) is searched from within the cam data range.
- When "nth point of cam data ≤ Cam position calculation current position per cycle < Cam data n + First point" is satisfied, the position corresponding to the cam position calculation cam set position is searched from the nth point of cam data.
- When the cam position calculation current position per cycle is in the middle of cam data and there is no corresponding position until the last point of cam data, the search returns to the first point of cam data and searches to the position where the search started.
- When there is no corresponding position in range (1), range (2) is searched. When there is no corresponding position in range (2) either, range (3) is searched.
- When there is no corresponding position after searching range (2) to (3), "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs for a two-way cam.
- For a feed cam, the cam position calculation cam set position is calculated from the stroke difference, and the entire range is searched from the 0th point. When there is no corresponding position even after researching, "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs.

<Example 1>


When the cam position calculation current position per cycle is before the first point of cam data



- 1 Search from cam data first point to second point, second point to third point, and up to fourth point to fifth point (last point) in order.
- 2 If there is no corresponding position until the last point of cam data, search from range (3).

<Example 2>

When the cam position calculation current position per cycle corresponds to the third point of cam data



- 1 Search in the order from cam data third point to fourth point, fourth point to fifth point (last point).
- 2 If there is no corresponding position until the last point of cam data, search from the first point of cam data.
- 3 If there is no corresponding position in the cam data first point to second point and second point to third point, search from range (3).


■Range from the cam data last point to the length per cycle

When "Last point of cam data ≤ Cam position calculation Current position per cycle (PositionPerCycle) < Length per cycle" is satisfied, the position corresponding to the cam position calculation Cam set position (MCv_AdvPositionPerCycleCalc.SetPosition) is searched from the range after the last point of cam data.

If there is no corresponding position after searching range (3), "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs for a two-way cam. For a feed cam, the cam position calculation cam set position is calculated from the stroke difference, and the entire range is searched from the 0th point. When there is no corresponding position even after researching, "Unable to Calculate Cam Position Under Advanced Synchronous Control" (error code: 34AFH) occurs.

<Example>

When the cam position calculation current position per cycle corresponds to the last point of cam data



① Search from range (3).


Cam set position calculation (MCv_AdvCamSetPositionCalc)

When the Execute command (Execute) is changed from "FALSE" to "TRUE", the cam set position is calculated based on the cam position calculation Current position per cycle (PositionPerCycle) and the cam position calculation Cam reference position (ReferenceSetPosition). The calculation result is outputted to the Calculation result (CalculationResult).


■When the ring counter upper limit is set

The calculation result is rounded to a value that takes into account the ring counter when the cam position calculation Ring counter upper limit (RingCountUpperValue) is set.

- When the calculation result does not exceed the ring counter upper limit




- When the calculation result exceeds the ring counter upper limit



■When the cam starting point is set

The cam set position is calculated with the current position per cycle that takes into account the cam starting point when the cam position calculation Cam starting point (StartingPoint) is set.



Precautions

- Set the cam data to expand automatically in the expand setting in advance, or send it to the open area with MC_CamTableSelect (Cam Table Selection) for use.
- Apply the calculation results of the Current position per cycle calculation (MCv_AdvPositionPerCycleCalc) and the Cam set position calculation (MCv_AdvCamSetPositionCalc) only to MCv_AdvancedSync (Advanced Synchronous Control). If they are applied to Motion FBs (such as MC_CamIn) other than MCv_AdvancedSync (Advanced Synchronous Control), the calculation result and the actual operation will not match.
- The current position per cycle calculation of the coordinate data may result as follows depending on the length per cycle of the last point of cam data.

Last point of cam data	Description
Larger than the length per cycle	The entire range of cam data is searched regardless of the set value of the length per cycle, which may result in a different calculation result from the path of synchronous control.
Smaller than the length per cycle	The current position per cycle may become larger than the length per cycle depending on the relation between the cam set position and the cam reference position. When using the coordinate data, it is recommended to match the final point of cam data with the length per cycle.

15.7 Applied Functions

Phase compensation function

In synchronous control, delays in progresses, etc. cause the phase to deviate at the output axis motor shaft end with respect to the input axis (real drive, real encoder axis, virtual encoder axis). The phase compensation function compensates in this case so that the phase does not deviate.

Phase compensation can be set for the input and the output axis. It is possible to compensate using the delay time peculiar to the system based on the input axis type on the input axis side. It is also possible to use a compensation delay time equivalent to the position deviation for each drive unit on the output axis side.

Phase compensation on delay time of the input axis

Set delay time peculiar to the system in the phase compensation advance time of the input axis (AdvInputName.Pr.PhaseCompensationAdvanceTime). For reference, the delay time peculiar to a system with MR-J5(W)-G connected to the drive unit is shown below. As the delay time will change depending on the actual equipment configuration, make adjustments from reference values below.

■ Delay time peculiar to the system for a real drive axis (MR-J5(W)-G)*1

The delay time depending on the setting of data source selection (AdvInputName.PrConst.SourceValue) is as follows.

- When set to "1: Set value (mcSetValue)" or "101: Latest set value (mcLatestSetValue)"
 - Delay time: 0 [μs]
- When set to "2: Actual value (mcActualValue)" or "102: Latest actual value (mcLatestActualValue)"

The delay time is calculated using the following formula.

Motion Synchronization Station Send/Receive Data Refresh Method (System.PrConst.Link_MotionStationRefreshType)	
0: Response preferred method (EmphasisResponse)	1: Operation cycle preferred method (EmphasisOperationCycle)
Operation cycle × 5 + 750 [μs]	Operation cycle × 7 + 750 [μs]

- *1 The delay time of "1: Set value (mcSetValue)" and "2: Actual value (mcActualValue)" is the delay time of "101: Latest set value (mcLatestSetValue)" and "102: Latest actual value (mcLatestActualValue)" + 1 operation cycle.
When compensating a delay, set the value obtained by adding 1 operation cycle to the delay time peculiar to the system as the compensation time.

■ Delay time peculiar to the system for a real encoder axis*1

The delay time is calculated using the following formula and does not depend on the setting of data source selection (AdvInputName.PrConst.SourceValue).

Motion Synchronization Station Send/Receive Data Refresh Method (System.PrConst.Link_MotionStationRefreshType)	
0: Response preferred method (EmphasisResponse)	1: Operation cycle preferred method (EmphasisOperationCycle)
Operation cycle × 5 + 750 [μs]	Operation cycle × 7 + 750 [μs]

- *1 The delay time of "1: Set value (mcSetValue)" and "2: Actual value (mcActualValue)" is the delay time of "101: Latest set value (mcLatestSetValue)" and "102: Latest actual value (mcLatestActualValue)" + 1 operation cycle.
When compensating a delay, set the value obtained by adding 1 operation cycle to the delay time peculiar to the system as the compensation time.

■ Delay time peculiar to the system for a virtual encoder axis

The delay time is calculated using the following formula.

- Delay time peculiar to the input target + Virtual encoder input value refresh time [μs]

Ex.

For the following

Example	Description
1	<p>■ When setting the MR-J5(W)-G object data <code>_PosActualValue</code> (<code>AxisName.Md.Io_PosActualValue</code>) to the virtual encoder axis object data (<code>AxisName.PrConst.SlaveObject.PosActualValue</code>) settings</p> <ul style="list-style-type: none"> • Delay time peculiar to the real drive axis^{*1} + Refresh cycle of <code>AxisName.Md.Io_PosActualValue</code> (1 operation cycle)
2	<p>■ When updating the virtual encoder axis encoder input value (<code>AxisName.Cd.Encoder_InputValue</code>) with a counter value of another unit in an ST program</p> <ul style="list-style-type: none"> • Delay time peculiar to the counter + ST program scan time
3	<p>■ When using the encoder value of an encoder connected with the drive unit</p> <p>For the setting example, refer to the following.</p> <p>☞ Page 53 When using the encoder value of a scale measurement encoder connected with the drive unit</p> <p>A rough standard for the delay time peculiar to the system is the same value as the delay time peculiar to the system for a real encoder axis. For the delay time peculiar to the system for a real encoder axis, refer to the following.</p> <p>☞ Page 679 Delay time peculiar to the system for a real encoder axis^{*1}</p>

*1 "102: Latest actual value (`mcLatestActualValue`)" of data source selection (`AdvInputName.PrConst.SourceValue`)

■ Delay time peculiar to the system for a virtual drive axis/virtual linked axis

The delay time is "0 [μs]" and does not depend on the setting of data source selection (`AdvInputName.PrConst.SourceValue`).

Phase compensation of delay time of the output axis

Set delay time equivalent to the position deviation on the drive unit in the output axis phase compensation advance time (`AdvOutputName.Pr.Cam.PhaseCompensationAdvancedTime`). The delay time equivalent to position deviation of the drive unit is calculated using the following formula.

<When using MR-J5(W)-G>

Delay time [μs] = $1000000 \div \text{Servo parameter "Model loop gain (PB07)"}$

When the servo parameter "Feed forward gain (PB04)" is set, the delay time is set to a smaller value than the value listed above.

The model loop gain will change when "Gain adjustment mode selection (PA08.0)" is set to "1: Auto tuning mode 1" or "2: Auto tuning mode 2". For axes executing phase compensation, set "3: Manual mode" or "0: 2 gain adjustment mode 1 (interpolation mode)" to prevent model loop gain from changing.

Setting example

When the output axis is synchronized with a synchronous encoder axis, the phase compensation advance time is set as follows.

- When model loop gain of the output axis is 80

Setting item	Setting value
Input axis	<p>Phase compensation advance time (<code>AdvInputName.Pr.PhaseCompensationAdvanceTime</code>)</p> <p>Set the delay time peculiar to the system for a real encoder axis. Refer to the following for delay time peculiar to the system for a real encoder axis.</p> <p>☞ Page 679 Delay time peculiar to the system for a real encoder axis^{*1}</p>
Output axis	<p>Phase compensation advance time (<code>AdvOutputName.Pr.Cam.PhaseCompensationAdvancedTime</code>)</p> <p>$1000000 \div 80 = 12500$ [μs]</p>


When the slave axis set velocity overshoots or undershoots during acceleration/deceleration, set a longer time for the phase compensation time constant.

15.8 Example Programs


Example programs for advanced synchronous control are shown below.

Flying cutter

This section describes the example program and how to use a clutch operation that uses an advanced synchronous control FB sensor input based on a flying cutter system.




<Operation flow>



Setting item	(1) Conveyor axis	(1) Synchronous encoder axis	(2) Cutter drive axis	(3) Cutter rising/ lowering axis	Virtual drive axis for cutter drive axis highspeed return operation
Axis name	Conveyor	ConveyorEncoder	CutterDrive	CutterUpDown	CutterDriveBack
Axis type	Real drive axis	Real encoder axis	Real drive axis	Real drive axis	Virtual drive axis
Real encoder axis type setting	—	Via drive unit	—	—	—
Station address	192.168.3.1	192.168.3.1	192.168.3.2	192.168.3.3	—
Position command unit	μm	μm	μm	μm	μm
Speed command unit	U/min	U/min	U/min	U/min	U/min

Operation overview

1. Advanced synchronous control FB starts with the conveyor axis as the "input axis" and the cutter drive axis as the "output axis".
2. The sensor input starts the clutch ON operation of the main shaft clutch.
3. After completing main shaft clutch ON smoothing, the speed of the conveyor axis and the cutter drive axis are the same.
4. The cutter rising/lowering axis is started by positioning control when the speed of the conveyor axis and the cutter drive axis become the same, and it cuts the workpiece.
5. After completing the cutting of the workpiece (completion of positioning control of the cutter rising/lowering axis), the main shaft clutch turns OFF and the cutter drive axis is stopped.
6. After stopping the cutter drive axis, positioning of the virtual drive axis that is set as the auxiliary shaft returns the cutter drive axis to its initial position.
7. Step 2. to 6. are repeated.



Parameter settings

■Setting of the real encoder axis (conveyor axis) to be used as the input axis of advanced synchronous control

In the "CC-Link IE TSN Configuration" screen under Network Configuration Settings in GX Works3, add the required objects for the real encoder axis in the "PDO Mapping Setting" of the MR-J5(W)-G(-RJ) that uses a synchronous encoder in [PDO Mapping Setting] ⇒ "<Detail Setting>" ⇒ "PDO Mapping Setting" screen.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Parameter(Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]

- RPDO mapping
 - None
- TPDO mapping

Index	Sub-index	Entry name	Data type
2d36	00	Scale cycle counter	UNSIGNED32
2d37	00	Scale ABS counter	INTEGER32
2d3c	00	Scale measurement encoder reception	UNSIGNED32

Also, when using a synchronous encoder, the scale measurement function must be enabled in MR-J5(W)-G(-RJ). Set the following servo parameter.

No.	Symbol	Name	Setting value
PA22.3	**PCS	Scale measurement function selection	Set 1 or 2. • 1: Use with absolute position detection system • 2: Use with incremental system

For the settings of the real encoder axis, refer to the following.

Page 43 Real encoder axis

■Setting of the sensor input (MR-J5(W)-G(-RJ) touch probe function)

In the "CC-Link IE TSN Configuration" screen under Network Configuration Settings in GX Works3, add the required objects for the touch probe function in the "PDO Mapping Setting" of the MR-J5(W)-G(-RJ) that uses a touch probe in [PDO Mapping Setting] ⇒ "<Detail Setting>" ⇒ "PDO Mapping Setting" screen.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]

- RPDO mapping

Index	Sub-index	Entry name	Data type
60b8	00	Touch probe function	UNSIGNED16

- TPDO mapping

Index	Sub-index	Entry name	Data type
60b9	00	Touch probe status	UNSIGNED16
60d1	00	Touch probe time stamp 1 positive	UNSIGNED32
60d2	00	Touch probe time stamp 1 negative	UNSIGNED32

In the "Network I/O" screen of Motion Control Setting Function of GX Works3, make the Touch probe function set in the RPDO mapping and TPDO mapping into a slave label.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Extended Parameter] ⇒ [Motion Control Setting Function] ⇒ Navigation window ⇒ [Network I/O]

For touch probe function settings, refer to the following.

Page 767 External signal high-accuracy input

For how to make slave labels, refer to the following.

Page 718 How to use the slave label

■Advanced synchronous control parameter settings

Set the parameters of the axes to be used as the input/output of the advanced synchronous control FB.


Parameter	Axis used
Input axis parameter	<ul style="list-style-type: none"> Conveyor axis Virtual drive axis for cutter drive axis highspeed return operation
Output axis parameter	<ul style="list-style-type: none"> Cutter drive axis

• Input axis parameter settings

In the "Advanced Synchronous Input Setting" screen of Motion Control Setting Function, configure the input axis settings of the main shaft and auxiliary shaft used by the advanced synchronous control FB.

Data name	Setting details
AdvInput_Conveyor	Real encoder axis (ConveyorEncoder) of the conveyor axis
AdvInput_CutterDriveBack	Virtual drive axis (CutterDriveBack) used for cutter drive axis highspeed return operation

 Motion Control Setting Function ⇒ Navigation window ⇒ [Add-on Data] ⇒ [Advanced Synchronous Control] ⇒ [Input Setting]



Advanced Synchronous Input Setting

Setting Item List

Input the Setting Item to Search

Select Folder Display All Data

Item	AdvInput_Conveyor	AdvInput_CutterDriveBack
Axis Label ID	1	2
Axis Information	ConveyorEncoder	CutterDriveBack
Parameter Constant	AdvInput.PrConstExpands setting values at input axis variable initialization.Re-	
Data Source Selection	I:Set Value	I:Set Value
Smoother Time Constant	0 ms	0 ms
Phase Compensation Time Constant	10 ms	10 ms
Moving Direction Restriction	0:Without Moving Direction Restriction	0:Without Moving Direction Restriction
Parameter	AdvInput.PrExpands initial values at input axis variable initialization.Re-import	
Phase Compensation Advance Time	0 us	0 us

Explanation

AdvInput.LabelID
Set the label ID of the input axis.

[Setting Range]
1 to 256

Item List Find Result


Restore the Default Settings With Selected Write Variables Read Variables

Apply

- Output axis parameter settings

In the "Advanced Synchronous Output Setting" screen of Motion Control Setting Function, configure the output axis settings of the output axes used by the advanced synchronous control FB.

 Motion Control Setting Function ⇒ Navigation window ⇒ [AddOn Data] ⇒ [Advanced Synchronous Control] ⇒ [Output Setting]



■ Settings of axes used by output axis and auxiliary shaft

Setting item	Setting value
Axis information (<u>AdvOutputName.Axis</u>)	CutterDrive (the axis used as the cutter drive axis)
Auxiliary shaft target (<u>AdvOutputName.Pr.AuxAxis</u>)	CutterDriveBack (the axis used for the cutter axis highspeed return operation)

■ Settings for main shaft/auxiliary shaft

Setting item	Setting value
Composite main shaft gear (<u>AdvOutputName.Pr.Gear.MasterCompositeGear</u>)	0001: Inputs of master axis +, no inputs of sub input axis
Main shaft gear: Numerator (<u>AdvOutputName.Pr.Gear.MasterNumerator</u>)	1
Main shaft gear: Denominator (<u>AdvOutputName.Pr.Gear.MasterDenominator</u>)	1
Composite auxiliary shaft gear (<u>AdvOutputName.Pr.Gear.AuxCompositeGear</u>)	0011: Inputs of master axis +, inputs of slave axis +
Auxiliary shaft gear: Numerator (<u>AdvOutputName.Pr.Gear.AuxNumerator</u>)	1
Auxiliary shaft gear: Denominator (<u>AdvOutputName.Pr.Gear.AuxDenominator</u>)	1

■Main shaft clutch setting

Setting item	Setting value
Main shaft clutch ON control setting (<u>AdvOutputName.Pr.Clutch.MasterOnControl</u>)	15: I/O data specification (ClutchSignal)
Main shaft clutch OFF control setting (<u>AdvOutputName.Pr.Clutch.MasterOffControl</u>)	1: Clutch command (ClutchCommand)
Main shaft clutch ON signal setting (Signal target) (<u>AdvOutputName.Pr.MasterOnClutchSignal.Source.Target</u>)	[OBJ]0x60B90010.6@192.168.3.1 (Touch probe 1 rising edge latch complete toggle status)
Main shaft clutch ON signal setting (Signal detection method) (<u>AdvOutputName.Pr.MasterOnClutchSignal.Detection</u>)	4: Detection at rising edge/falling edge (BothEdges)
Main shaft clutch ON signal setting (Compensation time) (<u>AdvOutputName.Pr.MasterOnClutchSignal.CompensationTime</u>)	0.0 [s]
Main shaft clutch ON signal setting (Filter time) (<u>AdvOutputName.Pr.MasterOnClutchSignal.FilterTime</u>)	0.0 [s]
Main shaft clutch reference address setting (<u>AdvOutputName.Pr.Clutch.MasterReference</u>)	0: Current position before gear (GearFrontPosition)
Movement amount before main shaft clutch ON (<u>AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOn</u>)	0.0 [mm]
Movement amount before main shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.MasterMovementAmountBeforeOff</u>)	330.0 [mm]
Main shaft clutch smoothing method (<u>AdvOutputName.Pr.ClutchMasterSmoothingMethod</u>)	4: Slippage method (linear) (SlippageLinear))
Slippage amount at main shaft clutch ON (<u>AdvOutputName.Pr.Clutch.MasterOnSlippageAmount</u>)	50.0 [mm] (Distance between the sensor position and the cutter drive axis initial position)
Slippage amount at main shaft clutch OFF (<u>AdvOutputName.Pr.Clutch.MasterOffSlippageAmount</u>)	20.0 [mm]

Program creation

■Enabling the touch probe function of MR-J5(W)-G(-RJ)

Use the label created in "Setting of the sensor input (MR-J5(W)-G(-RJ) touch probe function)" to enable the touch probe function.

ST program

```
// TouchProbe Enable
MR_J5_G_RJ_001_TouchProbeFunction:=UINT#16#0013;
```

- Labels used
- None

■Starting advanced synchronous control

Confirm that the input axis is enabled (AdvInput_Conveyor.Md.ActiveStatus is "1: Input axis enabled") and the output axis is on standby (CutterDrive.Md.AxisStatus is "4: Standby (Standstill)") before starting the advanced synchronous control FB.

- Example program

ST program

```
IF gb_SystemStart THEN
  // AdvSync Start
  IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
    CutterDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill THEN
    gb_AdvSync_Drive_Enable:=TRUE;
  END_IF;
END_IF;

MCv_AdvancedSync_Drive(
  Master:= AdvInput_Conveyor.Axis,
  Slave:= AdvOutput_CutterDrive.Axis,
  Enable:= gb_AdvSync_Drive_Enable,
  InSync=> gb_AdvSync_Drive_InSync);
```

- Labels used

Label name	Data type	Comment
gb_SystemStart	Bit	System start command
MCv_AdvancedSync_Drive	MCv_AdvancedSync	Advanced synchronous control FB (cutter drive axis)
gb_AdvSync_Drive_Enable	Bit	Advanced synchronous control FB start command
gb_AdvSync_Drive_InSync	Bit	Advanced synchronous control FB synchronizing

■Starting the conveyor axis (JOG Operation)

Confirm that the output axis is synchronized (AdvOutput_CutterDrive.Md.SyncStatus is"1: In synchronization") and start JOG operation on the conveyor axis.

- Example program

ST program

```
IF gb_SystemStart THEN
  // ConveyorAxis Move
  IF AdvOutput_CutterDrive.Md.SyncStatus=1 THEN
    gl_SetSpeedComveyor:=40000000.0;
    gb_MoveConveyorReq:=TRUE;
  END_IF;
END_IF;

MCv_Jog_Conveyor(
  Axis:= Conveyor.AxisRef,
  JogForward:= gb_MoveConveyorReq,
  Velocity:= gl_SetSpeedComveyor,
  Acceleration:= 0.5,
  Deceleration:= 0.5,
  Options:= H0001);
```

- Labels used

Label name	Data type	Comment
gb_SystemStart	Bit	System start command
MCv_Jog_Conveyor	MCv_Jog	JOG operation FB (conveyor axis)
gb_MoveConveyorReq	Bit	Positive direction JOG operation command
gl_SetSpeedComveyor	Double-precision real number	Command speed of JOG operation

■Positioning control of the cutter rising/lowering axis

Confirm that smoothing is complete for output axis main shaft clutch ON (Main shaft clutch ON/OFF status (AdvOutput_CutterDrive.Md.Clutch.MasterOnOffStatus) is TRUE and main shaft clutch smoothing status (AdvOutput_CutterDrive.Md.Clutch.MasterSmoothingStatus) is FALSE), before starting positioning control of the rising/lowering cutter axis. (An example of a return operation conducted by multiple start with Buffered.)

- Example program

ST program

```
IF AdvOutput_CutterDrive.Md.Clutch.MasterOnOffStatus AND
  NOT(AdvOutput_CutterDrive.Md.Clutch.MasterSmoothingStatus) AND
  NOT(lb_CutterMoveComp) THEN
```

```
  MC_MoveAbsolute_1.Execute:=TRUE;
  IF MC_MoveAbsolute_1.Busy THEN
    MC_MoveAbsolute_2.Execute:=TRUE;
  END_IF;
END_IF;
```

```
IF MC_MoveAbsolute_1.Done AND
  MC_MoveAbsolute_2.Done THEN
  MC_MoveAbsolute_1.Execute:=FALSE;
  MC_MoveAbsolute_2.Execute:=FALSE;
  lb_CutterMoveComp:=TRUE;
END_IF;
```

```
MC_MoveAbsolute_1(
  Axis:= CutterUpDown.AxisRef,
  Position:= 30000.0 ,//30.0 [mm]
  Velocity:= 3000000.0 ,//3000000.0 [mm/min]
  Acceleration:= 0.1,
  Deceleration:= 0.1,
  Direction:= MC_DIRECTION__mcShortestWay,
  Options:= H0001);
```

```
MC_MoveAbsolute_2(
  Axis:= CutterUpDown.AxisRef,
  Position:= 0.0,
  Velocity:= 3000000.0 ,
  Acceleration:= 0.1,
  Deceleration:= 0.1,
  Direction:= MC_DIRECTION__mcShortestWay ,
  BufferMode:= MC_BUFFER_MODE__mcBuffered,
  Options:= H0001);
```

- Labels used

Label name	Data type	Comment
MC_MoveAbsolute_1	MC_MoveAbsolute	Absolute positioning (cutting operation)
MC_MoveAbsolute_2	MC_MoveAbsolute	Absolute positioning (retracting operation)
lb_CutterMoveComp	Bit	Cutter operation complete flag

■Cutter drive axis high-speed return operation (positioning control of the virtual drive axis set to auxiliary shaft)

Confirm that smoothing is complete for output axis main shaft clutch ON (Main shaft clutch ON/OFF status (AdvOutput_CutterDrive.Md.Clutch.MasterOnOffStatus) is TRUE and main shaft clutch smoothing status (AdvOutput_CutterDrive.Md.Clutch.MasterSmoothingStatus) is FALSE), and positioning control of the cutter rising/lowering axis is complete before starting positioning control of the virtual drive axis (CutterDriveBack) set to auxiliary shaft.

- Example program

ST program

```
IF NOT(AdvOutput_CutterDrive.Md.Clutch.MasterOnOffStatus) AND
  NOT(AdvOutput_CutterDrive.Md.Clutch.MasterSmoothingStatus) AND
  lb_CutterMoveComp THEN
  MC_MoveRelative_1.Execute:=TRUE;
END_IF;
```

```
IF MC_MoveRelative_1.Done THEN
  MC_MoveRelative_1.Execute:=FALSE;
  lb_CutterMoveComp:=FALSE;
END_IF;
```


```
MC_MoveRelative_1(
  Axis:= CutterDriveBack.AxisRef,
  Distance:= -250000.0,
  Velocity:= 3000000.0,
  Acceleration:= 0.5,
  Deceleration:= 0.5,
  Options:= H0001);
```

- Labels used

Label name	Data type	Comment
MC_MoveRelative_1	MC_MoveRelative	Relative positioning (cutter drive axis return operation)
lb_CutterMoveComp	Bit	Cutter operation complete flag


Timing chart

The timing chart for the operation that uses the program example is shown below.



Filling machine


This section describes the example program and how to use synchronous control of multiple axes that use an advanced synchronous control FB operation profile (cam data), and how to restart synchronous control based on a filling machine system.



Setting item	(1) Conveyor axis	(2) Nozzle drive axis	(3) Nozzle axis
Axis name	Conveyor	NozzleDrive	Nozzle
Axis type	Real drive axis	Real drive axis	Real drive axis
Station address	192.168.3.1	192.168.3.2	192.168.3.3
Position command unit	μm	μm	μm
Speed command unit	U/min	U/min	U/min

Operation overview

1. An advanced synchronous control FB starts with the conveyor axis as the input axis and the nozzle drive axis as the output axis. Additionally, an advanced synchronous control FB starts with the conveyor axis as the input axis and the nozzle axis as the output axis.
2. The conveyor axis starts. The nozzle drive axis and the nozzle axis synchronize with the conveyor axis according to the set length per cycle and operation profile (cam data) and execute the operations in step 3. to 6.
3. The nozzle is set on the nozzle axis.
4. The bottle is filled.
5. The nozzle on the nozzle axis is ejected.
6. The nozzle drive axis and nozzle axis return to the reference position.
7. Step 3. to 6. are repeated.




Creating an operation profile (cam data)

The following describes how to create the operation profile (cam data) used by the nozzle drive axis and nozzle axis output axes.

■Creating the nozzle drive axis operation profile (cam data)

Create the "NozzleDrivePattern" cam data below with "Profile ID: 1" as the operation profile (cam data).


Step	Cam pattern details of each step	Setting details
2. to 5.	Cam pattern that synchronizes the speed with the conveyor axis	<ul style="list-style-type: none">• Current position per cycle: 0.0 [mm] → 600000.0 [mm]• Stroke amount: 0.0 [%] → 60.0 [%]
6.	Cam pattern that returns the nozzle drive axis to the reference position	<ul style="list-style-type: none">• Current position per cycle: 600000.0 [mm] → 1000000.0 [mm] (0.0 [mm])• Stroke amount: 60.0 [%] → 0.0 [%]



■Creating the nozzle axis operation profile (cam data)

Create the "NozzlePattern" cam data below with "Profile ID: 2" as the operation profile (cam data).

Step	Cam pattern details of each step	Setting details
3.	Cam pattern for the nozzle setting operation	<ul style="list-style-type: none">• Current position per cycle: 100000.0 [mm] → 150000.0 [mm]• Stroke amount: 0.0 [%] → -100.0 [%]
4.	Cam pattern while filling (operation that gradually raises the nozzle)	<ul style="list-style-type: none">• Current position per cycle: 150000.0 [mm] → 450000.0 [mm]• Stroke amount: 0.0 [%] → -100.0 [%] → 0.0 [%]
5.	Cam pattern for the nozzle eject operation	<ul style="list-style-type: none">• Current position per cycle: 500000.0 [mm] → 550000.0 [mm]• Stroke amount: 0.0 [%] → 0.0 [%] → 50.0 [%]
6.	Cam pattern that returns the nozzle to the reference position	<ul style="list-style-type: none">• Current position per cycle: 950000.0 [mm] → 1000000 [mm] (0.0 [mm])• Stroke amount: 0.0 [%] →50.0 [%] → 0.0 [%]



Parameter settings

Set the input axis parameters for the axis (conveyor axis) to be used as the input for the advanced synchronous control FB and the output axis parameters for the axes (nozzle drive axis and nozzle axis) to be used as the output for the advanced synchronous control FB.

Set the parameters for the axes used as the input/output for the advanced synchronous control FB.


Parameter	Axis used
Input axis parameter	• Conveyor axis
Output axis parameter	• Nozzle drive axis • Nozzle axis

■Advanced synchronous control input axis parameter settings

In the "Advanced Synchronous Input Setting" screen of Motion Control Setting Function, configure the input axis settings of the main shaft and auxiliary shaft used by the advanced synchronous control FB.

Data name	Setting details
AdvInput_Conveyor	Real drive axis (Conveyor) of the conveyor axis

 Motion Control Setting Function ⇒ Navigation window ⇒ [Add-on Data] ⇒ [Advanced Synchronous Control] ⇒ [Input Setting]



■Advanced synchronous control FB output axis parameter settings

In the "Advanced Synchronous Output Setting" screen of Motion Control Setting Function, configure the output axis settings of the output axes used by the advanced synchronous control FB.

🔗 Motion Control Setting Function ⇒ Navigation window ⇒ [Addon Data] ⇒ [Advanced Synchronous Control] ⇒ [Output Setting]

Setting Item

Item	AdvOutput_Drive	AdvOutput_Nozzle
Axis Information	NozzleDrive	Nozzle
Parameter Constant	AdvOutput.PrConst Expands setting values at output axis	
Parameter	AdvOutput.Pr Expands initial values at output axis variable	
Sub Input Axis Object		
Auxiliary Shaft Object		
Gear Parameter		
Main Shaft Clutch ON Signal Setting		
Main Shaft Clutch OFF Signal Setting		
Auxiliary Shaft Clutch ON Signal Setting		
Auxiliary Shaft Clutch OFF Signal Setting		
Clutch Parameter		
Speed Change Gear Parameter		
Cam Parameter		
Length per Cycle	1000000.0 pulse	1000000.0 pulse
Cam Stroke Amount	1000000.0 pulse	1000000.0 pulse
Cam No.	1	2
Cam Starting Point	0	0
Length per Cycle Change Setting	0Invalid	0Invalid
Phase Compensation Advance Time	0 us	0 us
Phase Compensation Time Constant	10 ms	10 ms
Synchronous Control Initial Position		

Explanation

AdvOutputLabelID
Set the label ID of the output axis.
[Setting Range]
1 to 256

Restore the Default Settings With Selected Write Variables Read Variables Apply

- Settings of axes used by output axis and auxiliary shaft

Setting item	Setting value	
	Nozzle drive axis	Nozzle axis
Axis information (AdvOutputName.Axis)	NozzleDrive	Nozzle

- Cam parameter setting

Setting item	Setting value	
	Nozzle drive axis	Nozzle axis
Length per cycle	1000000.0 (Match with the length per cycle set in the operation profile)	1000000.0 (Match with the length per cycle set in the operation profile)
Cam stroke amount	1000000.0 (Same as the length per cycle)	100000.0 (Set the stroke amount of the output axis when the stroke amount [%] set in the operation profile is 100 [%].)
Cam No.	1 (The profile ID set in the operation profile (NozzleDrivePattern))	2 (The profile ID set in the operation profile (NozzlePattern))

Program creation

■ Starting advanced synchronous control (initial start)

After setting the positions of the input axis and output axes by homing, etc., confirm that the input axis is enabled (AdvInput_Conveyor.Md.ActiveStatus is "1: Input axis enabled") and the output axes are on standby (NozzleDrive.Md.AxisStatus is "4: Standby (Standstill)" and Nozzle.Md.AxisStatus is "4: Standby (Standstill)") before starting the advanced synchronous control FB.

This section also describes the procedures for restarting synchronous control using cam set position restoration (restoring the input axis position as reference).

For restarting synchronous control using cam set position restoration (restoring the input axis position as reference), refer to the following.

 Page 701 Starting advanced synchronous control (restart)

Set the positions of the input axis (Conveyor) and the output axes (NozzleDrive and Nozzle), set the synchronous control initial position parameters as shown below, and start the advanced synchronous control FB.

Setting item	Setting value
Setting method of current position per cycle after main shaft gear • AdvOutput_NozzleDrive.Pr.Restore.MasterGearPositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object • AdvOutput_NozzleDrive.Pr.Restore.PositionRestorationObject • AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject	0: Current position per cycle restoration (RestorePositionPerCycle)
Setting method of cam reference position • AdvOutput_NozzleDrive.Pr.Restore.ReferenceSetPositionMethod • AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod	2: Set position (CamSetPosition)
Current position per cycle (initial setting) • AdvOutput_NozzleDrive.Pr.Restore.InitialPositionPerCycle • AdvOutput_Nozzle.Pr.Restore.InitialPositionPerCycle	0.0

- Example program

- Nozzle drive axis

ST program

```

IF NOT(gb_SystemStart) THEN
  gb_PositionAdjustComp_Drive:=FALSE;
  END_IF;

//-----For initial start (from here)-----
IF gb_SystemStart AND NOT(gb_SyncRestart) THEN
  // AdvSync Start(NozzleDrive)
  // Set Restore Parameter
  AdvOutput_Drive.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
  AdvOutput_Drive.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestorePositionPerCycle;
  AdvOutput_Drive.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__CamSetPosition;
  AdvOutput_Drive.Pr.Restore.InitialPositionPerCycle:=0.0;

  IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
    NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill THEN
    gdw_AdvSync_Drive_Options:=H00000000;
    gb_AdvSync_Drive_Enable:=TRUE;
  END_IF;
END_IF;
//-----For initial start (until here)-----

//-----For restart (from here)-----
IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(NozzleDrive)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
    RESTORE_POSITION_PER_CYCLE_FOR_PREPROMODE :
  <Omission>*1
    RESTORE_POSITION_PER_CYCLE_FOR_CAMCALCFUNC :
  <Omission>*1
    RESTORE_SETPOSITION_FOR_PREPROMODE :
  <Omission>*1
    RESTORE_SETPOSITION_FOR_CAMCALCFUNC :
  <Omission>*1

  ELSE
    ;
  END_CASE;
END_IF;
//-----For restart (until here)-----

MC_MoveAbsolute_Drive(
  Axis:= NozzleDrive.AxisRef,
  Execute:= gb_MoveAbsolute_Drive_Execute,
  Position:= gl_MoveAbsolute_Drive_Position,
  Velocity:= 10000000.0,
  Acceleration:= 0.5,
  Deceleration:= 0.5,
  Direction:= MC_DIRECTION__mcShortestWay,
  Options:= H0001);

MCv_AdvancedSync_Drive(
  Master:= AdvInput_Conveyor.Axis,
  Slave:= AdvOutput_Drive.Axis,
  Options:= gdw_AdvSync_Drive_Options,
  Enable:= gb_AdvSync_Drive_Enable,
  InSync=> gb_AdvSync_Drive_InSync);

MCv_AdvCamSetPositionCalc_Drive(
  Execute:= gb_AdvCamSetPositionCalc_Drive_Execute,
  CamTableID:= g_CamTableID_Drive,
  LengthPerCycle:= gl_AdvCamSetPositionCalc_Drive_LengthPerCycle,
  StrokeAmount:= gl_AdvCamSetPositionCalc_Drive_StrokeAmount,
  ReferenceSetPosition:= gl_AdvCamSetPositionCalc_Drive_ReferenceSetPosition,
  PositionPerCycle:= gl_AdvCamSetPositionCalc_Drive_PositionPerCycle);

```

*1 For an example program when restarting advanced synchronous control, refer to the following.

 Page 701 Starting advanced synchronous control (restart)

ST program

```

IF NOT(gb_SystemStart) THEN
  gb_PositionAdjustComp_Nozzle:=FALSE;
END_IF;

//-----For initial start (from here)-----
IF gb_SystemStart AND NOT(gb_SyncRestart) THEN
  // AdvSync Start(Nozzle)
  // Set Restore Parameter
  AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
  AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestorePositionPerCycle;
  AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__CamSetPosition;
  AdvOutput_Nozzle.Pr.Restore.InitialPositionPerCycle:=0.0;

  IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
    Nozzle.Md.AxisStatus=MC_AXIS_STATUS__Standstill THEN
    gdw_AdvSync_Nozzle_Options:=H00000000;
    gb_AdvSync_Nozzle_Enable:=TRUE;
  END_IF;
END_IF;
//-----For initial start (until here)-----

//-----For restart (from here)-----
IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(Nozzle)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
    RESTORE_POSITION_PER_CYCLE_FOR_PREPROMODE :
<Omission>*1
    RESTORE_POSITION_PER_CYCLE_FOR_CAMCALCFUNC :
<Omission>*1
    RESTORE_SETPOSITION_FOR_PREPROMODE :
<Omission>*1
    RESTORE_SETPOSITION_FOR_CAMCALCFUNC :
<Omission>*1

  ELSE
    ;
  END_CASE;
END_IF;
//-----For restart (until here)-----

MC_MoveAbsolute_Nozzle(
  Axis:= Nozzle.AxisRef,
  Execute:= gb_MoveAbsolute_Nozzle_Execute,
  Position:= gl_MoveAbsolute_Nozzle_Position,
  Velocity:= 10000000.0,
  Acceleration:= 0.5,
  Deceleration:= 0.5,
  Direction:= MC_DIRECTION__mcShortestWay,
  Options:= H0001);

MCv_AdvancedSync_Nozzle(
  Master:= AdvInput_Conveyor.Axis,
  Slave:= AdvOutput_Nozzle.Axis,
  Options:= gdw_AdvSync_Nozzle_Options,
  Enable:= gb_AdvSync_Nozzle_Enable,
  Deceleration:= 2000000.0,
  InSync=> gb_AdvSync_Nozzle_InSync);

MCv_AdvCamSetPositionCalc_Nozzle(
  Execute:= gb_AdvCamSetPositionCalc_Nozzle_Execute,
  CamTableID:= g_CamTableID_Nozzle,
  LengthPerCycle:= gl_AdvCamSetPositionCalc_Nozzle_LengthPerCycle,
  StrokeAmount:= gl_AdvCamSetPositionCalc_Nozzle_StrokeAmount,
  ReferenceSetPosition:= gl_AdvCamSetPositionCalc_Nozzle_ReferenceSetPosition,
  PositionPerCycle:= gl_AdvCamSetPositionCalc_Nozzle_PositionPerCycle);

//-----Continued on next page-----

```

ST program

//-----continued from previous page-----

```
MCv_AdvPositionPerCycleCalc_Nozzle(  
  Execute:= gb_AdvPositionPerCycleCalc_Nozzle_Execute,  
  CamTableID:= g_CamTableID_Nozzle,  
  LengthPerCycle:= gl_AdvPositionPerCycleCalc_Nozzle_LengthPerCycle,  
  StrokeAmount:= gl_AdvPositionPerCycleCalc_Nozzle_StrokeAmount,  
  ReferenceSetPosition:= gl_AdvPositionPerCycleCalc_Nozzle_ReferenceSetPosition,  
  SetPosition:= gl_AdvPositionPerCycleCalc_Nozzle_SetPosition,  
  PositionPerCycle:= gl_AdvPositionPerCycleCalc_Nozzle_PositionPerCycle);
```

*1 For an example program when restarting advanced synchronous control, refer to the following.

 Page 701 Starting advanced synchronous control (restart)

• Labels used

Label name	Data type	Comment
gb_SystemStart	Bit	System start command
gb_SyncRestart	Bit	System restart command
MC_MoveAbsolute_Drive	MC_MoveAbsolute	Absolute value positioning FB (Nozzle drive axis positioning)
gb_MoveAbsolute_Drive_Execute	Bit	Absolute value positioning FB start command (nozzle drive axis)
gl_MoveAbsolute_Drive_Position	Double-precision real number	Absolute value positioning FB target position (nozzle drive axis)
gb_PositionAdjustComp_Drive	Bit	Nozzle drive axis positioning complete flag
MCv_AdvancedSync_Drive	MCv_AdvancedSync	Advanced synchronous control FB (nozzle drive axis)
gb_AdvSync_Drive_Enable	Bit	Advanced synchronous control FB start command (nozzle drive axis)
gdw_AdvSync_Drive_Options	Double word [unsigned]/bit string [32-bit]	Advanced synchronous control FB option (nozzle drive axis)
gb_AdvSync_Drive_InSync	Bit	Advanced synchronous control FB synchronizing (nozzle drive axis)
MC_MoveAbsolute_Nozzle	MC_MoveAbsolute	Absolute value positioning FB (nozzle axis positioning)
gb_MoveAbsolute_Nozzle_Execute	Bit	Absolute value positioning FB start command (nozzle axis)
gl_MoveAbsolute_Nozzle_Position	Double-precision real number	Absolute value positioning FB target position (nozzle axis)
gb_PositionAdjustComp_Nozzle	Bit	Nozzle axis positioning complete flag
MCv_AdvancedSync_Nozzle	MCv_AdvancedSync	Advanced synchronous control FB (nozzle axis)
gb_AdvSync_Nozzle_Enable	Bit	Advanced synchronous control FB start command (nozzle axis)
gdw_AdvSync_Nozzle_Options	Double word [unsigned]/bit string [32-bit]	Advanced synchronous control FB option (nozzle axis)
gb_AdvSync_Nozzle_InSync	Bit	Advanced synchronous control FB synchronizing (nozzle axis)
gw_SelectRestoreMode	Word [signed]	Restoration mode selection at system restart
g_CamTableID_Drive	MC_CAM_ID	Cam ID (nozzle axis)
g_CamTableID_Nozzle	MC_CAM_ID	Cam ID (nozzle drive axis)
MCv_AdvCamSetPositionCalc_Nozzle	MCv_AdvCamSetPositionCalc	Advanced synchronous control cam set position calculation FB (nozzle axis)
gb_AdvCamSetPositionCalc_Nozzle_Execute	Bit	Advanced synchronous control cam set position calculation FB execute command (nozzle axis)
gl_AdvCamSetPositionCalc_Nozzle_PositionPerCycle	Double-precision real number	Advanced synchronous control cam set position calculation FB current position per cycle (nozzle axis)
gl_AdvCamSetPositionCalc_Nozzle_LengthPerCycle	Double-precision real number	Advanced synchronous control cam set position calculation FB length per cycle (nozzle axis)
gl_AdvCamSetPositionCalc_Nozzle_StrokeAmount	Double-precision real number	Advanced synchronous control cam set position calculation FB stroke amount (nozzle axis)
gl_AdvCamSetPositionCalc_Nozzle_ReferenceSetPosition	Double-precision real number	Advanced synchronous control cam set position calculation FB cam reference position (nozzle axis)
MCv_AdvCamSetPositionCalc_Drive	MCv_AdvCamSetPositionCalc	Advanced synchronous control cam set position calculation FB (nozzle drive axis)
gb_AdvCamSetPositionCalc_Drive_Execute	Bit	Advanced synchronous control cam set position calculation FB execute command (nozzle drive axis)
gl_AdvCamSetPositionCalc_Drive_PositionPerCycle	Double-precision real number	Advanced synchronous control cam set position calculation FB current position per cycle (nozzle drive axis)
gl_AdvCamSetPositionCalc_Drive_LengthPerCycle	Double-precision real number	Advanced synchronous control cam set position calculation FB length per cycle (nozzle drive axis)

Label name	Data type	Comment
gl_AdvCamSetPositionCalc_Drive_StrokeAmount	Double-precision real number	Advanced synchronous control cam set position calculation FB stroke amount (nozzle drive axis)
gl_AdvCamSetPositionCalc_Drive_ReferenceSetPosition	Double-precision real number	Advanced synchronous control cam set position calculation FB cam reference position (nozzle drive axis)
MCv_AdvPositionPerCycleCalc_Nozzle	MCv_AdvPositionPerCycleCalc	Advanced synchronous control current position per cycle calculation FB (nozzle axis)
gb_AdvPositionPerCycleCalc_Nozzle_Execute	Bit	Advanced synchronous control current position per cycle calculation FB current position per cycle (nozzle axis)
gl_AdvPositionPerCycleCalc_Nozzle_PositionPerCycle	Double-precision real number	Advanced synchronous control current position per cycle calculation FB current position per cycle (nozzle axis)
gl_AdvPositionPerCycleCalc_Nozzle_LengthPerCycle	Double-precision real number	Advanced synchronous control current position per cycle calculation FB length per cycle (nozzle axis)
gl_AdvPositionPerCycleCalc_Nozzle_StrokeAmount	Double-precision real number	Advanced synchronous control current position per cycle calculation FB stroke amount (nozzle axis)
gl_AdvPositionPerCycleCalc_Nozzle_ReferenceSetPosition	Double-precision real number	Advanced synchronous control current position per cycle calculation FB cam reference position (nozzle axis)
gl_AdvPositionPerCycleCalc_Nozzle_SetPosition	Double-precision real number	Advanced synchronous control current position per cycle calculation FB cam set position (nozzle axis)
gdw_AdvInput_Conveyor_CumulativePosition	Double word [signed]	Cumulative current position (conveyor axis) A temporary variable for rounding the cumulative current position calculation to the current position per cycle range
gdw_AdvOutput_Nozzle_LengthPerCycle	Double word [signed]	Current position per cycle (nozzle axis) A temporary variable for rounding the cumulative current position calculation to the current position per cycle range
gdw_AdvOutput_Drive_LengthPerCycle	Double word [signed]	Current position per cycle (nozzle drive axis) A temporary variable for rounding the cumulative current position calculation to the current position per cycle range
RESTORE_POSITION_PER_CYCLE_FOR_PREPROMODE	Word [signed]	Restoration mode selection at system restart: Current position per cycle restoration (analysis mode) (constant=1)
RESTORE_POSITION_PER_CYCLE_FOR_CAMCALCFUNC	Word [signed]	Restoration mode selection at system restart: Current position per cycle restoration (cam position calculation function) (constant=2)
RESTORE_SETPOSITION_FOR_PREPROMODE	Word [signed]	Restoration mode selection at system restart: Set position (analysis mode) (constant=3)
RESTORE_SETPOSITION_FOR_CAMCALCFUNC	Word [signed]	Restoration mode selection at system restart: Set position (cam position calculation function) (constant=4)

■Starting advanced synchronous control (restart)

When restarting advanced synchronous control select a restoration method suitable for the configuration and application of the equipment and start the advanced synchronous control FB. Additionally, use "synchronous control analysis mode" or "cam position calculation function" when recalculating to synchronize the input axis and output axis in order to restart advanced synchronous control.

An example of restoration procedures when using "synchronous control analysis mode" or "cam position calculation function" is shown below.

No.	Restoration method	Using method	Application
1	Current position per cycle restoration	Synchronous control analysis mode	Restart synchronization after moving the nozzle axis to the retract point.
2		Cam position calculation function (MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Current Position per Cycle Calculation))	
3	Cam set position restoration	Synchronous control analysis mode	Restart with the phases of input axis cumulative current position and the output axis current position per cycle matched. (When the workpiece has not been set)
4		Cam position calculation function (MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Cam Set Position Calculation))	

Point

For restoration after turning ON the motion system power again, the input axis and output axis must be set to absolute position detection system.

Operating procedure

■No.1 "Restart synchronization after moving the nozzle axis to the retract point" (when using synchronous control analysis mode)

1. Position the output axis (Nozzle) to the retract point (position of stroke amount "50%").
2. Set the synchronous control initial position parameters of the output axis (Nozzle) as follows, and execute the advanced synchronous control FB with the synchronous control analysis mode setting (Options (Options): Bit 16) set to "1: Enabled".

Setting item	Setting value
Setting method of current position per cycle after main shaft gear • AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object • AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject	0: Current position per cycle restoration (RestorePositionPerCycle)
Setting method of cam reference position • AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod	0: Previous value(PreviousPosition)
Current position per cycle (initial setting) • AdvOutput_NozzleDrive.Pr.Restore.InitialPositionPerCycle	0.0

3. To calculate the Cam set position (AdvOutput_Drive.Md.Cam.SetPosition) at the start of advanced synchronous control of the output axis (NozzleDrive) based on the position per cycle calculated in step 2., set the synchronous control initial position parameters of the output axis (NozzleDrive) as follows, and execute the advanced synchronous control FB with the synchronous control analysis mode setting (Options (Options): Bit 16) set to "1: Enabled".

Setting item	Setting value
Setting method of current position per cycle after main shaft gear • AdvOutput_NozzleDrive.Pr.Restore.MasterGearPositionPerCycleMethod	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object • AdvOutput_NozzleDrive.Pr.Restore.PositionRestorationObject	2: Cam set position restoration (RestoreCamSetPosition)
Setting method of cam reference position • AdvOutput_NozzleDrive.Pr.Restore.ReferenceSetPositionMethod	0: Previous value (PreviousPosition)
Setting method of current position per cycle • AdvOutput_NozzleDrive.Pr.Restore.PositionPerCycleMethod	1: Current position per cycle (InitialPositionPerCycle)
Current position per cycle (initial setting) • AdvOutput_NozzleDrive.Pr.Restore.InitialPositionPerCycle	The current position per cycle calculated in step 2. • AdvOutput_Nozzle.Md.Cam.PositionPerCycle

4. After synchronous control analysis mode execution completion (MCv_AdvancedSync.Done is TRUE), position the nozzle drive axis (NozzleDrive) to the position of the updated Cam set position (AdvOutput_Drive.Md.Cam.SetPosition).
5. Set the synchronous control initial position parameters of the output axes (NozzleDrive and Nozzle) as follows, and start (change Enable from FALSE to TRUE) the advanced synchronous control FB.

Setting item	Setting value
Setting method of current position per cycle after main shaft gear • AdvOutput_NozzleDrive.Pr.Restore.MasterGearPositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object • AdvOutput_NozzleDrive.Pr.Restore.PositionRestorationObject • AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject	0: Current position per cycle restoration (RestorePositionPerCycle)
Setting method of cam reference position • AdvOutput_NozzleDrive.Pr.Restore.ReferenceSetPositionMethod • AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod	0: Previous value (PreviousPosition)
Current position per cycle (initial setting) • AdvOutput_NozzleDrive.Pr.Restore.InitialPositionPerCycle • AdvOutput_Nozzle.Pr.Restore.InitialPositionPerCycle	The current position per cycle calculated in step 2. • AdvOutput_Nozzle.Md.Cam.PositionPerCycle

- Example program

■ Nozzle drive axis

ST program^{*1}

```
// Select For Restore Target
CASE gw_SelectRestoreMode OF
RESTORE_POSITION_PER_CYCLE_FOR_PREPROMODE :
  // Set Restore Parameter
  AdvOutput_Drive.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
  AdvOutput_Drive.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestoreCamSetPosition;
  AdvOutput_Drive.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
  AdvOutput_Drive.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__InitialPositionPerCycle;
  AdvOutput_Drive.Pr.Restore.InitialPositionPerCycle:=gl_Restored_Nozzle_PositionPerCycle;

  // Positionadjustment
  IF gb_PositionAdjustComp_Nozzle THEN
    IF NOT(gb_PositionAdjustComp_Drive) THEN
      IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
        gdw_AdvSync_Drive_Options:=H00010000;
        gb_AdvSync_Drive_Enable:=TRUE;

        IF MCv_AdvancedSync_Drive.Done THEN
          gl_MoveAbsolute_Drive_Position:=AdvOutput_Drive.Md.Cam.SetPosition;
          gb_MoveAbsolute_Drive_Execute:=TRUE;
        END_IF;

        IF MC_MoveAbsolute_Drive.Done THEN
          gb_AdvSync_Drive_Enable:=FALSE;
          gb_MoveAbsolute_Drive_Execute:=FALSE;
          gb_PositionAdjustComp_Drive:=TRUE;
        END_IF;
      END_IF;
    ELSE
      IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
        NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
        NOT(MCv_AdvancedSync_Drive.Done) THEN
        // Set Restore Parameter
        AdvOutput_Drive.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestorePositionPerCycle;
        AdvOutput_Drive.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__InitialPositionPerCycle;
        AdvOutput_Drive.Pr.Restore.InitialPositionPerCycle:=gl_Restored_Nozzle_PositionPerCycle;
        gdw_AdvSync_Drive_Options:=H00000000;
        gb_AdvSync_Drive_Enable:=TRUE;
      END_IF;
    END_IF;
  END_IF;
```

*1 For the entire program, refer to the following.

📖 Page 697 Starting advanced synchronous control (initial start)

ST program*1

```
// Select For Restore Target
CASE gw_SelectRestoreMode OF
RESTORE_POSITION_PER_CYCLE_FOR_PREPROMODE :
  // AdvSync Restart(Nozzle)
  AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
  AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestorePositionPerCycle;
  AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
  AdvOutput_Nozzle.Pr.Restore.InitialPositionPerCycle:=0.0;
  // Positionadjustment
  IF NOT(gb_PositionAdjustComp_Nozzle) THEN
    IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
      gl_MoveAbsolute_Nozzle_Position:=AdvOutput_Nozzle.Pr.Cam.StrokeAmount * 0.5;
      gb_MoveAbsolute_Nozzle_Execute:=TRUE;
      IF MC_MoveAbsolute_Nozzle.Done THEN
        gdw_AdvSync_Nozzle_Options:=H00010000;
        gb_AdvSync_Nozzle_Enable:=TRUE;
        END_IF;

        IF MCv_AdvancedSync_Nozzle.Done THEN
          gl_Restored_Nozzle_PositionPerCycle:=AdvOutput_Nozzle.Md.Cam.PositionPerCycle;
          gb_AdvSync_Nozzle_Enable:=FALSE;
          gb_PositionAdjustComp_Nozzle:=TRUE;
          END_IF;
        END_IF;
      ELSE
        IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
          NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
          NOT(MCv_AdvancedSync_Nozzle.Done) THEN
          AdvOutput_Drive.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__InitialPositionPerCycle;
          AdvOutput_Drive.Pr.Restore.InitialPositionPerCycle:=gl_Restored_Nozzle_PositionPerCycle;
          gdw_AdvSync_Nozzle_Options:=H00000000;
          gb_AdvSync_Nozzle_Enable:=TRUE;
          END_IF;
        END_IF;
      END_IF;
    END_IF;
  END_IF;
```

*1 For the entire program, refer to the following.

☞ Page 697 Starting advanced synchronous control (initial start)

• Labels used

For the labels used in the program, refer to the following.

☞ Page 697 Starting advanced synchronous control (initial start)

■No.2 "Restart synchronization after moving the nozzle axis to the retract point" (when using cam position calculation function (MCv_AdvCamSetPositionCalc (Advanced Synchronous Control Current Position per Cycle Calculation)))

1. Position the output axis (Nozzle) to the retract point (position of stroke amount "50%").
2. Calculate the current position per cycle based on the set position of the output axis (in this case output axis (Nozzle)) which keeps the set position.

Setting item	Setting value
Cam table ID • MCv_AdvPositionPerCycleCalc_Nozzle.CamTableID	Cam No. of output axis (Nozzle) • AdvOutput_Nozzle.Pr.Cam.CamNo
Cam position length per cycle • MCv_AdvPositionPerCycleCalc_Nozzle.LengthPerCycle	Length per cycle of output axis (Nozzle) • AdvOutput_Nozzle.Pr.Cam.LengthPerCycle
Cam position calculation stroke amount • MCv_AdvPositionPerCycleCalc_Nozzle.StrokeAmount	Stroke amount of output axis (Nozzle) • AdvOutput_Nozzle.Pr.Cam.StrokeAmount
Cam position calculation set position • MCv_AdvPositionPerCycleCalc_Nozzle.CamSetPosition	Set position of output axis (Nozzle) • AdvOutput_Nozzle.Md.SetPosition
Cam position calculation cam reference position • MCv_AdvPositionPerCycleCalc_Nozzle.ReferenceSetPosition	Cam reference position of output axis (Nozzle) • AdvOutput_Nozzle.Md.Cam.ReferenceSetPosition
Cam position calculation current position per cycle • MCv_AdvPositionPerCycleCalc_Nozzle.PositionPerCycle	Current position per cycle of output axis (Nozzle) • AdvOutput_Nozzle.Md.Cam.PositionPerCycle

3. Calculate the set position of the output axis (NozzleDrive) based on the current position per cycle calculated in step 2.

Setting item	Setting value
Cam table ID • MCv_AdvCamSetPositionCalc_Drive.CamTableID	Cam No. of output axis (NozzleDrive) • AdvOutput_Drive.Pr.Cam.CamNo
Cam position length per cycle • MCv_AdvCamSetPositionCalc_Drive.LengthPerCycle	Length per cycle of output axis (NozzleDrive) • AdvOutput_Drive.Pr.Cam.LengthPerCycle
Cam position calculation stroke amount • MCv_AdvCamSetPositionCalc_Drive.StrokeAmount	Stroke amount of output axis (NozzleDrive) • AdvOutput_Drive.Pr.Cam.StrokeAmount
Cam position calculation cam reference position • MCv_AdvCamSetPositionCalc_Drive.ReferenceSetPosition	Cam reference position of output axis (NozzleDrive) • AdvOutput_Drive.Md.Cam.ReferenceSetPosition
Cam position calculation current position per cycle • MCv_AdvCamSetPositionCalc_Drive.PositionPerCycle	Current position per cycle calculated in step 2. • MCv_AdvPositionPerCycleCalc.CalculationResult

4. Position the output axis (NozzleDrive) to the set position calculated in step 3., and match the current position per cycle of the output axis (Drive) and output axis (NozzleDrive).
5. Set the synchronous control initial position parameters of the output axes (NozzleDrive and Nozzle) as follows, and start (change Enable from FALSE to TRUE) the advanced synchronous control FB.

Setting item	Setting value
Setting method of current position per cycle after main shaft gear • AdvOutput_NozzleDrive.Pr.Restore.MasterGearPositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object • AdvOutput_NozzleDrive.Pr.Restore.PositionRestorationObject • AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject	0: Current position per cycle restoration (RestorePositionPerCycle)
Setting method of cam reference position • AdvOutput_NozzleDrive.Pr.Restore.ReferenceSetPositionMethod • AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod	0: Previous value (PreviousPosition)
Setting method of current position per cycle • AdvOutput_NozzleDrive.Pr.Restore.PositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.PositionPerCycleMethod	1: Current position per cycle (initial setting) (InitialPositionPerCycle)
Current position per cycle (initial setting) • AdvOutput_NozzleDrive.Pr.Restore.InitialPositionPerCycle • AdvOutput_Nozzle.Pr.Restore.InitialPositionPerCycle	Current position per cycle calculated in step 2. • MCv_AdvPositionPerCycleCalc.CalculationResult

- Example program

■ Nozzle drive axis

ST program^{*1}

```
IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(NozzleDrive)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
<Omission>
  RESTORE_POSITION_PER_CYCLE_FOR_CAMCALCFUNC :
    // Set Restore Parameter
    AdvOutput_Drive.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
    AdvOutput_Drive.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestorePositionPerCycle;
    AdvOutput_Drive.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
    AdvOutput_Drive.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__InitialPositionPerCycle;
    AdvOutput_Drive.Pr.Restore.InitialPositionPerCycle:=gl_Restored_Nozzle_PositionPerCycle;

  // Positionadjustment
  IF gb_PositionAdjustComp_Nozzle THEN
    IF NOT(gb_PositionAdjustComp_Drive) THEN
      IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
        g_CamTableID_Drive.ProfileID.Number := AdvOutput_Drive.Pr.Cam.CamNo;
        gl_AdvCamSetPositionCalc_Drive_LengthPerCycle := AdvOutput_Drive.Pr.Cam.LengthPerCycle;
        gl_AdvCamSetPositionCalc_Drive_StrokeAmount := AdvOutput_Drive.Pr.Cam.StrokeAmount;
        gl_AdvCamSetPositionCalc_Drive_ReferenceSetPosition := AdvOutput_Drive.Md.Cam.ReferenceSetPosition;
        gl_AdvCamSetPositionCalc_Drive_PositionPerCycle := gl_Restored_Nozzle_PositionPerCycle;
        gb_AdvCamSetPositionCalc_Drive_Execute := TRUE;

        IF MCv_AdvCamSetPositionCalc_Drive.Done THEN
          gl_MoveAbsolute_Drive_Position:=MCv_AdvCamSetPositionCalc_Drive.CalculationResult;
          gb_MoveAbsolute_Drive_Execute:=TRUE;
        END_IF;

        IF MC_MoveAbsolute_Drive.Done THEN
          gb_AdvSync_Drive_Enable:=FALSE;
          gb_MoveAbsolute_Drive_Execute:=FALSE;
          gb_PositionAdjustComp_Drive:=TRUE;
        END_IF;
      END_IF;
    ELSE
      IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
        NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
        NOT(MCv_AdvancedSync_Drive.Done) THEN
        gdw_AdvSync_Drive_Options:=H00000000;
        gb_AdvSync_Drive_Enable:=TRUE;
      END_IF;
    END_IF;
  END_IF;
```

^{*1} For the entire program, refer to the following.

 Page 697 Starting advanced synchronous control (initial start)

ST program*1

```

IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(Nozzle)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
<Omission>
  RESTORE_POSITION_PER_CYCLE_FOR_CAMCALCFUNC :
    // Set Restore Parameter
    AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
    AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestorePositionPerCycle;
    AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
    AdvOutput_Nozzle.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__InitialPositionPerCycle;
    AdvOutput_Nozzle.Pr.Restore.InitialPositionPerCycle:=gl_Restored_Nozzle_PositionPerCycle;

  // Positionadjustment
  IF NOT(gb_PositionAdjustComp_Nozzle) THEN
    IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
      gl_MoveAbsolute_Nozzle_Position:=AdvOutput_Nozzle.Pr.Cam.StrokeAmount * 0.5;
      gb_MoveAbsolute_Nozzle_Execute:=TRUE;
      IF MC_MoveAbsolute_Nozzle.Done THEN
        g_CamTableID_Nozzle.ProfileID.Number := AdvOutput_Nozzle.Pr.Cam.CamNo;
        gl_AdvPositionPerCycleCalc_Nozzle_LengthPerCycle := AdvOutput_Nozzle.Pr.Cam.LengthPerCycle;
        gl_AdvPositionPerCycleCalc_Nozzle_StrokeAmount := AdvOutput_Nozzle.Pr.Cam.StrokeAmount;
        gl_AdvPositionPerCycleCalc_Nozzle_ReferenceSetPosition := AdvOutput_Nozzle.Md.Cam.ReferenceSetPosition;
        gl_AdvPositionPerCycleCalc_Nozzle_SetPosition := Nozzle.Md.SetPosition;
        gl_AdvPositionPerCycleCalc_Nozzle_PositionPerCycle := 0.0;
        gb_AdvPositionPerCycleCalc_Nozzle_Execute := TRUE;
      END_IF;
      IF MCv_AdvPositionPerCycleCalc_Nozzle.Done THEN
        gl_Restored_Nozzle_PositionPerCycle := MCv_AdvPositionPerCycleCalc_Nozzle.CalculationResult;
        gb_AdvSync_Nozzle_Enable:=FALSE;
        gb_PositionAdjustComp_Nozzle:=TRUE;
      END_IF;
    END_IF;
  ELSE
    IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
      NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
      NOT(MCv_AdvancedSync_Nozzle.Done) THEN
      gdw_AdvSync_Nozzle_Options:=H00000000;
      gb_AdvSync_Nozzle_Enable:=TRUE;
    END_IF;
  END_IF;

```

*1 For the entire program, refer to the following.

📖 Page 697 Starting advanced synchronous control (initial start)

• Labels used

For the labels used in the program, refer to the following.

📖 Page 697 Starting advanced synchronous control (initial start)

■No.3 "Restart with the phases of input axis cumulative current position and the output axis current position per cycle matched" (when using synchronous control analysis mode)

1. Set the synchronous control initial position parameters of the output axes (NozzleDrive, Nozzle) as follows, and execute the advanced synchronous control FB with the synchronous control analysis mode setting (Options (Options): Bit 16) set to "1: Enabled".
2. After synchronous control analysis mode execution completion (MCv_AdvancedSync.Done is TRUE), use the updated Set position (AdvOutput_Drive.Md.Cam.SetPosition, AdvOutput_Nozzle.Md.Cam.SetPosition) to position the nozzle drive axis (NozzleDrive) and nozzle axis (Nozzle) to the position of the updated set position.
3. Set the synchronous control analysis mode setting (Options (Options): Bit 16) set to "1: Disabled" and start (change Enable from FALSE to TRUE) the advanced synchronous control FB again.

Setting item	Setting value
Setting method of current position per cycle after main shaft gear <ul style="list-style-type: none"> • AdvOutput_NozzleDrive.Pr.Restore.MasterGearPositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod 	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object <ul style="list-style-type: none"> • AdvOutput_NozzleDrive.Pr.Restore.PositionRestorationObject • AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject 	2: Cam set position restoration (RestoreCamSetPosition)
Setting method of cam reference position <ul style="list-style-type: none"> • AdvOutput_NozzleDrive.Pr.Restore.ReferenceSetPositionMethod • AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod 	0: Previous value (PreviousPosition)
Setting method of current position per cycle <ul style="list-style-type: none"> • AdvOutput_NozzleDrive.Pr.Restore.PositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.PositionPerCycleMethod 	2: Current position per cycle after main shaft gear (MasterGearPositionPerCycle)

- Example program

■ Nozzle drive axis

ST program^{*1}

```
IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(NozzleDrive)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
<Omission>
  RESTORE_SETPOSITION_FOR_PREPROMODE :
    // Set Restore Parameter
    AdvOutput_Drive.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
    AdvOutput_Drive.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestoreCamSetPosition;
    AdvOutput_Drive.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
    AdvOutput_Drive.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__MasterGearPositionPerCycle;

    // Positionadjustment
    IF NOT(gb_PositionAdjustComp_Drive) THEN
      IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
        gdw_AdvSync_Drive_Options:=H00010000;
        gb_AdvSync_Drive_Enable:=TRUE;

        IF MCv_AdvancedSync_Drive.Done THEN
          gl_MoveAbsolute_Drive_Position:=AdvOutput_Drive.Md.Cam.SetPosition;
          gb_MoveAbsolute_Drive_Execute:=TRUE;
        END_IF;

        IF MC_MoveAbsolute_Drive.Done THEN
          gb_AdvSync_Drive_Enable:=FALSE;
          gb_MoveAbsolute_Drive_Execute:=FALSE;
          gb_PositionAdjustComp_Drive:=TRUE;
        END_IF;
      END_IF;
    ELSE
      IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
        NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
        NOT(MCv_AdvancedSync_Drive.Done) THEN
        gdw_AdvSync_Drive_Options:=H00000000;
        gb_AdvSync_Drive_Enable:=TRUE;
      END_IF;
    END_IF;
```

*1 For the entire program, refer to the following.

☞ Page 697 Starting advanced synchronous control (initial start)

ST program*1

```

IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(Nozzle)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
<Omission>
  RESTORE_SETPOSITION_FOR_PREPROMODE :
    // Set Restore Parameter
    AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
    AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestoreCamSetPosition;
    AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
    AdvOutput_Nozzle.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__MasterGearPositionPerCycle;

    // Positionadjustment
    IF NOT(gb_PositionAdjustComp_Nozzle) THEN
      IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
        gdw_AdvSync_Nozzle_Options:=H00010000;
        gb_AdvSync_Nozzle_Enable:=TRUE;

        IF MCv_AdvancedSync_Nozzle.Done THEN
          gl_MoveAbsolute_Nozzle_Position:=AdvOutput_Nozzle.Md.Cam.SetPosition;
          gb_MoveAbsolute_Nozzle_Execute:=TRUE;
        END_IF;

        IF MC_MoveAbsolute_Nozzle.Done THEN
          gb_AdvSync_Nozzle_Enable:=FALSE;
          gb_MoveAbsolute_Nozzle_Execute:=FALSE;
          gb_PositionAdjustComp_Nozzle:=TRUE;
        END_IF;
      END_IF;
    ELSE
      IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
        Nozzle.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
        NOT(MCv_AdvancedSync_Nozzle.Done) THEN
        gdw_AdvSync_Nozzle_Options:=H00000000;
        gb_AdvSync_Nozzle_Enable:=TRUE;
      END_IF;
    END_IF;
  
```

*1 For the entire program, refer to the following.

📖 Page 697 Starting advanced synchronous control (initial start)

• Labels used

For the labels used in the program, refer to the following.

📖 Page 697 Starting advanced synchronous control (initial start)

■No.4 "Restart with the phases of input axis cumulative current position and the output axis current position per cycle matched" (when using cam position calculation function (MCv_AdvPositionPerCycleCalc (Advanced Synchronous Control Current Position per Cycle Calculation)))

1. Use the cumulative current position of the input axis (Conveyor) to calculate the set position with the following settings and calculate set position of the output axis (NozzleDrive and Nozzle).

Setting item	Setting value	
	Output axis (NozzleDrive)	Output axis (Nozzle)
Cam table ID • MCv_AdvCamSetPositionCalc_Drive.CamTableID • MCv_AdvCamSetPositionCalc_Nozzle.CamTableID	Cam No. of output axis (NozzleDrive) • AdvOutput_Drive.Pr.Cam.CamNo	Cam No. of output axis (Nozzle) • AdvOutput_Nozzle.Pr.Cam.CamNo
Cam position length per cycle • MCv_AdvCamSetPositionCalc_Drive.LengthPerCycle • MCv_AdvCamSetPositionCalc_Nozzle.LengthPerCycle	Length per cycle of output axis (NozzleDrive) • AdvOutput_Drive.Pr.Cam.LengthPerCycle	Length per cycle of output axis (Nozzle) • AdvOutput_Nozzle.Pr.Cam.LengthPerCycle
Cam position calculation stroke amount • MCv_AdvCamSetPositionCalc_Drive.StrokeAmount • MCv_AdvCamSetPositionCalc_Nozzle.StrokeAmount	Stroke amount of output axis (NozzleDrive) • AdvOutput_Drive.Pr.Cam.StrokeAmount	Stroke amount of output axis (Nozzle) • AdvOutput_Nozzle.Pr.Cam.StrokeAmount
Cam position calculation cam reference position • MCv_AdvCamSetPositionCalc_Drive.ReferenceSetPosition • MCv_AdvCamSetPositionCalc_Nozzle.ReferenceSetPosition	Cam reference position of output axis (NozzleDrive) • AdvOutput_Drive.Md.Cam.ReferenceSetPosition	Cam reference position of output axis (Nozzle) • AdvOutput_Nozzle.Md.Cam.ReferenceSetPosition
Cam position calculation current position per cycle • MCv_AdvCamSetPositionCalc_Drive.PositionPerCycle • MCv_AdvCamSetPositionCalc_Nozzle.PositionPerCycle	The value of the input axis (Conveyor) cumulative current position rounded within the cam position length per cycle ^{*1}	The value of the input axis (Conveyor) cumulative current position rounded within the cam position length per cycle ^{*1}

*1 When main shaft/auxiliary shaft gear or main shaft/auxiliary shaft speed change gear are set, the gear ratio and speed change gear ratio for the movement amount from synchronization stop until restart need to be taken into account in the calculation. When setting gears and speed change gears, using synchronous control analysis mode is recommended.

2. Position to the position of the set position (MCv_AdvCamSetPositionCalc.CalculationResult) calculated with the nozzle drive axis (NozzleDrive) and nozzle axis (Nozzle) in step 1.
3. Set the synchronous control initial position parameters of the output axes (NozzleDrive and Nozzle) as follows, and start (change Enable from FALSE to TRUE) the advanced synchronous control FB.

Setting item	Setting value
Setting method of current position per cycle after main shaft gear • AdvOutput_NozzleDrive.Pr.Restore.MasterGearPositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod	2: Calculate from input axis (CalculateFromInputAxis)
Cam axis position restoration object • AdvOutput_NozzleDrive.Pr.Restore.PositionRestorationObject • AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject	2: Cam set position restoration (RestoreCamSetPosition)
Setting method of cam reference position • AdvOutput_NozzleDrive.Pr.Restore.ReferenceSetPositionMethod • AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod	0: Previous value (PreviousPosition)
Setting method of current position per cycle • AdvOutput_NozzleDrive.Pr.Restore.PositionPerCycleMethod • AdvOutput_Nozzle.Pr.Restore.PositionPerCycleMethod	2: Current position per cycle after main shaft gear (MasterGearPositionPerCycle)

- Example program

■ Nozzle drive axis

ST program^{*1}

```

IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(NozzleDrive)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
<Omission>
  RESTORE_SETPOSITION_FOR_CAMCALCFUNC :
    // Set Restore Parameter
    AdvOutput_Drive.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
    AdvOutput_Drive.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestoreCamSetPosition;
    AdvOutput_Drive.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
    AdvOutput_Drive.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__MasterGearPositionPerCycle;

    // Positionadjustment
    IF NOT(gb_PositionAdjustComp_Drive) THEN
      IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
        g_CamTableID_Drive.ProfileID.Number := AdvOutput_Drive.Pr.Cam.CamNo;
        gl_AdvCamSetPositionCalc_Drive_LengthPerCycle := AdvOutput_Drive.Pr.Cam.LengthPerCycle;
        gl_AdvCamSetPositionCalc_Drive_StrokeAmount := AdvOutput_Drive.Pr.Cam.StrokeAmount;
        gl_AdvCamSetPositionCalc_Drive_ReferenceSetPosition := AdvOutput_Drive.Md.Cam.ReferenceSetPosition;

        //Rounding PositionPerCycle
        gdw_AdvInput_Conveyor_CumulativePosition := LREAL_TO_DINT(AdvInput_Conveyor.Md.CumulativePosition);
        gdw_AdvOutput_Drive_LengthPerCycle := LREAL_TO_DINT(AdvOutput_Drive.Pr.Cam.LengthPerCycle);
        IF AdvInput_Conveyor.Md.CumulativePosition < 0.0 THEN
          gl_AdvCamSetPositionCalc_Drive_PositionPerCycle := AdvInput_Conveyor.Md.CumulativePosition -
            (DINT_TO_LREAL(DIV((gdw_AdvInput_Conveyor_CumulativePosition + 1) ,
              gdw_AdvOutput_Drive_LengthPerCycle) - 1) * AdvOutput_Drive.Pr.Cam.LengthPerCycle);

        ELSE
          gl_AdvCamSetPositionCalc_Drive_PositionPerCycle := AdvInput_Conveyor.Md.CumulativePosition -
            (DINT_TO_LREAL(DIV(gdw_AdvInput_Conveyor_CumulativePosition ,
              gdw_AdvOutput_Drive_LengthPerCycle)) * AdvOutput_Drive.Pr.Cam.LengthPerCycle);

        END_IF;
        gb_AdvCamSetPositionCalc_Drive_Execute := TRUE;

        IF MCv_AdvCamSetPositionCalc_Drive.Done THEN
          gl_MoveAbsolute_Drive_Position:=MCv_AdvCamSetPositionCalc_Drive.CalculationResult;
          gb_MoveAbsolute_Drive_Execute:=TRUE;
        END_IF;

        IF MC_MoveAbsolute_Drive.Done THEN
          gb_AdvSync_Drive_Enable:=FALSE;
          gb_MoveAbsolute_Drive_Execute:=FALSE;
          gb_PositionAdjustComp_Drive:=TRUE;
        END_IF;
      END_IF;
    ELSE
      IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
        NozzleDrive.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
        NOT(MCv_AdvancedSync_Drive.Done) THEN
        gdw_AdvSync_Drive_Options:=H00000000;
        gb_AdvSync_Drive_Enable:=TRUE;
      END_IF;
    END_IF;

  ELSE
    ;
  END_CASE;
END_IF;

```

*1 For the entire program, refer to the following.

☞ Page 697 Starting advanced synchronous control (initial start)

ST program*1

```

IF gb_SystemStart AND gb_SyncRestart THEN
  // AdvSync Restart(Nozzle)

  // Select For Restore Target
  CASE gw_SelectRestoreMode OF
<Omission>
  RESTORE_SETPOSITION_FOR_CAMCALCFUNC :
    // Set Restore Parameter
    AdvOutput_Nozzle.Pr.Restore.MasterGearPositionPerCycleMethod:=MC_GEAR_RESTORE_METHOD__CalculateFromInputAxis;
    AdvOutput_Nozzle.Pr.Restore.PositionRestorationObject:=MC_CAM_RESTORE_METHOD__RestoreCamSetPosition;
    AdvOutput_Nozzle.Pr.Restore.ReferenceSetPositionMethod:=MC_CAM_REFERENCE_METHOD__PreviousPosition;
    AdvOutput_Nozzle.Pr.Restore.PositionPerCycleMethod:=MC_CAM_CYCLE_METHOD__MasterGearPositionPerCycle;

  // Positionadjustment
  IF NOT(gb_PositionAdjustComp_Nozzle) THEN
    IF AdvInput_Conveyor.Md.ActiveStatus=1 THEN
      g_CamTableID_Nozzle.ProfileID.Number := AdvOutput_Nozzle.Pr.Cam.CamNo;
      gb_AdvCamSetPositionCalc_Nozzle_Execute := TRUE;
      gl_AdvCamSetPositionCalc_Nozzle_LengthPerCycle := AdvOutput_Nozzle.Pr.Cam.LengthPerCycle;
      gl_AdvCamSetPositionCalc_Nozzle_StrokeAmount := AdvOutput_Nozzle.Pr.Cam.StrokeAmount;
      gl_AdvCamSetPositionCalc_Nozzle_ReferenceSetPosition := AdvOutput_Nozzle.Md.Cam.ReferenceSetPosition;

      //rounding
      gdw_AdvInput_Conveyor_CumulativePosition := LREAL_TO_DINT(AdvInput_Conveyor.Md.CumulativePosition);
      gdw_AdvOutput_Nozzle_LengthPerCycle := LREAL_TO_DINT(AdvOutput_Nozzle.Pr.Cam.LengthPerCycle);
      IF AdvInput_Conveyor.Md.CumulativePosition < 0.0 THEN
        gl_AdvCamSetPositionCalc_Nozzle_PositionPerCycle := AdvInput_Conveyor.Md.CumulativePosition -
          (DINT_TO_LREAL(DIV((gdw_AdvInput_Conveyor_CumulativePosition + 1) ,
            gdw_AdvOutput_Nozzle_LengthPerCycle) - 1) * AdvOutput_Nozzle.Pr.Cam.LengthPerCycle);

      ELSE
        gl_AdvCamSetPositionCalc_Nozzle_PositionPerCycle := AdvInput_Conveyor.Md.CumulativePosition -
          (DINT_TO_LREAL(DIV(gdw_AdvInput_Conveyor_CumulativePosition ,
            gdw_AdvOutput_Nozzle_LengthPerCycle)) * AdvOutput_Nozzle.Pr.Cam.LengthPerCycle);

      END_IF;
      IF MCv_AdvCamSetPositionCalc_Nozzle.Done THEN
        gl_MoveAbsolute_Nozzle_Position:=MCv_AdvCamSetPositionCalc_Nozzle.CalculationResult;
        gb_MoveAbsolute_Nozzle_Execute:=TRUE;
      END_IF;

      IF MC_MoveAbsolute_Nozzle.Done THEN
        gb_AdvSync_Nozzle_Enable:=FALSE;
        gb_MoveAbsolute_Nozzle_Execute:=FALSE;
        gb_PositionAdjustComp_Nozzle:=TRUE;
      END_IF;
    END_IF;
  ELSE
    IF AdvInput_Conveyor.Md.ActiveStatus=1 AND
      Nozzle.Md.AxisStatus=MC_AXIS_STATUS__Standstill AND
      NOT(MCv_AdvancedSync_Nozzle.Done) THEN
      gdw_AdvSync_Nozzle_Options:=H00000000;
      gb_AdvSync_Nozzle_Enable:=TRUE;
    END_IF;
  END_IF;

  ELSE
  ;
  END_CASE;
END_IF;

```

*1 For the entire program, refer to the following

📖 Page 697 Starting advanced synchronous control (initial start)

• Labels used

For the labels used in the program, refer to the following.

📖 Page 697 Starting advanced synchronous control (initial start)

■Starting the conveyor axis (JOG Operation)

Confirm that the output axes are synchronized (AdvOutput_Drive.Md.SyncStatus is "1: In synchronization" and AdvOutput_Nozzle.Md.SyncStatus is "1: In synchronization") and start the conveyor axis (Conveyor).

- Example program

ST program

```
IF gb_SystemStart THEN
  // Conveyor Move
  IF AdvOutput_Drive.Md.SyncStatus=1 AND AdvOutput_Nozzle.Md.SyncStatus=1 THEN
    gl_SetSpeedConveyor:=10000000.0;
    gb_MoveConveyorReq:=TRUE;
  END_IF;
END_IF;


MCv_Jog_Conveyor(
  Axis:= Conveyor.AxisRef,
  JogForward:= gb_MoveConveyorReq,
  Velocity:= gl_SetSpeedConveyor,
  Acceleration:= 0.5,
  Deceleration:= 0.5,
  Options:= H0001);
```

- Labels used

Label name	Data type	Comment
gb_SystemStart	Bit	System start command
MCv_Jog_Conveyor	MCv_Jog	JOG operation FB (conveyor axis)
gb_MoveConveyorReq	Bit	Positive direction JOG operation command
gl_SetSpeedConveyor	Double-precision real number	Command speed of JOG operation

Timing chart

The timing chart for the operation that uses the program example is shown below.



PART 3

CONNECTABLE DEVICE to CC-Link IE TSN

This part consists of the following chapters.

16 CONNECTABLE DEVICE to CC-Link IE TSN

16 CONNECTABLE DEVICE to CC-Link IE TSN

This section describes how to set and use the motion system when a connectable device to CC-Link IE TSN is connected with the Motion module.

For details on the wiring and the parameters, refer to the manual of each device.


16.1 Common Items for All Devices

How to use the slave label


Labels assigned to the cyclic data of the device station in the motion control station are called "Slave labels". The slave labels are generated by setting unique device name (device label) for each device station in the engineering tool.

MR-J5-G usage example is used to describe the method of using the slave label. and Other devices can also be used it with the same method.


1. In Motion Control Setting Function, select Navigation window => [Network I/O](1) to open the "Network I/O" screen.
2. From the devices displayed on "Network I/O" screen, click the "+" on the left end of the device to generate labels.
(Example: Click "+"(2) of No.1 device (MR-J5-G))



- Open the object list of the selected device. Insert checks in labeling targets for the data types to label. (Example: Insert checks (3) in data type "RWwC to RWwE")
- When checks have been inserted for all the data types to label, click the [Create Label] button (4).



- [NW+Global1] (5) is registered in Navigation window ⇒ [Label] ⇒ [Global Label]. Select the registered [NW+Global1] to open the "NW+Global1" screen. A list of the created labels is displayed.



- Slave labels are performed to refresh the values automatically (reflect to send data/import receive data) in operation cycle process. For details of operation cycle, refer to the following.
 Page 107 Operation Cycle
- When device stations are disconnected, the slave labels stored the corresponding receive data hold the value before disconnected.
- For RPDO (RWw) of stations in which axis assignment is executed, do not generate slave label for objects set in object data settings.

Precautions

- The slave labels cannot be used properly when there are mismatches in the settings of network configuration in the settings of network configuration and network I/O in the engineering tool. Perform the procedure above again when the network configuration setting is changed.
- When the slave labels are assigned to 1 byte cyclic data (such as Modes of operation display object), the lower byte of Word [signed] type label is used, and The upper byte will always be 0. Therefore, even when the cyclic data is a negative value, it is displayed as a positive value.

Ex.

When the cyclic data is "-1(FFH)"
The slave label is "255(00FFH)".

PDO mapping setting

When the "CC-Link IE TSN Configuration" screen is closed without setting the PDO mapping pattern, the default mapping pattern is set.

Ex.

For MR-J5(W)-G

Item	Mapping pattern
TPDO	1st Transmit PDO Mapping
RPDO	1st Receive PDO Mapping

When setting a mapping pattern other than the default or when a PDO setting is required by a function, set the mapping pattern in the PDO mapping setting.

This section describes an example of how to set the PDO mapping pattern when using MR-J5-G.

Follow the same procedure for other drive units.


1. Set the number of RWr/RWw points to be assigned for PDO mapping.

Set the number of RWr/RWw points in the "RWr Setting/RWw Setting" (1) according to the number of objects to be assigned to PDO mapping. The number of RWr/RWw points to be set varies depending on the drive unit used. For the number of points that can be set, refer to the manual of the drive unit to be used.

2. Set the PDO mapping.

Click "<Detail Setting>" (2) of [PDO Mapping Setting] of the target servo amplifier to display the "PDO Mapping Setting (1/2)" screen.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]



3. Select the PDO mapping pattern to be used.

In the "PDO Mapping Pattern Selection (1/2)" screen, select the mapping pattern for "TPDO", and clicking the [Next] button will switch the screen to the "PDO Mapping Pattern Selection (2/2)" screen. Select the mapping pattern for "RPDO" and click the [OK] button to display the "PDO Mapping Setting" screen.

■TPDO Mapping Pattern

No.	Pattern Name	Used Points
1	1st Transmit PDO Mapping	21 Points
2	2nd Transmit PDO Mapping	12 Points
3	3rd Transmit PDO Mapping	14 Points
4	4th Transmit PDO Mapping	18 Points

■RPDO Mapping Pattern

No.	Pattern Name	Used Points
1	1st Receive PDO Mapping	16 Points
2	2nd Receive PDO Mapping	6 Points
3	3rd Receive PDO Mapping	21 Points
4	4th Receive PDO Mapping	13 Points



For the PDO mapping pattern that can be set, refer to the manual of the drive unit to be used.

4. Add or change objects to be mapped to the PDO.

In the "PDO Mapping Setting" screen, add and change the PDO mapping according to the functions used. Switch the setting screen by selecting TPDO and RPDO on the window (3).

To add objects to be exchanged using PDO, set "Index/Sub-Index" (4). If not added, leave blank. For the necessary of objects of each function, refer to each function.

(3)

MR-JE-G (Station No. 1)

Link Device Points: 20

Link Device	Index [Hexadecimal]	Sub-Index [Hexadecimal]	Entry Name	Comment	Data Type
-	1d01	01	Watchdog counter DL 1		UNSIGNED 16
-	6060	00	Modes of operation		INTEGER8
-	607a	00	Target position		INTEGER32
-	607a	00	Target position		INTEGER32
-	60ff	00	Target velocity		INTEGER32
-	60ff	00	Target velocity		INTEGER32
-	6040	00	Controlword		UNSIGNED 16
-	60e0	00	Positive torque limit value		UNSIGNED 16
-	60e1	00	Negative torque limit value		UNSIGNED 16
-	6071	00	Target torque		INTEGER16
-	2d20	00	Velocity limit value		UNSIGNED 32
-	2d20	00	Velocity limit value		UNSIGNED 32
-	2d01	00	Control DI 1		UNSIGNED 16
-	2d02	00	Control DI 2		UNSIGNED 16
-	2d03	00	Control DI 3		UNSIGNED 16
-	2d04	00	Control DI 4		UNSIGNED 16
-	2d05	00	Control DI 5		UNSIGNED 16
-	0000	00	GAP	2byte GAP	-


(4)



For the object that can be set, refer to the manual of the drive unit to be used.

5. Change the number of link devices if necessary.

When the size of the objects mapped to TPDO/RPDO is greater than the RWr/RWw points, "The range of link device has been exceeded" (5) is displayed. Delete the objects being mapped, or click [Cancel], and then try again after increasing the number of "RWw/RWr Setting" points on the "CC-Link IE TSN Configuration" screen. To change a mapping object, select the "Index/Sub-Index" (6) from the drop-down list. To delete it, select "Index" (6) and press the Delete key.



Batch setting of PDO mapping

When setting a mapping pattern for a drive unit, the default mapping pattern can be set for all placed drive units at once by the batch setting of PDO mapping.

1. Go to "CC-Link IE TSN Configuration" screen menu and click [CC-Link IE TSN Configuration] ⇒ [Batch Setting of PDO Mapping].
2. Display the confirmation message "Batch set default pattern of PDO mapping". Confirm the contents of the message and click the [Yes] button.
3. Display the completion message "Batch setting of PDO mapping was completed". Click the [OK] button to set the default mapping pattern for all placed drive units.

Communication period setting

The communication period interval must be set to a time that can be set by a device station and the Motion module.

For example, if a device station is settable in 500 [μs] increments, it is not possible to set a time of 1400 [μs].

For the communication period interval, refer to the manual of the device station to be used.

When setting the communication period interval, also refer to the following.

☞ Page 107 Operation Cycle

Device station parameter automatic setting


Whether to support the device station parameter automatic setting function depends on the drive unit. For support information, refer to the manual of the drive unit to be used.

If the device station parameter automatic setting function is supported, it can be set from the "CC-Link IE TSN Configuration" screen.

1. Set the device station parameter automatic setting.

Check [Parameter Automatic Setting] (1). For the drive units that support the device station parameter automatic setting function, check the box to change the parameters of the drive unit.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]



Point

- For a drive unit, even if the device station parameter automatic setting function is not supported, if the drive unit supports the parameter read/write by SDO communication, the drive unit parameters can be set using the Motion control FB. For information on the SDO communication, refer to the manual of the drive unit to be used. For details on Motion control FB, refer to the following.
Page 873 Parameter Read/Write Function
- Parameters for connection and reconnection may not be set by the device station, and parameters may not match between the master station and the device station. For the conditions under which the parameters are not set and how to take corrective actions, refer to the manual of the drive unit

16.2 Connection Method for MELSERVO

MR-J5(W)-G (Cyclic synchronous mode)

This section describes how to set when connecting MR-J5(W)-G (Cyclic synchronous mode) and use various functions. For details about wiring and parameters of MR-J5(W)-G, refer to MR-J5(W)-G manuals.

Setting methods

■Parameter setting

Set the servo parameters of MR-J5(W)-G as below when executing motion control with MR-J5(W)-G.

No.	Name	Default value	Setting value
PA01.0 ^{*1}	Control mode selection	0	0h (Network standard mode)
PA06	Electronic gear - Numerator	1	<p>■MR-J5(W)-G (version A3 or earlier) Set 1 or 2ⁿ when using for positioning control.^{*6} Set 1 when using for other than positioning control.</p> <p>■MR-J5(W)-G (version A4 or later) Set 1 or 2ⁿ when using for positioning control.^{*6} Set as follows when using for other than positioning control.</p> <ul style="list-style-type: none"> If "Speed/acceleration/deceleration unit selection (PT01.1)" is set to "0h", the setting value is 1 and if PT01.1 is "1h", it is 1 or 2ⁿ.
PA07	Electronic gear - Denominator	1	<p>■MR-J5(W)-G version (version A3 or earlier) Set 1 or 2ⁿ when using for positioning control.^{*6} Set 1 when using for other than positioning control.</p> <p>■MR-J5(W)-G version (version A4 or later) Set 1 or 2ⁿ when using for positioning control.^{*6} Set as follows when using for other than positioning control.</p> <ul style="list-style-type: none"> If "Speed/acceleration/deceleration unit selection (PT01.1)" is set to "0h", the setting value is 1 and if PT01.1 is "1h", it is 1 or 2ⁿ.
PC29.5	[AL. 0E3 Absolute position counter warning] selection	1h	0h (Available for infinite feed function.) (When using the absolute position system)
PT01.1 ^{*2}	Velocity / acceleration / deceleration unit selection	0h	Any setting value can be used for positioning control. For using other than positioning control, set 1h when [Pr. PA06 Electronic gear - Numerator] and [Pr. PA07 Electronic gear - Denominator] are other than 1 : 1 (velocity command unit: command unit/s, acceleration/deceleration unit: command unit/s ²) and it is arbitrary when they are 1 : 1. ^{*4}
PT01.2 ^{*3}	Unit for position data	3h	3h (pulse)
PT15	Software position limit +	0	0 ^{*5}
PT17	Software position limit -	0	0 ^{*5}
PV23 ^{*2}	Speed unit conversion electronic gear - numerator	1	1
PV24 ^{*2}	Speed unit conversion electronic gear - denominator	1	1

*1 Supported by MR-J5(W)-G (version B8) or later

*2 Supported by MR-J5(W)-G (version A4) or later

*3 Supported by MR-J5(W)-G (version B6) or later

*4 If "0h" is set for velocity / acceleration/deceleration unit selection, the object data "Velocity actual value (606CH)" may not be acquired correctly when other than 1 : 1 is set for electronic gear.

*5 This function is the same as the software stroke limit function of motion system. Therefore, use the function of motion system side to restrict the command position.

*6 Set 1 when the resolution of the encoder connected with MR-J5(W)-G is not multiple of two to the power of n.

For the following servo parameters, the setting values of the table below are recommended.

No.	Name	Default value	Overview
PD01	Input signal automatic on selection 1	000000000h	000000000h
PD41.2	Limit switch enabled status selection	0h	1h: Enabled only for homing mode ^{*1}
PD41.3	Sensor input method selection	0h	1h: Input from controller (FLS/RLS/DOG) ^{*2}
PT29.0	Device input polarity 1	0h	1h: Dog detection with on (When "Sensor input method selection (PD41.3)" is set to "1: input from controller (FLS/RLS/DOG)")

*1 When "0h" is set, the command of motion system is ignored and the motor stops as the limit switch signal is detected in MR-J5(W)-G side during control. Consider any of the following to stop the system safely.

<Method 1>

Invalidates the detected signal of the MR-J5(W)-G side, and detects the limit by the hardware stroke limit function of the motion system side.

<Method 2>

Sets Driver Command Discard Detection Setting (*AxisName.Pr.StopOption_DriverTargetIgnored*) to valid to stop the command of the motion side when the motor is stopped due to the signal detection of the MR-J5(W)-G side.

*2 When "1h" is set, wire the limit switch to the controller side since the input to MR-J5(W)-G becomes invalid. In the case of wiring to MR-J5(W)-G, the motor does not stop if the limit is detected.

Also, the labeling of the slave must not be carried out since [Control DI 5(2D05h)] of the RPDO mapping is used for sending signal to MR-J5(W)-G side.

■Profile registration to the engineering tool

Since the profile of MR-J5(W)-G is registered at the same time when the engineering tool is installed, no profile registration is required.

However, when updating a profile, register it from "Profile Management" of the engineering tool.

 [Tool] menu ⇒ [Profile Management]⇒[Register]

For how to register profiles, refer to the following.

 GX Works3 Operating Manual


■Module parameter (network) [GX Works3]

This section describes the network parameter setting when using MR-J5-G.

1. Add the MR-J5-G to the network configuration settings on the "CC-Link IE TSN Configuration" screen. Select the MR-J5-G to be used from the "Module List" on the "CC-Link IE TSN Configuration" screen, and drag and drop it to the location to be placed.


 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]

2. Check "Motion Control Station" (2) of the set MR-J5-G.



3. In the "CC-Link IE TSN Configuration" screen, set the "Network Synchronous Communication" (3) of the MR-J5-G to be used in cyclic synchronous mode to "Synchronous"*1.

*1 The setting, "Synchronous" is available from version "1.5" or later of add-on baseSystem.
Set "Asynchronous" when using version "1.4" or earlier.




4. Set PDO mapping.

In the "CC-Link IE TSN Configuration" screen, click "<Detail Setting>" (4) of the [PDO Mapping Setting] of the target servo amplifier to open the "PDO Mapping Pattern Selection" screen. For the setting method of the PDO mapping pattern, refer to the following.

☞ Page 721 PDO mapping setting


When using MR-J5(W)-G in cyclic synchronous mode, set the following mapping patterns.

Mode	Mapping pattern	
	TPDO	RPDO
Cyclic synchronous operation (csp, csv, cst, ct, cspr, hm)	1st Transmit PDO Mapping	1st Receive PDO Mapping



5. Set the CC-Link IE TSN Class.

Set "CC-Link IE TSN Class" (5) of MR-J5-G to "CC-Link IE TSN Class B".



6. Click [Close with Reflecting the Setting] menu of the "CC-Link IE TSN Configuration" screen, and close the "CC-Link IE TSN Configuration" screen.

7. On the "Module Parameter" screen, click the [Apply] button to confirm the changed settings.

16

Point

Do not assign an MR-J5(W)-G set to CC-Link IE TSN Class A to an axis. When an MR-J5(W)-G set to CC-Link IE TSN Class A is assigned to an axis, a servo alarm [AL. 19E.2_Control mode setting warning 2] occurs in the MR-J5(W)-G when connected.

■Module extended parameter [Motion control setting function]

Configure the settings in the motion control setting function.

1. Set the axis type.

On the "New Data" screen of an axis, set the axis of MR-J5(W)-G.

For the axis type, set the Axis Type Setting (1) to the following.

- Real drive axis
- Real encoder axis^{*1}
- Virtual encoder axis^{*1}


^{*1} Specify this when used in combination with the scale measurement function on MR-J5(W)-G.

Refer to the following for details on how to use the real encoder axis and the virtual encoder axis.

☞ Page 43 Real encoder axis

☞ Page 49 Virtual encoder axis

☞ [Motion Control Setting Function] ⇒ Navigation window ⇒ Right-click [Axis] ⇒ [Add New Data]




2. Set the object data.

Click the [...] button of [Object Data] (2) to display "Object Data Setting" window.

Normally, use the default setting.

☞ [Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ [Target Axis] ⇒ [Axis Parameter Constant] ⇒ [Object Data]




3. Set the parameter of "Absolute position detection system".

Set the absolute positioning control setting (3) for the axis parameter constant. For details on the absolute positioning control, refer to the following.

Page 94 Absolute Position Control

Absolute Positioning Control Setting (AxisName.PrConst.PosRestoration_AbsPosEnable) is recommended to be set to default (-1: Automatic Setting (Acquire from Connected Device)).

[Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ [Target Axis] ⇒ [Axis Parameter Constant] ⇒ [Absolute Positioning Control Setting]



4. On the "Axis Parameter Setting" screen, click the [Apply] button to confirm the changed settings.

Using methods

■How to operate external signal of MR-J5(W)-G via communication

1. Preparation

Generates the required objects of the slave label according to the procedures described in common items for all devices ( Page 718).

Object	
Input	Control DI1 to Control DI10
Output	Status DO1 to Status DO10

Also, when using functions of each external signal, some parameters should be changed. For details, refer to MR-J5(W)-G manuals.

2. Using methods

Operating / referring external signals of MR-J5(W)-G are allowed by changing / referring the values of generated labels from the program or watch. A sample program to carry out the gain switching by using the slave label is shown below. (Generate the label previously as Control DI1 and Status DO1 are used for the gain switching.)

[Global label]
bGainChange //Bit type label

[ST program]
//the gain switching request to MR-J5-G
MR_J5_G_001_ControlDI1.4 := bGainChange;

//check the gain of MR-J5-G is switched or not
IF(MR_J5_G_001_StatusDO1.4 = TRUE) THEN
 //describes the process after the gain switching
END_IF;

The bit4 of ControlDI1 is the gain switching request.
This program switches the gain of MR-J5-G as operating bit4 of ControlDI1 with bGain Change.

The bit4 of StatusDO1 is the gain switching status.
The process which is performed only during the gain switching can be created by checking the bit4 status.

■The connection with MR-J5(W)-G in fast operation mode

For details on the fast operation mode, refer to the following.


☞ Page 107 Operation Cycle

1. Preparation

- Setting of network (GX Works3)

Set [Motion Mode (High-Speed)] (1) to [Station-specific mode setting] on the "CC-Link IE TSN Configuration" screen.

☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]



When Motion Mode (High-Speed) is set, select [2nd Transmit PDO Mapping] and [2nd Receive PDO Mapping] in the PDO Mapping Pattern. The following objects are mapped in each PDO.

■TPDO Mapping Pattern [2nd Transmit PDO Mapping]

No.	Object name
1	Watch dog counter UL
2	Modes of operation display
3	Position actual value
4	Statusword
5	Status DO1
6	Status DO4
7	Torque actual value
8	Velocity actual value
9	Current alarm

■RPDO Mapping Pattern [2nd Receive PDO Mapping]

No.	Object name
1	Watch dog counter DL
2	Modes of operation
3	Target position
4	Controlword
5	Control DI4

- Motion system setting (Motion control setting function)

Set to the fast operation mode. For details, refer to the following.

☞ Page 107 Operation Cycle

- MR-J5(W)-G setting (MR Configurator2)

When connecting with 31.25 [μs] of communication cycle interval setting, set "High-speed mode selection (PA01.7)" to "1h: enabled". When connecting with other than 31.25 [μs], no specific setting is required.

2. Using method

Communication in high speed mode is allowed when MR-J5(W)-G is connected with motion system in the above setting.

■The method for setting (LSP/LSN/DOG) input into MR-J5(W)-G to the upper limit/lower limit and home position switch of the motion system

(LSP/LSN/DOG) input signal of the servo amplifier side can be used as the FLS/RLS, and home position switch signal of the motion system by assigning the object, [Digital inputs(60fdh)] to TPDO mapping of MR-J5(W)-G and creating the slave label.

1. Map [Digital inputs(60fdh)] to TPDO.


In the "CC-Link IE TSN Configuration" screen, click "<Detail Setting>" (1) of [PDO Mapping Setting] for the target servo amplifier to open the "PDO Mapping Setting" screen.

Selecting the following for [Index] (2) and [Sub-index] (3) in the "PDO Mapping Setting" screen adds "Digital inputs" to [Entry Name] (4).

- Index: 60fdh
- Sub-index: 00h

When completed, click the [OK] button to close the "PDO Mapping Setting" screen.

In the "Module Parameter" screen, click the [Apply] button to fix the changed objects.



2. Make [Digital inputs (60fdh)] the slave label.


Make slave labels in the "Network I/O" screen of Motion Control Setting Function.

For the method of the slave labeling, refer to the following.

Page 718

Ex.

When the labeling is performed with the label name of "MR_J5_G_001_DigitalInputs" (5).




3. Specify the slave label to the home position switch of FLS/RLS or MC_Home (OPR).

- The upper limit/lower limit setting

Set the target of the upper limit signal (6)/lower limit signal (7) of the "axis parameter setting" screen of Motion Control Setting Function.

Variable	Setting value (when "Travel direction selection (PA14)" is 0)
Target <u>[AxisName.PrConst.HwStrokeLimit_FlsSignal.Source.Target]</u>	[VAR]MR_J5_G_001_DigitalInputs.1
Target <u>[AxisName.PrConst.HwStrokeLimit_RlsSignal.Source.Target]</u>	[VAR]MR_J5_G_001_DigitalInputs.0



- Specify the DOG signal at homing

Specify the following to "home position switch" input into MC_Home (OPR).

Variable	Setting value (when "Travel direction selection (PA14)" is 0)
Target (MC_INPUT_REF.Signal.Source.Target)	[VAR]MR_J5_G_001_DigitalInputs.2

- This setting is not required if "0h: Input from servo amplifier (LSP/LSN/DOG)" is selected in "Sensor input method selection (PD41.3)", input the DOG signal to MRJ5(W)-G directly.
- Set "1: Dog detection with on" to "Device input polarity 1 (PT29.0)" if "1h: Input from controller (FLS/RLS/DOG)" is selected in "Sensor input method selection (PD41.3)".

Precautions


- Assign LSP/LSN/DOG signal to "Input device selection 1 to 3" (PD03 to 05) of MR-J5(W)-G side to use the signal of the motion system.
- The polarities of Bit0(Negative limit switch) and Bit1(Positive limit switch) of the object, [Digital inputs(60fdh)] are changed according to the setting of "Travel direction selection (PA14)". For details, refer to the manuals of each drive unit.
For MR-J5(W)-G: MR-J5-G/MR-J5W-G User's Manual (Parameters)
- Set the following for signal detection method of the motion system side to be the same polarity of Bit0 (Negative limit switch) and Bit1 (Positive limit switch) of object [Digital inputs(60fdh)] of MR-J5(W)-G. If the setting is different, unintended operation may occur.

Variable	Setting value
Signal Detection Method (<u>AxisName</u> .PrConst.HwStrokeLimit_FlsSignal.Detection)	1: Detection at FALSE (LowLevel)
Signal Detection Method (<u>AxisName</u> .PrConst.HwStrokeLimit_RlsSignal.Detection)	

■MR-J5(W)-G

Servo parameter	Setting value for signal detection method (<u>AxisName</u> .PrConst.HwStrokeLimit_FlsSignal.Detection)/Signal detection method (<u>AxisName</u> .PrConst.HwStrokeLimit_RlsSignal.Detection)
Limit switch status read selection (PC76.3)	Limit switch status read selection (PC76.3) <ul style="list-style-type: none"> 0: 1 (Detection at FALSE (LowLevel)) (Initial value) 1: 0 (Detection at TRUE (HighLevel))

- The data flow of object [Digital inputs(60fdh)] is shown below when "0h: Input from servo amplifier (LSP/LSN/DOG)" is selected in "Sensor input method selection (PD41.3)".



Signal input	MR-J5(W)-G			→	Limit switch status read selection (PC76.3)*2	[Digital inputs(60FDH)] Bit0, Bit1	→	Motion module	
	"DI pin polarity selection (PD60)"	External input signal logic	Hardware stroke limit error detection*1					External input signal logic setting	Hardware stroke limit error detection*3
ON	0	Negative logic	Not detect	→	0	TRUE	→	Negative logic (1: Detection at FALSE (LowLevel))	Not detect
	1		Detect			FALSE			Detect
OFF	0		Detect			FALSE			Detect
	1		Not detect			TRUE			Not detect
ON	0	Positive logic	Not detect	→	1	FALSE	→	Positive logic (0: Detection at TRUE (HighLevel))	Not detect
	1		Detect			TRUE			Detect
OFF	0		Detect			TRUE			Detect
	1		Not detect			FALSE			Not detect

*1 When "Limit switch enabled status selection (PD41.2)" is "0: Limit switch always enabled", the error stop is executed in the servo amplifier side not even during homing.

*2 Settable on MR-J5(W)-G supporting "Limit switch status read selection (PC76.3)". Refer to the manuals of MR-J5(W)-G for details. (If not supported, the operation is the same as 0.)

*3 The error stop is executed even in the Motion module during homing. The hardware stroke limit error detection in homing can be temporarily disabled by setting Hardware Stroke Limit Override (AxisName.Cd.HwStrokeLimit_Override).

■How to disable some axes of the multi-axis servo amplifier

When disabling some axes of the multi-axis servo amplifier (MR-J5W-G), disable them starting from the axis in the back part.

Ex.

When disabling an axis of MR-J5W3-G

○: Disabling possible, ×: Disabling Impossible

Axis	Disabling possible/impossible
Axis A only	×
Axis B only	×
Axis C only	○
Axes B and C	○

For disabling axes, set the servo amplifier and GX Works3 as follows.

- Servo amplifier

Set the control axis disabling switch of the axis to be disabled to ON. For details, refer to the following.

📖MR-J5-G/MR-J5W-G User's Manual (Introduction)

- GX Works3

Delete the disabled axis from the list of network configuration settings.

Ex.

When disabling axis C of MR-J5W3-G

- Select and delete line (1) of device No.3.

Precautions

- When labeling of data sent from the motion system is performed, the send data is overwritten with the label values.
Labeling of only necessary objects should be performed because the motion control cannot be performed for a part of the objects such as Target position by the labeling.

The following table shows whether the labeling of the mapped objects in the initial state is possible or not.

○: labeling possible, ×: labeling not possible, △: restrictions apply

Index	SubIndex	Object name	Labeling possible/not possible
1D01h	1	Watchdog counter DL	×
6060h	0	Modes of operation	×
607Ah	0	Target position	×
60FFh	0	Target velocity	×
6040h	0	Controlword	×
60E0h	0	Positive torque limit value	×
60E1h	0	Negative torque limit value	×
6071h	0	Target torque	×
2D20h	0	Velocity limit value	×
2D01h	0	Control DI 1	○
2D02h	0	Control DI 2	○
2D03h	0	Control DI 3	○
2D04h	0	Control DI 4	×
2D05h	0	Control DI 5	△*1

*1 When "Sensor input method selection (PD41.3)" is set to "1h: Input from controller (FLS/RLS/DOG)", the input of FLS and RLS from the motion system cannot be sent to the servo amplifier. For making it the slave label, change to "0h: Input from servo amplifier (LSP/LSN/DOG)" in "Sensor input method selection (PD41.3)".

- A servo alarm [AL. 035_Command frequency error] may be detected in MR-J5(W)-G when an operation cycle over occurs in the motion system during a motor operation and the command differs greatly before the operation cycle over and after a restoration. Check the program and increase the operation cycle setting or decrease the loading if necessary.
- When connecting MR-J5(W)-G in a communication cycle of 31.25 [μs]/62.5 [μs], use version A6 or later. If its version is not compatible, "Communication Cycle Unsupported Driver Connection" (error code: 1C47H) will occur at connection and it cannot be connected with the corresponding drive unit.
- When connecting MR-J5-G-LL, use version "F0" or later. If its version is earlier than "F0", "Drive Unit Version Combination Error" (error code: 1C54H) will occur at connection, and it cannot be connected with the corresponding drive unit.

MR-J5(W)-G (other than Cyclic synchronous mode)

This section describes how to set when connecting MR-J5(W)-G (other than the cyclic synchronous mode) and use various functions.

For details on wiring and parameters of MR-J5(W)-G, refer to MR-J5(W)-G manuals.

There is the firmware for MR-J5(W)-G which is available with the mode other than the cyclic synchronous mode. For details, refer to the manual of MR-J5(W)-G.

Setting method

■Parameter setting

Set the servo parameters of MR-J5(W)-G according to the mode to be used.

For details of the servo parameters used in each mode, refer to the manual of MR-J5(W)-G.

■Profile registration to the engineering tool

Since the profile of MR-J5(W)-G is registered at the same time when the engineering tool is installed, no profile registration is required.

However, when updating a profile, register it from "Profile Management" of the engineering tool.

 [Tool] menu ⇒ [Profile Management] ⇒ [Register]

For how to register profiles, refer to the following.

 GX Works3 Operating Manual


■Module parameter (network) [GX Works3]

An example for using two servo amplifiers of MR-J5-G as the first station (192.168.3.1) set in the cyclic synchronous mode and the second station (192.168.3.2) set in a mode other than the cyclic synchronous mode. For details of the objects used in each mode is shown below.


1. Add the MR-J5-G to the network configuration settings on the "CC-Link IE TSN Configuration" screen. Select the MR-J5-G to be used from the "Module List" on the "CC-Link IE TSN Configuration" screen, and drag and drop it to the location to be placed.

 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]

2. Check or uncheck "Motion Control Station" (2) according to the MR-J5-G to be used.



- On the "CC-Link IE TSN Configuration" screen, set "Synchronous" or "Asynchronous" for the "Network Synchronous Communication" (3) according to the MR-J5-G to be used.




- Set the PDO mapping pattern.

In order to set the second station as a mode other than the cyclic synchronous mode, conduct the PDO mapping settings for the second station.

In the "CC-Link IE TSN Configuration" screen, click "<Detail Setting>"(4) of the [PDO Mapping Setting] of the target servo amplifier to open the "PDO Mapping Pattern Selection" screen. For the setting method of the PDO mapping pattern, refer to the following.

Page 721 PDO mapping setting



When using the second station in a mode other than the cyclic synchronous mode, set the following mapping patterns depending on the operation mode used.


Mode	Mapping pattern	
	TPDO	RPDO
Profile mode (pp, pv, tq)	3rd Transmit PDO Mapping	3rd Receive PDO Mapping ^{*1}
Point table mode (pt)	4th Transmit PDO Mapping	4th Receive PDO Mapping

*1 When the "RWw Setting" points set on the "CC-Link IE TSN Configuration" screen is set to the initial value (20 points), the size of the objects to be mapped exceeds the number of points.
Set the "RWw Setting" points to 24 points or above in advance or delete any unnecessary objects from the "PDO Mapping Setting" screen.

5. Set the CC-Link IE TSN Class.

When connecting MR-J5(W)-G in a mode other than the cyclic synchronous mode, there are no restrictions on CC-Link IE TSN Class settings.

Set "CC-Link IE TSN Class B" or "CC-Link IE TSN Class A" for "CC-Link IE TSN Class" (5) depending on the motion network environment.




- Click [Close with Reflecting the Setting] menu of the "CC-Link IE TSN Configuration" screen, and close the "CC-Link IE TSN Configuration" screen.
- In the "Module Parameter" screen, click the [Apply] button to fix the changed settings.


■Module extended parameter [Motion control setting function]

The axis to be used in other than the cyclic synchronous mode must not be set.

1. Set the axis used with cyclic synchronous mode (first station (192.168.3.1)) (1). The axis used with a mode other than the cyclic synchronous mode (second station (192.168.3.2)) is not set as it is used with a mode other than the cyclic synchronous mode.



2. Generate the slave label of MR-J5-G (second station (192.168.3.2)) used with a mode other than the cyclic synchronous mode by checking all the labeling targets (2) and clicking the [Create Label] button according to the procedure described in "Common Items for all devices". For using with a mode other than the cyclic synchronous mode, generate labels of the entire device as the labeling target.




Setting method

■How to drive motors with other than the cyclic synchronous mode

Since axis assignment is not performed in a mode other than the cyclic synchronous mode, slave labels must be operated by a program. For how to set slave labels, refer to the following.

☞ Page 718 How to use the slave label

The following figure describes the process for driving motors with other than the cyclic synchronous mode.



*1 A label name differs depending on a labeled device. The name described in this process indicates the name for generating the label targeting the second station of MR-J5-G.

*2 Depending on the version of add-on baseSystem, the following is required.

Add-on baseSystem version	Description
"1.14" or earlier	<p>When Watch dog counter DL is mapped to the PDO, creating the program to update Watch dog counter DL is required for each communication cycle. (When updating is not performed, the motors do not drive.)</p> <p>When it is not needed, exclude it from mapping.</p> <p>When using Watch dog counter DL, set as follows in the program.</p> <p>■Method 1 Set bit15 to TRUE.</p> <p>■Method 2 Add 1 for each communication cycle. (As bit15 must always be TRUE, add 1 to keep bit15 from changing to FALSE.)</p>
"1.16" or later	<p>When Watch dog counter DL is mapped to PDO, Creating of an update program by users is not required because the WDC process is performed in the module</p>

■How to disable some axes of the multi-axis servo amplifier

Same as how to disable some axes of the multi-axis servo amplifier of MR-J5W-G (cyclic synchronous mode). For details, refer to the following.

☞ Page 737 How to disable some axes of the multi-axis servo amplifier

Precautions

- Do not execute servo-on before switching to the profile mode. An improper operation, such as sudden acceleration of the motors, might occur.
- Do not switch to the cyclic synchronous mode after switching to the profile mode. An improper operation, such as sudden acceleration of the motors, might occur.
- Do not switch MR-J5(W)-G set as the axis to the profile mode. In the profile mode and the cyclic synchronous mode after being switched from profile mode again, an improper operation might occur.
- When connecting MR-J5(W)-G in a communication cycle of 31.25 [μ s]/62.5 [μ s], use "A6" or later. If its version is not compatible, "Communication Cycle Unsupported Driver Connection" (error code: 1C47H) will occur at connection and it cannot be connected with the corresponding drive unit.
- When connecting MR-J5-G-LL, use version "F0" or later. If its version is earlier than "F0", "Drive Unit Version Combination Error" (error code: 1C54H) will occur at connection, and it cannot be connected with the corresponding drive unit.

How to connect MR-JET-G

This section describes how to set when connecting MR-JET-G and use various functions.
For details on wiring and parameters of MR-JET-G, refer to MR-JET-G manuals.

Setting method

The same as MR-J5(W)-G

How to use

The same as MR-J5(W)-G

Precautions

Do not set the following objects as MR-JET-G is not compatible with them.

Index	SubIndex	Object name	Parameter name
2D35h	2	Encoder status 2	<u>AxisName</u> .PrConst.SlaveObject.vEncoderStatus2
2D36h	0	Scale cycle counter	<u>AxisName</u> .PrConst.SlaveObject.vScaleCycleCounter
2D37h	0	Scale ABS counter	<u>AxisName</u> .PrConst.SlaveObject.vScaleAbsCounter
2D38h	0	Scale measurement encoder resolution	<u>AxisName</u> .PrConst.SlaveObject.vScaleMeasurementEncoderResolution
2D3Ch	0	Scale measurement encoder reception status	<u>AxisName</u> .PrConst.SlaveObject.vScaleMeasurementEncoderReceptionStatus

- MR-JET-G is not compatible with the communication with 31.25 [μs] and 62.5 [μs]. Set the communication period interval setting with 125 [μs] or more.
- When parameter automatic setting is enabled in the network configuration settings on the engineering tool, according to the communication load condition, the changed parameters might not be reflected in the CPU module as the parameter is changed for the multiple stations at the same time in the communication on MR Configurator2. Change them one by one. Otherwise, carry out writing of the project into the CPU module after starting MR Configurator2 and changing the parameters via GX Works3.
- A servo alarm [AL. 035_Command frequency error] may be detected in MR-JET-G when an operation cycle over occurs in the motion system during a motor operation and the command differs greatly before the operation cycle over and after a restoration. Check the program and increase the operation cycle setting or decrease the loading if necessary.

16.3 Connection Method for Drive Unit other than MELSERVO

Drive unit other than MELSERVO (cyclic synchronous mode)

This section describes the settings when assigning a drive unit other than MELSERVO to an axis, and connecting in the cyclic synchronous (position, velocity, torque) mode, and how to use various functions.

For information on connecting drive units other than MELSERVO in the cyclic synchronous mode, download and refer to the connection manuals for the drive unit provided by our partner companies to be used from the Mitsubishi Electric FA website.

Restrictions on connection

■Supported versions for connection

When assigning a drive unit other than MELSERVO to an axis, there are restrictions imposed by the versions of the engineering tool.

Engineering tool	Description
Motion control setting function	
"1.055H" or later	Can connect to the drive unit.
"1.050C" or earlier	When connecting the drive unit, "Drive Unit Connection Setting Other Than MELSERVO Is Invalid" (error code: 1AFEH) occurs.

■Necessary requirements for connection

The following are the necessary requirements for connecting the motion system and a drive unit. For details on the drive unit, refer to the manual of the drive unit to be used.

Network specification	Necessary requirements
Station type	The station type of the drive unit to be connected must be a remote station.
CC-Link IE TSN Class	The CC-Link IE TSN Class of the drive unit to be connected must be CC-Link IE TSN Class B.
Link device points	In the link device setting of the drive unit to be connected, set RWr/RWw to within 40 points each. If the value is greater than 40 points, "PDO Size Over" (error code: 3237H) occurs.
CC-Link IE TSN network synchronous communication	The drive unit to be connected must support CC-Link IE TSN network synchronous communication function.
Cyclic transmission	The drive unit to be connected must support the CANopen communication function.
CANopen profile	The drive unit to be connected must be compatible with the CiA402 drive profile.

• Object data

◎: Necessary

Object			Motion system parameter name (object data)	PDO mapping assignment necessary or not	Object data setting necessary or not	Requirements
Index	SubIndex	Name				
6040h	00h	Controlword	ControlWord	◎	◎	Cannot be connected when unsupported.
6041h	00h	Statusword	StatusWord	◎	◎	
608Fh	00h	Position encoder resolution	PosEncoderResolution	—	◎	
608Fh	01h	Encoder increments	EncoderIncrements	—	◎	<ul style="list-style-type: none"> The encoder connected to the drive unit can be used with a resolution of "2147483647 pulses" or less. Cannot be connected when unsupported.

Object			Motion system parameter name (object data)	PDO mapping assignment necessary or not	Object data setting necessary or not	Requirements
Index	SubIndex	Name				
608Fh	02h	Motor revolutions	PosEncoderResolutionMotorRevolutions	—	⊙	Cannot be connected when unsupported.
60F4h	00h	Following error actual value	FollowingErrActualValue	—	⊙	
6080h	00h	Max motor speed	MaxMotorSpeed	—	⊙	
6060h	00h	Modes of operation	ModesOfOp	⊙	⊙	
6061h	00h	Modes of operation display	ModesOfOpDisp	⊙	⊙	
6502h	00h	Supported drive modes	SupportedDriveModes	—	⊙	<ul style="list-style-type: none"> • Drive units that are compatible with csp (cyclic synchronous position mode) can be used. • Cannot be connected when unsupported.
607Ah	00h	Target position	TargetPos	⊙	⊙	<ul style="list-style-type: none"> • Drive units with the position command of 32-bit ring counter value can be used. • Cannot be connected when unsupported.
6064h	00h	Position actual value	PosActualValue	⊙	⊙	<ul style="list-style-type: none"> • Drive units with the current position of 32-bit ring counter value can be used. • Cannot be connected when unsupported.
60A8h	00h	SI unit position	SiUnitPos	—	—	<ul style="list-style-type: none"> • Any unit other than "degree" can be used for the position command unit of the drive unit. • If the position command unit of the drive unit is other than "pulse", set the electronic gear to convert the unit.
60A9h	00h	SI unit velocity	SiUnitVel	—	—	When Encoder increments or Motor revolutions is set to "0 pulse", units other than "r/min" can be used for the velocity command unit of the drive unit.

■List of function restrictions

The following table lists the functions that are restricted in the use of the drive unit. Functions not listed in the following table can be used in the same way as MELSERVO.

Item		Restrictions	Details on function
Axis management function	Absolute position control	64-bit restoration is not supported. 32-bit restoration is performed.	☞ Page 94 Absolute Position Control
Basic function	Operation cycle	<ul style="list-style-type: none"> • Axis operation cycle high speed mode is not supported. • When setting the axis operation cycle high speed mode, "Drive Unit Connection Setting Other Than MELSERVO Is Invalid." (error code: 1AFEH) occurs. 	☞ Page 107 Operation Cycle
Homing	Driver homing method	<ul style="list-style-type: none"> • If the drive unit does not support the homing mode (hm), the driver homing method cannot be used. Even if homing is performed for a drive unit that does not support the homing mode (hm), the home position cannot be established because homing is not performed. Therefore, use an incremental system. • Set the parameter so that "Home offset" is "0". If the parameter is set to a value other than "0", an unintended operation may occur at completion of homing. • When the Home position switch (AbsSwitch) is used, the DOG signal cannot reach the drive unit. 	☞ Page 198 Driver homing method
Axis control function	Speed to positioning move	External signal high-accuracy input is not supported.	☞ Page 288 Speed to Positioning Move Control

Item			Restrictions	Details on function
Direct control	Velocity control		<ul style="list-style-type: none"> If the drive unit does not support cyclic speed mode (csv), velocity control cannot be used. If velocity control is executed for a drive unit that does not support cyclic synchronous velocity mode (csv), "csv Unsupported Driver" (error code: 1A1BH) occurs. If the drive unit supports the following object, speed control can be used. <ul style="list-style-type: none"> Target velocity (60FFh) 	 Page 295 Velocity Control
	Torque control		<ul style="list-style-type: none"> Torque control cannot be used if the drive unit does not support cyclic synchronous torque mode (cst). If torque control is executed for a drive unit that does not support cyclic synchronous torque mode (cst), "cst Unsupported Driver" (error code: 1A1CH) occurs. If the drive unit supports the following object, torque control can be used. <ul style="list-style-type: none"> Target torque (6071h) Set the value set for the target torque (Torque) of MC_TorqueControl (Torque Control) in the unit of the torque command of the drive unit. Continuous operation to torque control is not supported. When continuous operation to torque control is executed, "Driver Control Mode Unsupported" (error code: 1AE9H) occurs. 	 Page 306 Torque Control
	Pressure control		Pressure control is unsupported. When performing pressure control, "Driver Control Mode Unsupported" (error code: 1AE9H) occurs.	 Page 322 Pressure Control
Torque-related function	Torque limit		If the drive unit supports the following objects, torque limit can be used. <ul style="list-style-type: none"> Positive torque limit value (60E0h) Negative torque limit value (60E1h) 	 Page 398 Torque Limit
Common function	External signal selection		External signal high-accuracy input is not supported.	 Page 424 External Signal Selection
	Touch probe		External signal high-accuracy input is not supported.	 Page 432 Touch Probe
	Axis emulation		<ul style="list-style-type: none"> At the time of axis emulation, this function operates as MR-J5-10G or equivalent. If the axis emulate setting is switched when using the absolute position system, an absolute position erased occurs. When the axis emulate function is enabled, the servo motor (HK-KT13W) is used simulatively. Because of the different resolution of the servo motor actually used, the speed differs from the device configuration actually used. At the time of axis emulation, the set value of object data (AxisName, PrConst.SlaveObject) is set to the same value as the initial set value of the real drive axis in the motion system. For the initial setting value of the real drive axis, refer to the following.  Page 60 Object data settings 	 Page 440 Axis Emulation
	Master-slave operation		<ul style="list-style-type: none"> Master-slave operation is not supported. If it is set to the axis for master-slave operation, "Driver Communication Setting Error 1" (error code: 3230H) occurs. 	 Page 452 Master-Slave Operation
Extended function	Advanced synchronous control		External signal high-accuracy input is not supported.	 Page 555 ADVANCED SYNCHRONOUS CONTROL
RAS function	History data	Positioning data history	If the drive unit does not support the related object, the following data may be fixed to "0". <ul style="list-style-type: none"> Home cycle counter (2D3DH) Home ABS counter (2D3EH) Encoder multiple revolution position Encoder 1 revolution position 	 Page 824 Positioning data history

Setting method

■Parameter setting

For the servo parameters of drive units other than MELSERVO, refer to the manual of the drive unit to be used.

■Profile registration to the engineering tool

To specify the drive unit in the engineering tool, the profile of the drive unit to be used is registered in the "Profile Management" of the engineering tool.

 [Tool] menu ⇒ [Profile Management] ⇒ [Register]

For how to obtain profiles, check the manual of the drive unit to be used.

For how to register profiles, refer to the following.


 GX Works3 Operating Manual

■Module parameter (network) [GX Works3]


1. Add the drive unit to be used to the network configuration settings. Select the drive unit to be used from the "Unit List" on the "CC-Link IE TSN Configuration" screen, and drag and drop it to the location to be placed.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]

2. Check "Motion Control Station"(1) of the set drive unit.



- On the "CC-Link IE TSN Configuration" screen, set "Synchronous" to "Network Synchronous Communication" (2). When "Asynchronous" is set, the control of the cyclic synchronous mode may not be executed correctly depending on the drive unit specifications.




- Set the number of RWr/RWw points in the "RWr /RWw Setting"(2) according to the number of objects to be assigned to PDO mapping. The number of RWr/RWw points to be set varies depending on the drive unit used. For the number of points that can be set, refer to the manual of the drive unit to be used.

5. Set the PDO mapping pattern.

On the "CC-Link IE TSN Configuration" screen, click "<Detail Setting>" (4) of the [PDO Mapping Setting] of the target drive unit to display the "PDO Mapping Pattern Selection" screen.

For the PDO mapping setting, set the object to be assigned to the required the PDO mapping according to the function to be used. For the setting method of the PDO mapping pattern, refer to the following.

☞ Page 721 PDO mapping setting



When using the motion system, the recommended mappings are shown in the following. Also, if the object that must be assigned to the mapping is not assigned, "Necessary Object Data Unset" (error code: 1AA8H) occurs.

- RPDO

◎: Necessary

Index	SubIndex	DataType	Object name	PDO mapping necessary or not
1D01h	01h	U16	Watchdog counter DL 1	—
6060h	00h	I8	Modes of operation	◎
607Ah	00h	I32	Target position	◎
60FFh	00h	I32	Target velocity	—
6040h	00h	U16	Controlword	◎
60E0h	00h	U16	Positive torque limit value	—
60E1h	00h	U16	Negative torque limit value	—
6071h	00h	I16	Target torque	—

- TPDO

◎: Necessary

Index	SubIndex	Data Type	Object name	PDO mapping necessary or not
1D02h	01h	U16	Watchdog counter UL 1	—
6061h	00h	I8	Modes of operation display	◎
6064h	00h	I32	Position actual value	◎
606Ch	00h	I32	Velocity actual value	—
60F4h	00h	I32	Following error actual value	—
6041h	00h	U16	Statusword	◎
6077h	00h	I16	Torque actual value	—
603Fh	00h	U16	Error code	—

When using drive unit-specific functions that do not depend on motion system functions, assign objects to PDO mapping and use slave labels to read and write objects.

Refer to the following for the slave label conversion method.

📖 Page 718 Common Items for All Devices

For an example of slave label usage, refer to the following.


📖 Page 756 How to operate external signals of the drive unit via communication

Point

When an object used by the motion system is converted to a slave label, the data sent from the motion system to the drive unit is overwritten with the value of the slave label. Therefore, the commands generated by the motion system are not sent to the drive unit, and motion control is always disabled. When converting objects to slave labels, convert only the necessary objects.

6. Set the CC-Link IE TSN Class.

Set "CC-Link IE TSN Class" (5) to "CC-Link IE TSN Class B". When setting "CC-Link IE TSN Class A", the cyclic synchronous mode may not be controlled properly depending on the drive unit specifications.



7. Click [Close with Reflecting the Setting] menu of the "CC-Link IE TSN Configuration" screen, and close the "CC-Link IE TSN Configuration" screen.

8. On the "Module Parameter" screen, click the [Apply] button to confirm the changed settings.

■Module extended parameter [Motion control setting function]


The motion system is set by the motion control setting function.

1. Set the axis type.

On the "New Data" screen of an axis, set the axis of the drive unit.

For the axis type, set "0: Real Drive Axis" to the Axis Type Setting (1).


[Motion Control Setting Function] ⇒ Navigation window ⇒ Right-click [Axis] ⇒ [Add New Data]



2. Set the object data. Click the [...] button of [Object Data] (2) to display "Object Data Setting" window.

[Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ [Target axis] ⇒ [Axis Parameter Constant]

3. Click the [Restore the Default Settings] button (3) on the "Object Data Setting" screen to set the general default value. Click the [Restore the Default Settings] button to display the confirmation screen, and then click the [YES] button to display the confirmation screen for default value setting. Then, click the [YES] button.



- Set the object data as follows.

Parameter	General object value	Setting value (according to support status of drive unit)
ControlWord	"[OBJ]0x60400010"	Do not change the initial value.
EncoderIncrements	"[OBJ]0x608F0120"	
FollowingErrActualValue	"[OBJ]0x60F40020"	
GearRatioMotorRevolutions	""	<ul style="list-style-type: none"> • Supported: Do not change the initial value. • Unsupported: ""
HomeOffset	"[OBJ]0x607C0020"	Do not change the initial value.
MaxMotorSpeed	"[OBJ]0x60800020"	
MaxTorque	"[OBJ]0x60720010"	
ModesOfOp	"[OBJ]0x60600008"	Do not change the initial value.
ModesOfOpDisp	"[OBJ]0x60610008"	
NegativeTorqueLimitValue	"[OBJ]0x60E10010"	
Polarity	"[OBJ]0x607E0008"	<ul style="list-style-type: none"> • Supported: Do not change the initial value. • Unsupported: ""
PosActualValue	"[OBJ]0x60640020"	Do not change the initial value.
PosEncoderResolution	"[OBJ]0x608F0008"	
PosEncoderResolutionMotorRevolutions	"[OBJ]0x608F0220"	
PositiveTorqueLimitValue	"[OBJ]0x60E00010"	<ul style="list-style-type: none"> • Supported: Do not change the initial value. • Unsupported: ""
ShaftRevolutions	""	Do not change the initial value.
SiUnitPos	"[OBJ]0x60A80020"	
SiUnitVel	"[OBJ]0x60A90020"	
StatusWord	"[OBJ]0x60410010"	Do not change the initial value.
SupportedDriveModes	"[OBJ]0x65020020"	
TargetPos	"[OBJ]0x607A0020"	
TargetTorque	"[OBJ]0x60710010"	<ul style="list-style-type: none"> • Supported: Do not change the initial value. • Unsupported: ""
TargetVelocity	"[OBJ]0x60FF0020"	
TorqueActualValue	"[OBJ]0x60770010"	
VelActualValue	"[OBJ]0x606C0020"	<ul style="list-style-type: none"> • Supported: If an object corresponding or equivalent to the parameter name exists in the drive unit, set that object. • Unsupported: ""
ControlDil1	""	
ControlDil2	""	
ControlDil3	""	
ControlDil4	""	
ControlDil5	""	
ControlDil6	""	
ControlDil7	""	
ForwardSideStopFunction	""	
PressureActualValue	""	
TargetPressure	""	
CurrentAlarm	"[OBJ]0x603F0010"	<ul style="list-style-type: none"> • Supported: When supporting error codes, set "[OBJ]0x603F0010". • Unsupported: ""

Parameter	General object value	Setting value (according to support status of drive unit)
EncoderStatus1	""	<ul style="list-style-type: none"> Supported: If an object corresponding or equivalent to the parameter name exists in the drive unit, set that object. Unsupported: ""
HomeAbsCounter	""	
HomeCycleCounter	""	
InitialAbsCounter	""	
InitialCycleCounter	""	
InitialPos	""	
MaxAbsCounter	""	
StatusDo1	""	
StatusDo2	""	
StatusDo3	""	
StatusDo4	""	
StatusDo5	""	
StatusDo6	""	
StatusDo7	""	
SupportedControlDi1	""	
SupportedControlDi2	""	
SupportedControlDi3	""	
SupportedControlDi4	""	
SupportedControlDi5	""	
SupportedControlDi6	""	
SupportedControlDi7	""	
SupportedStatusDo1	""	
SupportedStatusDo2	""	
SupportedStatusDo3	""	
SupportedStatusDo4	""	
SupportedStatusDo5	""	
SupportedStatusDo6	""	
SupportedStatusDo7	""	
SyncAbsCounter	""	
SyncCycleCounter	""	
VellimitValue	""	
WatchDogCounterDI	"[OBJ]0x1D010110"	<ul style="list-style-type: none"> Supported: Do not change the initial value. Unsupported: ""
WatchDogCounterUI	"[OBJ]0x1D020110"	
EncoderStatus2	""	<ul style="list-style-type: none"> Supported: If an object corresponding or equivalent to the parameter name exists in the drive unit, set that object. Unsupported: ""
ScaleCycleCounter	""	
ScaleAbsCounter	""	
ScaleMeasurementEncoderResolution	""	
ScaleMeasurementEncoderReceptionStatus	""	



If the settings are not made as shown in the table above, the following malfunctions may occur.


- "SLMP Communication Error" (error code: 1C43H) occurs to fail to connect with the drive unit.
- The intended data cannot be sent or received because the object data of the Motion module and the object of the drive unit cannot be linked. In this case, the function using the object data does not operate properly.

4. Set the parameter of "Absolute position detection system".

To match the drive unit settings, set the absolute position control setting of the axis parameter constant (4). Set "0: Disable Absolute Position System" or "1: Enable Absolute Position System". If "-1: Automatic Setting (Acquire from Connected Device) (Auto)" is set, "Absolute Position Management Setting Incorrect Warning" (warning code: 0D4CH) occurs, and operation is performed as "incremental system". For details, refer to the following.

☞ Page 94 Absolute Position Control

🔍 [Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ [Target Axis] ⇒ [Axis Parameter Constant] ⇒ [Absolute Position Control Setting]



Using method

■How to operate external signals of the drive unit via communication

Examples of operating an external signal on a drive unit are shown in the following.

1. Preparation

Generate a slave label for the required objects according to the procedure in Common Items for All Devices (☞ Page 718 Common Items for All Devices).

The external signals of the drive unit assign the following objects to PDO mapping.

Object	
Output signal	Physical outputs (Obj. 60FEH: 01H)
Input signal	Digital inputs (Obj. 60FDH: 00H)

2. How to control output signals from the program

The output signal of the drive unit can be controlled by operating the value of the generated slave label from the program or from the watch.

Ex.

When changing the output of the output signal (DO1) of the drive unit by operating Bit 17 of the Physical outputs

```
[ST program]
//Turn ON output signal DO1
DRIVE_UNIT_001_PhysicalOutputs := H00020000;

//Turn OFF output signal DO1
DRIVE_UNIT_001_PhysicalOutputs := H00000000;
```

- Refer to the manual of the drive unit to be used for the bits to be operated.
- Slave label name is based on the case where the device label is "DRIVE_UNIT_001" at slave label generation.

3. How to use input signals as hardware stroke limit


Set the upper limit signal (1) and lower limit signal (2) targets on the "Axis Parameter" screen of the motion control setting function.

Ex.

When assigning Bit0 (Negative limit switch) and Bit1 (Positive limit switch) of object [Digital inputs (60fdh)] to hardware stroke limit

Setting item	Setting value
AxisName.PrConst.HwStrokeLimit_FlsSignal.Source.Target	[VAR]DRIVE_UNIT_001_DigitalInputs.1*1
AxisName.PrConst.HwStrokeLimit_RlsSignal.Source.Target	[VAR]DRIVE_UNIT_001_DigitalInputs.0*1

*1 The following is the case when the device label is "DRIVE_UNIT_001" when the slave label is generated.



16

Point

- To pass the input signal to the motion system, LSP/LSN signals may need to be assigned to the input device in the drive unit settings. For details, refer to the manual of the drive unit to be used.
- Set the signal detection method on the motion system side to be the same as the polarity of the object being used. If different settings are made, it may result in unintended operation. For details, refer to the manual of the drive unit to be used.

Error

For errors in the drive unit, refer to the manual of the drive unit to be used. When the object data (AxisName.PrConst.SlaveObject.vCurrentAlarm) is set to "[OBJ]0x603F0010", the drive unit error detail code (AxisName.Md.DriverErrorDetailID), which is the monitor data of drive unit errors, stores "0000".

For details, refer to the following.

☞ Page 909 Checking Errors and Warnings

Drive unit other than MELSERVO (other than cyclic synchronous mode)

For drive units other than MELSERVO to which no axis is assigned, map the object to PDO according to the control mode to be used, and generate slave labels for the required objects according to the procedure in the common Items for all devices (☞ Page 718 Common Items for All Devices). Refer to the manual of the drive unit to be used for the objects according to the control mode.

16.4 Relevant Functions

Driver control mode

The motion system supports operation of the following control modes.

Supported control mode	Driver control mode (AxisName.Md.Driver_Mode)	Description	Parameter name
Homing mode (hm)	6: Homing mode (hm)	A mode to execute homing operation by a drive unit.	Page 198 Driver homing method
Cyclic synchronous position mode (csp)	8: Cyclic synchronous position mode (csp)	Executes control following the sequential positioning command from the controller in each communication cycle.	Page 294 DIRECT CONTROL
Cyclic synchronous velocity mode (csv)	9: Cyclic synchronous velocity mode (csv)	Executes control following the velocity command from the controller in each communication cycle.	
Cyclic synchronous torque mode (cst)	10: Cyclic synchronous torque mode (cst)	Executes control following the torque command from the controller in each communication cycle.	
Continuous operation to torque control mode (ct)	-104: Continuous operation to torque control mode (ct)	A mode to switch to the continuous operation to torque operation smoothly without stopping from the cyclic synchronous position mode or the cyclic synchronous velocity mode.	Page 760 Continuous operation to torque control mode
Cyclic synchronous pressure mode (cspr)	-111: Cyclic synchronous pressure mode (cspr)	A mode to control pressure of the control target keeping the actual pressure constant even if the load fluctuates.	Page 764 Cyclic synchronous pressure mode

For details on driver control mode, refer to the following.

Page 41 Driver control mode transition

This section describes the following control modes and their transitions, which are available for some connected devices.

- Continuous operation to torque control mode
- Cyclic synchronous pressure mode

Continuous operation to torque control mode

For the drive unit which supports the continuous operation to torque control mode, when MC_TorqueControl (Torque Control) is started with "1: ct (continuous operation to torque control mode)" selected by Control mode switching selection (Options (Options): Bit 19), the drive unit control mode can be switched to the continuous operation to torque control mode (ct) and the drive unit can be controlled.

The continuous operation to torque control mode is a mode to switch to the continuous operation to torque operation smoothly without stopping from the cyclic synchronous position mode in positioning or the cyclic synchronous velocity mode in velocity command.


In the continuous operation to torque control mode, the driver executes the torque control with commanded torque set to Target torque (Torque) as accelerating or decelerating to the velocity set to Limit velocity (LimitVelocity).

To finish this FB, start MC_Stop (Forced Stop).

The firmware for connected devices which can use the continuous operation to torque control mode is shown below.

Model name	Version
MR-J5(W)-G	"B0" or later
MR-JET-G	

Transition of the continuous operation to torque control mode



*1 For details on switching to the continuous operation to torque control mode (ct), refer to the following.

Page 294 DIRECT CONTROL

No.	State transition description
(1)	Transits when a stop cause occurs.
(2)	Transits when multiple starting a motion FB (for example, positioning control FB) operated in the cyclic synchronous position mode (csp).

- "The cyclic synchronous torque mode ⇔ the continuous operation to torque control mode switching" cannot be executed when multiple start of MC_TorqueControl (Torque Control) is executed during MC_TorqueControl (Torque Control) start-up. If it is executed, "Control Mode Switching Disabled Warning" (warning code: 0D31H) occurs and the drive unit operates in the current control mode.


Precautions

- When the control mode does not switch within 1 [s] after requesting the control mode switching to the drive unit, "Control Mode Switching Error" (error code: 1A1DH) occurs and the axis stops.
- When specified as a master axis for master-slave operation, switching to the continuous operation to torque control mode cannot be executed.

■ Timing chart for input signals

- When the FB is normally completed

■ Operation for "cyclic synchronous position mode ⇔ continuous operation to torque control mode switching"




16

Point

Set "1: Actual velocity" to Velocity initial value selection at continuous operation to torque control mode switching (Options (Options): Bit 20, 21) to switch to the continuous operation to torque control mode when there is a difference between set velocity and actual velocity such as accelerating and decelerating or the velocity does not reach to the set velocity due to the limited torque.

■ Operation for "cyclic synchronous velocity mode ⇔ continuous operation to torque control mode switching"



Point

A torque command value in the continue operation to torque control mode will be disabled when it is switched from the continuous operation to torque control mode to the cyclic synchronous velocity mode.

As shown above, when the drive unit is continuously operates to torque to the continuous operation to torque direction, the torque will be output to the torque limit value when it is switched to the cyclic synchronous velocity mode.

In this case, execute any of the following before switching to the cyclic synchronous velocity mode.

- Start MC_MoveVelocity (Speed Control) in the reverse direction setting to the continuous operation to torque direction and switch to the cyclic synchronous velocity mode. (At this time, it is recommended to specify "0: Acceleration/deceleration specification method (mcAccDec)" for Acceleration/deceleration method setting (Options (Options): Bit 0 to 2).)
- Change the torque limit value to the lower value.

• When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Relevant variables/FB

For details, refer to the following.

 Page 306 Relevant variables

■Control details

For details, refer to the following.

However, read cst (cyclic synchronous torque mode) as ct (continuous operation to torque control mode).

 Page 307 Control details

■Precautions

- An actual motor velocity may not reach the limit velocity depending on the machine load during the continuous operation to torque control mode.
- It is recommended to match the direction of the torque command and the velocity command. If they differ, the velocity may decelerate once to 0.
- When switching from the continuous operation to torque control mode to the cyclic synchronous position mode, it is recommended to switch after changing the motor to stop status (zero speed status). The zero speed status can be monitored by labeling Status DO2 (2D12H) to the slave label.
- When switching the control mode from the cyclic synchronous position mode to the continuous operation to torque control mode, if the stop cause (axis error detection) occurs before control mode switching, the follow up may be executed, with the control mode left in the cyclic synchronous position mode, until achieving the zero speed status.
- When switching from the continuous operation to torque control mode to the cyclic synchronous position mode without waiting for stop of the motor, set "ZSP disabled selection at control switching (PC76.1)" of the servo parameter to "1: Disabled" and disable monitoring of zero speed status. However, note that it may cause vibration or impact at control mode switching.
- For unavailable functions of the servo amplifier during the continuous operation to torque control mode, refer to the drive unit manuals.

Point

- Set the system configuration with an unlimited operation range during the continuous operation to torque control mode as a stroke limit signal of the servo amplifier cannot be used during the continuous operation to torque control mode. Use the software stroke limit function of Motion module side to restrict the set position.
- If vibration occurs during the continuous operation to torque control, decrease "Torque feedback loop gain (PB03)" and check if the issue has been solved.

Cyclic synchronous pressure mode


The cyclic synchronous pressure mode (cspr) controls pressure of the control target keeping the actual pressure constant even if the load fluctuates.

When executing MCv_PressureControl (Pressure Control) with respect to the drive unit supporting the cyclic synchronous pressure mode (cspr), the drive unit control mode is switched to the cyclic synchronous pressure mode (cspr) to control pressure.

The firmware version for connected devices which can use the cyclic synchronous pressure control mode (cspr) is shown below.

Model name	Version
MR-J5-G-LL	"F0" or later

Transition of the cyclic synchronous pressure mode



No.	State transition description
(1)	Transits when a stop cause occurs.
(2)	Transits when multiple starting a motion FB (for example, positioning control FB) operated in the cyclic synchronous position mode (csp).


- Only from the cyclic synchronous position mode (csp), the drive unit control mode can switch to the cyclic synchronous pressure mode (cspr). Moreover, from the cyclic synchronous pressure mode (cspr), the drive unit control mode can switch only to the cyclic synchronous position mode (csp). When switching "from a mode other than the cyclic synchronous position mode (csp) to the cyclic synchronous pressure mode (cspr)" or "from the cyclic synchronous pressure mode (cspr) to a mode other than the cyclic synchronous position mode (csp)" with respect to the drive unit supporting the cyclic synchronous pressure mode (cspr), the control mode fails to switch, resulting in "Control Mode Switching Error" (error code: 1A1DH) due to a timeout.

Precautions

- When the control mode does not switch within 1 [s] after requesting the control mode switching to the drive unit, "Control Mode Switching Error" (error code: 1A1DH) occurs, and the axis stops.

■ Timing chart for I/O signals

- When the FB is normally completed



*1 Set pressure at operation start depends on Set pressure initial value selection (Options (Options): Bit 16). (The above figure is an example at setting to "0: Commanded pressure".)

- When an error occurs

For details when an error occurs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

■Parameter setting

Set the following parameters for the connected devices using the cyclic synchronous pressure control mode (cspr).

Parameter	Setting value
Forward/reverse-side stop function (PW12.2)* ¹	1: Forward-side stop (Enabled), Reverse-side stop (Disabled)
Control switching method setting (PW13.4)* ²	0: Disabled

*1 Do not set "0: Forward-side stop (Enabled), Reverse-side stop (Enabled)". If "0: Forward-side stop (Enabled), Reverse-side stop (Enabled)" is set, pressure control is not available. (If starting or multiple starting pressure control, servo alarm [AL. 09E.9 Control mode setting warning] occurs in the connected device, and thus "Driver Ready OFF" (error code: 1AAFH) occurs.
When "2: Forward-side stop (Disabled), Reverse-side stop (Disabled)" is set, pressure control is available. But the forward-side stop function is disabled in the connected device. Set the software stroke limit in order to limit the range where an axis can move in the increasing pressure direction.
Moreover, when using MCv_PressureControl (Pressure Control), set object data "Forward-side stop function (2E56H)" so as not to be mapped to PDO. For details, refer to the following.

☞ Page 322 Pressure Control

*2 When "1: Enabled" is set, the control mode of the connected device does not switch from the cyclic synchronous position mode (csp) to the cyclic synchronous pressure mode (cspr), and "Control Mode Switching Error" (error code: 1A1DH) occurs due to a timeout on the motion system side. When "2: Set disabled/enabled with controller" is set, the operation is the same as "0: Disabled".

■Relevant variables/FB

For details, refer to the following.

☞ Page 322 Relevant variables

■Control details

For details, refer to the following.

☞ Page 324 Control details

■Precautions

For details, refer to the following.

☞ Page 336 Precautions

Safety communication

A safety CPU and the firmware for connectable devices which can combine with RD78G(H) and perform the safety communication are shown below.

Model name	Version
RnSFCPU	☞ Page 981 Restrictions by the version
MR-J5-G-RJ	"B2" or later For details, refer to the following manual. ☞ MR-J5-G/MR-J5W-G User's Manual (Introduction)
MR-J5D-G	"C0" or later For details, refer to the following manual. ☞ MR-J5D-G User's Manual (Introduction)

Precautions for the safety communication with MR-J5-G-RJ

When executing safety communication with MR-J5-G-RJ, the servo warning [AL. 5E2.1_Safety communication no connection warning A (safety sub-function)] or [AL. 5E2.9_Safety communication no connection warning B (safety sub-function)] occurs in the drive unit until the safety communication is established. Therefore "Driver Warning" (warning code: 0D1FH) is detected in the motion system at connecting.

When referring the warning as execution conditions of the program, execute an error reset after connecting.

External signal high-accuracy input

For some functions that have external signal inputs such as touch probe and advanced synchronous control, when the following signals that support external signal high-accuracy input are used for the function that has Trigger input signal (TriggerInput), high-accuracy control with a device station signal detection time is enabled.
For the accuracy of signal detection time, refer to the manual of the device station to be used.

Precautions

- When MR-J5(W)-G series is used as external signal high-accuracy input, the touch probe function of MR-J5(W)-G series is required. The touch probe function of MR-J5(W)-G series has restrictions of the device and the version that can be used.
For details, refer to the manual of MR-J5(W)-G series.
MR-J5-G/MR-J5W-G: MR-J5-G/MR-J5W-G User's Manual (Introduction)
MR-J5D-G: MR-J5D-G User's Manual (Introduction)
 - Connected devices and versions that support the touch probe function

Device name	Supported version
MR-J5-G-RJ	"B6" or later
MR-J5(W)-G	"B6" or later
MR-J5D-G	"C0" or later

Relevant variables

I/O signals are expressed by the TARGET_REF structure. For details, refer to the following.
 Page 424 External Signal Selection

Control details

For the control details of each function when using external signal high-accuracy input, refer to the specification of each function.
For the list of functions that support external signal high-accuracy input, refer to the following.
 Page 424 External Signal Selection

Required settings for external signal high-accuracy input

External signal high-accuracy input uses a device station signal detection time, so that the setting to obtain the signal detection time is required.

If the required setting is not executed to external signal high-accuracy input, the signals operate with the same accuracy as normal signals.

■When using MR-J5(W)-G series

When using MR-J5(W)-G series, the touch probe function of MR-J5(W)-G series is used. For the details of parameters and objects of MR-J5(W)-G series, refer to the manual of MR-J5(W)-G.

The touch probe function of MR-J5(W)-G series has restrictions of the device and the version that can be used. For details, refer to the manual of MR-J5(W)-G series.

• Setting of MR-J5(W)-G series

1. Set connector pins to assign TPR1, TPR2, and TPR3 of the input device to be used.

<Setting example>

When using TPR1, TPR2, and TPR3 with MR-J5-G-RJ

- Set "2Ch (TRR1)" to "Device selection (PD38.0-1)". (Assign TPR1 to connector the pin CN3-10.)
- Set "2Dh (TRR2)" to "Device selection (PD39.0-1)". (Assign TPR2 to connector the pin CN3-1.)
- Set "63h (TRR3)" to "Device selection (PD05.0-1)". (Assign TPR3 to connector the pin CN3-19.)

• Setting of the Motion system

1. Set the following objects to TPDO of PDO mapping.

For the method of mapping, refer to "CC-Link IE TSN Configuration Window" of the following manual.

 MELSEC iQ-R Motion Module User's Manual (Network)

• When using TPR1

Index	Sub Index	Object name	Description
60B9h	00h	Touch probe status 1	Set to use TPR1 and 2.
60D1h	00h	Touch probe time stamp 1 positive value	Set to detect the rising edge of TPR1. (The setting is not required for detecting the falling edge only.)
60D2h	00h	Touch probe time stamp 1 negative value	Set to detect the falling of TPR1. (The setting is not required for detecting the rising only.)

• When using TPR2

Index	Sub Index	Object name	Description
60B9h	00h	Touch probe status 1	Set to use TPR1 and 2.
60D3h	00h	Touch probe time stamp 2 positive value	Set to detect the rising edge of TPR2. (The setting is not required for detecting the falling edge only.)
60D4h	00h	Touch probe time stamp 2 negative value	Set to detect the falling of TPR2. (The setting is not required for detecting the rising only.)

• When using TPR3

Index	Sub Index	Object name	Description
2DE9h	00h	Touch probe status 2	Set to use TPR3.
2DF8h	00h	Touch probe time stamp 3 positive value	Set to detect the rising edge of TPR3. (The setting is not required for detecting the falling edge only.)
2DF9h	00h	Touch probe time stamp 3 negative value	Set to detect the falling edge of TPR3. (The setting is not required for detecting the rising edge only.)

2. Set high-accuracy input to data of MC_TRIGGER_REF type.

Detection signal	Detection direction	Setting of MC_TRIGGER_REF type data			
		Target (Target)	Signal Detection Method (Detection)*1	Compensation Time (CompensationTime)*2	Filter Time (FilterTime)*3
TPR1	Rising edge	[OBJ]0x60B90010.6@station address	4: Detection at Rising Edge/ Falling Edge (BothEdges)	Arbitrary value	0.0
	Falling edge	[OBJ]0x60B90010.7@station address	4: Detection at Rising Edge/ Falling Edge (BothEdges)	Arbitrary value	0.0
TPR2	Rising edge	[OBJ]0x60B90010.E@station address	4: Detection at Rising Edge/ Falling Edge (BothEdges)	Arbitrary value	0.0
	Falling edge	[OBJ]0x60B90010.F@station address	4: Detection at Rising Edge/ Falling Edge (BothEdges)	Arbitrary value	0.0
TPR3	Rising edge	[OBJ]0x2DE90010.6@station address	4: Detection at Rising Edge/ Falling Edge (BothEdges)	Arbitrary value	0.0
	Falling edge	[OBJ]0x2DE90010.7@station address	4: Detection at Rising Edge/ Falling Edge (BothEdges)	Arbitrary value	0.0

*1 Toggle status for latch completion at the rising edge/the falling edge which is set to Target (Target) differs the status (0 and 1) every detection at rising/falling edge. Therefore, set "4: Detection at Rising Edge/Falling Edge (BothEdges)".

*2 For the setting range, refer to the specification of each function.

*3 To use as the external signal high-accuracy input, set 0.0.

3. Set to the input of function that uses the external signal with MC_TRIGGER_REF type data which has been set. (Example) Trigger input signal (TriggerInput) of MC_TouchProbe (Touch Probe Enabled)

4. Enable the touch probe function of MR-J5(W)-G series.

Enable the touch probe function of MR-J5(W)-G series using the following objects.

• When using TPR1 and TPR2

Index	Sub Index	Size (number of bits)	Object name
60B8h	00h	10h	Touch probe function 1

• When using TPR3

Index	Sub Index	Size (number of bits)	Object name
2DE8h	00h	10h	Touch probe function 2

Set the following value to the objects above. There are two methods to set the value to the object, one is using the transient transmission and the other one is using the cyclic transmission.

Detection signal	Detection direction	Object name	Value to be set	Description
TPR1	Rising edge	Touch probe function 1	Set "1" to Bit0, 1, 4.	Bit0: Touch probe 1 enabled Bit1: Continuous trigger mode
	Falling edge	Touch probe function 1	Set "1" to Bit0, 1, 5.	Bit4: Start sampling the rising edge of touch probe 1 Bit5: Start sampling the falling edge of touch probe 1
TPR2	Rising edge	Touch probe function 1	Set "1" to Bit8, 9, 12.	Bit8: Touch probe 2 enabled Bit9: Continuous trigger mode
	Falling edge	Touch probe function 1	Set "1" to Bit8, 9, 13.	Bit12: Start sampling the rising edge of touch probe 2 Bit13: Start sampling the falling edge of touch probe 2
TPR3	Rising edge	Touch probe function 2	Set "1" to Bit0, 1, 4.	Bit0: Touch probe 3 enabled Bit1: Continuous trigger mode
	Falling edge	Touch probe function 2	Set "1" to Bit0, 1, 5.	Bit4: Start sampling the rising edge of touch probe 1 Bit5: Start sampling the falling edge of touch probe 1



If the device station that is used is disconnected from the network, reconnect the device station and execute the procedure from 4. again.

●How to use the transient transmission

Write to the following object using MC_WriteParameter (Parameter Write).

For details of MC_WriteParameter (Parameter Write), refer to the following.

📖 Page 873 Parameter Read/Write Function

Point

Object writing by MC_WriteParameter (Parameter Write) can be executed in the device station in which axis is assigned only. For device stations in which the axis is not assigned, use the method for cyclic transmission.

(Program example)

When using TPR1 of MR-J5-G-RJ (When using both of rising edge and falling edge)

ST program

```
// Enable the touch probe function of MR-J5-G-RJ.
// writeValue is a label of DINT
// writeParameterExecute and writeParameterDone are labels of BOOL type.
writeValue := DINT#16#00000033; //Set Bit0, 1, 4, and 5.
MC_WriteParameter_1(
  Axis:= Axis0001.AxisRef ,
  Execute:= writeParameterExecute ,
  ParameterNumber:= UDINT#16#60B80010 , //Touch probe function 1
  Value:= DINT_TO_LREAL( writeValue ) ,
  ExecutionMode:= 0 ,
  Options:= UDINT#16#000000010000, //Set the setting value of integer data to the integer value without a sign.
  Done => writeParameterDone);
```

●How to use the cyclic transmission

(a) Set the following object to RPDO of PDO mapping.

For the method of mapping, refer to "CC-Link IE TSN Configuration Window" of the following manual.

📖MELSEC iQ-R Motion Module User's Manual (Network)

- When using TPR1 and TPR2

Index	Sub Index	Object name
60B8h	00h	Touch probe function 1

- When using TPR3

Index	Sub Index	Object name
2DE8h	00h	Touch probe function 2

(b) Generate a device label of the above object.

For how to generate a device label, refer to the following.

📖 Page 718

(c) Execute the following operation to the generated device label.

(Program example)

When using TPR1 of MR-J5-G-RJ (When using both of rising edge and falling edge)

ST program

```
// Enable the touch probe function of MR-J5-G-RJ.
MR_J5_G_RJ_001_TouchProbeFunction:= UINT#16#0033; //(Set 1 to BIT0, 1, 4, and 5.)
```


5. Check whether the touch probe function of MR-J5(W)-G series is enabled.

Check whether the touch probe function of MR-J5(W)-G series is enabled using the following object.

- When using TPR1 and TPR2

Index	Sub Index	Size (number of bits)	Object name
60B9h	00h	10h	Touch probe status 1

- When using TPR3

Index	Sub Index	Size (number of bits)	Object name
2DE9h	00h	10h	Touch probe status 2

Check the following value is stored to the above object. There are two methods to check the object, one is using the transient transmission and the other one is using the cyclic transmission.

Detection signal	Detection direction	Object name	Value at touch probe enabled	Description
TPR1	Rising edge	Touch probe Status1	Bit0 is set to 1.	Bit0: Touch probe 1 enabled
	Falling edge	Touch probe Status1	Bit0 is set to 1.	
TPR2	Rising edge	Touch probe Status1	Bit8 is set to 1.	Bit8: Touch probe 2 enabled
	Falling edge	Touch probe Status1	Bit8 is set to 1.	
TPR3	Rising edge	Touch probe Status2	Bit0 is set to 1.	Bit0: Touch probe 3 enabled
	Falling edge	Touch probe Status2	Bit0 is set to 1.	

●How to use the transient transmission

Read the following object using MC_ReadParameter (Parameter Read).

For details of MC_ReadParameter (Parameter Read), refer to the following.

 Page 873 Parameter Read/Write Function

(Program example)

When using TPR1 of MR-J5-G-RJ

ST program
<pre>// Obtain the status of touch probe of MR-J5-G-RJ. // readValue is a label of LREAL. // tempValue is a label of INT. // readParameterEnable and readParameterValid are labels of BOOL type. MC_ReadParameter_1(Axis:= Axis0001.AxisRef , Enable:= readParameterEnable , ParameterNumber:= UDINT#16#60B90010 , //Touch probe status 1 Options:= UDINT#16#000000010000, //Set the setting value of integer data to the integer value without a sign. Valid => readParameterValid, Value => readValue); // Check whether touch probe of MR-J5-G-RJ is enabled. tempValue := LREAL_TO_INT(readValue); IF tempValue.0 THEN //Start the function that uses external signal high-accuracy input. END_IF;</pre>

●How to use the cyclic transmission

(a) Generate a device label of the following object.

For how to generate a device label, refer to the following.

 Page 718

- When using TPR1 and TPR2

Index	Sub Index	Object name
60B9h	00h	Touch probe status 1

- When using TPR3

Index	Sub Index	Object name
2DE9h	00h	Touch probe status 2

(b) Execute the following operation to the generated device label.

(Program example)

When using TPR1 of MR-J5-G-RJ (When using both of rising edge and falling edge)

ST program

```
// Check whether touch probe of MR-J5-G-RJ is enabled.  
IF MR_J5_G_RJ_001_TouchProbeStaus.0 THEN  
  //Start the function that uses external signal high-accuracy input.  
  END_IF;
```

Program example

■When using MR-J5-G-RJ series

- When TPR1 of MR-J5-G-RJ (station address: 192.168.3.1) is used as Trigger input signal (TriggerInput) of MC_TouchProbe (Touch Probe Enabled) at the rising edge detection

<Setting of MR-J5-G-RJ>

1. Set a connector pin to assign TPR1 of the input device to be used.
Set "2Ch (TPR1)" to "Device selection (PD38.0-1)". (Assign TPR1 to the connector pin CN3-10.)

<Setting of the Motion system>

1. Set the following object to TPDO of PDO mapping.
For the method of mapping, refer to "CC-Link IE TSN Configuration Window" of the following manual.
 MELSEC iQ-R Motion Module User's Manual (Network)

Index	Sub Index	Object name
60B9h	00h	Touch probe status 1
60D1h	00h	Touch probe time stamp 1 positive value

2. Generate a label to be used as Trigger input signal (TriggerInput) of MC_TouchProbe (Touch Probe Enabled).
Create a new data of MC_TRIGGER_REF type and set Toggle status (Touch probe status 1 (Bit6)) for latch completion of TPR1 to Target (Target).

Data name	Setting of MC_TRIGGER_REF type data			
	Target (Target)	Signal Detection Method (Detection)	Compensation Time (CompensationTime)	Filter Time (FilterTime)
SignalData0001	[OBJ]0x60B90010.6@192.168.3.1	4: Detection at RisingEdge/Falling Edge (BothEdges)	0.0	0.0

3. Generate a label to be used as Probe data (ProbeData) of MC_TouchProbe (Touch Probe Enabled).
Create a new data of TARGET_REF type and set Probe data (ProbeData). As an example, the case to set axis data is shown below.

Data name	Setting of TARGET_REF type data			
	Target (Target)			
SignalData0002	[AXIS]mcSetValue@Position			

4. Enable the touch probe function of MR-J5-G-RJ by ST program and start MC_TouchProbe (Touch Probe Enabled).

ST program

```
// Enable the touch probe function of MR-J5-G-RJ.
// writeValue is a label of DINT.
// writeParameterExecute, writeParameterDone, and touchProbeExecute are labels of BOOL type.
writeValue := DINT#16#00000013; //Set Bit0, 1, 4.
MC_WriteParameter_1(
  Axis:= Axis0001.AxisRef ,
  Execute:= writeParameterExecute ,
  ParameterNumber:= UDINT#16#60B80010 , //Touch probe function 1
  Value:= DINT_TO_LREAL( writeValue ) ,
  ExecutionMode:= 0 ,
  Options:= UDINT#16#000000010000, //Set the setting value of integer data to the integer value without a sign.
  Done => writeParameterDone);

// Obtain the status of touch probe of MR-J5-G-RJ.
// readValue is a label of LREAL. tempValue is a label of INT.
// readParameterEnable and readParameterValid are labels of BOOL type.
MC_ReadParameter_1(
  Axis:= Axis0001.AxisRef ,
  Enable:= readParameterEnable ,
  ParameterNumber:= UDINT#16#60B90010 , //Touch probe status 1
  Options:= UDINT#16#000000010000, //Set the setting value of integer data to the integer value without a sign.
  Valid => readParameterValid,
  Value => readValue );

tempValue := LREAL_TO_INT(readValue); // When touch probe of MR-J5-G-RJ is enabled
IF tempValue.0 THEN
  touchProbeExecute := TRUE; //Set TRUE to Execute of MC_TouchProbe.
  readParameterEnable := FALSE; //Stop readParameter.
END_IF;

// Set external signal high-accuracy input to TriggerInput of MC_TouchProbe.
// Latch the data set to ProbeData at the rising edge of TPR1 of MR-J5-G-RJ.
// touchProbeRecordedPos is a label of LREAL type.
MC_TouchProbe_1(
  Axis:= Axis0001.AxisRef ,
  Execute := touchProbeExecute,
  TriggerInput := SignalData0001 ,
  ProbeData := SignalData0002 ,
  RecordedPosition => touchProbeRecordedPos);
```

Precautions

- When using external signal high-accuracy input, set "0.0" to Filter Time (FilterTime) of the external signal selection.
If the device station has the input filter, use the filter of the device station.
When using external signal high-accuracy input and setting other than "0.0" to Filter Time (FilterTime) of the external signal selection, a signal detection time cannot be detected correctly.
- Note that the signal to be input to the device station as high-accuracy input should not be turned ON/OFF several times within a communication cycle. If the signal turns ON/OFF several times within a communication cycle, the signal cannot be detected correctly.
- If a signal that cannot be used as a high-accuracy input is set, it operates as operation cycle accuracy and may not achieve the intended accuracy. The following objects can be used to check if the operation is being performed with a high-accuracy input.
If the operation is not performed as a high-accuracy input, review the device used and its settings according to "Required settings for external signal high-accuracy input" ( Page 768 Required settings for external signal high-accuracy input).

Device station	How to check if high-accuracy is valid			How to check if the signal detection time is stored		
MR-J5(W)-G series	TPR1	Touch probe status	Bit0 = 1	Rising edge detection	Touch probe time stamp 1 positive value(60D1h)	The time information must be stored in the object.
				Falling edge detection	Touch probe time stamp 1 negative value(60D2h)	
	TPR2	Touch probe status	Bit8 = 1	Rising edge detection	Touch probe time stamp 2 positive value(60D3h)	
				Falling edge detection	Touch probe time stamp 2 negative value(60D4h)	
	TPR3	Touch probe status 2	Bit0 = 1	Rising edge detection	Touch probe time stamp 3 positive value(2DF8h)	
				Falling edge detection	Touch probe time stamp 3 negative value(2DF9h)	

Master-slave operation


This section describes an example of how to use master-slave operation.
For details on master-slave operation, refer to the following.

☞ Page 452 Master-Slave Operation

System configuration

This section uses the following system configuration example to describe the master-slave operation.

Motion module (master axis)
Network No.1




Parameter setting

This section describes each parameter setting.

■Master-slave operation setting

Set "Master-slave Operation Setting"(1) of the module parameter (motion) to "Used".

☞ Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Motion)] ⇒
"Parameter editor" screen ⇒ [Module Operation Setting] ⇒ [Master-slave Operation Setting]



■Network configuration setting

Check "Motion Control Station"(2) and "Parameter Automatic Setting"(3) of the stations specified as the master axis and the slave axis.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting]

CC-Link IE TSN Configuration (Start I/O: 0000)

Connected/Disconnected Module Detection Detailed Display

Mode Setting: Online (Unicast Mode) Assignment Method:

Cyclic Transmission Time (Min.): 22.00 us Communication Period Interval (Min.): 125.00 us

No.	Model Name	STA#	Station Type	Motion Control Station	RX Setting Points	RY Setting Points	RWIr Setting Points	RWW Setting Points	Parameter Automatic Setting	PDO Mapping Setting
0	Host Station	0	Master Station	☒					☒	<Detail Setting>
1	MR-J5-G	1	Remote Station	☒			24	20	☒	<Detail Setting>
2	MR-J5-G	2	Remote Station	☒			24	20	☒	<Detail Setting>
3	MR-J5-G	3	Remote Station	☒			24	20	☒	<Detail Setting>

Host Station

STA#0 Master Station
Total STA#3
Line/Star

MR-J5-G MR-J5-G MR-J5-G

Module List

CC-Link IE TSN Selection | Find Module | My

- General CC-Link IE TSN Module
- CC-Link IE TSN Module (Mitsubishi Electric)
- Master/Local Module
- Motion Module
- GOT2000 Series
- General-Purpose AC Servo
- General-purpose Inverter
- DG Input
- Transistor Output
- I/O Combined
- Analog Input
- Analog Output
- Bridge module(CC-Link IE TSN-Any)

Output

Error Warning Information

Servo parameter setting

Set the servo parameters for the station in which master-slave operation is enabled.

For details on the servo parameters used for master-slave operation, refer to the following.


Page 459 Parameter automatic setting

- Set the following servo parameters for the station in which master-slave operation is enabled.

No.	Name	Station 1	Station 2	Station 3
PD15.0	Master axis operation selection	1: Enabled	0: Disabled	0: Disabled
PD15.1	Slave axis operation selection	0: Disabled	1: Enabled	1: Enabled
PD22	Driver communication setting - Slave - Master axis 1 - Station No. setting	0	1	1
PD23.1	Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting	0	1	2
PD30	Master-slave operation - Slave-side torque command coefficient	0	100 ^{*1}	100 ^{*1}
PD31	Master-slave operation - Slave-side speed limit coefficient	0	100 ^{*1}	100 ^{*1}

*1 Set the parameters according to your environment.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Network Configuration Settings] ⇒ [Detailed Setting] ⇒ "CC-Link IE TSN Configuration" screen ⇒ [Parameter Automatic Setting] ⇒ [Detailed Setting]



16



Set other servo parameters according to your environment.

■Communication period interval setting

Set the communication period interval setting (4) and the cyclic transmission time (5).


For the setting details, refer to the following.

📖 Page 458 Communication period setting

Set the following values.

Item	Setting value
Communication period interval setting	1000.00 [μs]
Cyclic transmission time	31.00 [μs]

🔍 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Parameter (Network)] ⇒ "Parameter editor" screen ⇒ [Basic Settings] ⇒ [Communication Period Setting]



■Module extended parameter

Create a new axis for the axis specified as the master axis and set the axis type setting to "Real Drive Axis" (7).

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Extended Parameter] ⇒ [Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ Right-click ⇒ [Add New Data]

The 'New Data' dialog box shows the following settings:

- Basic Setting:** Data Type: Axis, (Data Name): Axis0001
- Detailed Setting:**
 - Axis Information: Axis No.: 1
 - Axis Parameter Constant: Station Address Setting: 192.168.3.1
 - Axis Type Setting: Real Drive Axis (7)**
 - Control Cycle Setting: Operate in the First Operation Cycle

Set the station addresses for the slave axes in "Slave Axis Station Address Setting [1 to 8]" (8) in the master-slave operation setting of the axis parameter constant.

In addition, set "Axis Emulation Enabled" (9) of the axis parameter constant to "0: Disabled".

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Module model] ⇒ [Module Extended Parameter] ⇒ [Motion Control Setting Function] ⇒ Navigation window ⇒ [Axis] ⇒ [Target axis] ⇒ [Axis Parameter Constant]

The 'Axis Parameter Setting' window displays the following settings for Axis0001:

Item	Value
Axis No.	1
Axis Parameter Constant	Expands setting values at axis variable initialization. Re-i
Station Address Setting	192.168.3.1
Axis Type Setting	0:Real Drive Axis
Upper Limit Signal	
Signal	
Target	
Signal Detection Method	0:Detection at TRUE
Compensation Time	0.0 s
Filter Time	0.0 s
Lower Limit Signal	
Signal	
Target	
Signal Detection Method	0:Detection at TRUE
Compensation Time	0.0 s
Filter Time	0.0 s
Master-slave Operation Setting	
Slave Axis Station Address Setting[1]	192.168.3.2
Slave Axis Station Address Setting[2]	192.168.3.3
Slave Axis Station Address Setting[3]	
Slave Axis Station Address Setting[4]	
Slave Axis Station Address Setting[5]	
Slave Axis Station Address Setting[6]	
Slave Axis Station Address Setting[7]	
Slave Axis Station Address Setting[8]	
Control Cycle Setting	0:Operate in the First Operation Cycle
Absolute Position Reference Setting	3:Machine Feed Value
Absolute Position Control Setting	-1:Automatic Setting (Acquire from Connected Device)
Ring Counter Enabled Selection	0:Disabled
Ring Counter Lower Limit Value	-10000000000.0 pulse
Ring Counter Upper Limit Value	10000000000.0 pulse
Axis Emulation Enabled	0:Disabled (9)
Torque Limit Maximum Value	1000.0 %

The 'Slave Axis Station Address Setting' table (8) is highlighted with a red box. The 'Axis Emulation Enabled' setting is set to '0:Disabled' (9).

Program example

■Slave labels

The slave labels used in the program example are shown below.

For how to use slave labels, refer to the following.

☞ Page 718 How to use the slave label

Master axis/slave axis	Device label	Label name
Master axis	MR_J5_G_001	—
Slave axis 1	MR_J5_G_002	MR_J5_G_002_Controlword
		MR_J5_G_002_PositiveTorqueLimitValue
		MR_J5_G_002_NegativeTorqueLimitValue
		MR_J5_G_002_Statusword
Slave axis 2	MR_J5_G_003	MR_J5_G_003_Controlword
		MR_J5_G_003_PositiveTorqueLimitValue
		MR_J5_G_003_NegativeTorqueLimitValue
		MR_J5_G_003_Statusword

■Labels

The labels used in the program example are shown below.

Label name	Data type	Comment
MC_Power_1	MC_Power	Master axis servo ON FB
bSlaveAxis1_ServoOnReq	Bit	Slave axis 1 servo ON request
bSlaveAxis1_ServoOnSts	Bit	Slave axis 1 servo ON status
bSlaveAxis2_ServoOnReq	Bit	Slave axis 2 servo ON request
bSlaveAxis2_ServoOnSts	Bit	Slave axis 2 servo ON status
bSlaveAxis1_ErrorReset	Bit	Slave axis 1 error reset request
bSlaveAxis2_ErrorReset	Bit	Slave axis 2 error reset request

■Program for servo ON

Execute servo ON of the slave axis and the master axis when Master-slave operation - axes group ready (Axis0001.Md.MasterSlave_ReadyOnGroup) of the master axis is TRUE.

- Master axis

ST program

```
//-----Axes Group Ready-----
IF ( Axis0001.Md.MasterSlave_ReadyOnGroup = TRUE ) THEN
  //-----Master axis servo ON-----
  MC_Power_1(Axis:= Axis0001.AxisRef, Enable:= TRUE, ServoON:= TRUE);
  //-----Slave axis 1, 2 servo ON-----
  bSlaveAxis1_ServoOnReq := TRUE;
  bSlaveAxis2_ServoOnReq := TRUE;
ELSE
  //-----Master axis servo OFF-----
  MC_Power_1(Axis:= Axis0001.AxisRef, Enable:= FALSE ,ServoON:= FALSE );
  //-----Slave axis 1, 2 servo OFF-----
  bSlaveAxis1_ServoOnReq := FALSE;
  bSlaveAxis2_ServoOnReq := FALSE;
END_IF;
```

- Slave axis 1

ST program

```
//-----Data link check-----
IF NOT SW0B0.1 THEN
  //----- Servo ON-----
  IF bSlaveAxis1_ServoOnReq THEN
    //-----PDS state transitions
    //-----For MR-J5, servo ON (transition to the Operation enabled state) can be executed directly by sending
    // the "Enable operation" command in the "Switch on disabled" state.-----
    IF MR_J5_G_002_Statusword.6 THEN //-----PDS state: Switch on disabled-----
      //-----Command: Shutdown-----
      MR_J5_G_002_Controlword := MR_J5_G_002_Controlword AND HFFF0 OR H0006;
      bSlaveAxis1_ServoOnSts := FALSE;
    ELSE
      CASE WORD_TO_INT(MR_J5_G_002_Statusword AND H000F) OF
        1: //-----PDS state: Ready to switch on-----
          //-----Command: Switch on-----
          MR_J5_G_002_Controlword := MR_J5_G_002_Controlword AND HFFF0 OR H0007;
          bSlaveAxis1_ServoOnSts := FALSE;
        3: //-----PDS state: Switched on-----
          //-----Command: Enable operation-----
          MR_J5_G_002_Controlword := MR_J5_G_002_Controlword AND HFFF0 OR H000F;
          bSlaveAxis1_ServoOnSts := FALSE;
        7: //-----PDS state: Operation enabled-----
          bSlaveAxis1_ServoOnSts := TRUE;
      ELSE //-----PDS state: Fault , Fault reaction active-----
        bSlaveAxis1_ServoOnSts := FALSE;
      END_CASE;
    END_IF;
  ELSE
    //-----Command: Shutdown-----
    MR_J5_G_002_Controlword := MR_J5_G_002_Controlword AND HFFF0 OR H0006;
    bSlaveAxis1_ServoOnSts := FALSE;
  END_IF;

  //-----Torque limit-----
  MR_J5_G_002_PositiveTorqueLimitValue := 1000; //-----100%-----
  MR_J5_G_002_NegativeTorqueLimitValue := 1000; //-----100%-----
END_IF;
```

- Slave axis 2

ST program

```
//-----Data link check-----
IF NOT SW0B0.2 THEN
  //-----Servo ON-----
  IF bSlaveAxis2_ServoOnReq THEN
    //-----PDS state transitions-----
    //-----For MR-J5, servo ON (transition to the Operation enabled state) can be executed directly
    //by sending the "Enable operation" command in the "Switch on disabled" state.-----
    IF MR_J5_G_003_Statusword.6 THEN // PDS state: Switch on disabled
      bSlaveAxis2_ServoOnSts := FALSE;
      //-----Command: Shutdown-----
      MR_J5_G_003_Controlword := MR_J5_G_003_Controlword AND HFFF0 OR H0006;
      ELSE
      CASE WORD_TO_INT(MR_J5_G_003_Statusword AND H000F) OF
        1: //-----PDS state: Ready to switch on-----
          //-----Command: Switch on-----
          MR_J5_G_003_Controlword := MR_J5_G_003_Controlword AND HFFF0 OR H0007;
          bSlaveAxis2_ServoOnSts := FALSE;
        3: //-----PDS state: Switched on-----
          //-----Command: Enable operation-----
          MR_J5_G_003_Controlword := MR_J5_G_003_Controlword AND HFFF0 OR H000F;
          bSlaveAxis2_ServoOnSts := FALSE;
        7: //-----PDS state: Operation enabled-----
          bSlaveAxis2_ServoOnSts := TRUE;
      ELSE //-----PDS state: Fault , Fault reaction active-----
        bSlaveAxis2_ServoOnSts := FALSE;
      END_CASE;
    END_IF;
  ELSE
    //-----Command: Shutdown-----
    MR_J5_G_003_Controlword := MR_J5_G_003_Controlword AND HFFF0 OR H0006;
    bSlaveAxis2_ServoOnSts := FALSE;
  END_IF;

  //-----Torque limit-----
  MR_J5_G_003_PositiveTorqueLimitValue := 1000; //-----100%-----
  MR_J5_G_003_NegativeTorqueLimitValue := 1000; //-----100%-----
END_IF;
```

■Program for slave axis error reset

The following is a program example for error reset when an error occurs on the slave axis.

- Slave axis 1

ST program

```
//-----Data link check-----  
IF NOT SW0B0.1 THEN  
  //-----Error reset-----  
  IF bSlaveAxis1_ErrorReset THEN  
    IF MR_J5_G_003_Statusword.3 THEN //-----PDS state: Fault , Fault reaction active-----  
      //-----Command: Fault Reset-----  
      MR_J5_G_002_Controlword.7 := TRUE;  
    ELSE  
      MR_J5_G_002_Controlword.7 := FALSE;  
      bSlaveAxis1_ErrorReset := FALSE;  
    END_IF;  
  END_IF;  
END_IF;
```

- Slave axis 2

ST program

```
//-----Data link check-----  
IF NOT SW0B0.2 THEN  
  //-----Error reset-----  
  IF bSlaveAxis2_ErrorReset THEN  
    IF MR_J5_G_003_Statusword.3 THEN //-----PDS state: Fault , Fault reaction active-----  
      //-----Command: Fault Reset-----  
      MR_J5_G_002_Controlword.7 := TRUE;  
    ELSE  
      MR_J5_G_002_Controlword.7 := FALSE;  
      bSlaveAxis2_ErrorReset := FALSE;  
    END_IF;  
  END_IF;  
END_IF;
```

16.5 Precautions

- When using MR-J5(W)-G with old firmware, "Watchdog Counter Error" (error code: 1C41H) may occur at connecting. When this symptom occurs, update the firmware of MR-J5(W)-G.
- When parameter automatic setting is enabled in the network configuration settings on the engineering tool, the number of targets is limited. For details, refer to "Device station parameter automatic setting" in the following manual.
 MELSEC iQ-R Motion Module User's Manual (Network)
- When using MR-J5(W)-G in modes other than cyclic synchronous mode, the motion system does not perform the limit check of the command, or issue the forced stop command. Carry out safety measures at the user's program or the drive unit side.
- When an axis group is set by combining drive units of different models, there may be a difference in the operation results of each axis due to the performance difference of each model. When the interpolation control or synchronous control is performed, the work trajectory may be disturbed.
- When using MR-J5(W)-G in cyclic speed mode, cyclic synchronous torque mode, continuous operation to torque control mode or cyclic synchronous pressure mode, if a value smaller than the unit of the mapped object data is sent to the drive unit, the value smaller than the unit is truncated when it is sent.

Ex.

When the unit of Target Velocity is "0.1rpm", and the velocity command value after the driver unit conversion is "1.11 [rpm]". "1.1 [rpm]" is sent to the drive unit.

PART 4

CONTROL/OPERATION/ MAINTENANCE

This part consists of the following chapters.

17 LOGGING

18 RAS FUNCTIONS

19 MOTION SERVICE PROCESSING

20 HOW TO CONTROL FROM CPU MODULE

21 FILE CONTROL

22 SECURITY

23 MOTION MODULE SOFTWARE INSTALLATION

24 TROUBLESHOOTING

17 LOGGING

"Logging" is used as a generic term for "Data logging" and "Real-time monitor". This chapter describes how to use data logging and real-time monitor.

17.1 Data Logging/Real-Time Monitor

Operation of this function at each status of system

○: Possible, ×: Not possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	×

Relevant variables

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
Logging_AutoLoggingEnable	Auto Logging Enabled	Sets "Allow" or "Do not allow" of auto logging function when the logging setting file is stored in the SD memory card. <ul style="list-style-type: none">• FALSE: Disabled• TRUE: Enabled

Logging monitor data (System.LoggingRef[1..10].Md.)

The elements [1] to [10] of the "System.LoggingRef[1..10].Md." array correspond to logging settings 1 to 10.

Variable/Structure name	Name	Details
SettingPath	Logging Setting File	Displays the path (file name) of the logging setting file during the logging.
LogDataPath	Logging Data File Path	Displays the path (file name) of the logging data file.
LoggingStatus	Logging Status	Indicates the logging execution status. • FALSE: Stop • TRUE: Executing
Triggered	Triggered	Displays the triggered status. • FALSE: Not triggered • TRUE: Triggered
TriggerCount	Trigger Detection Count	Displays the trigger detection count.
TriggerCountIgnored	Trigger Ignored Count	A trigger occurs again during collecting data after trigger and it indicates the trigger ignored count.
LogDataSavedCount	Number of Saved Files	Displays the number of saved data logging files.
TriggerStatus[1..32]	Trigger Status	Displays the status of each trigger condition as a bit (b0 to b31). Indicates the status of each trigger condition. • FALSE: Trigger condition not established • TRUE: Trigger condition established
TriggerStatusword	Trigger Status Word	Reflects the same status as Trigger status (TriggerStatus[1..32]) variable to a bit (b0 to b31).
SaveStatus	Save Status	Displays the save status to files of collected data. • 0: Unsaved (UnSave) • 1: Saving (Saving) • 2: Saved (Saved) • 3: All Files Saved (FullySaved)
LogType	Logging Type	Displays the logging type in progress. • 0: None (_None) • 1: Continuous logging (ContinuousLogging) • 2: Trigger logging (TriggerLogging)
ErrStatus	Error Status	Stores the error code related to logging.
SamplingTime[0..1]	Data Collection Interval	Displays the data collection interval in a unit of ns. • [0] Sampling interval lower 32 bits • [1] Sampling interval upper 32 bits

Logging control data(System.LoggingRef[1..10].Cd.)



The elements [1] to [10] of the "System.LoggingRef[1..10].Cd." array correspond to logging settings 1 to 10.

Variable/Structure name	Name	Details
SettingPath	Logging Setting Path	Sets the storage location path (folder name/file name) of logging setting.
StartLog	Logging Request	Requests the execution of logging. • FALSE: STOP • TRUE: RUN
Trigger	Trigger Request	Requests the trigger when "Trigger command" is set for a trigger condition. • FALSE: No request • TRUE: Request

Data logging function

Data logging function is used to collect the motion system data at a specified interval based on the logging setting (trigger condition or data collection condition) written by the engineering tool and save the result to the data logging file.

The collected data is saved as the logging file. The data logging setting up to 10 can be executed at the same time in the motion system.



Real-time monitor


Real-time monitor is used to set the data collection and monitor the collected data (waveform display) in real time in the status where the engineering tool has been connected with the motion system.

For details, refer to Help of the engineering tool.

Steps until the collected data is saved

Data logging

The motion system executes data logging according to the description of logging setting files.
The control and monitor of data logging are executed by the LOGGING_REF structure.
The collected data is saved to the internal buffer in real-time processing and it is saved to the file in back-ground processing.




Real-time monitor

Real-time monitor is used in the status where the engineering tool has been connected with the motion system. The motion system executes the followings according to the description of the real-time monitor setting file set in the engineering tool.

Execution details	Data	Maximum number of points
Data collection to the internal buffer	All of the specified data	Max. 1024 points
Data output to the buffer for the real-time display	Data that are selected as the real-time waveform display target from the specified data	Max. 32 points

When the data collection is completed, the collected data in the internal buffer is saved and displayed in the engineering tool. Real-time monitor can start with new setting independently from data logging. Also, it can start based on the setting of the data logging in progress.




Status of logging

The status of logging in progress can be checked by the following.

- Logging Status (System.LoggingRef[1..10].Md.LoggingStatus)
- Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32])
- Triggered (System.LoggingRef[1..10].Md.Triggered)
- Save Status (System.LoggingRef[1..10].Md.SaveStatus).

The following describes the operation at trigger logging when Data = 100 is set for a "Trigger condition", and 2 is set for a "Number of trigger logging".



It becomes TRUE while trigger condition is processed for Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32]), and after trigger condition is processed for Triggered (System.LoggingRef[1..10].Md.Triggered). After the completion of collecting the number of records set to the "number of records after trigger", they both returns to FALSE.

After the completion of saving files, it turns the state of Save Status (System.LoggingRef[1..10].Md.SaveStatus) as follows.

Save Status (System.LoggingRef[1..10].Md.SaveStatus)	Description
3: All Files Saved (FullySaved)	<ul style="list-style-type: none"> • When the all records specified the number in "Number of file switching records" by continuous logging are saved to files • When the all records specified the number in "Number of trigger records after trigger" by trigger logging are saved to files and the only files specified the number in "Number of trigger logging"
2: Saved (Saved)	When the files are saved with the condition which is not met the condition of "3: All Files Saved (FullySaved)"

However, after the status becomes "2: Saved (Saved)" or "3: All Files Saved (FullySaved)", the status moves to be "0: Unsaved (UnSave)" immediately if the logging is in progress.

Internal buffer

The internal buffer which is used to temporarily store collected data frees up the memory capacity up to the capacity assigned to the logging function by "System memory setting". Adjust the system memory setting according to the number of logging settings and data.

The following shows a rough standard of the required amount of memory for logging.

Minimum required amount per setting (k bytes) = $100 + (\text{The total number of the appropriate words for each data}) \times R \times B / 1024$

Item	Description
Minimum required amount per setting	<p>It may increase more than the minimum required amount depending on the setting order of the data when different types of word data exist as the target data. For the internal buffer, the number of appropriate words of the smaller type may be rounded up to the number of the appropriate words of the next bigger type. Because the two-word data and the four-word data are set in the two-word border and the four-word border respectively.</p> <p><Example></p> <p>When the setting order is four-word data, one-word data, four word data.</p> <ul style="list-style-type: none"> • The number of appropriate words is "12". (The number of appropriate words for one word data is rounded up to "4".)
Total number of the appropriate words for each data	<p>The number of the appropriate words per one for each data is shown below.</p> <ul style="list-style-type: none"> • Bit: 1 / 16 (one word for 16) • Word (signed): 1 • Double word (signed): 2 • Word (unsigned): 1 • Double word (unsigned): 2 • Single-precision real number: 2 • Double-precision real number: 4
R(Number of records)	<p>■ During continuous logging R is Number of file switching records (SAVSWICTMNRECNUM)</p> <p>■ In trigger logging R is Number of trigger records before trigger (LLNBEFOR) + Number of trigger records after trigger (LLNAFTER)</p>
B(Number of buffer)	<p>■ When the specification of the number of buffer (NUMBUFF) is 2 to 10: B = NUMBUFF</p> <p>■ When the specification of the number of buffer (NUMBUFF) is 0, and when the number of records R × collection interval is as follows</p> <ul style="list-style-type: none"> • Within 1 [s]: B is 4 • Within 1 [s] to 5 [s]: B is 3 • Other than the above: B is 2

SD memory card replacement

When the storage location of the data logging files is set to an SD memory card, the SD memory card can be replaced by using the SD memory card forced disable function even while data logging is in progress. Only the data saving to the SD memory card is stopped. The data collection keeps working.



If a new SD memory card is inserted before the next file saving is started, the logging result is saved to the new SD memory card. If an SD memory card is not inserted before the next file saving is started, the file saving is failure and an error occurs.

Logging setting

The following describes how to set data logging/real-time monitor.

The () of the title indicates the object name of logging setting files (Json format) in this below.

Data to be collected (DATA)

Set data to be collected by logging. The number of data can be set is up to 1024. Duplicate data records are counted as distinct.

■Data name (NAME)

Set the data name to be collected (device, label). For the format specification, refer to the following.

☞ Page 428 TARGET_REF structure

To collect a mapped object to cyclic data, assign the object to the device label and set it. For how to assign the device label, refer to the following.

☞ Page 718 CONNECTABLE DEVICE to CC-Link IE TSN

■Data type (TYPE)

The following shows data type that can be specified to the data name.

- Bit
- Word [unsigned]
- Double word [unsigned]
- Word [signed]
- Double word [signed]
- Single-precision real number
- Double-precision real number

When the device is specified to the data name, it is required to specify the data type as well. The data type also can be specified by the specification of the NAME object. When both NAME and TYPE are specified, the specification of NAME takes priority.

When the label is specified to the data name, the data type specification is ignored.

Logging setting (LOGGING)

Set the logging operation.

■Logging start conditions (STARTCONDITION)

Set a logging start condition.

When the logging is stopped, the data in buffer at the time is output to the file.

Logging start conditions	Description
Starts automatically	When the motion system starts ^{*1} , Logging Request (System.LoggingRef[1..10].Cd.StartLog) becomes TRUE and logging starts automatically. Logging can start and stop after the system starts by Logging Request (System.LoggingRef[1..10].Cd.StartLog).
Stop disabled after automatically start	When the motion system starts ^{*1} , Logging Request (System.LoggingRef[1..10].Cd.StartLog) becomes TRUE and logging starts automatically. Logging cannot stop manually (Logging Request (System.LoggingRef[1..10].Cd.StartLog) changes to FALSE).
Starts by user operation	Logging can start and stop by Logging Request (System.LoggingRef[1..10].Cd.StartLog).

^{*1} When the system starts, the logging setting file exists as follows, and when the logging start condition is "Starts automatically", the logging starts.

/rom/LOGGING/LOG**/LOGGING.json (** corresponds to the logging setting No.01 to 10.)

When using the logging setting file on the SD memory card, refer to the following.

☞ Page 800 Auto logging

■Collection interval (SMPHSPDTYPE, SMPHSPDTIME)


Set the collection timing of the target data.

Data collection timing	Description
Operation cycle	Collects data in operation cycle interval. From the first operation cycles are available.
Time specification	Collects data at specified time interval ([ms]). (from 1 to 86400 [ms]) The closest cycle among cycles obtained by multiplying the first operation cycles by an integer becomes the actual collection interval. (When there are multiple options of the cycle, the longer cycle is obtained) <Example> When the first operation is 4.0 [ms] • When specifying 6.0 [ms], the actual collection interval is 8.0 [ms] (the first operation cycle × 2)

■Logging type (TFFLGTP)

Set the logging type to be executed. The continuous logging and trigger logging methods of data collection are available.

- Continuous logging
In continuous logging, the module collects specified data continuously and keeps saving the data logging file at file switching timing.




<Operating procedure for continuous logging>

1. Set the logging setting and start logging.
2. Collect data and save the file with the condition specified at "File switching timing".
3. Data collection finishes at the following cases: upon reaching the number of files to be saved specified as part of the "Stop" setting configured in "Operation when exceeds the number of files", or when Logging Request (System.LoggingRef[1..10].Cd.StartLog) changes to FALSE.

- Trigger logging

In trigger logging, the module stores specified data in its internal buffer; it extracts a specified number of data records before and after the satisfaction of a trigger condition and saves the extracted data in a data logging file. Note that data collection is performed not only at the specified collection interval or timing but also when a trigger condition is met.



<Operating procedure for trigger logging>

1. Set the logging setting and start logging.
2. Wait until the trigger condition is met. (The trigger condition status can be checked by Triggered (System.LoggingRef[1..10].Md.Triggered) and Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32]).)
3. When the trigger condition is met, collect as much data as the number of records specified in the number of records after trigger and save the collected data to the file.
4. Save Status (System.LoggingRef[1..10].Md.SaveStatus) changes to "2: Saved (Saved)" and "3: All Files Saved (FullySaved)" when the writing of the collected data to the file is completed.
5. Data collection is completed when the file is saved at the number of times set in "Number of trigger logging" or Logging Request (System.LoggingRef[1..10].Cd.StartLog) is changed to FALSE.

■Number of trigger logging (TRIGGER TIME)

Set the repeat number of trigger logging. A file is saved each time a trigger is executed once.

Number of trigger logging	Description
1 to 32767 (Number of times specification)	Executes repeatedly at the number of specified times. When exceeding the number of files that specified to the "Number of save files", the setting of "Operation when exceeding the number of files" will be ignored and "Overwrite" will be operated.
0 (Number of save files specification)	Executes repeatedly according to the "Number of save files" and the "Operation when exceeding the number of files". When the file save setting (SAVENABLE) is the "Not save", it executes repeatedly without the limit of number of times.

■Number of records (LLNBEFOR, LLNAFTER)

Set the number of records before and after trigger condition occurrence.

Item	Description	Setting range
Number of records before trigger	Sets the number of records to be output as pre-trigger record.	0 to 999999
Number of records after trigger	Sets the number of records to be logged during and after a trigger occurrence.	1 to 1000000
Number of total records	Number of total records of number of records before and after trigger. Set the number of records before trigger/the number of records after trigger not to exceed the setting range.	1 to 1000000

Point

- When setting from the engineering tool, the setting range is as follows.
 - Number of records before trigger: 0 to 299999
 - Number of records after trigger: 1 to 300000
 - Number of total records: 1 to 300000
- If there are many records, the free space of the operation folder may be insufficient. The place of the operation folder can be changed. For details, refer to the following.
 - ☞ Page 801 Precautions


■Trigger type (TRGCOMPTYPE)

Set the combination of multiple trigger conditions. One trigger type can be set for one setting.

Trigger type	Number of trigger conditions can be set	Trigger conditions can be specified
OR Combination	Up to 32	<p>■The following conditions are regarded as an AND/OR condition is satisfied when a condition is satisfied only.</p> <ul style="list-style-type: none"> • Data conditions (Comparison) • Data conditions (Value change) (Condition is satisfied only at the changed timing) • Fixed cycle (Condition is satisfied only at the fixed cycle timing) <p>■The following conditions are regarded as an AND/OR condition is satisfied after a condition is satisfied once.</p> <ul style="list-style-type: none"> • System start • At trigger command execution • Event history
AND Combination	Up to 32	


• OR Combination

When any of the set conditions is satisfied, the trigger occurs.



• AND Combination

When all the set trigger conditions are satisfied, the trigger occurs.



■File save setting (SAVENABLE)

Set the saving enabled/disabled of a data logging file. When "Disabled" is set, the collected data file is not saved and only the trigger detection is executed.

■File storage location (SAVFLDNAMEDETLFRMT)

Set a folder name of the data logging file storage location. When this setting is empty (""), the file is saved in the same folder as the logging setting file.

The file name is the date (YYYYMMDD)_time(hhmmss).extension.

The file created in the storage location is overwritten when the file with the same file name already exists. It is recommended to specify a different storage location for each file when specifying the location in this setting and executing multiple logging settings simultaneously.

■File format (TFFFILE)

"CSV (Unicode)" and "JSON" storage formats are available for data logging files. For details on the output format, format specifications, and output contents of each file, refer to the data output format.

 Page 804 Data Logging Format

File format	Description
CSV (Unicode)	This is a file format which can be opened in generic-purpose application programs such as table calculated software and GX LogViewer.
JSON	This is a file format which is appropriate for data operation on the host system. The file size will be smaller than CSV (Unicode) format. It can also be opened in GX LogViewer.

Point

- To display date and time in the 1st column by unit of 10 ns when opening CSV (Unicode) file by Excel®, import the file in text format, and specify the data format "character string" to the 1st column by text file wizard.
- A time and date data recorded in the data logging file is based on the system time (the time of control CPU module) at data collection. Therefore, the setup collection interval and display time may not match. Check the fixed periodicity (missing or not) of the data in INDEX column (reset to INDEX = 1 when missing occurs) instead of the display time.

■Number of files to be saved (SAVFNUM)

Set the maximum number of data logging files (Files of the extension specified with "File format") in the storage location folder.

The setting range of files is "0 to 65535".

When the setting value is "greater than or equal to 1", the current number of files is stored in Number of Saved Files (System.LoggingRef[1..10].Md.LogDataSavedCount). The operation when the number of files exceeds the setting value is specified by "Operation when exceeds the number of files".

When the setting value is "0", the maximum number of files is not checked. When the logging starts, Number of Saved Files (System.LoggingRef[1..10].Md.LogDataSavedCount) becomes "0", after this the saved number of files is stored.

Point

It may take time to save files if the number of maximum files is large.

■Operation when exceeding number of files (SAVFNUMTYPE)

Set the operation when the number of files in the storage location folder exceeds the setting value of Number of Saved Files (System.LoggingRef[1..10].Md.LogDataSavedCount).

Setting	Description
Overwrite	When creating the next storage file, the oldest file is deleted, and a new file is created and the logging is continued.
Stop	When trying to create the next save file, the error will occur, and the logging operation will be stopped.

■Number of file switching records (SAVSWICTMNRECNUM)

Sets the number of records to switch a file to be saved during continuous logging.

In trigger logging, since a file to be saved is switched automatically when the trigger is satisfied, this setting is ignored.

■Number of buffers (NUMBUFF)

Set the number of internal data collection buffers.


When the creation interval of the data logging files is short, and the error BUSY occurs, increase this setting value. When the setting value is "0", the number of buffers is determined automatically according to the file creation interval. For details, refer to the following.

 Page 792 Internal buffer

Trigger condition (TRIGGERCONDITION)

Sets a trigger condition. Conditions can be created up to 32 and combined by "Trigger type" setting.


■Condition type (TYPE)

Condition		Description
Data condition	Comparison	<p>Data is compared with data or constant and a trigger occurs when a condition is satisfied. (=, ≠, ≥, >, ≤, <)</p> <ul style="list-style-type: none"> • =: When the current value of monitored data is equal to the comparison value • ≠: When the current value of monitored data is not equal to the comparison value • ≥: When the current value of monitored data is greater than or equal to the comparison value • >: When the current value of monitored data is greater than the comparison value • ≤: When the current value of monitored data is less than or equal to the comparison value • <: When the current value of monitored data is less than the comparison value
	Value change	<p>A trigger occurs when a value is changed. (↑, ↓, at change)</p> <ul style="list-style-type: none"> • ↑: When the monitored data becomes FALSE to TRUE • ↓: When the monitored data becomes TRUE to FALSE • At change: When the current value of the monitored data changes
Fixed cycle		<p>A trigger occurs in the specified interval (specified cycle [ms]) after logging starts.</p> <p>However, when the specified interval in the fixed cycle and the collection timing are not matched, a trigger occurs at the first sampling after the specified fixed cycle interval is elapsed.</p> <ul style="list-style-type: none"> • The cycle that can be specified: 1 to 86400000 [ms] <p><Example></p> <p>When the fixed cycle is specified to 10 seconds</p> 
System start		<p>A trigger occurs at system start (at completion of initialization processing) automatically.</p> <p>When this condition is used, set the start condition of logging setting to "Starts automatically".</p>
Trigger command		<p>A trigger occurs when Trigger Request (System.LoggingRef[1..10].Cd.Trigger) is set to TRUE.</p>
Event history		<p>A trigger occurs when an event of the specified event history occurs.</p> <p>Set an event code to be triggered.</p> <p>Multiple event codes can be specified using "-" (hyphen) and "," (comma).</p> <p><Example></p> <p>When setting event codes from 0x80001000 to 0x80001010 as a trigger condition</p> <ul style="list-style-type: none"> • 0x80001000-0x80001010 <p><Example></p> <p>When setting all event codes as a trigger condition</p> <ul style="list-style-type: none"> • 0x00000000-0xFFFFFFFF

Event detection

When File save setting is set to "Disabled" in the logging setting, only the trigger detection is executed without saving files. The following can be applied easily by using the trigger detection function of the logging function instead of description of the satisfied judgement processing of various signal conditions (event detection processing) by a user program.

- Set the complicated error condition or program execution status to the trigger condition and utilize it for preventive maintenance.
- Monitor whether the monitor value exceeds the threshold value from the upper system and utilize it for debugging of the program.




Procedures of event detection

1. Set as follows in the logging setting and start logging.


Item	Setting details
File save setting	Disabled
Logging type	Trigger logging
Number of trigger logging	1 time
Number of trigger records before trigger	0
Number of trigger records after trigger	1

2. When the set trigger condition is detected, Trigger Request (System.LoggingRef[1..10].Md.TriggerCount) turns 1. This signal is used to control. (From the upper, used for monitoring, program execution condition, etc.)
3. To detect an event continuously, set Logging Request (System.LoggingRef[1..10].Cd.StartLog) to FALSE once after a trigger is detected and set to TRUE again.



Auto logging

When inserting an SD memory card, which holds logging setting, into the motion system, the data logging automatically starts based on the logging setting information on the SD memory card.



■How to use auto logging

The following describes how to use auto logging.

1. Set Auto Logging Enabled (System.PrConst.Logging_AutoLoggingEnable) to "1: Enabled" in advance and allow the auto logging function.
2. Write the following logging setting file. Set "/sdc/LOGGING□□.json" or "/sdc/LOGGING/LOG□□/LOGGING.json(□□ = 01 to 10)" to the writing destination. (When there are both files, the priority is the former.)
Logging start conditions is set as "Starts automatically".
3. Start the system by inserting the SD memory card prepared in step 2 into the Motion module or insert the Motion module while it is running.
4. Logging Setting Path (System.LoggingRef[1..10].Cd.SettingPath) which corresponds to the logging setting file stored in the SD memory card automatically becomes the path of the setting file, Logging Request (System.LoggingRef[1..10].Cd.StartLog) becomes TRUE and logging starts. If the logging setting of that number already operates, a new logging does not start and an error occurs. (The logging which has already started is not affected.)

Servo system recorder

The servo system recorder function automatically corrects the position command or actual position at an error occurrence, etc. of the drive unit connected to the servo system by using logging function.

The setting file of the servo system recorder function is automatically generated when using the function. For details, refer to the following.

☞ Page 825 Servo System Recorder


Precautions

The following describes precautions to take when using the logging function.

- When the AND condition is used, the condition at the motion system start is satisfied only once. Therefore, the trigger occurs at the first time only even if the trigger count is set to other than 1.
- The judgement of data condition is executed by the collected data in each set collecting interval.
When the data condition is specified to the trigger, data is not detected unless the data condition has been satisfied at collecting. Set the condition established time longer than the collecting interval.
- If the 2nd operation cycle is not set when the 2nd operation cycle is selected for the collection interval, the status will be logging error and the data collection will not be executed.
- The write for System.LoggingRef[1..10].Cd.** must not be carried out during the logging operation by the engineering tool.
(** supports variables included in System.LoggingRef[1..10].Cd)
- After the trigger condition is satisfied, if a new trigger occurs during sampling of records after trigger, a new trigger is ignored. When the sampling of records after trigger is completed and the file is started to be saved, a new trigger is allowed to be received.

The example of operation is shown below.

1. Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32]) becomes TRUE when the trigger condition is satisfied. (File 1)
2. When the trigger condition is satisfied, sampling records after trigger is executed.
3. The trigger condition occurred during sampling of records after trigger is ignored.
4. When the file save is executed, Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32]) becomes FALSE. (Preparation for the next logging operation)
5. Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32]) becomes TRUE when the trigger condition is satisfied. (File 2)




- Saving files can be carried out continuously up to the number specified in the number of buffers (NUMBUFF). If it takes time to save the file when the file size is large and a trigger is established during the time, the trigger is ignored. The example of operation is shown below.

Ex.

When "Number of buffers (NUMBUFF) = 2".

1. Trigger Status (System.LoggingRef[1..10].Md.TriggerStatus[1..32]) becomes TRUE when the trigger condition is satisfied.
2. When the trigger condition is satisfied, sampling records after trigger is executed.
3. The logging whose file size is large is continued 2 times and it takes time to save files.
4. The 3rd trigger established is ignored.



- In logging, the folder which the environmental variable %TEMP% indicates is used as the operation folder. (/ram/temp by default) If the drive free space is insufficient due to many records, etc., consider changing the place of the operation folder. For details, refer to the following.

Page 863 FILE CONTROL

- If the file is saved after the data collection, "Logging Error" (error code: 4008H) occurs and stops the logging. By taking following the corrective actions, the error may be avoided or the frequency may be reduced.
 - Specify the file storage location of the data logging file to the SD memory card.
 - Set file format to JSON.
 - Reduce the number of files in the file storage location of the data logging file.
 - Set a longer data collection interval.
 - Increase the number of buffer. Also, increase the assignment of the system memory (RAM) of the Add-on Logging if necessary.
 - Increase the operation time of the motion service processing by executing such as setting longer operation cycle and decreasing the loading of the program execution. (The file saving is processed by the motion service processing.)

Error

No diagnostic error occurs if an error occurs during logging, and the error event is not recorded in the error history. To check the error status, refer to System.LoggingRef[1..10].Md.ErrStatus.

For the list of logging error codes, refer to the following.

Page 978 List of Logging Error Codes

Relevant add-ons

The following add-on is required to use this function.

- Logging
- SignalIO
- MotionEventHist^{*1}

^{*1} For using "Event history" as the trigger conditions

System memory capacity

■RAM Usage

Refer to the following.


☞ Page 792 Internal buffer

■Backup RAM Usage

Backup RAM is not used.

Folder configuration

The default folder configuration of logging is shown below.



Folder	■Data logging Route of drive/LOGGING/LOG**/ (The ** corresponds to No.1 to 10 of logging setting) ■Real-time monitor Route of drive/LOGGING/LOG_REAL/
Logging setting file	LOGGING.json
Data logging file	[SAVFLDNAMEDETLFRMT]/[YYYYMMDD]_[hhmmss].[TFFFILE]

17.2 Data Logging Format

This section describes file format of the data logging.

CSV file data specifications

File information row

Column No.	Column name	Description
1st column	File type	Fixed character "[LOGGING]"
2nd column	Type information_file version	Output file version "RD78G(H)_1" (Initial version)
3rd column	Data type information row number	Number which indicates data type information row: a
4th column	Data name row number	Number which indicates data name row: a + 1
5th column	Data start row number	Number for data starting row: a + 2
6th column	Device comment row number	Number indicates device comment row: a + 3 When the device comment does not exist, it can be omitted.

Setting data information row

The description of the setting file (json) is output. For data details, refer to the followings.

☞ Page 793 Logging setting

☞ Page 806 JSON file data specifications

Data type information row

Data type information row is output in the format of "(Data type)[additional information]".

Column No.	Column name	Description
1st column	Date and time column	Indicates data type of date and time. Fixed character "DATETIME[YYYY/MM/DD hh:mm:ss.ssssssss]" ^{*1}
2nd column	Index column	Fixed character "INDEX" which indicates index column Index does not have additional information. [] is not output.
3rd column and later	Data column	Indicates data type of the sampled data.
Last column	Trigger generation information column	The following character string is output regardless of continuous logging/ trigger logging. "TRIGGER[trigger ON string]" ^{*2} The character string with double quotation "" is fixed character.

*1 Regarding .ssssssss at the end, three digits for information of [ms], three digits for information of [μs], and two digits for information of [ns] are output.

*2 "" is output for trigger ON string.

Details of data column are shown below.

Data type of data	Output character for the data type	Description
Bit	BIT	Outputs in the format of "BIT[1;0]".
Word [unsigned]	USHORT	Outputs in the format of "USHORT[DEC.0]". ^{*1}
Double word [unsigned]	ULONG	Outputs in the format of "ULONG[DEC.0]". ^{*1}
Word [signed]	SHORT	Outputs in the format of "SHORT[DEC.0]". ^{*1}
Double word [signed]	LONG	Outputs in the format of "LONG[DEC.0]". ^{*1}
Single-precision real number	FLOAT	Outputs in the format of "FLOAT[DEC.7]". ^{*1*2}
Double-precision real number	DOUBLE	Outputs in the format of "DOUBLE[DEC.14]". ^{*1*2}

*1 [DEC.(Number)] shows the numerical value format and the maximum number of fractional part digit.
<Example> For [DEC.7]

The fractional part digit is seven with decimal notation.

*2 The number of digits after the decimal point is not always same as the specified one.

<Example> For 1.2345

'1.2345000' is not output.

Data name row

Data name row indicates the title character string of each column.

Column No.	Column name	Description
1st column	Date and time column	Indicates title of date and time. Fixed character "TIME[time zone]"
2nd column	Index column	Indicates title of index column. Fixed character "INDEX"
3rd column and later	Data column	Indicates title of data column. <u>Device label</u> (Example: FeedAxis.AxisMntr.Feedcurrent)
Last column	Trigger generation information column	Indicates title of trigger generation information column. Fixed character "Trigger"

Device comment row

The following description is output in the device comment row.

Column No.	Column name	Description
1st column	Date and time column	Blank
2nd column	Index column	Blank
3rd column and later	Data column	Outputs device comment.
Last column	Trigger generation information column	Blank

Data row

Data of each data name is output in the data row.

Column No.	Column name	Description
1st column	Date and time column	Indicates data of date and time. Output in the format of "YYYY/MM/DD hh:mm:ss:sssssss" with the fixed format.
2nd column	Index column	Indicates data of index. The numerical values starting from 1 and increased in ascending order are output. When the value exceeds the upper limit value 4294967295, it returns to 0, and the value increases within the range of 0 to 4294967295 again. The values are taken over from file to file when performing continuous logging. (When missing, reassigns it from one.)
3rd column and later	Data column	Indicates value of data name. Value according to the data type of data type information row.
Last column	Trigger generation information column	Indicates data of trigger generation information. Character string at occurrence is output in trigger row.

JSON file data specifications

Common items (LOGGING)

Item name		Data type	Description
Data logging name	NAME	string	Arbitrary character string *: Being treated as the setting file for the servo system recorder when it is ServoSystemRecorder or ServoSystemRecorder_*** (Arbitrary character string). For details, refer to the following.  Page 825 Servo System Recorder
Logging type* ¹	TFFLGTP	string	CONT: Continuous logging TRIGGER: Trigger logging
Number of file switching records* ¹	SAVSWICTMNRECNUM	number	100 to 100000
Storage location path* ¹	SAVFLDNAMEDETLFRMT	string	Path name. *: Blank is available. (Regarded as the same folder of the setting file.)
File format* ¹	TFFFILE	string	CSV_UTF-16LE: CSV(Unicode)* ² CSV_UTF-16LE_ZIP: ZIP compression CSV(Unicode)* ² JSON: JSON* ² JSON_ZIP: ZIP compression JSON* ²
Collecting interval	SMPHSPDTYPE	string	EACHSCAN: Operation cycle TIME: Time specification
Time specification	SMPHSPDTYPE	number	■When SMPHSPDTYPE = EACHSCAN 1 to 3: The nth operation cycle ■When SMPHSPDTYPE = TIME 31250 to 86400000000 [ns] *: Set a unit of ms (floating point) on display
Trigger type (complex condition)	TRGCOMPTYPE	string	OR AND
Number of trigger records before trigger* ¹	LLNBEFOR	number	0 to 999999
Number of trigger records after trigger* ¹	LLNAFTER	number	1 to 1000000
Total number of rows* ¹	LLNTOTAL	number	LLNBEFOR + LLNTOTAL
Number of save files* ¹	SAVFNUM	number	0: No upper limits 1 to 65535: Maximum number of files
Operation when exceeds the number of files* ¹	SAVFNUMTYPE	string	OVERWRITE: Overwrite STOP: Stop
Start condition* ²	STARTCONDITION	string	AUTO: Starts automatically CONTINUE: Starts automatically (Stop disabled) MANUAL: Starts by user operation
File save* ²	SAVENABLE	boolean	Saving enabled/disabled of a data logging file FALSE: Not save TRUE: Automatically decelerating
Number of trigger logging* ²	TRIGGERTIME	number	0: Number of save files specification 1 to 32767: Number of times specification
Number of buffer	NUMBUFF	number	0: Automatic setting 2 to 10: Specified number of buffer

*¹ When SAVENABLE = FALSE, setting is not required.

*² It is a unique setting item for the Motion module (Logger Module does not have this setting).

Trigger condition (TRIGGERCONDITION)

Item name		Data type	Description
No.	NO	number	1 to 32 (Serial number is not required)
Condition type	TYPE	string	DATACOMP: Data condition (Comparison) DATACHANGE: (Value change) CYCLE: Fixed cycle STARTMODULE: At module start EVENTHISTORY: Event history ^{*1} LOGTRG: At trigger command execution ^{*1}
Data name	DATA1	number	1 to 1024
Condition	DATAOPE	string	EQUAL: = NOTEQUAL: ≠ GREATERTHANEQUAL: ≥ GREATERTHAN: > LESSTHANEQUAL: ≤ LESSTHAN: < RISINGEDGE: ↑ ^{*1} FALLINGEDGE: ↓ ^{*1}
Data/constant	DATA2TYPE	string	DATA CONST
Data name (data name/ constant value)	DATA2	number	1 to 1024
Constant value (data name/ constant value)	DATA2CONST	string	Constant value Set 0/1 for bit data
Fixed-cycle	CYCL	number	1000000 to 8640000000000 [ns] *: Set an unit of ms (floating point) on display
Event code ^{*1}	EVENTCODE	string	Event code (0XXXXXXXX type, Settable in the range)

^{*1} It is a unique setting item for the Motion module (Logger Module does not have this setting).

Data (DATA)

Item name		Data type	Description
No.	NO	number	1 to 1024 (Serial number is not required)
Name	NAME	string	Label/device character string
Data name	DATA1	number	1 to 1024
Data type	TYPE	string	Available only at device specification. (Ignores at label specification) <ul style="list-style-type: none"> • BIT: Bit (BIT) • UWORD: Word [unsigned]/Bit column (16 bits) • UDWORD: Double word [unsigned]/Bit column (32 bits) • SWORD: Word [signed] • SDWORD: Double word [signed] • FLOAT: Single-precision real number • DFLOAT: Double-precision real number • SQWORD: Long word [signed]^{*1} • UQWORD: Long word [unsigned]^{*1}
Input method	INPUTMETHOD ^{*1}	number	<For data name restoration by logging setting tool> <ul style="list-style-type: none"> • 0: Directly input (No restoration) • 1: Input from label input assistant display (Restores label name) • No specification/value other than above: Directly input
Axis type	AXISTYPE ^{*1}	string	<For data name restoration by logging setting tool> <ul style="list-style-type: none"> ■ Available only at input method "1" • "SYSTEM": System • "AXIS_REAL": Real drive axis • "AXIS_ENCODER": Real encoder axis • "AXIS_VIRTUAL": Virtual drive axis • "AXIS_VIRTUAL_ENCODER": Virtual encoder axis • "AXIS_VIRTUAL_LINK": Virtual linked axis • "AXES_GROUP": Axes group • No specification/value other than above: Regard as directly input data
Motion unit	MOTIONUNIT ^{*1}	string	Specifies the unit information of the motion control data. Outputs the unit information to the logging data file based on this setting value. (Valid only when the label and the instance of the axis, etc. are specified. Other than this, it is ignored.) <ul style="list-style-type: none"> • POSITION: Position • VELOCITY: Velocity • ACCELERATION: Acceleration • JERK: Jerk • TORQUE: Torque

^{*1} It is a unique setting item for the Motion module (Logger Module does not have this setting).

17.3 Logging Data (JSON format)

This section shows the JSON file of the logging result which is compatible with GX LogViewer.

Basic specifications


The following JSON files are supported.

- Unicode (UTF-8 with BOM.)
- With or without line break

Whole configuration

The logging setting file configuration is shown below. (The following figure is an image.)

[No group]



The number of data and limitation

GX LogViewer has a limitation to the number of data points and records it can read.

■No group

- Only 1 Waveform data (Record)

Item	The maximum number
Number of data points (Data column information (DataInfo) type is DATA)	1024 points (BIT and WORD mixed)
Number of data	1000000 records

However, GX LogViewer cannot read 1024 data points × 1000000 records because much capacity is required. If more than 300M bytes file is read, the error occurs.

Data specification

Common items

Item name	Omission	Key name	Data type	Description
File type	Not possible	FileType	Character string	LOGGING fixed (To make the tool determine the logging data)
File version	Not possible	Ver	Character string	Major version, minor version ^{*1} 1.00 ^{*2} ^{*3}
File author ^{*1}	Not possible	Creator	Character string	For the Motion module (RD78): RD78G(H) , (a comma) is not allowed.
File comment	Possible	Comment	Character string	Arbitrary character string
Record	Not possible	Record	 Page 810 Waveform data (Record)	Waveform data
Status bar color	Possible	StatusBarColor	Color object	0x 112233 11 : Red, 22 : Green, 33 : Blue Hexadecimal color codes expressed as above

*1 Read is not allowed when the major version of GX LogViewer is other than 1. When its minor version is inconsistent, it reads within the supported range.

*2 This version remains the same even if the device dependent information is changed.

*3 GX LogViewer can read triple-digit minor version.

Waveform data (Record)

Item name	Omission	Key name	Data type	Description
Waveform data name	Not possible	Name	Character string	Arbitrary character string
Waveform data comment	Possible	Comment	Character string	Arbitrary character string (Comment as 1 record)
Device dependent information	Possible	Arbitrary key	 Page 812 Device dependent information	Refer to the manual of each device.
Data column information	Not possible	DataInfo	 Page 811 Data column information (DataInfo)	Array of data column information
Data	Not possible	Data	 Page 812 Data (Data)	Array of waveform data
Device information	Possible	UnitName	Character string	Outputs when the actual logged device is different with the one outputted on Creator. (If this item does not exists, the device is regarded as the one which is actually logged by Creator.)

Data column information (DataInfo)

■Common

Item name	Omission	Key name	Data type	Description
Type	Not possible	Type	Character string	TIME: Time information TRIGGER: Triggered flag information DATA: Sampling data INDEX: Index information
Order	Arbitrary	Order	Value (starts from 1)	Corresponding column number in the Data part

■When the type is time information

Item name	Omission	Key name	Data type	Description
Time information type	Not possible	TimeType	Character string	ABS_TIME: Absolute value

- TimeType is ABS_TIME

Item name	Omission	Key name	Data type	Description
Time format	Not possible	DateFormat	Character string	Only when TimeType is absolute value <Example> YYYY/MM/DD hh:mm:ss.s

■When the type is triggered flag information

Item name	Omission	Key name	Data type	Description
Trigger signal	Not possible	Mark	Character	<Example> ***

■When the type is index information (Used for determination of missing data)

Item name	Omission	Key name	Data type	Description
—	—	—	—	—

■When the type is sampling data

Item name	Omission	Key name	Data type	Description
Data name	Not possible	DataName	Character string	—
Comment	Possible	DataComment	Character string	—
Data type	Not possible	DataType	Character string	(Corresponding with the type of EdgeCross) BOOL[1;0] ■Integer type in decimal format INT[DEC.0] UINT[DEC.0] DINT[DEC.0] UDINT[DEC.0] LINT[DEC.0] ^{*1} ■Integer type in hexadecimal format UINT[HEX] UDINT[HEX] ULINT[HEX] ^{*1} REAL[DEC.(number of digits after the decimal point)] LREAL[DEC.(number of digits after the decimal point)] REAL[EXP.(number of digits after the decimal point)] LREAL[EXP.(number of digits after the decimal point)] STRING[(data length)] ^{*1} WSTRING[(data length)] ^{*1}
Unit	Possible	Unit	Character string	Depends on items
Display color	Possible	LineColor	Value	RGB value

*1 This data format cannot be read by GX LogViewer.

Data (Data)

Array of value column according to Data column information (DataInfo)

■The type of Data column information (DataInfo) is "DATA"

The range for each data type is as follows.

Data type	Display of data type information row	Value range
BOOL type	BOOL[1;0]	1(ON), 0(OFF)
Integer type in decimal format	INT[DEC.0]	-32768 to 32767
	UINT[DEC.0]	0 to 65535
	DINT[DEC.0]	-2147483648 to 2147483647
	UDINT[DEC.0]	0 to 4294967295
	LINT[DEC.0]	-9,223,372,036,847,775,808 to 9,223,372,036,854,775,807
Integer type in hexadecimal format	UINT[HEX]	0 to FFFF
	UDINT[HEX]	0 to FFFFFFFF
	ULINT[HEX]	0 to FFFFFFFFFFFFFFFF
Real number	REAL[DEC.(number of digits after the decimal point)]	-3.40282346E+38 to -1.40129846E-45, 0, 1.40129846E-45 to 3.40282346E+38 "NaN" (outputs in string type), "Inf" (outputs in string type), "-Inf" (outputs in string type)
	REAL[EXP.(number of digits after the decimal point)]	
	LREAL[DEC.(number of digits after the decimal point)]	-1.7976931348923158E+308 to -4.9406564584124654E-324, 0, 4.9406564584124654E-324 to 1.7976931348923158E+308 "NaN" (outputs in string type), "Inf" (outputs in string type), "-Inf" (outputs in string type)
	LREAL[EXP.(number of digits after the decimal point)]	
Character string	STRING	—
	WSTRING	—

■The type of Data column information (DataInfo) is "INDEX"

The numerical values counted up from 1 in ascending order are output.

When the count exceeds 4294967295 which is the upper limit, it returns to 0 and starts a new count within the range from 0 to 4294967295.

If missing occurs in correcting data, index will be reassigned from 1 again.

When this value is continuing in 2 files, the graphs are drawn without missing at the joint when performing "Show Next/Previous Graph" (combining graphs).

Device dependent information


For the motion system, the key name is MotionSettingInfo.

18 RAS FUNCTIONS

18.1 Execution Time Monitor

18

This function is used to monitor the operation cycle processing and the normal task execution time.



Operation of this function for each system status

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
OperationCycle[1]	Operation Cycle Setting	Sets each setting value of first operation cycle. Operation Cycle Setting (OperationCycle[1]) is a CYCLE_PARAM structure.
BuffermemoryRefreshCycle	Buffer Memory Refresh Cycle Setting	Sets each setting value of buffer memory refresh cycle. Buffer Memory Refresh Cycle Setting (BuffermemoryRefreshCycle) is a CYCLE_PARAM structure.

System monitor data (System.Md.)

Variable/Structure name	Name	Details
SystemBaseCycle	System Basic Cycle Monitor	Stores the monitor value of system basic cycle. System Basic Cycle Monitor (SystemBaseCycle) is a CYCLE_MONI structure.
OperationCycle[1]	Operation Cycle Monitor	Stores the monitor value of first operation cycle. Operation Cycle Monitor (OperationCycle[1]) is a CYCLE_MONI structure.
BuffermemoryRefreshCycle	Buffer Memory Refresh Cycle Monitor	Stores each monitor value of buffer memory refresh cycle. Buffer Memory Refresh Cycle Monitor (BuffermemoryRefreshCycle) is a CYCLE_MONI structure.
Program_NormalTaskCycle	Normal Task Processing Time Monitor	Stores the monitor value of normal task. Normal Task Processing Time Monitor (Program_NormalTaskCycle) is a CYCLE_MONI structure. The output specific to Normal Task Processing Time Monitor (Program_NormalTaskCycle) is shown below. ■Cycle Setting (Cycle) "0" is always stored because the cycle setting is not existed. ■Cycle Over (CycleOver) FALSE is always set because the cycle over detection is not executed.
WDTerror	WDT Error	Becomes TRUE when WDT error is detected. • FALSE: No WDT error • TRUE: WDT error present
SystemBaseCycle_Counter	System Basic Cycle Counter	Stores the system basic cycle counter.

CYCLE_PARAM

Variable/Structure name	Name	Details
Cycle	Cycle Setting	For details, refer to the following. ☞ Page 107 Operation Cycle
NumOfCycleOverWngDetectTimes	Number of Cycle Over Warning Detections	The number of cycles until the cycle over warning of each cycle is detected can be set. Warning is not detected when 0 is set. • 0 to 65535
NumOfCycleOverErrDetectTimes	Number of Cycle Over Error Detections	The number of cycles until the cycle over error of each cycle is detected can be set. When "0" is set, it will operate as "5 (initial value)". • 0 to 65535
CycleOverErrorType	Cycle Over Error Selection	An assignment for the over error of each cycle can be selected. • 2: Minor Error (MinorError) • 3: Moderate Error (ModerateError)

CYCLE_MONI

Variable/Structure name	Name	Details
ProcessingTime	Processing Time	Stores the processing time [ns] of each cycle.
MaximumProcessingTime	Maximum Processing Time	Stores the maximum processing time [ns] of each cycle.
Cycle	Setting Cycle	Stores the cycle setting [ns] of each cycle.
CycleOver	Cycle Over	Becomes TRUE when the cycle over of each cycle is detected.

Control details

System basic cycle

For details on system basic cycle, refer to the following.

☞ Page 107 Operation Cycle

■System basic cycle setting

Stores the system basic cycle setting in Cycle Setting (System.Md.SystemBaseCycle.Cycle) with a unit of nanosecond [ns].

■System basic cycle processing time

Stores the system basic cycle processing time in Processing Time (System.Md.SystemBaseCycle.ProcessingTime) with a unit of nanosecond [ns].

■Maximum processing time of system basic cycle

Stores the maximum value of system basic cycle processing time in Maximum Processing Time (System.Md.SystemBaseCycle.MaximumProcessingTime) with a unit of nanosecond [ns].

■System basic cycle over

For details, refer to the following.

☞ Page 817 System basic cycle over check

Normal task


■Normal task processing time

Stores the normal task processing time in Processing Time (System.Md.Program_NormalTaskCycle.ProcessingTime) with a unit of nanosecond [ns]. It includes the task processing time whose priority is higher than the normal task.

[Normal execution type program processing]

For details on the processing, refer to "Execution of programs" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)



■Maximum processing time of normal task

Stores the maximum value of the normal task processing time in Maximum Processing Time (System.Md.Program_NormalTaskCycle.MaximumProcessingTime) with a unit of nanosecond [ns].

First operation cycle

For details, refer to the following.

📖 Page 107 Operation Cycle


■First operation cycle setting

Stores the first operation cycle setting in Setting Cycle (System.Md.OperationCycle[1].Cycle) with a unit of nanosecond [ns].

■First operation cycle processing time

Stores the first operation cycle processing time in Processing Time (System.Md.OperationCycle[1].ProcessingTime) with a unit of nanosecond [ns].

It includes the task processing time whose priority is higher than the first operation cycle.



■Maximum processing time of first operation cycle

Stores the maximum value of the first operation cycle processing time in Maximum Processing Time (System.Md.OperationCycle[1].MaximumProcessingTime).

■First operation cycle over

For details, refer to the following.

📖 Page 817 Operation cycle over check

Buffer memory refresh

For details, refer to the following.

📖 Page 107 Operation Cycle

■Buffer memory refresh cycle setting

Stores the buffer memory refresh cycle setting in Setting Cycle (System.Md.BufferMemoryRefreshCycle.Cycle) with a unit of nanosecond [ns].

■Buffer memory refresh cycle processing time

Stores the buffer memory refresh cycle processing time in Processing Time (System.Md.BufferMemoryRefreshCycle.ProcessingTime) with a unit of nanosecond [ns]. It includes the task processing time whose priority is higher than the buffer memory refresh cycle.

■Maximum processing time of buffer memory refresh cycle

Stores the maximum value of the buffer memory refresh cycle processing time in Maximum Processing Time (System.Md.BufferMemoryRefreshCycle.MaximumProcessingTime) with a unit of nanosecond [ns].

■Buffer memory refresh cycle over

For details, refer to the following.

📖 Page 818 Buffer memory refresh cycle over check

Processing time over check

System basic cycle over check


When the system basic cycle processing is not completed before the start of the next system basic cycle processing, the system basic cycle over flag becomes TRUE.

When the system basic cycle over is detected, the number of the fixed-cycle program should be reviewed.

If the system basic cycle exceeds the set cycle at the start of the first operation cycle, a new operation cycle is not executed in this cycle and it is executed in the start timing of the next cycle.

To set the system basic cycle over flag to FALSE, operate one of the followings.

- Power OFF → ON and reset
- Reset by user program




Operation cycle over check

When the first operation cycle has exceeded the set cycle, the first operation cycle over flag becomes TRUE. When the operation cycle over is detected, the number of the fixed-cycle program or the operation cycle setting should be reviewed, or set the greater value for the cycle over detection number or the operation cycle setting.

To set the operation cycle over flag to FALSE, operate the following.

- Power OFF → ON and reset



When the operation cycle over flag is detected, correct the positioning content or increase the operation cycle.

Buffer memory refresh cycle over check


When the buffer memory refresh cycle is not completed before the start of the next cycle, the buffer memory refresh cycle over flag becomes TRUE.

When the buffer memory refresh cycle over is detected, correct the buffer memory refresh number or increase the buffer memory refresh cycle setting or the cycle over error detection number.

Unless one or more of the processing of system basic cycle, first operation cycle, second operation cycle or buffer memory refresh is completed, the processing of buffer memory refresh cycle is skipped in the cycle.

To let the buffer memory refresh cycle over flag be FALSE, perform the following operation.

- Power OFF → ON and reset



Output of errors

WDT error detection

When the processing is stopped because the operation cycle or other processing is error, a WDT error occurs 1 [s] later.

When the WDT error is detected, the motion system stops following the process selected by Stop Selection at All Axes Stop Cause Occurrence (System.Pr.StopMode_All), and a moderate error occurs.

Cycle over warning and error detection

When the number of cycle over of each cycle reaches the set cycle over warning/error detection number, the cycle over warning/the error occur.

When the same values are set to cycle over warning detection number and cycle over error detection number, a warning does not occur. When "0" is set to the detection number of the cycle over warning, a warning does not occur.

When "0" is set to the detection number of the cycle over error, it will operate as "5 (initial value)".

The assignment of over error of each cycle can be selected.

When a minor error is selected, the deceleration stop is executed. When a moderate error is selected, the motion system stops following the process selected by Stop Selection at All Axes Stop Cause Occurrence (System.Pr.StopMode_All).


CAUTION

- When the deceleration stop cannot be executed because of such as system unstable or hang-ups, a moderate error occurs by WDT error detection. When a minor error is selected, the operation may keep until the WDT error detection. Ensure safety by a user.
- Depending on the system status, the axis cannot decelerate to stop at WDT error detection and may stop immediately.

18.2 History Data

- History data contains "Event history" and "Positioning data history".
- Positioning data history is used to save such as positioning data of each axis as history at event occurrence related to the absolute position control.
- Event history is used to save the error information and the operation for the module as an event in the CPU module and the motion system. In each event, the records of the CPU module and motion system can be set. The store destination of event records can be set according to event frequency or priority.

Figure related to history data



Operation of this function for each system status

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

Event history filter setting

■System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
EventHistoryMotion_Exclude	Event Excluding Motion Event History	Sets an event code which does not register an event to the motion system.
EventHistoryMotion_Path	Motion Event History Path	Sets the store destination of event history file.
EventHistoryMotion_Capacity	Motion Event History Capacity	Sets the size of event history file. <ul style="list-style-type: none">• 1 to 2048 [k bytes]
EventHistoryCpu_Exclude	Event Excluding CPU Event History	Sets an event code which does not register an event to the CPU module.

■System monitor data (System.Md.)

Variable/Structure name	Name	Details
EventHistoryMotion_Path	Motion Event History Path	Stores the store destination (absolute path) of event history file.
EventHistoryMotion_ClearStatus	Motion Event History Clear Execution Status	Displays the execution status of the event history clear. <ul style="list-style-type: none">• 0: Waiting for Execution Request (Ready)• 1: Executing (Executing)• 2: Execution Completed (Done)• -1: Error Occurrence (Error_)

■System control data (System.Cd.)

Variable/Structure name	Name	Details
EventHistoryMotion_Clear	Motion Event History Clear Execution Request	Carries out execution requests of the event history clear. <ul style="list-style-type: none">• FALSE: Not executed• TRUE: Executes the clear

Positioning data history monitor

There is no positioning data history monitor.

Event history function

- This function is used to save the data such as the error detected by the motion system, the operation executed to the module, the event related to the motion control of start and stop as event history.
- The occurrence history of the information such as the saved operation and error can be checked in chronological order.
- The data is saved as event history, so that the history can be checked even if the module turns OFF or resets.
- Using this function enables exploration of failure cause occurred in equipment and device, check of the control data update status of CPU module, and detection of illegal access.
- The event history is always collected regardless of the operation status of Motion module. However, it may not be collected in the cases such as major error of the module, base module error, or cable error.
- The event which occurred in the Motion module and is not set to be filtered is registered in the event history of the control CPU module. For event history of a CPU module, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

Event occurred in the motion system

The items saved in the event history are shown below.

For details on the event, refer to the following.

 Page 979 List of Event Codes

Event type	Category	Details	Event item	Event code
System	Error	Not applicable	Not applicable	—
	Warning	Not applicable	Not applicable	—
	Information	An event on the right is detected in the Motion module.	 Page 979 System	00000H to 007FFH
Security	Error	Not applicable	Not applicable	—
	Warning	Not applicable	Not applicable	—
	Information	An event on the right related to the security is detected in the Motion module.	 Page 980 Security	10000H to 17FFFH
Operation	Error	Not applicable	Not applicable	—
	Warning	Not applicable	Not applicable	—
	Information	Operation by the user on the right is detected in the motion system.	 Page 980 Operation	20000H to 27FFFH

■ Motion control FB execution and stop event

- The Motion control FB execution event can be monitored.
- Restart and multiple start by buffer mode also can be monitored as an event.
- Monitoring the execution event enables check such as whether each operation has started in intended order at the system startup, etc.
- The stop event when the axis stops caused by stop factor input can be monitored.
- Monitoring the stop event enables check of the stop factor caused when the unintended stop has been executed, etc.

Event history file of the Motion module side

- Event history data of the Motion module side is saved into the drive in the motion system as a file.
- Event history is saved to EVENT.LOG in the storage destination specified by Motion Event History Path (System.PrConst.EventHistoryMotion_Path). The file capacity is specified in Motion Event History Capacity (System.PrConst.EventHistoryMotion_Capacity) in k bytes.
When Motion Event History Path (System.PrConst.EventHistoryMotion_Path) is blank, the event history is saved to the latch drive.
- When the storage destination is the latch drive, the setting of the system memory (backup RAM) size and Motion Event History Capacity (System.PrConst.EventHistoryMotion_Capacity) whichever is smaller amount is the event history file size. To change the file capacity, confirm and change the system memory (backup RAM) size as well. To increase the file capacity, it is recommended to specify the storage destination to an SD memory card. For details on the system memory (backup RAM) size, refer to the following.
 Page 123 System Memory Settings
- If Motion Event History Path (System.PrConst.EventHistoryMotion_Path) and Motion Event History Capacity (System.PrConst.EventHistoryMotion_Capacity) are changed, the event registered before the change cannot refer.
- When saving the event history file fails, "Event History File Incorrect" (error code: 1C85H) occurs and the event history file update stops.
- When events frequently occur, the event history storage area in the motion system might be full of event information which has not been collected. If a new event occurs in this state, the motion system discards the event information and outputs the message "**HST.LOSS**" (The event information has been erased.) which indicates the event information has been erased.
- Event history file is updated periodically. When the power of the motion system is turned OFF or the system is reset before saving the event information to the event history file, the unsaved event information is erased.

■Display of the event history

The event history of the Motion module side can be displayed on the motion control setting function of GX Works3. For the details about the operating procedures and how to interpret the displayed information etc., refer to the following.

 GX Works3 Operating Manual

■Clearing the event history

The following methods are available for clearing the event history.

Event history clearing method	Description
Clearing by the engineering tool	The event history can be cleared by the motion control setting function of GX Works3. For the details about the operating procedures, etc., refer to the following.  GX Works3 Operating Manual
Clearing by the event history clear request	<ul style="list-style-type: none">• The event history clear is the function to clear the event history by setting Motion Event History Clear Execution Request (System.Cd.EventHistoryMotion_Clear) to TRUE.• Motion Event History Clear Execution Status (System.Md.EventHistoryMotion_ClearStatus) turns "1: Executing (Executing)" during the event history clear execution.• Motion Event History Clear Execution Status (System.Md.EventHistoryMotion_ClearStatus) turns "2: Execution Completed (Done)" as the event history clear is completed. When executing the event history clear again, set Motion Event History Clear Execution Request (System.Cd.EventHistoryMotion_Clear) to FALSE and execute the clearing after confirming that Motion Event History Clear Execution Request (System.Cd.EventHistoryMotion_Clear) turns "0: Waiting for Execution Request (Ready)".• When the event history clear is failed, Motion Event History Clear Execution Status (System.Md.EventHistoryMotion_ClearStatus) turns "-1: Error Occurrence (Error_)". When turning to "-1: Error Occurrence (Error_)", Motion Event History Clear Execution Request (System.Cd.EventHistoryMotion_Clear) set to FALSE temporarily and after a while, carry out the event history clear again after confirming that Motion Event History Clear Execution Status (System.Md.EventHistoryMotion_ClearStatus) turns "0: Waiting for Execution Request (Ready)".

The event history file of the CPU module side

The event history data of the CPU module side is saved into the drive of the CPU module as a file.

For the details about the event history of the CPU module, refer to the manual of the CPU module.

■Display of the event history

The event history of the CPU module side can be displayed on GX Works3. For the details about the operating procedures and how to interpret the displayed information, etc., refer to the following.

 GX Works3 Operating Manual

■Clearing the event history

The event history can be cleared by GX Works3. For the details about the operating procedures, etc., refer to the following.

 GX Works3 Operating Manual

Filter setting

- The filter setting enables to specify whether the event detected in the motion system is registered in event history. For example, when an error is registered to the filter setting, the error processing is executed at the error detection. However, the error event is not registered in the event history.

■Filter type

The following two settings are available for filter setting.

Setting	Details
Event registration in the motion system	Specifies the event code not to be registered in the event history of the motion system at the event detection.
Event registration in the CPU module	Specifies the event code not to be registered in the event history of the CPU module at the event detection.

■Filter setting and event history registration

The following shows the registration result of event history of each module by the filter settings of event registration of the motion system and the CPU module.

Filter setting	Event history
Excluded	Not registered
Other than the above	Registered

■Default value of filter setting

Setting	Filter setting
Event registration in the motion system	None
Event registration in the CPU module	0x700-0x7ff

■Filter setting method

- The filter setting can be set by the following.
 - Event Excluding Motion Event History (System.PrConst.EventHistoryMotion_Exclude)
 - Event Excluding CPU Event History
- The filter can be set for each event code. The range can be specified by tying event codes using "-" (hyphen). A setting example is shown below.

Setting example	Setting value
For the setting when the event codes 0x80001000 and 0x80001010 are not to be registered in event history	0x80001000,0x80001010
For the setting when the event codes from 0x80001000 to 0x80001010 are not to be registered in event history	0x80001000-0x80001010
For the setting when all event codes are not to be registered in event history	0x00000000-0xFFFFFFFF

- The filter setting is enabled at the power OFF of the motion system, reset, or PLC READY ON, after writing in the motion system.

Positioning data history

- The positioning data history of each axis can be monitored by the engineering tool.
- The related positioning data is stored in the history when the following operations are executed.
 - At homing completion: 1 time
 - At axis connection/axis disconnection: 20 times
- For the positioning data at the axis disconnection, the data at the final backup is set. When the backup data does not exist or the backup data is an error, 0 is set for all.
- The positioning data history is stored in PosHist.bin of the root path (%PROJECT_ROOT%).
- The file size of the positioning data history can be calculated with the following formula.
The positioning data file size (byte) = 110 + (the number of the setting axis × 2126)
- The positioning data history file is updated periodically. When the power of the motion system is turned OFF or the system is reset before saving positioning data to the positioning data history file, the unsaved positioning data is erased.

Precautions

- The history data in the Motion module can record and monitor the event occurrence time in a unit of ns. However, the event history saved in the CPU module is in a unit of ms (round down 1 [ms] or less).
- The occurrence order and saved order of events may not match in the event recorded in the event history. When the event history is displayed in the engineering tool, the history can be checked in the event occurrence order by sorting the occurrence time.
- The event which occurs frequently may short the memory life of the event history saving destination. It is recommended that unnecessary events are filtered.
- When the axis setting is not existed at the power ON, the positioning data history data of nonexistent axis is deleted.
- To clear the positioning data history, delete the positioning data history file by file transfer function and turn the power OFF to ON or reset the module.
- When the drive memory of root path (%PROJECT_ROOT%) lacks its capacity, "Position Data History Update Disabled Warning" (warning code: 0F03H) occurs and the positioning data contents are cleared. After that, the absolute position control data for one time is read and the positioning data file is written. Also, if the memory extremely lacks its capacity and the file cannot be created, the positioning data history file is not created.
- The No.1 CPU clock data is the standard for the Motion module. Therefore, the time and date of the event that occurred during initial processing may be different from the actual time and date. Also, the time and date of event occurrence already saved in the event history cannot be corrected even if clock data is received from the CPU module.

Relevant add-ons

The following add-on is required to use this function.

- MotionEventHist

System memory capacity

■Backup RAM Usage

Refer to the following.

 Page 822 Event history file of the Motion module side

18.3 Servo System Recorder


The servo system recorder generates a logging setting file which is optimal for analyzing of the error factors when Add-on ServoSystemRecorder Monitor is enabled. The logging setting file continuously monitors the error status of the motion system and supported device stations. When an error is detected, the status before and after occurrence is recorded for a certain period of time and saved in the data logging file.

Logging setting file editing and data logging file analysis are possible from the engineering tool.

The collecting target is the real drive axis only. The collected data helps to investigate causes of factor which cannot be solved easily just by information of "Event history".

Ex.

When an error occurs to device stations which are connected to the slave axis in cam control.



Operation of this function for each system status

○: Possible, △: Possible (restricted), ×: Not possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	△ (Not possible if READY does not become TRUE)
Major error	×

Relevant variables

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
Addon_ServoSystemRecorder	Add-on ServoSystemRecorder Parameter	Sets the maximum capacity for the memory used in Add-on ServoSystemRecorder parameter (Addon_ServoSystemRecorder). Add-on ServoSystemRecorder parameter (Addon_ServoSystemRecorder) is a CYCLE_PARAM structure.
Logging_AutoLoggingEnable	Auto Logging Enabled	Sets "Disabled" and "Enabled" of the auto logging function when logging setting files are stored in the SD memory card. • FALSE: Disabled • TRUE: Enabled For details on the auto logging, refer to the following.  Page 800 Auto logging
CoRecordingEnable	Co-recording Setting	Sets whether to enable/disable co-recording. • FALSE: Not used • TRUE: Used

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Addon_ServoSystemRecorder	Add-on ServoSystemRecorder Monitor	Sets the maximum capacity for the memory used in Add-on ServoSystemRecorder parameter (Addon_ServoSystemRecorder). Add-on ServoSystemRecorder parameter (Addon_ServoSystemRecorder) is an ADDON_MONI structure.
ServoSystemRecorder_Enable	Servo System Recorder Enabled	Displays whether logging collection by the servo system recorder is enabled or disabled. Becomes TRUE when the logging collection is operating normally. • FALSE: Disabled • TRUE: Enabled
CoRecordingStatus	Co-recording Operation Status	Displays the operation status of co-recording. • 0: Stopped (CoRecordingStopping) • 1: In operating (CoRecordingEnable)

ADDON_PARAM

Variable/Structure name	Name	Details
RamSizeMax	Maximum RAM Size	Specifies the maximum amount of system memory (RAM) used in the Add-on ServoSystemRecorder in k bytes. When the operation cycle over is detected during the logging, increase the maximum RAM size of the add-on logging parameter.
BackupRamSizeMax	Maximum Backup RAM Size	Specifies the maximum amount of system memory (backup RAM) used in the Add-on ServoSystemRecorder in k bytes. When backup memory lacks its capacity during the logging, increase the maximum backup RAM size of the add-on logging parameter.

ADDON_MONI

Variable/Structure name	Name	Details
RamUsage	RAM Usage	Stores current amount of system memory (RAM) used in the Add-on ServoSystemRecorder in k bytes.
RamMaxUsage	RAM Usage Maximum	Stores the maximum amount of system memory (RAM) used in the Add-on ServoSystemRecorder in k bytes.
BackupRamUsage	Backup RAM Usage	Stores the current amount of system memory (backup RAM) used in the Add-on ServoSystemRecorder in k bytes.
BackupRamMaxUsage	Backup RAM Usage Maximum	Stores the maximum amount of system memory (backup RAM) used in the Add-on ServoSystemRecorder in k bytes.
Addon_ServoSystemRecorder	Version	Stores the version information of the Add-on ServoSystemRecorder.

Logging setting file auto generation


This add-on reads the axis setting in the project at the start of the motion system and automatically generates a logging setting file with collected data reflected with a number of axis setting required for error analysis.

The logging setting file is automatically generated every time the motion system is started so the data will be reflected at the start of the motion system even if the axis setting in the project is changed.

The data logging name which will be added in the file of the generated logging setting file will be "ServoSystemRecorder". When the name starts with "ServoSystemRecorder", the data in the logging setting file is overwritten every time the motion system is started. When the name starts other than "ServoSystemRecorder", the data in the logging setting file is not be overwritten and "Servo System Recorder Setting File Creation Disabled Warning" (warning code: 0F13H) occurs and the servo system recorder will not start.

The auto-generation can be confirmed if "ServoSystemRecorder" is shown on the "Motion System Logging Status and Operation" window as follow.

🖱️ Motion Control Setting Function ⇒ [Tool] menu ⇒ [Logging function] ⇒ [Logging Setting] ⇒ "Motion System Logging Setting" window ⇒ [Online] ⇒ [Logging Status and Operation]



Also, the auto-generation completion can be confirmed if "007EE: Servo System Recorder Start" is shown in the "event history" window.

 Motion Control Setting Function ⇒ [Online] menu ⇒ [Motion Monitor] ⇒ [Event History]

Event History- [0010:RD78G64]

Refresh(U)

Number of Events:1242

Refine(D)

Events to Exclude

Refine

☒ Match All the Conditions

☐ Match Any One of the Conditions

1. Event Type

Including Next

2.

3.

☐ Include program errors (Allow jumping)

Start Refine

Clear Refine Conditions

No.	Occurrence Date	Event Type	Status	Event Code	Overview
00001	2020/06/24 09:08:08.723795768	System		007F0	MCFB Start (Control System)
00002	2020/06/24 09:08:08.568889312	System		007EE	Servo System Recorder Start
00003	2020/06/24 09:08:08.445867584	System		007FE	Homing Request OFF to ON
00004	2020/06/24 09:08:08.445862936	System		007FE	Homing Request OFF to ON
00005	2020/06/24 09:08:08.445858112	System		007FE	Homing Request OFF to ON
00006	2020/06/24 09:08:08.445853296	System		007FE	Homing Request OFF to ON
00007	2020/06/24 09:08:08.445848488	System		007FE	Homing Request OFF to ON

Precautions

- If the real drive axis does not exist in the project, the logging setting file is not generated.
- When starting the motion system without an SD memory card being inserted, the logging setting file is generated in the user drive. When the motion system is restarted with an SD memory card being inserted, both the user drive and the SD memory card will be in the state that the logging setting file is being generated. In this case, the logging is executed by prioritizing the logging setting saved in the SD memory card.

Restriction

If the add-on is disabled, the logging setting file with the data logging name which starts from "ServoSystemRecorder" does not execute the operation. If the file is not needed, delete it.
For how to delete files, refer to the following.

 Page 840 How to delete the logging setting file

Storage location


The logging setting file generated by this add-on is stored in an SD memory card or the user drive of the motion system. If the SD memory card is inserted, it is prioritized as a storage location of the logging setting file. (The storage location of the result file will be the same directory of the logging setting file.)

A logging function provides 10 logging setting file available for execution at the same time, and the following settings will be used in this add-on.

Number of real drive axis		Setting
When setting 1 to 128 axes		Logging setting 10 (LOG10)
When setting 129 to 256 axes	For 1 to 128 axes	Logging setting 10 (LOG10)
	For 129 to 256 axes	Logging setting 09 (LOG09)

■Folder configuration

The folder configuration is shown below.



Precautions

- When using this function, do not use the logging setting 10 and 09 by normal logging operation. The logging setting 09 can be used by normal logging operation depending on the number of set axis. In such a case, the motion system does not notify to the device station.
- When the logging setting 10 and 09 are once created with this function, the logging setting 09 is not deleted even if the number of set axis is changed to 128 axes or less and the motion system is turned on again. Delete the specified logging setting by its tool.

Editing logging setting file

For the logging setting file generated by this add-on, changing the collected data, collection interval (rate), number of collection, and trigger detection position can be edited by the following procedure. In such a case, change the data logging name to "ServoSystemRecorder_****". By doing this, the logging setting file is not overwritten by this add-on even if the motion system power is turned on again.

■Editing procedure

1. Read the logging setting file (LOG10 or LOG09) in the motion system by logging setting tool.
2. Edit the logging setting file and change the data logging name to "ServoSystemRecorder_****".
("****" part in the data logging name can be arbitrarily set by the user)
3. Write from the logging setting tool to the motion system (LOG10 or LOG09).

By editing the logging setting file, adding the target data or deleting the unnecessary data is possible as necessary to the logging setting file generated automatically.

If the operation cycle over occurs, the processing time of the operation cycle can be shortened by reducing the number of target data.

When the edited logging setting file is no longer needed, delete it by logging setting tool. By doing so, the logging setting file is automatically generated by default when the motion system power is turned on.

Precautions

- If the logging setting file is edited, be sure to change the data logging name to "ServoSystemRecorder_****". If the change is not executed, the logging setting file is overwritten by default when the motion system power is turned on.
- If the data logging name starts other character string than "ServoSystemRecorder", "Servo System Recorder Setting File Creation Disabled Warning" (warning code: 0F13H) occurs and the servo system recorder does not start.
- Do not change the logging start condition of the logging setting file. The servo system recorder starts automatically even when the setting is changed to "Starts by user operation".

Details of logging setting

The specifications of the logging setting generated by the Add-on ServoSystemRecorder are shown below.

- Logging setting file

Item	Specification / Description	
Logging setting file (Uses the last LOG10 and LOG09 from 1 to 10 areas.)	LOG10/LOGGING.json	1 to 128 axes Number of set axis in the motion system (real drive axis) Collected data of 1 to 128 axes
	LOG09/LOGGING.json	129 to 256 axes Number of set axis in the motion system (real drive axis) Collected data of 129 to 256 axes
Logging start condition	Stop disabled after automatically start	
Logging type	Trigger logging (The rows before and after the trigger are output)	
Data storage location	SD memory card *: If an SD memory card is not inserted, the storage location of the data is in the user drive. The user drive is the ROM area of the motion system.	

- Data logging file (result file)

Item	Specification	
Logging data file name	20YYMMDD_hhmmss.json (Date and time at the file being generated.)	
File size	Changes depending on the number of collected data (number of axis) and the data value.	
File format	JSON	
Collection interval	125.00 [μs] (When the operation cycle is 125.00 [μs] or more, the collection interval will be the operation cycle)	
Operation when the file exceeds the number of saved files	Overwrite	
Trigger type	OR combination	
Number of records	Number of real drive axis: 1 to 128	Number of LOG10 records • Number of trigger records before trigger: 1434 [records] • Number of trigger records after trigger: 614 [records]
	Number of real drive axis: 129 to 256	Number of LOG09 and LOG10 records • Number of trigger records before trigger: 717 [records] • Number of trigger records after trigger: 307 [records]
Number of saved files	Sets 16 when the storage location of the data is an SD memory card, and 2 for the user drive.	

■Collected data of the servo system recorder

The following data is set automatically. The setting details can be changed by logging setting tool.

- Axis monitor data (AxisName.Md.)

○: Set in the collected data, —: Not set in the collected data

Item	Description	Setting number of the number of real drive axis	
		128 or less (LOG10 setting)	129 or more (LOG10 and LOG09 setting)
Object Data_TargetPos (Io_TargetPos)	Displays a value of object data "TargetPosition (607AH)". (The position command to be sent to the device station)	○	○
Object Data_PosActualValue (Io_PosActualValue)	Displays a value of object data "PosActualValue (6064H)". (The feedback of position to be received from the device station)	○	○
Object Data_TorqueActualValue (Io_TorqueActualValue)	Displays a value of object data "TorqueActualValue (6077H)". (The feedback of torque to be received from the device station)	○	○
Axis Error Code (ErrorID)	Displays the error code at axis error occurrence.	○	○
Axis Status (AxisStatus)	Displays the current status of the axis. When the axis starts, it transits to the axis status according to the command.	○	○
Object Data_VelActualValue (Io_VelActualValue)	Displays a value of object data "VelActualValue (606CH)". (The feedback of velocity to be received from the device station) For the unit, refer to the manual of connected drive unit.	○	—*1
Object Data_TargetVelocity (Io_TargetVelocity)	Displays a value of object data "TargetVelocity (60FFH)". (The velocity command to be sent to the device station) For the unit, refer to the manual of connected drive unit.	○	—*1

*1 To set Object Data_VelActualValue (AxisName.Md.Io_VelActualValue) and Object Data_TargetVelocity (AxisName.Md.Io_TargetVelocity) data even when there are 129 axes or more, add them by logging setting tool.

- System monitor data (System.Md.)

Item	Description
Processing time (OperationCycle[1].ProcessingTime)*1	Stores the processing time of the first operation cycle in a unit of μs.
Cycle over (OperationCycle[1].CycleOver)*1	Becomes TRUE when the cycle over of the first operation cycle is detected.
Latest motion area system error code (ErrorID)	Stores the latest error code.
Network area error code (NetWorkErrorID)	Stores the error code when a network error occurs.

*1 CYCLE_MONI structure

Precautions

When the axis operation process fast operation mode is enabled, the sampled value is always 0 because the following monitors are not updated.

- Object Data_TargetPos (AxisName.Md.Io_TargetPos)
- Object Data_PosActualValue (AxisName.Md.Io_PosActualValue)
- Object Data_TargetVelocity (AxisName.Md.Io_TargetVelocity)
- Object Data_VelActualValue (AxisName.Md.Io_VelActualValue)
- Object Data_TorqueActualValue (AxisName.Md.Io_TorqueActualValue)

■Trigger condition (TRIGGERCONDITION)

No.	Specification
1	Event history (EVENTHISTORY) <ul style="list-style-type: none"> • An error occurrence that stops an axis is to be the trigger. For the target range of the events, refer to the following. <ul style="list-style-type: none"> ☞ Page 832 Target error code to be triggered • An error occurrence in other than real drive axis is to be the trigger as well. • Saves the logging data file every time the event code which is different from the previous code is registered to the event history.
2	At trigger command execution (LOGTRG) <ul style="list-style-type: none"> • The execution of Trigger Request (LOGGING_REF.Cd.Trigger) is to be the trigger.

■Target error code to be triggered

Error code	Name.	Remark
1A00H to 1BFFH	—	Minor error (Axis error)
1C41H	Watchdog Counter Error	Minor error (Network error)
1C43H	SLMP Communication Error	Minor error (Network error)
1C45H	SLMP Communication Error (Timeout)	Minor error (Network error)
1C80H	Cycle Over	Minor error (System error)
2000H to 32FFH	—	Moderate error
3C00H to 3FFFH	—	Major error

If an error which may stop the system occurs and the logging is being unable to continue, the logging data may not be collectable.

Co-recording function

The co-recording function synchronizes data-saving trigger generation between recording devices supporting the co-recording function.

Because each recording device can save data simultaneously by using this function, the triggers of the servo system recorder or recorders of programmable controllers on other stations can be generated at the same time as a trigger that detects a problem. In addition, by comparing and analyzing the data saved on different recording devices, a wide range of data anomalies can be found. (This function reduces the time to run an anomaly analysis of the entire system.)

The co-recording function in the Motion module applies to the logging data created by the servo system recorder function. For details of the co-recording function, refer to the following.

 MELSEC iQ-R System Recorder Co-recording Function Reference Manual

This section describes the operation of the Motion module for the co-recording function.

Control details

Enable co-recording function by setting Co-recording setting (System.PrConst.CoRecordingEnable) to "TRUE (Used)". (The initial value of Co-recording setting (System.PrConst.CoRecordingEnable) is "FALSE (Not used)".)

The co-recording operation status can be checked in Co-recording operation status (System.Md.CoRecordingStatus).

Co-recording Operation Status (System.Md.CoRecordingStatus)	Description
0: Stopped (CoRecordingStopping)	The co-recording is in the stop status.
1: In operating (CoRecordingEnable)	The co-recording is in the operating status.

Point

When the control CPU module does not support the co-recording function, or its co-recording setting is set to "Not used", "Co-recording Setting Error" (error code: 1300H, 1301H) will occur, and the co-recording function is not enabled.

■Co-recording trigger sending/receiving

The servo system recorder detects triggers when a co-recording trigger detected in another module is received via a control CPU module. Additionally, when the servo system recorder detects a trigger, it notifies other modules via a control CPU module with a co-recording trigger.

Item	Description
Co-recording trigger receiving	When a recording trigger in another module is generated, and a co-recording trigger is received via a control CPU module, the servo system recorder sets the Trigger Request (System.LoggingRef[10,(9)].Cd.Trigger) of the data logging in operation (Logging Status (System.LoggingRef[10,(9)].Md.LoggingStatus) is "TRUE (Executing)") to "TRUE (Requested)" and detects a trigger.
Co-recording trigger sending	When a trigger is detected (Triggered (System.LoggingRef[10,(9)].Md.Triggered) is TRUE (Triggered)) in the data logging operating, the servo system recorder sends a co-recording trigger to other modules via a control CPU module.

■Co-recording trigger relay

Co-recording triggers are relayed within the programmable controller system that a module is installed, and to other stations that belong to the same network. For details, refer to "Co-recording function" in the following manual.

 MELSEC iQ-R Motion Module User's Manual (Network)

Precautions

- For restrictions on the co-recording function, refer to the following.
 MELSEC iQ-R System Recorder Co-recording Function Reference Manual
- For each device, after generating a recording trigger, there is a delay in the time until the recording trigger is generated in the other recording devices. For delay times, refer to the following.
 MELSEC iQ-R System Recorder Co-recording Function Reference Manual
- When the logging setting file is edited and the "Trigger command" is excluded from the trigger conditions, co-recording trigger receiving will not operate even if the Co-recording setting (System.PrConst.CoRecordingEnable) is set to "TRUE (Used)". When using the co-recording function, do not exclude the trigger command from the trigger conditions.

Point

When the co-recording function does not operate, check the following items.

- Check that the firmware version of each module supports co-recording. For devices that support co-recording, refer to the following.
 MELSEC iQ-R System Recorder Co-recording Function Reference Manual
- Check that the co-recording setting is set to "Used" for each module.
 <Programmable controller setting>
 Set the co-recording setting to "Used".
 <Motion module setting>
 Set the Co-recording setting (System.PrConst.CoRecordingEnable) to "TRUE (Used)".
- Co-recording relay range
 For an add-on baseSystem version of "1.26" or later, the number of relay networks is fixed to 1.

Version combinations

This function can be used with ServoSystemRecorder add-on version "1.25" or later.

For the versions of other devices and engineering tools, refer to the following.

 MELSEC iQ-R System Recorder Co-recording Function Reference Manual

Restart from the logging interruption

If an error occurs in the logging while starting the servo system recorder using an SD memory card, the logging is interrupted. By inserting the SD memory card again, the logging can be restarted without turning the motion system power on again.

How to restart logging

1. After pressing down the SD memory card access control switch until CARD READY LED turns off, pull out the SD memory card.
2. CARD READY LED turns on as the SD memory card is inserted again.
3. Restart of the logging can be confirmed if the Servo System Recorder Enabled (System.Md.ServoSystemRecorder_Enable) of the system label is TRUE.

Logging restart conditions

- The servo system recorder is started with using an SD memory card.
- Auto Logging Enabled (System.PrConst.Logging_AutoLoggingEnable) is TRUE.
- The logging setting file of the servo system recorder is saved in LOG10 or LOG09 in an SD memory card.
- The write-protected in an SD memory card is canceled.
- The error factors occurred in the logging are removed.


Precautions

- The logging cannot be restarted even if the Logging Request (System.LoggingRef[1..10].Cd.StartLog) of the system label is turned TRUE.
- "Servo System Recorder Logging Execution Disabled Warning" (warning code: 0F14H) occurs when the logging in LOG10 or LOG09 is being executed at reinserting the SD memory card and the logging of the servo system recorder does not start.


How to check the logging data

This section describes the procedures to check the logging data in the motion system.


1. In "Motion Control Setting Function", select [Tool] menu ⇒ [Logging Function] ⇒ [Start GX LogViewer](1).




2. GX LogViewer starts. Select [Online] ⇒ [Open Logging File](2).




3. The "Connection Destination" window opens. Select "Select the equipment at the connection destination"(3), Select "MELSEC iQ-R Series Motion Module RD78G(H)"(4) from the pull-down list, and click the [OK] button.



4. The "Logging File" window opens. Specify the "Target Memory"(5). (When the SD memory card is inserted, the storage location of the data logging file is the SD memory card.)
5. Select the logging data to be checked, and click the [Open File] button. (Multiple selection of logging data files is not possible.)




6. The "Historical Trend" window of the selected logging data opens. The contents of the logging data can be checked in the "Historical Trend" window.




<The following procedures are required when there are 129 or more axes for logging.>


7. In GX LogViewer, select [Graph View] menu ⇒ [Change the Data to Draw Graphs](6).



8. The "Change the Data to Draw Graphs" window opens, click the [Add online files to the list] button(7).




9. The "Connection Destination" window opens. Add data logging file by the same operation as step 3 to 4.
10. Check the "Add to the Legends"(8) column of the added data logging file.
Up to 32 data are available to draw at the same time. Change the target data of drawing if necessary.




How to delete the logging setting file

This section describes the procedures to delete the logging setting file.


1. In "Motion Control Setting Function" , select [Tool] menu ⇒ [Logging function] ⇒ [Logging Setting](1).



2. The "Motion System Logging Setting" window opens. Select [Online] ⇒ [Delete Logging Setting](2).




3. The "Delete Logging Setting" window opens. Select the memory which stores the logging setting file to be deleted from "Target memory"(3).
4. The stored logging setting file is displayed in "Target logging setting data". Insert a check(4) for the logging setting file to be deleted, and click the [Delete] button.




How to disable servo system recorder

When not using this function, disable the Add-on ServoSystemRecorder with the add-on library setting. This section describes the procedures to set the add-on library to disable setting.


1. In "Motion Control Setting Function", select [Tool] menu ⇒ [Add-on Management](1).



2. The "Add-on Management" window opens. Click the [Enable/Disable Setting] button(2).




3. The "Add-on Management Enable/Disable" window opens. Uncheck(3) the Enable column of ServoSystemRecorder, and click the [Update] button.




When not using this function the processing time of the operation cycle is reduced. An approximate guide of the reduced processing time is shown below.

• For RD78G



• For RD78GH



Precautions

Relevant add-ons and versions

The following add-ons are required besides this add-on.

- Logging version "1.7" or later
- Axis version "1.7" or later

When the above add-ons are being disabled while this add-on is enabled, "Servo System Recorder Inconsistency Incorrect Warning" (warning code: 0F10H) occurs.

System memory capacity

With the operation of this function, the system memory of Add-on Logging in addition to Add-on ServoSystemRecorder is used.

The system memory (RAM) usage of each add-on is shown below.

■Add-on ServoSystemRecorder

- RamUsage


Motion module	RAM usage
RD78G	256K bytes
RD78GH	512K bytes

- BackupRamUsage
Backup RAM is not used.

■Add-on Logging

- RamUsage

RAM is used when logging with the logging setting file output by the servo system recorder. An example is shown below.



- The default memory usage setting of the logging is 16384K bytes.
- When 129 axes or more are set, the memory capacity is less than setting 128 axes because the number of collected data points and the record points of axis are being reduced.

Point

RAM usage may be insufficient when logging settings are changed. When RAM usage is insufficient, review the logging settings, or increase the RAM usage of Add-on Logging from system settings. For how to change RAM usage, refer to the following.

➡ Page 123 System Memory Settings

- BackupRamUsage
Backup RAM is not used.

Logging setting file and logging result file sizes


The logging setting file and logging result file generated by this add-on are saved in a user drive or an SD memory card. For logging setting file and logging result file refer to the following.

☞ Page 830 Details of logging setting

The default setting for the logging setting file size is up to 500K bytes. An approximate guide for the memory usage required for saving the logging result file is shown below.


- When saving to a user drive

When using a user drive as the default setting, the number of saved files for the logging result file is "2".



- When saving to an SD memory card

When using an SD memory card as the default setting, the number of saved files for the logging result file is "16".



When editing the logging settings by adding collected data or number of records, the memory capacity may become insufficient. When memory capacity is insufficient, review the logging settings, or change the saving destination to SD memory card.

19 MOTION SERVICE PROCESSING

This section describes the motion service processing which is executed in the service task.

Operation of this function for each system state

○: Possible


Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

19.1 Motion Service Processing Control

The following shows the operation by the motion service processing setting.

The motion service processing is executed in vacancy time of the fixed cycle processing as well as the normal execution type program.

When all normal execution type program is executed once, the motion service processing is started.



19.2 Motion Service Processing Description

The following shows the list of the motion service processing.

Applicable function	Description
File access processing	Executes the access processing to the file. The file access processing by a part of FBs is executed in higher priority task than the motion service processing. Refer to the specification of each FB.
MELSOFT communication processing	Executes the communication with the peripheral equipment such as the engineering tool and GOT.
Variable importing/reflection processing	Imports/reflects the variables whose import timing is "service".
Initialization processing for each function	Executes the initialization processing for each function. For details, refer to the specifications of each function.

20 HOW TO CONTROL FROM CPU MODULE

20.1 Specifications of I/O Signals with CPU Modules

This section describes how to control the Motion module from the CPU module (control CPU only).

For Motion module program creation procedure, refer to "Motion Module Program Creation" in the following manual.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

For the setting method from the C Controller module, refer to the following.

📖 MELSEC iQ-R C Controller Module User's Manual (Application)

Module label


The global label in the Motion module is available as the module label from the CPU module.

Using method

Follow the procedure below to create the module labels on the engineering tool.

1. In the label editor, set the "public label" of label to be made public as module label to the CPU module to "Enable".
2. Set "Motion Control Attribute" to decide direction of the label refresh.
3. Execute "Public label reflection" operation.

For details, refer to Help of the engineering tool.



When using the public labels, the data refresh is executed using the following memory area. For specifications such as the number of labels to be made public, refer to Help of the engineering tool.

Memory location	Name	Refresh timing
CPU module	Refresh memory (module label assignment area)	Specified in the module parameter (motion)
Motion module	Buffer memory (public label area)	Buffer memory refresh cycle

- The global labels to be made public to the CPU module use the buffer memory (area for the labels) of the Motion module. Read/Write directly for the buffer memory other than user setting area must not be carried out in the user program. For the global label size to disclose (the available label size to assign), refer to the following.

📖 GX Works3 Operating Manual

- The disclosed labels are refreshed in the "buffer memory refresh cycle". For details, refer to the following.


📖 Page 107 Operation Cycle

- When simultaneously reading or writing to multiple public labels, the following may occur.
 - Values are inconsistent among public labels.
 - Refresh order is irregular among public labels.

Therefore, it is necessary to interlock between public labels in the user program. For example programs of an interlock, refer to the following.

📖 Page 851 Example programs

- In an interlock program, the refresh interval of a public label is longer. The refresh interval varies depending on the scan program of the PLC CPU or program execution time of the Motion module. Therefore, if real-time performance is required, we recommend using the Motion control FB library or programming with the Motion module.



<Ex.1> The CPU module sets values for public labels, and the Motion module program uses them as input variables of the Motion control FB.

<Ex.2> The axis monitor of the Motion module is set as public labels and referenced by the program of the CPU module.

Motion control attribute

The public labels have attributes (= refresh direction).

The label attributes provided by the system cannot be changed.

■The CPU module → The Motion module

Writes from the CPU module to the Motion module. In the labels provided by the system, they become the attributes when the parameters and control data (Pr, PrConst, Cd, etc.) are disclosed.

■The Motion module → The CPU module

Writes from the Motion module to the CPU module. In the labels provided by the system, they become the attributes when the monitor data (Md, etc.) are disclosed.

Precautions

- A string type or a structured data type include a string type is not made public. For other restrictions, refer to the following.
 GX Works3 Operating Manual
- If the different direction from the attribute is written (e.g. The public labels, which attributes are "The CPU module → The Motion module", are written from the Motion program or watch), the values of the refresh-source overwrite the label values with the next buffer memory refresh cycle.
 Therefore, label values (some Cd. etc.) with attribute "The CPU module → The Motion module" which are changed from the motion system cannot confirm the values are changed from the CPU module. Refer to the Md. which is compatible with the Cd. or use the FB which provides the same function without operating the Cd.
- The operation performance is improved and the memory capacity can be reduced by reducing the number of the public labels.
- When the program is carried out with mismatches between the CPU module and the Motion module for the setting of the public labels, the refreshing cannot be performed correctly.
 When the setting of the disclosed labels is changed, make sure to carry out the write of the program for both the CPU module and the Motion module.
- The closed labels of the same structure data type cannot be substituted for the public labels of the structure including the closed member (and vice versa). Especially, when setting the public labels for the I/O pin (the structure) of the FB, disclose the all member of the public labels.
- When substituting to the structure type labels having the different attribute member such as AXIS_REAL type, the member values of the CPU module ⇔ the Motion module attribute are irregular (The values of the refresh-source overwrite the label values with the next buffer memory refresh cycle.)
- When using the public labels, do not execute the software reboot. If it is executed, turn on the power of the motion system again
- All the parameter constants (□.PrConst.) and the variables in the following parameters (□.Pr.) should not be set to public labels. If they are set to public labels, the initial value is "0" regardless of the value set by the motion control setting function. Moreover, a label such that "0" is outside the valid range will cause the error of out-of-parameter range when the power is ON, and therefore the READY does not turn to ON.

■List of parameters causing the error of out-of-parameter range when set to public labels

- Axis parameter (AxisName.Pr.)

Name	Variable name
Operation Selection at Start Acceleration/Deceleration 0	<u>AxisName</u> .Pr.AccelerationZeroBehavior
Driver Unit Conversion Numerator	<u>AxisName</u> .Pr.Drive_UnitConvRatioNum
Driver Unit Conversion Denominator	<u>AxisName</u> .Pr.Drive_UnitConvRatioDen
Operation Setting at Overrun	<u>AxisName</u> .Pr.OverrunOperation
Stop Selection at Deceleration to Stop	<u>AxisName</u> .Pr.StopMode_DecelerationCurve
Stop Selection at Stop Cause Occurrence	<u>AxisName</u> .Pr.StopMode_General
Stop Selection at Hardware Stroke Limit Error Occurrence	<u>AxisName</u> .Pr.StopMode_HwStrokeLimit
Stop Selection at Software Stroke Limit Error Occurrence	<u>AxisName</u> .Pr.StopMode_SwStrokeLimit
Negative Direction Velocity Limit Value	<u>AxisName</u> .Pr.VelocityLimit_Negative
Positive Direction Velocity Limit Value	<u>AxisName</u> .Pr.VelocityLimit_Positive

- Axis group parameter (AxesGroupName.Pr.)

Name	Variable name
Operation Setting at Overrun	<u>AxesGroupName</u> .Pr.OverrunOperation
Stop Selection at Deceleration to Stop	<u>AxesGroupName</u> .Pr.StopMode_DecelerationCurve
Configuration Axes Operation Selection at Axis Stop Cause Occurrence	<u>AxesGroupName</u> .Pr.StopMode_ErrorInGroup
Stop Selection at Stop Cause Occurrence	<u>AxesGroupName</u> .Pr.StopMode_General
Velocity Command Unit Setting	<u>AxesGroupName</u> .Pr.Unit_Velocity
Velocity Limit Value	<u>AxesGroupName</u> .Pr.VelocityLimit

Example programs

The restrictions and corresponding countermeasures (example programs of interlock) for reading or writing multiple public labels simultaneously in a sequence program of the CPU module are shown below.

Refresh direction	Restriction	Example program of interlock
CPU module → Motion module	Refresh order is irregular among public labels.	☞ Page 851 Starting Motion control FB of motion program from CPU module
	Values may be inconsistent among public labels.	—
Motion module → CPU module	Refresh order is irregular among public labels.	—
	Values may be inconsistent among public labels.	☞ Page 853 Referencing multiple axis monitors simultaneously from public label by the CPU module

■ Starting Motion control FB of motion program from CPU module

This section describes a case in which values are set to public labels in the CPU module and used as input variables for a Motion control FB by a Motion module program.

When setting public label values for input variables of a Motion control FB, there is no guarantee that the input variables of the Motion control FB will be reflected simultaneously even if the input variables are set in a same scan by a sequence program of the CPU module. Therefore, it is necessary to interlock the input variables including Execute command (Execute).

An example program that interlock FB input variables by a motion program when setting input variables of the Motion control FB simultaneously by the sequence program of the CPU module is shown below.

• CPU module side

■ Labels used

Label name	Data type	Comment
StartMotionAxis	Bit	Axis start flag

■ Scan program

ST program

```
//Axis operation start
IF StartMotionAxis THEN
  //FB input variable setting & Starting FB
  RD78_0000.bExecute := TRUE;
  RD78_0000.bContinuousUpdate := FALSE;
  RD78_0000.leDistance := 10000.0;
  RD78_0000.leVelocity := 100.0;
  RD78_0000.leAcceleration := 5.0;
  RD78_0000.leDeceleration := 50.0;
  RD78_0000.leJerk := 1.0;
  RD78_0000.wBufferMode := 1;
  RD78_0000.udOptions := 0;
END_IF;

//Interlock variable update
RD78_0000.uCpu_SD420 := SD420;
```

- Motion module side

■Global labels used

Label name	Data type	Comment	Public label	Motion control attribute
MC_MoveRelative_1	MC_MoveRelative	Relative positioning	Disabled	—
bExecute_Copy	Bit	Execute command	Disabled	—
bExecute	Bit	Execute command	Enabled	WRITE (⇒Motion)
bContinuousUpdate	Bit	Continuous update	Enabled	WRITE (⇒Motion)
leDistance	Double-precision real number	Movement amount	Enabled	WRITE (⇒Motion)
leVelocity	Double-precision real number	Velocity	Enabled	WRITE (⇒Motion)
leAcceleration	Double-precision real number	Acceleration	Enabled	WRITE (⇒Motion)
leDeceleration	Double-precision real number	Deceleration	Enabled	WRITE (⇒Motion)
leJerk	Double-precision real number	Jerk	Enabled	WRITE (⇒Motion)
wBufferMode	Word [signed]	Buffer mode	Enabled	WRITE (⇒Motion)
udOptions	Double word [unsigned]/bit string [32-bit]	Option	Enabled	WRITE (⇒Motion)
uCpu_SD420	Word [unsigned]/bit string [16-bit]	PLC CPU_Scan counter	Enabled	WRITE (⇒Motion)
uCpu_SD420_Latch	Word [unsigned]/bit string [16-bit]	Temporary variable of PLC CPU_Scan counter (for input variables)	Disabled	—
uCpu_SD420_Diff	Word [unsigned]/bit string [16-bit]	Temporary variable of PLC CPU_Scan counter (for difference)	Disabled	—
bLatchComplete	Bit	Latch completion for PLC CPU_Scan counter	Disabled	—

■Normal execution type program

ST program

```
// FB start acceptance processing
IF (bExecute) THEN
  //Awaiting FB input variable refresh
  IF NOT (bLatchComplete) THEN
    uCpu_SD420_Latch:= uCpu_SD420;
    bLatchComplete:= TRUE;
  END_IF;
  uCpu_SD420_Diff:= uCpu_SD420 - uCpu_SD420_Latch;
  IF(uCpu_SD420_Diff >= 2) THEN
    //FB start
    bExecute_Copy := bExecute;
  END_IF;
ELSE
  bExecute_Copy := bExecute;
  uCpu_SD420_Latch:= 0;
  uCpu_SD420_Diff:= 0;
  bLatchComplete:= FALSE;
END_IF;

MC_MoveRelative_1(
  Axis:= Axis0001.AxisRef ,
  Execute:= bExecute_Copy ,
  ContinuousUpdate:= bContinuousUpdate ,
  Distance:= leDistance ,
  Velocity:= leVelocity ,
  Acceleration:= leAcceleration ,
  Deceleration:= leDeceleration ,
  Jerk:= leJerk ,
  BufferMode:= wBufferMode ,
  Options:= udOptions
);
```

■Referencing multiple axis monitors simultaneously from public label by the CPU module

When referencing multiple axis monitors from public labels by a sequence program of the CPU module, the consistency of values among the public labels is not guaranteed. Therefore, interlock must be performed by the program to ensure consistency of values among the multiple public labels.

An example program to interlock axis monitors is shown below.

Labels to be interlocked and associated labels are shown below.

CPU module side	Motion module side	
Label referenced by CPU module	Label to be interlocked	Temporary label for interlock
Read_Axis0001SetPosition	Axis0001.Md.SetPosition	Open_Axis0001SetPosition
Read_Axis0001ActualPosition	Axis0001.Md.ActualPosition	Open_Axis0001ActualPosition

• CPU module side

■Labels used

Label name	Data type	Comment
ProgPouNumber_Latch	Word [unsigned]/bit string [16-bit]	Latch data for Motion module program execution count
ProgPouNumber_Pre	Word [unsigned]/bit string [16-bit]	Previous value of Motion module program execution count
Read_Axis0001SetPosition ^{*1}	Double-precision real number	Set position (interlocked value)
Read_Axis0001ActualPosition ^{*1}	Double-precision real number	Actual position (interlocked value)

*1 This label adds as many times as the number of public labels to be interlocked.

■Scan program

ST program

```

Interlocking Motion module public label
IF RD78_0000.WriteMotionDataFlg AND NOT(RD78_0000.ReadMotionDataFlg) THEN
  IF RD78_0000.ProgPou.Number <> ProgPouNumber_Pre THEN
    ProgPouNumber_Latch := ProgPouNumber_Latch + 1;
    IF ProgPouNumber_Latch > 2 THEN
      //Awaiting completion of writing on Motion module side
      //-----Reading public label to be interlocked   Start-----
      Read_Axis0001SetPosition := RD78_0000.Open_Axis0001SetPosition;
      Read_Axis0001ActualPosition := RD78_0000.Open_Axis0001ActualPosition;
      //-----Reading public label to be interlocked   End-----
      RD78_0000.ReadMotionDataFlg := TRUE;
      ProgPouNumber_Latch := 0;
    END_IF;
  END_IF;
ELSIF NOT(RD78_0000.WriteMotionDataFlg) AND RD78_0000.ReadMotionDataFlg THEN
  //Post-reading processing
  RD78_0000.ReadMotionDataFlg := FALSE;
END_IF;
ProgPouNumber_Pre := RD78_0000.ProgPou.Number;
RD78_0000.uCpu_SD420 := SD420;

```

- Motion module side

■Global labels used

Label name	Data type	Comment	Public label	Motion control attribute
uCpu_SD420	Word [unsigned]/bit string [16-bit]	PLC CPU_Scan counter	Enabled	WRITE (⇒Motion)
uCpu_SD420_Latch	Word [unsigned]/bit string [16-bit]	Temporary variable of PLC CPU_Scan counter	Disabled	—
uCpu_SD420_Pre	Word [unsigned]/bit string [16-bit]	Previous value of PLC CPU_Scan counter	Disabled	—
Open_Axis0001SetPosition	Double-precision real number	Set position (temporary variable for interlock)	Enabled	READ (Motion⇒)
Open_Axis0001ActualPosition	Double-precision real number	Actual position (temporary variable for interlock)	Enabled	READ (Motion⇒)
WriteMotionDataFlg	Bit	Write flag	Enabled	READ (Motion⇒)
ReadMotionDataFlg	Bit	Read flag	Enabled	WRITE (⇒Motion)
ProgPou ^{*2}	PROGRAM_INFO	Execution count of fixed-cycle execution type program	Enabled	READ (Motion⇒)

*2 This program uses the following member variables of PROGRAM_INFO structure.

Label name	Data type	Comment	Public label	Motion control attribute
Number	Word [unsigned]/bit string [16-bit]	Execution count	Enabled	READ (Motion⇒): MdConst

■Initial execution type program

ST program

```
EI(TRUE);
```

■Fixed-cycle execution type program

ST program^{*3}

```
//Interlocking public label
IF NOT(WriteMotionDataFlg) AND NOT(ReadMotionDataFlg) THEN
  //Writing public label
  //-----Writing public label to be interlocked   Start-----
  Open_Axis0001SetPosition := Axis0001.Md.SetPosition;
  Open_Axis0001ActualPosition := Axis0001.Md.ActualPosition;
  //-----Writing public label to be interlocked   End-----
  WriteMotionDataFlg := TRUE;
ELSIF WriteMotionDataFlg AND ReadMotionDataFlg THEN
  //Post-writing processing
  IF uCpu_SD420 <> uCpu_SD420_Pre THEN
    uCpu_SD420_Latch := uCpu_SD420_Latch + 1;
    IF uCpu_SD420_Latch > 2 THEN
      //Awaiting completion of reading on CPU module side
      WriteMotionDataFlg := FALSE;
      uCpu_SD420_Latch := 0;
    END_IF;
  END_IF;
END_IF;

uCpu_SD420_Pre := uCpu_SD420;
```

*3 The fixed-cycle interval setting for the fixed-cycle execution type program should be the same as the operation cycle setting.

I/O signals

The Motion module uses 32 points of the input and 32 points of the output for exchanging data with the CPU module.


The following table shows the I/O signals when 0H has been set to the start I/O number of the Motion module.

The device X is the input signal from the Motion module to the CPU module, and the device Y is the output signal from the CPU module to the Motion module.

Signal direction: Motion module → CPU module		Signal direction: CPU module → Motion module	
Device No.	Signal name	Device No.	Signal name
X0	READY	Y0	PLC READY
X1	Synchronization flag	Y1	Use prohibited
X2	Use prohibited	⋮	
⋮			
X1F		Y1F	

The ON/OFF timing and conditions of the I/O signals are shown below.

Input signal (Device X)

Device No.	Signal name	Signal state	Description
X0	READY	OFF: Not READY ON: READY	<ul style="list-style-type: none"> When the PLC READY turns from OFF to ON, the parameter setting range is checked. If no error is found, this signal turns ON. When the PLC READY turns OFF, this signal turns OFF. When a moderate error or a major error occurs, this signal turns OFF. This signal is used for interlock in a program, etc. 
X1	Synchronization flag	OFF: Module access disabled ON: Module access enabled	<ul style="list-style-type: none"> After the CPU module is turned ON or reset, this signal turns ON if the access from the CPU module to the Motion module is possible.^{*1}

*1 For accessing to the Motion module from the program, necessity of the interlock according to the module synchronization setting of the CPU module and the access destination in the Motion module are shown below.

Access destination	Module synchronization setting	
	"Synchronize" the rising of the module	"Asynchronous" the rising of the module
Motion control area	The interlock by Synchronization flag is required.	The interlock by Synchronization flag is required.
Network control area	The interlock is not required.	

Output signal (Device Y)

Device No.	Signal name	Signal state	Description
Y0	PLC READY	OFF: PLC READY OFF ON: PLC READY ON	<ul style="list-style-type: none"> This signal notifies the Motion module that the CPU module is normal. <ul style="list-style-type: none"> It is turned ON/OFF with the sequence program. When a stop error occurs in the PLC CPU, it is treated as power OFF. When the data (parameter) is changed, the PLC READY is turned OFF depending on the parameter. The following processes are carried out when the PLC READY turns from OFF to ON. <ul style="list-style-type: none"> The parameter setting range is checked. The READY signal turns ON. The following processes are carried out when the PLC READY turns from ON to OFF. <ul style="list-style-type: none"> The READY signal turns OFF. The operating axis stops.

Buffer Memory

For the buffer memory arrangement, refer to "Buffer Memory" in the following manual.

 MELSEC iQ-R Motion Module User's Manual (Network)

User setting area can be used for exchanging data between the CPU module and the Motion module.

Start No.	End No.	Name
11478000	11997999	User setting area

Do not use the other areas than the above.

20.2 Using Motion control FB

This section describes how to use the Motion control FB in sequence programs of the CPU module.

Relevant variable

System monitor data (System.Md.)

Variable/Structure name	Name	Details
BuffermemoryFreeMcfbArea	Buffer Memory MCFB Communication Area Free Size	Displays the number of unused points of the area for Motion control FB.

Control details

20

The specifications of variables that are used for the Motion control FB of the CPU module side are shown below.

- Specifying AXIS_REF and AXES_GROUP_REF

When using the Motion control FB of the CPU module side, use the followings for the axis information (AXIS_REF) and the axes group information (AXES_GROUP_REF) that are specified for the I/O variables of the Motion control FB.

AXIS_REF and AXES_GROUP_REF to be specified	Setting
When AXIS_REF(UNIT_LABEL.AxisName.AxisRef) or AXES_GROUP_REF(UNIT_LABEL.AxesGroupName.AxesGroupRef) in the axis disclosed in the module labels or the axes group variables are used.	The setting in the sequence program is not required as the members of AXIS_REF and AXES_GROUP_REF (the axis No. , axes group No., and module I/O Number of the control target) are set.
When AXIS_REF and AXES_GROUP_REF that are defined as labels in the CPU module are used.	Set the members (the axis No. , axes group No. and the module I/O Number to be controlled) of AXIS_REF and AXES_GROUP_REF by using the sequence program.

- Specifying the I/O number

When using the Motion control FB of the CPU module side, the start I/O number of the target Motion module has to be specified for the I/O variables (I/O Number (AxisName.AxisRef.StartIO), etc.) used in the Motion control FB.

Each Motion control FB definitely defines one input variable that requires the I/O Number (StartIO) setting. For the input variables that require the I/O Number (StartIO) setting, refer to "Motion Control FB Overview" in the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

For the Motion control FB that can input multiple variables whose member includes I/O Number (StartIO), the setting of I/O Number (StartIO) excluding the corresponding variables is not required. (The values are ignored.)

For the start I/O number of the target module, refer to UNIT_LABEL.uIO of the module label or directly input the constant.


Be sure to establish I/O Number (StartIO) of each Motion control FB before the FB is called for the first time.

- Specifying file names and variables (label, device)

The files and the variables when using the FILE_LOCATION type structure (for specifying file names) or the TARGET_REF type structure (for specifying variables such as labels and devices) in a sequence program of the CPU module, they are the files and the variables used in the Motion module, not used in the CPU module.

Generating Motion control FB instance

Control corresponding to the Motion control FB can be carried out in the Motion module side by instantiating the Motion control FB as a global label or a local label on the CPU module and calling the Motion control FB on the sequence program.



When using the Motion control FB of the CPU module side, the following memory areas are used. The number of available Motion control FB instances must not exceed the size of each area.

Memory location	Name	How to check the available size
CPU module	Label memory	Check by using the engineering tool
Motion module	Buffer memory (Area for Motion control FB)	Buffer Memory MCFB Communication Area Free Size (System.Md.BuffermemoryFreeMcfbArea)
	Memory for PLCopen motion control basic add-on	<ul style="list-style-type: none"> • RAM Usage Maximum (System.PrConst.Addon_MotionControl_General.RamSizeMax) • RAM Usage (System.Md.Addon_MotionControl_General.RamUsage)

Point

- The buffer memory (area for the Motion control FB) and the memory for the motion control add-on are hold when the Motion control FB is called for the first time after the CPU module is set to RUN. If the free space is in short, "Memory Shortage" (error code: 349AH) will occur when the Motion control FB is called for the first time, and the Motion control FB will not be executed.
- Even if the Motion control FB of the CPU module side is deleted, the memory on the Motion module side is not released. Therefore, if the Motion control FB is added or deleted repeatedly by writing during RUN, the memory area of the Motion module side will be in short and "Memory Shortage" (error code: 349AH) may occur. In this case, reset the CPU module once.

Operating Motion control FB

■Operation conditions

The conditions (available conditions) to operate the Motion control FB of the CPU module side are shown below.

CPU module	Motion module	
	RUN	Other than RUN
RUN	Available	Unavailable
Other than RUN	Available ^{*1}	the Motion control FB in execution is stopped

*1 This state occurs when PLC Ready (System.Cd.SequenceReady) is being RUN by operated directly, and the stop error is not occurring in the CPU module.

In this case, execute such as an axis stop in the Motion module program if necessary because the Motion module cannot be controlled from the CPU module. For details, refer to the following.

☞ Page 130 Relevant variables

■Processing order

The processing order of the operation cycle in the Motion module corresponding to the Motion control FB instance of the CPU module side is the order when the Motion control FB is called for the first time.


■Mix of the Motion control FB of CPU module side and the Motion control FB of the Motion module side

When the Motion control FB of the CPU module side and the Motion control FB of the Motion module side are simultaneously executed to the same axis or axes group, the specifications of the buffer mode and the single axis synchronous control are applied.

Even if the global instance names are the same between the Motion control FB of the CPU module side and the Motion control FB of the Motion module side, these are treated as different control FBs in the Motion module.

Ex.

When executing Aborting to the on-going Motion control FB in the Motion module side by the Motion control FB of the CPU module side




(1) Execute the Move1 of the Motion module side.

(2) When executing the Move2 of the CPU module side while the Move1 is in execution, the program is operated with the buffer mode specified by the Move2.

Ex.

When mixing the Motion control FBs of the single axis synchronous control in the Motion module side and the CPU module side



- (1) When executing the GearInA and GearInB of the Motion module side, the Axis2 and Axis3 of the slave axes run.
- (2) When executing the GearIn1 of the CPU module side, the Axis4 runs using the slave axis of the GearInB (Axis3) as the master axis.
- (3) When attempting to execute the GearIn2 of the CPU module side, the Axis1 to Axis4 make a circular reference. Therefore, an error occurs and the GearIn2 cannot be executed.

■Refresh cycle of I/O variables and public variables

The refresh response time of I/O variables and public variables for the Motion control FB of the CPU module side is as shown below.

Motion control FB call cycle in the CPU module + Buffer memory refresh cycle × 2

■Interlock of I/O variables when using Execute command (Execute) type FBs

For Execute command (Execute) type FBs, refer to "Basic operation of Execute command (Execute) type Motion control FBs" in the following manual.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Note that there is the difference in some of the specification as follows.

- Difference of the specification with the Motion control FBs of the Motion module side
After the falling edge of Execute command (Execute), Abortion of execution (CommandAborted) is reset from 1 to a few scans behind.
When re-executing after the Motion control FBs have stopped, execute after confirming the reset of Execution completion (Done), Error (Error), and Abortion of execution (CommandAborted) have been performed.

■Interlock of I/O variables when using Enabled (Enabled) type FBs

For Enable (Enable) type FBs, refer to "Basic operation of Enable (Enable) type Motion control FBs" in the following.

📖MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Precautions

For Motion control FBs, refer to precautions of the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

The precautions only for the Motion control FB in a sequence program of the CPU module are shown below.

- When executing the Motion control FBs in the interrupt program of the CPU module, fixed-cycle execution type program or event execution type program, the Motion control FBs may not start.

Use them with the following special relay ON.*1 Note that the completion signal of all dedicated instructions is maintained with ON at instruction completion by the following special relay ON so that the process which the completion signal is set to OFF should be created in a program when the program which is needed to set ON for only one cycle exists.

Number	Name
SM752	Dedicated instruction End bit control flag

*1 For details of the special relay, refer to the following.

📖 MELSEC iQ-R CPU Module User's Manual (Application)

- When writing the Motion control FB in the control syntax such as the IF statement or the MC instruction, the Motion control FBs may not start.

Do not write the Motion control FB in the control syntax.

- When using the Motion control FB in the CPU module side, do not execute the software reboot. If it is executed, turn on the power of the motion system again.
- The number of steps of FBs built into a program is different depending on the CPU module to use, the I/O definition, or Options setting of GX Works3. For Options setting of GX Works3, refer to the following.

📖 GX Works3 Operating Manual

- This FB uses the index register. When using the interrupt program, fixed-cycle execution type program or event execution type program, do not use the following index register.

When the corresponding index register is used, the FB may not operate correctly.

When using the corresponding index register in the interrupt program, fixed-cycle execution type program or event execution type program, do not assign the corresponding index register as the local index register.

Motion control FB Library version	Index register
Earlier than "1.09J"	Z1
"1.09J" or later	Z1, Z2

- Even if a warning of duplicated coil may occur in compiling, this is not particular problem in use.
- When using the subroutine type FBs in a ladder program, connect the I/O labels to both input and output sides.
- This FB uses the label initial value for each program. When specifying the program file using this FB by boot settings, specify the label initial value for each program by boot settings in the boot operation of the CPU module.
- If an Execute command (Execute) type Motion control FB is added by online change while Execute command (Execute) is TRUE, the added Motion control FB will not start. Change Execute command (Execute) from FALSE to TRUE after the online change is completed.
- When the motion system ready is OFF, the output variables of the Motion control FB are not guaranteed. If the input variables of the Motion control FB are changed, the output variables of the Motion control FB are not updated.

-
- Errors (including warnings) of the CPU module side during Motion control FB execution are output as errors of the Motion module. For the error code output to Error code (ErrorID) of the Motion control FB, refer to the following.

 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

However, when the I/O number ( Page 857 Relevant variable) of the Motion module specified with the Motion control FB argument is not correct and the Motion module to execute the FB cannot be specified, no operation is performed or the error code is output in the CPU module side.

- The Motion control FBs do not include an error recovery process. Create the error recovery process separately according to the user setting system or required operation.
 - The Motion control FBs do not detect the alarms and the warnings which occurred in the servo amplifier. Create the monitoring process of the alarms and the warnings which occurred in the servo amplifier separately. For the alarms and the warnings which occurred in the servo amplifier, refer to the manuals of the servo amplifier in use.
-

21 FILE CONTROL

21.1 Memory and File

The programs and parameters used in the motion system control are stored in files. The file storage location can be set freely by parameters of each control and I/O variables of FB.

The motion system built-in memory, the control CPU module memory of the motion system, and an SD memory card can be used as data area for file storage.

Operation of this function at each status of system

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Storage_rom	User Drive Information	Stores the information of user drive.
Storage_sys	System Drive Information	Stores the information of system drive.
Storage_ram	RAM Drive Information	Stores the information of RAM drive.
Storage_lch	Latch Drive Information	Stores the information of latch drive.
Storage_sdc	SD Memory Card Information	Stores the information of SD memory card.
HwStatus_RomWriteCycle	Flash ROM Write Count Index Value	Stores the flash ROM write count index value.

Drive

Drive structure

A generic term for the file storage memory and the SD memory card slot of the motion system is called "Drive". The following shows available drives of the motion system.

Item	User drive	System drive	RAM drive	Latch drive	SD memory card
Usage	<ul style="list-style-type: none">• Project data• General data	<ul style="list-style-type: none">• Module software• Add-on	Work data	<ul style="list-style-type: none">• Absolute position data• Synchronous restoration data	<ul style="list-style-type: none">• Project data• General data
Drive identifier	/rom	/sys	/ram	/lch	/sdc
Memory capacity ^{*1}	■When using RD78G 16M bytes ■When using RD78GH 64M bytes	■When using RD78G 8M bytes ■When using RD78GH 24M bytes	■When using RD78G 16M bytes ■When using RD78GH 32M bytes	■When using RD78G 240k bytes ■When using RD78GH 480k bytes	maximum 32G bytes
File system	Equivalent to FAT16(VFAT) ^{*2}	Equivalent to FAT16(VFAT) ^{*2}	FAT16(VFAT)	FAT12(VFAT) ^{*2}	■SD memory card: FAT16(VFAT) ■SDHC memory card: FAT32(VFAT)
Format necessity before the first usage	Not necessary ^{*3}	Not necessary ^{*3}	Not necessary ^{*4}	Not necessary ^{*3}	Not necessary ^{*5}

*1 Total capacity including file management area. The available capacity is smaller.

*2 Power off is protected. (The file system is not damaged even if the power is off during writing.)

*3 Formatting is completed prior to shipping.

*4 Formatting is completed prior to power on/reset. (The file is deleted at power on/reset.)

*5 To format an SD memory card, format it with the CPU module. If formatted with such as the Windows formatting function, an SD memory card may not be able to be used by inserting it into the Motion module.

Point

The drive that can be used may be restricted depending on functions. Also, the function may be restricted depending on the drive to be used. For details, refer to each function.

Drive status

The drive status can be checked by STORAGE_INFORMATION type variable (System.Md.Storage_<drive>) which corresponding to each drive. (The <drive> indicates drive identifier: rom, sys, ram, lch, sdc.)

Variable/Structure name	Description
STORAGE_INFORMATION.Capacity	Stores the drive capacity in a unit of 1k bytes.
STORAGE_INFORMATION.FreeSpace	Stores the drive free space in a unit of 1k bytes.
STORAGE_INFORMATION.Mount	Indicates the drive mounted status. Furthermore, it indicates file access is available when it is set to TRUE.

Memory life

■Life of flash ROM

Since a user drive and system drive use a flash ROM, it has writable times (life). An indication of write times can be monitored by Flash ROM Write Count Index Value (System.Md.HwStatus_RomWriteCycle) and data can be written until it reaches to 100,000 times. If the value exceeds 100,000 times, it is registered in the event history.

If the write count index value exceeds 100,000 times, the following symptoms may occur. Replace the motion system.

- Decrease of writing speed to file
- Unable to write data to file

The write count index value may not match the write count by user operation. For example, the write count index value may not increase even if data is written to a file.

Point

- Since the motion system operation is checked at factory acceptance test, the initial value of the write count index is not 0.
- Since a motion system always checks data in the flash ROM, the write count index value may be increased without writing by user operation.

Path setting

The file path (including file name) to be used for control is specified with the STRING or FILE_LOCATION type variable by parameters and I/O variables of FB of each control. The following describes the path specification.

Path specifications

- For the file path, alphabetic characters (a-z, A-Z, 0-9), symbols (!#\$%&'()+,.-:=@[]^_`{}~), spaces and directory delimiters (/) are available.
- A wild card (*) is available for a file name depending on the function. Refer to each function for the availability.
- The path length is up to 127 characters.
- The path is not case-sensitive.

■How to set the path

For the path setting, the absolute path and the relative path are available.

- Absolute path

The path start with / is an absolute path. An absolute path must be described with a character string combined with a file name to a drive identifier. For a drive identifier and a file name, refer to the following.

📖 Page 864 Drive

📖 Page 868 Storage files

Ex.

/sdc/\$MOTPRJ\$/calc_profile/cam0001.csv

- Relative path

Paths that do not start with "/" are relative paths. When a relative path is specified, the following directory is the root and the actual file access is performed with a root path + a relative path. The specified root path is shown below.

Module extended parameter storage location setting	Specified root path %PROJECT_ROOT%^*1	Specified root drive %PROJECT_ROOT_DRIVE%^*1
Motion module (internal memory)	/rom/\$MOTPRJ\$	/rom
Motion module (SD memory card)	/sdc/\$MOTPRJ\$	/sdc

*1 The root path is stored in the environmental variable PROJECT_ROOT defined with system. Also the drive name including root path (root drive) is stored in the environmental variable PROJECT_ROOT_DRIVE. These can be changed to the arbitrarily path by the pathset command of file transfer function.

Ex.

When the root path is not specified by the pathset command and the module extended parameter storage location setting is set to "Motion module (SD memory card)"

Specify the following path:

Relative path: calc_profile/cam0002.csv

The actual accessed file is as follows.

sdc/\$MOTPRJ\$/calc_profile/cam0002.csv

Ex.

When the \$MOTPRJ\$ path has been specified to /sdc/MyMachine/Work002/ by the pathset command and the following path is specified

Relative path: calc_profile/cam0002.csv

The actual accessed file is as follows.

/sdc/MyMachine/Work002/calc_profile/cam0002.csv

As the special relative path, ./ (indicates current directory) and ../ (indicates upper directory) can be used.

Ex.

When the root path is set to /sdc/\$MOTPRJ\$/ and the following path is specified

Relative path: ../cam0002.csv

The actual accessed file is as follows.

/sdc/cam0002.csv

■Environmental variables

The path includes environmental variables. The format of environmental variables is specified with %Environmental variable name%. Environmental variables are defined with system and users and those can be set by the pathset command of the file transfer function. For details, refer to the following.

 Page 877 File Transfer Function

The environmental variables defined with system are as follows.

Environmental variable	Overview	Default value
PROJECT_ROOT	Root directory	/rom/\$MOTPRJ\$ (Changed depending on the module extended parameter storage location setting)
CALC_PROFILE_DIR	Operation profile storage location	%PROJECT_ROOT%/calc_profile

Ex.

When the environmental variable MY_DIR defined by user is set to /sdc/my_data by the pathset command and the following path is specified

The path including MY_DIR: %MY_DIR%/file.csv

The actual accessed file is as follows.

/sdc/my_data/file.csv

■Drive No.

To access the file in the motion system with functions to use "Drive No." for path specification (SLMP communication, etc.), use the path combining "File name" to the drive identifier corresponding to "Drive No.".

For the correspondence of drive Nos. and drive identifiers, refer to the following.

 Page 864 Drive structure

Ex.

When setting as follows and the root path is set to /sdc/\$MOTPRJ\$/

Drive No.: 0000H (root)

File name: calc_profile/cam0002.csv

The actual accessed file is as follows.

/sdc/\$MOTPRJ\$/calc_profile/cam0002.csv

Ex.

When setting as follows

Drive No.: 0002H (SD memory card)

File name: \$MOTPRJ\$/calc_profile/cam0002.csv

The actual accessed file is as follows.

/sdc/\$MOTPRJ\$/calc_profile/cam0002.csv

Operation that can be executed

The following shows operations that can be executed to the drive in the motion system.

- Writing, reading and deleting a file
- Formatting a drive

Point

- When a file attribute is set to read only, writing and deleting are not executed.
- When write protect is set to an SD memory card, writing and deleting are not executed.
- The update time and create time of files are based on the clock data of CPU No.1 module.

Storage files

The programs and parameters to be used to control the motion system are stored in the root path by default. The directory corresponding to the root path is created automatically when writing a file in the root path. For details, refer to the following.

☞ Page 866 Path setting

File lists

The following shows the list of files to be used in the motion system.

■%PROJECT_ROOT%

File name	Usage	Module extended parameter target	Path change with pathset
%PROJECT_ROOT%/			
/prog		○	○
/F000		○	○
*.PFB	FB/FUN	○	○
*.MLB	Member definition	○	○
/P???	Subfolder (??? = 000 to 032)	○	○
*.PRG	Motion program	○	○
*.LBS	Local label setting	○	○
*.LID	Local label default value	○	○
GLBLINF.IFG	Global label setting	○	×
GLBLINF.LBS	Global label setting	○	×
GLBLINF.LID	Global label default value setting	○	×
MTNSTR.MLB	Member definition	○	×
MTNSTR.STR	Structure type definition	○	×
PRG.PRM	Program setting	○	×
/calc_profile	Operation profile folder	○	○
/PD??	Subfolder (?? = 00 to 03)	○	○
*.csv	Operation profile (csv format)	○	○
/auto_open	Operation profile folder (automatically opened)	○	○
/PD??	Subfolder (?? = 00 to 03)	○	○
*.csv	Operation profile (csv format)	○	○
*.cab	Project control data for engineering tool	○	×
PosHist.bin	Position data history file	×	○
filelog.txt	File transfer log file	×	○
filelog.bak	File transfer log backup file	×	○

■rom

File name	Usage	Module extended parameter target
/LOGGING	Logging folder	×
/LOG**	Logging setting ** folder	×
LOGGING**.json	Logging setting file	×
*.csv	Logging data file (csv format)	×
*.json	Logging data file (json format)	×
time.json	Time zone information	×
SimpleMotionRom.bin	For the Simple motion mode (Data saving of flash)	○

■sys

File name	Usage
/	
*.smpk	Motion module software
*.mpk	Motion module add-on
/disabled	Temporary disabled file

■ram

File name	Usage
AxisList.json	Axis instance list
AxesGroupList.json	Axes group instance list
AddonInstallInfo.json	Add-on installation information list
/temp	Temporary folder
/LOGGING	Operation folder for logging
AdvSyncInputList.json	Advanced synchronous input axis instance list
AdvSyncOutputList.json	Advanced synchronous output axis instance list

■lch

File name	Usage
abs_axis.bin	Axis absolute position data
EVENT.LOG	Motion event history
SimpleMotionFram.bin	For the Simple motion mode (Data saving of FRAM)
abs_advsync.bin	Advanced synchronous control backup data

■sdc

File name	Usage
LOGGING**.json	Auto logging

Module extended parameters

The programs and the parameters that are used for controlling the motion system are handled as module extended parameters. For the target files of the module extended parameter, refer to the following.

 Page 868 Storage files

The module extended parameter storage location can be selected from the below by "Module extended parameter storage location setting" of the module parameter.

Module extended parameter storage location setting	Storage location	Storage file format
Motion system (internal memory)	User drive of motion system (/rom)	Individual file
Motion module (SD memory card)	SD memory card drive of Motion module (/sdc)	Individual file

The module extended parameter storage location setting can be overwritten (override) by specifying PATHSET of the root path using the boot operation file.

Point

To write the module extended parameter from the engineering tool, specify the writing destination same as the module extended parameter storage location setting. When the different writing destination is specified, the written module extended parameter is not enabled.

Data backup

Data saving/restoration in each drive to the outside the motion system can be executed by user operation using such as file transfer function.

Some data may be saved incorrectly if saving/restoration set procedure is not being followed. Also, when transferring drive data of the Motion module by using file transfer function by user operation, read/write of the target drive needs to be permitted in access control setting in advance. For details, refer to the specifications of each function.

To secure the consistency of the backup data, it is recommended to execute data saving (backup) and restoration (restored) while the drive unit is not connected and PLC READY is OFF.

Data saving (backup)

The saving (backup) procedure of all data in the motion system by user operation is shown below.

1. To save the label values, reflect the description of the labels (user defined labels, each type of Pr and PrConst) to the label default value file (specified to store in the root path) by using "Filing" command of the file transfer function.
For details, refer to the following.
 Page 880 Filing
2. If function such as the absolute position system which uses latch drive is being used, use Backup/Restore Request (System.Cd.BackupRestore) to stop the data update of the latch drive.
For details, refer to the following.
 Page 101 Saving (backup) and restoration (restored) of the absolute position data
3. Execute saving of all files under the root path, in the latch drive, and in the system drive to the outside using the file transfer function. For details, refer to the following.
 Page 879 Data copy / Data move
Note that saving RAM drive is not required as it is used only to store temporary operation files.
4. If the data update of the latch drive is stopped following procedure 2, resume the update using Backup/Restore Request (System.Cd.BackupRestore). For details, refer to the following.
 Page 101 Saving (backup) and restoration (restored) of the absolute position data

Data restoration (restored)

The restoration (restored) procedure of all data in the motion system by user operation is shown below.

- 1.** If function such as the absolute position system which uses latch drive is being used, use Backup/Restore Request (System.Cd.BackupRestore) to stop the data update of the latch drive. For details, refer to the following.
 Page 101 Saving (backup) and restoration (restored) of the absolute position data
- 2.** By using the file transfer function, restore files stored outside drive to the original drive. For details, refer to the following.
 Page 879 Data copy / Data move
- 3.** If the files in the latch drive are changed following procedure 2, execute restored data saving request by using Backup/Restore Request (System.Cd.BackupRestore). For details, refer to the following.
 Page 101 Saving (backup) and restoration (restored) of the absolute position data
- 4.** Reboot (software reboot or hardware reboot) the motion system.

Point

- Data saving/restoration can be executed with the saving/restoration functions of the engineering tool. For details, refer to Help of the engineering tool.
- The Motion module does not hold either network or drive unit parameters. To execute saving/restoration, check the specifications of CPU module and the drive unit and execute it.

Operation folder

When operating files by each function, a temporary file might be created for operating in the operating file (a folder which is indicated with the environmental variable%TEMP%). The user is not allowed to change and delete the data in the operating folder. (The error might occur in the functions under control.)

The operating folder is %TEMP% = /ram/temp by default. The place for %TEMP% can be changed by the pathset command of file transfer function. For handling large amount of files, change the operating folder to the SD memory card, etc. if the RAM drive lacks its capacity. However, the execution speed for file operating will be slower if other than RAM drive is used.

Precautions

Processing of reading/writing files

- Processing of reading/writing files is executed in the background processing of the motion system. Reading/Writing time is changed depending on the file size and the system load state. Therefore, the system startup time and the switching time from STOP to RUN may be longer.
- Writing time of the user drive may be longer if the free space of the drive decreases.
- The timeout error may occur during reading/writing files due to the communication failure with the engineering tool. In such a case, try the operation after a while.

Power OFF at file operation (including reset)

- While file operation excluding data reading, if the software is reset or the power of the motion system is turned OFF or reset, the file contents are not guaranteed. To prevent data damage, turn OFF the power (including reset) after the file operation is completed.
- Check the consistency of the file system at the motion system initialization (at inserting a card for an SD memory card). It may take time to check when there are many files in the drive.

Access to the same file at the same time

When the following operations are performed via engineering tool or SLMP, an error occurs. Execute the next access after the processing of one request source is completed.

- Execute access (reading/writing) from another request source to the file which is being writing.
- Execute writing from another request source to the file which is being accessing (reading/writing).

Access to the different files from multiple request sources at the same time

Access to the different files from multiple request sources at the same time is up to 16 files.

21.2 Parameter Read/Write Function

This function reads/writes parameters.
It can read and write objects of the device stations.

Relevant FBs

For details on Motion control FBs, refer to the following.
MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MC_ReadParameter	Parameter Read	Read objects of the device stations.
MC_WriteParameter	Parameter Write	Write objects of the device stations.

Control details


21

Object read/write (Transient)


Objects can be read/written by indicating 00010000H or later to the parameter No. In this case, data is sent/received by using the transient transmission function.
When (response code (SDO Abort Code)) for transient request is received from the device station, Error (Error) becomes TRUE and then "SDO Communication Error" (error code: 1800H) is stored to Error code (ErrorID) and the response code (SDO Abort Code) from device stations is stored to Transient error code (SDOErrorID).

■The timing of send/receive

- At successful completion
 - For executing parameter read




■For executing parameter write




• At unsuccessful completion (SDO communication error has occurred.)

■For executing parameter read




■For executing parameter write




• At unsuccessful completion (the I/O variables and the Input variables are abnormal)

■For executing parameter write



■For executing parameter write



Response code (SDO abort code)

For the response code by using the transient transmission function when the data send/receive is unsuccessful, refer to "Response Code (SDO Abort Code)" in the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Network)

Precautions

- The transient transmission can be executed up to four toward the same axis. If MC_ReadParameter (Parameter Read)/MC_WriteParameter (Parameter Write) for the object is executed toward the axis which is already executing four transient transmissions, "Parameter Reading And Writing FB Execution Disabled Error" (error code: 34A1H) occurs and the next FB is not executed. (The FB which is being executed continues.)
Obtains home position data of the drive unit by the transient transmission function in a driver homing method. Therefore, if the parameter read/write for the object is executed when MC_Home (OPR) is carried out, "ABS Reference Point Read Error" (error code: 1AAAH) might occur in MC_Home (OPR).
- When reading/writing the integer type/BOOL type parameters or objects, the setting value of MC_WriteParameter (Parameter Write) is converted into integer type or BOOL type and taken. Also, the written value in MC_ReadParameter (Parameter Read) is respectively converted into LREA type or BOOL type and output.

Ex.

When writing parameters by specifying two bytes size with MC_WriteParameter (Parameter Write).

Setting value (Value) (Data type: LREAL)	Write value (2 bytes data)	
	Specifies unsigned (Options (Options): Bit 16) "0: Signed"	Specifies unsigned (Options (Options): Bit 16) "1: Unsigned"
10000.5	10000.0	10000.0
-10000.4	-10000.0	55536.0
65535.0	-1.0	65535.0
-65535.0	1.0	1.0
65536.0	0.0	0.0
131071.0	-1.0	65535.0

Ex.

When reading parameters by specifying two bytes size with MC_ReadParameter (Parameter Read).

Parameter value	Read value (Value) (Data type: LREAL)	
	Specifies unsigned (Options (Options): Bit 16) "0: Signed"	Specifies unsigned (Options (Options): Bit 16) "1: Unsigned"
10000	10000.0	10000.0
-20000	-20000.0	45536.0
65535	-1.0	65535.0
65536	0.0	0.0
131071	-1.0	65535.0

- The changed values by this function are not saved. To use the changed values at the next power supply, save the parameters. For how to save parameters of device objects, refer to the manual for the device stations.
- When device stations in transient transmission are disconnected, all the transient requests for disconnected device stations are fail, and "SDO Communication Error" (error code: 1800H) occurs.
- Start this FB after checking that the driver status (AxisName.Md.Driver_State) is not "-1: Invalid" or "0: Not Ready To Switch On". If this FB is executed when the driver status (AxisName.Md.Driver_State) is "-1: Invalid" or "0: Not Ready To Switch On", "Parameter Reading And Writing FB Execution Disabled Error" (error code: 34A1H) occurs.

21.3 File Transfer Function

This function executes file operation and data backup/restore based on the specified command.

This function executes the file operation according to the command description set in File Transfer Command (System.Cd.FileTransfer_Command) by setting TRUE in File Transfer Execution Request (System.Cd.FileTransfer_Execute). While the file transfer is executed, File Transfer Executing State (System.Md.FileTransfer_State) is set to Executing (Executing).

The execution of file transfer is registered in the event history (type: system).

Operation of this function at each status of system

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

21

Relevant variables

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
FileTransfer_LogCapacity	File Transfer Log Capacity	Specifies the log file capacity in a unit of k byte. • -1 to 2048 [k bytes]
FileTransfer_AcFile_lch	File Transfer Access Control (Files in Latch Drive)	Specifies the access control to files in the latch drive. For details, refer to the following.  Page 878 Access control setting
FileTransfer_AcFile_ram	File Transfer Access Control (Files in RAM Drive)	Specifies the access control to files in the RAM drive. For details, refer to the following.  Page 878 Access control setting
FileTransfer_AcFile_rom	File Transfer Access Control (Files in User Drive)	Specifies the access control to files in the user drive. For details, refer to the following.  Page 878 Access control setting
FileTransfer_AcFile_sdc	File Transfer Access Control (Files in SD Memory Card)	Specifies the access control to files in the SD memory card. For details, refer to the following.  Page 878 Access control setting
FileTransfer_AcFile_sys	File Transfer Access Control (Files in System Drive)	Specifies the access control to files in the system drive. For details, refer to the following.  Page 878 Access control setting
FileTransfer_AcLabel	File Transfer Access Control (Label)	Specifies the access control to labels. For details, refer to the following.  Page 878 Access control setting

System monitor data (System.Md.)

Variable/Structure name	Name	Details
FileTransfer_State	File Transfer Executing State	Displays the execution state of file transfer. • 0: Waiting for Execution Request (Ready) • 1: Executing (Executing) • -1: Error Occurrence (Error_)

System control data (System.Cd.)

Variable/Structure name	Name	Details
FileTransfer_Execute	File Transfer Execution Request	Requests the execution of file transfer. When the file transfer is completed, FALSE is set automatically. • FALSE: Not executed • TRUE: Executes the file transfer
FileTransfer_Command	File Transfer Command	Specifies the command of file transfer. When the file transfer is completed, it is cleared automatically. For details, refer to the following.  Page 879 Command format

Access control setting

Set the availability of data transfer by the file transfer function using the engineering tool.

- Set the access permission to each data by the WORD value shown below.

Bit	Meaning
0	Write permission (1: Allowed, 0: Prohibited)
1	Read permission (1: Allowed, 0: Prohibited)
2 to 15	Empty (Specify "0".)* ¹

*¹ If specifying other than "0", "Out of Options Range" (error code: 1A4EH) occurs, and the function will not start.

- For details on the access permission required for command execution, refer to specifications of each command.
- The access control setting read at the last is enabled at the execution timing of the file transfer function.

Functions of file transfer

Operations to be specified by the file transfer function are as follows.

Function (Command string)	Operation	Remark
Data copy (copy)	Copies a specified file, a file in a specified folder, or a subfolder.	When a file with the same name exists in the copy destination, the file is overwritten.
Data move (move)	Moves a specified file, a file in a specified folder, or a subfolder.	When a file with the same name exists in the destination, the file is overwritten. The source file is deleted.
Data delete (delete)	Deletes the specified file or the specified folder.	—
Environmental variable specification (pathset)	Specifies the data path to be used by each function. It can read the file stored in another folder and start the system without change of the user drive.	—
Filing (file)	Performs filing of label values.	<ul style="list-style-type: none"> • When a file with the same name exists in the specified path destination, the file is overwritten. • Uses the operation folder during command execution.
Data compression (compress)	Compresses a specified file or a file in a folder. (The name of compressed file is arbitrary.)	<ul style="list-style-type: none"> • When a compressed file with the same name exists in the destination, the file is overwritten. The source file is not deleted. • Uses the operation folder during command execution.
Data extraction (extract)	Extracts a compressed file to a specified folder.	When a file with the same name exists in the destination, the file is overwritten.
File attribute (attrib)	Changes a file attribute of a specified folder.	—

Command format

Specify the command to be specified by the file transfer function with the following formats.

Format

[Command] [Argument 1] [Argument 2] [Argument 3]

- For details on argument, refer to the description of each command.
- For a delimiter between commands and arguments, write a space.
- Multiple commands can be specified by using a newline code (`\n`) as a delimiter. The number of commands to be specified at the same time is not restricted.

Writing example

```
copy /rom/$MOTPRJ$/* /sdc/$MOTPRJ$/ \n delete /rom/$MOTPRJ$/
```

- For details on path that can be specified as an argument, refer to the following.
 Page 866 Path setting
- If a space is included in the path, round the path with double quotation (").
- The path is not case-sensitive.
- When "/" is written before a command, the command is ignored. If the next command exists, the execution continues.
- When the command failed to execute, File Transfer Executing State (System.Md.FileTransfer_State) turns "-1: Error Occurrence (Error_)" and the execution ends.
- When the command format is abnormal, File Transfer Executing State (System.Md.FileTransfer_State) turns "-1: Error Occurrence (Error_)" and the execution ends.
- For the operation to the file set with the read only attribute, refer to the following.
 Page 868 Operation that can be executed
- When writing commands in ST program, make sure not to include characters which cannot be expressed as a character string type constant in the argument or the path, etc. Replacing might be required. For details, refer to the following.
 GX Works3 Operating Manual

Data copy / Data move

■Format

Command	copy or move
Argument 1	<ul style="list-style-type: none"> • Specify the source data path of the target for copy / move • Wild card characters (*: arbitrary character string, ?: arbitrary single character) enable specification of multiple data. • All data in the specified folder (including the data in the sub directory as well) is copied or moved as the folder is specified. The specified folder itself is not targeted for copy or move. • For copy, read permission to the file is required. • For move, read and write permission to the file is required.
Argument 2	<ul style="list-style-type: none"> • Specify the folder path of copying or moving destination. Indicates the folder when the path ends in "/" and the file when the path does not end in "/". • As argument 1 is a single file, specifies the move destination folder (ends in "/") or the file (not end in "/"). • As argument 1 is multiple files (including the folder), specifies the move destination folder (ends in "/"). • Write permission to the file is required. • When moved to the same drive, the free space of the drive for the source data size is required.
Argument 3	<ul style="list-style-type: none"> • Specify whether the output to the log file is enabled. • Note that the argument 3 must not be specified to output the log. • Note that specifying "nolog" not to output the log.

■Writing example

- Copies IFG of the "/rom/\$MOTPRJ\$/" folder to the "/sdc/\$MOTPRJ\$/" folder.

```
copy /rom/$MOTPRJ$/param/*.csv /rom*.IFG/sdc/$MOTPRJ$/
```

- Moves all the data in the "/rom/\$MOTPRJ\$/" folder to the "/sdc/\$MOTPRJ\$/" folder without leaving the log.

```
move /rom/$MOTPRJ$/ /sdc/$MOTPRJ$/ nolog
```

- Renames ProfileData0001.CSV to ProfileData0002.CSV.

```
move /rom/$MOTPRJ$/calc_profile/PD01/ProfileData0001.CSV /rom/$MOTPRJ$/calc_profile/PD01/ProfileData0002.CSV
```

Data delete

■Format

Command	delete
Argument 1	<ul style="list-style-type: none">Specify the data path of the delete target.Wild card characters (*: arbitrary character string, ?: arbitrary single character) enable specification of multiple data.All data in the specified folder (including the data in the sub directory as well) is deleted as the folder is specified.Writing permission to the file is required.
Argument 2	<ul style="list-style-type: none">Specify whether the output to the log file is enabled.Note that the argument 2 must not be specified to output the log.Not to output the log, specify "nolog".

■Writing example

- Delete the MTNSTR.STR of "/rom/\$MOTPRJ\$/ " folder.

```
delete /rom/$MOTPRJ$/MTNSTR.STR
```

Environmental variable specification

■Format

Command	pathset
Argument 1	<ul style="list-style-type: none">Specify the environmental variable.For details on the environmental variable to be specified, refer to the following.  Page 867 Environmental variablesThe specified environmental variable has been enabled until the power ON/reset or the software reset of the motion area.
Argument 2	<ul style="list-style-type: none">Specify the file/folder path to be set to the environmental variable.Specify "/cpu" to use the data of the CPU module.Wild card characters (*: arbitrary character string, ?: arbitrary single character) enable specification of multiple data.
Argument 3	<ul style="list-style-type: none">Specify whether the output to the log file is enabled.Note that the argument 3 must not be specified to output the log.Not to output the log, specify "nolog".

■Writing example

- Specify the root path to the "/sdc/\$MOTPRJ\$/ " folder.

```
pathset PROJECT_ROOT /sdc/$MOTPRJ$/
```

Filing

■Format

Command	file
Argument 1	<ul style="list-style-type: none">Specify the target data for filing. Target data: Label Argument: labelFor the global label of the filing target, refer to "List of Variables" in the following. (The label whose attribute is LIST_WRITE_BACK is the filing target.)  MELSEC iQ-R Programming Manual (Motion Control Function Blocks)Read permission to the target data is required.
Argument 2	<ul style="list-style-type: none">Specify the output destination of the filing data.When Label is specified to argument 1, specify the path of the label default value file to be rewritten. (The file name cannot be omitted).Outputting the file with the specified name is allowed as specifying the arbitrarily named file.Write permission to the target data is required.
Argument 3	<ul style="list-style-type: none">Specify whether the output to the log file is enabled.Note that the argument 3 must not be specified to output the log.Note that specifying "nolog" not to output the log.

- The label value return to an initial value as the system is rebooted with the different value from the label initial value due to rewrite of the label value. The backed up label value at rebooting can be used as filing the label value (backup to the label default fail) by the file command. (An error does not occur if a value out of setting range is written at backup. Do not write the value of the out of setting range. It may cause an unexpected operation of the system.)
- When files before the import are specified as the target data, they may cause filing failure (such as when local labels are specified before PLC READY is ON). Execute it after the import.
- When replacing the motion system, all the data in the motion system including the absolute position data is backed up and restored (write) again to the motion system by the backup/restore function of the engineering tool.
- When filing (backing up to the label default value file) the label value, the value set to the first element becomes the default value of all elements for array labels at reboot.

■Writing example

- Files the global label.

Files (Backup to the file with a label initial value (GLBLINF.LID)) the label value.

```
file label /rom/$MOTPRJ$/GLBLINF.LID
```

Data compression

■Format

Command	compress
Argument 1	<ul style="list-style-type: none"> • Specify the target file for compression. • Wild card characters (*: arbitrary character string, ?: arbitrary single character) enable specification of multiple data. • All data in the specified folder (including the data in the sub directory as well) is compressed as the folder is specified. • Read permission to the file is required.
Argument 2	<ul style="list-style-type: none"> • Specify the path which includes the file name after compression. • Specifies the following for the compressed file extension depending on the intended use. Compression format: Zip file format Extension: zip • Write permission to the file is required. • If the file password is set for the file specified by argument 1, compress the file as it is (the file password is set for the file). In this case, the compressed file itself (*.zip or *.prm) is not added the file password.
Argument 3	<ul style="list-style-type: none"> • Specify whether the output to the log file is enabled. • Note that the argument 3 must not be specified to output the log. • Note that specifying "nolog" not to output the log.

■Writing example

- Compresses the data in the "/rom/\$MOTPRJ\$/" folder and saves as the compressed file (compress.zip) in the "/sd/\$MOTPRJ\$/" folder.

```
compress /rom/$MOTPRJ$/* /sd/$MOTPRJ$/compress.zip
```

Data extraction

■Format

Command	extract
Argument 1	<ul style="list-style-type: none">• Specify the target file for extraction.• Read permission to the file is required.• If the file password, "read protection" is set to the file in the compressed file, authentication is required.
Argument 2	<ul style="list-style-type: none">• Specify the path for the extracted folder destination.• Write permission to the file is required.• If the same named file of the extracted destination is the read-only attribute, File Transfer Executing State (System.Md.FileTransfer_State) turns "-1: Error Occurrence (Error_)".
Argument 3	<ul style="list-style-type: none">• Specify whether the output to the log file is enabled.• Note that the argument 3 must not be specified to output the log.• Note that specifying "nolog" not to output the log.

■Writing example

- Extracts the compressed file (compress.zip) in the "/sdc/\$MOTPRJ\$/ " folder to the "/rom/\$MOTPRJ\$/".

```
extract /sdc/$MOTPRJ$/compress.zip /rom/$MOTPRJ$/
```

File attribute

■Format

Command	attrib
Argument 1	Specify the path for the target file which is changed the file attribute.
Argument 2	<ul style="list-style-type: none">• Specify the file attribute to be changed.• When setting the read-only attribute, specify "+r".• When clearing the read-only attribute, specify "-r".• This argument cannot be omitted.• Write permission to the file is required.
Argument 3	<ul style="list-style-type: none">• Specify whether the output to the log file is enabled.• Note that the argument 3 must not be specified to output the log.• Note that specifying "nolog" not to output the log.

■Writing example

- Makes "/rom/\$MOTPRJ\$/PRG.PRM" the read-only file.

```
attrib /rom/$MOTPRJ$/PRG.PRM +r
```


Log file

When the file transfer function is executed, the log file (filelog.txt/filelog.bak) is stored in the directory (Default is user root) that the environmental variable FILE_TRANS_LOG indicates at the timing of the execution completion. When the environmental variable is changed by pathset command, the log file is created to the path after change.

The capacity of the log file can be specified by File Transfer Log Capacity (System.PrConst.FileTransfer_LogCapacity) and the operation depends on the setting value as follows.

File Transfer Log Capacity (FileTransfer_LogCapacity)	Log create operation
-1	Create a new file in each file transfer execution. The existing filelog.txt is renamed to filelog.bak.
0	Not created.
1 to 2048 [k bytes]	Add writing to a file in each file transfer execution. When filelog.txt exceeds the file capacity, filelog.txt is created after filelog.txt is renamed to filelog.bak.

When the log file (filelog.txt) error is detected, "Log file create disabled warning" (warning code: 0F01H) is output. After the warning is output, the file transfer execution is maintained without log files.

Precautions

- Note that the writing to the file that is being used by the control during PLC READY ON may cause unexpected operation. Besides, reading of the file that is being operated by each function may cause lost of the data consistency. Therefore, check the file is not operated and execute the file transfer function.
- The file transfer function is used when the project data is read or written from the engineering tool. While the project data is operated by the engineering tool, note that not write to File Transfer Execution Request (System.Cd.FileTransfer_Execute) and File Transfer Command (System.Cd.FileTransfer_Command).
- Note that the CPU module must not be reset and that the power must not be turned OFF during the file transmission. If the power is turned OFF or the CPU module is reset during the file transmission and the processing is forced interrupted, the file being transmitted may be broken.
- Some commands such as compression use the operation folder. The error may occur due to the insufficient capacity of the operation folder caused by large files and folder compression, etc. In such a case, change the operation folder to an SD memory card, etc. (The operation folder can be specified by changing the environmental variable %TEMP%).

Relevant add-ons

The following add-on is required to use this function.

- FileTransfer

21.4 SD Memory Card

This section describes functions using an SD memory card.

Operation of this function at each status of system

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Relevant variables

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Storage_sdc	SD Memory Card Information	Displays the SD memory card information. SD Memory Card Information (Storage_sdc) is a STORAGE_INFORMATION structure
Storage_sdcProtected	SD Memory Card Protected	Displays whether the write protect switch of the SD memory card is ON/OFF. <ul style="list-style-type: none">• FALSE: Write protect switch OFF• TRUE: Write protect switch ON
Storage_sdcInserted	SD Memory Card Inserted	Displays whether the SD memory card is inserted. <ul style="list-style-type: none">• FALSE: Not inserted• TRUE: Inserted
Storage_sdcForcedDisabled	SD Memory Card Force Disabled	Displays whether the usage of SD memory card is being forced stopped. <ul style="list-style-type: none">• FALSE: Not forced stopped• TRUE: Force stopped

System control data (System.Cd.)

Variable/Structure name	Name	Details
Storage_sdcRemovalProhibit	SD Memory Card Removal Prohibition	Specifies whether to prohibit removal of the SD memory card. <ul style="list-style-type: none">• FALSE: Removal allowed• TRUE: Removal prohibited
Storage_sdcForcedDisable	SD Memory Card Force Disabled Command	Specifies whether to restrict usage of the forced stop for the SD memory card. <ul style="list-style-type: none">• FALSE: Forced stop release• TRUE: Forced stop

STORAGE_INFORMATION

Variable/Structure name	Name	Details
Capacity	Capacity	Stores the capacity of the SD memory card in a unit of 1k bytes. (Stores the free space after formatting.)
FreeSpace	Free Space	Stores the free space of the SD memory card in a unit of 1k bytes.
Mount	Mount Status	Stores the mount status of the SD memory card.

SD memory card handling

- Format an SD memory card which is used with the motion system from the CPU module. If formatting an SD memory card using the function such as the format function of Windows?, an SD memory card may not be able to be used with the motion system.
- Data contained in an SD memory card may be corrupted if the power supply is turned OFF, the system is reset, or the SD memory card is removed while the card is being accessed. If the CARD ACCESS LED is ON, always stop access to the SD memory card with the SD memory card access control switch before turning OFF the power supply, resetting, or removing the SD memory card.
- The SD memory card is handled as the drive in the internal of the motion system and the engineering tool. For details on the SD memory card, refer to the following.

☞ Page 863 Memory and File

Installation and removal of SD memory card

For details, refer to "Installation and Removal of SD Memory Card" of Part 1 in the following manual.

📖 MELSEC iQ-R Motion Module User's Manual (Startup)

Precautions

- If each function accesses to the SD memory card during the SD memory card use stop status, the operation is the same as the operation when the SD memory card is not inserted.
- If the SD memory card is stopped while writing a file to the SD memory card from an external device, file writing may fail. Write the file again after cancelling the SD memory card use stop status.

22 SECURITY

This function serves to protect the user property stored in a personal computer and the user property inside modules in the MELSEC iQ-R series system against threats such as theft, faulty operation, and unauthorized execution due to the unauthorized access by an outsider. Use an appropriate security function according to the purpose as shown in the following table.

Security function	Purpose
Security key authentication	Prevents unauthorized viewing of a program in the engineering tool. Also prevents unauthorized program execution in a motion system. (By using a security key.) A program locked by a security key can only be executed with a motion system that has the same security key set to it.
IP filter	Blocks access from an invalid IP address by identifying the IP address of an external device connected by Ethernet. Thus, unauthorized access to the system can be prevented. For details, refer to "Security" in the following manual.  MELSEC iQ-R Motion Module User's Manual (Network)
Remote password	Limits access to just specific communication routes connected by Ethernet. (A password is used.) Thus, unauthorized access from a remote place to the system via Ethernet can be prevented. For details, refer to "Security" in the following manual.  MELSEC iQ-R Motion Module User's Manual (Network)

Operation of this function for each system status

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

22.1 Security Key Authentication Function


The security key authentication function is used to protect the user data by setting a common security key to the project and motion system to restrict the personal computer which operates the project and motion system which runs the project. The security key is created in an engineering tool and registered to the personal computer, or motion system. Security keys are set for the following.

Security key target		Application
Program file	Security keys can be registered for each program file, however, the same security key is used for all program files in a project.	<ul style="list-style-type: none">• Restricts the viewing of program files inside the project.• Restricts the execution of programs with motion systems.
Personal computer	Multiple security keys can be registered to a single personal computer.	Protected program files can be viewed with a security key.
Motion system	Only one security key can be written per motion system.	Restricted programs can be executed by security keys.

Operations that can be restricted with security key authentication function


■Program viewing

Viewing a program on an engineering tool is controlled based on whether the security keys for program files and the personal computer match.




■Program execution inside motion system

Program execution in the motion system is controlled based on whether the security keys of program files written to the motion system and the motion system security key match.



Copying security keys

Security keys registered to a personal computer can be imported or exported using an engineering tool for use at another personal computer. Expiry dates can be set for copied security keys.



Point

- When the project data or the security key set to a motion system cannot be imported in an engineering tool, the security key cannot be canceled with repairs or maintenance. Thus the project data can never be viewed or edited. Mitsubishi Electric accepts no responsibility for losses to customers, other individuals, or organizations as a result of not being able to view or edit project data.
- To prevent losses occurring when a personal computer at which security keys are registered malfunctions, create backups by importing registered security keys to another personal computer, or storing exported files containing registered security keys in a safe location.

Control details

The operations of the security key authentication function and the control details are shown below.

Operation target	Item	Details
Security key	Security key creating/deleting	Security key creating
		Generates a security key with an engineering tool.
	Security key copying	Security key deleting
		Deletes the security key from an engineering tool.
Project	Security key exporting	Security key exporting
		Writes a security key that can be used in the engineering tool of another personal computer to a file.
	Security key importing	Security key importing
		Registers an exported security key to an engineering tool.
Motion system	Registration of security key to program file	Registration of security key to program file
		Locks specified project data with a security key.
Motion system	Deleting security key of program file	Deleting security key of program file
		Cancels the security key lock of specified project data.
	Writing/deleting of security key to motion system	Writing of security key to motion system
		Writes a security key to a motion system.
Motion system	Deleting of security key	Deleting security key of motion system
		Deletes a security key of a motion system.
	Checking security key information	
Motion system	Preventing unauthorized program execution	
	Checks the information (key name/date of generation) of the security key registered to the motion system.	
Motion system	Prevents unauthorized program execution by verifying the security key written to the motion system, and the security key of the program file.	

Creating/deleting the security key

The creating/deleting of a security key is executed on the security key management screen of an engineering tool.

For details of the operation procedures, refer to help of an engineering tool.

■Creating the security key

Creates a new security key in the security key management screen of an engineering tool and registers it to a personal computer.

The information that the security key contains is shown below.

Item	Details
Name	The name of the security key (32 characters).
Date of generation	The date the security key was generated in an engineering tool.
Authentication code	The information for verifying the validity of the security key during security key authentication.
Password for importing ^{*1}	The password to be input when importing the security key.
Operation restrictions ^{*1}	Operation restrictions <ul style="list-style-type: none"> • Availability to re-export the security key • Availability to change the lock status of project data • Availability to write the security key to a motion system
Expiry date ^{*1}	Time period that the security can be used.

^{*1} Can be added when exporting. Newly created keys do not have operation restrictions and expiry dates. For operation restrictions and expiry dates, refer to the following.

 Page 890 Copying the security key

■Deleting the security key

Deletes the security key registered to the personal computer.

Point

When a security key registered to a personal computer is deleted without being exported, the project data that is locked by that security key can no longer be viewed or edited. Before deleting a security key on a personal computer, cancel the lock on the project data.

Copying the security key

Security keys can be copied (exported/imported) and used on a personal computer other than the personal computer on which the security key was generated.

Security keys are copied (imported/exported) on the security key management screen of an engineering tool.

For details of the operation procedures, refer to help of an engineering tool.

■Exporting the security key

Exports the security key registered to a personal computer as a file that can be imported.

An expiry date and operation restrictions can be added to the security key to be exported.

- Expiry date

When the expiry date elapses on an engineering tool, the security key becomes invalid. Programs can no longer be viewed and the security key cannot be written to a motion system. Export/import the security key again. When the expiry date of a security key in a motion system elapses, the unauthorized execution of a program is still prevented.

- Operation restriction

Restricts the operations available on the engineering tool of the personal computer that the security key is imported. For details of the operation procedures, refer to help of an engineering tool.

■Importing the security key

Imports the exported security key file to a personal computer and registers the security key.

Registering the security key to the program file

Security keys are registered to/deleted from a program file on the security key management screen of an engineering tool. For details of the operation procedures, refer to help of an engineering tool.

The name and date of generation of the security key registered to a program file in a motion system are displayed in the security key management screen of an engineering tool.

■Registering the security key to the program file

Registers the security key to a program file.

The user can select whether to register a security key to each program file or not. However, all program files in a project will have the same security key.

The files to which a security key can be set, and the details of protection are shown below.

For the other files used for control in a motion system, refer to the following.

 Page 868 Storage files

Data type	File extension	Details of protection
Motion program file	*.PRG	• Restricts viewing of program files in the project. • Restricts execution of programs in the motion system.
FB/FUN file	*.PFB	

■Deleting the security key from the program file

Deletes the security key registered to the program file.

Writing/deleting the security key to the motion system

A program can be executed by writing the same security key as the program file to the motion system.

The security key is written to/deleted from the motion system with the "Security Key Setting" screen of the engineering tool.

For details of the operation procedures, refer to help of an engineering tool.

A security key that is written to a motion system can be deleted from a personal computer that does not have the security key registered to it.

Point

- When a motion system security key is deleted, the data written to the motion system is still locked and the program cannot be executed. Project data with the lock canceled must be written to the motion system again.
- The writing/deleting of the security key of the motion system is registered in the event history.
- The name and date of generation of the security key in the motion system can be checked in the "Security Key Setting" screen of the engineering tool.

Preventing the unauthorized execution of programs

When there is a program with a security key registered in the motion system, the security key of the motion system and the security key of the program file are verified when PLC READY turns OFF to ON.

When the security keys of all program files match the security key of the motion system, the program can be executed.

When the security key of the program file does not match the security key of the motion system, or a security key is registered to the program file but there is no security key in the motion system, "Security key authentication error" (error code: 2300 to 2302H) occurs, and the motion system does not start.

The motion system operations depending on whether a security key exists or not are shown below.

Security key in the motion system	Security key in the program file	Security key match/mismatch	Ability to execute the program
Not written	Not registered	—	Program can be executed
	Registered	—	Security key authentication error occurs and program cannot be executed
Written	Not registered	—	Program can be executed
	Registered	Match	
		Mismatch	Security key authentication error occurs and program cannot be executed

Precautions

Program asset outflow cannot be prevented if a personal computer at which a security key is set is misused by a third party, and therefore customers must take the following countermeasures to protect against this.

- Personal computer theft prevention measures (use of wire locks, etc.)
- Personal computer user management (deletion of redundant user accounts, strict control of login information, adoption of fingerprint authentication, etc.)

Furthermore, if a security key is lost, locked project data cannot be viewed or edited. Mitsubishi Electric accepts no responsibility for losses to customers, other individuals, or organizations as a result of this. Customers must therefore take the following countermeasures to protect against this.

- Import registered security keys to another personal computer.
- Store exported files containing registered security keys in a safe location.

Version combinations

The versions supporting the security key authentication function are shown below.

This function can be used when the following versions of the engineering tool and motion system software are combined.

Engineering tool version		Motion system software version
GX Works3	Motion control setting function	
"1.087R" or later	"1.035M" or later	"24" or later

The operations for version combinations of the engineering tool and the motion system are shown below.

Writing/deleting the security key to the motion system

The availability of writing/deleting the security key of the motion system using the engineering tool is shown below.

Engineering tool version		Motion system software version	Details
GX Works3	Motion control setting function		
"1.087R" or later	"1.035M" or later	"24" or later	A security key can be written/deleted.
		Earlier than "24"	A security key cannot be written as the motion system is unsupported.
	Earlier than "1.035M"	"24" or later	A security key cannot be written as the engineering tool is unsupported.
		Earlier than "24"	A security key cannot be written as the engineering tool is unsupported.

Writing the project data to the motion system

The availability of writing/deleting the project data to the motion system when there is a program with a security key registered by the engineering tool is shown below.

Engineering tool version		Motion system software version	Details
GX Works3	Motion control setting function		
"1.087R" or later	"1.035M" or later	"24" or later	Project data can be written.
		Earlier than "24"	Project data cannot be written by an engineering tool.
	Earlier than "1.035M"	"24" or later	Project data cannot be written as the project data cannot be opened by an engineering tool.
		Earlier than "24"	

Reading the project data from the motion system

The availability of reading the project data with an engineering tool when there is a program with a security key registered in the motion system is shown below.

Engineering tool version		Motion system software version	Details
GX Works3	Motion control setting function		
"1.087R" or later	"1.035M" or later	"24" or later	Project data can be read.
		Earlier than "24"*2	
	Earlier than "1.035M"*1	"24" or later	Project data cannot be read as the engineering tool is unsupported.
		Earlier than "24"*2	

*1 Applies to when an engineering tool is downgraded to an unsupported version after writing a program file with a security key registered by a supported version of an engineering tool.

*2 Applies to when a motion system is downgraded to an unsupported version after writing a project file with a security key set by a supported version of a motion system.

Preventing the unauthorized execution of programs

The operations for when a security key is set to a program file and not, and the version of the motion system are shown below.

Program file	Software version of the motion system	Details
Security key set	"24" or later	Program can be executed.
	Earlier than "24"	Program cannot be executed.
No security key set	"24" or later	Program can be executed.
	Earlier than "24"	

23 MOTION MODULE SOFTWARE INSTALLATION

This chapter describes how to install software of the motion system.

Various software can be updated at once by installing the motion system software.

If needed, boot software and software can also be installed individually.

However, when installing the software which version is "07 or earlier", install it after installing boot software.

23.1 Motion System Software Installation

The software is installed in the motion system when the product is shipped. Therefore, users do not have to install the software. However, when updating or changing to the new software, users have to install the software again. The latest software can be downloaded from MITSUBISHI ELECTRIC FA Global Website.

Point

- Even if carrying out installation, programs, parameters, and absolute position data that are written in the motion system are not rewritten.
- If installation is interrupted by the following operations during installation execution, the file in installation is deleted. Execute installation again.
 - "Turning OFF the power of the motion system"
 - "Turning RUN/STOP/RESET switch of the CPU module to RESET"
 - "Turning OFF the power of the personal computer (when using the engineering tool)"
 - "Disconnecting a communication cable from the personal computer (when using the engineering tool)"
 - "Removing the SD memory card (when using SD memory cards)"
- The installed software is reflected when the power is turned ON again.
- While installation is executed, installation operation is not accepted by the other installation method. For example, while installation by the SD memory card is executed, installation executed by the engineering tool will cause an error.
- The type name and the version of the motion system software which is installed to the motion system can be checked with the engineering tool.
- The software files are protected by CRC. The consistency of the file is checked when turning on the power of the motion system again, then if an error is detected, "Add-on Library Load Error" (error code: 3205H) will occur and the system will not start. Execute installation again to install the correct file.
- The combination of the software version should be matched with the one mentioned in the MITSUBISHI ELECTRIC FA Global Website or reference below.

If the combination of the software version does not match, "Add-on Library Load Error" (error code: 3205H) occurs and the system does not start. Execute installation again with the correct combination of the software version.

☞ Page 987 List of Add-on Library

☞ Page 992 List of Boot software

Operation of this function for each system status

○: Possible, △: Possible (Restricted)

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	△ (Operation may not be possible according to the error status)

Relevant variables

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Version_BootSw	Boot Software Version	Displays the version of the boot software
Version_NetworkBootSw	Network Boot Software Version	Displays the version of the network boot software
Version_BaseSystemSw	Basic System Software Version	Displays the version of the basic system software

Software file configuration of motion system

The configuration of motion system software downloaded from MITSUBISHI ELECTRIC FA Global Website is shown below. The following files are packed in the motion system software (sw12dnn-rmtufw_□.zip).

File	
Motion system software for RD78G(H) (sw12dnn-rmtufw_□.zip)*1	
Motion system software package (RD78GSW.smpk)	
instnew	
Basic system software (baseSystem.smpk)	
Each add-on library (.mpk)	
instboot	
Boot software(.img)	

*1 "□" is the version of the Basic system software.

The following files are packed in the motion software package (RD78GSW.smpk).

File	
Motion system software for RD78G(H) (RD78GSW.smpk)	
Basic system software	
Each add-on	


At installing, expanding is performed as follows on the motion system.

File	
/sys drive	
Basic system software	
Each add-on	

Boot software will not be recognized as a drive.

For file configuration of the add-on that is to be installed in the motion system, refer to the following.

📖 Page 120 Add-on Function



How to batch install the motion system software


This section describes how to batch install motion system software.

- When installing the motion system software from the motion system which version is "16" or later, the methods can be selected either installing from the engineering tool or installing from the SD memory card.
- When installing the motion system software from the motion system which version is "14" or earlier, install from the SD memory card.

Installation procedure using the engineering tool

The batch installation procedure of the motion system software using engineering tool is shown below.

Point When installing from the engineering tool, the version "1.020W" or later of Motion control setting function is required.



*1 "□" is the version of the Basic system software.

Install the software according to the instructions shown on "Motion Control Setting Function" window on GX Works3. For details, refer to Help of Motion Control Setting Function on GX Works3.

Installation procedure using the SD memory card

The batch installation procedure of the motion system software using SD memory card is shown below.


- To install the version of motion system software, "08" or later, install the software and the boot software simultaneously by batch installation. When the batch installation is executed, the separate installation of the software and the boot software is not required.
- To install the version of motion system software, "07" or earlier, install the software and the boot software separately because the batch installation is not supported. For the installation, refer to the following.

☞ Page 901 Installation of Basic System Software and Add-on Libraries

☞ Page 905 How to install the boot software

Point

To install the software separately, update the boot software first, and then install the software.



- Use an SD memory card formatted by the CPU module. When an SD memory card formatted by the Windows format function is used, the motion system software installation may fail.
- When formatting an SD memory card using the CPU module, use the CPU memory operation function in GX Works3. For details on operation, refer to the following.
 GX Works3 Operating Manual
- Do not install the folder combined [instnew] and [instboot] in the different motion software packages.
- When installation could not be normally completed because an error was detected after installation was started, the RUN LED turns OFF, and the PROGRAM RUN LED and the CARD READY LED are flashing (every 200ms). After dealing with the following errors (1) and (2), carry out installation again.
 (1) When reading the SD memory card is abnormal, check the SD memory card.
 (2) When the installation file is abnormal or when it cannot be recognized, check the installation file.
- The forced stop function of the SD memory card cannot be used during installation execution from the SD memory card. Do not remove the SD memory card during installation.
- The READY and the synchronization flag do not turn ON during installation execution from the SD memory card.

■LED displays during motion system software installation

The following shows the LED displays during motion system software installation.

Motion system status	LED display			Description	Action
	RUN	PROGRAM RUN	CARD READY		
Normal	Flashing (every 500ms)	Flashing (every 500ms)	OFF	Executing the installation.	Wait until the installation is completed.
	OFF	ON	ON	The installation is normally completed.	Turn the power of motion system OFF to ON, and check that the CPU module can be normally turned RUN/STOP.
Error	OFF	Flashing (every 200ms)	Flashing (every 200ms)	The installation is completed with an error.	Turn the power of motion system OFF to ON, and execute the installation again.

Checking software version

The installed software version can be checked with the engineering tool.

Checking the basic system software version

The basic system software version can be checked with Basic System Software Version (System.Md.Version_BaseSystemSw) or the engineering tool.

■Checking with the engineering tool

Check on the product information list screen.

[Diagnostics] menu ⇒ [System monitor] ⇒ [Product Information List] button

The basic system software and boot software (for control / for network) versions are displayed.

When the version of motion system software is "07" or earlier, only the version (2 digits from the left) of the boot software (for network) is displayed immediately after start (add-on loading) of the Motion module.

Product Information List

	Start I/O No.	Points	Module Name	Series	Error Status	
Basic-Power Supply	-	-	R64P	-	-	Power
Basic-CPU	3E00	-	R04CPU	IQ-R	-	CPU
Basic-I/O 0	0000	32 Point	RD78G64	IQ-R	-	CC-L
Basic-I/O 1	-	-	Empty	-	-	-
Basic-I/O 2	-	-	Empty	-	-	-
Basic-I/O 3	-	-	Empty	-	-	-
Basic-I/O 4	-	-	Empty	-	-	-
Basic-I/O 5	-	-	Empty	-	-	-
Basic-I/O 6	-	-	Empty	-	-	-
Basic-I/O 7	-	-	Empty	-	-	-

Create File...

Production information of the Motion module

IP Address (Port1 IPv4)	IP Address (Port2 IPv4)	Module Synchron ous Status	Firmware Version	Production information
192.168.3.39	-	-	53	
192.168.3.253	-	-	131328	
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-

Close

131328

The basic system software version (two digits)

The boot software (for control) version (two digits)

The boot software (for network) version (two digits)

Checking the add-on version


Check the add-on version on the engineering tool.

■Checking with the engineering tool

Check on the add-on management screen.

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ [Target module] ⇒ [Module Extended Parameter] ⇒ [Motion Control Setting Function] ⇒ [Tool] menu ⇒ [Add-on Management]

The add-on version is displayed.



Checking the boot software version

The boot software version can be checked with Boot Software Version (System.Md.Version_BootSw).

Precautions

Relevant add-ons

This function can be performed without add-ons.

System memory capacity

System memory is not required for the software installation.

23.2 Installation of Basic System Software and Add-on Libraries

How to install the basic system software and Add-on libraries


The procedure for installing the software is shown below.

The security function is valid regardless of the installation method. Installation cannot be carried out depending on the setting. For details, refer to the following.

☞ Page 886 SECURITY

Installation procedure using the engineering tool

The following shows a procedure to install the motion software by using the engineering tool.




Install the software according to the instructions shown on "Motion Control Setting Function" window on GX Works3. For details, refer to Help of Motion Control Setting Function on GX Works3.

Point

- The installed files can be verified with the files on the personal computer by using Motion Control Setting Function on GX Works3.
- Each function stored in the motion software package can be selected for the execution of the installation.
- Add-ons which have been installed are not deleted.

Installation procedure using the SD memory card

The following shows a procedure to install the software by using an SD memory card.



Point

- The motion software creates the [inst] folder or [instnew] folder in the root of the SD memory card. Store the file in the folder.
 - (1) [instnew] folder: When newly installing the file (The file is transmitted after the system drive is formatted.)
 - (2) [inst] folder: When updating (overwriting) and when installing an additional module
- When installation could not be normally completed because an error was detected after installation was started, the RUN LED turns OFF, and the PROGRAM RUN LED and the CARD READY LED are flashing (every 200ms). After dealing with the following errors (1) to (3), carry out installation again.
 - (1) When reading the SD memory card is abnormal, check the SD memory card.
 - (2) When the installation file is abnormal or when it cannot be recognized, check the installation file.
 - (3) When the system folder is abnormal, format it with instnew then install the file again.
- The forced stop function of the SD memory card cannot be used during installation execution from the SD memory card. Do not remove the SD memory card during installation.
- The READY and the synchronization flag do not turn ON during installation execution from the SD memory card.

■LED displays during basic system software installation

The following shows the LED displays during basic system software installation.

Motion system status	LED display			Description	Action
	RUN	PROGRAM RUN	CARD READY		
Normal	Flashing (every 500ms)	Flashing (every 500ms)	OFF	Executing the installation	Wait until software installation is completed.
	OFF	ON	ON	The installation is normally completed.	Turn the power of motion system OFF to ON, and check that the CPU module can be normally turned RUN/STOP.
Error	OFF	Flashing (every 200ms)	Flashing (every 200ms)	The installation is completed with an error.	Turn the power of motion system OFF to ON, or reset the system, then execute software installation again.

23.3 Boot Software Installation

This function updates the boot software which starts up the motion system. It is used when the boot software needs to be updated due to the restrictions of the motion software.

The latest boot software can be downloaded from MITSUBISHI ELECTRIC FA Global Website.

Point

- Even though update is carried out, programs, parameters, and the absolute position data written in the motion system will not be changed.
 - If update processing is interrupted during updating execution by the following operation, a file which is being updated will be deleted. Execute update again.
 - "Turning OFF the power of the motion system"
 - "Turning RUN/STOP/RESET switch of the CPU module to RESET"
 - "Removing the SD memory card (when using SD memory cards)"
 - The updated software is reflected when the power is turned ON again.
 - While update is executed, update operation is not accepted by the other installation method.
 - Version of the boot software which is installed to the motion system can be checked with Boot Software Version (System.Md.Version_BootSw).
 - The boot software is protected by CRC. The consistency of the data is checked when turning on the power of the motion system again, then if an error is detected, the system will not start. Execute update again.
-


How to install the boot software

The method to install boot software is shown below.

- When installing the motion system software from the motion system which boot software version is "07" or later, the methods can be selected either installing from the engineering tool or installing from the SD memory card.
- When installing the motion system software from the motion system which boot software version is "06" or earlier, install from the SD memory card.

Installation procedure using the engineering tool


This section describes the batch installation procedure of the boot software using engineering tool.



Install the software according to the instructions shown on "Motion Control Setting Function" window on GX Works3. For details, refer to Help of Motion Control Setting Function on GX Works3.

Installation procedure using the SD memory card

The following shows a procedure to install the boot software by using an SD memory card.



- The boot software creates the [instboot] folder in the root of the SD memory card. Store the file in the folder.
- When the update did not complete successfully because an error was detected after update of the boot software was started, the RUN LED turns OFF, and the PROGRAM RUN LED and the CARD READY LED are flashing (every 200ms). Install the software again after clearing the following errors (1) and (2).
 - (1) When reading the SD memory card is abnormal, check the SD memory card.
 - (2) When the boot software file is abnormal or when it cannot be recognized, check the boot software file.
- If the boot software updating cannot be completed successfully, the RUN LED turns OFF or the ERR LED turns OFF or flashing (every 200ms) even if the Motion module is powered ON and the Motion module might not be recognized.
 In this case, insert an SD memory card which the boot software is stored into the slot of the Motion module and power ON the motion system while pressing the SD memory card access control switch. In that condition, release a hand from the SD memory card access control switch after the ERR LED turns flashing (every 200ms) and the boot software can be recovered by turning OFF to ON the power of the Motion module after waiting for five minutes or longer.
 To restore the boot software, follow the procedure above after temporarily changing the rising edge time in the entire system to 15 [s] or less in the system configuration.
- To install the version "07" or earlier of the motion system software from the SD memory card, boot software update and software installation cannot be executed simultaneously. When there are both folders, only the boot software update is executed.
- The forced stop function of the SD memory card cannot be used during update execution from the SD memory card. Do not remove the SD memory card during update.
- The READY and the synchronization flag do not turn ON during installation execution from the SD memory card.

■LED displays during boot software update

The following shows the LED displays during boot software update.

Motion system status	LED display			Description	Action
	RUN	PROGRAM RUN	CARD READY		
Normal	Flashing (every 500ms)	Flashing (every 500ms)	OFF	Updating the boot software	Wait until boot software update is completed.
	OFF	ON	ON	Boot software update is normally completed.	Turn the power of the motion system OFF to ON, and check that the motion system can be normally turned RUN/ STOP.
Error	OFF	Flashing (every 200ms)	Flashing (every 200ms)	Boot software update is completed with an error.	Turn the power of the motion system OFF to ON, then execute boot software update again.

The boot software version

For the boot software versions, refer to the following.

☞ Page 992 List of Boot software

24 TROUBLESHOOTING

24.1 LED Control

The status of the motion system can be checked by the following.

The following lists the LED display specifications of the Motion module.

Description differs during software installation. For details, refer to the following.

☞ Page 894 MOTION MODULE SOFTWARE INSTALLATION

Name	Description
RUN LED	Displays the operation status. <ul style="list-style-type: none">• ON: Operating normally• Flashing (every 500ms): Clear / Quick clearing• OFF: Error occurrence^{*1} or initializing
ERR LED	Displays the error status. <ul style="list-style-type: none">• OFF: Operating normally• ON: Error occurrence^{*1}• Flashing (every 200 [ms]): Error occurrence^{*1}• Flashing (every 500 [ms]): A data link faulty station is detected.
PROGRAM RUN LED	Displays the execution status of the built-in program. <ul style="list-style-type: none">• ON: Executing program• OFF: Stopping program
CARD READY LED	Displays the status of an SD memory card. <ul style="list-style-type: none">• ON: SD memory card is usable• Flashing: Preparing• OFF: No SD memory card inserted
CARD ACCESS LED	Displays the access status of an SD memory card. <ul style="list-style-type: none">• ON: Accessing SD memory card• OFF: Not accessing SD memory card
D LINK LED	Displays the data link status. <ul style="list-style-type: none">• ON: Data link (cyclic transmission being performed)• Flashing: Data link (cyclic transmission stopped)• OFF: Data link not performed (disconnection)
SD/RD LED	Displays the data communication status. <ul style="list-style-type: none">• Flashing: Communicating data^{*2}• OFF: Not communicating data^{*2}
L ER LED	Displays the port status. <ul style="list-style-type: none">■When using RD78G<ul style="list-style-type: none">• ON: Abnormal data received• OFF: Normal data received■When using RD78GH<ul style="list-style-type: none"><When using add-on baseSystem version "1.28" or earlier><ul style="list-style-type: none">• ON: Abnormal data received• OFF: Normal data received<When using add-on baseSystem version "1.30" or later><ul style="list-style-type: none">• ON: Abnormal data received or loopback being performed^{*3}• OFF: Normal data received and loopback not performed
LINK LED	Displays the link status. <ul style="list-style-type: none">• ON: Link-up• OFF: Link-down

^{*1} Includes the cyclic transmission data and the transient transmission data of CC-Link IE TSN.

When multiple errors occur, the error status is displayed in the order of major, moderate, and minor.

RUN LED	ERR LED	Error status	Description
OFF	ON or flickering	Major error	An error such as hardware failure or memory failure. The module stops operating.
ON	Flashing	Moderate error	An error, such as parameter error, which affects module operation. The module stops operating.
ON	ON	Minor error	An error such as communication, positioning control and program failure. The module continues operating.

^{*2} Error status can be determined by status of the RUN LED and the ERR LED.

^{*3} If a station for which loopback is being performed is a station whose station number has not been set, the L ER LED of that station does not turn on.

If a station whose station number has not been set enters the ring structure, the L ER LED of the loopback station does not turn on.

24.2 Checking Errors and Warnings

Errors and warnings occurred in the motion system can be checked by the following methods.

Method	Details
Event history of the engineering tool	It can be checked by the event history window of the engineering tool. For details, refer to the following. GX Works3 Operating Manual
Module diagnostic of the engineering tool	It can be checked by the module diagnostic window of the engineering tool. For details, refer to the following. GX Works3 Operating Manual
Motion event history of the engineering tool	It can be checked by the motion event history window of the engineering tool (Motion control setting function). For details, refer to the following. Page 819 History Data
Monitor data (Label)	The detection flag of error/warning and the error code/warning code can be checked by the label of axis, axes group, and system. The CPU module can refer to these labels by the module label or the dedicated instruction.

Operation of this function for each system status

○: Possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	○
Major error	○

Overall block diagram

Refer to the following.

Page 819 History Data

Relevant variables

Axis monitor data (AxisName.Md.)

Variable/Structure name	Name	Details
Warning	Axis Warning Detection	Becomes TRUE at axis warning occurrence.
Error	Axis Error Detection	Becomes TRUE at axis error occurrence.
DriverError	Drive Unit Error Detection	Becomes TRUE at drive unit error occurrence.
WarningID	Axis Warning Code	Stores the warning code at axis warning occurrence.
ErrorID	Axis Error Code	Stores the error code at axis error occurrence.
DriverErrorID	Drive Unit Error Code	<p>Stores upper 16 bits of "Current alarm (2A41H)" of the object data at drive unit error occurrence.</p> <p><Example> For MR-J5(W)-G</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Drive Unit Error Code (AxisName.Md.DriverErrorID)</p> <div style="border: 1px dashed black; padding: 5px; display: inline-block;">0 0 3 5</div> </div> <div style="text-align: center;"> <p>Drive Unit Error Detail Code (AxisName.Md.DriverErrorDetailID)</p> <div style="border: 1px dashed black; padding: 5px; display: inline-block;">0 0 0 1</div> </div> </div> <p style="margin-left: 100px;">Axis monitor</p> <div style="margin-left: 150px;"> <p>→ Driver operation alarm</p> <p>→ Detail No.</p> </div> <p>• Stores "0035H" when servo alarm [AL.035. 1_Command frequency error] occurs at drive unit.</p>
DriverErrorDetailID	Drive Unit Error Detail Code	<p>Stores lower 16 bits of "Current alarm (2A41H)" of the object data at drive unit error occurrence.</p> <p><Example> For MR-J5(W)-G</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Drive Unit Error Code (AxisName.Md.DriverErrorID)</p> <div style="border: 1px dashed black; padding: 5px; display: inline-block;">0 0 3 5</div> </div> <div style="text-align: center;"> <p>Drive Unit Error Detail Code (AxisName.Md.DriverErrorDetailID)</p> <div style="border: 1px dashed black; padding: 5px; display: inline-block;">0 0 0 1</div> </div> </div> <p style="margin-left: 100px;">Axis monitor</p> <div style="margin-left: 150px;"> <p>→ Driver operation alarm</p> <p>→ Detail No.</p> </div> <p>• Stores "0001H" when servo alarm [AL.035. 1_Command frequency error] occurs at drive unit.</p>

Axes group monitor data (AxesGroupName.Md.)

Variable/Structure name	Name	Details
Warning	Axes Group Warning Detection	Becomes TRUE at axes group warning occurrence.
Error	Axes Group Error Detection	Becomes TRUE at axes group error occurrence.
WarningID	Axes Group Warning Code	Stores the warning code at axes group warning occurrence.
ErrorID	Axes Group Error Code	Stores the error code at axes group error occurrence.

System parameter constant (System.PrConst.)

Variable/Structure name	Name	Details
ExcludeWarning	Excluded Warning	<p>Sets the warning which is not to be detected.</p> <p><Example></p> <ul style="list-style-type: none"> • "": Not set • Not detect the warnings of "0x1000, 0x1001": 0x1000, 0x1001. • Not detect the warnings from "0x1000-0x1010": 0x1000 to 0x1010.

System monitor data (System.Md.)

Variable/Structure name	Name	Details
Warning	Motion Area System Warning Detection	Becomes TRUE at warning occurrence.
Error	Motion Area System Error Detection	Becomes TRUE at error occurrence.
NetworkError	Network Area Error Detection	Becomes TRUE at network error occurrence.
WarningID	Latest Motion Area System Warning Code	Stores the latest warning code.
ErrorID	Latest Motion Area System Error Code	Stores the latest error code.
NetworkErrorID	Network Area Error Code	Stores the error code at network error occurrence.

Control details

The latest error code occurred in motion is output in Latest Motion Area System Error Code (System.Md.ErrorID). When multiple errors occur, follow the conditions below whether the error code output to Latest Motion Area System Error Code (System.Md.ErrorID is updated).

Occurring error	Occurred error					
Latest Motion Area System Error Code (System.Md.ErrorID)	Axis Error Code (AxisName.Md.ErrorID)/Axes Group Error Code (AxesGroupName.Md.ErrorID)/Latest Motion Area System Error Code (System.Md.ErrorID)			Network Area Error Code (System.Md.NetworkErrorID)		
	Minor error	Moderate error	Major error	Minor error	Moderate error	Major error
No error	Updating	Updating	Updating	Updating	Updating	Updating
Minor error	Updating	Updating	Updating	Not updating	Updating	Updating
Moderate error	Not updating	Updating	Updating	Not updating	Not updating	Updating
Major error	Not updating	Not updating	Updating	Not updating	Not updating	Not updating

24

Excluded warning setting

- The specified warning can be ignored by setting Excluded Warning (System.PrConst.ExcludeWarning).
- When the warning set to Excluded Warning (System.PrConst.ExcludeWarning) has occurred, the relevant variables and each histories are not updated.
- If set Excluded Warning (System.PrConst.ExcludeWarning), each checking process to detect warnings is not omitted, so that the processing time is not reduced.
- If set the error code to Excluded Warning (System.PrConst.ExcludeWarning), the error is not excluded.

Precautions

Necessary object data

■PDO

- CurrentAlarm (monitor of drive unit errors)

■SDO

None

Relevant add-ons

The following add-on is required to use this function.

- MotionControl_General

24.3 Error and Warning Reset

Errors and warnings occurred in the motion system can be reset by the following methods.

Operation of this function for each system status

○: Possible, △: Possible (restricted), ×: Not possible

Status	Operation availability
STOP	○
RUN	○
Moderate error	△ (only for the axis and the axes group error reset)
Major error	×

Data to be reset

■System error reset

- All errors/warnings

Error type	Description	Variable name
System	Motion area system error detection	System.Md.Error
	Latest motion area system error code	System.Md.ErrorID
	Motion area system warning detection	System.Md.Warning
	Latest motion area system warning code	System.Md.WarningID
	Network area error detection	System.Md.NetworkError
	Network area error code	System.Md.NetworkErrorID
Axis	Axis warning detection	<u>AxisName</u> .Md.Warning
	Axis error code	<u>AxisName</u> .Md.ErrorID
	Axis error detection	<u>AxisName</u> .Md.Error
	Axis warning code	<u>AxisName</u> .Md.WarningID
	Drive unit error detection	<u>AxisName</u> .Md.DriverError
	Drive unit error code	<u>AxisName</u> .Md.DriverErrorID
	Drive unit error detail code	<u>AxisName</u> .Md.DriverErrorDetailID
Axes group	Axes group warning detection	<u>AxesGroupName</u> .Md.Warning
	Axes group warning code	<u>AxesGroupName</u> .Md.WarningID
	Axes group error detection	<u>AxesGroupName</u> .Md.Error
	Axes group error code	<u>AxesGroupName</u> .Md.ErrorID

■Axis error reset

- Axis error/warning

Error type	Description	Variable name
Axis	Axis warning detection	<u>AxisName</u> .Md.Warning
	Axis error code	<u>AxisName</u> .Md.ErrorID
	Axis error detection	<u>AxisName</u> .Md.Error
	Axis warning code	<u>AxisName</u> .Md.WarningID
	Drive unit error detection	<u>AxisName</u> .Md.DriverError
	Drive unit error code	<u>AxisName</u> .Md.DriverErrorID
	Drive unit error detail code	<u>AxisName</u> .Md.DriverErrorDetailID

■ Axes group error reset

- Axes group error/warning

Error type	Description	Variable name
Axes group	Axes group warning detection	<u>AxisGroupName</u> .Md.Warning
	Axes group warning code	<u>AxisGroupName</u> .Md.WarningID
	Axes group error detection	<u>AxisGroupName</u> .Md.Error
	Axes group error code	<u>AxisGroupName</u> .Md.ErrorID
	Axis warning detection* ¹	<u>AxisName</u> .Md.Warning
	Axis warning code* ¹	<u>AxisName</u> .Md.WarningID
	Axis error detection* ¹	<u>AxisName</u> .Md.Error
	Axis error code* ¹	<u>AxisName</u> .Md.ErrorID
	Drive unit error detection* ¹	<u>AxisName</u> .Md.DriverError
	Drive unit error code* ¹	<u>AxisName</u> .Md.DriverErrorID
	Drive unit error detail code* ¹	<u>AxisName</u> .Md.DriverErrorDetailID

*1 Only axis which belongs to axes group

Relevant variables

Axis control data (AxisName.Cd.)

Variable/Structure name	Name	Details
ErrorReset	Axis Error Reset	Resets axis errors/warnings/drive unit errors.

Axes group control data (AxisGroupName.Cd.)

Variable/Structure name	Name	Details
ErrorReset	Axes Group Error Reset	Resets axes group errors/warnings.

System control data (System.Cd.)

Variable/Structure name	Name	Details
ErrorReset	System Error Reset	Resets all errors and warnings.

Relevant FBs

For details on Motion control FBs, refer to the following.

📖 MELSEC iQ-R Programming Manual (Motion Control Function Blocks)

Motion control FB	Name	Description
MCv_MotionErrorReset	Motion Error Reset	Resets all errors and warnings of the Motion system.
MC_Reset	Axis Error Reset	Resets errors and warnings of the axis.
MC_GroupReset	Axes Group Error Reset	Resets errors and warnings of the axes group and each axis in the axes group.


System error reset

Reset all errors/warnings of the motion system. There are System Error Reset (System.Cd.ErrorReset), MCv_MotionErrorReset (Motion Error Reset) and clear error button on the module diagnostics window of GX Works3 as a reset method. (System Error Reset (System.Cd.ErrorReset) does not become TRUE as the reset is performed by clear error button.)


Control details

■System Error Reset (System.Cd.ErrorReset)

- Reset is executed at the rising edge detection of System Error Reset (System.Cd.ErrorReset).
- When the reset is completed, System Error Reset (System.Cd.ErrorReset) becomes FALSE.
- If the error reset is not succeeded, System Error Reset (System.Cd.ErrorReset) remains TRUE.
- If the error reset is executed while the axis or the axis group is operating, the error reset is not executed.
 - When the FB is normally completed (When the error reset is succeeded)




■When an error occurs (When the error reset is failed)




■MCv_MotionErrorReset (Motion Error Reset)

- The FB is executed with Execute command (Execute) = TRUE and Executing (Busy) becomes TRUE as the process starts, and then System Error Reset (System.Cd.ErrorReset) is set to TRUE.
- Executing (Busy) becomes FALSE and Execution completion (Done) becomes TRUE as clearing the errors/warnings of the motion system is completed.
- The errors/warnings are not cleared if Execute command (Execute) becomes TRUE while the error/warning causes still remain. In this case, Abortion of execution (CommandAborted) becomes TRUE and System Error Reset (System.Cd.ErrorReset) is set to FALSE if the errors are not cleared within two [s] after command executed. Temporarily set Execute command (Execute) to FALSE, remove the causes of the errors/warnings, then set Execute command (Execute) to TRUE again.

■When the FB is normally completed



■At timeout



Precautions

- Do not operate System Error Reset (System.Cd.ErrorReset) directly while System Error Reset (SYSTEM.Cd.ErrorReset) is executed.
- Use MCv_MotionErrorReset (Motion Error Reset) without operating System Error Reset (System.Cd.ErrorReset) to perform the error reset from the CPU module.


Axis error reset

Reset the error/warning of a single axis and drive unit error by Axis Error Reset (AxisName.Cd.ErrorReset).

Control details

■Axis Error Reset (AxisName.Cd.ErrorReset)

- Reset is executed at the rising edge detection of Axis Error Reset (AxisName.Cd.ErrorReset).
- When the reset is completed, Axis Error Reset (AxisName.Cd.ErrorReset) becomes FALSE.
- The error reset is not executed if it is executed during axis operation. The error monitor is reset when the axis is stopped completely and Axis Error Reset (AxisName.Cd.ErrorReset) is TRUE.




■MC_Reset (Axis Error Reset)


- The FB is executed with Execute command (Execute) = TRUE and Executing (Busy) becomes TRUE as the process starts, and then Axis Error Reset (AxisName.Cd.ErrorReset) of the target axis is set to TRUE.
- Executing (Busy) becomes FALSE and Execution completion (Done) becomes TRUE as clearing the errors/warnings of the axis is completed.
- Executing (Busy) is set to FALSE and Execution completion (Done) becomes TRUE after the warnings are cleared if execution is carried out as the axis status (AxisName.Md.AxisStatus) is "1: Stopping on error (ErrorStop)".
- The errors/warnings are not cleared if Execute command (Execute) is set to TRUE while the error/warning causes of the axis still remain. If the errors are not cleared within 1 [s] after command executed, Abortion of execution (CommandAborted) becomes TRUE. Set Execute command (Execute) to FALSE temporarily to clear the error/warning causes and set Execute command (Execute) to TRUE again.
- If the error occurs in the FB, Error (Error) is set to TRUE and the error code is stored in Error code (ErrorID). For details on error codes, refer to the following.

☞ Page 908 TROUBLESHOOTING

■When the FB is normally completed



■At timeout



Precautions

- Do not operate Axis Error Reset (AxisName.Cd.ErrorReset) directly while MC_Reset (Axis Error Reset) is executed.
- Use MC_Reset (Axis Error Reset) without operating Axis Error Reset (AxisName.Cd.ErrorReset) to perform the error reset from the CPU module.


Axes group error reset

Reset the error/warning of the axes group by Axes Group Error Reset (AxesGroupName.Cd.ErrorReset).
Reset also each axis error which belongs to the axes group in addition to the error/warning of the axes group.

Control details

■Axes Group Error Reset (AxesGroupName.Cd.ErrorReset)

- Reset is executed at the rising edge detection of Axes Group Error Reset (AxesGroupName.Cd.ErrorReset).
- When the reset is completed, Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) becomes FALSE.
- When the error reset of the configuration axis is not completed, the error reset of the axes group is not completed.
- If the error reset is not succeeded, Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) remains TRUE.
- The error reset is not executed if it is executed during axes group operation. The error monitor is reset when the axes group is stopped completely and Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) is TRUE.
- The error reset can be canceled by changing Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) to FALSE.




MC_GroupReset (Axes Group Error Reset)


- As the process start by executing this FB at detecting rising edge of Execute command (Execute), Executing (Busy) becomes TRUE, and then Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) of the target axes group is set to TRUE.
- Executing (Busy) becomes FALSE and Execution completion (Done) becomes TRUE as clearing the errors/warnings of the axis and the axes group is completed.
- Executing (Busy) becomes FALSE and Execution completion (Done) becomes TRUE after the warnings are cleared if execution is carried out as the axes group status (AxesGroupName.Md.GroupStatus) is not "1: Stopping on error (GroupErrorStop)".
- The errors/warnings are not cleared if Execute command (Execute) is set to TRUE while the error/warning causes still remain. In this case, Abortion of execution (CommandAborted) becomes TRUE and becomes FALSE Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) of the target axes group if the errors are not cleared within 1 [s] after command executed. Set Execute command (Execute) to FALSE temporarily to clear the error/warning causes and set Execute command (Execute) to TRUE again.
- If the error occurs in the FB, Error (Error) is set to TRUE and the error code is stored in Error code (ErrorID). For details of error codes, refer to the following.

Page 908 TROUBLESHOOTING

■When the FB is normally completed



■At timeout



Precautions

- Do not operate Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) directly while MC_GroupReset (Axes Group Error Reset) is executed.
- Use MC_GroupReset (Axes Group Error Reset) without operating Axes Group Error Reset (AxesGroupName.Cd.ErrorReset) to perform the error reset from the CPU module.

Precautions

Necessary object data

■PDO

None

■SDO

- Reset alarm (2A46H)*¹

*¹ For using the real drive axis, the real encoder axis

Relevant add-ons

The following add-on is required to use this function.

- AXIS
- MotionControl_General*¹
- ServoDriver_CANopen*²

*¹ For using the FBs in Relevant FBs

- MCv_MotionErrorReset (Motion Error Reset)
- MC_Reset (Axis Error Reset)
- MC_GroupReset (Axes Group Error Reset)

*² For using the real drive axis, the real encoder axis

24.4 Troubleshooting by Symptom

This section describes troubleshooting for the Motion module.

Servo ON failed

When Servo ON failed, check the following items.

Check item		Action
Are both MC_Power (Operation Available) and MCv_AllPower (All Axes Operation Available) being used?		Check whether both FBs perform Servo ON or not.
MCv_AllPower (All Axes Operation Available) is executed from the PLC CPU	Is I/O Number (StartIO) for the target Motion module set?	Set I/O Number (StartIO) for the target Motion module.
Device label of MR-J5(W)-G or MR-JET-G is set	In network I/O setting, is device label (Controlword of data type RWw) of MR-J5(W)-G or MR-JET-G targeted labeling?	Clear the device label (Controlword of data type RWw) of MR-J5(W)-G or MR-JET-G from labeling target.

A motor does not rotate

When a motor does not rotate, check the following items.

Check item		Action
Servo ON is TRUE	Is Driver unit conversion numerator/Driver unit conversion denominator being set?	Convert machine feed value to the set value of the driver unit by using driver unit conversion function.
Acceleration/Deceleration method is set to Acceleration/Deceleration specification method (default)	Is Acceleration or Deceleration set as Acceleration (Acceleration)/Deceleration (Deceleration), not acceleration/deceleration time?	Correct the setting value of acceleration/deceleration.

24.5 List of Warning Codes

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D00H	Axis	Absolute Position Data Incorrect Warning	<p>The absolute position data was incorrect at current position restoration for the following causes.</p> <ul style="list-style-type: none"> • The axis type was changed. • The absolute position data was erased. • The homing request was TRUE at backup. • Driver unit conversion of the axis (numerator/denominator) was changed. • Machine homing was started, but not completed properly. • "Absolute position erased" drive unit side of the real drive axis or the scale measurement encoder of the real encoder axis was detected. • Object data "Polarity(607EH)" b7: position polarity was changed on the real drive axis. • Object data "HomeOffset (607CH)" was changed on the real drive axis. • The connected drive unit was changed on the real drive axis. Alternatively, the encoder resolution of the connected driver device was changed. • The encoder resolution of the scale measurement encoder was changed on the real encoder axis. 	During control	The current position is restored with the same content as the incremental system, and the homing request becomes TRUE.	Please execute homing.
0D01H	Axis	Start during Operation Warning	An instruction that cannot start during operation was executed.	During control	Do not start after the execution of FB is interrupted.	Start when axis is Standstill.
0D02H	Axis	JOG Command Input at Both Directions Warning	JogForward and JogBackward became TRUE at the same time.	At start During control	<p>■At start Do not start after the execution of FB is interrupted.</p> <p>■During control Decelerates and continues stop/wait until the other JOG command becomes FALSE.</p>	Adjust settings so that JogForward and JogBackward do not become TRUE at the same time.
0D03H	Axis/Axes group	Velocity Limit Value Over Warning	<p>The target velocity exceeded the following when changing velocity/velocity override factor, or velocity exceeded the following during control.</p> <ul style="list-style-type: none"> • Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) (Detail Code: 0001H) • Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) (Detail Code: 0002H) • Velocity Limit Value (AxesGroupName.Pr.VelocityLimit) (Detail Code: 0003H) 	At control change During control	<p>■At control change Continues the operation at the previous speed.</p> <p>■During control Continues the operation over the speed limit.</p>	<p>Set the velocity within the following.</p> <ul style="list-style-type: none"> • Positive Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Positive) • Negative Direction Velocity Limit Value (AxisName.Pr.VelocityLimit_Negative) • Velocity Limit Value (AxesGroupName.Pr.VelocityLimit)

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D04H	Axis/Axes group	Acceleration Time Limit Over Warning	Acceleration time exceeded 8400 [s] when changing velocity/acceleration (acceleration/deceleration time)/velocity override factor/acceleration override factor.	During control	Continues the operation at the previous speed/acceleration (acceleration/deceleration time).	Set velocity/acceleration (acceleration/deceleration time)/velocity override factor/acceleration override factor so that acceleration time does not exceed 8400 [s].
0D05H	Axis/Axes group	Deceleration Time Limit Over Warning	The following occurred when changing velocity/deceleration (acceleration/deceleration time)/velocity override factor/acceleration override factor. <ul style="list-style-type: none"> Deceleration time exceeded 8400 [s]. The deceleration time for automatically decelerating from the target velocity exceeded 8400 [s]. 	During control	Continues the operation at the previous speed/deceleration (acceleration/deceleration time).	Set velocity/deceleration (acceleration/deceleration time)/velocity override factor/acceleration override factor as follows. <ul style="list-style-type: none"> Adjust settings so that the deceleration time does not exceed 8400 [s]. Adjust settings so that the deceleration time for automatically decelerating from the target velocity does not exceed 8400 [s].
0D06H	Axis/Axes group	Acceleration Limit Value Over Warning	Target acceleration exceeded <u>AxisName(AxesGroupName).Pr.AccelerationLimit</u> when changing acceleration/acceleration override factor.	During control	Continues the operation at the previous acceleration.	Set target acceleration so that it does not exceed <u>AxisName(AxesGroupName).Pr.AccelerationLimit</u> .
0D07H	Axis/Axes group	Deceleration Limit Value Over Warning	Target deceleration exceeded <u>AxisName(AxesGroupName).Pr.DecelerationLimit</u> when changing deceleration/acceleration override factor or when a stop cause occurred.	During control	<p>■At control change Continues the operation at the previous deceleration.</p> <p>■At stop cause occurrence Operates at the deceleration limit value.</p>	Set target deceleration so that it does not exceed <u>AxisName(AxesGroupName).Pr.DecelerationLimit</u> .
0D08H	Axis/Axes group	Position Command Unit Mismatch Warning	<u>AxisName(AxesGroupName).Pr.Unit_Position</u> has been set to different values between an axes group and the interpolation axes.	At start / At multiple start	—	Set the same value to <u>AxisName(AxesGroupName).Pr.Unit_Position</u> for the axes group and interpolation axes.
0D09H	Axis	Out of Forward Direction Torque Limit Value Specification Range Warning	The value is out of range for <u>AxisName.Cd.TorqueLimit_Positive</u> .	During control	Continues the operation with the previous torque limit value.	Set <u>AxisName.Cd.TorqueLimit_Positive</u> within the range.
0D0AH	Axis	Out of Reverse Direction Torque Limit Value Specification Range Warning	The value is out of range for <u>AxisName.Cd.TorqueLimit_Negative</u> .	During control	Continues the operation with the previous torque limit value.	Set <u>AxisName.Cd.TorqueLimit_Negative</u> within the range.
0D0BH	Axis/Axes group	Out of Velocity Override Factor Range Warning	The value is out of range for <u>AxisName(AxesGroupName).Cd.VelocityOverride</u> .	During control	Continues the operation with the previous value.	Set <u>AxisName(AxesGroupName).Cd.VelocityOverride</u> within the range.
0D0CH	Axis/Axes group	Out of Acceleration Override Factor Range Warning	The value is out of range for <u>AxisName(AxesGroupName).Cd.AccelerationOverride</u> .	During control	Continues the operation with the previous value.	Set <u>AxisName(AxesGroupName).Cd.AccelerationOverride</u> within the range.
0D0DH	Axis/Axes group	Out of Position/Distance Setting Range Warning	The value is out of range for Position/Distance.	At control change	Continues the operation with the previous Position/Distance.	Set Position/Distance within the range.
0D0FH	Axis/Axes group	Out of Velocity Range Warning	The value is out of range for Velocity.	During control	Continues the operation with the previous speed.	Set Velocity within the range.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D10H	Axis/Axes group	Overrun Warning	Target position turned overrun because the deceleration distance for command output velocity was not reached according to either of the following settings. <ul style="list-style-type: none"> Target position change during control Acceleration/deceleration, acceleration/deceleration time change during control Switching based on multiple start Switching from speed control to positioning control in Speed To Relative Positioning 	During control / When switching by multiple start	Stops immediately.	Set Velocity, Position/ Distance, and Deceleration so that an overrun will not occur.
0D11H	Axis/Axes group	Multiple Start Velocity Mode Specified Mismatch Warning	The VelocityMode of the under-control FB is different from that of the multiply-started FB.	At multiple start	Operates by "VelocityMode" of each FB.	Set the same VelocityMode for the under-control FB and the multiply-started FB.
0D12H	Axis	Torque Limit Value Over Warning	<ul style="list-style-type: none"> Torque was changed to a larger value than <u>AxisName</u>.Md.TorqueLimit_Positive. (Detail Code: 0001H) Torque was changed to a larger value than <u>AxisName</u>.Md.TorqueLimit_Negative. (Detail Code: 0002H) 	At control change	Continues the operation with the previous target torque.	Set Torque within the following. <ul style="list-style-type: none"> <u>AxisName</u>.Md.TorqueLimit_Positive <u>AxisName</u>.Md.TorqueLimit_Negative
0D13H	Axis	Filter Cumulated Value Over Warning	Filter cumulated value exceeded the positioning range.	During control	Filter cumulated value is clamped at the positioning range, and continues the operation.	Please reduce Master velocity.
0D15H	Axis	Current Position Change Execution Disabled Warning	An error occurred when changing the current position.	At start During control	Current position change is not executed.	<ul style="list-style-type: none"> Check the settings for MC_SetPosition. Execute when <u>AxisName</u>.Md.AxisStatus is StandStill.
0D16H	Axis	Out of Torque Setting Range Warning	The value is out of range for Torque.	At control change	Continues the operation with the previous target torque.	Set Torque within the range.
0D17H	Axis/Axes group	Out of Acceleration Range Warning	The value is out of range for Acceleration.	During control	Continues the operation with the previous acceleration.	Set Acceleration within the range.
0D18H	Axis/Axes group	Out of Deceleration Range Warning	The value is out of range for Deceleration.	During control	Continues the operation with the previous deceleration.	Set Deceleration within the range.
0D19H	Axis/Axes group	Out of Acceleration/ Deceleration Time Range Warning	The value is out of range for Acceleration.	During control	Continues the operation with the previous acceleration/ deceleration time.	Set Acceleration within the range.
0D1BH	Axis	Out of Limit Velocity Range Warning	The value is out of range for LimitVelocity.	At control change	Continues the operation with the previous limit velocity.	Set LimitVelocity within the range.
0D1CH	Axis	Out of Torque Forward Direction Ramp Range Warning	The value is out of range for TorquePositiveRamp.	At control change	Continues the operation with the previous torque forward direction ramp.	Set TorquePositiveRamp within the range.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D1DH	Axis	Out of Torque Reverse Direction Ramp Range Warning	The value is out of range for TorqueNegativeRamp.	At control change	Continues the operation with the previous torque reverse direction ramp.	Set TorqueNegativeRamp within the range.
0D1EH	Axes group	Velocity Command Unit Mismatch Warning	The velocity command unit is different from that of the under-control FB.	At multiple start	—	Set the same value to <u>AxisName(AxesGroupName).Pr.Unit_Velocity</u> for the axes group and interpolation axes.
0D1FH	Axis	Driver Warning	Warning occurred in the drive unit.	During operation	Executes the operation.	Please check the error details and take corrective actions according to <u>AxisName.Md.DriverErrorID</u> . (Please refer to the manual of each drive unit for details on <u>AxisName.Md.DriverErrorID</u> .)
0D20H	Axis	Velocity Limit Value Over Warning on Direction Change	Target velocity exceeded the velocity limit value on that direction when accelerating again from velocity 0 on direction change. <ul style="list-style-type: none"> • <u>AxisName.Pr.VelocityLimit_Positive</u> (Detail Code: 0001H) • <u>AxisName.Pr.VelocityLimit_Negative</u> (Detail Code: 0002H) 	During control	Continues the operation with speed 0.	Adjust settings so that the target velocity does not exceed the following velocity limit value after direction change. <ul style="list-style-type: none"> • <u>AxisName.Pr.VelocityLimit_Positive</u> • <u>AxisName.Pr.VelocityLimit_Negative</u>
0D21H	Axis	Out of End Velocity Range during Operation Warning	The value is out of range for EndVelocity when changing to the end target velocity.	During control	Continues the operation with the last speed.	Set EndVelocity within the range.
0D22H	Axis/Axes group	Warning Starting over Number of Buffering FBs	The maximum number of FBs which can be buffered has been exceeded with multiple start.	At multiple start	Waits analysis of the buffering FB until on-going FB is completed.	Multiple start is executed so that the maximum number of FBs which can be buffered has not been exceeded.
0D23H	Axis	Warning Changing Torque Limit Value for Unconnected Axis	The torque limit value change request was made to the unconnected axis.	At control change	The torque limit value is not sent to the drive unit	Please make the torque limit value change request to the connected axis.
0D24H	Axis	Out of FilterTime Setting Range of Each Axis Signal Warning	The value is out of range for FilterTime.	At power ON At ready ON	Continues the operation with FilterTime 0.	Set FilterTime within the range.
0D29H	Axis	Out of Denominator Range at Control Change Warning	The value is out of range for RatioDenominator.	At control change	Continues the operation with the previous gear ratio.	Set RatioDenominator within the range.
0D2DH	Axis/Axes group	Out of Position Command Unit Range Warning	The value is out of range for <u>AxisName(AxesGroupName).Pr.Unit_Position</u> .	At power ON At ready ON	Operates as "pulse".	Set <u>AxisName(AxesGroupName).Pr.Unit_Position</u> within the range.
0D2EH	Axis/Axes group	Out of Velocity Command Unit Range Warning	The value is out of range for <u>AxisName(AxesGroupName).Pr.Unit_Velocity</u> .	At power ON At ready ON	Operates as "s".	Set <u>AxisName(AxesGroupName).Pr.Unit_Velocity</u> within the range.
0D2FH	Axis/Axes group	Out of Operation Cycle Converted Velocity Range Warning	The velocity converted from Velocity/EndVelocity by operation cycle is out of the range.	During control	Continues the operation with the previous speed.	Set Velocity/EndVelocity so that the velocity converted by operation cycle is within the range.
0D30H	Axis/Axes group	Out of Deceleration Range at Stop Warning	The value was out of range for <u>AxisName(AxesGroupName).Pr.StopMode_Deceleration</u> or <u>System.Pr.StopMode_AllDeceleration</u> when factors that cause a stop occurred.	During control	<p>■At the upper limit value and value outside Decelerates and stops at the upper limit value.</p> <p>■At the lower limit value and value outside Stops immediately.</p>	Set <u>AxisName(AxesGroupName).Pr.StopMode_Deceleration</u> or <u>System.Pr.StopMode_AllDeceleration</u> within the range.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D31H	Axis	Control Mode Switching Disabled Warning	Control mode switching is requested during a switching disabled controlling.	During control	Continues the current control mode.	Please request for switching when control mode is switchable.
0D32H	Axis	Acceleration Time Exceeded during Direction Change Warning	Acceleration time exceeded 8400 [s] when accelerating again from velocity 0 on direction change.	During control	Continues the operation at speed 0.	Adjust settings so that the acceleration time after direction change does not exceed 8400 [s].
0D33H	Axis/Axes group	Deceleration Time Over Warning on FB Switching	Deceleration time exceeded 8400 [s] on FB switching.	During control	Continues the operation with the velocity and deceleration before the FB switch.	Set velocity, deceleration, and jerk so that deceleration time does not exceed 8400 [s].
0D34H	Axis/Axes group	Out of Velocity Range Clamping Warning	The velocity-overridden velocity was below the velocity lower limit value.	At start At control change	Operates at velocity 0.	Adjust settings so that the velocity after velocity override is within the range.
0D35H	Axis/Axes group	Out of Acceleration Range Clamping Warning	<p>■Acceleration/deceleration specification method The acceleration after acceleration override was out of range.</p> <p>■Time-fixed acceleration/deceleration method. The acceleration or deceleration calculated from Acceleration was out of range.</p>	At start At control change	<p>■Acceleration/deceleration specification method Operates at upper limit value of acceleration or 0.</p> <p>■Time-fixed acceleration/deceleration method Operates at upper limit value of acceleration (deceleration) or 0.</p>	<p>■Acceleration/deceleration specification method Adjust settings so that the acceleration after acceleration override is within the range.</p> <p>■Time-fixed acceleration/deceleration method Adjust settings so that the acceleration or deceleration calculated from Acceleration is within the range.</p>
0D36H	Axis/Axes group	Out of Deceleration Range Clamping Warning	The deceleration after acceleration override was out of range.	At start At control change	Operates at upper limit value of deceleration or 0.	Adjust settings so that the deceleration after acceleration override is within the range.
0D37H	Axis/Axes group	Out of Acceleration/Deceleration Time Range Clamping Warning	The acceleration/deceleration time after acceleration override was out of range.	At start At control change	Operates at upper limit value of acceleration/deceleration time or 0.	Adjust settings so that the acceleration/deceleration time after acceleration override is within the range.
0D38H	Axis/Axes group	Out of Operation Cycle Converted Acceleration Range Warning	Because the acceleration converted from Acceleration by operation cycle is low, there is a possibility that the error of set velocity is large.	At start At control change	Continues the control.	<ul style="list-style-type: none"> • Set Acceleration so that the acceleration converted by operation cycle becomes larger. • Increase the operation cycle.
0D39H	Axis/Axes group	Out of Operation Cycle Converted Deceleration Range Warning	Because the deceleration converted from Deceleration by operation cycle is low, there is a possibility that the error of set velocity is large.	At start At control change	Continues the control.	<ul style="list-style-type: none"> • Set Deceleration so that the deceleration converted by operation cycle becomes larger. • Increase the operation cycle.
0D3AH	Axis/Axes group	Out of Operation Cycle Converted Jerk Range Warning	Because the jerk converted from Jerk by operation cycle is low, there is a possibility that the error of set velocity or set acceleration is large.	At start At control change	Continues the control.	<ul style="list-style-type: none"> • Set Jerk so that the jerk converted by operation cycle becomes larger. • Increase the operation cycle.
0D3BH	Axis/Axes group	Jerk Acceleration/Deceleration Disabled Warning	Because the jerk converted from Jerk by operation cycle is 0, it does not operate as a jerk acceleration/deceleration.	At start	Operates as trapezoidal acceleration/deceleration.	<ul style="list-style-type: none"> • Set Jerk so that the jerk converted by operation cycle becomes larger. • Increase the operation cycle.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D3EH	Axis	Advanced Synchronous Control Operation Overflow Warning	<p>Overflow occurred during the operation of each module of advanced synchronous control.</p> <p>■Input Axis</p> <ul style="list-style-type: none"> • The movement amount of the data source overflowed. (Detail code: 0001H) • Movement amount overflowed during smoothing compensation. (Detail code: 0002H) • Movement amount overflowed during phase compensation. (Detail code: 0003H) • Phase compensation amount overflowed. (Detail code: 0004H) • The cumulated value of the moving direction restriction amount overflowed. (Detail code: 0005H) <p>■Output Axis</p> <ul style="list-style-type: none"> • The movement amount of the output axis overflowed during phase compensation. (Detail code: 0100H) 	During operation	Continues the control. It is controlled with the minimum or maximum value.	<ul style="list-style-type: none"> • Reduce the input axis velocity. • Review the setting value of the time constant to reduce the smoothing level, or increase the operation cycle. • Reduce the advance time for phase compensation. • Check the enabled direction of the moving direction restriction setting. (The setting may be reversed.) • Check if the input axis moves to the reverse direction of the enabled direction.
0D3FH	Axis	Out of Advanced Synchronous Control Variable Range Warning	The parameters or control data were out of range during advanced synchronous control.	During operation	Continues the operation with the setting before the change.	Set the value of the target variable within the range.
0D40H	Axis	Advanced Synchronous Control Restoration Incorrect Warning	<p>The absolute position data was incorrect when restoring current position due to the following causes.</p> <ul style="list-style-type: none"> • Target axes of the input axis and output axis of advanced synchronous control are different before and after the axis connection. (Detail code: 0001H) • File versions of the backup data are different. (Detail code: 0002H) 	When connecting drive unit	Does not execute restoration taking into account the previous value.	The target axes and axis label IDs of the input axis and output axis must be the same before and after the axis connection.
0D44H	Axis	No Cam Table Warning	The cam table specified in CamTableID does not exist.	During operation	Continues the operation with the setting before the change.	Open cam data to the open area with MC_CamTableSelect.
0D45H	Axis	Unable to Change Cam Length per Cycle Under Advanced Synchronous Control Warning	Under advanced synchronous control, when using operation profile data consisting of stroke ratio cam data where the cam data starting point was not 0, "Length per Cycle" was changed.	During operation	Continues operation with the length per cycle before the change.	Set the cam starting point (<u>AdvOutputName.Pr.Cam.StartingPoint</u>) to 0.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D46H	Axis	Operation Profile Data Settings Incorrect Under Advanced Synchronous Control Warning	<p>Any of the following operation profile data settings have been set to values that cannot be used under advanced synchronous control.</p> <ul style="list-style-type: none"> • Profile data type incorrect (Detail code: 0001H) • Operation profile data format incorrect (Detail code: 0002H) • The operation is not repetitive. (Detail code: 0003H) • The master axis (input) absolute coordinate is not set to relative coordinate. (Detail code: 0004H) • The slave axis (output) absolute coordinate is not set to relative coordinate. (Detail code: 0005H) • The starting point is not 0. (Detail code: 0006H) • The initial stroke is not 0. (Detail code: 0007H) • The cam starting point (<u>AdvOutputName.Pr.Cam.StartingPoint</u>) exceeded the resolution. (Detail code: 0008H) • The target operation profile data is being operated by another FB. (Detail code: 0009H) 	During operation	Continues the operation with the setting before the change.	<ul style="list-style-type: none"> • Set the profile data type to "1: Cam Data". (Detail code: 0001H) • Set the operation profile data format to "0: Linear Interpolation", "1: Section Interpolation", or "2: Spline Interpolation". (Detail code: 0002H) • Set repetitive operation to "1: Enable". (Detail code: 0003H) • Set master axis (input) absolute coordinate to "0: Relative Coordinate". (Detail code: 0004H) • Set slave axis (output) absolute coordinate to "0: Relative Coordinate". (Detail code: 0005H) • Set the starting point to "0". (Detail code: 0006H) • Set the initial stroke to "0". (Detail code: 0007H) • Set the cam starting point (<u>AdvOutputName.Pr.Cam.StartingPoint</u>) to a value smaller than the resolution. (Detail code: 0008H) • End the FB that is operating the target operation profile data. (Detail code: 0009H)
0D47H	Axis	Add-on Acquisition Failure Warning	Failed to acquire the necessary add-on for operation.	During operation	Continues the control.	Check the detailed information, then install the displayed add-on (*.mpk) and enable it.
0D48H	Axes group	Operation Profile Data Control Profile ID Setting Incorrect Warning	During the control of a multiple axes positioning data operation, the positioning data was switched to the next one in the M code outputting state, from one whose operation pattern was continuous path.	During control	Continues the control.	Do not set the M code for positioning data whose operation pattern is continuous path, or reset the M code before the data switches.
0D49H	Axis	Synchronous Control Variable Out-of-Range Warning	<p>Out-of-range value set for parameter or control data during synchronous control.</p> <ul style="list-style-type: none"> • Out of spindle offset range (Detail code: 0001H) • Out of the follow shaft offset range (Detail code: 0002H) • Out of spindle coefficient range (Detail code: 0003H) • Out of the dependent coefficient range (Detail code: 0004H) • Out of cam table ID range (Detail code: 0005H) 	During operation	Continues the operation with the setting before the change.	Set the target variable to a value within a range.
0D4AH	Axis/Axes group	Speed Bias Function Combination Not Supported Warning	For axis with a speed bias value other than 0.0, jerk was operated in start with a setting other than 0.0.	At start	Starts with the speed bias disabled.	Set jerk to 0.0.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D4BH	Axis/Axes group	Below Speed Bias Value Warning	<p>When changing set velocity or speed override coefficient, a speed other than 0.0 was specified for the target speed and less than the speed bias value set for the following parameters.</p> <ul style="list-style-type: none"> • Single axis operation: axis parameters for the specified axis • Linear interpolation operation (composite speed): axis group parameter of the specified axis group • In linear interpolation operation (reference axis speed): axis parameter of reference axis • Linear interpolation operation (Long axis speed): axis parameter of Long axis • In circular interpolation operation: axis group parameters for the specified axis group 	At start	Operates with the target speed as the velocity bias value.	Review the speed override factor and set velocity so that the target speed is equal to or greater than the speed bias value.
0D4CH	Axis	Absolute Position Management Setting Incorrect Warning	For an axis with setting value for object data Encoder status1 left blank, "-1: Obtained from connected device (Auto)" was set in the absolute position management settings (<u>AxisName</u> .PrConst.PosRestoration_AbsPosEnable).	When connecting drive unit	The current position is restored with the same content as the incremental system, and the homing request becomes TRUE.	Set the absolute position management setting (<u>AxisName</u> .PrConst.PosRestoration_AbsPosEnable) to "1: Use absolute position system (Enabled)" when the absolute position system is used, or to "0: Do not use absolute position system (Disabled)" when the absolute position system is not used.
0D4DH	Axis	Out of Pressure Range Warning	The value is out of range for Pressure.	During control	Continues the operation with the setting before the change.	Set Pressure within the range.
0D4EH	Axis	Out of Pressure Ramp Range Warning	The value is out of range for PressureRamp.	During control	Continues the operation with the setting before the change.	Set PressureRamp within the range.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0D4FH	Axis	Forward-side Position Incorrect Warning	<ul style="list-style-type: none"> ForwardSidePosition set out of range. (Detail code: 0001H) ForwardSidePosition was set outside the software stroke limit. (Detail code: 0002H) The absolute value of the difference between ForwardSidePosition and the reference position exceeded the upper limit, when using the set position (<code>AxisName.Md.SetPosition</code>) when requiring to change the control mode to cspr as the reference position. (Detail code: 0003H) The absolute value of the difference between ForwardSidePosition and the reference position exceeded the upper limit, when using the forward-side position (<code>AxisName.Md.Cspr_ForwardSidePosition</code>) at cspr as the reference position. (Detail code: 0004H) 	During control	Continues the operation with the setting before the change.	<ul style="list-style-type: none"> Set ForwardSidePosition to be within range. (Detail code: 0001H) Set ForwardSidePosition within the software stroke limit. (Detail code: 0002H) Set ForwardSidePosition so that the absolute value of the difference from the reference position does not exceed "$(2147483648 - 10 \times \text{encoder resolution} / \text{Electronic gear}) \times \text{driver unit conversion denominator} / \text{numerator}$". (Detail code: 0003H, 0004H)
0D50H	Axis	Process Incorrect Warning	The value is out of range for Process.	During control	Continues the operation with the setting before the change.	Set Process within the range.
0D51H	Axis	Ramp Time Over Warning	Pressure ramp time exceeded 8400 [s].	During control	Continues the operation with the setting before the change.	Set Pressure/PressureRamp in MCv_PressureControl so that the pressure ramp time does not exceed 8400 [s].
0F00H	System	Software Reboot Disabled Warning	Software reboot was executed when System.PrConst.SoftReboot_Enable is Disabled.	When executing software reboot	Not execute soft reboot.	Set System.PrConst.SoftRebootEnable as Enabled.
0F01H	System	Log File Create Disabled Warning	An error has been detected when updating log file.	When executing file transfer function	The log file is not created.	<ul style="list-style-type: none"> Delete unnecessary files and secure free capacity. Format the target drive. Delete log files.
0F02H	System	File Error	<ul style="list-style-type: none"> The parameter content is broken. Major version is unsupported. 	When importing file	The file is not imported.	Please check the detailed information (parameter information) and review parameter settings.
0F03H	System	Position Data History Update Disabled Warning	<ul style="list-style-type: none"> An error was detected when updating position data history. The memory capacity of add-on MotionEventHist is insufficient. 	When updating positioning data history file	The position data history is not updated.	<ul style="list-style-type: none"> Delete unnecessary files and secure free capacity. Format the target drive. Delete position data history files. Please check the memory capacity of add-on MotionEventHist.
0F04H	System	File Transfer Command Acquisition Disabled Warning	Failed to acquire the address of System.Cd.FileTransfer_Command.	At system start	Cannot execute the file transfer of the command label.	Start the system again.
0F05H	System	Event Filter Setting Failed Warning	<ul style="list-style-type: none"> Add-on MotionEventHist is disabled. The memory capacity of add-on MotionEventHist is insufficient. 	When updating filter setting	Continues the operation with the disabled filter setting.	<ul style="list-style-type: none"> Enable add-on MotionEventHist. Please check the memory capacity of add-on MotionEventHist.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0F06H	System	File Transfer Parameter Import Failed Warning	<ul style="list-style-type: none"> Failed to access to FRAM area. The compatibility does not exist in the version of file transfer parameter. The CRC value of file transfer parameter is abnormal. 	At system start	"System.PrConst.FileTransfer_LogCapacity" = 0, and continues the operation with disabled read/write (0x0000) of other access control.	Start the system again.
0F07H	System	Event History Parameter Incorrect Warning	The value is out of range for System.PrConst.EventHistoryMotion_Path or System.PrConst.EventHistoryMotion_Capacity.	At system start	Operates by the label default value.	Set System.PrConst.EventHistoryMotion_Path and System.PrConst.EventHistoryMotion_Capacity within the range.
0F08H	System	Cycle Over Warning	Operation processing or other fixed scan processing is not completed within the set cycle.	During operation	Continues the operation.	<ul style="list-style-type: none"> Change the fixed scan interval setting of fixed scan execution type program to a larger value. Change the communication cycle interval setting or buffer memory refresh cycle to a larger value. When using by an operation cycle of 31.25μs, please begin with a minimum configuration of add-ons, and then add more add-ons as required according to the load of the system. When the inter-module synchronization function is enabled, please be sure to execute the EI instruction with the PLC to enable I44 interrupt programs.
0F09H	System	File Transfer Execution Request Acquisition Disabled Warning	Failed to acquire the address of System.Cd.FileTransfer_Execute.	At system start	Cannot execute the file transfer of the command label.	Start the system again.
0F0AH	System	File Transfer Execution State Update Disabled Warning	Failed to acquire the address of System.Md.FileTransfer_State.	At system start	Cannot execute the file transfer of the command label.	Start the system again.
0F0BH	Axis	Maximum Setting Axis Number Over Warning	Axis setting that exceeded the maximum control axis number exists.	At ready ON	The axis which is greater than the maximum setting axis number is not recognized as the axis. (Md is not updated)	Set the number of setting axis within the maximum number of control axis.
0F0CH	System	Warning Filter Set Failed Warning	<ul style="list-style-type: none"> Add-on MotionEventHist is disabled. The memory capacity of add-on MotionEventHist is insufficient. 	At ready ON	Continues the operation with the disabled filter setting.	<ul style="list-style-type: none"> Enable add-on MotionEventHist. Please check the memory capacity of add-on MotionEventHist.
0F0DH	System	Program Setting Import Disabled Warning	Failed to import the program setting.	At ready ON	The program setting is not imported.	<ul style="list-style-type: none"> Please write the project to the user root path. If the label incorrect error (at system startup) occurred, please refer to the corrective action for label incorrect error (at system startup).
0F0EH	System	Module Extended Parameter Storage Location Warning	The project content of the storage location different from module extended parameter storage location setting was changed.	At system start	The written module extended parameter is not enabled.	Please check the module extended parameter storage location setting.

Warning code	Error	Warning name	Error detail and cause	Detection timing	Operation at warning occurrence	Action
0F0FH	System	Out of FilterTime Setting Range of System Signal Warning	The value is out of range for FilterTime.	At ready ON	Continues the operation with the FilterTime = 0.	Set FilterTime within the range.
0F10H	System	Servo System Recorder Inconsistency Incorrect Warning	<ul style="list-style-type: none"> The add-on on which it is dependent has not been installed. (Detail Code: 0001H) There is an inconsistency in the versions with other add-ons. (Detail Code: 0001H) There is an inconsistency in the versions with engineering tool. (Detail Code: 0002H) 	At power ON	The servo system recorder does not start.	<ul style="list-style-type: none"> Please install the software again. Please install the add-on which it is dependent. Please install the correct version of the add-on. Please execute project writing using the engineering tool that supports servo system recorder.
0F12H	System	Event History Filter Setting Error Warning	The event history filter is not set correctly.	At system start	Ignores the incorrect filter settings.	Check the filter setting and start the system again.
0F13H	System	Servo System Recorder Setting File Creation Disabled Warning	<ul style="list-style-type: none"> There is a user-created logging setting file in save destination. (Detail Code: 0001H) Memory capacity in save destination is insufficient. (Detail Code: 0002H) Cannot output logging setting file because of system error. (Detail Code: 0003H) 	At power ON	Logging setting data which is created in the servo system recorder is not created.	<ul style="list-style-type: none"> Please check if there is a user-created setting file in the save destination. Please check the free capacity in the save destination. Please check if any error has occurred to other add-ons.
0F14H	System	Servo System Recorder Logging Execution Disabled Warning	<ul style="list-style-type: none"> Cannot start servo system recorder because logging setting 10 or 9 is being executed. Cannot start servo system recorder because an error occurred during the logging. 	At power ON At servo system recorder stop	The logging does not start.	<ul style="list-style-type: none"> Please stop logging setting 10 or 9 if they are being executed. Please check the logging error code.
0F15H	System	SD Memory Card Removed Warning	The SD memory card was removed without being disabled.	At removing the SD memory card.	Continues the operation	Remove SD memory card after disabling it.
0F18H	System	Advanced Synchronous Control Backup Memory Insufficient Warning	The necessary capacity for the input axis and output axis to be backed up exceeds MotionControl_AdvancedSync_System.PrConst.AddonMemory.	At system start	Does not save the backup data of the input axis and output axis for the capacity exceeding the setting of MotionControl_AdvancedSync_System.PrConst.AddonMemory.	Review the setting of MotionControl_AdvancedSync_System.PrConst.AddonMemory.
0F2FH	System	Add-on Warning	An add-on warning occurred.	Depends on the add-on.	Depends on the add-on	Check the manual of the add-on for details about the detail code.

24.6 List of Error Codes

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1080H	System	Writing to Flash ROM Count Error	The number of writes to the flash ROM has exceeded 100000.	At module start	Does not execute the writes to the flash ROM.	Replace the module.
1300H	System	Co-recording Setting Error	Because the firmware version of the control CPU module does not support the co-recording function, co-recording does not operate.	At module start	Co-recording does not operate.	Please check the version of the control CPU module and use a product that supports the function.
1301H	System	Co-recording Setting Error	Because the co-recording setting of the control CPU module is not set to "Use", co-recording does not operate.	At trigger detection	Co-recording does not operate.	Please set the co-recording setting of the control CPU module to "Use".
1800H	System	SDO Communication Error	<ul style="list-style-type: none"> An error occurred in the SDO communication. Issued a large quantity of SLMP requests at a time. 	During FB execution	The Error of FB turns ON, and the error code of SDO is output to SDOErrorID.	<ul style="list-style-type: none"> Remove the error cause according to the SDO error code. Reduce the number of SLMPs to be issued, or modify the program to issue the next request after the response is received.
1A00H	Axis	Software Stroke Limit Over (Target Position)	A value out of the software stroke limit range was set for the target position.	At start At control change	<ul style="list-style-type: none"> At start Does not start. At control change Stops. 	Set the target position within the software stroke limit range.
1A01H	Axis	Software Stroke Limit Over (Start Position)	<ul style="list-style-type: none"> Started at a position out of the software stroke limit range. Started at a position out of the software stroke limit range towards a direction other than the returning enable direction. 	At start	Does not start.	Set ONLY_INSIDE or DISABLE to <u>AxisName.Cd.SwStrokeLimit_O</u> override and carry out a move to the movable range.
1A02H	Axis	Start when Software Stroke Limit is Valid	<ul style="list-style-type: none"> It was started except when <u>AxisName.Pr.SwStrokeLimit_Target</u> is invalid. It was started except when <u>AxisName.Md.SwStrokeLimit_Override</u> is DISABLE. 	At start	Does not start.	<ul style="list-style-type: none"> Set invalid for <u>AxisName.Pr.SwStrokeLimit_Target</u>. Set DISABLE for <u>AxisName.Cd.SwStrokeLimit_Override</u>.
1A03H	Axis	Software Stroke Limit Over (Forward Direction)	The value specified for <u>AxisName.Pr.SwStrokeLimit_Target</u> during control to forward direction would result in a move outside the software stroke limit range.	During control	Stops.	Carry out a move to the software stroke limit range.
1A04H	Axis	Software Stroke Limit Over (Reverse Direction)	The value specified for <u>AxisName.Pr.SwStrokeLimit_Target</u> during control to reverse direction would result in a move outside the software stroke limit range.	During control	Stops.	Carry out a move to the software stroke limit range.
1A05H	Axis/Axes group	Out of Target Position Range	<ul style="list-style-type: none"> The value is out of range for Position/Distance. In the case of target position designation beyond the ring counter, Direction was set to the shortest path and Position was set out of range. 	At start	Does not start.	<ul style="list-style-type: none"> Set Position/Distance within the range. Set the Direction to something other than the shortest path.
1A06H	Axis	Out of Limit Velocity Range	The value is out of range for LimitVelocity.	At start	Does not start.	Set LimitVelocity within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A07H	Axis/Axes group	Velocity Limit Value Over	The target velocity exceeded the following. <ul style="list-style-type: none"> • <u>AxisName</u>.Pr.VelocityLimit_Positive (Detail Code: 0001H) • <u>AxisName</u>.Pr.VelocityLimit_Negative (Detail Code: 0002H) • <u>AxesGroupName</u>.Pr.VelocityLimit (Detail Code: 0003H) 	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set target velocity so that it does not exceed the following. <ul style="list-style-type: none"> • <u>AxisName</u>.Pr.VelocityLimit_Positive • <u>AxisName</u>.Pr.VelocityLimit_Negative • <u>AxesGroupName</u>.Pr.VelocityLimit
1A0CH	Axis/Axes group	Acceleration/Deceleration 0 Specified Operation Error at Start	Started after setting <u>AxisName</u> (<u>AxesGroupName</u>).Pr.AccelerationZeroBehavior to -1: ACCError with Acceleration or Deceleration 0.	At start	Does not start.	Adjust settings so that Acceleration and Deceleration do not become 0.
1A0DH	Axis/Axes group	Out of Acceleration/Deceleration Time Range	Acceleration was out of range when using the time-fixed acceleration/deceleration method.	At start	Does not start.	Set Acceleration within the range.
1A0EH	Axis/Axes group	Acceleration/Deceleration Method Mismatched	The acceleration/deceleration method of the under-control FB is different from that of the multiply-started FB.	At multiple start	Stops the operation.	Set the same acceleration/deceleration method for the under-control FB and the multiply-started FB.
1A0FH	Axis	Acceleration Time Over at Start	Acceleration time exceeded 8400 [s].	At start	Does not start.	Set target velocity/target acceleration/target deceleration/target jerk so that acceleration time does not exceed 8400 [s].
1A10H	Axis	Deceleration Time Over at Start	<ul style="list-style-type: none"> • Deceleration time exceeded 8400 [s]. • The deceleration time for automatically decelerating from the target velocity exceeded 8400 [s]. 	At start	Does not start.	Set target velocity/target acceleration/target deceleration/target jerk as follows. <ul style="list-style-type: none"> • Adjust settings so that the deceleration time does not exceed 8400 [s]. • Adjust settings so that the deceleration time for automatically decelerating from the target velocity does not exceed 8400 [s].
1A11H	Axis	Out of Acceleration Range	The value is out of range for Acceleration.	At start	Does not start.	Set Acceleration within the range.
1A12H	Axis	Out of Deceleration Range	The value is out of range for Deceleration.	At start	Does not start.	Set Deceleration within the range.
1A13H	Axis/Axes group	Out of Jerk Range	The value is out of range for Jerk.	At start	Does not start.	Set Jerk within the range.
1A17H	Axis	Set Velocity of Converted Driver Velocity Unit Out of Range	The set velocity of converted driver velocity unit was out of the range from -2147483648 to 2147483647.	At start	Does not start.	Set the velocity of converted driver velocity unit within the setting range.
1A18H	Axis	Out of Velocity Initial Value Selection Range	<ul style="list-style-type: none"> • The value is out of range for velocity initial value selection of Options. • The value is out of range for command velocity limit initial value selection of Options. 	At start	Does not start.	<ul style="list-style-type: none"> • Set velocity initial value selection of Options within the range. • Set command velocity limit initial value selection of Options within the range.
1A19H	Axis	Out of Driver Unit Conversion Numerator/Denominator Range	The value is out of range for driver unit conversion numerator/denominator.	At start	Does not start.	Set driver unit conversion numerator/denominator within the setting range.
1A1BH	Axis	csv Unsupported Driver	The drive unit does not support csv (cyclic synchronous velocity mode).	At start	Does not start.	Execute the instruction in the drive unit supporting csv (cyclic synchronous velocity mode).
1A1CH	Axis	cst Unsupported Driver	The drive unit does not support cst (cyclic synchronous torque mode).	At start	Does not start.	Execute the instruction in the drive unit supporting cst (cyclic synchronous torque mode).

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A1DH	Axis	Control Mode Switching Error	<ul style="list-style-type: none"> • Drive unit control mode switching did not complete within 1 [s] after control mode switching command had been issued. • During communication initialization, the drive unit control mode did not switch to csp (cyclic synchronous position mode). 	During control During initial	Stops. Unable to connect to the drive unit.	<ul style="list-style-type: none"> • Please check whether an error occurred in the drive unit or whether the setting is incorrect, and take necessary actions. • When the MR-J5(W)-G or MR-JET-G is connected: When switching the driver control mode while the motor is operating, please set ZSP disabled selection at control switching (PC76.1) to "1: Disabled". • When MR-J5-G-LL is connected: Please set "Control switching method setting (PW13.4)" to "0: Disabled."
1A1EH	Axis	Out of Target Torque Range	The value is out of range for Torque.	At start	Does not start.	Set Torque within the range.
1A1FH	Axis	Out of Torque Positive Direction Ramp Range	The value is out of range for TorquePositiveRamp.	At start	Does not start.	Set TorquePositiveRamp within the range.
1A20H	Axis	Out of Torque Negative Direction Ramp Range	The value is out of range for TorqueNegativeRamp.	At start	Does not start.	Set TorqueNegativeRamp within the range.
1A22H	Axis	Start at Homing Incomplete	The positioning was started when homing request flag is ON.	At start	Does not start.	Start the operation after executing homing.
1A26H	Axis	Axis Status Incorrect Start	The axis is started in the status except when <u>AxisName.Md.AxisStatus</u> is Standstill.	At start	Does not start.	Start the axis when <u>AxisName.Md.AxisStatus</u> is Standstill.
1A27H	Axes group	Axes Group Status Incorrect Start	<ul style="list-style-type: none"> • The axes group was started when <u>AxesGroupName.Md.AxesGroupStatus</u> was other than GroupStandby. • There are unconnected actual axes among the configured axes. 	At start	Does not start.	<ul style="list-style-type: none"> • Start the axes group operation when <u>AxesGroupName.Md.AxesGroupStatus</u> is GroupStandby. • Start the axis group operation after connecting the configured axes.
1A2DH	Axis	FLS Signal Detection (at Start)	The signal input from FLS signal at start was detected.	At start	Does not start.	Set ONLY_INSIDE or DISABLE to <u>AxisName.Cd.HwStrokeLimit_O</u> override and carry out a move to the controllable range.
1A2EH	Axis	RLS Signal Detection (at Start)	The signal input from RLS signal at start was detected.	At start	Does not start.	Set ONLY_INSIDE or DISABLE to <u>AxisName.Cd.HwStrokeLimit_O</u> override and carry out a move to the controllable range.
1A2FH	Axis	FLS Signal Detection (Controlling)	The signal input from FLS signal during controlling was detected.	During control	Stops.	Set ONLY_INSIDE or DISABLE to <u>AxisName.Cd.HwStrokeLimit_O</u> override and carry out a move to the controllable range.
1A30H	Axis	RLS Signal Detection (Controlling)	The signal input from RLS signal during controlling was detected.	During control	Stops.	Set "ONLY_INSIDE" or "DISABLE" to <u>AxisName.Cd.HwStrokeLimit_O</u> override and carry out a move to the controllable range.
1A34H	Axis/Axes group	Out of Gear Denominator Range	The value is out of range for RatioDenominator.	At start	Does not start.	Set the value of RatioDenominator within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A36H	Axis/Axes group	Velocity Limit Value Over during Controlling	The set velocity exceeded the following when <u>AxisName.Pr.VelocityLimit_Over</u> Operation is 3:ImmediateStop. <ul style="list-style-type: none"> • <u>AxisName.Pr.VelocityLimit_Positive</u> (Detail Code: 0001H) • <u>AxisName.Pr.VelocityLimit_Negative</u> (Detail Code: 0002H) 	During control	Operates exceeding " <u>AxisName.Pr.VelocityLimit_Positive</u> " or " <u>AxisName.Pr.VelocityLimit_Negative</u> ".	Set the velocity within the following. <ul style="list-style-type: none"> • <u>AxisName.Pr.VelocityLimit_Positive</u> • <u>AxisName.Pr.VelocityLimit_Negative</u>
1A37H	Axis	Out of Direction Selection Range	The value is out of range for Direction.	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set Direction within the range.
1A38H	Axis	Acceleration Limit Value Over	Target acceleration exceeded <u>AxisName(AxesGroupName).Pr.AccelerationLimit</u> .	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set target acceleration so that it does not exceed <u>AxisName(AxesGroupName).Pr.AccelerationLimit</u> .
1A39H	Axis	Deceleration Limit Value Over	Target deceleration exceeded <u>AxisName(AxesGroupName).Pr.DecelerationLimit</u> .	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set target deceleration so that it does not exceed <u>AxisName(AxesGroupName).Pr.DecelerationLimit</u> .
1A3AH	Axis	Jerk Limit Value Over	Target jerk exceeded <u>AxisName(AxesGroupName).Pr.JerkLimit</u> .	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set target jerk so that it does not exceed <u>AxisName(AxesGroupName).Pr.JerkLimit</u> .
1A3BH	Axis	Deceleration Stop by Servo OFF During Operation	[5: Servo OFF After Deceleration to Stop (ServoOffAfterDecelStop)] was selected for <u>AxisName.Pr.StopMode_ServoOff</u> , and ServoOn of MC_Power (MCv_AllPower) was set to FALSE during operation.	During control	Deceleration stops.	Set TRUE to ServoOn in MC_Power (MCv_AllPower).
1A3CH	Axis	Immediate Stop by Servo OFF During Operation	<ul style="list-style-type: none"> • [4: Servo OFF After Immediate Stop (ServoOffAfterImmediateStop)] was selected for <u>AxisName.Pr.StopMode_ServoOff</u>, and ServoOn of MC_Power (MCv_AllPower) was set to FALSE during operation. • Enable of MC_Power (MCv_AllPower) was set to FALSE during operation. 	During control	Immediately stops.	Set TRUE to Enable and ServoOn in MC_Power (MCv_AllPower).
1A3DH	Axes group	Stop Cause of Axes Group Configuration Axis	Error occurred in configuration axis.	At start During control	■At start Does not start. ■During control Stops.	Please check the error details of configuration axis.
1A3EH	Axis	Master Axis and Slave Axis No. Duplicated	The same axis No. has been set to master axis and slave axis.	At start When executing FB	Does not execute FB.	Set different axis No. to master axis and slave axis.
1A3FH	Axis	Master Axis and Slave Axis Cyclic Reference	The master axis is set to the slave axis in the latter part of the FB. The number of connected FBs for synchronization exceeds the upper limit.	At start When executing FB	Does not execute FB.	Do not set master axis to the slave axis in the latter part of the FB. Reduce the number of connected FBs for synchronization less than the upper limit.
1A40H	Axis	Out of Cam Table ID Range	The value is out of range for CamTableID.	At start When executing FB	Does not execute FB.	Specify the value within the range for CamTableID.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A41H	Axis	Out of Master Axis Offset Range	The value is out of range for MasterOffset.	At start When executing FB	Does not execute FB.	Set the value within the range for MasterOffset.
1A42H	Axis	Out of Slave Axis Range	The value is out of range for SlaveOffset.	At start When executing FB	Does not execute FB.	Set the value within the range for SlaveOffset.
1A43H	Axis	Out of Master Axis Coefficient Range	<ul style="list-style-type: none"> The value is out of range for MasterScaling. The result of multiplying MasterScaling and the length per cycle is out of the positioning range. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set a value within the range for MasterScaling. Set values so that the result of multiplying MasterScaling and the length per cycle is within the positioning range.
1A44H	Axis	Out of Slave Axis Coefficient Range	<ul style="list-style-type: none"> The value is out of range for SlaveScaling. The result of multiplying SlaveScaling and the stroke amount is out of the positioning range. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value of SlaveScaling within the range. Set values so that the result of multiplying SlaveScaling and the stroke amount is within the positioning range.
1A45H	Axis	Out of Master Axis Follow-up Distance Range	The value is out of range for MasterStartDistance.	At start When executing FB	Does not execute FB.	Set the value of MasterStartDistance within the range.
1A46H	Axis	Out of Master Axis Synchronization Start Position Range	The value is out of range for MasterSyncPosition.	At start When executing FB	Does not execute FB.	Set the value of MasterSyncPosition within the range.
1A47H	Axis	Out of Start Mode Range	The value is out of range for StartMode.	At start When executing FB	Does not execute FB.	Set the value of StartMode within the range.
1A48H	Axis/Axes group	Out of Master Axis Data Source Range	The value is out of range for MasterValueSource.	At start When executing FB	Does not execute FB.	Set the value of MasterValueSource within the range.
1A49H	Axis/Axes group	Same Master Axis Data Source Selection	An axis selected as Master in a configuration that connects multiple axes with single axis synchronization FB is used as Slave axis of latter FB.	At start When executing FB	Does not execute FB.	Check axes specified by Master.
1A4AH	Axis	Out of BufferMode Range	The value is out of range for BufferMode.	At start	Does not start.	Set BufferMode within the setting range.
1A4CH	Axis	No Cam Table	The cam table specified in CamTableID does not exist.	At start When executing FB	Does not execute FB.	Open cam data to the open area with MC_CamTableSelect.
1A4DH	Axis/Axes group	Out of Velocity Range	The value is out of range for Velocity.	At start	Does not start.	Set Velocity within the range.
1A4EH	Axis	Out of Options Range	The value is out of range for Options.	At start	Does not start.	Set Options within the setting range.
1A4FH	Axis	Same Master Axis 1 Slave Axis Error	The same axis No. was specified to Master1 and Slave.	At start	Does not start.	Set different axis No. to Master1 and Slave.
1A50H	Axis	Same Master Axis 2 Slave Axis Error	The same axis No. was specified to Master2 and Slave.	At start	Does not start.	Set different axis No. to Master2 and Slave.
1A51H	Axis	Out of Master Axis 1 Gear Denominator Range	The value is out of range for GearRatioDenominatorM1.	At start	Does not start.	Set the value of GearRatioDenominatorM1 within the range.
1A52H	Axis	Out of Master Axis 2 Gear Denominator Range	The value is out of range for GearRatioDenominatorM2.	At start	Does not start.	Set the value of GearRatioDenominatorM2 within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A57H	Axes group	Configuration Axis No. Duplication Error	The duplicated axis number of configuration axis was set.	At power ON / During Configuration Axis Write	<p>■At power ON Generating axes group fails.</p> <p>■During Configuration Axis Write Continues the configuration axis which is before write.</p>	Set configuration axis so that axis No. does not duplicate.
1A58H	Axes group	Axes Group No. Setting Duplication Error	The axes group No. was duplicated.	At power ON / During Configuration Axis Write	<p>■At power ON Generating axes group fails.</p> <p>■During Configuration Axis Write Continues the configuration axis which is before write.</p>	Change the axes group No. of axes group where the error was detected.
1A59H	Axes group	Axes Group Configuration Axis Operation Cycle Incorrect	Operation cycles of configuration axes in axes group are different.	At power ON / During Configuration Axis Write	<p>■At power ON Generating axes group fails.</p> <p>■During Configuration Axis Write Continues the configuration axis which is before write.</p>	Set the same operation cycle in all configuration axes.
1A5BH	Axis	Forced Stop Status	Forced stop signal was detected during operating.	When inputting forced stop signal	Stops immediately.	Please cancel the forced stop signal.
1A5DH	System	Axis Data Memory Size Over	The memory size of axis data exceeds the memory capacity set in system.	At power ON	Generating axis fails.	<ul style="list-style-type: none"> • Please increase the memory capacity set in System.PrConst.Addon_Axis.RamSizeMax, System.PrConst.Addon_MotionEngine.RamSizeMax. • Please delete unnecessary axes and reduce memory size of axis data.
1A5EH	System	Mapping Size Incorrect Error	PDO size exceeds the settable size.	When connecting drive unit	The axis set incorrectly is not communicated.	Please check the mapping object.
1A5FH	System	Mapping Communication Error	<ul style="list-style-type: none"> • An object that cannot be mapped was mapped. • An object that does not exist in the object data setting was mapped. • The station-specific mode was set to Motion mode when <u>AxisName.PrConst.FastOperationMode</u> was 5FE2H (fast operation mode). • The mapping for fast operation mode was changed when <u>AxisName.PrConst.FastOperationMode</u> was 5FE2H (fast operation mode). 	When connecting drive unit	The axis set incorrectly is not communicated.	<ul style="list-style-type: none"> • Please check the mapping object. • Please check the setting of station-specific mode.
1A60H	System	Maximum Number of Registrations for Axes Group Over	The memory size of axes group data exceeds the memory capacity set in system.	At power ON At ready ON	Generating axes group fails.	Increase the memory capacity set in system. Or, delete unnecessary axes and keep the memory size of axis data within the memory capacity.
1A61H	Axes group	Out of Velocity Mode Range	The value is out of range for velocity mode.	At start At multiple start	<p>■At start Does not start.</p> <p>■At multiple start Stops.</p>	Correct the velocity mode so that it is within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A62H	Axes group	Circular Interpolation Axes Unset	<ul style="list-style-type: none"> A configuration axis not set up was set in CircAxes. Same index No. was set in CircAxes in duplicate. 	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	<ul style="list-style-type: none"> Set the configuration axis in CircAxes with an axis that has been set up. Set index No. of configuration axes in CircAxes avoiding duplication.
1A63H	Axes group	Out of Circular Interpolation Mode Range	The value is out of range for CircMode.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set CircMode within the range.
1A64H	Axes group	Out of Boundary Point Address Range	The value is out of range for boundary point (AuxPoint) at circular interpolation.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set boundary point (AuxPoint) within the range.
1A65H	Axes group	Start Point - Center Point Address Same Value	Start point is equal to center point at circular interpolation of center point specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set center point (AuxPoint) so that start point is not equal to center point.
1A66H	Axes group	Start Point - End Point Address Same Value	Start point is equal to end point at circular interpolation.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set end point (EndPoint) so that start point is not equal to end point.
1A67H	Axes group	End Point - Center Point Address Same Value	End point is equal to center point at circular interpolation of center point specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set center point (AuxPoint) or end point (EndPoint) so that end point is not equal to center point.
1A68H	Axes group	Start Point - Boundary Point Address Same Value	Start point is equal to boundary point at circular interpolation of boundary point specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set boundary point (AuxPoint) so that start point is not equal to boundary point.
1A69H	Axes group	End Point - Boundary Point Address Same Value	End point is equal to boundary point at circular interpolation of boundary point specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set boundary point (AuxPoint) so that end point is not equal to boundary point.
1A6AH	Axes group	Start Point - Boundary Point - End Point Address Same Straight Line	Start point, end point and boundary point are on the same straight line at circular interpolation of boundary point specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set boundary point (AuxPoint) so that it is not on the same straight line with start point and end point.
1A6BH	Axes group	Out of Center Point Address Range	The value is out of range for center point (AuxPoint) at circular interpolation.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set center point (AuxPoint) within the range.
1A6CH	Axes group	Out of Radius Range	The radius is out of range at circular interpolation.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set end point (EndPoint) or auxiliary point (AuxPoint) so that radius is within the range.
1A6DH	Axes group	Out of End Point Address Range	The value is out of range for end point (EndPoint) at circular interpolation.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set end point (EndPoint) within the range.
1A6EH	Axes group	Radius Setting Error	End point (EndPoint) and radius (AuxPoint) which were not able to form an arc were set at circular interpolation of radius specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set them so that the distance between start point - end point (EndPoint) is less than or equal to the radius (AuxPoint) × 2.
1A6FH	Axes group	Out of Path Selection Range	The value is out of range for PathChoice.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set PathChoice within the range.
1A70H	Axes group	Out of Circular Interpolation Error Allowable Value Range	The value is out of range for CircularErrorTolerance.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set CircularErrorTolerance within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A71H	Axes group	Circular Interpolation Error Allowable Value Over	The difference between radius of start point - center point and radius of end point - center point exceeds CircularErrorTolerance at circular interpolation of center point specification.	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set end point (EndPoint), center point (AuxPoint), and CircularErrorTolerance so that CircularErrorTolerance is not exceeded.
1A72H	Axes group	Software Stroke Limit Invalid at Circular Interpolation	Circular interpolation including an axis where software stroke limit is set to invalid was executed.	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Enable software stroke limit for the axis to execute circular interpolation.
1A73H	Axes group	Out of Pitch Number Range	The value is out of range for Pitch.	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set Pitch within the range.
1A78H	Axis	Out of Signal Selection Range	<ul style="list-style-type: none"> The value is out of range for Direction. The value is out of range for CompensationTime. The value is out of range for FilterTime. 	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	<ul style="list-style-type: none"> Set Direction within the range. Set CompensationTime within the range. Set FilterTime within the range.
1A79H	Axis	Out of Forward Direction Torque Limit Initial Value Specification Range	AxisName.PrConst.TorqueLimit_PositiveInitial was set to a value larger than AxisName.PrConst.TorqueLimit_Max.	At power ON	Generating axis fails.	Set AxisName.PrConst.TorqueLimit_PositiveInitial within the range of 0 to AxisName.PrConst.TorqueLimit_Max.
1A7AH	Axis	Out of Reverse Direction Torque Limit Initial Value Specification Range	AxisName.PrConst.TorqueLimit_NegativeInitial was set to a value larger than AxisName.PrConst.TorqueLimit_Max.	At power ON	Generating axis fails.	Set AxisName.PrConst.TorqueLimit_NegativeInitial within the range of 0 to AxisName.PrConst.TorqueLimit_Max.
1A7BH	Axes group	Insufficient Movement Amount at Changing Target Address	Movement amount became 0 after changing target position/ movement distance at multiple axes interpolation control of reference axis/long axis velocity designation.	During control	Stops the operation.	Set target position/movement distance so that movement amount is not insufficient.
1A7CH	Axes group	Motion FB Issue Error to the Axis during Axes Group Operating	Multiple start of single axis control FB was executed for operating axis in axes group to stop them.	At start	Stops the operation.	Execute multiple start of multiple axes control FB for the axis of axes group operating to stop them.
1A7EH	Axis/Axes group	Overrun Error	<ul style="list-style-type: none"> Overrun occurred since the deceleration distance for the output velocity was not satisfied after the last positioning address detected. Positioning direction was inverted when switching to the subsequent buffering FB during axis operation. Positioning direction was inverted when changing target position. 	Controlling At multiple start At control change	Stops the operation.	Set Velocity, Position/Distance, and Deceleration so that an overrun will not occur.
1A7FH	Axes group	Driver Emulation Switch Error	Driver emulation switch was executed when AxisName.Md.AxisStatus is other than Disable or Standstill.	When executing driver emulate switching	Stops.	Execute driver emulation switch when AxisName.Md.AxisStatus is Disable or Standstill.
1A80H	Axis/Axes group	BufferMode Specification Disabled	Multiple start was executed in combination disable BufferMode.	At multiple start	Stops.	Please specify combinatorial BufferMode.
1A85H	Axis	Out of Frequency Specification Range	The value is out of range for Frequency.	At start	Does not start.	Set Frequency within the range.
1A86H	Axis	Out of Filter Operation Specification Range	The value is out of range for Filter.	At start	Does not start.	Set Filter within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A87H	Axis	Out of Direction Limit Value Specification Range	The value is out of range for PositiveLimit and NegativeLimit.	At start	Does not start.	Set PositiveLimit and NegativeLimit within the range.
1A8AH	Axis	Out of Overrun Operation Setting Range	The value is out of range for <u>AxisName(AxesGroupName).Pr.OverrunOperation</u> .	At start	Does not start.	Set <u>AxisName(AxesGroupName).Pr.OverrunOperation</u> within the range.
1A90H	System	Synchronous Encoder Via Drive Unit Setting Incorrect	<ul style="list-style-type: none"> The real drive axis with the same station address as the real encoder axis via drive unit is not set. (Detail Code: 0001H) The scale measurement function of the connected driver is disabled. (Detail Code: 0002H) There is no object data required to be set for the real encoder axis via the drive unit. (Detail Code: 0003H) Scale measurement encoder Resolution is 0 (Detail Code: 0004H) The object required to be set for the real encoder axis via drive unit is not mapped to the real drive axis with the same station address. (Detail Code: 0005H) Absolute position control settings do not match. (Detail Code: 0006H) 	At power ON When connecting drive unit	<ul style="list-style-type: none"> Generating axis fails. Unable to connect to the drive unit. 	<ul style="list-style-type: none"> Set the real drive axis with the same station address as the real encoder axis via drive unit. Enable scale measurement function of the connected driver. Check if the drive unit holds the object data that needs to be set for the real encoder axis via the drive unit. Map the object required to be set for the real encoder axis via drive unit to the real drive axis with the same station address. Connect the encoder whose Scale measurement encoder resolution is not 0. Match the absolute position control settings of the real encoder axis and the connected device.
1A91H	Axis	Axis No. Setting Duplication Error	The same axis No. has been set.	At power ON	Generating axis fails.	Set a different axis No.
1A94H	Axis	Station Address Duplication Error	The set of IP address and multidrop number of a real drive axis overlaps with that of another.	At power ON	Generating axis fails.	Set real drive axes and sets of IP address and multidrop number to one on one.
1A95H	Axis	Station Address Setting Incorrect	<ul style="list-style-type: none"> There are no specified station address or connection devices in the real axis that not use axis emulation function. A moderate error occurred in the motion module. 	At power ON	Generating axis fails.	<ul style="list-style-type: none"> Specify a station address where a device is connected, when the axis emulation function is not to be used. Refer to the remedy for the moderate error that occurred in the Motion module.
1A96H	Axis	Object Data Setting Incorrect	<ul style="list-style-type: none"> The data type is incorrect. [OBJ] was set for the data type, and sizes other than 8bit, 16bit, and 32bit were set for the size portion. Changed from the initial value when <u>AxisName.PrConst.FastOperationMode</u> was 5FE2H (fast operation mode). The mandatory requirements for object data are not met. 	At power ON	Generating axis fails.	<ul style="list-style-type: none"> Set [OBJ] or [CONST] as the data type. Set [OBJ] as the data type, and set 8bit, 16bit, and 32bit sizes for the size portion. If the high-speed mode is set, the initial value is set. Specify a value other than "".
1A97H	Axes group	Axes Group Status Incorrect (When Axes Group is Disabled)	MC_GroupDisable was executed when <u>AxesGroupName.Md.GroupStatus</u> is other than GroupStandby or GroupErrorStop.	Axes Group Disable	Stops the operation.	Execute MC_GroupDisable when <u>AxesGroupName.Md.GroupStatus</u> is GroupStandby or GroupErrorStop.
1A98H	Axes group	No Configuration Axis	Configuration axis is not set in axes group.	At power ON / During Configuration on Axis Write	<ul style="list-style-type: none"> ■At power ON Generating axes group fails. ■During Configuration Axis Write In operation, the operation is stopped. 	Set configuration axis in axes group.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1A99H	Axes group	No axis	A non-existent axis was set in configuration axis.	At power ON / During Configuration Axis Write	<ul style="list-style-type: none"> ■At power ON Generating axes group fails. ■During Configuration Axis Write In operation, the operation is stopped. 	Set an existing axis in configuration axis.
1A9AH	Axis	Absolute Position Control Setting Mismatch	The Encoder status 1 object setting in connection devices is not match.	When restoring current position	Current position is not restored.	Please correct the axis and absolute position control setting of connection device.
1AA3H	Axis	Out of Ring Counter Range	<ul style="list-style-type: none"> • The settings of ring counter upper limit value and lower limit value exceeded the positioning range. • Ring counter lower limit value > Ring counter upper limit value. • $0 < \text{Ring counter upper limit value} - \text{Ring counter lower limit value} < 2.0$ • The setting values exceeded the positioning range. 	At power ON	Generating axis fails.	<ul style="list-style-type: none"> • Set the ring counter upper limit value and lower limit value within the positioning range. • Set the values so that they meet the following condition: Ring counter lower limit value < Ring counter upper limit value. • Set the values so that they meet the following condition: $2.0 < \text{Ring counter upper limit value} - \text{Ring counter lower limit value}$.
1AA4H	Axis	Driver Unit Conversion Magnification Upper Over	The magnification that exceeded upper limit in the driver unit conversion numerator/denominator is set.	At ready ON	<ul style="list-style-type: none"> • Generating axis fails. • The driver unit conversion numerator/denominator is not changed. 	Set values to make sure the calculation result of driver unit conversion numerator/denominator does not exceed 400000000.
1AA5H	Axis	Driver Unit Conversion Numerator/Denominator Change Timing Incorrect	The driver unit conversion numerator/denominator setting was changed when follow-up operation cannot be executed.	At ready ON	The driver unit conversion numerator/denominator is not changed.	<ul style="list-style-type: none"> • Revert the settings of the driver unit conversion numerator/denominator to their previous state and READY ON. • READY ON when both of the following conditions are met (in a follow-up capable state). <ul style="list-style-type: none"> (1) <code>AxisName.Md.AxisStatus</code> is Disabled. (2) <code>AxisName.Md.FollowupDisable</code> is FALSE.
1AA7H	Axis	Add-on Acquisition Failure	Failed to acquire the add-on SignalIO when set the "Counter Disabling Signal".	At power ON	Generating axis fails.	Install the add-on SignalIO and enable it.
1AA8H	Axis/Axes group	Necessary Object Data Unset	<ul style="list-style-type: none"> • Necessary object data for control instruction execution have not been set for axes (configuration axes in the case of an axes group). • There are no objects required for the connection of the real drive axis. 	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	<ul style="list-style-type: none"> • Please set necessary object data in control command. • Please map the objects required for the connection of the real drive axis.
1AA9H	Axis/Axes group	Out of Acceleration/Deceleration Method Range	The value is out of range for acceleration/deceleration method of Options.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set the acceleration/deceleration method according to the executed control command.
1AAAH	Axis	ABS Reference Point Read Error	Failed to get the data from drive unit normally for homing.	During operation	Homing is not completed normally.	<ul style="list-style-type: none"> • Execute homing again. • When reading or writing parameters of a device station while executing homing, reduce the number of executions at a time.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AABH	Axes group	Reference Axis Movement Amount 0	The movement amount of the reference axis was 0 during a linear interpolation with reference axis designated.	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set the axis of which the movement amount is not 0 to a reference axis.
1AACH	Axis	Out of Torque Lamp Function Selection Range	The value is out of range for torque lamp function selection of Options.	At start At multiple start	■At start Does not start. ■At multiple start Stops the operation.	Set torque lamp function selection of Options within the range.
1AADH	Axis	Start Not Possible	Positioning start not possible. For error details and causes of each setting, refer to the following detail code. ☞ Page 974 Start Not Possible (error code: 1AADH)	At start	Does not start.	For the actions for each setting, refer to the following detail code. ☞ Page 974 Start Not Possible (error code: 1AADH)
1AAEH	Axis	Driver Error	An error occurred in the drive unit.	During operation	Stops immediately.	Please check the error details and take corrective actions according to <u>AxisName.Md.DriverErrorID</u> . (Please refer to the manual of each drive unit for details on <u>AxisName.Md.DriverErrorID</u> .)
1AAFH	Axis	Driver Ready OFF	<ul style="list-style-type: none"> During control, the drive unit power was turned OFF. During control, the drive unit was servo OFF. During control, a driver error occurred. 	During operation	Stops immediately.	<ul style="list-style-type: none"> Please turn on the power supply of drive unit. Please turn the drive unit servo ON. Check and address the error details using <u>AxisName.Md.DriverErrorID</u>. (For details on <u>AxisName.Md.DriverErrorID</u>, please refer to the manual of each drive unit.)
1AB0H	Axis	PLC READY OFF During Operation	READY is turned OFF during operation due to the following causes. <ul style="list-style-type: none"> PLC READY is turned OFF during operation. An error whose operation at the time of error is "The program stops" occurs. 	During operation	Stops the operation.	<ul style="list-style-type: none"> Review the sequence program that changes PLC READY status. Check the event history, and follow the procedure for the error whose operation at the time of error is "The program stops".
1AB1H	Axis	Module Error During Operation	Moderate error or major error was detected in the Motion module during operation.	During operation	Stops the operation.	Please turn the module power on again.
1AB2H	Axis	Driver Network Disconnection	Network disconnection between the Motion module and drive unit was detected during operation.	During operation	Stops immediately.	Please check the connection cable of drive unit.
1AB3H	Axis	Executing FB Analysis Disabled	An error was detected in executing FB analysis at target position changing. <ul style="list-style-type: none"> Position/Distance after change is out of range. Target position after change is out of range of software stroke limit. 	At control change	Stops the operation.	Set Position/Distance at target position changing within the range.
1AB4H	Axis/Axes group	Buffering FB Analysis Disabled	An error was detected in the buffering FB analysis.	During operation	Stops the operation.	Set buffering FB analysis so that it will not result in an error.
1AB5H	Axis	Ring Counter Invalid Start	Ring counter setting was started in the invalid status.	At start	Does not start.	<ul style="list-style-type: none"> Enable the <u>AxisName.PrConst.RingCount_Enable</u>. Set <u>AxisName.PrConst.RingCount_UpperValue</u> and <u>AxisName.PrConst.RingCount_LowerValue</u> to not match the positioning range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AB6H	Axis	External Signal String Incorrect	<ul style="list-style-type: none"> Incorrect string was set in the string of external signal. A signal that does not exist or is incorrect was set. An unconnected or non-existent station was set when [OBJ] was specified. A non-existent object was set for TPDO/RPDO when [OBJ] was specified. 	At start	Does not start.	<ul style="list-style-type: none"> Set to a valid string for the external signal. Set a signal that can be used. Connect the target station if [OBJ] has been specified. Set the target object for TPDO/RPDO if [OBJ] has been specified.
1AB7H	Axes group	Path Choice Setting Incorrect	Incorrect value was set in PathChoice.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set the value of PathChoice to one that corresponds to CircMode.
1AB8H	Axes group	Total Movement Angle 0	The angle between start point - end point became 0 at circular interpolation of boundary point specification or radius specification.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set EndPoint or PathChoice so that the angle of start point - end point will not be 0.
1AB9H	Axes group	Linear Interpolation Axes Setting Incorrect	<ul style="list-style-type: none"> A configuration axis not set up was set in LinearAxes. 0 was set in the first element of LinearAxes. Same index No. was set in LinearAxes in duplicate. The number of axes set for LinearAxes exceeded the maximum number of interpolation axes. 	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	<ul style="list-style-type: none"> Set the configuration axis in LinearAxes with an axis that has been set up. Set a configuration axis in the first element of LinearAxes. Set index No. of configuration axes in LinearAxes avoiding duplication. Set the number of axes set for LinearAxes less than the maximum number of interpolation axes.
1ACBH	Axis	Add-on SignalIO Acquisition Failure	Failed to acquire the add-on SignalIO.	At power ON At ready ON	The signal is detected continuously.	Install SignalIO.mpk and enable it.
1AD8H	Axis	Out of Master Axis No. Range	The value is out of range for Master.AxisNo.	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value of Master.AxisNo within the range. Set to an axis No. for which an instance has been created.
1AD9H	Axis	Out of Slave Axis No. Range	The value is out of range for Slave.AxisNo.	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value of Slave.AxisNo within the range. Set to an axis No. for which an instance has been created.
1ADAH	Axis	Out of BufferMode Range	The value is out of range for BufferMode.	At start When executing FB	Does not execute FB.	Set the value of BufferMode within the range.
1ADBH	System	Command Filter Add-on System Memory Shortage	System memory for the add-on is insufficient.	At start At multiple start	Does not start.	Please check the System.PrConst.Addon_MotionControl_AxisFilter.RamSizeMax.
1ADCH	System	Add-on Memory Shortage	System memory for the add-on is insufficient.	At start At multiple start	Does not start.	Please check the System.PrConst.Addon_*.RamSizeMax for related add-ons.
1ADEH	Axes group	Out of Linear Movement Amount Range	An interpolation axis for which the movement amount exceeds "4294967296.0 (= 2 ³²)" exists during a linear interpolation with vector speed designated.	At start At multiple start	<ul style="list-style-type: none"> ■At start Does not start. ■At multiple start Stops the operation. 	Set the value of Position or Distance so that the movement amount of each interpolation axis does not exceed "4294967296.0 (= 2 ³²)".
1ADFH	Axis	Insufficient Current Position Backup Capacity	The necessary memory capacity in backup was not secured when restoring current position.	When restoring current position	Restoring current position is not completed.	Please execute software reboot after checking the System.PrConst.Addon_AbsSystem.BackupRamSizeMax.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AE0H	Axis	Driver Restoration Data Incorrect	The parameter of connected drive unit was incorrect when restoring current position. • Parameter of connected drive unit was incorrect (Detail code: 0001H) • Restoration data of connected drive unit was incorrect (Detail code: 0002H)	When restoring current position	Restoring current position is not completed.	<ul style="list-style-type: none"> • Please change the Electronic Gear to a power of two at connected drive unit side. • Please change the Electronic Gear to 1:1 at connected drive unit side, if the connected encoder resolution is not a power of two.
1AE1H	System	Out of Encoder Ring Counter Setting Range	Encoder Ring counter lower limit value > Encoder Ring counter upper limit value.	At power ON	Generating axis fails.	Set the values so that they meet the following condition: Encoder Ring counter lower limit value < Encoder Ring counter upper limit value.
1AE2H	Axis	Out of Addition and Subtraction Selection Range	The value is out of range for CombineMode.	At start	Does not start.	Set CombineMode within the setting range.
1AE3H	Axis	csp Unsupported Driver	The drive unit does not support csp (cyclic synchronous position mode) or could not switch to csp (cyclic position mode).	At initial communicating	Unable to connect to the drive unit	<ul style="list-style-type: none"> • Please connect a drive unit that supports csp (cyclic synchronous position mode). • If you are using a drive unit that supports csp (cyclic position mode), this issue may have occurred due to parameter settings on the drive unit side. For details, please refer to the manual of the relevant drive unit.
1AE4H	Axis/Axes group	Out of Operation Cycle Converted Velocity Range	The velocity converted from Velocity/EndVelocity by operation cycle is out of the range.	At start	Does not start.	Set Velocity/EndVelocity so that the velocity converted by operation cycle is within the range.
1AE5H	Axis	Communication Error of Connected Encoder	A communication error occurred between the drive unit <=> encoder.	When connecting During control	<ul style="list-style-type: none"> ■When connecting Disable to connect encoder. ■During control Disconnects encoder. 	Please check the motor and encoder cable.
1AE6H	Axis	Driver Command Discard Detection	Statusword bit12 OFF is received from the drive unit while the axis is operating. (In drive unit, Statusword bit12 is turned OFF to discard motion system commands such as stopping motor when limit signal or forced stop is detected.)	During operation	Stops the operation.	The drive unit alarm causing Statusword bit12 OFF may occur before or after this error occurs. If there are any alarms, follow the drive unit documentation for troubleshooting.
1AE7H	Axis	Driver Execution Control Mode Incorrect	The control mode of the connected drive unit switched to an unsupported mode for the motion system during operation.	During operation	Stops immediately.	Switch the driver control mode to a control mode that is supported by the motion system.
1AE8H	Axis/Axes group	Velocity Range Over during Controlling	Set velocity exceeded the velocity command range.	During operation	Stops the operation.	Adjust settings so that the set velocity does not exceed the velocity command range.
1AE9H	Axis	Driver Control Mode Unsupported	The drive unit was switched to an unsupported driver control mode. • ct: Continuous operation to torque control mode (Detail Code: 0001H) • cspr: Cyclic synchronous pressure mode (Detail Code: 0002H)	At start	Does not start	Connect a drive unit that supports the driver control mode to be switched to.
1AEAH	System	Servo Driver Memory Size Over	The memory size of the servo driver exceeds the memory capacity set in system.	When connecting	Unable to connect to the drive unit	<ul style="list-style-type: none"> • Please increase the memory capacity set in system. • Please delete unnecessary axes and reduce memory size.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AF0H	Axis	Advanced Synchronization Control Axis Unset	<p>An invalid axis or an axis that has not been set in the advanced input/output axis setting was designated to the main shaft, auxiliary shaft, sub input axis and slave axis of advanced synchronous control.</p> <ul style="list-style-type: none"> • Main Shaft (Detail code: 0001H) • Main Shaft Sub (Detail code: 0002H) • Auxiliary Shaft (Detail code: 0003H) • Slave Axis (Detail code: 0004H) 	When executing FB	■At start Does not start.	<p>Review the following settings of the axes corresponding to the detailed code.</p> <ul style="list-style-type: none"> • Designate an axis that has been set in the advanced synchronous control input/output axis setting to the main shaft, auxiliary shaft, sub input axis and slave axis of advanced synchronous control. • Correct the setting values if the advanced synchronous control input/output axis is outside the parameter range.
1AF1H	Axis	Advanced Synchronization Control Operation Overflow	<p>Overflow occurred in any of the modules of the output axis of synchronous control.</p> <ul style="list-style-type: none"> • Composite Main Shaft Gear (Detail code: 0001H) • Main Shaft Gear (Detail code: 0002H) • Main Shaft Clutch (Detail code: 0003H) • Main Shaft Module Speed Change Gear (Detail code: 0004H) • Auxiliary Shaft (Detail code: 0005H) • Auxiliary Shaft Gear (Detail code: 0006H) • Auxiliary Shaft Clutch (Detail code: 0007H) • Auxiliary Shaft Module Speed Change Gear (Detail code: 0008H) • Composite Auxiliary Shaft Gear (Detail code: 0009H) • Output Axis Speed Change Gear (Detail code: 000AH) • Output Axis Phase Compensation (Detail code: 000BH) • Output Axis Smoothing (Detail code: 000CH) • Output Axis Synchronous Control Change (Detail code: 000DH) • Output Axis Cam Operation (Detail code: 000EH) 	During operation	Stops the operation.	<p>Check the following settings of the modules corresponding to the detail codes.</p> <p>■Common</p> <ul style="list-style-type: none"> • Reduce the input axis velocity of the corresponding module. <p>■Main Shaft Gear/Auxiliary Shaft Gear</p> <ul style="list-style-type: none"> • Reduce the gear ratio (gear numerator/gear denominator) of the corresponding module. <p>■Output Axis Smoothing</p> <ul style="list-style-type: none"> • Review the setting value of the time constant to reduce the smoothing level, or increase the operation cycle. <p>■Composite Main Shaft Gear/Composite Auxiliary Shaft Gear</p> <ul style="list-style-type: none"> • Reduce the input values of the main and sub input axes of the main shaft. • Reduce the input values of the main shaft and auxiliary shaft. <p>■Output Axis Phase Compensation</p> <ul style="list-style-type: none"> • Reduce the advance time or increase the time constant for phase compensation. <p>■Output Axis Synchronous Control Change</p> <ul style="list-style-type: none"> • Reduce the synchronous control change value, or increase the synchronous control change reflection time. <p>■Output Axis Cam Operation</p> <ul style="list-style-type: none"> • Review the cam waveform so that the stroke does not change rapidly.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AF2H	Axis	Advanced Synchronous Control Restoration Disabled	<p>■For current position per cycle restoration When the Cam Axis Position Restoration Object was "0: Current Position per Cycle Restoration", the current position per cycle corresponding to the value output at the start of the advanced synchronous control could not be restored. (Occurs in reciprocating cam patterns.)</p> <p>■For cam set position restoration When the Cam Axis Position Restoration Object was "2: Cam Set Position Restoration, the difference between the restored output value and the set value of the slave axis at the start of the advanced synchronous control exceeded the value of the Cam Set Position Restoration: Allowable Movement Amount Setting, and the set position could not be restored.</p>	At start	<p>■At start Does not start.</p>	<p>■For current position per cycle restoration</p> <ul style="list-style-type: none"> • Move the slave axis to make sure that the current value per cycle is within the stroke of the reciprocating cam pattern before starting the advanced synchronous control. • Set the cam reference position to make sure that the current value per cycle is within the stroke of the reciprocating cam pattern. <p>■For cam set position restoration</p> <ul style="list-style-type: none"> • Calculate the restored output value using the cam position calculation function and move the slave axis accordingly before starting advanced synchronous control. • Increase the Cam Set Position Restoration: Allowable Movement Amount Setting if it is extremely small, for example, 0.
1AF3H	Axis	Out of Parameter Range (Advanced Synchronous Control Output Axis)	Parameter is out of the range.	At start At multiple start	<p>■At start Does not start.</p> <p>■At multiple start Stops the operation.</p>	Set the value within the range.
1AF4H	Axis	Out of Advanced Synchronous Control Output Axis Ring Counter range	If ring counter has been enabled for the output axis, the setting value of the ring counter is invalid.	At power ON	<p>■At power ON Generation of the advanced synchronous control output axis fails.</p>	<p>Set the ring counter upper and lower limit values as either of the following.</p> <ul style="list-style-type: none"> • Ring counter upper limit value = 10000000000.0, Ring counter lower limit value = -10000000000.0 • $0.0 < \text{Ring counter upper limit value} \leq 2147483648.0$, Ring counter lower limit value = 0.0
1AF5H	Axis/Axes group	FB Input Variable Error	<ul style="list-style-type: none"> • The value is out of range for FB Input Variable. (Detail code: 0001H) • The value is out of range for the following variables. <ul style="list-style-type: none"> · PositioningData.ProfileID.Number (Detail Code: 0003H) · StartDataNo (Detail Code: 0004H) · StepMode (Detail Code: 0005H) 	At start At multiple start	<p>■At start Does not start.</p> <p>■At multiple start Stops the operation.</p>	<ul style="list-style-type: none"> • Check the detailed information (Data Error Information), and set the variable displayed for "Data Name" within the range. (Detail code: 0001H) • Set the target variable within the range. (Detail code: 0003H to 0005H)
1AF6H	Axis/Axes group	Add-on Acquisition Failure	Failed to acquire the necessary add-on for Axis Generation, operation.	At power ON At ready ON At start At multiple start	<p>■At power ON/At ready ON Axis is not generated.</p> <p>■At start Does not start.</p> <p>■At multiple start Stops the operation.</p>	Check the detailed information, then install the displayed add-on (*.mpk) and enable it.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AF8H	Axis	Operation Profile Data Settings Incorrect Under Advanced Synchronous Control	Each operation profile data setting has been set to a value that cannot be used under advanced synchronous control. For error details and causes of each setting, refer to the following detail code. ☞ Page 974 Operation Profile Data Settings Incorrect Under Advanced Synchronous Control (error code: 1AF8H)	At start At multiple start During control	■At start Does not start. ■At multiple start Stops the operation. ■During control Stops the operation.	For the actions for each setting, refer to the following detail code. ☞ Page 974 Operation Profile Data Settings Incorrect Under Advanced Synchronous Control (error code: 1AF8H)
1AF9H	System	Cycle Assignment Incorrect (Axis)	"Communication Period Setting" in "Module Parameter (Network)" was set a period that cannot be used in the control cycle of an axis.	At power ON At ready ON	Generating axis fails.	If "Set" is set for "Setting in Units of 1μs" in "Basic Period Setting" of "Module Parameter (Network)", set one of the following in "Communication Period Interval Setting (Set it in Units of 1μs)". ■Earlier than version "32" 125.00μs, 250.00μs, 500.00μs, 1000.00μs, 2000.00μs, 4000.00μs, 8000.00μs ■Version "32" or later 125.00μs, 250.00μs, 500.00μs, 1000.00μs, 1500.00μs, 2000.00μs, 2500.00μs, 3000.00μs, 3500.00μs, 4000.00μs, 4500.00μs, 5000.00μs, 5500.00μs, 6000.00μs, 6500.00μs, 7000.00μs, 7500.00 μs, 8000.00μs
1AFAH	Axes group	Operation Profile Data Control Profile ID Setting Incorrect	The operation profile data specified in the PROFILE_ID type data is invalid due to each cause. For each error detail and cause, refer to the following detail code. ☞ Page 975 Operation Profile Data Control Profile ID Setting Incorrect (error code: 1AFAH)	At start At multiple start During control	■At start Does not start. ■At multiple start Stops the operation. ■During control Stops the operation.	For the actions for each cause, refer to the following detail code. ☞ Page 975 Operation Profile Data Control Profile ID Setting Incorrect (error code: 1AFAH)
1AFBH	Axes group	Invalid Post-Skip Control Method	The positioning data to be executed after the skip is invalid due to each factor. For each error detail and cause, refer to the following detail code. ☞ Page 976 Invalid Post-Skip Control Method (error code: 1AFBH)	During control	Stops the operation.	For the actions for each cause, refer to the following detail code. ☞ Page 976 Invalid Post-Skip Control Method (error code: 1AFBH)
1AFCH	Axis/Axes group	Speed Bias Value Speed Limit Over	The velocity bias value (<u>AxisName</u> (<u>AxesGroupName</u>).Pr.VelocityBias) was set to a value larger than the positive direction velocity limit value (<u>AxisName</u> .Pr.VelocityLimit_Positive), the negative direction velocity limit value (<u>AxisName</u> .Pr.VelocityLimit_Negative), and the velocity limit value (<u>AxesGroupName</u> .Pr.VelocityLimit).	At ready ON	The READY does not turn ON.	Set the speed bias value (<u>AxisName</u> (<u>AxesGroupName</u>).Pr.VelocityBias) to a value equal to or less than the positive direction speed limit value (<u>AxisName</u> .Pr.VelocityLimit_Positive), the negative direction speed limit value (<u>AxisName</u> .Pr.VelocityLimit_Negative), and the speed limit value (<u>AxesGroupName</u> .Pr.VelocityLimit).

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1AFDH	Axis/Axes group	Error Below Speed Bias Value	<p>A speed at which the target speed is not 0.0 and is less than the speed bias value set for the following parameter was specified during axis start.</p> <ul style="list-style-type: none"> • Single axis operation: axis parameters for the specified axis • Linear interpolation operation (composite speed): axis group parameter of the specified axis group • In linear interpolation operation (reference axis speed): axis parameter of reference axis • Linear interpolation operation (Long axis speed): axis parameter of Long axis • In circular interpolation operation: axis group parameters for the specified axis group 	At start	Does not start.	Review the speed override factor and set velocity so that the target speed is equal to or greater than the speed bias value.
1AFEH	Axis	Drive Unit Connection Setting Other Than MELSERVO Is Invalid.	<ul style="list-style-type: none"> • The calculation processing high-speed mode was enabled on axis to which drive unit other than MELSERVO was allocated. • An engine tool that does not support drive unit connections other than MELSERVO was used to set the parameters for assigning a drive unit other than MELSERVO to real drive axis. 	During initial	Unable to connect to the drive unit	<ul style="list-style-type: none"> • Set the fast mode setting (<u>AxisName</u>.PrConst.FastOperationMode) to something other than "5FE2H: fast mode". • Update engineering tools to a version that supports non-MELSERVO drive unit connections and set parameters.
1B00H	Axis	Start when Software Stroke Limit is Disabled	Started or multiple started with the software stroke limit disabled.	At start At multiple start	<p>■At start Does not start.</p> <p>■At multiple start Stops the operation.</p>	Set the software stroke limit so that it becomes effective.
1B01H	Axis	Forward-side Position Incorrect	<ul style="list-style-type: none"> • The "ForwardSidePosition" out of the software stroke limit range was set for the target position. (Detail code: 0001H) • The absolute value of the difference between "ForwardSidePosition" and the reference position exceeded the upper limit when using set position (<u>AxisName</u>.Md.SetPosition) as the reference position during require to change the control mode to the cyclic synchronous pressure mode (cspr). (Detail code: 0002H) 	At start At multiple start	<p>■At start Does not start.</p> <p>■At multiple start Stops the operation.</p>	<ul style="list-style-type: none"> • Set the "ForwardSidePosition" within the software stroke limit range. (Detail code: 0001H) • Set the "ForwardSidePosition" so that the absolute value of the difference from the reference position does not exceed $(2147483648 - 10 \times \text{encoder resolution} / \text{Electronic gear}) \times \text{driver unit conversion denominator/numerator}$. (Detail code: 0002H)
1B02H	Axis	Ramp Time Over	Pressure ramp time exceeded 8400 [s].	At start At multiple start	<p>■At start Does not start.</p> <p>■At multiple start Stops the operation.</p>	Set the Pressure/ PressureRamp in MCv_PressureControl so that the pressure ramp time does not exceed 8400 [s].
1B03H	Axis	Forward-side Position Exceeded	The absolute value of the difference between the set position (<u>AxisName</u> .Md.SetPosition) and the forward-side position (<u>AxisName</u> .Md.Cspr_ForwardSidePosition) at cspr exceeded the upper limit.	At start At multiple start	Stops the operation.	Revise the setting so that the absolute value of the difference does not exceed $(2147483648 - 10 \times \text{encoder resolution} / \text{Electronic gear}) \times \text{driver unit conversion denominator/numerator}$.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1B04H	Axis	Speed To Positioning Move Target Position Calculation Error	<p>An invalid result was obtained when recalculating the target position at the switch to positioning control in a Speed To Positioning Move.</p> <ul style="list-style-type: none"> The positioning travel amount to the target position in a Speed To Absolute Positioning exceeded the upper limit. (Detail Code: 0001H) In a Speed To Relative Positioning, the travel amount traced back by the ChangeSignal compensation time from the switch to positioning control exceeded Distance. Or, when Options "Position selection at speed position switching signal detection" is set to "1: Feedback Position," the difference between the feedback position and the commanded current position exceeds the travel amount since the switch to positioning control. (Detail Code: 0002H) In a Speed To Relative Positioning, when a negative value is set for the ChangeSignal compensation time, the travel amount since the switch to positioning control to the target position exceeded the upper limit. (Detail Code: 0003H). 	During control	Stops the operation.	<ul style="list-style-type: none"> Set Velocity/EndVelocity, Position, and Deceleration so that the travel amount up to the final positioning address does not exceed 20000000000.0. (Detail Code: 0001H) Review the settings so that the travel amount traced back by the ChangeSignal compensation time from the switch to positioning control does not exceed Distance. If the Options parameter "Position selection at speed position switching signal detection" is set to "1: Feedback Position," also review the settings so that the travel amount since the switch to positioning control is greater than the difference between the feedback position and the commanded current position. (Detail Code: 0002H) Review the settings so that the travel amount after switching to positioning control remains within the range -10000000000.0 to 10000000000.0. (Detail Code: 0003H).
1C40H	System	Network Parameter Error (Total No. of Stations < Station No.)	<p>■Add-on baseSystem version "1.15" or earlier</p> <p>The station number of the device station to connect to the network in "Network Configuration Settings" exceeds the total number of device stations configured.</p>	At power ON	The station cannot be connected to the drive unit.	Set the station number of the device station to connect to the network to be less than or equal to the total number of device stations.
1C41H	Axis	Watchdog Counter Error	A watchdog counter error of drive unit was detected.	During communication	Stops immediately.	<ul style="list-style-type: none"> When a stop error of the CPU module is detected, please check the error of the CPU module and take corrective action. Please review the communication period. Please check for errors in surrounding environment, e.g. noise, and remove the error factor. After the above procedure, please switch the power off and then on, or reset the CPU module.
1C42H	Axis	Unsupported Driver Connection	An unsupported drive unit was connected.	At power ON When connecting drive unit	Creating an instance of drive unit fails.	Please connect a supported drive unit.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1C43H	Axis	SLMP Communication Error	An error occurred in SLMP communication.	During communication	■During initial communication Unable to connect to the drive unit	<ul style="list-style-type: none"> • Open the object data setting window from object data setting in axis parameter setting window and delete object data where column "Object" is blank. • Please check the manual of the drive unit.
1C44H	System	Network Parameter Error (Station No. Order Error)	■Add-on baseSystem version "1.15" or earlier The station numbers of the device stations to connect to the network are not listed in ascending order in "Network Configuration Settings".	At power ON	The station cannot be connected to the drive unit.	Please set the station numbers of the device stations to connect to the network in ascending order.
1C45H	System	SLMP Communication Error (Timeout)	Response timeout was detected in SLMP communication.	During communication	Disable SLMP communication.	Please check the transient transmission time. It is derived by the following formula. (Transient Transmission Time = Communication Cycle Interval Setting - Cyclic Transmission Time - System Reserved Time)
1C46H	System	Time Synchronization Error	There is a disconnected station where time synchronization is incomplete.	At start communication	The station cannot be connected to the drive unit.	<ul style="list-style-type: none"> • Please change to a short communication cycle. • Please check surrounding environment errors such as noise etc., and remove the cause. • Please connect the stations set in the network configuration settings only.
1C47H	System	Communication Cycle Unsupported Driver Connection	An MR-J5(W)-G or MR-JET-G that does not support a communication cycle of 31.25/62.5μs was connected.	At start communication	The station cannot be connected to the drive unit.	Please check the version of MR-J5(W)-G or MR-JET-G amplifier and apply the latest version.
1C48H	System	PDO Mapping Setting Error	Abnormal response for PDO mapping setting was received from a device station.	At start communication	The station cannot be connected to the drive unit.	Please check the details of the error according to the error code (SDO Abort Code) and review the PDO mapping setting.
1C49H	System	Configuration Mismatch on Reconnection	A model name mismatch was detected on reconnection of device station.	At start communication	The station cannot be connected to the drive unit.	Please connect the device station with the same model name as the disconnected device station.
1C4CH	System	Power Not Turned ON After Parameter Distribution	After master-slave operation was enabled, the device station parameter automatic setting was performed.	At power ON	The station cannot be connected to the drive unit.	Start the system again.
1C4DH	System	Number of Master Axes Error	The number of master axes, set with the servo parameter "Driver communication setting (PD15.0)" in the device station parameter automatic setting, exceeds the number of settable axes.	At power ON	The station cannot be connected to the drive unit.	Keep the number of master axes, set with the servo parameter "Driver communication setting (PD15.0)" in the device station parameter automatic setting, at or below the number of settable axes.
1C4EH	System	Master Axis No. Error	The station No. of an own axis is specified for the servo parameter "Driver communication setting - Slave - Master axis 1 - Station No. setting (PD22)" in the device station parameter automatic setting.	At power ON	The station cannot be connected to the drive unit.	Review the master axis No. specified for the servo parameter "Driver communication setting - Slave - Master axis 1 - Station No. setting (PD22)" in the device station parameter automatic setting.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1C4FH	System	Master Axis Setting Error	The station No. of the master axis has not been specified for the servo parameter "Driver communication setting - Slave - Master axis 1 - Station No. setting (PD22)" in the device station parameter automatic setting.	At power ON	The station cannot be connected to the drive unit.	Review the master axis No. specified for the servo parameter "Driver communication setting - Slave - Master axis 1 - Station No. setting (PD22)" in the device station parameter automatic setting.
1C50H	System	Driver Communication Setting Error	Driver communication settings of the Motion module and servo amplifier are different.	At power ON	The station cannot be connected to the drive unit.	<ul style="list-style-type: none"> • Check the driver communication settings and the actually connected servo amplifier. • After setting the module type and configuring the servo parameters "Driver communication setting (PD15.0), (PD15.1)", "Driver communication setting - Slave - Master axis 1 - Station No. setting (PD22)", and "Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting (PD23.1)" in the device station parameter automatic setting, write the settings you made to the project, then switch the power off and on again or reset the PLC. After that, power the servo amplifier off and then on, and power cycle or reset the PLC again.
1C51H	Axis	Slave Axis Specification Error	The station address of the slave axis was set in the station address setting.	When connecting drive unit	Unable to connect to the drive unit.	Set a station address other than the slave axis in the station address setting.
1C52H	Axis	Driver Position Unit Error	Motion system detected an unsupported driver position unit.	When connecting	Unable to connect to the drive unit.	Set the driver unit for drive unit location to something other than "degree".
1C53H	Axis	Driver Speed Unit Error	Motion system detected an unsupported driver speed unit.	When connecting	Unable to connect to the drive unit.	Set drive unit speed driver unit to something other than "r/min". Or use an drive unit with Encoder Increments or Motor revolutions other than 0pulse.
1C54H	System	Drive Unit Version Combination Error	MR-J5-G-LL whose version is earlier than F0 is connected. (Error Description: 00000001H)	At start communication	The station cannot be connected to the drive unit.	Check the version of MR-J5-G-LL and apply the latest version. (Error Description: 00000001H)
1C80H	System/ Axis	Cycle Over	Operation processing or other fixed scan processing is not completed within the set cycle.	During operation	The axis in operation decelerates and stops.	<ul style="list-style-type: none"> • Change the fixed scan interval setting of fixed scan execution type program to a larger value. • Change the communication cycle interval setting or buffer memory refresh cycle to a larger value. • When using by an operation cycle of 31.25μs, please begin with a minimum configuration of add-ons, and then add more add-ons as required according to the load of the system. • When the inter-module synchronization function is enabled, please be sure to execute the EI instruction with the PLC to enable I44 interrupt programs.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1C81H	System	Cycle Assignment Incorrect	The value is out of range for system basic cycle, the first operation cycle, buffer memory refresh cycle, or the value which cannot be set was specified.	At power ON	Operates in default operation cycle.	Please set the following within the range. <ul style="list-style-type: none"> • System.PrConst.OperationCycle[1].Cycle • System.PrConst.BuffermemoryRefreshCycle.Cycle
1C83H	System	Boot Software File Error	The file of boot software is abnormal.	At power supply	The motion system does not start.	Please install the boot software again.
1C84H	System	Saved File Number Over	The saved file reached the upper limit value.	At saving files	The files cannot be saved.	Please delete all the saved files.
1C85H	System	Event History File Incorrect	<ul style="list-style-type: none"> • An error was detected in the event history file. • The memory capacity of add-on MotionEventHist is insufficient. • The drive specified for System.PrConst.EventHistoryMotion_Path is not mounted. 	At updating the event history file.	Updating the event history file stops.	<ul style="list-style-type: none"> • Delete unnecessary files and secure free capacity. • Format the target drive. • Delete event history files. • Please check the memory capacity of a dd-on MotionEventHist. • Please check the status of the target drive (System.Md.Storage_*).
1C86H	System	Out of Cycle Over Error Selection Range	The value is out of range for Cycle Over Error Selection.	At power ON	Operates in default cycle over error type.	Please set the following within the range. <ul style="list-style-type: none"> • System.PrConst.OperationCycle[1].CycleOverErrorType • System.PrConst.BuffermemoryRefreshCycle.CycleOverErrorType
1C87H	System	Label Incorrect (at system startup)	Failed to import the label definition.	At power ON	Interrupts the process to import the labels.	<ul style="list-style-type: none"> • Please write label settings. • If the device label import error occurred, please refer to the corrective action for device label import error.
1C88H	System	Label Memory Shortage	Label which exceeds the label capacity has been defined.	At power ON At ready ON	Interrupts the process to import the labels.	<ul style="list-style-type: none"> • Please change the System.Md.LabelMemoryFreeSize to a larger value. • Please check the label usage.
1C8EH	System	Variable Manager Acquisition Failure	Failed to acquire variable manager.	At power ON	The add-on which is described in the detailed information is invalid function.	Please re-install the baseSystem.smpk
1C8FH	System	Add-on SignalIO Acquisition Failure	Failed to acquire the add-on SignalIO.	At power ON At ready ON	<ul style="list-style-type: none"> ■At power ON Generating axis fails. ■At ready ON The READY does not turn ON. 	Install SignalIO.mpk and enable it.
1C91H	System	Insufficient Memory Capacity of Add-on SignalIO	Cannot create a signal, because the memory capacity of the add-on SignalIO is insufficient.	At power ON At ready ON	<ul style="list-style-type: none"> ■At power ON Generating axis fails. ■At ready ON The READY does not turn ON. 	<ul style="list-style-type: none"> • Increase the memory capacity of add-on SignalIO. • Increase the memory capacity of add-on ExternalSignal.
1C93H	System	Network Driver Memory Size Over	The memory size of the network driver exceeds the memory capacity set in system.	At power ON	SLMP communication error.	<ul style="list-style-type: none"> • Please increase the memory capacity set in system. • Please delete unnecessary stations and reduce memory size.
1C94H	System	Absolute Position Management Backup Data Saving Failure	Failed to save the backup data because of insufficient capacity in the Ich drive.	During operation	Files are not saved.	<ul style="list-style-type: none"> • Please check the free capacity in the Ich drive and delete unnecessary files. • Please check the capacity of motion event histories if the destination to save motion event histories is the Ich drive.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1C95H	System	Label Instance Error	An error occurred in the corresponding add-on for the label instances.	At power ON At ready ON	Interrupts the process to import the labels.	<ul style="list-style-type: none"> • Please check the version of the corresponding add-on for the labels. • Please increase the maximum RAM size of the corresponding add-on for the labels.
1C96H	System	Device Label Import Error	<ul style="list-style-type: none"> • There are inconsistencies in network configuration settings and the settings at device label creation. • Failed to import device labels. • A moderate error occurred in the motion module. 	At power ON	Interrupts the process to import the labels.	<ul style="list-style-type: none"> • Please check the settings of network configuration and then create device labels again. • Refer to the remedy for the moderate error occurred in the motion module.
1C99H	System	Backup Data Saving Failure	<ul style="list-style-type: none"> • Failed to save the backup data because of insufficient capacity in the backup data write area. • The backup data is corrupted. 	During operation	Backup data are not saved.	<ul style="list-style-type: none"> • Please delete unnecessary cam data and positioning data. • Please execute parameter initialization and flash ROM write.
1C9BH	System	Advance Synchronous Control Add-on Memory Shortage	<p>System memory for add-on AdvancedSync is insufficient.</p> <ul style="list-style-type: none"> • Failed to create the input/output data. (Detail code: 0001H) • Failed to create the backup data. (Detail code: 0002H) 	At power ON	The add-on is invalid function.	<p>Increase the memory capacity of add-on AdvancedSync.</p> <p>Delete unnecessary labels and reduce memory usage.</p>
1C9CH	System	Advanced Synchronous Control Smoothing Memory Shortage	<p>The smoothing memory could not be secured because the system memory of add-on AdvancedSync is insufficient.</p> <p>The memory could not be secured for the smoothing time constants corresponding to the detail codes shown below.</p> <ul style="list-style-type: none"> • PrConst.SmoothingTimeConstant (Detail code: 0001H) • PrConst.MasterSpeedChangeGearSmoothingTimeConstant (Detail code: 0002H) • PrConst.MasterClutchSmoothingTimeConstant (Detail code: 0003H) • PrConst.AuxSpeedChangeGearSmoothingTimeConstant (Detail code: 0004H) • PrConst.AuxClutchSmoothingTimeConstant (Detail code: 0005H) • PrConst.OutSpeedChangeGearSmoothingTimeConstant (Detail code: 0006H) 	At power ON At ready ON	The corresponding input axis/output axis becomes invalid.	<ul style="list-style-type: none"> • Increase the memory capacity of add-on AdvancedSync. • Review the setting value of the time constant to reduce the smoothing level, or increase the operation cycle.
1C9DH	System	Advanced Synchronous Control Input Axis Incorrect	<p>Invalid values have been set in axis parameters of the input axes of advanced synchronous control. (Refer to the detail code in event history for the cause.)</p> <ul style="list-style-type: none"> • The label ID of the input axis of advanced synchronous control is duplicated. (Detail code: 0001H) • The axis No. of the input axis of advanced synchronous control is duplicated. (Detail code: 0002H) 	At power ON	<p>■At power ON</p> <p>Generation of the advanced synchronous control input axis fails.</p>	<ul style="list-style-type: none"> • Review the settings so that the label IDs of the input axis for advanced synchronization control do not overlap. • Review the settings so that the axis Nos. of the input axis for advanced synchronization control do not overlap.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
1C9EH	System	Advanced Synchronous Control Output Axis Incorrect	An invalid value is set in axis parameters of the output axis of advanced synchronous control. (Refer to the detail code in event history for the cause.) <ul style="list-style-type: none"> The label ID of the output axis of advanced synchronous control is duplicated. (Detail code: 0001H) The axis No. of the output axis of advanced synchronous control is duplicated. (Detail code: 0002H) An invalid axis type (real encoder axis/virtual encoder axis) is set for the output axis of advanced synchronous control. (Detail code: 0003H) 	At power ON	■At power ON Generation of the advanced synchronous control output axis fails.	<ul style="list-style-type: none"> Set the label ID of the output axis of advanced synchronous control avoiding duplication. Set the axis No. of the output axis of advanced synchronous control avoiding duplication. Set a valid axis type for the output axis of advanced synchronous control.
1CAFH	System	Add-on Error (Minor)	An add-on error occurred.	Depends on the add-on	Depends on the add-on	Check the manual of the add-on for details about the detail code.
1D80H	System	Out of Parameter Range (Axis)	Parameter is out of the range.	When executing FB At power ON At ready ON	■When executing FB The error of FB turns ON and the command is not executed. ■At power ON Generating axis fails. ■At ready ON The READY does not turn ON.	Change the specified value of the parameter in detailed information within the range.
1D81H	System	Out of Parameter Range (Axes Group)	Parameter is out of the range.	When executing FB At power ON At ready ON	■When executing FB The error on FB turns ON and the command is not executed. ■At power ON Generating axes group fails. ■At ready ON The READY does not turn ON.	Change the specified value of the parameter in detailed information within the range.
1D82H	System	Out of Parameter Range (System)	Parameter is out of the range.	When executing FB At power ON At ready ON	■When executing FB The error of FB turns ON and the command is not executed. ■At power ON/At ready ON The READY does not turn ON.	Change the specified value of the parameter in detailed information within the range.
1D83H	System	Parameter Write-protected	Wrote in the parameter which can only read.	When executing FB	The error of FB turns ON and the command is not executed.	Change to the parameter that can be written.
1D85H	System	Out of Parameter Range (Advanced Synchronous Control Input Axis)	Parameter is out of the range.	At power ON	■At power ON Generation of the advanced synchronous control input axis fails.	Set the value within the range.
1D86H	System	Out of Parameter Range (Advanced Synchronous Control Output Axis)	Parameter is out of the range.	At power ON	■At power ON Generation of the advanced synchronous control output axis fails.	Set the value within the range.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
2300H	System	Security Key Authentication Error	The security key which locks the program does not match the key written to the motion system.	At ready ON	The program stops.	Please review the security key.
2301H	System	Security Key Authentication Error	Program is locked by the security key, but there is no security key written to the motion system.	At ready ON	The program stops.	Please review the security key.
2302H	System	Security Key Authentication Error	<ul style="list-style-type: none"> The security key set in the file is corrupted and does not match the key written to the motion system. The security key set in the motion system is corrupted and does not match the key set in the file. 	At ready ON	The program stops.	Please write files to the motion again. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the motion system. Please consult your local Mitsubishi representative.
3200H	System	File Access Error	<p>The following operations were performed via engineering tool or SLMP.</p> <ul style="list-style-type: none"> An access (read/write) from another request source to the file which was being written was executed. Writing from another request source to the file which was being accessed (read/write) was executed. 	When accessing file	Fails to access the files.	Please execute the next access after the processing of one request source is completed.
3203H	System	WDT Error Detected	<p>The following errors were detected in the software or hardware.</p> <p><Software></p> <p>■Programming</p> <ul style="list-style-type: none"> It exceeded 2.0 [s] from start to end of the execution. (Initial execution type) The execution time of all normal execution type programs exceeded 1.0 [s]. <p>■Execution time monitor</p> <p>Operation processing or other processing was in abnormal conditions. Processing stopped for more than 1 [s].</p> <p><Hardware></p> <p>An error was detected in the hardware.</p>	During operation	<ul style="list-style-type: none"> The axis in operation stops immediately or decelerate stops. Stops the system. 	<p>Please take the following actions.</p> <p><Software></p> <p>■Programming</p> <p>Reduce the number of command execution of initial execution type and normal execution type by program.</p> <p>■Execution time monitor</p> <ul style="list-style-type: none"> Change the communication cycle interval setting or buffer memory refresh cycle to a larger value. Change the fixed scan interval setting of fixed scan execution type program to a larger value. <p><Hardware></p> <ul style="list-style-type: none"> Please take measures to reduce noise. Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3205H	System	Add-on Library Load Error	<ul style="list-style-type: none"> The add-on or add-on file is broken. Alternatively, an error occurred during initialization processing. (Detail Code: 0001H) Dependent add-ons are not installed or enabled. Or, the version is inconsistent. (Detail Code: 0002H) An add-on with incorrect combination is installed or enabled. Or, the version is inconsistent. (Detail Code: 0003H) An add-on with the same name is installed or enabled. (Detail Code: 0004H) 	At power ON	Add-on The motion system does not start.	<ul style="list-style-type: none"> Please install the software or add-on again. (Detail Code: 0001H). Please install or enable dependent add-ons. Alternatively, install the correct version of the add-on. (Detail Code: 0002H) Please delete or disable the add-on that cannot be combined. Alternatively, install the correct version of the add-on. (Detail Code: 0003H) Please delete or disable the add-on with the same name. (Detail Code: 0004H)
3207H	System	Drive Error	<ul style="list-style-type: none"> Failed to mount the drive. Check disk ended with error. A verification error of plane management target memory occurred. 	At system start	Access to the target drive is not allowed.	Format the target drive.
3208H	System	Insufficient Total System Memory (RAM)	The total number of System.PrConst.Addon_*.RamSizeMax of all add-ons exceeds the total size of system memory (RAM).	At power ON	The motion system does not start.	Please make the total number of System.PrConst.Addon_*.RamSizeMax of all add-ons not exceed the total size of system memory (RAM).
3209H	System	Insufficient Add-on System Memory (RAM)	Memory that exceeded System.PrConst.Addon_*.RamSizeMax has been used.	At power ON During operation	<ul style="list-style-type: none"> ■At power ON The motion system does not start. ■During operation WDT error occurs if the function has an effect on control. 	Please increase System.PrConst.Addon_*.RamSizeMax.
320AH	System	Insufficient Total System Memory (Backup RAM)	The total number of System.PrConst.Addon_*.BackupRamSizeMax of all add-ons exceeds the total size of system memory (backup RAM).	At power ON	The motion system does not start.	Please make the total number of System.PrConst.Addon_*.BackupRamSizeMax of all add-ons not exceed the total size of system memory (backup RAM).
320BH	System	Insufficient Add-on System Memory (Backup RAM)	Memory that exceeded System.PrConst.Addon_*.BackupRamSizeMax has been used.	At power ON During operation	<ul style="list-style-type: none"> ■At power ON The motion system does not start. ■During operation WDT error occurs if the function has an effect on control. 	Please increase System.PrConst.Addon_*.BackupRamSizeMax.
320CH	System	Cycle Over	Operation processing or other fixed scan processing is not completed within the set cycle.	During operation	The axis in operation stops immediately or decelerate stops.	<ul style="list-style-type: none"> Change the fixed scan interval setting of fixed scan execution type program to a larger value. Change the communication cycle interval setting or buffer memory refresh cycle to a larger value. When using by an operation cycle of 31.25μs, please begin with a minimum configuration of add-ons, and then add more add-ons as required according to the load of the system. When the inter-module synchronization function is enabled, please be sure to execute the EI instruction with the PLC to enable I44 interrupt programs.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
320DH	System	Base System Error	<ul style="list-style-type: none"> Failed to configure labels. Failed in initial process. 	At power ON	The motion system does not start.	Please reinstall the software and rewrite the program. If the same error occurs again, there may be a hardware fault in the Motion module. Please consult the nearest Mitsubishi Electric System Service Co., Ltd. or our branch office or agent.
320EH	System	Network Driver Error	Failed in communication between motion area and network area.	At power ON During operation	<ul style="list-style-type: none"> The motion system does not start. The axis in operation stops immediately. 	Please reinstall the software and rewrite the program. If the same error occurs again, there may be a hardware fault in the Motion module. Please consult the nearest Mitsubishi Electric System Service Co., Ltd. or our branch office or agent.
320FH	System	Servo Driver Error	Failed to initialize the servo driver.	At power ON During operation	<ul style="list-style-type: none"> The motion system does not start. The axis in operation stops immediately or decelerate stops. 	Please reinstall the software and rewrite the program. If the same error occurs again, there may be a hardware fault in the Motion module. Please consult the nearest Mitsubishi Electric System Service Co., Ltd. or our branch office or agent.
3212H	System	Public Label Address Check Error	Refresh target of public label is incorrect.	At power ON	Interrupts the process to import the labels.	Please install the latest add-on and engineering tool.
3217H	System	Add-on SimpleMotion Acquisition Failure	Failed to acquire the add-on SimpleMotion.	At power ON	The motion system does not start.	Install SimpleMotion.mpk and enable it.
3218H	System	Add-on SimpleMotion Internal Error	Failed in initial process of the add-on SimpleMotion.	At power ON	The motion system does not start.	Please install the software again.
3219H	System	Add-on SimpleMotion Memory Shortage	System memory for the add-on SimpleMotion is insufficient.	At power ON	The motion system does not start.	Please install the software again.
3228H	System	Standard Station Communication Cycle Combination Error	After setting the device station as a standard station in "Network Configuration Settings", a value less than 125μs was set for "Communication Period Interval Setting".	At power ON	<ul style="list-style-type: none"> Data link does not start. The READY does not turn ON. 	In "Network Configuration Settings", set the device station that is currently a standard station as a motion control station, or set "Communication Period Interval Setting" to a value equal to or more than 125μs.
3229H	System	Motion Synchronization Station Send/Receive Data Refresh Method Setting Combination Error	System.PrConst.Link_MotionStationRefreshType (motion synchronization station send/receive data refresh method) is set to 0 (respond preferred method) while Communication Period Setting is set to 31.25μs.	At power ON	<ul style="list-style-type: none"> Unable to connect to the drive unit. Refresh of the slave label is not executed. 	Set "Communication Period Setting" to 62.5μs or more, or change the System.PrConst.Link_MotionStationRefreshType (motion synchronization station send/receive data refresh method) to 1 (operation cycle preferred method).
322AH	System	Communication Period Interval Setting Combination Error	<p>The following settings were made after setting a value less than 125μs for "Communication Period Interval Setting".</p> <ul style="list-style-type: none"> "Multicast" was set in "Communication Mode". "Ring" was set in "Network Topology". Set a value equal to or more than 125μs for 	At power ON	<ul style="list-style-type: none"> Data link does not start. The READY does not turn ON. 	<p>Set "Communication Period Interval Setting" to a value equal to or more than 125μs, or perform the following settings.</p> <ul style="list-style-type: none"> Set "Unicast" to "Communication mode". Set "Line or Star or mixture of Line/Star" to "Network Topology".

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
322BH	System	Motion Control Station Setting Error	Any of the items in "Network Configuration Settings" under "Basic Settings" are set as follows. <ul style="list-style-type: none"> • A local station was set as the motion control station. • The communication period setting of the remote station designated as the motion control station was set to other than "Basic Period". 	At power ON	<ul style="list-style-type: none"> • Data link does not start. • The READY does not turn ON. 	Please correct the parameters shown in the cause.
322CH	System	Link Device Setting Error	The following settings were made while the start/end of the link device for the device station which was set as the motion control station in "Network Configuration Settings" had not been set. <ul style="list-style-type: none"> • A local station was set in "Network Configuration Settings". • "Communication Mode" was set to "Multicast". 	At power ON	<ul style="list-style-type: none"> • Data link does not start. • The READY does not turn ON. 	Through GX Works3 version 1.085P or later, set the start/end of the link device for the station which is set as the motion control station in network configuration settings, or make the following settings. <ul style="list-style-type: none"> • Change the device station set as the motion control station in "Network Configuration Settings" to be a standard station. • Remove local stations from "Network Configuration Settings". • Set "Unicast" to "Communication Mode".
322FH	System	Add-on Error (Moderate)	An add-on error occurred	Depends on the add-on	Depends on the add-on	Check the manual of the add-on for details about the detail code.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3230H	System	Driver Communication Setting Error 1	<ul style="list-style-type: none"> There are abnormal values in the driver communication settings (servo parameters in the device station parameter automatic setting). There are errors in the network configuration settings. 	At power ON	Data link does not start.	<ul style="list-style-type: none"> Please check the driver communication settings (servo parameters in the device station parameter automatic setting). Please set the number of slave axes drove by the master axis within the range of 1 to 8. Please do not enable driver communication for multi-axis servo amplifiers. Please set the servo parameter "Driver communication setting - Slave - Master axis 1 - Control slave axis No. setting (PD23.1)" of each slave axis belonging to the same master axis avoiding duplication. Please do not enable driver communication for stations for which the station-specific mode setting in the network configuration settings has been set to "Motion Mode (Safety)". Please set the master axis to a real drive axis, and set slave axes to motion control stations. Please specify an authentication Class B device for a master-slave operation enabled axis. Please review the Master-slave Operation - Slave Axis Station Address Setting. Please write the project where master-slave operation has been enabled.
3231H	System	Driver Communication Setting Error 2	The communication cycle or communication speed setting is not supported by driver communication.	At power ON	Data link does not start.	<ul style="list-style-type: none"> Set the factor of "Low-Speed" in "Multiple Period Setting" to be 128 times or less after multiplying by the driver communication factor (basic). Please set the communication speed to 1Gbps. Please invalidate the inter-module synchronization. To connect a CC-Link IE TSN Class A device station, please set the "TSN HUB Setting" to "Use TSN HUB".
3233H	System	File Error	Parameter settings are corrupted.	When importing file	The file is not imported. The motion system does not start.	Please write the program again.
3234H	System	Ring Topology Unsupported Station Detection	A station that did not support ring topology was detected.	At start communication	Does not data link.	Update stations that do not support ring topology to a version that supports ring topology. Alternatively, set "Line", "Star", or "Line/Star" in "Network Topology" under "Basic Settings" of the master station.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3235H	System	Driver Communication Cyclic Transmission Time Setting Error	The cyclic transmission time setting does not support driver communication function.	At power ON	Data link does not start.	Set the value of "Cyclic Transmission Time" in "Communication Period Setting" in "Basic Settings" of the master station to not less than Cyclic transmission time of detailed information and not more than 216μs. If the cyclic transmission time of detailed information exceeds 216μs, reduce the number of stations connected to the master station and the number of link devices allocated to each device in "Network Configuration Settings".
3236H	System	Driver Communication Period Interval Setting Error	"Communication Period Interval Setting" does not support Driver communication function.	At power ON	Data link does not start.	In "Communication Cycle Setting" of "Basic Settings" of the master station, set the value of "Communication Cycle Period Interval" shall be set so that it is greater than or equal to the communication cycle interval of detailed information and less than or equal to 4000μs, and one of the following shall apply. <ul style="list-style-type: none"> • 125μs • 250μs • 500μs • 1000μs • 2000μs • 4000μs If the communication cycle interval for detailed information exceeds 4000μs, do one of the following. <ul style="list-style-type: none"> • Decrease the "Cyclic Transmission Time" setting. • Reduce the number of devices connected to the master station and the number of link devices allocated to each unit in "Network Configuration Settings".
3237H	System	PDO Size Over	The size of the PDO exceeds the configurable range when the CANopen device station is set to motion control station.	At power ON	<ul style="list-style-type: none"> • Data link does not start. • The READY does not turn ON. 	Among CANopen supported device station, set the station as motion control station as follows. <ul style="list-style-type: none"> • Set the RWr and RWw settings within 40 points from "Network Configuration" in the unit parameters (network).
3400H	System	Out of Axis No. Range	<ul style="list-style-type: none"> • The value is out of range for axis No. • Invalid axis No. has been set. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> • Set the value within the range of 1 to 10000. • Set the axis No. in which instance is created.
3401H	System	Axis No. Duplication Setting	The same axis No. has been set to master axis and slave axis.	At start When executing FB	Does not execute FB.	Set different axis No. to master axis and slave axis.
3402H	System	Out of Axes Group No. Range	<ul style="list-style-type: none"> • The value is out of range for axes group No. • Invalid axes group has been set. 	When executing FB	Does not execute FB.	<ul style="list-style-type: none"> • Set the value within the range of 1 to 10000. • Set the axes group No. in which instance is created.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3403H	System	Out of Master Axis No. Range	<ul style="list-style-type: none"> The value is out of range for master axis No. Invalid axis No. has been set. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value within the range of 1 to 10000. Set the axis No. in which instance is created.
3404H	System	Out of Slave Axis No. Range	<ul style="list-style-type: none"> The value is out of range for slave axis No. Invalid axis No. has been set. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value within the range of 1 to 10000. Set the axis No. in which instance is created.
3405H	System	Out of Master Axis 1 No. Range	<ul style="list-style-type: none"> The value is out of range for axis No. of master axis 1. An unavailable axis No. is set. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value within the range of 1 to 10000. Set the axis No. in which instance is created.
3406H	System	Out of Master Axis 2 No. Range	<ul style="list-style-type: none"> The value is out of range for axis No. of master axis 2. Invalid axis No. has been set. 	At start When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set the value within the range of 1 to 10000. Set the axis No. in which instance is created.
3407H	System	Out of Latch Count Range	The value is out of range for RecordCount.	When executing FB	Does not execute FB.	Set the value within the range.
3408H	System	Latch Count Incorrect	The value has been out of range for RecordCount when RecordMode=RecordCount, RingBuffer.	When executing FB	Does not execute FB.	Set the value of RecordCount within the range.
3409H	System	Out of Touch Probe ID Range	The probe ID of a touch probe that does not exist in Touch probe ID (TouchProbeID) was set.	When executing FB	Does not execute FB.	Set the probe ID of an existing touch probe to Touch probe ID (TouchProbeID).
340DH	System	Out of Compensation Time Range	The value is out of range for CompensationTime.	When executing FB	Does not execute FB.	Set the value within the range of -5.0 to 5.0 [s].
340EH	System	Out of Latch Mode Range	The value is out of range for RecordMode.	When executing FB	Does not execute FB.	Set the value of MC_RECORD_MODE within the range.
340FH	System	No Operation Profile Data	<ul style="list-style-type: none"> PROFILE_DATA.Location is not set. The operation profile data does not exist in PROFILE_DATA.Location. 	When executing FB During operation	<ul style="list-style-type: none"> Does not execute FB. The execution of FB is interrupted. 	Set the operation profile data storage location for PROFILE_DATA.Location.
3410H	System	Operation Profile Data Incorrect	<ul style="list-style-type: none"> An error occurred in the file format of operation profile data (file). (Detail Code: 1001H) Failed to write operation profile data (file). (Detail Code: 1002H) Operation profile data format or interpolation method specification is invalid. (Detail Code: 1003H) Operation profile data setting is out of range. (Detail Code: 1004H) 1 cycle current values are not in ascending order. (Detail Code: 1005H) 	During operation	The execution of FB is interrupted.	<ul style="list-style-type: none"> Set the value in the range for operation profile data (file) according to the file format. (Detail Code: 1001H) Set the value in the range to match the file format. (Detail Code: 1002H) Set the value in the range for operation profile data format or interpolation method specification. (Detail Code: 1003H) Set the value in the range. (Detail Code: 1004H) Arrange the current values per cycle in ascending order. (Detail Code: 1005H)
3411H	System	Operation Profile Data Being Operated	Operation was executed while the operation profile data was being operated by another FB.	During operation	The execution of FB is interrupted.	Operate it again after another FB is completed (Busy of FB is FALSE.).
3412H	System	Operation Profile Data Error	The operation profile data is broken, or the format is incorrect.	During operation	The execution of FB is interrupted.	Set the operation profile data in a correct format.
3413H	System	Out of Offset Range	Offset exceeds the number of elements of the operation profile data (in a file or open area).	During operation	The execution of FB is interrupted.	Set Offset to a value that does not exceed the number of elements of the operation profile data (in a file or open area).

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3414H	System	Out of Operation Profile Data ID Range	Set the value of ProfileData.ID.Number or ProfileID.Number within the range.	At start During operation	<ul style="list-style-type: none"> ■At start Does not execute FB. ■During operation Operates with previous setting value. 	Set the value of ProfileData.ID.Number or ProfileID.Number within the range.
341DH	System	Out of MasterAbsolute Range	The value is out of range for MasterAbsolute.	When executing FB	Does not execute FB.	Set the value within the range.
341EH	System	Out of SlaveAbsolute Range	The value is out of range for SlaveAbsolute.	When executing FB	Does not execute FB.	Set the value within the range.
342FH	System	SD Memory Card Detached	The SD memory card was removed without being disabled	When removing SD memory card	—	Remove the SD memory card after disabling it.
343FH	System	Out of Backlash Amount Range	The value is out of range for BacklashAmount.	When executing FB	Does not execute FB.	Set the value within the range.
344EH	System	MC_SetPosition Instruction Error	During the execution of MC_SetPosition, an error occurred due to any of the following causes. <ul style="list-style-type: none"> • Position is out of range (Detail Code: 0001H) • ExecutionMode is out of range (Detail Code: 0002H) • The current position after changing is out of range of software stroke limit (Detail Code: 0003H) • Axis status at execution is incorrect (Detail Code: 0004H) • Another MC_SetPosition was executed for the specified axis (Detail Code: 0008H) • Options is out of range (Detail Code: 0009H) 	At start During operation	<ul style="list-style-type: none"> • Does not execute FB. • The execution of FB is interrupted. 	<ul style="list-style-type: none"> • Set Position within the range. • Set ExecutionMode within the range. • Set the values so that the current position after changing is within the software stroke limit range. • Execute it when the axis status is Standstill. • Execute another MC_SetPosition after completing MC_SetPosition. • Set Options within the range.
3450H	System	MCv_SetTorqueLimit Instruction Error	During the execution of MCv_SetTorqueLimit, an error occurred due to any of the following causes. <ul style="list-style-type: none"> • PositiveValue is out of range. (Detail Code: 0001H) • NegativeValue is out of range. (Detail Code: 0002H) • ExecutionMode is out of range. (Detail Code: 0003H) • Axis type is incorrect. (Detail Code: 0004H) • Axis status at execution is incorrect. (Detail Code: 0005H) • Another MCv_SetTorqueLimit was executed for the specified axis. (Detail Code: 0006H) • Options is out of range. (Detail Code: 0007H) 	At start During operation	Does not execute FB.	<ul style="list-style-type: none"> • Set PositiveValue within the range. • Set NegativeValue within the range. • Set ExecutionMode within the range. • Execute it for an axis whose axis type is real drive axis. • Execute it when the axis status is Standstill. • Execute another MCv_SetTorqueLimit after completing MCv_SetTorqueLimit. • Set Options within the range.
3451H	System	Out of Start Mode Range	The value is out of range for ExecutionMode.	At start	Does not execute FB.	Set the value of ExecutionMode within the range.
3452H	System	Insufficient Operation Profile Data ID	The profile ID to be assigned automatically is insufficient.	During operation	The execution of FB is interrupted.	Specify and open the unused profile ID.
3453H	System	Operation Profile Data Control Unsupported	Control FB was executed for the unsupported operation profile data.	At start	Does not execute FB.	Open operation profile data which supports the operation profile data control FB in the open area.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
345EH	System	Operation Profile Data Read/Write Unsupported	Operation profile data which does not support operation profile data read/write is set.	During operation	The execution of FB is interrupted.	Set operation profile data which supports read/write.
345FH	System	Out of Read Target/Write Target Range	The value is out of range for Target.	During operation	The execution of FB is interrupted.	Set a value within the range for Target.
3460H	System	Read/Write Data Data Type Incorrect	The incorrect data type is set in Data1 or Data2.	During operation	The execution of FB is interrupted.	Set a normal data type in Data1 and Data2.
3461H	System	Read/Write Data Data Name Specification Method Incorrect	The incorrect data name specification method is set in Data1 or Data2.	During operation	The execution of FB is interrupted.	Set a normal data name specification method in Data1 and Data2.
3462H	System	Read/Write Data Type Incorrect	<ul style="list-style-type: none"> An incorrect type is set in Data1 or Data2. Add-on that supports the operation profile data format has not been installed. 	During operation	The execution of FB is interrupted.	<ul style="list-style-type: none"> Set a normal type in Data1 and Data2. Install and enable the add-on that supports the operation profile data format.
3463H	System	Read/Write Data Target Modification Incorrect	The incorrect target modification is set in Data1 or Data2.	During operation	The execution of FB is interrupted.	Specify a normal target modification in Data1 and Data2.
3464H	System	Number of Read/Write Data Mismatch	Points do not match the number of elements of read/write structured data type.	During operation	The execution of FB is interrupted.	Set Points to match with the number of elements of read/write structured data type.
3465H	System	Number of Offset/Read/Write Data Incorrect	<ul style="list-style-type: none"> Values other than Offset = 0 and Points = 0 were set when read target/write target was a file. Points were set to 0 when the writing destination was the open area and Offset wasn't set to 0. The source DataNo. isn't 0 and different from the writing destination DataNo. when writing multiple axes positioning data to the open area. 	During operation	The execution of FB is interrupted.	<ul style="list-style-type: none"> Set Offset = 0 and Points = 0 when the read target/write target was a file. Set Points to 0 when the writing destination was the open area and Offset wasn't set to 0. Set the writing source DataNo. to 0 or set the same value as the writing destination DataNo. when writing multiple axes positioning data to the open area.
3466H	System	Out of Current Value per Cycle Range	The value is out of range for Cycle.	During operation	The execution of FB is interrupted.	Set the value of Cycle within the range.
3467H	System	Current Value per Cycle Change Unsupported	FB which does not support the current value per cycle change is set.	At start	Does not execute FB.	Set FB which supports the current value per cycle change.
3468H	System	No Instance ID	The set instance ID does not exist.	At start	Does not execute FB.	Set an existing instance ID.
3470H	System	SD Memory Card is not Inserted	SD memory card is not inserted.	During operation	The execution of FB is interrupted.	Execute it after SD memory card inserted.
3471H	System	SD Memory Card is Write-protected	SD memory card is write-protected.	During operation	The execution of FB is interrupted.	Execute it after cancelling SD memory card write-protected.
3492H	System	Operation Profile Data Add-on System Memory Shortage	System memory for the add-on is insufficient.	At ready ON	The program stops.	<ul style="list-style-type: none"> Please check the System.PrConst.Addon_ProfileControl.RamSizeMax. Please check the setting to reduce the usage of the open area. Please reduce the number of FBs to be executed simultaneously.
3493H	System	Operation Profile Data Add-on Internal Error	An error occurred in internal of operation profile data add-on.	At ready ON	The program stops.	<ul style="list-style-type: none"> Please install the software again. Please write the program again.
3494H	System	Axis Status Incorrect (When Axes Group is Enabled)	MC_GroupEnable was executed when AxisName.Md.AxisStatus of a configuration axis is other than Standstill or Disabled.	When Axes Group is Valid	The axes group status does not turn to "GroupStandby".	Execute MC_GroupEnable after setting Standstill or Disabled in AxisName.Md.AxisStatus of all configuration axes.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3495H	System	Axes Group Status Incorrect (When Axes Group is Enabled)	MC_GroupEnable was executed when <u>AxesGroupName.Md.GroupStatus</u> is other than GroupStandby or GroupDisabled.	When Axes Group is Valid	Does not execute FB.	Execute MC_GroupEnable when <u>AxesGroupName.Md.GroupStatus</u> is GroupStandby or GroupDisabled.
3496H	System	Axes Group Configuration Axis Is in Use	MC_GroupEnable was executed for an axes group in which the <u>AxisName.Md.UseInGroup</u> of a configuration axis is TRUE (the configuration axis is in use in another axes group).	When Axes Group is Valid	The axes group status does not turn "GroupStandby".	Disable the axes group in use and execute MC_GroupEnable.
3497H	System	MCv_ChangeCycle Instruction Error	During the execution of MCv_ChangeCycle, an error occurred due to each cause. For each error detail and cause, refer to the following detail code. ☞ Page 976 MCv_ChangeCycle Instruction Error (error code: 3497H)	At start During operation	<ul style="list-style-type: none"> Does not execute FB. The execution of FB is interrupted. 	For the actions for each cause, refer to the following detail code. ☞ Page 976 MCv_ChangeCycle Instruction Error (error code: 3497H)
3499H	System	Add-on Memory Shortage	System memory for the related add-ons is insufficient.	At start up	Does not execute FB.	Please increase System.PrConst.Addon_*.RamSizeMax of related add-ons.
349AH	System	Memory Shortage	The memory capacity in which MCFB instance is created is insufficient.	When executing dedicated instruction	Dedicated instruction is completed with the error.	Check setting data.
349BH	System	Motion Command Execution at STOP	Motion Command Execution was executed when it is in STOP status.	When executing dedicated instruction	Dedicated instruction is completed with the error.	Set module to RUN status.
349CH	System	Out of Velocity Override Factor (VelFactor) Range	The value is out of range for VelFactor.	During control	Continues the operation with the previous value.	Set VelFactor within the range.
349DH	System	Out of Acceleration Override Factor (AccFactor) Range	The value is out of range for AccFactor.	During control	Continues the operation with the previous value.	Set AccFactor within the range.
349EH	System	Out of Jerk Override Factor (JerkFactor) Range	The value is out of range for JerkFactor.	During control	Continues the operation with the previous value.	Set JerkFactor within the range
349FH	System	Latch Data Storage Shortage	<ul style="list-style-type: none"> The number of elements specified for OutputBuffer is less than RecordCount. Access to the outside of device or label range was made. 	When executing FB During operation	Does not execute FB.	<ul style="list-style-type: none"> Set the number of elements specified for OutputBuffer to be more than RecordCount. Adjust settings to avoid an access to the outside of the range.
34A0H	System	Out of Backlash Compensation Direction Range	The value is out of range for BacklashDirection.	When executing FB	Does not execute FB.	Set the value within the range.
34A1H	System	Parameter Reading And Writing FB Execution Disabled Error	<ul style="list-style-type: none"> Unable to execute the parameter reading FB or the parameter writing FB. An unconnected station or a station that does not exist was set. Before issued a SLMP request, PLC READY was turned OFF. 	When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Check the setting data. Check the execution count of transient transmission. Check the sequence program which turns PLC READY ON/OFF.
34A2H	System	Out of Parameter No. Range	The value is out of range for ParameterNumber.	When executing FB	Does not execute FB.	Set the value within the range.
34A3H	System	Out of Option Range	The value is out of range for Options.	When executing FB	Does not execute FB	Set the value within the range.
34A4H	System	MC_AbortTrigger Unsupported	FB which does not support MC_AbortTrigger (the touch probe disabling) is set.	When executing FB	Does not execute FB.	Set FB which supports MC_AbortTrigger (the touch probe disabling).

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
34A5H	System	Signal Target Incorrect	<ul style="list-style-type: none"> An incorrect string was set for the Target of the signal. An unconnected or non-existent station was set when [OBJ] was specified. A non-existent object was set for TPDO/RPDO when [OBJ] was specified. 	When executing FB	Does not execute FB.	<ul style="list-style-type: none"> Set to a valid string for the Target of the signal. Connect the target station if [OBJ] has been specified. Set the target object for TPDO/RPDO if [OBJ] has been specified.
34A6H	System	Out of Detection Setting Range of Signal	The value is out of range for Detection.	When executing FB	Does not execute FB.	Set the value of Detection within the range.
34A7H	System	Out of CompensationTime Setting Range of Signal	The value is out of range for CompensationTime.	When executing FB	Does not execute FB.	Set the value of CompensationTime within the range.
34A8H	System	Out of FilterTime Setting Range of Signal	The value is out of range for FilterTime.	When executing FB	Does not execute FB.	Set FilterTime within the range.
34ABH	System	Add-on Acquisition Failure	Failed to acquire the necessary add-on for FB execution.	When executing FB	Does not execute FB.	Check the detailed information, then install the displayed add-on (*.mpk) and enable it.
34ACH	System	MCv_AdvCamPositionPerCycleCalc Instruction Error	<p>During the execution of MCv_AdvCamPositionPerCycleCalc, an error occurred due to each cause.</p> <p>For each error detail and cause, refer to the following detail code.</p> <p>☞ Page 976</p> <p>MCv_AdvCamPositionPerCycleCalc Instruction Error (error code: 34ACH)</p>	During operation	The execution of FB is interrupted.	<p>For the actions for each cause, refer to the following detail code.</p> <p>☞ Page 976</p> <p>MCv_AdvCamPositionPerCycleCalc Instruction Error (error code: 34ACH)</p>
34ADH	System	MCv_AdvCamSetPositionCalc Instruction Error	<p>During the execution of MCv_AdvCamSetPositionCalc, an error occurred due to each cause.</p> <p>For each error detail and cause, refer to the following detail code.</p> <p>☞ Page 977</p> <p>MCv_AdvCamSetPositionCalc Instruction Error (error code: 34ADH)</p>	During operation	The execution of FB is interrupted.	<p>For the actions for each cause, refer to the following detail code.</p> <p>☞ Page 977</p> <p>MCv_AdvCamSetPositionCalc Instruction Error (error code: 34ADH)</p>
34AFH	System	Unable to Calculate Cam Position Under Advanced Synchronous Control	The corresponding current position per cycle could not be calculated during the current value per cycle calculation. (Occurs in reciprocating cam patterns.)	During operation	The execution of FB is interrupted.	Set "StrokeAmount", "ReferenceSetPosition", and "SetPosition" within the stroke range of the reciprocating cam pattern.
34B0H	System	Operation Profile Data Settings Incorrect for Cam Position Under Advanced Synchronous Control	<p>Each operation profile data setting has been set to the value that cannot be used for calculating cam position.</p> <p>For each error detail and cause, refer to the following detail code.</p> <p>☞ Page 977</p> <p>Operation Profile Data Settings Incorrect for Cam Position Under Advanced Synchronous Control (error code: 34B0H)</p>	During operation	The execution of FB is interrupted.	<p>For the actions for each cause, refer to the following detail code.</p> <p>☞ Page 977</p> <p>Operation Profile Data Settings Incorrect for Cam Position Under Advanced Synchronous Control (error code: 34B0H)</p>
34B2H	System	MCv_MovePositioningData Instruction Error	<p>When MCv_MovePositioningData was executed or being executed, an error occurred.</p> <p>The detected positioning data No. (data No.) and the related error code (related event code) are stored in the detailed information (operation profile data control information).</p>	<p>When executing FB</p> <p>During FB execution</p>	<p>Does not execute FB.</p> <p>The execution of FB is interrupted.</p>	<ul style="list-style-type: none"> Review the settings of the positioning data No. where the error occurred. Check the corrective actions for the related error code.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
34F8H	System	Device/Label Specification Incorrect	<ul style="list-style-type: none"> A device or label that cannot be used in the instruction was specified. In the assignment of structure type label, an assignment was made to satisfy all of the following conditions. <ul style="list-style-type: none"> - Include Private label in structure members. - Assignment between public label and private label. 	When executing instruction	Program stops/keeps Follow the setting below. Operation setting at error: Invalid device/label/buffer memory specification	<ul style="list-style-type: none"> Please check and correct error occurrence points. When assigning a structure type label, make sure that the source and destination public label settings match.
34F9H	System	FB/FUN Called Incorrect	The function block (FB) or function (FUN) specified in the program does not exist.	When executing instruction	The program stops.	<ul style="list-style-type: none"> Please check the error occurrence points and correct it. Please write the program again.
34FAH	System	Label Temporary Area Incorrect	The label temporary area was used incorrectly.	When executing instruction	The program stops.	Please perform all the following operations from Motion Control Setting Function and write the program again. <ul style="list-style-type: none"> From the menu, select [Convert]⇒[Rebuild All]. From the menu, select [Online]⇒[Delete Module Data]⇒Check all the checkboxes on "Online Data Operation" screen⇒[Execute].
34FBH	System	DI Instruction Nesting Number Error	The number of nesting levels in the DI instruction exceeded its limit (16).	When executing instruction	The program stops.	Please change the number of nesting levels (16 or less).
34FCH	System	FB/FUN Call Nesting Number Error	The number of nesting levels in the function block (FB) or function (FUN) exceeded its limit (32).	When executing instruction	The program stops.	Please change the number of nesting levels (32 or less).
34FDH	System	Pointer execution error	<ul style="list-style-type: none"> The target pointer specified in the instruction does not exist. Exceeded the usable range when the array elements was specified dynamically. 	When executing instruction	The program stops.	<ul style="list-style-type: none"> Please check the error occurrence points and correct it. Please write the program again.
34FEH	System	Label Temporary Area Exceeded	The secured label temporary area size exceeded its limit.	When executing instruction	The program stops.	<ul style="list-style-type: none"> Please increase the capacity of label area. Please write the program again.
34FFH	System	Operation Error	Division where the divisor is zero was performed.	When executing instruction	Program stops/continues Follow the setting below. Operation setting at error: Operation error	Please check and correct error occurrence points.
3500H	System	Operation Error	Incorrect data that cannot be converted by using the data conversion instruction was input.	When executing instruction	Program stops/continues Follow the setting below. Operation setting at error: Operation error	Please check and correct error occurrence points.
3501H	System	Operation Error	The operation was performed with the invalid data (denormalized number, NaN (not a number), or $\pm\infty$).	When executing instruction	Program stops/continues Follow the setting below. Operation setting at error: Operation error	Please check and correct error occurrence points.
3502H	System	Operation Error	Overflow occurred during calculation.	When executing instruction	Program stops/continues Follow the setting below. Operation setting at error: Operation error	Please check and correct error occurrence points.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3503H	System	File Incorrect	The program file is incorrect or is not correctly written.	When executing instruction	Interrupts importing the files.	Please write the program again.
3504H	System	Insufficient Memory Capacity	Failed to execute PSCAN/PSTOP instruction because the execution count of PSCAN/PSTOP instruction in 1 scan is too many.	When executing instruction	The program stops.	Please correct it so that it does not execute unnecessary PSCAN/PSTOP instructions after checking the error occurrence points.
3505H	System	Memory Error	The memory jump destination is out of the range for memory assignment.	When executing instruction	The program stops.	Please write the program again.
3506H	System	Device/Label Specification Incorrect	<ul style="list-style-type: none"> The device or label specified in the instruction exceeded the usable range. Insufficient number of array elements. 	When executing instruction	Program stops/continues Follow the setting below. Operation setting at error: Invalid device/label/buffer memory specification	Please check and correct error occurrence points.
3507H	System	Operation Error	The data out of the specified range was input.	When executing instruction	Stops/continues Follow the setting below. Operation setting at error: Operation error	Please check and correct error occurrence points.
3508H	System	Operation Error	The operation result is out of the output range. (When the result of the instruction that concatenate character strings exceeded the allowable number of characters)	When executing instruction	Stops/continues Follow the setting below. Operation setting at error: Operation error	Please check and correct error occurrence points.
3509H	System	Program Name Specification Incorrect	The program specified in the instruction is not registered to the program setting.	During END processing	Stops/continues Follow the setting below. Operation setting at error: File name specification	Modify it to a correct program name.
350AH	System	Program Error	The program includes an instruction that cannot be used or decoded.	At ready ON	The program stops.	Please check the corresponding program, and correct it.
350BH	System	END Instruction Error	The END (FEND) instruction does not exist in the program.	At ready ON	The program stops.	<ul style="list-style-type: none"> Please check the corresponding program, and correct it. Please write the program and FB program again.
350CH	System	Program Execution Error	<ul style="list-style-type: none"> After the global label setting file was modified, only the global label setting was written. Or, after the global label setting was modified, only the program and FB/FUN were written. (The global label setting file was not written.) After the FB/FUN was modified, only the FB/FUN was written. Or, after the FB/FUN was modified, only the program and global label setting were written. (The FB/FUN was not written.) After the buffer memory refresh setting of the global label setting was modified, only the program and FB/FUN were written to PLC. (The global label setting was not written.) 	At ready ON	The program stops.	Please write the program, FB/FUN and global label setting.
350DH	System	Insufficient Memory Capacity	Insufficient capacity of program storage location.	At ready ON	The program stops.	Please check the memory capacity of ST add-on.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
350EH	System	FB FUN Program Error	FB/FUN program configuration is incorrect.	At ready ON	The program stops.	<ul style="list-style-type: none"> • Please check the corresponding file, and correct it. • Please write the program and FB/FUN again.
350FH	System	Operation Error	A link direct device or buffer memory access device is specified for both (s) and (d) used in the BMOV instruction.	At ready ON	The program stops.	Please check the BMOV instruction of corresponding file, and correct it.
3510H	System	Device/Label Specification Incorrect	<ul style="list-style-type: none"> • The device or label specified in the instruction exceeded the usable range. • Array was not selected. 	At ready ON	The program stops.	Please check the corresponding file, and correct it.
3511H	System	FB FUN Execution Error	Before the FB/FUN program ends, the call source program ended.	At ready ON	The program stops.	<ul style="list-style-type: none"> • Please check the corresponding file, and correct it. • Please write the program and FB/FUN again.
3512H	System	Parameter Error	The fixed scan program interval exceeded 16 kinds.	At ready ON	The program stops.	Please set the fixed scan program interval within 16 kinds.
3513H	System	Parameter Error	<p>The "Fixed Scan Interval Setting" of the program whose "Execution Type" is set to "3: Fixed Scan" in "Program Execution Setting" is one of the following.</p> <ul style="list-style-type: none"> • Values out of the range • Other than multiplication by n of the first operation cycle 	At ready ON	The program stops.	<ul style="list-style-type: none"> • Set the program's "Fixed Scan Interval Setting" to satisfy all of the following. • From the first operation cycle to 60,000ms. • Multiplication by n of the first operation cycle. • If you want the program to operate according to the "Fixed Scan Interval Setting" you set, review the "Communication Period Setting" in "Module Parameter (Network)".
3514H	System	Program Error	The execution type that cannot be changed has been specified.	During END processing	The program stops.	Please specify the execution type that can be changed.
3515H	System	MCFB Specification Incorrect	Undefined MCFB exists.	At ready ON	The program stops.	<ul style="list-style-type: none"> • Please write the program again. • Please check if the necessary add-on has been installed in MCFB execution.
3516H	System	MCFB Execution Error	Unable to execute MCFB.	When executing instruction	The program stops.	<ul style="list-style-type: none"> • Please check if the label area which is out of range has not been written. • Please write the program again.
3517H	System	ST Add-on System Memory Shortage	System memory for the add-on is insufficient.	At ready ON	The program stops.	Please check the System.PrConst.Addon_Program_ST.RamSizeMax.
3518H	System	ST Add-on Internal Error	An error occurred in ST add-on.	At ready ON	The program stops.	<ul style="list-style-type: none"> • Please install the software again. • Please write the program again.
3C00H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3C01H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3C02H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3C03H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3C0FH	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3C10H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3C11H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.

Error code	Error	Error name	Error detail and cause	Detection timing	Operation at error occurrence	Action
3C13H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the motion module. Please consult your local Mitsubishi representative.
3C14H	System	Hardware Error	An error was detected in the hardware.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3C2FH	System	Memory Error	An error was detected in the memory.	During operation	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please format the memory. After that, please write all files and reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.
3F00H	System	Firmware Version Unsupported	The firmware version is not supported by the CPU module.	At power ON	Stops the system.	Please use a CPU module which supports Motion modules.
3F40H	System	Hardware Error	An error was detected in the hardware.	At initialization	Stops the system.	<ul style="list-style-type: none"> • Please take measures to reduce noise. • Please reset the Motion module. If the same error occurs again even after taking the above, the possible cause is a hardware failure of the Motion module. Please consult your local Mitsubishi representative.

Detailed information

■Start Not Possible (error code: 1AADH)

The detail codes for Start Not Possible (error code: 1AADH) are shown below.

Detail code	Error detail and cause	Action
0001H	Moderate error detection	Start after clearing the medium error.
0002H	PLC READY OFF	<ul style="list-style-type: none"> Start when PLC READY and READY are turned ON. Review the sequence program that changes PLC READY status.
0003H	Forced stop signal ON	Start when the emergency stop release is ON.
0004H	Axis stop signal ON	Start when the stop state is OFF.
0005H	Hardware stroke limit override incorrect at homing start	When homing starts, do not set the hardware stroke limit override to ONLY_INSIDE.
0100H	Axis/axes group status incorrect	<ul style="list-style-type: none"> Check the power status of the drive unit, wiring, and connector connections. Start after transition of Axis Status (<u>AxisName</u>.Md.AxisStatus) to "4: Standstill". Start after transition of Axes Group Status (<u>AxesGroupName</u>.Md.GroupStatus) to "4: GroupStandby".
0101H	Axes group operating	Disable the axis group for axes where the axis group in use is ON.
0102H	Configuration axis status incorrect	<ul style="list-style-type: none"> Check the power status of the drive unit, wiring, and connector connections. Start after transition of Axis Status (<u>AxisName</u>.Md.AxisStatus) to "4: Standstill".

■Operation Profile Data Settings Incorrect Under Advanced Synchronous Control (error code: 1AF8H)

The detail codes for Operation Profile Data Settings Incorrect Under Advanced Synchronous Control (error code: 1AF8H) are shown below.

Detail code	Error detail and cause	Action
0001H	Profile data type incorrect	Set the profile data type to "1: Cam Data".
0002H	Operation profile data format incorrect	Set the operation profile data format to "0: Linear Interpolation", "1: Section Interpolation", or "2: Spline Interpolation".
0003H	The operation is not repetitive.	Set repetitive operation to "1: Enable".
0004H	The master axis (input) absolute coordinate is not set to relative coordinate.	Set master axis (input) absolute coordinate to "0: Relative Coordinate".
0005H	The slave axis (output) absolute coordinate is not set to relative coordinate.	Set slave axis (output) absolute coordinate to "0: Relative Coordinate".
0006H	The starting point is not 0.	Set the starting point to "0".
0007H	The initial stroke is not 0.	Set the initial stroke to "0".
0008H	The cam starting point (<u>AdvOutputName</u> .Pr.Cam.StartingPoint) exceeded the resolution.	Set the cam starting point (<u>AdvOutputName</u> .Pr.Cam.StartingPoint) to a value smaller than the resolution.
0009H	The target operation profile data is being operated by another FB.	End the FB that is operating the target operation profile data.
000AH	The output coordinate is set to a value exceeding 32 bits.	If the operation profile data format is "0: Linear Interpolation", correct the cam data so that no output values will exceed 32 bits.
000BH	An output value calculated by extending the line segment between two coordinates exceeded 32 bits.	Adjust the slope between the two coordinates so that the output value calculated by extending the line segment between them does not exceed 32 bits within the length per cycle.

■Operation Profile Data Control Profile ID Setting Incorrect (error code: 1AFAH)

The detail codes for Operation Profile Data Control Profile ID Setting Incorrect (error code: 1AFAH) are shown below.

Detail code	Error detail and cause	Action
0001H	It was not opened to the open area specified in the PROFILE_ID type data.	Open the operation profile data to the open area specified in the PROFILE_ID type data.
0002H	The type of the open area specified in the PROFILE_ID type data is invalid.	Specify an open area that is available for operation profile data control.
0003H	The target operation profile data is being operated by another FB.	End the FB that is operating the target operation profile data.
1001H	The value is out of range for OperationPattern.	Set OperationPattern within the range.
1002H	The value is out of range for ControlMethod.	Set ControlMethod within the range.
1003H	The value is out of range for DwellTime.	Set DwellTime within the range.
1004H	The value is out of range for McodeOutput_Override.	Set McodeOutput_Override within the range.
1005H	The value is out of range for JumpDestinationDataNo.	Set JumpDestinationDataNo within the range.
1006H	The value is out of range for LoopCount.	Set LoopCount within the range.
1007H	The value is out of range for ConditionSignalNo or the signal has not been configured for the No. specified with ConditionSignalNo.	Set ConditionSignalNo within the range or set the condition signal for the No. specified with ConditionSignalNo.
1008H	The value is out of range for SkipSignalNo or the signal has not been configured for the No. specified with SkipSignalNo.	Set SkipSignalNo within the range or set the condition signal for the No. specified with SkipSignalNo.
1101H	For some positioning data whose control method is JUMP, JumpDestinationDataNo has been set to a positioning data No. whose control method is also JUMP.	Set JumpDestinationDataNo to a positioning data No. whose control method is not JUMP.
1102H	Positioning data of another control method was continuously executed exceeding the limit.	Set the positioning data, which has another control method, so that it won't be continuously executed exceeding the limit.
1211H to 121AH	An invalid string was specified for a string of the target (Target) of any of Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10). *: Each detail code of Condition signal 1 (ConditionSignal1) to Condition signal 10 (ConditionSignal10) is from 1211H to 121AH.	Set the valid string for the target (Target) of applicable Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10).
1221H to 122AH	The value is out of range for the Signal detection method (Detection) of any of Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10). *: Each detail code of Condition signal 1 (ConditionSignal1) to Condition signal 10 (ConditionSignal10) is from 1221H to 122AH.	Set the Signal detection method (Detection) of applicable Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) within the range.
1231H to 123AH	The value is out of range for the Compensation time (CompensationTime) of any of Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10). *: Each detail code of Condition signal 1 (ConditionSignal1) to Condition signal 10 (ConditionSignal10) is from 1231H to 123AH.	Set the Compensation time (CompensationTime) of applicable Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) within the range.
1241H to 124AH	The value is out of range for the Filter time (FilterTime) of any of Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10). *: Each detail code of Condition signal 1 (ConditionSignal1) to Condition signal 10 (ConditionSignal10) is from 1241H to 124AH.	Set the Filter time (FilterTime) of applicable Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) within the range.
1311H to 131AH	An invalid string was specified for a string of the target (Target) of any of Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10). *: Each detail code of Skip signal 1 (SkipSignal1) to Skip signal 10 (SkipSignal10) is from 1311H to 131AH.	Set the valid string for the target (Target) of applicable Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10).
1321H to 132AH	The value is out of range for the Signal detection method (Detection) of any of Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10). *: Each detail code of Skip signal 1 (SkipSignal1) to Skip signal 10 (SkipSignal10) is from 1321H to 132AH.	Set the Signal detection method (Detection) of applicable Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10) within the range.
1331H to 133AH	The value is out of range for the Compensation time (CompensationTime) of any of Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10). *: Each detail code of Skip signal 1 (SkipSignal1) to Skip signal 10 (SkipSignal10) is from 1331H to 133AH.	Set the Compensation time (CompensationTime) of applicable Condition signal 1 to Condition signal 10 (ConditionSignal1 to ConditionSignal10) within the range.

Detail code	Error detail and cause	Action
1341H to 134AH	The value is out of range for the Filter time (FilterTime) of any of Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10). *: Each detail code of Skip signal 1 (SkipSignal1) to Skip signal 10 (SkipSignal10) is from 1341H to 134AH.	Set the Filter time (FilterTime) of applicable Skip signal 1 to Skip signal 10 (SkipSignal1 to SkipSignal10) within the range.

■Invalid Post-Skip Control Method (error code: 1AFBH)

The detail codes for Invalid Post-Skip Control Method (error code: 1AFBH) are shown below.

Detail code	Error detail and cause	Action
0001H	When skipping, the control method (ControlMethod) of the next positioning data is "0103H: Absolute value circular interpolation (CircularAbsolute)". When skipping, when the control method (ControlMethod) passes only the positioning data of "0102H: Relative value linear interpolation (LinearRelative)" or "0104H: Relative value circular interpolation (CircularRelative)", it anticipates the positioning data of "0103H: Absolute value circular interpolation (CircularAbsolute)". Or, it has passed through "0101H: Absolute value linear interpolation (LinearAbsolute)" positioning data, but has anticipated "0103H: Absolute value circular interpolation (CircularAbsolute)" positioning data, which is an interpolation axis different from its interpolation axis.	Make sure that the control method (ControlMethod) executes "0101H: Absolute value linear interpolation (LinearAbsolute)" positioning data between the positioning data to be skipped and "0103H: Absolute value circular interpolation (CircularAbsolute)" positioning data. In addition, set the interpolation axis for "0101H: Absolute value linear interpolation (LinearAbsolute)" positioning data to include the interpolation axis for "0103H: Absolute value circular interpolation (CircularAbsolute)" positioning data.
0002H	When skipping, the control method (ControlMethod) was "0101H: Absolute value linear interpolation (LinearAbsolute)" and Velocity mode (VelocityMode) was looking ahead to "1: Long Axis Velocity (LongAxisSpeed)" positioning data.	For positioning data to be executed after skipping, set Velocity mode (VelocityMode) to something other than "1: Long Axis Velocity (LongAxisSpeed)".
0003H	After skipping, the positioning data of "0103H: Absolute value circular interpolation (CircularAbsolute)" was read ahead while the control method (ControlMethod) passed only the positioning data of "0102H: Relative value linear interpolation (LinearRelative)" or "0104H: Relative value circular interpolation (CircularRelative)". Alternatively, you have read ahead the positioning data of "0103H: Absolute value circular interpolation (CircularAbsolute)", which is an interpolation axis that has passed through the positioning data of "0101H: Absolute value linear interpolation (LinearAbsolute)" but is different from its interpolation axis.	Make sure that the control method (ControlMethod) executes "0101H: Absolute value linear interpolation (LinearAbsolute)" positioning data between the positioning data to be skipped and "0103H: Absolute value circular interpolation (CircularAbsolute)" positioning data. In addition, set the interpolation axis for "0101H: Absolute value linear interpolation (LinearAbsolute)" positioning data to include the interpolation axis for "0103H: Absolute value circular interpolation (CircularAbsolute)" positioning data.

■MCv_ChangeCycle Instruction Error (error code: 3497H)

The detail codes for MCv_ChangeCycle Instruction Error (error code: 3497H) are shown below.

Detail code	Error detail and cause	Action
0001H	Current value per cycle (Cycle) is out of range.	Set Current value per cycle (Cycle) within the range.
0002H	Execution mode (ExecutionMode) is out of range.	Set Execution mode (ExecutionMode) within the range.
0004H	MCv_ChangeCycle (Current Value Change per Cycle) was executed when the axis status was "7: During synchronous operation (SynchronizedMotion)".	Execute it when the axis status is "4: Standby (Standstill)".
0008H	Another MCv_ChangeCycle (Current Value Change per Cycle) was executed with the specified instanceID.	Execute another MCv_ChangeCycle (Current Value Change per Cycle) after the current MCv_ChangeCycle (Current Value Change per Cycle) is completed.
0009H	Options (Options) is out of range.	Set Options (Options) within the range.
000AH	MCv_ChangeCycle (Current Value Change per Cycle) was executed when the axis status was "4: Standby (Standstill)".	Execute it when the axis status is "7: During synchronous operation (SynchronizedMotion)".

■MCv_AdvCamPosition PerCycleCalc Instruction Error (error code: 34ACH)

The detail codes for MCv_AdvCamPositionPerCycleCalc Instruction Error (error code: 34ACH) are shown below.

Detail code	Error detail and cause	Action
0001H	The Ring counter upper limit (RingCountUpperValue) is out of range.	Set the Ring counter upper limit (RingCountUpperValue) within the range.
0002H	The cam position length per cycle (LengthPerCycle) is out of range.	Set the cam position length per cycle (LengthPerCycle) within the range.

Detail code	Error detail and cause	Action
0003H	Set the cam position calculation stroke amount (StrokeAmount) within the range.	Set the cam position calculation stroke amount (StrokeAmount) within the range.
0004H	The cam position calculation current position per cycle (PositionPerCycle) is out of range.	Set the values so that the cam position calculation current position per cycle (PositionPerCycle) is within the range.
0005H	The cam position calculation cam reference position (ReferenceSetPosition) is out of range.	Set the cam position calculation cam reference position (ReferenceSetPosition) within the range.
0006H	Set the cam position calculation set position (SetPosition) is out of range.	Set the cam position calculation set position (SetPosition) within the range.
0007H	The cam starting point for cam position calculation (StartingPoint) is out of range.	Set the cam starting point for cam position calculation (StartingPoint) within the range.

■MCv_AdvCamSetPositionCalc Instruction Error (error code: 34ADH)

The detail codes for MCv_AdvCamSetPositionCalc Instruction Error (error code: 34ADH) are shown below.

Detail code	Error detail and cause	Action
0001H	The Ring counter upper limit (RingCountUpperValue) is out of range.	Set the Ring counter upper limit (RingCountUpperValue) within the range.
0002H	The cam position length per cycle (LengthPerCycle) is out of range.	Set the cam position length per cycle (LengthPerCycle) within the range.
0003H	Set the cam position calculation stroke amount (StrokeAmount) within the range.	Set the cam position calculation stroke amount (StrokeAmount) within the range.
0004H	The cam position calculation current position per cycle (PositionPerCycle) is out of range.	Set the values so that the cam position calculation current position per cycle (PositionPerCycle) < the cam position length per cycle (LengthPerCycle).
0005H	The cam position calculation cam reference position (ReferenceSetPosition) is out of range.	Set the cam position calculation cam reference position (ReferenceSetPosition) within the range.
0007H	The cam starting point for cam position calculation (StartingPoint) is out of range.	Set the cam starting point for cam position calculation (StartingPoint) within the range.

■Operation Profile Data Settings Incorrect for Cam Position Under Advanced Synchronous Control (error code: 34B0H)

The detail codes for Operation Profile Data Settings Incorrect for Cam Position Under Advanced Synchronous Control (error code: 34B0H) are shown below.

Detail code	Error detail and cause	Action
0001H	Profile data type incorrect	Set the profile data type to "1: Cam Data".
0002H	Operation profile data format incorrect	Set the operation profile data format to "0: Linear Interpolation", "1: Section Interpolation", or "2: Spline Interpolation".
0003H	The operation is not repetitive.	Set repetitive operation to "1: Enable".
0004H	The master axis (input) absolute coordinate is not set to relative coordinate.	Set master axis (input) absolute coordinate to "0: Relative Coordinate".
0005H	The slave axis (output) absolute coordinate is not set to relative coordinate.	Set slave axis (output) absolute coordinate to "0: Relative Coordinate".
0006H	The starting point is not 0.	Set the starting point to "0".
0007H	The initial stroke is not 0.	Set the initial stroke to "0".
0008H	The cam starting point for cam position calculation (StartingPoint) exceeded the resolution.	Set the cam starting point for cam position calculation (StartingPoint) to a value smaller than the resolution.
0009H	The target operation profile data is being operated by another FB.	End the FB that is operating the target operation profile data.
000AH	The output coordinate is set to a value exceeding 32 bits.	If the operation profile data format is "0: Linear Interpolation", correct the cam data so that no output values will exceed 32 bits.
000BH	An output value calculated by extending the line segment between two coordinates exceeded 32 bits.	Adjust the slope between the two coordinates so that the output value calculated by extending the line segment between them does not exceed 32 bits within the length per cycle.

24.7 List of Logging Error Codes

Error code	Cause	Action
4008H	The system is in the BUSY state.	Execute it again after a certain period of time has elapsed.* ¹
4030H	Data logging was started in the following status. • Data logging with an invalid device name was specified.	Check the specified device name.
4053H	An error occurred during writing data to the specified drive.	• Check the specified drive, and then write data again. • Replace the target drive, and then write data again.
4080H	An error in the request/setting data.	Check the specified data and write it again.
40C0H	Specified label name does not exist.	• Check the label name. • Execute it again after the module RUN when using local labels.* ¹
40C1H	Failed to access in label name because specified array number is larger than array size.	Reduce value of specified array, and specify within array size.
41CCH	• Started the data logging in the status that sub folder for storing the file (folder) to be used in each function cannot be created or accessed. • Unable to create and access file (folder) used in each function during data saving or data logging execution.	Execute it again after checking the file name and sub folder name.* ¹
41CDH	• Registered in the status that file (folder) cannot be created or accessed because any of the existing files (folders) has the same name as the file (folder) to be used in each function. • Unable to create and access file (folder) during data saving or data logging execution.	• Do not access the specified file or folder. • Execute it again after checking the file or folder.* ¹
41CEH	The specified file is read only and write protected.	The specified file is write protected. Check the attributes and then execute it again.* ¹
41D0H	No free space in the specified drive, or the number of files in the directory of the specified drive has exceeded the maximum limit.	• Increase the free space in the drive and then execute it again. • Delete the files in the drive and then execute it again.* ¹
41D2H	Unsupported function.	• Check if the related add-on is installed. • Add-on SignalIO is required to use devices or labels. • Add-on MotionEventHist is required to use "Event History" for the trigger condition.
41F4H	Unable to execute request content since operation protected in the system is executed.	Enable auto-logging.
4262H	The number of data points exceeds the maximum (1024 points).	Make the number of data points per setting less than 1024.
4277H	Data logging was started in the following status. • The number of saved files exceeding the set number while the "operation for exceeding file number" was set to "Stop". • The number of files exceeding the number of saved files while the "operation for exceeding file number" was set to "Overwrite".	• Execute it again after deleting the files in the memory for saving the data logging results. • Execute it again after changing the save destination.* ¹
4283H	Registered when the number of records exceeded the number of collectable records at the set internal buffer capacity.	• Correct the internal buffer capacity setting. • Reduce the number of records.
4288H	Unable to execute the request because the specified file name has exceeded the maximum number of characters.	Recheck the path name and execute it again.* ¹
4289H	An item that cannot be set in data sample condition is being set.	Check the setting of data sampled condition.
4293H	Unable to execute because the total of internal buffer has been exceeded the maximum capacity.	Recheck the total of internal buffer capacity setting and execute it again.* ¹
4C00H	There is not enough free space on target memory for result file creation.	Increase free space of target memory, then execute it again.* ¹
4C06H	System Error	Confirm specified data and write again.
4C0DH	Tried to start data logging when result file is being transferring.	Start data logging again after data logging file transfer is completed.* ¹
4C0FH	The sequence program file or global label setting file was changed when the function for which the label (global label, local label) had been specified as "Sample", "Data" or "Trigger condition" is being executed (the status is "RUN waiting (no collection)", "condition waiting (no collection)", "start waiting (no collection)", "pause", "collecting", "trigger waiting (collecting before trigger)", "collecting after trigger", "saving").	Execute it again.* ¹
4C56H	• Failed to read (access) file. • The specified file does not exist. Or the specified sub directory does not exist.	• Check the file is deleted or not. • Check the file name or sub directory name and then execute it again.* ¹
4F01H	An error in the data type.	Recheck the data to be collected.

*¹ For the method of re-executing the servo system recorder logging, refer to the following.

 Page 835 Restart from the logging interruption

24.8 List of Event Codes

This section lists the events which occur in CC-Link IE TSN.
System, security, and operation are included in the event types.

System		
Event code	Overview	Cause
00100	Link-up	Link-up occurred when the external device was connected.
00170	Co-recording trigger sending	The co-recording trigger has been sent.
00171	Co-recording trigger receiving	The co-recording trigger has been received.
00173	Co-recording trigger sending/receiving	The co-recording trigger was sent to the network.
00174	Co-recording trigger sending/receiving	The co-recording trigger received from another station has been sent to the control CPU module.
00175	Co-recording trigger sending/receiving	The co-recording trigger received from another station has been sent to the network.
06FB	Device station parameter automatic setting completion	Device station parameters were automatically set from the master station.
06FC	Device station parameter backup completion	Device station parameters were backed up to the master station.
06FD	Master-slave Operation - Axes Detection Started/Completed	<ul style="list-style-type: none"> The detection of master-slave operation axes was started. (Detail Code: 0000H) The detection of master-slave operation axes was completed. (Detail Code: 0001H)
06FF	Add-on Event 1	An add-on event occurred.
07ED	Velocity Override "0"	"0" was set to velocity override.
07EE	Servo System Recorder Start	Servo system recorder is started.
07EF	Follow-up Temporarily Invalid Cancellation	Follow-up invalid has been canceled.
07F0	Motion Control FB Start (Administrative)	A Motion control FB (administrative) was started.
07F1	Motion Control FB Start (Motion)	A Motion control FB (motion) was started or multiply started.
07F2	Motion Control FB (General)	A Motion control FB (general) was started.
07F3	Motion Control FB Stop	A Motion control FB was stopped by stop cause.
07F4	File Transfer Start	File transfer was started by script file/label.
07F5	Start when SW Stroke Limit is Disabled	Started when software stroke limit was disabled by Software Stroke Limit Override (<i>AxisName</i> .Cd.SwStrokeLimit_Override).
07F6	Start when HW Stroke Limit is Disabled	Started when hardware stroke limit was disabled by Hardware Stroke Limit Override (<i>AxisName</i> .Cd.HwStrokeLimit_Override).
07F7	Forced Stop Detection	Forced stop signal is detection status.
07F8	Event History File Creation	Event history file was created.
07F9	Homing Request Clear	Homing request clear is ON.
07FA	Current Position Change	Current position change was executed.
07FB	Follow-up Temporarily Invalid	Follow-up was switched to invalid.
07FC	Servo ON when Follow-up is Invalid	Changed it to servo ON in follow-up invalid status during servo OFF.
07FD	Current Position Restoration Completion	Current position restoration was completed.
07FE	Homing Request OFF to ON	Homing request is ON. <ul style="list-style-type: none"> Absolute position erased on drive unit side was detected. [Real drive axis only] (Detail Code: 0000H) An absolute position data error in the Motion module was detected. (Detail Code: 0001H) The axis type was changed. (Detail Code: 0002H) Drive unit object "Polarity (607EH)" b7: position polarity was changed. (Detail Code: 0003H) Change of the drive unit or motor encoder was detected (Detail Code: 0004H) Machine homing was started. (Detail Code: 0005H) Driver unit conversion (numerator/denominator) of the axis was changed. (Detail Code: 0006H) Machine homing has never been executed after the system started. (Detail Code: 0007H) Current position restoration was executed. (Detail Code: 0007H) A drive unit other than the one used at last home position establishment was connected for a virtual axis. (Detail Code: 0008H) The upper/lower limit value of the encoder ring counter (encoder resolution) was changed. (Detail Code: 0009H) Drive unit object "Home offset (607CH)" was changed. (Detail Code: 000AH)

Event code	Overview	Cause
07FF	Add-on Event 2	An add-on event occurred.
00800	Link-down	The system was linked down by removing a device (such as an external device).
00906	Alive check error	The alive status of an external device could not be checked.
00907	Divided messages receive timeout error	<ul style="list-style-type: none"> • Sufficient data for the data length could not be received. • The remaining part of the divided message could not be received.
00908	IP assembly timeout error	<ul style="list-style-type: none"> • Due to high transient transmission load or insufficient transmission time, an IP assembly timeout error has occurred. (The remaining part of the divided data could not be received and a timeout has occurred.) • IP communication is highly loaded.
00909	TCP specification port No. error	The port No. used in a connection already opened is set. (For TCP/IP)
0090A	UDP specification port No. error	The port No. used in a connection already opened is set. (For UDP/IP)

Security

Event code	Overview	Cause
10100	Security key Registration/Deletion	A security key was registered or deleted.
10200	Remote Password Lock	The lock processing for the remote password was performed.
10201	Remote Password Unlock Successful	The unlock processing for the remote password was completed successfully.
10202	Remote Password Unlock Failed	The unlock processing for the remote password was not completed successfully.
10300	Access from an IP restricted with IP filter setting	It was accessed from an IP address restricted with the IP filter setting.

Operation

Event code	Overview	Cause
20300	SD Memory Card Usable	The SD memory card was in usable status.
20301	SD Memory Card Forced Stop	The SD memory card was in removable (disabled) status due to SD memory card forced stop function.
27FFE	Software Reboot Execution	The software reboot was executed.
27FFF	Event History Clear	The event history was cleared.

APPENDICES

Appendix 1 Restrictions by the version

Compatible versions of the engineering tool

The CPU module and engineering tool versions compatible with their respective Motion modules are shown below.

Motion module		CPU module		Engineering tool version	Motion control FB Library version
Model	Software version	Model	Firmware version	GX Works3	
RD78G	"04" or earlier	R00CPU, R01CPU, R02CPU	"12" or later	"1.056J" or later	"1.00A"
		R04CPU, R08CPU, R16CPU, R32CPU, R120CPU	"44" or later		
		R04ENCPU, R08ENCPU, R16ENCPU, R32ENCPU, R120ENCPU	"44" or later		
	"05" or later	R00CPU, R01CPU, R02CPU	"12" or later	"1.060N" or later (The motion control setting function "1.005F" or later)	"1.00A" or later
		R04CPU, R08CPU, R16CPU, R32CPU, R120CPU	"44" or later		
		R04ENCPU, R08ENCPU, R16ENCPU, R32ENCPU, R120ENCPU	"44" or later		
RD78GH	—	R00CPU, R01CPU, R02CPU	"14" or later	"1.060N" or later	"1.00A" or later
		R04CPU, R08CPU, R16CPU, R32CPU, R120CPU	"46" or later		
		R04ENCPU, R08ENCPU, R16ENCPU, R32ENCPU, R120ENCPU	"46" or later		

Compatible versions of the Motion control FB library

The engineering tool versions compatible with the Motion control FB Library are shown below.

Motion control FB Library version	Engineering tool version	
	GX Works3	Motion control setting function
"1.00A"	"1.056J" or later	Motion control setting function "1.000A" or later
"1.01B" or later	"1.060N" or later	Motion control setting function "1.005F" or later

A



The engineering tools other than those mentioned in this section do not support the Motion module.

Compatible versions for each Motion module function

The compatible CPU module and engineering tool versions have restrictions depending on the functions of the Motion module.

The correspondences between the Motion module functions and their compatible versions are shown below.



The correspondences between the add-on versions and their compatible software versions of the Motion module are shown below.

Page 987 List of Add-on Library

—: There is no restriction by the version.

Function	Add-on library		CPU module		Engineering tool version		Motion control FB Library version	
	Library name	Version	Model	Firmware version	GX Works3	Motion control setting function	FB name	Version
Supports communication cycle 31.25μs, 62.5μs and 8000.0μs	baseSystem	1.5	—	—	1.060N	—	—	—
Supports network synchronous communication setting	baseSystem	1.5	—	—	1.060N	—	—	—
Supports PDO mapping configuration	baseSystem	1.5	—	—	1.060N	—	—	—
	ServoDriver_CA Nopen	1.4	—	—				
Supports safety communication function	baseSystem	1.8	R08SFCPU/ R16SFCPU/ R32SFCPU/ R120SFCPU	20	1.065T	—	—	—
	NetworkDriver_CCIETSN	1.7						
Supports communication speed 100Mbps	baseSystem	1.8	—	—	1.065T	—	—	—
Supports Inter-module Synchronization Function	baseSystem	1.16	R00CPU/ R01CPU/ R02CPU	24	1.075D	—	—	—
			R04CPU/ R08CPU/ R16CPU/ R32CPU/ R120CPU	57				
			R04ENCPU/ R08ENCPU/ R16ENCPU/ R32ENCPU/ R120ENCPU	57				
Supports the Simple motion mode	baseSystem	1.16	—	—	1.075D	—	—	—
	Axis	1.15						
	ServoDriver_CA Nopen	1.15						
	NetworkDriver_CCIETSN	1.15						
	SignalIO	1.15						
	SimpleMotion	1.15						
Supports station information list	baseSystem	1.16	—	—	1.075D	—	—	—
Supports up to 120 network stations	baseSystem	1.5	—	—	—	—	—	—
Supports general purpose connection of CANopen devices	NetworkDriver_CCIETSN	1.4	—	—	—	—	—	—

Function	Add-on library		CPU module		Engineering tool version		Motion control FB Library version	
	Library name	Version	Model	Firmware version	GX Works3	Motion control setting function	FB name	Version
Supports partial read and write of operation profile	ProfileControl	1.4	—	—	—	—	—	—
	PackagingApp	1.4						
Adds file transfer commands (copy, move, file, compress, extract and attrib)	FileTransfer	1.4	—	—	—	—	—	—
Supports Continuous operation to torque control mode	MotionEngine	1.7	—	—	—	—	—	—
	ServoDriver_CANopen	1.7						
Supports watchdog counter	baseSystem	1.16	—	—	—	—	—	—
	NetworkDriver_CCIETSN	1.15						
Supports MR-J5D-G	baseSystem	1.17	—	—	—	—	—	—
Adds fast axis operation mode	Axis	1.4	—	—	—	1.005F	—	—
	ServoDriver_CANopen	1.4						
	NetworkDriver_CCIETSN	1.4						
Adds encoder axis types	Axis	1.4	—	—	—	1.005F	—	—
	ServoDriver_CANopen	1.4						
Adds override function, MC_SetOverride and MC_GroupSetOverride	MotionEngine	1.4	—	—	—	1.005F	MC_SetOverride, MC_GroupSetOverride	00A
	Axis	1.4						
	MotionControl-General	1.4						
Adds MC_ReadParameter and MC_WriteParameter	Axis	1.4	—	—	—	1.005F	MC_ReadParameter, MC_WriteParameter	00A
	MotionControl-General	1.4						
Adds MC_Reset, MC_GroupReset and MCv_MotionErrorReset	MotionControl-General	1.4	—	—	—	1.005F	MCv_MotionErrorReset, MC_GroupReset, MC_Reset	00A
Adds MC_TouchProbe and MC_AbortTrigger	MotionControl-General	1.4	—	—	—	1.005F	MC_TouchProbe, MC_AbortTrigger	00A
Supports unit label	baseSystem	1.5	—	—	1.060N	1.005F	—	—
	Axis	1.4						
	Program_ST	1.4						
Supports TargetIgnored status of the drive unit	Axis	1.4	—	—	—	1.005F	—	—
	ServoDriver_CANopen	1.4						
Adds file transfer access control	FileTransfer	1.4	—	—	—	1.005F	—	—
Adds MCv_BacklashCompensationFilter, MCv_DirectionFilter and MCv_SpeedLimitFilter	MotionControl-AxisFilter	1.4	—	—	—	1.005F	MCv_BacklashCompensationFilter, MCv_DirectionFilter, MCv_SpeedLimitFilter	00A
Adds purged pool monitor in MCv_SmoothingFilter	MotionControl-AxisFilter	1.4	—	—	—	1.005F	MCv_SmoothingFilter	01B

Function	Add-on library		CPU module		Engineering tool version		Motion control FB Library version	
	Library name	Version	Model	Firmware version	GX Works3	Motion control setting function	FB name	Version
Supports RD78GH	baseSystem	1.5	R00CPU/ R01CPU/ R02CPU	14	1.060N	1.005F	—	—
			R04CPU/ R08CPU/ R16CPU/ R32CPU/ R120CPU	46				
			R04ENCPU/ R08ENCPU/ R16ENCPU/ R32ENCPU/ R120ENCPU	46				
Adds memory usage monitor for BaseSystem	—	—	—	—	—	1.005F	—	—
Adds clearing command for motion event history	MotionEventHist	1.4	—	—	—	1.005F	—	—
Adds logging real-time monitor	Logging	1.4	—	—	—	1.005F	—	—
Supports initial stroke of operation profile	ProfileControl	1.4	—	—	—	1.005F	—	—
Adds Servo System Recorder	Axis	1.7	—	—	—	1.010L	—	—
	Logging	1.7						
Supports Position data history	Axis	1.7	—	—	—	1.010L	—	—
	MotionEventHist	1.7						
Supports Response Preferred Method	NetworkDriver_CCIETSN	1.19	—	—	—	1.030G	—	—
Supports security key authentication function	baseSystem	1.24	—	—	—	1.035M	—	—
Supports LB/LW	baseSystem	1.24	—	—	1.085P	1.035M	—	—
	SignalIO	1.23						
	Program_ST	1.23						
Supports Advanced synchronous control	baseSystem	1.26	—	—	—	1.040S	MCv_AdvancedSync, MCv_AdvPositionPerCycleCalc, MCv_AdvCamSetPositionCalc	06G
	MotionEngine	1.25						
	Axis	1.25						
	MotionControl_General	1.25						
	MotionControl_AdvancedSync	1.25						
Supports Co-recording function	baseSystem	1.26	R00CPU/ R01CPU/ R02CPU/ R04CPU/ R08CPU/ R16CPU/ R32CPU/ R120CPU/ R04ENCPU/ R08ENCPU/ R16ENCPU/ R32ENCPU/ R120ENCPU	65	1.090U	1.040S	—	—
	Logging	1.25						
	ServoSystemRecorder	1.25						
Supports selective write function	baseSystem	1.26	—	—	—	1.040S ^{*1}	—	—

Function	Add-on library		CPU module		Engineering tool version		Motion control FB Library version	
	Library name	Version	Model	Firmware version	GX Works3	Motion control setting function	FB name	Version
Supports Multiple Axes Positioning Data Operation (MCv_PositioningData)	MotionEngine	1.27	—	—	—	1.042U	MCv_PositioningData	1.07H
	MotionControl_General	1.27						
	ProfileControl	1.27						
Supports master-slave operation function	baseSystem	1.28	—	—	1.095Z ²	1.042U	—	—
	Axis	1.27						
	ServoDriver_CANopen	1.27						
	NetworkDriver_CCIETSN	1.27						
Supports operation profile (positioning data format)	ProfileControl	1.27	—	—	—	1.042U	—	—
Supports Multiple Axes Positioning Data Operation (MCv_MovePositioningData) conditional JUMP	MotionEngine	1.27	—	—	—	1.050C	—	—
	MotionControl_General	1.27						
	ProfileControl	1.27						
Adds operation profile (positioning data format) condition signal	ProfileControl	1.27	—	—	—	1.050C	—	—
Supports IP address setting function	baseSystem	1.32	—	—	1.100E	—	—	—
Supports operation cycle settings subdivision	baseSystem	1.32	—	—	—	—	—	—
Improves detection function of connected/disconnected devices	baseSystem	1.24	—	—	1.105K	—	—	—
Supports Multiple Axes Positioning Data Operation (MCv_MovePositioningData), skip function, step function	MotionEngine	1.33	—	—	—	1.055H	—	—
	MotionControl_General	1.33						
	ProfileControl	1.33						
Adds operation profile (positioning data format) skip signal, supports read/write of condition signal and skip signal	ProfileControl	1.33	—	—	—	1.055H	—	—
Supports velocity bias	MotionEngine	1.33	—	—	—	1.055H	—	—
	Axis	1.33						
Supports connection of drive unit other than MELSERVO	Axis	1.33	—	—	—	1.055H	—	—
	ServoDriver_CANopen	1.33						
Supports Absolute Position System at connection of drive unit other than MELSERVO	Axis	1.35	—	—	—	—	—	—
	ServoDriver_CANopen	1.35						
Supports pressure control (MCv_PressureControl)	MotionEngine	1.37	—	—	—	1.065T	MCv_PressureControl	11L
	Axis	1.37						
	MotionControl_General	1.37						
	ServoDriver_CANopen	1.37						

Function	Add-on library		CPU module		Engineering tool version		Motion control FB Library version	
	Library name	Version	Model	Firmware version	GX Works3	Motion control setting function	FB name	Version
Supports speed to positioning move (MCv_SpeedToMoveAbsolute, MCv_SpeedToMoveRelative)	MotionEngine	1.39	—	—	—	1.070Y	MCv_SpeedToMoveAbsolute, MCv_SpeedToMoveRelative	12M
	MotionControl_General	1.39						
	ServoDriver_CA Nopen	1.39						
	NetworkDriver_CCIETSN	1.39						
	SignalIO	1.39						

- *1 When using the selective write function with baseSystem version "1.26", the project data must be written in advance with motion control setting function version "1.040S" or later.
After writing the project data using baseSystem version "1.26" or later and motion control setting function version "1.040S" or later, restoring to a baseSystem version earlier than "1.26" will cause an error in the motion module. In this case, the project data must be written again.
- *2 Registering the profile version "09C" for software version "28" of the Motion module or using GX Works3 version "1.095Z" or later is required.
The profile can be downloaded from MITSUBISHI ELECTRIC FA Global Website.
For how to register profiles, refer to the following.
 GX Works3 Operating Manual

Appendix 2 List of Add-on Library

The add-on versions respectively compatible with the software versions of the Motion module are shown below.

Software version	Add-on library name						
	baseSystem	MotionEngine	Axis	MotionContro l_General	MotionContro l_Sync	AbsSystem	ServoDriver_ CANopen
01	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0
02	1.2.1.0	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0
03	1.3.1.0	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0
04	1.4.1.0	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0
05	1.5.1.0	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0
06	1.6.1.0	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0
07	1.7.1.0	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0
08	1.8.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0
09	1.9.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0
10	1.10.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0
12	1.12.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0
13	1.13.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0
14	1.14.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0
16	1.16.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0
17	1.17.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0
18	1.18.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0
20	1.20.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0
21	1.21.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0
22	1.22.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0
24	1.24.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0
26	1.26.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0
28	1.28.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0
30	1.30.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0
31	1.31.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0
32	1.32.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0
33	1.33.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0
34	1.34.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0
36	1.36.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0
37	1.37.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0
38	1.38.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0
39	1.39.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0
40	1.40.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0

Software version	Add-on library name						
	NetworkDrive r_CCIETSN	PicInstruction	SignalIO	ExternalSignal	Program_ST	Logging	MotionEventHist
01	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0
02	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0
03	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0
04	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0
05	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0
06	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0
07	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0
08	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0
09	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0
10	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0
12	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0
13	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0
14	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0
16	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0
17	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0
18	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0
20	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0
21	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0
22	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0
24	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0
26	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0
28	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0
30	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0
31	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0
32	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0
33	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0
34	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0
36	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0
37	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0
38	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0
39	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0
40	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0

Software version	Add-on library name						
	FileTransfer	MotionControl_AxisFilter	ProfileControl	PackagingApp	ServoSystemRecorder	SimpleMotion	MotionControl_AdvancedSync
01	1.0.1.0	1.0.1.0	1.0.1.0	1.0.1.0	—	—	—
02	1.1.1.0	1.1.1.0	1.1.1.0	1.1.1.0	—	—	—
03	1.2.1.0	1.2.1.0	1.2.1.0	1.2.1.0	—	—	—
04	1.3.1.0	1.3.1.0	1.3.1.0	1.3.1.0	—	—	—
05	1.4.1.0	1.4.1.0	1.4.1.0	1.4.1.0	—	—	—
06	1.5.1.0	1.5.1.0	1.5.1.0	1.5.1.0	—	—	—
07	1.6.1.0	1.6.1.0	1.6.1.0	1.6.1.0	—	—	—
08	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	1.7.1.0	—	—
09	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	1.8.1.0	—	—
10	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	1.9.1.0	—	—
12	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	1.11.1.0	—	—
13	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	1.12.1.0	—	—
14	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	1.13.1.0	—	—
16	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	1.15.1.0	—
17	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	1.16.1.0	—
18	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	1.17.1.0	—
20	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	1.19.1.0	—
21	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	1.20.1.0	—
22	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	1.21.1.0	—
24	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0	1.23.1.0
26	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0	1.25.1.0
28	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0	1.27.1.0
30	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0	1.29.1.0
31	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0	1.30.1.0
32	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0	1.31.1.0
33	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0	1.32.1.0
34	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0	1.33.1.0
36	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0	1.35.1.0
37	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0	1.36.1.0
38	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0	1.37.1.0
39	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0	1.38.1.0
40	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0	1.39.1.0

Add-on library details

The details of the add-on library are shown below.

—: No dependent add-on

Add-on library name	Name	Description	Dependent add-on (Necessary)	Dependent add-on (Restricted)
baseSystem	baseSystem	Basic software	—	—
MotionEngine	Motion control basic	Basic add-on for motion control	[baseSystem] [Axis]	—
Axis	Axis control	Add-on for axis control	[baseSystem] [MotionEngine]	[AbsSystem] [ServoDriver] [SignalIO] [MotionEventHist]
MotionControl_General	PLCopen motion control single-axis/multi-axis control FB	Enables PLCopen® motion control single-axis/multi-axis control FB.	[baseSystem] [MotionEngine] [Axis]	[SignalIO]
MotionControl_Sync	PLCopen motion control synchronous control	Enables PLCopen® motion control synchronous control FB.	[baseSystem] [MotionEngine] [Axis] [MotionControl_General]	—
AbsSystem	Absolute position control	Enables absolute position control.	[baseSystem] [Axis]	—
ServoDriver_CANopen	Servo driver (CANopen)	CANopen servo driver	[baseSystem] [Axis] [NetworkDriver_CCIETSN] [SignalIO]	—
NetworkDriver_CCIETSN	Network driver (CC-Link IE TSN)	Network driver of CC-Link IE TSN	[baseSystem]	—
PlcInstruction	External sequence dedicated instructions	Enables external sequence dedicated instructions.	[baseSystem]	[PLCopenMC_General] [ST] [SignalIO]
SignalIO	I/O signal	Provides the signal input/output function.	[baseSystem]	[Axis]
ExternalSignal	External signal	Enables external signals.	[baseSystem] [SignalIO] [Axis]	—
Program_ST	ST language execution	Add-on that executes ST language	[baseSystem]	[PLCopenMC_General]
Logging	Logging	Provides the logging function.	[baseSystem] [SignalIO]	—
MotionEventHist	Motion event history	Add-on for motion event history.	[baseSystem]	—
FileTransfer	File transfer	Provides the file transfer function.	[baseSystem]	—
MotionControl_AxisFilter	Command filter	Enables PLCopen® motion control command filter FB.	[baseSystem] [MotionEngine] [Axis] [MotionControl_General] [MotionControl_Sync]	—
ProfileControl	Operation profile control	Enables operation profile control.	[baseSystem] [MotionEngine] [Axis] [MotionControl_General] [MotionControl_Sync]	[SignalIO]
PackagingApp	Packaging	Provides functions for packaging machines.	[baseSystem] [ProfileControl]	—
ServoSystemRecorder	Servo System Recorder	Provides the servo system recorder function.	[baseSystem] [Logging] [Axis]	[ServoDriver_CANopen]
SimpleMotion	SimpleMotion	Add-on for simple motion.	[baseSystem] [Axis] [ServoDriver_CANopen] [NetworkDriver_CCIETSN] [SignalIO]	—

Add-on library name	Name	Description	Dependent add-on (Necessary)	Dependent add-on (Restricted)
MotionControl_AdvancedSync	Advanced Synchronous Control	Provides the advanced synchronous control function.	[baseSystem] [Axis] [MotionEngine] [MotionControl_General]	[AbsSystem] [SignalIO] [ProfileControl]



baseSystem is necessary.

Appendix 3 List of Boot software

The versions of each boot which is compatible with the software version of the Motion module are shown below.

Software version	Boot name	
	Network boot software	Boot software
01	1	1
02	2	1
03	2	1
04	2	2
05	3	3
06	3	3
07	3	3
08	4	4
09	4	4
10	5	5
12	5	5
13	5	5
14	6	6
16	7	7
17	8	8
18	8	8
20	9	9
21	9	9
22	10	10
24	11	11
26	12	12
28	13	13
30	14	14
31	14	14
32	15	15
33	15	15
34	16	16
36	17	17
37	17	17
38	18	18
39	18	18
40	19	19

INDEX

A

Absolute position control	94
Absolute positioning control	206
Acceleration/Deceleration processing function	358
Addition/Subtraction positioning	500
Add-on library	121
Advanced synchronous control	555
Axis	30
Axis Emulation	440
Axis type	37

B

Backlash compensation filter	411
Boot software	904
Buffer memory refresh	115

C

Cam operation	468
CC-Link IE TSN	718
Circular interpolation control	233
Command format	879
Command In-position	342
Co-recording function	833
CPU MODULE	848

D

Data logging function	788
Direct control	294
Driver unit conversion	403

E

Engineering tool	74
Event history	821
External signal selection	424

F

Follow up	89
-----------	----

G

Gear operation	497
----------------	-----

H

Hardware stroke limit	351
Homing	196

J

Jerk acceleration/deceleration	377
Jerk limit value	374
JOG operation	211
JSON file data specifications	806

L

LED	908
Linear interpolation control	227
Log file	883
Logging	786

M

Master-slave operation	452
Module extended parameters	870
Motion control FB	857
Motion service processing	846
Motion system software	894
MR-J5(W)-G	725
Multiple axes positioning control	213
Multiple axes positioning data operation	242
Multiple start	134

N

Near pass	154
-----------	-----

O

Object data	60
Operation cycle	107
Operation profile	502
Override function	392

P

PDO mapping	61
Positioning data history	824
Positioning data setting	245
Positioning range	81
Pressure control	322
Processing time over check	817

R

RAS	813
Real drive axis	41
Real encoder axis	43
Real-time monitor	788
Relative positioning control	207
Response code (SDO Abort code)	876

S

Security Key Authentication Function	887
Servo ON/OFF	86
Set position	82
SIGNAL_SELECT structure	426
Single axis manual control	210
Single axis positioning control	206
Single axis speed control	208
Single axis synchronization control	464
Slave object map	399
Smoothing filter	407
Software reboot	126
Software stroke limit	344

Speed to positioning move control	288
Storage files	868
System basic cycle	108

T

TARGET_REF structure	428
Torque control	306
Torque limit	398
Touch probe	432
Trigger condition (TRIGGERCONDITION)	798

V

Virtual drive axis	49
Virtual encoder axis.	49
Virtual linked axis	56

REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Description
July 2019	IB(NA)-0300411ENG-A	First edition
January 2020	IB(NA)-0300411ENG-B	<p>■Added models RD78GHV, RD78GHW</p> <p>■Added or modified parts TERMS, GENERIC TERMS AND ABBREVIATIONS, HOW TO READ THIS MANUAL, FUTURE SUPPORT PLANNED, Chapter 23, 24, 25, 26, Section 1.1, 1.2, 1.3, 1.4, 1.5, 1.6, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 3.1, 3.2, 3.3, 4.3, 4.4, 4.5, 5.1, 6.1, 6.2, 6.3, 6.4, 7.1, 7.2, 8.1, 8.4, 9.1, 9.2, 9.3, 10.2, 11.1, 11.2, 12.1, 12.2, 12.3, 13.1, 13.2, 14.2, 14.3, 14.4, 14.5, 14.6, 14.7, 14.8, 14.9, 15.1, 15.2, 16.1, 16.2, 18.1, 18.2, 19.1, 19.2, 19.3, 21.1, 21.3, 22.3, 22.4, 22.5, 22.6, 25, Appendix 1, 2, 3, 4, 5, INDEX, WARRANTY, TRADEMARKS</p>
August 2020	IB(NA)-0300411ENG-C	<p>■Added or modified parts SAFETY PRECAUTIONS, RELEVANT MANUALS, TERMS, GENERIC TERMS AND ABBREVIATIONS, HOW TO READ THIS MANUAL, FUTURE SUPPORT PLANNED, Chapter 7, 23, 24, 25, 26, 27, 28 Section 1.1, 1.2, 1.4, 1.5, 1.6, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 3.1, 3.2, 3.3, 3.4, 4.1, 4.2, 4.3, 4.4, 4.5, 5.1, 5.2, 6.1, 6.2, 6.3, 6.4, 7.1, 7.2, 8.1, 8.2, 8.3, 8.4, 9.1, 9.2, 9.3, 10.2, 11.1, 11.2, 11.3, 12.1, 12.2, 12.3, 13.1, 13.2, 13.3, 13.4, 13.5, 13.6, 13.7, 13.8, 13.9, 14.1, 14.2, 15.1, 15.2, 15.3, 16.1, 16.2, 16.3, 17.2, 18.1, 18.2, 19.1, 19.2, 19.3, 19.4, 21.1, 21.2, 21.3, 22.1, 22.2, 22.3, 22.4, 22.5, 22.7, Appendix 1, 2, 3</p>
August 2021	IB(NA)-0300411ENG-D	<p>■Added or modified parts SAFETY PRECAUTIONS, RELEVANT MANUALS, TERMS, GENERIC TERMS AND ABBREVIATIONS, HOW TO READ THIS MANUAL, FUTURE SUPPORT PLANNED, Chapter 7, 20, 23, 24, 25, 27, 28, Section 1.1, 1.2, 1.3, 1.4, 1.5, 1.6, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 3.1, 3.2, 3.3, 3.4, 4.1, 4.2, 4.3, 4.4, 4.5, 5.1, 6.1, 6.2, 6.3, 6.4, 7.1, 7.2, 8.1, 8.2, 8.3, 8.4, 9.1, 9.2, 9.3, 10.1, 10.2, 11.1, 11.2, 11.3, 12.1, 12.2, 12.3, 12.4, 13.1, 13.2, 13.3, 13.4, 13.5, 13.6, 13.7, 13.8, 13.9, 13.10, 14.1, 14.2, 15.1, 15.2, 15.3, 16.1, 16.2, 16.3, 18.1, 18.2, 19.1, 19.2, 19.3, 19.4, 21.1, 21.2, 21.3, 22.1, 22.2, 22.3, 22.4, 22.5, 22.6, 22.7, 22.8, Appendix 1, 2, 3, WARRANTY, TRADEMARKS</p>
January 2022	IB(NA)-0300411ENG-E	<p>■Added or modified parts INTRODUCTION, TERMS, GENERIC TERMS AND ABBREVIATIONS, Chapter 5, 7, Section 1.1, 1.2, 1.3, 1.4, 1.5, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 3.1, 3.2, 3.4, 4.1, 4.3, 4.4, 4.5, 5.1, 5.2, 6.1, 6.2, 6.3, 6.4, 7.1, 7.2, 8.1, 8.2, 8.3, 8.4, 9.1, 9.2, 9.3, 10.1, 10.2, 11.1, 11.2, 11.3, 12.1, 12.2, 12.3, 13.1, 13.7, 13.8, 13.9, 14.1, 14.2, 15.1, 15.3, 16.1, 16.2, 16.3, 18.2, 19.1, 19.2, 19.3, 19.4, 20.1, 21.1, 21.2, 21.3, 22.1, 22.2, 22.3, 22.5, 22.6, Appendix 1, 2, 3, 4</p>
August 2022	IB(NA)-0300411ENG-F	<p>■Added or modified parts RELEVANT MANUALS, TERMS, GENERIC TERMS AND ABBREVIATIONS, HOW TO READ THIS MANUAL, FUTURE SUPPORT PLANNED, Chapter 5, 21, 24, 26, 27, 28, Section 1.1, 1.2, 1.3, 1.4, 2.1, 2.3, 2.4, 2.5, 2.6, 3.1, 3.2, 3.4, 4.2, 4.3, 4.4, 4.5, 5.1, 5.2, 6.1, 6.2, 6.3, 6.4, 7.1, 7.2, 8.1, 8.2, 8.3, 8.4, 9.1, 9.3, 10.2, 11.2, 12.1, 12.2, 12.4, 13.1, 13.2, 13.7, 13.8, 13.9, 14.1, 14.2, 15.1, 15.2, 15.3, 16.3, 18.1, 18.2, 19.1, 19.2, 19.3, 21.1, 21.2, 21.3, 22.2, 22.3, 22.5, 22.6, 22.8, Appendix 1, 3, INDEX</p>
May 2023	IB(NA)-0300411ENG-G	<p>■Added functions Multiple axes positioning data operation, Master-slave operation, Advanced synchronous control, Co-recording function</p> <p>■Added or modified parts SAFETY PRECAUTIONS, TERMS, GENERIC TERMS AND ABBREVIATIONS, Chapter 15, 18, 22, Section 1.2, 1.3, 1.4, 2.1, 2.2, 2.5, 3.1, 3.2, 3.4, 4.3, 4.4, 4.5, 5.1, 6.4, 6.5, 7.1, 8.3, 8.4, 9.1, 11.2, 12.1, 12.2, 12.4, 12.5, 13.1, 13.7, 14.1, 14.2, 15.1, 15.2, 15.3, 15.4, 15.5, 15.6, 15.7, 15.8, 16.1, 17.3, 18.1, 18.2, 19.1, 19.2, 20.1, 20.2, 22.1, 23.3, 23.5, 23.6, 23.7, 23.8, Appendix 1, 2, 3, 4</p>
August 2023	IB(NA)-0300411ENG-H	<p>■Added or modified parts TERMS, Section 1.1, 1.2, 1.3, 1.4, 2.5, 2.6, 3.1, 4.4, 4.5, 7.2, 8.4, 12.1, 12.3, 12.5, 13.7, 14.1, 17.1, 17.3, 20.1, 20.2, 22.1, 23.5, 23.6, 23.8, Appendix 1, 2, 3, 4</p>
January 2024	IB(NA)-0300411ENG-J	<p>■Added or modified parts SAFETY PRECAUTIONS, 1.1, 1.2, 1.3, 1.4, 2.1, 2.4, 2.5, 2.6, 3.1, 4.3, 4.5, 6.4, 6.5, 7.1, 7.2, 8.3, 9.1, 12.1, 12.2, 12.3, 13.7, 14.1, 14.2, 15.7, 20.4, 22.1, 22.2, 22.3, 23.1, 23.3, 23.5, 23.6, 23.7, 23.8, Appendix 1, 2, 3, 4</p>
September 2024	IB(NA)-0300411ENG-K	<p>■Added or modified parts SAFETY PRECAUTIONS, TERMS, GENERIC TERMS AND ABBREVIATIONS, Chapter 16, 17, Section 1.1, 1.2, 1.3, 1.4, 2.6, 3.2, 4.4, 5.1, 6.5, 9.1, 11.1, 12.1, 12.2, 12.3, 12.5, 13.7, 14.1, 14.2, 15.2, 15.4, 16.2, 16.3, 16.4, 17.1, 19.2, 21.2, 22.2, 25.3, 25.5, 25.6, 25.8, Appendix 1, 2, 3</p>
February 2025	IB(NA)-0300411ENG-L	<p>■Added or modified parts RELEVANT MANUALS, TERMS, Section 1.1, 1.3, 2.6, 4.4, 5.1, 7.1, 9.1, 12.1, 12.3, 13.7, 15.2, 15.4, 15.6, 16.1, 16.2, 16.3, 16.4, 16.5, 21.1, 24.1, 24.2, 24.3, 25.5, 25.6, 25.8, Appendix 1, 2, 3</p>

Revision date	*Manual number	Description
July 2025	IB(NA)-0300411ENG-M	<p>■Added function Pressure control</p> <p>■Added or modified parts</p> <p>■TERMS, GENERIC TERMS AND ABBREVIATIONS, Chapter 7, Section 1.1, 1.2, 1.3, 1.4, 2.2, 2.4, 2.5, 2.6, 4.3, 4.4, 4.5, 5.1, 6.2, 7.1, 7.2, 7.3, 8.4, 9.1, 9.2, 9.3, 10.1, 10.2, 11.1, 12.1, 12.3, 12.5, 13.7, 14.1, 15.2, 15.4, 15.8, 16.2, 16.3, 16.4, 16.5, 18.3, 19.2, 19.3, 21.1, 25.5, 25.6, 25.8, Appendix 1, 2, 3, TRADEMARKS</p>
September 2025	IB(NA)-0300411ENG-N	<p>■Added or modified parts</p> <p>Section 11.3, Appendix 2, 3</p>
January 2026	IB(NA)-0300411ENG-P	<p>■Added function Speed to positioning move control</p> <p>■Added or modified parts</p> <p>SAFETY PRECAUTIONS, Section 1.1, 2.1, 2.5, 4.2, 4.3, 6.5, 6.6, 7.2, 7.3, 9.1, 9.3, 10.2, 11.3, 12.1, 12.2, 12.5, 13.7, 15.4, 16.2, 16.3, 16.4, 21.2, 22.1, 25.5, 25.6, 25.8, Appendix 1, 2, 3</p> <p>■Deleted part Chapter 17</p>

Japanese manual number: IB-0300410-T

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

©2019 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Warranty

1. Warranty period and coverage

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

For terms of warranty, please contact your original place of purchase.

[Limitations]

(1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule.

It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.

(2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.

(3) Even during the term of warranty, the repair cost will be charged on you in the following cases;

1. a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
2. a failure caused by any alteration, etc. to the Product made on your side without our approval
3. a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
4. a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
5. any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
6. a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
7. a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
8. any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

(1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.

(2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA center for details.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

(1) For the use of our Motion module, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in the Motion module, and a backup or fail-safe function should operate on an external system to the Motion module when any failure or malfunction occurs.

(2) Our Motion module is designed and manufactured as a general purpose product for use at general industries.

Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.

In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used. We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

(3) Mitsubishi shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

INFORMATION AND SERVICES

For further information and services, please contact your local Mitsubishi Electric sales office or representative.
Visit our website to find our locations worldwide.

MITSUBISHI ELECTRIC Factory Automation Global Website

Locations Worldwide

www.MitsubishiElectric.com/fa/about-us/overseas/

TRADEMARKS

CANopen[®] is registered Community Trademarks of CAN in Automation e.V.

Microsoft and Windows are trademarks of the Microsoft group of companies.

Unicode is either a registered trademark or a trademark of Unicode, Inc. in the United States and other countries.

PLCopen is a registered trademark owned by PLCopen[®].

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.

TRANSLATION OF THE ORIGINAL INSTRUCTIONS

IB(NA)-0300411ENG-P(2601)MEE

MODEL: RD78-U-APP-E

MODEL CODE: 1XB039

mitsubishi electric corporation

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.