


MELSOFT

User Web Page Design Tool Operating Manual

-SW1DNN-WSVDT-MD



SAFETY PRECAUTIONS

(Read this section before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the user's manual for the module used.

In this manual, the safety precautions are classified into two levels: "⚠ WARNING" and "⚠ CAUTION".



WARNING

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



CAUTION

Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[DESIGN PRECAUTIONS]



WARNING

- If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Failure to do so may result in an accident due to an incorrect output or malfunction.
-

[SECURITY PRECAUTIONS]



WARNING

- To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from unreliable networks and devices via network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.
-

[STARTUP AND MAINTENANCE PRECAUTIONS]



CAUTION

- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
-

CONDITIONS OF USE FOR THE PRODUCT

- (1) MELSEC programmable controller ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries. MITSUBISHI ELECTRIC SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI ELECTRIC USER'S, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.
- ("Prohibited Application")
- Prohibited Applications include, but not limited to, the use of the PRODUCT in;
- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
 - Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
 - Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.
- Notwithstanding the above restrictions, Mitsubishi Electric may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi Electric and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi Electric representative in your region.
- (3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

INTRODUCTION

Thank you for purchasing the Mitsubishi Electric programmable controllers.

This manual is to help users understand the User Web Page Design Tool.

Before using this product, read this manual carefully to fully understand the User Web Page Design Tool's functions/ capabilities, and make sure that this product is used correctly.

Please make sure that the end users read this manual.

CONTENTS

SAFETY PRECAUTIONS	1
CONDITIONS OF USE FOR THE PRODUCT	2
INTRODUCTION	2
RELEVANT MANUALS	4
TERMS	4
GENERIC TERMS AND ABBREVIATIONS	4
CHAPTER 1 BEFORE USING THIS PRODUCT	5
1.1 Features	5
1.2 Operating Environment	5
1.3 Software License	7
CHAPTER 2 USER INTERFACE	22
2.1 Screen Structure	22
2.2 Shortcut	23
2.3 Menu Bar	24
2.4 Tool Buttons	32
2.5 Component Window	33
PLC components	33
Generic components	48
Common items	54
2.6 Design Window	58
2.7 Property Window	59
Component properties	59
Page properties	59
Common items	60
CHAPTER 3 TUTORIAL	61
3.1 Before Tutorial	61
3.2 Practical Examples	63
Creating a user Web page	63
Access to user Web page	70
CHAPTER 4 NOTES	71
APPENDIX	73
Appendix 1 Project Management	73
INDEX	75
REVISIONS	77
INFORMATION AND SERVICES	78
TRADEMARKS	78

RELEVANT MANUALS

The following manuals are relevant to this product.

Manual name <manual number>	Description
MELSEC iQ-R/MELSEC iQ-F Web Server Function Guide Book <SH-081982ENG>	This describes the specifications of the Web server's functions, procedures before its operations, and its troubleshooting.
MELSEC iQ-R Ethernet User's Manual (Application) <SH-081257ENG>	This describes Ethernet functions, parameter settings, programming, troubleshooting, I/O signals, and buffer memory. For the Web server functions, this describes the details of JavaScript components which can be used in a user Web page.
MELSEC iQ-F FX5 User's Manual (Communication) <SH-082625ENG>	This describes contents about built-in Ethernet port communication's functions. For the Web server functions, this describes the details of JavaScript components which can be used in a user Web page.
MELSEC MX Controller MX-R Model User's Manual <SH-082641ENG>	Procedures before operation, specifications, devices, memory, functions, parameters, and troubleshooting of the controller
User Web Page Design Tool Operating Manual <SH-082315ENG> (this manual)	This describes the user Web page tool's functions and how to use it.

TERMS

Unless otherwise stated expressly, the following terms shall be used in this manual for an explanation.

Terms	Description
Device	This is a device which a CPU module has in it (such as X, Y, M, D, etc.)
GX Works3	The product name of the software package for the MELSEC programmable controllers

GENERIC TERMS AND ABBREVIATIONS

Unless otherwise specified, this manual uses the following generic terms and abbreviations.

Generic term/abbreviation	Description
Controller	This is a generic name for MELSEC MX Controller MX-R Models.
CPU module	This is a generic term for the MELSEC iQ-R series CPU modules, MELSEC iQ-F series CPU modules, and MELSEC MX Controller MX-R Models.
FX5CPU	This is a generic name for MELSEC iQ-F series CPU modules.
RCPU	This is a generic name for MELSEC iQ-R series CPU modules.

1 BEFORE USING THIS PRODUCT

This User Web Page Design Tool is a tool to help its users create user Web pages using Web server functions.



To use all the functions described in this manual, install the latest version of User Web Page Design Tool.

1.1 Features

This section describes features of this tool.

Easy operations enabling users to create user Web pages

Its screen operations allocate PLC and generic components and configure property settings, and thereby HTML files for user Web pages can be created, which will operate on a CPU module's Web server functions.

Components prepared beforehand are selected and their property settings are configured, and therefore its users can create HTML files without knowing HTML tags and Cascading Style Sheets (CSS).

HTML files transferable to a CPU module

HTML files created by this tool can be transferred to an SD memory card attached to a CPU module through FTP communication.*1

*1 When a MELSEC iQ-R series CPU module is used, there are restrictions on the firmware version. (Page 27 Communication)

1.2 Operating Environment

This section describes the operating environment of this tool.

Item	Description
Personal computer main part	This must be a personal computer that can run Microsoft® Windows®.
CPU	Intel® Core® i3 2GHz or better is recommended.
Required memory size	8GB or more is recommended.
Hard disk free space	400MB or more
Display resolution	1280 × 1024 pixels or better
OS (English, Japanese, and Chinese (simplified characters) versions)*1	Windows 10 (Home, Pro, Enterprise, and Education) (64 bit) Windows 11 (Home, Pro, Enterprise, and Education) (64 bit)
Supporting CPU modules	■MELSEC iQ-R series*2 • R01CPU and R02CPU: Firmware version "18" or later*3 • CPU modules other than those above: Firmware version "50" or later*4 ■MELSEC iQ-F series • FX5S CPU modules: Firmware version "1.000" or later • FX5UJ CPU modules: Firmware version "1.020" or later • FX5U/FX5UC CPU modules: Firmware version "1.220" or later ■MELSEC MX Controller • MX-R Models: Firmware version "03" or later

*1 English, Japanese, and Chinese (simplified characters) are supported as the display languages of this tool. (Page 26 Switch Display Language) However, selection button displays, etc. depend on an OS's language, and therefore they may be displayed in one other than those languages above.

*2 There are some restrictions on the combination of user Web page and CPU module firmware versions.
(MELSEC iQ-R/MELSEC iQ-F Web Server Function Guide Book)

*3 The communication function of this tool is supported by firmware version "30" or later.

*4 The communication function of this tool is supported by firmware version "63" or later.

The communication function cannot be used in the R00CPU module because an SD memory card is required for the function.

Client operating environment

Clients whose operability have been confirmed by Mitsubishi Electric Corporation are as shown below. Use a Web browser that supports HTML5, CSS3, and JavaScript.

Terminal	OS	Browser	Browser version		
			MELSEC iQ-R	MELSEC iQ-F	MELSEC MX Controller
Personal computer	Microsoft® Windows®	Internet Explorer®	11	11	—
		Microsoft® Edge	85	85	130.0
		Google Chrome	85	85	102.0
Tablet	Android®	Mobile Google Chrome	81	81	127.0
Smartphone	iOS®	Mobile Safari	12	12	17.6

1.3 Software License

This tool is composed of multiple software components. There are copyrights of our company and third parties to those individual software components. This tool includes the software items shown below.

- Software items to which there exist third-party copyrights and which are distributed as free software. For software items to which Mitsubishi Electric Corporation or third parties have copyrights, their source codes shall not be distributed.

Please refrain from contacting Mitsubishi Electric Corporation about open sources' source codes.

Software information

This product contains the software items shown below.

OSS (Open Source Software)	Software version	License name
electron	8.2.5	MIT License
electron-splashscreen	1.0.0	MIT License
electron-progressbar	1.2.0	MIT License
connected-react-router	6.8.0	MIT License
react	16.13.1	MIT License
react-bootstrap	1.0.1	MIT License
react-dnd	16.13.1	MIT License
react-dnd-html5-backend	7.4.4	MIT License
react-helmet	6.1.0	MIT License
react-dom	16.13.0	MIT License
react-id-generator	3.0.0	MIT License
react-router	5.1.2	MIT License
react-select	3.1.0	MIT License
react-tabs	3.1.0	MIT License
react-i18next	11.3.5	MIT License
react-redux	7.2.0	MIT License
redux-actions	2.6.5	MIT License
redux-localstorage	0.4.1	MIT License
redux	4.0.5	MIT License
redux-thunk	2.2.0	MIT License
bootstrap	4.4.1	MIT License
i18next	19.4.2	MIT License
sweetalert2	9.10.12	MIT License
fs-extra	9.0.0	MIT License
file-exists	5.0.1	MIT License
babel	7.9.0	MIT License
history	4.10.1	MIT License
immer	6.0.3	MIT License
jquery	3.5.1	MIT License
popper.js	1.16.0	MIT License
prop-types	15.7.2	MIT License
Json.NET	12.0.3	MIT License
lodash	4.17.15	MIT License
extend	3.0.2	MIT License
mxgraph-js	1.0.1	Apache License 2.0
guid-typescript	1.0.9	ISC License

■electron

This product uses electron which is licensed by MIT.

The copyright and license notice of electron is shown below.

Version 8.2.5
MIT License
Copyright (c) 2013-2019 GitHub Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■electron-splashscreen

This product uses electron-splashscreen which is licensed by MIT.

The copyright and license notice of electron-splashscreen is shown below.

Version: 1.0.0
MIT License
Copyright (c) 2017 Troy McKinnon.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■electron-progressbar

This product uses electron-progressbar which is licensed by MIT.

The copyright and license notice of electron-progressbar is shown below.

Version: 1.2.0
MIT License
Copyright (c) 2017 Anderson Ravagnani Mamede

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■connected-react-router

This product uses connected-react-router which is licensed by MIT.

The copyright and license notice of connected-react-router is shown below.

Version: 6.8.0
 MIT License
 Copyright (c) 2016-present Supasate Choochaisri

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react

This product uses react which is licensed by MIT.

The copyright and license notice of react is shown below.

Version 16.13.1
 MIT License
 Copyright (c) Facebook, Inc. and its affiliates.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-bootstrap

This product uses react-bootstrap which is licensed by MIT.

The copyright and license notice of react-bootstrap is shown below.

Version 1.0.1
 MIT License
 Copyright (c) 2014-present Stephen J. Collings, Matthew Honnibal, Pieter Vanderwerff

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-dnd

This product uses react-dnd which is licensed by MIT.

The copyright and license notice of react-dnd is shown below.

Version 16.13.1
MIT License
Copyright (c) 2015 Dan Abramov.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-dnd-html5-backend

This product uses react-dnd-html5-backend which is licensed by MIT.

The copyright and license notice of react-dnd-html5-backend is shown below.

Version 7.4.4
MIT License
Copyright (c) 2015 Dan Abramov.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-helmet

This product uses react-helmet which is licensed by MIT.

The copyright and license notice of react-helmet is shown below.

Version 6.1.0
MIT License
Copyright (c) 2015 NFL.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-dom

This product uses react-dom which is licensed by MIT.

The copyright and license notice of react-dom is shown below.

Version 16.13.0
MIT License
Copyright (c) Facebook, Inc. and its affiliates.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-id-generator

This product uses react-id-generator which is licensed by MIT.

The copyright and license notice of react-id-generator is shown below.

Version 3.0.0
MIT License
Copyright (c) 2019 Tomek.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-router

This product uses react-router which is licensed by MIT.

The copyright and license notice of react-router is shown below.

Version 5.1.2
MIT License
Copyright (c) React Training 2016-2018

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-select

This product uses react-select which is licensed by MIT.

The copyright and license notice of react-select is shown below.

Version 3.1.0
MIT License
Copyright (c) 2018 Jed Watson

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-tabs

This product uses react-tabs which is licensed by MIT.

The copyright and license notice of react-tabs is shown below.

Version 3.1.0
MIT License
Copyright (c) 2015-2019 by Matt Zabriskie

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-i18next

This product uses react-i18next which is licensed by MIT.

The copyright and license notice of react-i18next is shown below.

Version: 11.3.5
MIT License
Copyright (c) 2015 i18next

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■react-redux

This product uses react-redux which is licensed by MIT.

The copyright and license notice of react-redux is shown below.

Version 7.2.0
MIT License
Copyright (c) 2015-present Dan Abramov

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■redux-actions

This product uses redux-actions which is licensed by MIT.

The copyright and license notice of redux-actions is shown below.

Version: 2.6.5
MIT License
Copyright (c) Andrew Clark.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■redux-localstorage

This product uses redux-localstorage which is licensed by MIT.

The copyright and license notice of redux-localstorage is shown below.

Version: 0.4.1
MIT License
Copyright (c) 2015 Elger Lambert

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■redux

This product uses redux which is licensed by MIT.

The copyright and license notice of redux is shown below.

Version 4.0.5
MIT License
Copyright (c) 2015-present Dan Abramov

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■redux-thunk

This product uses redux-thunk which is licensed by MIT.

The copyright and license notice of redux-thunk is shown below.

Version: 2.2.0
MIT License
Copyright (c) 2015-present Dan Abramov.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■bootstrap

This product uses bootstrap which is licensed by MIT.

The copyright and license notice of bootstrap is shown below.

Version 4.4.1
MIT License
Copyright (c) 2014-present Stephen J. Collings, Matthew Honnibal, Pieter Vanderwerff

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■i18next

This product uses i18next which is licensed by MIT.

The copyright and license notice of i18next is shown below.

Version 19.4.2
MIT License
Copyright (c) 2017 i18next

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■sweetalert2

This product uses sweetalert2 which is licensed by MIT.

The copyright and license notice of sweetalert2 is shown below.

Version 9.10.12
MIT License
Copyright (c) 2014 Tristan Edwards & Limon Monte

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■fs-extra

This product uses fs-extra which is licensed by MIT.

The copyright and license notice of fs-extra is shown below.

Version: 9.0.0
The MIT License
Copyright (c) 2011-2017 JP Richardson.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■file-exists

This product uses file-exists which is licensed by MIT.

The copyright and license notice of file-exists is shown below.

Version 5.0.1
MIT License
Copyright (c) 2014 Scott Corgan

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■babel

This product uses babel which is licensed by MIT.

The copyright and license notice of babel is shown below.

Version 7.9.0
MIT License
Copyright (c) 2014-present Sebastian McKenzie and other contributors

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■history

This product uses history which is licensed by MIT.

The copyright and license notice of history is shown below.

Version 4.10.1
MIT License
Copyright (c) React Training 2016-2018

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■immer

This product uses immer which is licensed by MIT.

The copyright and license notice of immer is shown below.

Version 6.0.3
MIT License
Copyright (c) 2017 Michel Weststrate

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■jquery

This product uses jquery which is licensed by MIT.

The copyright and license notice of jquery is shown below.

Version 3.5.1
MIT License
Copyright OpenJS Foundation and other contributors, <https://openjsf.org/>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■popper.js

This product uses popper.js which is licensed by MIT.

The copyright and license notice of popper.js is shown below.

Version 1.16.0
MIT License
Copyright (c) 2019 Federico Zivolo

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■prop-types

This product uses prop-types which is licensed by MIT.

The copyright and license notice of prop-types is shown below.

Version 15.7.2

MIT License

Copyright (c) 2013-present, Facebook, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■Json.NET

This product uses Json.NET which is licensed by MIT.

The copyright and license notice of Json.NET is shown below.

Version 12.0.3
MIT License
Copyright (c) 2007 James Newton-King.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■lodash

This product uses lodash which is licensed by MIT.

The copyright and license notice of lodash is shown below.

Version 4.17.15
MIT License
Copyright JS Foundation and other contributors <<https://js.foundation/>>

Based on Underscore.js, copyright Jeremy Ashkenas, DocumentCloud and Investigative Reporters & Editors <<http://underscorejs.org/>>
This software consists of voluntary contributions made by many individuals. For exact contribution history, see the revision history available at <https://github.com/lodash/lodash>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■extend

This product uses extend which is licensed by MIT.

The copyright and license notice of extend is shown below.

Version 3.0.2
MIT License (MIT)
Copyright (c) 2014 Stefan Thomas

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

■mxgraph-js

This product uses mxgraph-js which is licensed by Apache (version 2.0).

The copyright and license notice of mxgraph-js is shown below.

Version 1.0.1
Apache License 2.0
Copyright 2010-2013 Coda Hale and Yammer, Inc., 2014-2015 Dropwizard Team

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

■guid-typescript

This product uses guid-typescript which is licensed by ISC.

The copyright and license notice of guid-typescript is shown below.

Version 1.0.9
ISC License


Permission to use, copy, modify, and/or distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS" AND THE AUTHOR DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

2 USER INTERFACE

2.1 Screen Structure

If a project is newly created or an existing one is opened, the following user interfaces will be displayed. When this tool is started, it will be in a state where no project is created, and only its menu bar and tool buttons will be displayed.



- ❶ Menu bar (👉 Page 24 Menu Bar)
- ❷ Tool buttons (👉 Page 32 Tool Buttons)
- ❸ Component window (👉 Page 33 Component Window)
- ❹ Design window (👉 Page 58 Design Window)
- ❺ Property window (👉 Page 59 Property Window)

2.2 Shortcut

Shortcuts can be used for this tool.

Shortcut	Description	Reference
Ctrl + N	Create Project	Page 24 Create Project
Ctrl + O	Open	Page 24 Open
Ctrl + S	Save	Page 24 Save
Ctrl + Shift + P	Preview	Page 26 Preview
Alt + F4	End Tool	Page 24 Exit
Delete	Delete Component Currently Selected	Page 58 Context menu
Ctrl + C	Copy Component Currently Selected	—
Ctrl + X	Cut Component Currently Selected	
Ctrl + V	Paste "copied" Component	
Ctrl + A	Select all components allocated in the design window	
Alt + A	Save the properties of the changed component	
Ctrl + Z	Undo the operation	
Ctrl + Y	Redo the operation canceled by [Undo]	
Ctrl + K	Bring the selected component to the front	
Ctrl + B	Send the selected component to the back	
Ctrl + Shift + [	Bring the selected component forward	
Ctrl + Shift +]	Send the selected component backward	

2.3 Menu Bar

The menu bar can be used to conduct edit and display operations. The items below are shown on the menu bar.


- Project ( Page 24 Project)
- Edit ( Page 25 Edit)
- View ( Page 26 View)
- Communication ( Page 27 Communication)
- Help ( Page 31 Help)

Project

■Create Project

[Project] ⇒ [Create Project]

This is used to select a CPU module's series and newly create a project. If a project is opened which is not saved yet, after having performed an operation to save it, this will create a new one.



[Range]
• FX5CPU
• RCP
• MX Controller

■Open

[Project] ⇒ [Open]

This is used to read a project which is saved in a personal computer's hard disk, etc.

■Save

[Project] ⇒ [Save]

This is used to overwrite and save the project currently opened.

■Save As

[Project] ⇒ [Save As]

This is used to set a project's name and save it in a personal computer's hard disk, etc.


The maximum length of a project's name specifiable can be varied from 1 to 216 bytes, depending on its save location.

Prohibited characters (\, /, :, *, ?, ", <, >, |) cannot be used for a project name.

■Recent Projects

[Project] ⇒ [Recent Projects]

This is used to select one from projects shown on its submenu. The submenu displays projects which are opened recently.
(Up to 5 projects)



■Exit

[Project] ⇒ [Exit]


This is used to end this tool. If a project is opened which is not saved yet, after having performed an operation to save it, this will end this tool.

Edit

■Create Page

[Edit] ⇨ [Create Page]

This is used to set an HTML file's name and newly create it in a project in question. It is possible to create an HTML file that contains no more than 160 pages (including its index.html) in a project.

A screenshot of a 'Create Page' dialog box. It has a title bar with a close button (X). Below the title bar is a label 'Page Name' followed by a text input field. At the bottom of the dialog are two buttons: 'OK' and 'Cancel'.

For a file name, only half-width alphanumeric characters, "-", and "_" can be used, and no more than 26 such characters must be entered. A file name can be changed from its property window. (📖 Page 59 Property Window)

■Undo

[Edit] ⇨ [Undo]

This is used to undo the operation.

■Redo

[Edit] ⇨ [Redo]

This is used to redo the operation canceled by [Undo].

■Apply

[Edit] ⇨ [Apply]

This is used to save the properties of the changed component.

View

■Preview

[View] ⇒ [Preview]

This is used to show the preview display of the currently displayed design window's contents in a Web browser.

■Show Gridlines


[View] ⇒ [Show Gridlines]

This can be used to display/not display gridlines in the design window. As far as a user doesn't change the display/not display of those gridlines, this situation will not be changed even if this tool is restarted.

■Guide Setting

[View] ⇒ [Guide Setting]

This can be used to select the display/not display of the guide in the design window. This can be used to set the guide's size.



Such guide settings will be reflected in all pages within a project in question.

[Range]

- Width: 1 to 3840
- Height: 1 to 2160
- Color code: This will be selected from the color palette.
- Display: Display/Not Display
- Screen adjust setting: None/Horizontal width adjust/Vertical width adjust/Horizontal, Vertical width adjust

These settings can be initialized using "Reset to Default".


Point

The guide is shown only on the design window. It is not shown on a preview window or a window written to an SD memory card.

■Switch Display Language

[View] ⇒ [Switch Display Language]

A display language used in this tool (English, Japanese, and Chinese (simplified characters)) can be changed.



Communication

- For MELSEC iQ-R series CPU modules, the R01CPU and R02CPU with firmware version "30" or later support this function.
- For MELSEC iQ-R series CPU modules, the R04CPU, R08CPU, R16CPU, R32CPU, R120CPU, R04ENCPU, R08ENCPU, R16ENCPU, R32ENCPU, and R120ENCPU with firmware version "63" or later support this function.
- When the FX5S CPU module is used, an SD memory card module is required.

With the communication function, this tool communicates with CPU modules through FTP communication. For the FTP server settings, refer to the following.

 MELSEC iQ-R Ethernet User's Manual (Application)

 MELSEC iQ-F FX5 User's Manual (Communication)

 MELSEC MX Controller MX-R Model User's Manual

Point



Although the controller can use FTPS as the protocol of the FTP server function, User Web Page Design Tool does not support FTPS communication. Set the protocol of the FTP server function of the controller to FTP or FTP/FTPS when communicating with User Web Page Design Tool.

■Write files to PLC (SD Memory Card)

[Communication] ⇒ [Write files to PLC (SD Memory Card)]

This is used to write a project file, which is opened by this tool, to an SD memory card attached to a CPU module. However, it is necessary to create a folder hierarchy for a user Web page in such an SD memory card beforehand. (📖 Page 73 File configuration)



After all files under a WWW folder in such an SD memory card are deleted, such a project will be written to it.



Read files from PLC (SD Memory Card)

[Communication] ⇨ [Read files from PLC (SD Memory Card)]


This is used to read a project from an SD memory card attached to a CPU module.



■Communication Settings

[Communication] ⇒ [Communication Settings]

This is used to configure FTP communication with a CPU module.



Use the same IP address and FTP server settings of a CPU module with which communication is to be conducted.

■Range (RCPU)

- IP Address: 0.0.0.1 to 223.255.255.254
- Login Name: 1 to 12 half-width characters
- Password: 0 to 32 half-width characters (alphanumeric characters and symbols)

■Range (FX5CPU)

- IP Address: 0.0.0.1 to 223.255.255.254
- Login Name: 1 to 12 half-width characters
- Password: 1 to 32 half-width characters (alphanumeric characters and symbols)

■Range (controller)

- IP Address: 0.0.0.1 to 223.255.255.254
- Login Name: 1 to 32 half-width (alphanumeric characters and symbols) and full-width characters
- Password: 6 to 64 half-width characters (alphanumeric characters and symbols)

Conduct a communication test to check if communication with a CPU module in question is possible.

It is necessary to configure a CPU module's Web server settings to view a user Web page in a browser.

📖 MELSEC iQ-R/MELSEC iQ-F Web Server Function Guide Book

📖 MELSEC MX Controller MX-R Model User's Manual

Help

■Show Help

[Help] ⇒ [Show Help]

This is used to view the help file (in PDF format).

■Connection to MITSUBISHI ELECTRIC FA Global Website

[Help] ⇒ [Connection to MITSUBISHI ELECTRIC FA Global Website]

This is used to view the MITSUBISHI ELECTRIC FA Global Website in a Web browser. Different websites will be displayed, depending on selected languages.

- For a case where "English" or "Chinese" is selected in "Switch Display Language": MITSUBISHI ELECTRIC FA Global Website
- For a case where "Japanese" is selected in "Switch Display Language": MITSUBISHI ELECTRIC FA Website

■Version

[Help] ⇒ [Version]

This is used to view information items on a software version, etc.

■License

[Help] ⇒ [License]

This is used to view information items on the licenses of software items used by this tool. ( Page 7 Software License)

2.4 Tool Buttons

The tool buttons are equivalent to some of the menu commands. The following table lists the tool buttons.

Icon	Description	Reference
	[Create Project] This is used to select a CPU module's series and newly create a project.	Page 24 Create Project
	[Save Project] This is used to overwrite and save the project currently opened.	Page 24 Save
	[Copy Page] This is used to set a page name and copy the design window currently displayed.	—
	[Preview] This is used to preview the design window currently displayed, on a web browser.	Page 26 Preview
	[Zoom-In] This is used to zoom in on the display. Each click of this button increases the zoom level by 10%. (200% maximum)	—
	[Zoom-Out] This is used to zoom out on the display. Each click of this button decreases the zoom level by 10%. (10% minimum)	—
	[Zoom] This is used to change the zoom level. To change the zoom level, select a percentage from the drop-down list or enter a desired percentage into this field. (Range: 10% to 200%)	—
	[Communication Settings] This is used to configure FTP communication with a CPU module.	Page 30 Communication Settings
	[Write files to PLC (SD Memory Card)] This is used to write a project to an SD memory card attached to a CPU module.	Page 28 Write files to PLC (SD Memory Card)
	[Read files from PLC (SD Memory Card)] This is used to read a project from an SD memory card attached to a CPU module.	Page 29 Read files from PLC (SD Memory Card)
	[Undo] This is used to undo the processing.	—
	[Redo] This is used to redo the processing.	—
	[Snap] This is used to change the travel distance when moving the selected component.	—
	[Grid interval] This is used to change the gridlines interval.	—

2.5 Component Window

This is used to view components used to configure a user Web page. Drag an individual component to the design window so that it can be allocated. ( Page 58 Design Window) To configure an individual item's settings, use its property window. ( Page 59 Property Window)

Refer to the following documents for more information about individual components.

 MELSEC iQ-R Ethernet User's Manual (Application)

 MELSEC iQ-F FX5 User's Manual (Communication)

 MELSEC MX Controller MX-R Model User's Manual

PLC components

The followings can be used as PLC components.

Icon	Description	Reference
	[UserWebPage component - Data Block] This is used to display specified device data items in a tabular format. Multiple devices and their directions can also be specified.	Page 34 Data Block
	[UserWebPage component - Level Display] This is used to view the current value of a specified device as a level relative to its upper and lower limits. Different colors can be allocated to a level display component, depending on whether its current value is larger than its upper limit or smaller than its lower limit, and its direction can also be specified.	Page 36 Level Display
	[UserWebPage component - Graphic Display] This is used to display a figure in a specified color when the current value of a specified device is within a set range.	Page 37 Graphic Display
	[UserWebPage component - Image Display] This is used to display a specified image file when the current value of a specified device is within a set range.	Page 39 Image Display
	[UserWebPage component - Historic Graph] This is used to display the time series of a device's values in a line graph. A device's value is read at update intervals, and when the number of allowed records is reached, the oldest record will be deleted and the line graph will shift to the left.	Page 41 Historic Graph
	[UserWebPage component - Input Button] This is used to display a preset button that writes a value to a specified device.	Page 42 Input Button
	[PLC component - Character Display (ASCII)] This is used to display the current value of the specified device as the text type.	Page 43 Character Display (ASCII)
	[PLC component - Arbitrary value write Button] This is used to display a set of an input field and a write button to write an arbitrary value.	Page 45 Arbitrary value Write Button
	[UserWebPage component - Logout Button] This is used to display a button for logging out. If a logout button is clicked, a user login page (Log-in_User.html) will appear.	Page 47 Logout Button

The current value of a device will be updated at regular intervals. ( Page 59 Display update interval)

Up to 128 PLC components can be allocated to an HTML file page. However, for logout button components, only one can be used in an HTML file.

If the input button and arbitrary value write button components are used, set "Write Device" in "Web Server Account Settings" to "Enable". ( MELSEC iQ-R/MELSEC iQ-F Web Server Function Guide Book) For an account that does not write operations, such a setting is not necessary.

Data Block

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
Direction <input type="text" value="Vertical"/>	Direction	Vertical, Horizontal
Block Size <input type="text" value="1"/>	Block Size	1 to 32
Device Property <input type="button" value="Settings"/>	Device Property	 Page 35 Device Property
Line Color <input type="color" value="#0000FF"/>	Line Color	This will be selected from the color palette.
— Device Name		
Display ☒ Display ☐ Not Display	Device Name	Display, Not Display
Font Color <input type="color" value="#000000"/>	Font Color	This will be selected from the color palette.
Background Color <input type="color" value="#808080"/>	Background Color	This will be selected from the color palette.
Bg-color Transparency <input type="range" value="0%"/>	Bg-color Transparency	0% to 100%
Cell Width <input type="text" value="100"/>	Cell Width ^{*1}	10 to 1920
Cell Height <input type="text" value="40"/>	Cell Height ^{*2}	10 to 1080
— Device Value		
Font Color <input type="color" value="#0000FF"/>	Device Value	Font Color
Background Color <input type="color" value="#000000"/>	Background Color	This will be selected from the color palette.
Bg-color Transparency <input type="range" value="0%"/>	Bg-color Transparency	0% to 100%
Cell Width <input type="text" value="80"/>	Cell Width	10 to 1920
Cell Height <input type="text" value="50"/>	Cell Height	10 to 1080
— Text Format		
Font Attributes B I U	Text Format	Font Attributes
Font Size <input type="text" value="20"/>	Font Size	1 to 1500
Vertical Align <input type="text" value="Middle"/>	Vertical Align	Top, Bottom, Middle
Horizontal Align <input type="text" value="Center"/>	Horizontal Align	Left, Right, Center
Left Margin <input type="text" value="0"/>	Left Margin	0 to 32
Right Margin <input type="text" value="0"/>	Right Margin	0 to 32
Top Margin <input type="text" value="0"/>	Top Margin	0 to 32
Bottom Margin <input type="text" value="0"/>	Bottom Margin	0 to 32
— Conditional Format		
Use Conditional Format <input type="text" value="No"/>	Conditional Format	Use Conditional Format
— Display		
Parts Display/Hide <input type="text" value="No"/>	Parts Display/Hide	Yes, No
X Coordinate <input type="text" value="10"/>	Device	 Page 54 Device settings
Y Coordinate <input type="text" value="20"/>	Device Number	
	Data Type	
	Comparison Value	
	Display Condition	=, !=, >, >=, <, <=
	Mode ^{*4}	Display when ON, Display when OFF
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160
In order to save the changes, please click on the [Apply] button.		

*1 It can be edited when "Vertical" is selected as a direction.

*2 It can be edited when "Horizontal" is selected as a direction.

*3 For Japanese (two-byte characters), italics are not applied.

*4 It can be edited when "Bit" is selected as the Data Type.

■Device Property

A device to be displayed in a data block can be registered. Up to 32 devices can be registered per data block.

Device Property

Display Label	Preview Value	Language	Device		Data Type	Display Format	
D0	1234	Comment 1 ▾	D ▾	0	Word [Signed] ▾	Decimal ▾	+
D0	1234	Comment 1 ▾	D ▾	0	Word [Signed] ▾	Decimal ▾	-

OK

Cancel

Properties	Settings
Display Label	No more than 100 characters
Preview Value	No more than 100 characters
Language	Comment 1, Comment 2, Comment 3
Device	📖 Page 54 Device settings
Data Type	
Display Format	
+	This is used to add a line to a displayed device.
-	This is used to delete a line from a displayed device. (The second line or thereafter)

■Setting Range Property

The settings of Conditional Format can be set. Depending on the number of ranges set, the number of settings will vary.

Setting Range Property

Low	High	Font Color	Background Color	Bg-color Transparency
-5000	5000			◀▶ 0%

OK

Cancel

Properties	Settings
Low	📖 Page 56 Settings(Decimal)
High	
Font Color	This will be selected from the color palette.
Background Color	This will be selected from the color palette.
Bg-color Transparency	0% to 100%

Level Display

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div> Direction <input type="text" value="Vertical"/> </div> <div> Device <input type="text" value="D"/> </div> <div> Device Number <input type="text" value="0"/> </div> <div> Data Type <input type="text" value="Word [Signed]"/> </div> <div> Level Color <input type="text"/> </div> <div> Upper Color <input type="text"/> </div> <div> Lower Color <input type="text"/> </div> <div> Background Color <input type="text"/> </div> <div> Upper Value <input type="text" value="32767"/> </div> <div> Lower Value <input type="text" value="-32768"/> </div> <div> Alarm Value </div> <div> Display Line ☒ Display ☐ Not Display </div> <div> Line Color <input type="text"/> </div> <div> Upper Value <input type="text" value="20000"/> </div> <div> Lower Value <input type="text" value="-20000"/> </div> <div> Current Value </div> <div> Display ☒ Display ☐ Not Display </div> <div> Color <input type="text"/> </div> <div> Background Color <input type="text"/> </div> <div> Width <input type="text" value="150"/> </div> <div> Height <input type="text" value="50"/> </div> <div> Level Length <input type="text" value="10"/> </div> <div> Level Width <input type="text" value="150"/> </div> <div> X Coordinate <input type="text" value="250"/> </div> <div> Y Coordinate <input type="text" value="20"/> </div> <div> In order to save the changes, please click on the [Apply] button. </div>	Direction	Vertical, Horizontal
	Device	Page 54 Device settings
	Device Number	
	Data Type	
	Level Color	This will be selected from the color palette.
	Upper Color	
	Lower Color	
	Background Color	
	Upper Value	Page 56 Settings(Decimal)
	Lower Value	
	Alarm Value	Display, Not Display
	Line Color	This will be selected from the color palette.
	Upper Value	Page 56 Settings(Decimal)
	Lower Value	
	Current Value	Display, Not Display
	Color	This will be selected from the color palette.
	Background Color	
	Width	10 to 3840
	Height	10 to 2160
	Level Length	10 to 3840
	Level Width	10 to 2160
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

Graphic Display

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
Figure Type <input type="text" value="Triangle"/>	Figure Type	Triangle, Rectangle, and Ellipse
Default Color <input type="text" value="Red"/>	Default Color	This will be selected from the color palette.
Device <input type="text" value="D"/>	Device	☞ Page 54 Device settings
Device Number <input type="text" value="0"/>	Device Number	
Data Type <input type="text" value="Word [Signed]"/>	Data Type	
Range Number <input type="text" value="2"/>	Range Number	
Setting Range Property <input type="text" value="Settings"/>	Setting Range Property	☞ Page 38 Setting Range Property
Figure Height <input type="text" value="-30"/>	Figure Height ^{*1}	-2160 to -1, 1 to 2160
Figure Width <input type="text" value="60"/>	Figure Width	10 to 3840
— Text Format		
Label Text <input type="text" value=""/>	Label Text	No more than 1000 characters (Comment 1, Comment 2, and Comment 3 can be input by clicking the icon of Label Text.)
Vertical Align <input type="text" value="Middle"/>	Vertical Align	Top, Bottom, Middle
Horizontal Align <input type="text" value="Center"/>	Horizontal Align	Left, Right, Center
Outside Parts <input type="text" value="Show"/>	Outside Parts	Show, Hide
Font Size <input type="text" value="20"/>	Font Size	1 to 1500
Font Attributes <input type="text" value="B I U"/>	Font Attributes	Bold, italic ^{*2} , underscore
Left Margin <input type="text" value="0"/>	Left Margin	0 to 32
Right Margin <input type="text" value="0"/>	Right Margin	0 to 32
Top Margin <input type="text" value="0"/>	Top Margin	0 to 32
Bottom Margin <input type="text" value="0"/>	Bottom Margin	0 to 32
Font Color <input type="text" value="Black"/>	Font Color	This will be selected from the color palette.
— Display		
Parts Display/Hide <input type="text" value="No"/>	Parts Display/Hide	Yes, No
X Coordinate <input type="text" value="70"/>	Device	☞ Page 54 Device settings
Y Coordinate <input type="text" value="190"/>	Device Number	
	Data Type	
	Comparison Value	
	Display Condition	=, !=, >, >=, <, <=
	Mode ^{*3}	Display when ON, Display when OFF
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

*1 If the "Figure Type" property is "Triangle", setting a negative number will result in a downward triangle.

*2 For Japanese (two-byte characters), italics are not applied.

*3 It can be edited when "Bit" is selected as the Data Type.

■Setting Range Property

A figure's upper and lower limits can be set to change its color. Depending on the number of ranges set, the number of settings will vary.

Range ✕

Low	High	Color	Text	Language	Fontcolor
-5000	5000	<div></div>		Comment 1 ▾	<div></div>
-10000	10000	<div></div>		Comment 1 ▾	<div></div>

OK

Cancel

Properties	Settings
Low	 Page 56 Settings(Decimal)
High	
Color	This will be selected from the color palette.
Text	No more than 100 characters
Language	Comment 1, Comment 2, Comment 3
Fontcolor	This will be selected from the color palette.

Image Display

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div>Default Image <input type="button" value="Upload Image"/></div> <div>sample0.png</div> <div>Device <input type="text" value="D"/></div> <div>Device Number <input type="text" value="0"/></div> <div>Data Type <input type="text" value="Word [Signed]"/></div> <div>Range Number <input type="text" value="2"/></div> <div>Setting Range Property <input type="button" value="Settings"/></div> <div>Image Height <input type="text" value="30"/></div> <div>Image Width <input type="text" value="30"/></div> <div>— Text Format</div> <div>Label Text <input type="text" value=""/></div> <div>Vertical Align <input type="text" value="Middle"/></div> <div>Horizontal Align <input type="text" value="Center"/></div> <div>Outside Parts <input type="text" value="Show"/></div> <div>Font Size <input type="text" value="20"/></div> <div>Font Attributes <input type="text" value="B I U"/></div> <div>Left Margin <input type="text" value="0"/></div> <div>Right Margin <input type="text" value="0"/></div> <div>Top Margin <input type="text" value="0"/></div> <div>Bottom Margin <input type="text" value="0"/></div> <div>Font Color <input type="text" value=""/></div> <div>— Display</div> <div>Parts Display/Hide <input type="text" value="No"/></div> <div>X Coordinate <input type="text" value="310"/></div> <div>Y Coordinate <input type="text" value="190"/></div> <div>In order to save the changes, please click on the [Apply] button.</div>	Default Image ^{*1}	Page 57 Image file
	Device	Page 54 Device settings
	Device Number	
	Data Type	
	Range Number	1 to 5
	Setting Range Property	Page 38 Setting Range Property
	Image Height	10 to 3840
	Image Width	10 to 2160
	Text Format	Label Text
		No more than 1000 characters (Comment 1, Comment 2, and Comment 3 can be input by clicking the icon of Label Text.)
		Vertical Align
		Top, Bottom, Middle
		Horizontal Align
		Left, Right, Center
		Outside Parts
		Show, Hide
		Font Size
		1 to 1500
		Font Attributes
		Bold, italic ^{*2} , underscore
		Left Margin
		0 to 32
		Right Margin
		0 to 32
		Top Margin
		0 to 32
		Bottom Margin
		0 to 32
		Font Color
		This will be selected from the color palette.
	Display	Parts Display/Hide
		Yes, No
		Device
		Page 54 Device settings
		Device Number
		Data Type
		Comparison Value
		Display Condition
		=, !=, >, >=, <, <=
		Mode ^{*3}
		Display when ON, Display when OFF
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

*1 This is an image when the value of a device in question is out of a setting range in "Setting Range Property".

*2 For Japanese (two-byte characters), italics are not applied.

*3 It can be edited when "Bit" is selected as the Data Type.

■Setting Range Property

Upper and lower limits can be set to change a displayed image. Depending on the number of ranges set, the number of settings will vary.

Range ✕

Low	High		Image File	Fontcolor	Text	Language
-5000	5000	Upload Image	sample1.png	<div></div>		Comment 1 ▾
-10000	10000	Upload Image	sample2.png	<div></div>		Comment 1 ▾

OKCancel

Properties	Settings
Low	 Page 56 Settings(Decimal)
High	
Image File	 Page 57 Image file
Fontcolor	This will be selected from the color palette.
Text	No more than 100 characters
Language	Comment 1, Comment 2, Comment 3

Historic Graph

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div> <div>Graph Element Number</div> <div>2</div> </div> <div> <div>Graph Element Property</div> <div>Settings</div> </div> <div> <div>Data Type</div> <div>Word [Signed]</div> </div> <div> <div>Upper Limit Value</div> <div>32767</div> </div> <div> <div>Lower Limit Value</div> <div>-32768</div> </div> <div> <div>Number Of Records</div> <div>20</div> </div> <div> <div>Vertical Axis Interval</div> <div>5</div> </div> <div> <div>Number Of Horizontal Axes</div> <div>9</div> </div> <div> <div>Graph Background Color</div> <div></div> </div> <div> <div>Character Color</div> <div></div> </div> <div> <div>Right Margin</div> <div>25</div> </div> <div> <div>Left Margin</div> <div>75</div> </div> <div> <div>Upper Margin</div> <div>15</div> </div> <div> <div>Lower Margin</div> <div>55</div> </div> <div> <div>Graph Height</div> <div>380</div> </div> <div> <div>Graph Width</div> <div>550</div> </div> <div> <div>X Coordinate</div> <div>390</div> </div> <div> <div>Y Coordinate</div> <div>38</div> </div> <div> <div>Apply</div> </div> <div> <div>In order to save the changes, please click on the [Apply] button.</div> </div>	Graph Element Number	1 to 32
	Graph Element Property	Page 41 Graph Element Property
	Data Type	Page 54 Device settings
	Upper Limit Value	Page 56 Settings(Decimal)
	Lower Limit Value	
	Number Of Records	5 to 100
	Vertical Axis Interval	0 to 99
	Number Of Horizontal Axes	0 to 99
	Graph Background Color	This will be selected from the color palette.
	Character Color	This will be selected from the color palette.
	Right Margin	1 to 3840
	Left Margin	1 to 3840
	Upper Margin	1 to 2160
	Lower Margin	1 to 2160
	Graph Height	10 to 2160
	Graph Width	10 to 3840
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

■Graph Element Property

This is used to set a device whose graph will be displayed. Depending on the number of graph elements, the number of settings will vary.

Graph Elements

Device Name

Device Number

Line Color

D

0

D

1

OK

Cancel

Properties	Settings
Device Name	Page 54 Device settings
Device Number	
Line Color	This will be selected from the color palette.

Input Button

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div> Device <input type="text" value="X"/> Device Number <input type="text" value="0"/> Data Type <input type="text" value="Bit"/> Operation Settings <input type="text" value="Bit Set"/> Display Format <input type="text" value="Binary"/> Write Value <input type="text" value="1"/> Write Confirm <input type="text" value="Display"/> Multi Function <input type="text" value="OFF"/> Multiple Settings <input type="text" value="Settings"/> Button Width <input type="text" value="150"/> Button Height <input type="text" value="50"/> </div> <div> Text Format <div> Button Text <input type="text" value="OK"/> Vertical Align <input type="text" value="Middle"/> Horizontal Align <input type="text" value="Center"/> Outside Parts <input type="text" value="Show"/> Font Size <input type="text" value="20"/> Font Attributes <input type="text" value="B I U"/> Left Margin <input type="text" value="0"/> Right Margin <input type="text" value="0"/> Top Margin <input type="text" value="0"/> Bottom Margin <input type="text" value="0"/> Font Color <input type="text" value="Black"/> Bg-color on OFF <input type="text" value="Light Gray"/> Transparency on OFF <input type="text" value="0%"/> Bg-color on ON <input type="text" value="Light Gray"/> Transparency on ON <input type="text" value="0%"/> Show Border <input type="text" value="Yes"/> Border Color <input type="text" value="Dark Gray"/> </div> Display <div> Parts Display/Hide <input type="text" value="No"/> </div> <div> X Coordinate <input type="text" value="260"/> Y Coordinate <input type="text" value="310"/> </div> <div> In order to save the changes, please click on the [Apply] button. </div> </div>	Device	Page 54 Device settings
	Device Number	
	Data Type	
	Operation Settings	Bit Set: Clicking the button sets the write value. Bit Momentary: Clicking the button turns on/off a bit.
	Display Format	Page 54 Device settings
	Write Value	Page 56 Settings
	Write Confirm	Display, Not Display
	Multiple Function	ON, OFF
	Multiple Settings	Page 43 Multiple Settings
	Button Width	10 to 3840
	Button Height	10 to 2160
	Text Format	Button Text
		No more than 1000 characters (Comment 1, Comment 2, and Comment 3 can be input by clicking the icon of Label Text.)
		Vertical Align
		Top, Bottom, Middle
		Horizontal Align
		Left, Right, Center
		Outside Parts
		Show, Hide
		Font Size
		1 to 1500
		Font Attributes
		Bold, italic ^{*1} , underscore
		Left Margin
		0 to 32
		Right Margin
		0 to 32
		Top Margin
		0 to 32
		Bottom Margin
		0 to 32
		Font Color
		This will be selected from the color palette.
		Bg-color on OFF
		This will be selected from the color palette.
		Transparency on OFF
		0% to 100%
		Bg-color on ON
		This will be selected from the color palette.
		Transparency on ON
		0% to 100%
		Show Border
		Yes, No
		Border Color
		This will be selected from the color palette.
	Display	Parts Display/Hide
		Yes, No
		Device
		Page 54 Device settings
		Device Number
		Data Type
		Comparison Value
		Display Condition
		=, !=, >, >=, <, <=
		Mode ^{*2}
		Display when ON, Display when OFF
	X Coordinate	
	0 to 3840	
	Y Coordinate	
	0 to 2160	

*1 For Japanese (two-byte characters), italics are not applied.

*2 It can be edited when "Bit" is selected as the Data Type.

Multiple Settings

The settings can be configured by turning on the multiple function.

Multiple Settings ✕

Operation Type	Device		Data Type	Display Format	Operation Settings	Write Value	
Write ▼	D ▼	0	Word [Signed] ▼	Decimal ▼	Bit Set ▼	0	+
Write ▼	D ▼	0	Word [Signed] ▼	Decimal ▼	Bit Set ▼	0	-

OK Cancel

Properties	Settings
Operation Type	Write
Device	Page 54 Device settings
Data Type	
Display Format	
Operation Settings	Bit Set: Clicking the button sets the write value. Bit Momentary: Clicking the button turns on/off a bit.
Write Value	0, 1
+	This is used to add a line to a displayed device.
-	This is used to delete a line from a displayed device. (The second line or thereafter)

Character Display (ASCII)

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
Device	Device* ¹	Page 54 Device settings
Device Number	Device Number* ¹	
Data Type	Data Type	
Char Count	Char Count* ² * ³ * ⁴	1 to 64
	Write Confirm	Display, Not Display
Text Format	Text Format	Display Text* ⁵
Display Text	Font Size	Input up to 64 characters
Font Size	Font Attributes	1 to 1500
Font Attributes	Font Color	Bold, italic* ⁶ , underscore
Font Color	Horizontal Align	This will be selected from the color palette.
Horizontal Align	Vertical Align	Left, Right, Center
Vertical Align	Outside Parts	Top, Bottom, Middle
Outside Parts	Text Wrap	Select Show/Hide
Text Wrap	Show Scrollbar	Yes, No
Show Scrollbar	Left Margin	Select Show/Hide
Left Margin	Right Margin	0 to 32
Right Margin	Top Margin	0 to 32
Top Margin	Bottom Margin	0 to 32
Bottom Margin	Font Color	0 to 32
		This will be selected from the color palette.
Background/Border	Background/Border	
Border Type	Border Type	Select Square/Rounded Corners
Background Color	Background Color	This will be selected from the color palette.
Bg-color Transparency	Bg-color Transparency	0% to 100%
Show Border	Show Border	Yes, No

Property window	Properties		Settings
<div> <div>Conditional Format</div> <div> <div>Use Conditional Format</div> <div>No ▼</div> </div> </div> <div> <div>Write Operations</div> <div> <div>Enable Write</div> <div>No ▼</div> </div> </div> <div> <div>Display</div> <div> <div>Parts Display/Hide</div> <div>No ▼</div> </div> <div> <div>Width</div> <div>120</div> </div> <div> <div>Height</div> <div>30</div> </div> <div> <div>X Coordinate</div> <div>30</div> </div> <div> <div>Y Coordinate</div> <div>620</div> </div> <div> In order to save the changes, please click on the [Apply] button. </div> </div>	Conditional Format	Use Conditional Format	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Range Number	0 to 16
		Setting Range Property	Page 44 Setting Range Property
	Write Operations	Enable Write	Yes, No
		Write Confirm	Select Display/Not Display
		Write Condition	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Comparison Value	
		Write Condition	=, !=, >, >=, <, <=
		Mode*7	Display when ON, Display when OFF
		Write Disabled Font Color	This will be selected from the color palette.
		Write Disabled Bg color	This will be selected from the color palette.
		Write Disabled Transparency	0% to 100%
	Display	Parts Display/Hide	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Comparison Value	
		Display Condition	=, !=, >, >=, <, <=
		Mode*7	Display when ON, Display when OFF
	Width		0 to 3840
	Height		0 to 2160
	X Coordinate		0 to 3840
	Y Coordinate		0 to 2160

*1 This device is the start device of the text data to be displayed.

*2 Two characters per word

*3 The characters are displayed in order of the lower and upper devices.

*4 The characters that can be displayed are 0x20 to 0x7e in the ASCII code (half-width alphanumeric characters).

*5 Set the initial value. The size of the text box can be checked in the preview.

*6 For Japanese (two-byte characters), italics are not applied.

*7 It can be edited when "Bit" is selected as the Data Type.

Setting Range Property

The settings of Conditional Format can be set. Depending on the number of ranges set, the number of settings will vary.

Setting Range Property

Low	High	Font Color	Background Color	Bg-color Transparency
-5000	5000			0%

OK

Cancel

Properties	Settings
Low	Page 56 Settings(Decimal)
High	
Font Color	This will be selected from the color palette.
Background Color	This will be selected from the color palette.
Bg-color Transparency	0% to 100%

Arbitrary value Write Button

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
Position <input type="text" value="Right"/>	Position	Left, Right, Top, and Bottom
Input Value <input type="text" value="0"/>	Input Value	 Page 56 Settings
Device <input type="text" value="D"/>	Device	 Page 54 Device settings
Device Number <input type="text" value="0"/>	Device Number	
Data Type <input type="text" value="Word [Signed]"/>	Data Type	
Write Format <input type="text" value="Decimal"/>	Write Format	
Write Confirm <input type="text" value="Display"/>	Write Confirm	Display, Not Display
— Text Format		
Vertical Align <input type="text" value="Middle"/>	Text Format	Vertical Align
Horizontal Align <input type="text" value="Center"/>		Horizontal Align
Outside Parts <input type="text" value="Show"/>		Outside Parts
Font Size <input type="text" value="20"/>		Font Size
Font Attributes <input type="text" value="B I U"/>		Font Attributes
Left Margin <input type="text" value="0"/>		Left Margin
Right Margin <input type="text" value="0"/>		Right Margin
Top Margin <input type="text" value="0"/>		Top Margin
Bottom Margin <input type="text" value="0"/>		Bottom Margin
— Input area Style		
Font Color <input type="text" value=""/>	Input area Style	Font Color
Background Color <input type="text" value=""/>		Background Color
Bg-color Transparency <input type="text" value="0%"/>		Bg-color Transparency
Show Border <input type="text" value="Yes"/>		Show Border
Border Color <input type="text" value=""/>		Border Color
— Button Style		
Button Text <input type="text" value="SET"/>	Button Style	Button Text
Bg-color on OFF <input type="text" value=""/>		Bg-color on OFF
Transparency on OFF <input type="text" value="0%"/>		Transparency on OFF
Bg-color on ON <input type="text" value=""/>		Bg-color on ON
Transparency on ON <input type="text" value="0%"/>		Transparency on ON
Show Border <input type="text" value="Yes"/>		Show Border
Border Color <input type="text" value=""/>		Border Color

Property window	Properties		Settings
<div> <div>Conditional Format</div> <div> <div>Use Conditional Format</div> <div>No ▼</div> </div> </div> <div> <div>Display</div> <div> <div>Parts Display/Hide</div> <div>No ▼</div> </div> </div> <div> <div>Width</div> <div>220</div> </div> <div> <div>Height</div> <div>30</div> </div> <div> <div>X Coordinate</div> <div>270</div> </div> <div> <div>Y Coordinate</div> <div>490</div> </div> <div> In order to save the changes, please click on the [Apply] button. </div>	Conditional Format	Use Conditional Format	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Range Number	0 to 16
		Setting Range Property	Page 46 Setting Range Property
	Display	Parts Display/Hide	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Comparison Value	
		Display Condition	=, !=, >, >=, <, <=
		Mode*2	Display when ON, Display when OFF
	Width		10 to 3840
	Height		10 to 2160
	X Coordinate		0 to 3840
	Y Coordinate		0 to 2160

*1 For Japanese (two-byte characters), italics are not applied.

*2 It can be edited when "Bit" is selected as the Data Type.

Setting Range Property

The settings of Conditional Format can be set. Depending on the number of ranges set, the number of settings will vary.

Setting Range Property

Low	High	Font Color	Background Color	Bg-color Transparency
-5000	5000			0%

OK

Cancel

Properties	Settings
Low	Page 56 Settings(Decimal)
High	
Font Color	This will be selected from the color palette.
Background Color	This will be selected from the color palette.
Bg-color Transparency	0% to 100%

Logout Button

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div> <div> <div>Button Text</div> <div>Logout</div> </div> <div> <div>Button Width</div> <div>100</div> </div> <div> <div>Button Height</div> <div>26</div> </div> <div> <div>Bg-color on OFF</div> <div></div> </div> <div> <div>Transparency on OFF</div> <div>◀▶ 0%</div> </div> <div> <div>Bg-color on ON</div> <div></div> </div> <div> <div>Transparency on ON</div> <div>◀▶ 0%</div> </div> <div> <div>Show Border</div> <div>Yes ▼</div> </div> <div> <div>Border Color</div> <div></div> </div> <div> <div>— Text Format</div> <div></div> </div> <div> <div>Font Attributes</div> <div>B <i>I</i> <u>U</u></div> </div> <div> <div>X Coordinate</div> <div>60</div> </div> <div> <div>Y Coordinate</div> <div>490</div> </div> <div> <div>In order to save the changes, please click on the [Apply] button.</div> </div> </div>	Button Text	No more than 100 characters
	Button Width	10 to 3840
	Button Height	10 to 2160
	Bg-color on OFF	This will be selected from the color palette.
	Transparency on OFF	0% to 100%
	Bg-color on ON	This will be selected from the color palette.
	Transparency on ON	0% to 100%
	Show Border	Yes, No
	Border Color	This will be selected from the color palette.
	Text Format	Font Attributes
	Font Attributes	Bold, italic ^{*1} , underscore
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

*1 For Japanese (two-byte characters), italics are not applied.

Generic components

For generic components, the followings can be used.

Icon	Description	Reference
	[Label] This is used to display a label.	Page 49 Label
	[Hyper Link] This is used to display a label to which a hyper link is set. Click the label to jump to the hyper link destination. A hyper link to an HTML page in a project and one to an external URL can be set.	Page 51 Hyper Link
	[Image Tag] This is used to display an image file.	Page 52 Image Tag
	[Line] This is used to display a line in a specified area.	Page 52 Line
	[Ellipse] This is used to display an ellipse.	Page 53 Ellipse
	[Rectangle] This is used to display a rectangle.	Page 53 Rectangle

Up to 256 generic components can be allocated to an HTML file page.

Label

Below are setting items which will be displayed in its property window.

Property window	Properties		Settings
<div> <div>Text Format</div> <div> <div>Label Text</div> <div>Label [%]</div> </div> <div> <div>Font Size</div> <div>20</div> </div> <div> <div>Font Attributes</div> <div>B <i>I</i> <u>U</u></div> </div> <div> <div>Font Color</div> <div></div> </div> <div> <div>Horizontal Align</div> <div>Left ▼</div> </div> <div> <div>Vertical Align</div> <div>Top ▼</div> </div> <div> <div>Outside Parts</div> <div>Show ▼</div> </div> <div> <div>Text Wrap</div> <div>Yes ▼</div> </div> <div> <div>Show Scrollbar</div> <div>Hide ▼</div> </div> <div> <div>Left Margin</div> <div>0</div> </div> <div> <div>Right Margin</div> <div>0</div> </div> <div> <div>Top Margin</div> <div>0</div> </div> <div> <div>Bottom Margin</div> <div>0</div> </div> </div> <div> <div>Background/Border</div> <div> <div>Border Type</div> <div>Square ▼</div> </div> <div> <div>Background Color</div> <div></div> </div> <div> <div>Show Border</div> <div>No ▼</div> </div> </div> <div> <div>Conditional Format</div> <div> <div>Use Conditional Format</div> <div>No ▼</div> </div> </div> <div> <div>Display</div> <div> <div>Parts Display/Hide</div> <div>No ▼</div> </div> <div> <div>Width</div> <div>100</div> </div> <div> <div>Height</div> <div>50</div> </div> <div> <div>X Coordinate</div> <div>40</div> </div> <div> <div>Y Coordinate</div> <div>30</div> </div> </div> <div> <div>In order to save the changes, please click on the [Apply] button.</div> </div>	Text Format	Label Text	No more than 1000 characters (Comment 1, Comment 2, and Comment 3 can be input by clicking the icon of Label Text.)
		Font Size	1 to 1500
		Font Attributes	Bold, italic ^{*1} , underscore
		Font Color	This will be selected from the color palette.
		Horizontal Align	Left, Right, Center
		Vertical Align	Top, Bottom, Middle
		Outside Parts	Show, Hide
		Text Wrap	Yes, No
		Show Scrollbar	Show, Hide
		Left Margin	0 to 32
		Right Margin	0 to 32
		Top Margin	0 to 32
		Bottom Margin	0 to 32
	Background/Border	Border Type	Select Square/Rounded Corners
		Background Color	This will be selected from the color palette.
		Show Border	Yes, No
	Conditional Format	Use Conditional Format	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Range Number	0 to 16
		Setting Range Property	Page 50 Setting Range Property
	Display	Parts Display/Hide	Yes, No
		Device	Page 54 Device settings
		Device Number	
		Data Type	
		Comparison Value	
		Display Condition	=, !=, >, >=, <, <=
		Mode ^{*2}	Display when ON, Display when OFF
	X Coordinate		0 to 3840
	Y Coordinate		0 to 2160

*1 For Japanese (two-byte characters), italics are not applied.

*2 It can be edited when "Bit" is selected as the Data Type.

■Setting Range Property

Upper and lower limits can be set to change the text data to be displayed. Depending on the number of ranges set, the number of settings will vary.

Setting Range Property ✕

Low	High	Font Color	Background Color
<input type="text" value="-5000"/>	<input type="text" value="5000"/>	<input type="color" value="#00FF00"/>	<input type="color"/>

Properties	Settings
Low	☞ Page 56 Settings(Decimal)
High	
Font Color	This will be selected from the color palette.
Background Color	This will be selected from the color palette.
Bg-color Transparency	0% to 100%

Hyper Link

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
Type	Type	Page, URL
URL	URL	No more than 1000 characters* ¹
Page	Page	Select a page that is already created and the own page.* ²
Target	Target	Other window, Same window
<div>— Text Format</div>		
Label Text	Label Text	No more than 1000 characters (Comment 1, Comment 2, and Comment 3 can be input by clicking the icon of Label Text.)
Vertical Align	Vertical Align	Top, Bottom, Middle
Horizontal Align	Horizontal Align	Left, Right, Center
Outside Parts	Font Size	1 to 1500
Font Size	Font Attributes	Bold, italic* ³ , underscore
Font Attributes	Left Margin	0 to 32
Left Margin	Right Margin	0 to 32
Right Margin	Top Margin	0 to 32
Top Margin	Bottom Margin	0 to 32
Bottom Margin	Font Color	This will be selected from the color palette.
Font Color		
<div>— Background/Border</div>		
Border Type	Border Type	Select Square/Rounded Corners
Background Color	Background Color	This will be selected from the color palette.
Show Border	Show Border	Yes, No
Border Color		
<div>— Display</div>		
Parts Display/Hide	Parts Display/Hide	Yes, No
Width	Device	 Page 54 Device settings
Height	Device Number	
X Coordinate	Data Type	
Y Coordinate	Comparison Value	
Display Condition		=, !=, >, >=, <, <=
Mode* ⁴		Display when ON, Display when OFF
X Coordinate		0 to 3840
Y Coordinate		0 to 2160

In order to save the changes, please click on the [Apply] button.

^{*1} It can be edited when "URL" is selected for the type property.


^{*2} It can be edited when "Page" is selected for the type property.

^{*3} For Japanese (two-byte characters), italics are not applied.

^{*4} It can be edited when "Bit" is selected as the Data Type.


Image Tag

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
	Image	 Page 57 Image file
	Image Width	10 to 3840
	Image Height	10 to 2160
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

Line

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
	Stroke Color	This will be selected from the color palette.
	Stroke Width	1 to 100
	Line Type	Straight line, dotted line 1 to 6
	X1 Coordinate ^{*1*2}	0 to 3840
	Y1 Coordinate ^{*1*2}	0 to 2160
	X2 Coordinate ^{*2*3}	0 to 3840
	Y2 Coordinate ^{*2*3}	0 to 2160

*1 Coordinate of line start point

*2 The same coordinate cannot be set to (X1, Y1) and (X2, Y2).

*3 Coordinate of line end point

Ellipse

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div> Stroke Color <input type="color" value="#000000"/> Stroke Width <input type="text" value="1"/> Fill Color <input type="color" value="#FF0000"/> Ellipse Width <input type="text" value="100"/> Ellipse Height <input type="text" value="100"/> X Coordinate <input type="text" value="660"/> Y Coordinate <input type="text" value="650"/> <input type="button" value="Apply"/> In order to save the changes, please click on the [Apply] button. </div>	Stroke Color	This will be selected from the color palette.
	Stroke Width	1 to 1080 ^{*1}
	Fill Color	This will be selected from the color palette.
	Ellipse Width	10 to 3840
	Ellipse Height	10 to 2160
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

*1 Set the upper limit value to a value equal to or lower than half the smaller value of the width or height. If the value of the width or height exceeds the upper limit value when the part is resized, the input value is automatically calculated so that it does not exceed the upper limit value.

Rectangle

Below are setting items which will be displayed in its property window.

Property window	Properties	Settings
<div> Fill Color <input type="color" value="#00FFFF"/> Stroke Color <input type="color" value="#000000"/> Stroke Width <input type="text" value="2"/> Rectangle Width <input type="text" value="150"/> Rectangle Height <input type="text" value="150"/> X Coordinate <input type="text" value="85"/> Y Coordinate <input type="text" value="441"/> <input type="button" value="Apply"/> In order to save the changes, please click on the [Apply] button. </div>	Fill Color	This will be selected from the color palette.
	Stroke Color	
	Stroke Width	1 to 1080 ^{*1}
	Rectangle Width	10 to 3840
	Rectangle Height	10 to 2160
	X Coordinate	0 to 3840
	Y Coordinate	0 to 2160

*1 Set the upper limit value to a value equal to or lower than half the smaller value of the width or height. If the value of the width or height exceeds the upper limit value when the part is resized, the input value is automatically calculated so that it does not exceed the upper limit value.

Common items

This section shows items common to individual components.

Device settings

Consistency among a device, a data type, and a display format is required for device settings. Use the following combinations to perform device settings.

■RCPU

○: can be set, ×: cannot be set

Device *1		Data type *2				
		Word [signed/unsigned]	Double word [signed/unsigned]	Floating point real number	Double point real number	Bit
X	Input	×	×	×	×	○
Y	Output	×	×	×	×	○
M	Internal relay	×	×	×	×	○
L	Latch relay	×	×	×	×	○
B	Link relay	×	×	×	×	○
F	Annunciator	×	×	×	×	○
SB	Link special relay	×	×	×	×	○
V	Edge relay	×	×	×	×	○
T	Timer	○: K, H [unsigned]	×	×	×	×
ST	Retentive timer	○: K, H [unsigned]	×	×	×	×
LT	Long timer	×	○: K, H [unsigned]	×	×	×
LST	Long retentive timer	×	○: K, H [unsigned]	×	×	×
C	Counter	○: K, H [unsigned]	×	×	×	×
LC	Long counter	×	○: K, H [unsigned]	×	×	×
D	Data register	○: K, H	○: K, H	○: K	○: K	×
W	Link register	○: K, H	○: K, H	○: K	○: K	×
SW	Link special register	○: K, H	○: K, H	○: K	○: K	×
DX	Direct access input	×	×	×	×	○
DY	Direct access output	×	×	×	×	○
SM	Special relay	×	×	×	×	○
SD	Special register	○: K, H	○: K, H	○: K	○: K	×
J□\X	Link input	×	×	×	×	○
J□\Y	Link output	×	×	×	×	○
J□\B	Link relay	×	×	×	×	○
J□\SB	Link special relay	×	×	×	×	○
J□\W	Link register	○: K, H	○: K, H	○: H	○: H	×
J□\SW	Link special register	○: K, H	○: K, H	○: H	○: H	×
U□\G	Module access device	○: K, H	○: K, H	○: K	○: K	×
U3E□\G	CPU buffer memory	○: K, H	○: K, H	○: K	○: K	×
U3E□\HG		○: K, H	○: K, H	○: K	○: K	×
Z	Index register	○: K, H	○: K, H	○: K	○: K	×
LZ	Long index register	×	○: K, H	○: K	×	×
R	File register	○: K, H	○: K, H	○: K	○: K	×
ZR	File register	○: K, H	○: K, H	○: K	○: K	×
RD	Refresh data register	○: K, H	○: K, H	○: K	○: K	×
BL	SFC block device	×	×	×	×	○
BL□\S		×	×	×	×	○

*1 For a device number, refer to the user's manual of a CPU module used.

*2 K: Decimal, H: Hexadecimal

■FX5CPU

○: can be set, ×: cannot be set

Device*1			Data type*2			
			Word [signed/unsigned]	Double word [signed/unsigned]	Floating point real number	Bit
X	Input		×	×	×	○*3
Y	Output		×	×	×	○*3
M	Internal relay		×	×	×	○
L	Latch relay		×	×	×	○
B	Link relay		×	×	×	○
F	Annunciator		×	×	×	○
SB	Link special relay		×	×	×	○
S	Step relay		×	×	×	○
T	Timer	Contact: TS/Coil: TC	×	×	×	○
		Current value: TN	○: K, H [unsigned]	×	×	×
ST	Retentive timer	Contact: STS/Coil: STC	×	×	×	○
		Current value: STN	○: K, H [unsigned]	×	×	×
C	Counter	Contact: CS/Coil: CC	×	×	×	○
		Current value: CN	○: K, H [unsigned]	×	×	×
LC	Long counter	Contact: LCS/Coil: LCC	×	×	×	○
		Current value: LCN	×	○: K, H	×	×
D	Data register		○: K, H	○: K, H	○: K	×
W	Link register		○: K, H	○: K, H	○: K	×
SW	Link special register		○: K, H	○: K, H	○: K	×
SM	Special relay		×	×	×	○
SD	Special register		○: K, H	○: K, H	○: K	×
U□/G	Module access device		○: K, H	○: K, H	○: K	×
Z	Index register		○: K, H	○: K, H	○: K	×
LZ	Long index register		×	○: K, H	○: K	×
R	File register		○: K, H	○: K, H	○: K	×
BL	SFC block device		×	×	×	○
BL□/S			×	×	×	○

*1 For a device number, refer to the user's manual of a CPU module used.

*2 K: Decimal, H: Hexadecimal

*3 If X and Y are to be specified, specify them in octal numbers.

■Controller

○: can be set, ×: cannot be set

Device*1			Data type*2				
			Word [signed/unsigned]	Double word [signed/unsigned]	Floating point real number	Double point real number	Bit
X	Input		×	×	×	×	○
Y	Output		×	×	×	×	○
M	Internal relay		×	×	×	×	○
L	Latch relay		×	×	×	×	○
B	Link relay		×	×	×	×	○
F	Annunciator		×	×	×	×	○
SB	Link special relay		×	×	×	×	○
V	Edge relay		×	×	×	×	○
T	Timer	Contact: TS/Coil: TC	×	×	×	×	○
		Current value: TN	○: K, H [unsigned]	×	×	×	×

Device*1			Data type*2				
			Word [signed/unsigned]	Double word [signed/unsigned]	Floating point real number	Double point real number	Bit
ST	Retentive timer	Contact: STS/Coil: STC	×	×	×	×	○
		Current value: STN	○: K, H [unsigned]	×	×	×	×
LT	Long timer	Contact: LTS/Coil: LTC	×	×	×	×	○
		Current value: LTN	×	○: K, H [unsigned]	×	×	×
LC	Long retentive timer	Contact: LSTS/Coil: LSTC	×	×	×	×	○
		Current value: LSTN	×	○: K, H [unsigned]	×	×	×
C	Counter	Contact: CS/Coil: CC	×	×	×	×	○
		Current value: CN	○: K, H [unsigned]	×	×	×	×
LC	Long counter	Contact: LCS/Coil: LCC	×	×	×	×	○
		Current value: LCN	×	○: K, H [unsigned]	×	×	×
D	Data register		○: K, H	○: K, H	○: K	○: K	×
W	Link register		○: K, H	○: K, H	○: K	○: K	×
SW	Link special register		○: K, H	○: K, H	○: K	○: K	×
DX	Direct access input		×	×	×	×	○
DY	Direct access output		×	×	×	×	○
SM	Special relay		×	×	×	×	○
SD	Special register		○: K, H	○: K, H	○: K	○: K	×
Jn\X	Link input		×	×	×	×	○
Jn\Y	Link output		×	×	×	×	○
Jn\B	Link relay		×	×	×	×	○
Jn\SB	Link special relay		×	×	×	×	○
Jn\W	Link register		○: K, H	○: K, H	○: K	○: K	×
Jn\SW	Link special register		○: K, H	○: K, H	○: K	○: K	×
U□\G	Module access device		○: K, H	○: K, H	○: K	○: K	×
U3E□\G	CPU buffer memory access device		○: K, H	○: K, H	○: K	○: K	×
Z	Index register		○: K, H	○: K, H	○: K	○: K	×
LZ	Long index register		×	○: K, H	○: K	×	×
R/ZR	File register		○: K, H	○: K, H	○: K	○: K	×
RD	Refresh data register		○: K, H	○: K, H	○: K	○: K	×

*1 For the device number, refer to the following.

📖 MELSEC MX Controller MX-R Model User's Manual

*2 K: Decimal, H: Hexadecimal

Settings

If individual components' upper/lower limits, etc. are to be set, their ranges will vary depending on their data types.

Data type	Range
Word [signed]	-32768 to +32767
Word [unsigned]	0 to 65535
Double word [signed]	-2147483648 to +2147483647
Double word [unsigned]	0 to 4294967295
Floating point real number	-3.402823e+38 to +3.402823e+38
Double point real number (RCPU and controller only)	-1.79769313486231e+308 to +1.79769313486231e+308
Bit	0, 1

Coordinate

To define the design window's coordinate, its upper left corner is set as the origin, (0, 0), the X-axis is set along the horizontal direction from the origin, and the Y-axis is set along the vertical direction from the origin. Individual components' coordinates represent their upper left positions.

Image file

For an image file which this tool can use, its file name consists of no more than 27 half-width characters of alphanumeric characters, "-", "_", and "." including its extension (.jpg, .gif, .jpeg, and .png). Aim for 100 KB or less as the total size of image files in one screen. (This also includes a case where an image display component uses multiple image files.)

If an image file is specified, its copy will be stored in the img folder. (👉 Page 73 File configuration) If a file in the img folder is specified, its copy will not be created.


If an image is not specified, a default image will appear.

Ordered arrangement of components

The ordered arrangement of components is their allocated order in the design window. Only generic and arbitrary value write button components can optionally change their ordered arrangements to the forefront/backmost. (👉 Page 58 Context menu)

Window folding

A component window can be folded to make more space for the design window.



Click the symbol on the right side of ❶ to fold a component window in question. If a component window is folded, click such a symbol to unfold it. Click the symbol on the right side of ❷ to fold a corresponding PLC/generic component's list.

2.6 Design Window

The design window can create/edit an HTML file which will allocate components and show them in a Web browser. This section describes how to operate the design window. The highest resolution of the design window (an HTML section) is 4K (3840 × 2160 pixels).

Select HTML file



This is used to display in the design window, an HTML file whose file name is selected.

Delete HTML file



This is used to delete an HTML file that is created in a project. However, index.html cannot be deleted.

Create new HTML file



This is used to set an HTML file's name and newly create it in a project in question. ( Page 25 Create Page)

Context menu

If a component allocated in the design screen is selected and right-clicked, a context menu will appear. The following operations can be performed from the context menu.

Context menu		Description
Align	Left	This is enabled when two or more components are selected. All the selected components are aligned to the left.
	Right	This is enabled when two or more components are selected. All the selected components are aligned to the right.
	Top	This is enabled when two or more components are selected. All the selected components are aligned to the top.
	Bottom	This is enabled when two or more components are selected. All the selected components are aligned to the bottom.
	Horizontal Center	This is enabled when two or more components are selected. All the selected components are aligned to the horizontal center.
	Vertical Middle	This is enabled when two or more components are selected. All the selected components are aligned to the vertical middle.
	Distribute Horizontally	This is enabled when three or more components are selected. The components at the left and right ends of all the selected components are fixed, and the components in between are equally spaced.
	Distribute Vertically	This is enabled when three or more components are selected. The components at the top and bottom of all the selected components are fixed, and the components in between are equally spaced.
Cut		This is used to cut a selected component.
Copy		This is used to copy a selected component.
Paste		This is used to paste a cut or copied component. "Paste" can be executed only within a project of the same series. (Example: A component copied in a project of the FX5 CPU series cannot be pasted in a project of the RCP series.)
Delete		This is used to delete a selected component.
Bring to Front		This is used to bring the selected component to the front. (The component will be brought to the front among all components which are allocated to and displayed in the design window.)
Send to Back		This is used to send the selected component to the back. (The component will be sent to the back among all components which are allocated to and displayed in the design window.)
Bring to Forward		This is used to bring the selected component one layer forward.
Send Backward		This is used to send the selected component one layer backward.

■Select multiple components

Multiple components can be selected in the design window. When multiple components are selected, only "Cut", "Copy", "Paste", and "Delete" context menu options are valid.

2.7 Property Window

If a component is allocated to the design window, its property and HTML file page settings can be conducted. If a component is selected in the design window, its component properties will be displayed, and if a component is not selected, its page properties will be displayed.

Component properties


If a component is selected in the design window, its component properties will be displayed. This section describes how to operate the design window. For individual components' properties which can be set, refer to  Page 33 Component Window.

Delete component



This is used to delete a selected component. This is an operation common to all components.

"Apply" button



This can be clicked when a setting value is changed in the component property. When the component property is switched, the input values are retained only with the [Apply] button clicked.

This is an operation common to all components.

Page properties

If an HTML file is displayed in the design screen, its page properties will be displayed. Those page properties which can be set are shown below.

Page name

To change a page name, click the [Edit] button. ( Page 25 Create Page)

Note, however, that the page names of index.html and Log-in_User.html cannot be changed.

Background color

The background color of an HTML file can be set from the color palette.

If such a background color is set as "Reflect in all pages", it will be reflected in all HTML files in a project in question.

Display update interval

This is used to set the display update interval of a PLC component allocated to an HTML file which is displayed in the design window. The setting range is as follows.

Project	User Web Page Design Tool	Setting range
RCPU	Version "1.00A"	5 to 120 (second)
	Version "1.01B" or later	1 to 120 (second)
FX5CPU	Version "1.00A"	5 to 120 (second)
	Version "1.01B" or later	1 to 120 (second)
MX Controller	Version "1.03D" or later	0.05 to 120 (second)

If such a display update interval is set as "Reflect in all pages", the display update interval will be reflected in all HTML files in a project in question.

Page display language

This is used to set the display language of input button and arbitrary value write button components allocated to an HTML file which is displayed in the design window (English, Japanese, and Chinese (simplified characters)). The default display language is one set in index.html.

If such a display language is set as "Reflect in all pages", the display language will be reflected in all HTML files in a project in question.

Common items

This section shows setting items common to all property windows.

Window folding



This is used to fold a property window to make more space for the design window. If a property window is folded, this is used to unfold the window.

3 TUTORIAL

This section describes the procedures, operations, and practical examples before using the user Web page.

3.1 Before Tutorial

To use this tutorial, it is necessary to obtain this tool and become familiar with its operations. Check a system configuration to read/write a project through FTP communication with an SD memory card attached to a CPU module.

3

How to obtain and start the tool

This section describes how to obtain and start this tool and associated functions.


■How to Obtain

Please consult your local Mitsubishi representative.

■Installing and Uninstalling

- To install, execute setup.exe and install the tool according to the message of the installer. To use this tool, turn off SmartScreen in the Microsoft® Edge settings as follows.

1. Select [Settings and more] ⇒ [Settings] ⇒ [Privacy, search, and services].
2. Turn off "Microsoft Defender SmartScreen" in "Security".



- To uninstall, execute uninstall.exe and uninstall the tool according to the message.

■Start and End


To start it: [Start Menu] ⇒ [UserWebPageDesignTool] ⇒ [UserWebPageDesignTool]

To end it: [Project] ⇒ [Exit] (➤ Page 24 Exit)

FTP communication

If this tool (installed on a personal computer) is connected to a CPU module through Ethernet, a project can be read/written through FTP communication.

For more information about how to operate FTP communication, refer to  Page 27 Communication.



Use a straight cable with either of the following specifications.

If a personal computer is to be directly connected to a CPU module with an Ethernet cable, a cross cable whose specification is category 5e or less can be used.

[When 100BASE-TX connection is available]

Cable products compliant with the Ethernet standard whose specification is category 5 or better (STP cables)

[When 10BASE-T connection is available]

Cable products compliant with the Ethernet standard whose specification is category 3 or better (STP cables)

3.2 Practical Examples

The practical examples of user Web pages are shown below.

Top page (index.html)	Continuous Filling Machines
Parking Lot monitoring system	Chemical production line

This section describes procedures to create a project with continuous filling machines as an example.

The "Continuous filling machines" example is about a user Web page to monitor the states and measurements of individual devices.

Creating a user Web page

This section describes procedures to create the HTML files of the continuous filling machines.

Creating a project

For a project, refer to [Page 73 Project Management](#).

1. Newly Creating Project

After having installed this tool, start this tool, and perform the following operation to create a new project.

[Project] ⇒ [Create Project] ([Page 24 Create Project](#))

2. Creating HTML File

Perform the following operation to create an HTML file. For this example, its page name is "001".


[Edit] ⇒ [Create Page] ([Page 25 Create Page](#))

Editing HTML file

By allocating individual components, the continuous filling machines' user Web page will be created. The continuous filling machines consist of the following items.

- [Tank] This monitors water storage (R3) in the equipment's tank
- [Liquid tank 1] This monitors the water level (R1) and analog output (D102) of the equipment's liquid tank.
- [Liquid tank 2] This monitors the water level (R2), analog input (D101), and temperature (D100) of the equipment's liquid tank.
- [Batch display section] This monitors the analog input/output (D101 and D102) and the temperatures (D100 and R100).


Tank

Design window	Used components
	<p>Allocate the following components from the component window.</p> <ul style="list-style-type: none">❶ Image tag components In this example, the image files of "Tank" and "Liquid tank 1" are the same.❷ Level display and rectangle components This shows the water storage (R3) using a level indication.

❷ The following items are set for the level display component. (Property window)

Properties		Settings	Properties		Settings
Direction		Vertical	Current Value	Display	Not Display
Device		R		Color	Set this optionally.
Device Number		3		Background Color	
Data Type		word [signed]		Width	10
Level Color		Set this optionally.		Height	10
Upper Color			Level Length		160
Lower Color			Level Width		30
Background Color			X Coordinate		Set this optionally.
Upper Value		5000	Y Coordinate		
Lower Value		-10	—		
Alarm Value	Display Line	Display			
	Line Color	Set this optionally.			
	Upper Value	4999			
	Lower Value	-1			

■Liquid Tank 1

Design window	Used components
	<p>Allocate the following components from the component window.</p> <p>❶ Image tag components In this example, the image files of "Tank" and "Liquid tank 1" are the same.</p> <p>❷ Image tag components Allocate an image file specific to "Liquid tank 1".</p> <p>❸ Line components</p> <p>❹ Label components</p> <p>❺ Level display and rectangle components This shows a water level (R1) in the liquid tank using a level indication. The rectangular component has to be located so that it will overlap with the level display component.</p> <p>❻ Data block components This shows the analog output (D102).</p> <p>❼ Image display components This indicates whether the analog output is monitored.</p> <p>❽ Hyper link components</p>

❺ The following items are set for the level display component. (Property window)

Properties	Settings	Properties	Settings
Direction	Vertical	Current Value	Display
Device	R		Color
Device Number	1		Background Color
Data Type	word [signed]		Width
Level Color	Set this optionally.		Height
Upper Color		Level Length	160
Lower Color		Level Width	30
Background Color		X Coordinate	Set this optionally.
Upper Value	5000	Y Coordinate	—
Lower Value	-10		
Alarm Value	Display Line		
	Line Color		
	Upper Value		
	Lower Value		

❻ The following items are set for the data block component. (Property window)

Properties	Settings	Properties	Settings
Direction	Horizontal	Device Value	Font Color
Block Size	1		Background Color
Device	Display Label		Cell Width
Property	Device		Cell Height
	Data Type	X Coordinate	Set this optionally.
	Display Format	Y Coordinate	—
Line Color	Set this optionally.		
Device Name	Display		
	Font Color		
	Background Color		
	Cell Width		
	Cell Height		


7 The following items are set for the image display component. (Property window)

Properties	Settings	Properties	Settings
Default Image	An image file that will be displayed when OFF.	Setting Range Property	Low 1
Device	M		High 1
Device Number	202		Image File An image file that will be displayed when ON.
Data Type	Bit	Image Height	25
Range Number	1	Image Width	100
—		X Coordinate	Set this optionally.
		Y Coordinate	

8 The following items are set for the hyper link component. (Property window)

Properties	Settings	Properties	Settings
Type	URL	Text	Inverter Manual
URL	An arbitrary address	Font Size	20
Page	—	X Coordinate	Set this optionally.
Target	Same Window	Y Coordinate	

■Liquid Tank 2

Design window	Used components
	<p>Allocate the following components from the component window.</p> <ul style="list-style-type: none"> 1 Image tag components 2 Line components 3 Level display and rectangle components <p>This shows a water level (R2) in the liquid tank using a level indication. The rectangular component has to be located so that it will overlap with the level display component.</p> <ul style="list-style-type: none"> 4 Data block component <p>This displays the analog input value (D101).</p> <ul style="list-style-type: none"> 5 Data block components <p>This shows the measured temperature of temperature (D100).</p> <ul style="list-style-type: none"> 6 Image display components <p>This indicates whether the analog input value is monitored.</p>

3 The following items are set for the level display component. (Property window)

Properties		Settings	Properties		Settings
Direction		Vertical	Current Value	Display	Not Display
Device		R		Color	Set this optionally.
Device Number		2		Background Color	
Data Type		word [signed]		Width	10
Level Color		Set this optionally.		Height	10
Upper Color			Level Length		160
Lower Color			Level Width		30
Background Color			X Coordinate		Set this optionally.
Upper Value		5000		Y Coordinate	
Lower Value		-10	—		
Alarm Value	Display Line	Display			
	Line Color	Set this optionally.			
	Upper Value	4999			
	Lower Value	-1			

④ The following items are set for the data block component. (Property window)

Properties		Settings	Properties		Settings
Direction		Horizontal	Device Value	Font Color	Set this optionally.
Block Size		1		Background Color	
Device Property	Display Label	Analog input (AD)		Cell Width	190
	Device	D101		Cell Height	50
	Data Type	word [signed]	X Coordinate		Set this optionally.
	Display Format	Decimal	Y Coordinate		
Line Color		Set this optionally.	—		
Device Name	Display	Display			
	Font Color	Set this optionally.			
	Background Color				
	Cell Width	—			
	Cell Height	40			


⑤ The following items are set for the data block component. (Property window)

Properties		Settings	Properties		Settings
Direction		Horizontal	Device Value	Font Color	Set this optionally.
Block Size		1		Background Color	
Device Property	Display Label	Thermocouple (TC)		Cell Width	190
	Device	D100		Cell Height	50
	Data Type	word [signed]	X Coordinate		Set this optionally.
	Display Format	Decimal	Y Coordinate		
Line Color		Set this optionally.	—		
Device Name	Display	Display			
	Font Color	Set this optionally.			
	Background Color				
	Cell Width	—			
	Cell Height	40			

⑥ The following items are set for the image display component. (Property window)

Properties	Settings	Properties		Settings
Default Image	An image file that will be displayed when OFF.	Setting Range Property	Low	1
Device	M		High	1
Device Number	201		Image File	An image file that will be displayed when ON.
Data Type	Bit	Image Height		25
Range Number	1	Image Width		100
—		X Coordinate		Set this optionally.
		Y Coordinate		

■Batch Display Section

Design window	Used components
	<p>Allocate the following components from the component window.</p> <ul style="list-style-type: none"> ❶ Label components ❷ Data block components <p>This shows the analog input/output values (D101 and D102) and the temperatures (D100 and R100).</p> <ul style="list-style-type: none"> ❸ Historic graph components <p>This shows the temperature (R100) in a time series line graph.</p> <ul style="list-style-type: none"> ❹ Image display components <p>This shows whether the temperatures are monitored.</p> <ul style="list-style-type: none"> ❺ Rectangle, label, and line components

❷ The following items are set for the data block component. (Property window)

Properties	Settings	Properties	Settings
Direction	Vertical	Device Value	Font Color
Block Size	4		Background Color
Device Property	*1		Cell Width
Line Color	Set this optionally.		Cell Height
Device Name	Display	X Coordinate	Set this optionally.
	Font Color	Y Coordinate	
	Background Color	—	
	Cell Width		
	Cell Height		

*1 The following items are set for individual lines. (Display label, device, data type, and display format)

First line: TC, D100, word [signed], and decimal number

Second line: AD, D101, word [signed], and decimal number

Third line: DA, D102, word [signed], and decimal number

Fourth line: PT, R100, word [signed], and decimal number

❸ The following items are set for the historic graph component. (Property window)


Properties	Settings	Properties	Settings
Graph Element Number	1	Graph Background Color	Set this optionally.
Graph Element Property	Device Name	Character Color	Set this optionally.
	Device Number	Right Margin	10
	Line Color	Left Margin	40
Data Type	word [signed]	Upper Margin	15
Upper Limit Value	110	Lower Margin	75
Lower Limit Value	-10	Graph Height	215
Number Of Records	20	Graph Width	462
Vertical Axis Interval	5	X Coordinate	Set this optionally.
Number Of Horizontal Axes	11	Y Coordinate	

❹ The following items are set for the image display component. (Property window)

Properties	Settings	Properties	Settings
Default Image	An image file that will be displayed when OFF.	Setting Range Property	Low
Device	M		High
Device Number	200		Image File
Data Type	Bit		An image file that will be displayed when ON.
Range Number	1	Image Height	25
—		Image Width	100
		X Coordinate	Set this optionally.
		Y Coordinate	

■Start Button and Hyper Link

A button to start monitoring and a hyper link to the top page will be allocated.

Design window	Used components
	<p>Allocate the following components from the component window.</p> <p>❶ Input button components A button (Y0) to start monitoring will be allocated.</p> <p>❷ Hyper link components A hyper link to return to the top page will be allocated.</p>

❶ The following items are set for the input button component. (Property window)

Properties	Settings	Properties	Settings
Device	Y	Write Confirm	Not Display
Device Number	0	Button Width	150
Data Type	Bit	Button Height	50
Display Format	Binary	X Coordinate	Set this optionally.
Write Value	1	Y Coordinate	
Button Text	Start		

❷ The following items are set for the hyper link component. (Property window)

Properties	Settings	Properties	Settings
Type	Page	Text	Back
URL	—	Font Size	26
Page	index.html	X Coordinate	Set this optionally.
Target	Same Window	Y Coordinate	

Writing the Project

If a project is created, save it to an SD memory card attached to a CPU module.

When writing the project to the SD memory card, make sure that there are the css and img folders in the SD memory card. (☞ Page 73 File configuration) In addition, when the project is written to the SD memory card, all files under the USER folder in the SD memory card will be deleted. Save files in the SD memory card, as appropriate.

1. Communication Settings

[Communication] ⇒ [Communication Settings]

Set an IP address, a user name, and a password from "Communication Settings". Make sure that these settings are the same as those settings which are written to the CPU module by GX Works3. (☞ Page 30 Communication Settings)

2. Uploading to SD Memory Card

[Communication] ⇒ [Write files to PLC (SD Memory Card)]

Use "Write files to PLC (SD Memory Card)" to write the project, which is currently opened and already saved, to the SD memory card. (☞ Page 28 Write files to PLC (SD Memory Card))



When an SD memory card is used on the FX5S CPU module, an SD memory card module is required.

Access to user Web page

If a project is written to an SD memory card attached to a CPU module, the user Web page can be accessed from the web browser. Refer to the following documents for more information about respective settings.

📖 MELSEC iQ-R Ethernet User's Manual (Application)

📖 MELSEC iQ-F FX5 User's Manual (Communication)

📖 MELSEC MX Controller MX-R Model User's Manual

📖 MELSEC iQ-R/MELSEC iQ-F Web Server Function Guide Book

1. Setting CPU Module Parameters

Use GX Works3 to set the CPU module's "IP Address" and "Web Server Settings". For "Authority for Window Display" in "Web Server Settings," select either "Permit Both Displays" or "User Web Page Only" to write the selection to the CPU module.

If the input button and arbitrary value write button components are used, set "Write Device" in "Web Server Account Settings" to "Enable".

2. Access to Login Page

Enter the following URL to a Web browser's address bar to access the user Web page.

http://[the IP address of the Web server (the CPU module)]/

For example, if the IP address of the CPU module is 192.168.3.39: http://192.168.3.39/

If the own station's port number is changed from its default value (80), enter the following.

http://[the IP address of the Web server (the CPU module)]:[the own station's port number]/

For example, if the IP address of the CPU module is 192.168.3.39: http://192.168.3.39:8080/

3. Login Operations

On a login screen, enter the "Use Name" and "Password" set by "Web Server Settings" to log in to the user Web page.

4. Access to User Web Page

Access destinations after login may vary, depending on what is set for "Initial Display Window".

[When "System Web Page" is selected]

A system Web page will be accessed after login. If "User Web Page" is selected from its menu, the user Web page will be accessed.

[When "User Web Page" is selected]

The user Web page will be accessed after login.

4 NOTES

Notes are as shown below.

User operation

Only one keyboard shortcut or menu command can be used at a time.

External editing

- If an HTML file is created externally, it cannot be processed by this tool.
- If an HTML file was created by this tool but is directly edited externally, it may not be processed by this tool.

Project file configuration

Do not remove MENUWDT.WSV from the USER folder. If removed, this tool cannot read the project.

Overlapping setting ranges

For a generic component or an image display component, if its setting ranges overlap each other, one with a smaller setting range number will be displayed. For example, if a device value is in both setting range 1 and setting range 2, it will be displayed in setting range 1.

Image file

Only one file with the same file name and extension can be used in a project. If there is a file in the img folder with the same file name and extension as those of a used image (specified by an image component), the file in the img folder will be overwritten with one specified later.

Preview

- If there are problems in the property settings of PLC and generic components allocated to an HTML file displayed in the design window, their previews cannot be displayed. For a problematic component, an error message will be displayed and therefore deal with the problematic component. (Even if there are multiple problematic components, an error message for only one of the problematic components will be displayed.)
- As executing a preview, the system outputs files under the install folder. If the memory of the file output destination is insufficient, the output fails and the preview cannot be displayed.

Access to Web server

Communication in the Web server's functions doesn't support encrypted communication (SSL communication). Do not access the Web server via the Internet. When accessing the Web server, access it within its LAN. When it is accessed via the Internet, the communication may be intercepted.

Access to HTML file

After having logged in the Web server, do not access an individual user Web page by directly specifying its URL. If such a URL is specified, the screen will not be displayed correctly, and information cannot be collected from the Web server.

Device value of historic graph

If a heavy communication load state continues for a historic graph component, it may miss its device values.

Troubleshooting

For FTP communication failure or the troubleshooting for the Web server function, refer to the following document for troubleshooting.

 MELSEC iQ-R Ethernet User's Manual (Application)

 MELSEC iQ-F FX5 User's Manual (Communication)

 MELSEC MX Controller MX-R Model User's Manual

 MELSEC iQ-R/MELSEC iQ-F Web Server Function Guide Book

APPENDIX

Appendix 1 Project Management

This section describes how to conduct the basic operations and management of a project.


Project file

This tool treats an HTML file for user Web pages (up to 160 pages) for one CPU module as a project. A generated project is stored in a file and managed on a project basis.

File configuration

This section shows the file configuration of a project created by this tool.

Do not change the configurations of folders and files other than those encircled by the dotted lines. If file names and folder configuration are different from what are shown here, the project cannot be written to a CPU module.



A

*1 Its file name varies, depending on a project's series.

RCPU: RUserWebLib.js

FX5CPU: FUserWebLib.js

MX Controller: MXUserWebLib.js

*2 □: 0 to 3

*3 If an HTML file is created and edited by one other than this tool and is read, it will not be displayed correctly.

■ Configuration file list

Configuration files are extracted to the work area of the installation destination in accordance with the series selection, this tool, or display language setting of the target project.

File name	Description
MENUWDT.WSV	This is the configuration file of a project in question. If this file is stored in the WWW/USER folder, this tool will recognize it as a project.
index.html	This is an HTML file which will be displayed initially when a user Web page is logged in.* ¹
Log-in_User.html	This is an HTML file that will be displayed when the user Web page is logged out.* ¹
FUserWebLib.js	This is a JavaScript library file for the user Web page. This will be allocated only for an FX5CPU project.
RUserWebLib.js	This is a JavaScript library file for the user Web page. This will be allocated only for an RCPN project.
MXUserWebLib.js	This is a JavaScript library file for the user Web page. This will be allocated only for an MX Controller project.
sample□.png* ²	This is a default image file for image display and image components.
UserWebStyle.css	This is a style sheet for the User Web page.
DevCtrl.js	This is a JavaScript library file for an arbitrary value write button component. If no arbitrary value write button component is used, this will not be shown.

*¹ It is possible to edit an HTML file.

*² □: 0 to 3

INDEX

A

Arbitrary value Write Button 45

C

Character Display (ASCII) 43
Component properties 59
Component Window 33

D

Data Block 34
Design Window. 58

E

Ellipse 53

F

FTP communication 62

G

Generic components 48
Graphic Display 37

H

Historic Graph 41
Hyper Link 51

I

Image Display. 39
Image Tag 52
Input Button 42

L

Label 49
Level Display 36
Line. 52
Logout Button. 47

M

Menu Bar. 24

O

Operating Environment 5

P

Page properties 59
PLC components 33
Property Window 59

R

Rectangle 53

S

Software License 7

MEMO

REVISIONS

Revision date	Revision	Description
October 2020	A	First Edition
October 2021	B	■Added or modified part Section 1.2
May 2022	C	■Added or modified parts Chapter 1, 2, 3, 4, Appendix 1
June 2023	D	■Added or modified parts RELEVANT MANUALS, Section 2.3, 2.5, 3.1, 3.2, Chapter 4, TRADEMARKS
April 2025	E	■Added or modified parts Section 2.1, 2.2, 2.3, 2.4, 2.5, 2.6
October 2025	F	■Added or modified parts RELEVANT MANUALS, TERMS, Section 1.2, 2.3, 2.5, 2.7, 3.2, Chapter 4, Appendix 1

Japanese manual number: SH-082314-F

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2020 MITSUBISHI ELECTRIC CORPORATION

INFORMATION AND SERVICES

For further information and services, please contact your local Mitsubishi Electric sales office or representative.
Visit our website to find our locations worldwide.

MITSUBISHI ELECTRIC Factory Automation Global Website
Locations Worldwide
www.MitsubishiElectric.com/fa/about-us/overseas/

TRADEMARKS

Microsoft, Windows, Microsoft Edge, and Internet Explorer are trademarks of the Microsoft group of companies.

Android and Google Chrome are either registered trademarks or trademarks of Google LLC.

Safari is a trademark of Apple Inc., registered in the U.S. and other countries.

IOS (iOS) is either a registered trademark or trademark of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries, and iOS is used under license by Apple Inc.

Intel is either registered trademarks or trademarks of Intel Corporation in the United States and/or other countries.

Oracle and Java are registered trademarks of Oracle and/or its affiliates.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as TM or ® are not specified in this manual.

Manual number: SH(NA)-082315ENG-F

mitsubishi electric corporation

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.