



Mitsubishi Electric Industrial Robot

CR800 series controller

Force Sense Function Instruction Manual

4F-FS002H-W200

4F-FS002H-W1000

4F-FS005H-IFUS

Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

 **CAUTION** All teaching work must be carried out by an operator who has received special training.
(This also applies to maintenance work with the power source turned ON.)
→Enforcement of safety training

 **CAUTION** For teaching work, prepare a work plan related to the methods and procedures of operating the robot, and to the measures to be taken when an error occurs or when restarting. Carry out work following this plan.
(This also applies to maintenance work with the power source turned ON.)
→Preparation of work plan

 **WARNING** Prepare a device that allows operation to be stopped immediately during teaching work.
(This also applies to maintenance work with the power source turned ON.)
→Setting of emergency stop switch

 **CAUTION** During teaching work, place a sign indicating that teaching work is in progress on the start switch, etc.
(This also applies to maintenance work with the power source turned ON.)
→Indication of teaching work in progress

 **DANGER** Provide a fence or enclosure during operation to prevent contact of the operator and robot.
→Installation of safety fence

 **CAUTION** Establish a set signaling method to the related operators for starting work, and follow this method.
→Signaling of operation start

 **CAUTION** As a principle turn the power OFF during maintenance work. Place a sign indicating that maintenance work is in progress on the start switch, etc.
→Indication of maintenance work in progress

 **CAUTION** Before starting work, inspect the robot, emergency stop switch and other related devices, etc., and confirm that there are no errors.
→Inspection before starting work

The points of the precautions given in the separate "Safety Manual" are given below.
Refer to the actual "Safety Manual" for details.

 **DANGER** When automatic operation of the robot is performed using multiple control devices (GOT, programmable controller, push-button switch), the interlocking of operation rights of the devices, etc. must be designed by the customer.

 **CAUTION** Use the robot within the environment given in the specifications. Failure to do so could lead to faults or a drop of reliability.
(Temperature, humidity, atmosphere, noise environment, etc.)

 **CAUTION** Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.

 **CAUTION** Always use the robot installed on a secure table. Use in an instable posture could lead to positional deviation and vibration.

 **CAUTION** Wire the cable as far away from noise sources as possible. If placed near a noise source, positional deviation or malfunction could occur.

 **CAUTION** Do not apply excessive force on the connector or excessively bend the cable. Failure to observe this could lead to contact defects or wire breakage.

 **CAUTION** Make sure that the workpiece weight, including the hand, does not exceed the rated load or tolerable torque.
Exceeding these values could lead to errors or faults.

 **WARNING** Securely install the hand and tool, and securely grasp the workpiece. Failure to observe this could lead to personal injuries or damage if the object comes off or flies off during operation.

 **WARNING** Securely ground the robot and controller. Failure to observe this could lead to malfunctioning by noise or to electric shock accidents.

 **CAUTION** Indicate the operation state during robot operation. Failure to indicate the state could lead to operators approaching the robot or to incorrect operation.

 **WARNING** When carrying out teaching work in the robot's movement range, always secure the priority right for the robot control. Failure to observe this could lead to personal injuries or damage if the robot is started with external commands.

 **CAUTION** Keep the jog speed as low as possible, and always watch the robot. Failure to do so could lead to interference with the workpiece or peripheral devices.

**CAUTION**

After editing the program, always confirm the operation with step operation before starting automatic operation. Failure to do so could lead to interference with peripheral devices because of programming mistakes, etc.

**CAUTION**

Make sure that if the safety fence entrance door is opened during automatic operation, the door is locked or that the robot will automatically stop. Failure to do so could lead to personal injuries.

**CAUTION**

Never carry out modifications based on personal judgments, non-designated maintenance parts. Failure to observe this could lead to faults or failures.

**WARNING**

When the robot arm has to be moved by hand from an external area, do not place hands or fingers in the openings. Failure to observe this could lead to hands or fingers catching depending on the posture.

**CAUTION**

Do not stop the robot or apply emergency stop by turning the robot controller's main power OFF. If the robot controller main power is turned OFF during automatic operation, the robot accuracy could be adversely affected. Also a dropped or coasted robot arm could collide with peripheral devices.

**CAUTION**

Do not turn OFF the robot controller's main power while rewriting the robot controller's internal information, such as a program and parameter. Turning OFF the robot controller's main power during automatic operation or program/parameter writing could break the internal information of the robot controller.

**DANGER**

Do not connect the Handy GOT when using the GOT direct connection function of this product. Failure to observe this may result in property damage or bodily injury because the Handy GOT can automatically operate the robot regardless of whether the operation rights are enabled or not.

**DANGER**

Do not connect the Handy GOT to a programmable controller when using an iQ Platform compatible product with the CR800-R/Q series. Failure to observe this may result in property damage or bodily injury because the Handy GOT can automatically operate the robot regardless of whether the operation rights are enabled or not.

**DANGER**

Do not remove the SSCNET III cable while power is supplied to the multiple CPU system or the servo amplifier when using an iQ Platform compatible product with the CR800-R/Q series.

Do not look directly at light emitted from the tip of SSCNET III connectors or SSCNET III cables of the Motion CPU or the servo amplifier.

Eye discomfort may be felt if exposed to the light.

(Reference: SSCNET III employs a Class 1 or equivalent light source as specified in JIS C 6802 and IEC 60825-1 (domestic standards in Japan).)

**DANGER**

Do not remove the SSCNET III cable while power is supplied to the controller.

Do not look directly at light emitted from the tip of SSCNET III connectors or SSCNET III cables. Eye discomfort may be felt if exposed to the light.

(Reference: SSCNET III employs a Class 1 or equivalent light source as specified in JIS C 6802 and IEC60825-1 (domestic standards in Japan).)

DANGER

Attach the cap to the SSCNET III connector after disconnecting the SSCNET III cable. If the cap is not attached, dirt or dust may adhere to the connector pins, resulting in deterioration connector properties, and leading to malfunction.

CAUTION

Make sure there are no mistakes in the wiring. Connecting differently to the way specified in the manual can result in errors, such as the emergency stop not being released. In order to prevent errors occurring, please be sure to check that all functions (such as the teaching box emergency stop, customer emergency stop, and door switch) are working properly after the wiring setup is completed.

CAUTION

Use the network equipments (personal computer, USB hub, LAN hub, etc) confirmed by manufacturer. The thing unsuitable for the FA environment (related with conformity, temperature or noise) exists in the equipments connected to USB. When using network equipment, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm the operation by customer. Guarantee and maintenance of the equipment on the market (usual office automation equipment) cannot be performed.

CAUTION

To maintain the safety of the robot system against unauthorized access from external devices via the network, take appropriate measures. To maintain the safety against unauthorized access via the Internet, take measures such as installing a firewall.

■ Revision History

Print Date	Instruction Manual No.	Revision content
2017-05-31	BFP-A3510	• First print
2018-02-01	BFP-A3510-A	• The CR800-Q controller was added.
2018-11-30	BFP-A3510-B	• A spare fuse was added to the product configuration.
2019-04-25	BFP-A3510-C	• Extended functions of the force sensor was added.
2022-11-30	BFP-A3510-D	• Revised "5.4 Securing the force sensor cable". • Corrected other mistakes and changed some sections.
2023-09-14	BFP-A3510-E	• Added the CR860 controller. • Changed some sections.
2024-09-24	BFP-A3510-F	• Added the force sensor set "4F-FS005H-IFUS". • Added support for R86TB. • Corrected other mistakes and changed some sections.
2025-07-02	BFP-A3510-G	• Revised "6.6 Default Parameter Settings" and "6.6.2 Calibration". • Changed some sections.
2026-01-30	BFP-A3510-H	• Added support for MR-J5-B. • Software version E4 supported. • Changed some sections.

■ Introduction

Thank you for purchasing a Mitsubishi Electric industrial robot. The "force sense function" uses force sensor information with 6 degrees of freedom to provide the robot with a sense of its own force. Using dedicated commands and status variables compatible with the robot program language (MELFA-BASIC V) facilitates work requiring minute power adjustments and power detection that was not possible on past robots. Always read over this manual to gain a sufficient understanding of its content before using the "force sense function".

Parameter adjustment which requires a high level of specialist knowledge is automated by using a MELFA Smart Plus function enhancement card. The learning function and the force sense wizard function optimize fitting, phase match insertion, and contact detection.

Please note that this instruction manual assumes that operators have an understanding of basic Mitsubishi Electric industrial robot operation and functionality. Refer to the separate "Instruction Manual, Detailed Explanations of Functions and Operations" for information on basic operation.

This manual describes the system configuration and product specifications of the force sense function. For details of basic operations, refer to the separate "Instruction Manual / Detailed Explanations of Functions and Operations".

The following are the series described in this instruction manual.

Name	Description
CR800 series	Indicates the CR800 and CR860 controllers.
CR800-Q series	Indicates the CR800-Q and CR860-Q controllers.
CR800-R series	Indicates the CR800-R and CR860-R controllers.

The following are the general-purpose servo amplifier models described in this instruction manual.

Model	Description
MR-J4-B	The MR-J4-□B or MR-J4W□-□B of the MELSERVO-J4 series general-purpose servo amplifiers connected as an additional axis to the CR800 series.
MR-J5-B	The MR-J5-□B or MR-J5W□-□B of the MELSERVO-J5 series general-purpose servo amplifiers connected as an additional axis to the CR800 series.

■ Notation used in this manual



Danger

Incorrect handling may result in imminent danger, leading to death or serious injury.



Warning

Incorrect handling may lead to death or serious injury.



Caution

Incorrect handling may result in property damage, or danger leading to impairment of the user.

Notice

- *ONLY QUALIFIED SERVICE PERSONNEL MAY INSTALL OR SERVICE THE ROBOT SYSTEM.
- *ANY PERSON WHO PROGRAM, TEACHES, OPERATE, MAINTENANCE OR REPAIRS THE ROBOT SYSTEM IS TRAINED AND DEMONSTRATES COMPETENCE TO SAFELY PERFORM THE ASSIGNED TASK.
- *ENSURE COMPLIANCE WITH ALL LOCAL AND NATIONAL SAFETY AND ELECTRICAL CODES FOR THE INSTALLATION AND OPERATION OF THE ROBOT SYSTEM.

[CONTENTS]

1 Using This Manual.....	1-1
1.1 Using This Manual	1-1
1.2 Terminology Used in This Instruction Manual	1-2
2 Work Flow	2-3
2.1 Flowchart.....	2-3
3 Force Sense Function System Specifications	3-4
3.1 What is the Force Sense Function?.....	3-4
3.2 Force Sense Function Compatible Devices.....	3-5
3.2.1 Force Sensor Sets and Compatible Force Sensors.....	3-5
3.2.2 Force Sense Function Compatible Robots.....	3-5
3.2.3 Force Sense Function Peripheral Devices.....	3-6
3.3 Select the Force Sensor	3-7
3.4 System Configuration.....	3-9
3.4.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets.....	3-9
3.4.2 4F-FS005H-IFUS Force Sensor Set	3-10
3.5 Force Sense Function Specifications.....	3-11
3.6 Force Sense Interface Unit Specifications	3-13
3.6.1 Force Sense Interface Unit External Dimensions	3-13
3.6.2 Name of Each Force Sense Interface Unit Part	3-14
3.7 Serial Cable Specifications	3-15
3.7.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets.....	3-15
3.7.2 4F-FS005H-IFUS Force Sensor Set	3-16
3.8 Adapter cable	3-20
3.9 24 VDC Power Supply Specifications.....	3-21
3.9.1 24 VDC Power Supply Outline Drawing.....	3-21
3.9.2 24 VDC Output Cable.....	3-22
3.9.3 24 VDC Input Cable.....	3-22
3.10 Force Sensor Specifications	3-23
3.10.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets.....	3-23
3.10.2 4F-FS005H-IFUS Force Sensor Set	3-25
3.11 Sensor Attachment Adapter External Dimensions	3-26
3.11.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets.....	3-26
3.11.2 4F-FS005H-IFUS Force Sensor Set.....	3-28
3.12 Coordinate System Definition	3-32
3.12.1 Force Sense Coordinate System (Mechanical Interface).....	3-33
3.12.2 Force Sense Coordinate System (Tool)	3-34
3.12.3 Force Sense Coordinate System (XYZ).....	3-35
3.12.4 Force Sensor Coordinate System	3-36
4 Check Before Use	4-37
4.1 Product Check.....	4-37
4.1.1 Force Sensor Set 4F-FS002H-W200	4-37
4.1.2 Force Sensor Set 4F-FS002H-W1000	4-38
4.1.3 Force Sensor Set 4F-FS005H-IFUS	4-40
4.2 Software Versions	4-41
4.2.1 Force sense function	4-41
4.2.2 Extended function.....	4-42
5 Attaching the Force Sensor	5-43
5.1 Sensor Attachment Adapter	5-43
5.2 Sensor Installation.....	5-43
5.2.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets.....	5-44
5.2.2 4F-FS005H-IFUS Force Sensor Set	5-44
5.3 Recommended Attachment Angle.....	5-47

5.3.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets	5-47
5.3.2 4F-FS005H-IFUS Force Sensor Set	5-48
5.4 Securing the force sensor cable	5-50
5.5 Tool installation.....	5-52
6 Device Connection, Wiring, and Settings	6-53
6.1 Force Sensor Interface Unit ↔ Robot Controller	6-53
6.1.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets	6-53
6.1.2 4F-FS005H-IFUS Force Sensor Set	6-54
6.2 Using Extended Functions of the Force Sensor	6-56
6.3 Force Sense Interface Unit ↔ Force Sensor.....	6-61
6.3.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets	6-61
6.3.2 4F-FS005H-IFUS Force Sensor Set	6-62
6.4 Turning ON the Power	6-64
6.5 Warm Up Operation	6-64
6.6 Default Parameter Settings.....	6-65
6.6.1 Force Sense Interface Unit identification.....	6-66
6.6.2 Calibration	6-68
6.6.3 Force Sensor Tolerance	6-75
6.6.4 Force Sensor Control Offset Limit	6-76
6.6.5 Force Sensor Data Filter Setting	6-76
6.6.6 Force Sense Control Low Pass Filter Cutoff Time Constant When MELFA High Drive is Enabled...	6-76
6.6.7 Force Sensor Minimum Control Force	6-77
6.6.8 Selection of Sensor Setting	6-77
7 Checking the Connection and Settings	7-78
7.1 Checking Force Sensor Data Communication.....	7-78
7.1.1 If Using R32TB	7-79
7.1.2 If Using R56TB	7-80
7.1.3 If Using the R86TB	7-81
7.2 Checking the Force Sensor Attachment Coordinate System	7-82
8 Using the Force Sense Function (Programming)	8-83
8.1 Force Sense Control	8-84
8.1.1 Force Sense Enable/Disable Commands	8-86
8.1.2 Control Mode / Control characteristics	8-87
8.1.3 Offset Cancel Designation.....	8-98
8.1.4 Control characteristics Change Commands.....	8-99
8.1.5 Usage Example (Force Sense Control).....	8-101
8.2 Force Sense Detection	8-110
8.2.1 Mo Trigger	8-111
8.2.2 Force Detection Status	8-114
8.2.3 Data Latch	8-114
8.2.4 Data Referencing.....	8-114
8.2.5 Usage Example (Force Sense Detection).....	8-115
8.3 Force Sense log	8-120
8.3.1 Force Sense Log Function Specifications	8-120
8.3.2 Parameter Settings.....	8-122
8.3.3 Force Sense Log Data Acquisition	8-123
8.3.4 Force Sense Log Data Display (RT ToolBox3).....	8-124
8.3.5 Force Sense Log File FTP Transfer	8-129
8.3.6 Usage Example (Force Sense Log)	8-130
8.4 Gravity Offset Cancel Function	8-133
8.4.1 Estimated data.....	8-133
8.4.2 About Calibration Posture.....	8-134
8.4.3 Calibration Procedure	8-135

8.4.4 Usage Example (Gravity offset cancel)	8-141
9 Using the Force Sense Function (Teaching).....	9-143
9.1 Force Sense T/B	9-144
9.1.1 Force Sense Control (T/B)	9-144
9.1.2 Force Sense Monitor	9-151
9.1.3 Contact Detection	9-153
9.1.4 Usage Example (Force Sense Function T/B).....	9-155
9.2 Teaching Operation	9-159
9.2.1 Teaching Position Precautions	9-159
9.2.2 Usage Example (Teaching Operation)	9-163
9.3 Force Sense Function Screen	9-167
9.3.1 R32TB	9-167
9.3.2 R56TB	9-171
9.3.3 R86TB	9-174
10 How to Use the Learning Function	10-178
10.1 Force Sense Movement Specifications	10-179
10.1.1 Insertion and fitting	10-180
10.1.2 Phase match insertion	10-182
10.1.3 Contact detection.....	10-185
10.2 Creation of Force Sense Movements (Sub-Program for Learning)	10-187
10.2.1 Creation of new movement	10-187
10.2.2 Creation of force sense movements.....	10-189
10.2.3 Force sense movement setting	10-193
10.2.4 Learning setting.....	10-220
10.2.5 Saving force sense movements	10-222
10.2.6 Editing the movement.....	10-224
10.3 Creation of Learning Programs.....	10-225
10.3.1 Basic Templates used in the learning program	10-226
10.3.2 Insertion of basic templates.....	10-228
10.3.3 Addition of pre-processing/post-processing operation	10-230
10.4 Implementation of Learning	10-231
10.4.1 Learning monitor.....	10-231
10.4.2 Interruption/resumption of learning.....	10-232
10.5 Creation of Operation Programs	10-233
10.6 Customized Learning	10-234
10.6.1 Initial setting of the learning function	10-235
10.6.2 Setting of evaluation values for learning	10-236
10.6.3 Updating the learning parameter.....	10-237
10.6.4 Saving and reading of learning data.....	10-238
10.6.5 Learning program examples.....	10-238
11 Application Examples.....	11-243
12 Language Specifications	12-247
12.1 Commands Relating to Force Sense Control Function	12-247
12.2 Status Variables Relating to Force Sense Control Function.....	12-255
12.3 Commands Relating to Force Sense Detection Function.....	12-267
12.4 Status Variables Relating Force Sense Detection Function	12-270
12.5 Commands Relating to Force Sense Log Function	12-285
12.6 Related Commands for Gravity Offset Cancel Function.....	12-288
12.7 Related Status Variables for Gravity Offset Cancel Function	12-291
12.8 Commands Relating to Learning Function	12-295
12.8.1 Reference program.....	12-301
12.9 Status Variables Relating to Learning Function.....	12-303
12.10 Other Related Commands	12-311
12.11 Related Status Variables for MELFA Smart Plus	12-315

12.12 Examples	12-316
13 Parameter Specifications.....	13-321
13.1 Force Sense Function Related Parameter List.....	13-321
13.2 RT ToolBox3 Force Sense Function Parameter Setting Screen.....	13-326
13.3 R56TB Force Sense Function Parameter Setting Screen.....	13-329
13.4 R86TB Force Sense Function Parameter Setting Screen.....	13-332
14 Troubleshooting.....	14-334
14.1 Behavior when Force Sense Control Errors Occur.....	14-334
14.2 Force Sense Fuction Related Error List.....	14-334
14.3 Force Control Function Related Error Details.....	14-336
14.4 MELFA Smart Plus Card Related Error Details	14-343
14.5 Q & A.....	14-344
15 Appendix.....	15-345
15.1 Example FTP Server Settings (Microsoft Internet Information Services).....	15-345
15.1.1 Windows 10	15-345
15.1.2 Windows 11	15-353
15.1.3 Checking the FTP Server Starts.....	15-361
15.2 Control Status Transition.....	15-361

1 Using This Manual

1.1 Using This Manual

This manual is divided up into the following sections, and describes how to use the force sense function, which employs a force sense interface and force sense sensor. Refer to the "Instruction Manual" provided with the robot controller for details on functionality and the operation methods for the standard robot controller.

Table 1-1: Instruction Manual content

Chapter	Title	Content
1	Using This Manual	Describes the makeup of this manual.
2	Work Flow	Describes the work required to construct a system employing a force sensor. Carry out the work as described.
3	Force Sense Function System Specifications	Describes the force sense function system specifications.
4	Check Before Use	Describes the product configuration and devices to be prepared. Check whether all the required products are present, and check the controller, T/B, and RT ToolBox3 versions.
5	Attaching the Force Sensor	Describes how to attach the force sensor to the robot. Pay heed to the precautions when using the robot with sensor attached.
6	Device Connection, Wiring, and Settings	Describes how to connect the respective devices.
7	Checking the Connection and Settings	Describes how to check that the sensor has been properly attached, that devices have been properly connected, and that all settings have been specified correctly. Always check these items before using the force sense function.
8	Using the Force Sense Function (Programming)	Describes how to use (programming method) the force sense function.
9	Using the Force Sense Function (Teaching)	Describes how to use (teaching method) the force sense function.
10	Using the Learning Function	Describes how to use the learning function.
11	Application Examples	Describes application examples using the force sense function.
12	Language Specifications	Describes detailed MELFA-BASIC language specifications relating to the force sense function.
13	Parameter Specifications	Describes detailed parameter specifications relating to the force sense function.
14	Troubleshooting	Describes the details of and remedies for errors relating to the force sense function.

1.2 Terminology Used in This Instruction Manual

The following is a list of terminology used in this manual.

Table 1-2: Description of Terminology


	Content
Force sense function	This is the name of the robot control function using a force sensor. It consists of force sense control, force sense detection, and force sense log functions.
Force sense control	This function uses real-time information from the force sense function to control robot softness and the amount of force applied to workpieces.
Force sense detection	This function detects force sensor information, performs interrupt processing, and retains force sense data and robot position data when interrupts occur.
Force sense log	This function obtains and displays force sensor and robot position information.
Force control	This is a control method used to control robot force. Controls robot force while offsetting position in order to obtain the specified reaction force. This is used when pushing with constant force.
Stiffness control/limited stiffness control	This is a robot control method used to control robot stiffness. Controls the robot as though there is a spring on the robot hand flange surface. This method is used for copying around workpieces and assembling flexible objects. The limited stiffness control can restrict the force of the robot.
Force sensor	This sensor detects force and moment.
Force sense I/F unit	This unit takes in sensor information obtained from the force sensor and passes it to the robot controller.
MELFA Smart Plus card pack MELFA Smart Plus card *1	A function enhancement card for the CR800 robot controller. All MELFA Smart Plus functions can be used when the MELFA Smart Plus card pack is installed. One of the MELFA Smart Plus functions can be used when the MELFA Smart Plus card is installed. Functions such as the learning function are enabled. For details, refer to the MELFA Smart Plus User's Manual.

*1: When the robot controller software version is Ver.E4 or later, extended force sensor functions are available without the MELFA Smart Plus card or the card pack.

2 Work Flow

The work required to construct a system employing a force sensor is shown below. Refer to the following work flow and carry out the work as described.

2.1 Flowchart



3 Force Sense Function System Specifications

3.1 What is the Force Sense Function?

The "force sense function" uses force sensor information with 6 degrees of freedom to provide the robot with a sense of its own force. Using dedicated commands and status variables compatible with the robot program language (MELFA-BASIC VI) facilitates work requiring minute power adjustments and power detection that was not possible on past robots.

<Main features>

- (1) Robots can be controlled softly and operated while copying applicable workpieces.
- (2) Robots can be operated while pushing in the desired direction with a fixed amount of force.
- (3) Robot softness and contact detection conditions can be changed during movement.
- (4) Contact status can be detected and interrupt processing performed.
- (5) Position information and force information at the time of contact can be performed.
- (6) Force data synchronized with position data can be saved as log data.
- (7) Log data can be displayed in a graph using RT ToolBox3.
- (8) Log data files can be transferred to an FTP server.

3.2 Force Sense Function Compatible Devices

3.2.1 Force Sensor Sets and Compatible Force Sensors

Force sensor sets and compatible force sensors are shown in the table below.

Table 3-1: Force sensor set compatibility

Force sensor set	Supported force sensor type	Force sensor manufacturer
4F-FS002H-W200	1F-FS001-W200	Mitsubishi Electric
4F-FS002H-W1000	1F-FS001-W1000	
4F-FS005H-IFUS	FH-300-20 *1	Canon Inc.
	ZYX080A501 *1	SINTOKOGIO, LTD.
	ZYX080A501Z *1	
	ZYX100A102 *1	
	ZYX125A102 *1	

*1: Either one of these force sensors is to be supplied by the customer.

3.2.2 Force Sense Function Compatible Robots

The following table shows the robot models that are compatible with force sensors.

Table 3-2: Force sensor compatibility

○: Compatible ×: Not compatible

Compatible Robot	Robot Specifications/Options	Compatible Force Sensor			Notes
		1F-FS001-W200/ 1F-FS001-W1000	Canon Inc.	SINTOKOGIO, LTD.	
RV-FR series	Normal environment specifications	○	○	○	*1
	Clean specifications	○ *2	○	○	
	Oil mist specifications	○ *2	○	○	
	Wiring and piping specifications	○	×	×	
	Forearm external wiring set/Base external wiring set	○	×	×	
RH-FRH series/RV-CR series/RV-5AS	Normal environment specifications	○	×	×	
	Clean specifications	○ *2	×	×	
	Oil mist specifications	○ *2	×	×	

*1: The RV-35FR, RV-50FR, and RV-80FR are not compatible with force sensors.

*2: Clean specifications and oil mist specifications are for the robots only. The force sensor does not have the same specifications as the robots. The protective structure of the force sensor is rated at IP30.

3.2.3 Force Sense Function Peripheral Devices

The devices that are required in order to use the force sense function are shown in Table 3-3.

Refer to section [3.4.1](#) for information of the system configurations for force sensor sets 4F-FS002H-W200 and 4F-FS002H-W1000.

Refer to section [3.4.2](#) for information of the system configuration for force sensor set 4F-FS005H-IFUS.

Table 3-3: Devices required when using the force sense function

Product Name	Force Sensor Set			Notes
	4F-FS002H-W200	4F-FS002H-W1000	4F-FS005H-IFUS	
Force sensor	○	○	●	
Sensor attachment adapter (For RV-2FR, RV-4FR, and RV-7FR)	○	●	●	
Sensor attachment adapter (For RV-13FR, RV-20FR, and RH-FRH)	●	●	●	
Serial cable between unit and sensor	○	○	● *1	
Force sensor interface unit	○	○	○	
SSCNET III cable	○	○	○	
24 VDC power supply	○	○	●	
24 VDC input cable	○	○	●	
24 VDC output cable	○	○	○	
Adapter cable	○	○	×	*2

*1: When using force sensors manufactured by Canon Inc., prepare this cable, and connect it to the force sensor interface unit.

The connector set required for connection is included in the force sensor set.

*2: This cable is required when using the optional forearm external wiring set or base external wiring set.

3.3 Select the Force Sensor

When choosing the 4F-FS002H-W200 or 4F-FS002H-W1000 force sensor set, decide on the sensor you will use by using the following flow chart and checking the force sensor specifications in section [3.10](#).




Fig. 3-1: Selection flow of force sensor

Table 3-4: First selection of force sensor

Application	Robot *1								
	RV-FR Series *2, RV-CR Series					RH-FRH Series			
	RV-2FR	RV-4FR	RV-7FR RV-8CRL	RV-13FR RV-12CRL	RV-20FR	RH-3FRH	RH-6FRH	RH-12FRH	RH-20 FRH
Close tolerance fit	4F-FS002H-W200		4F-FS002H-W1000 or 4F-FS002H-W200 (Upward and downward limited)			4F-FS002H-W200			
Phase focusing									
Parts assembly									
Test (Pressed/Pull-out)									
Inset	4F-FS002H-W1000					4F-FS002H-W1000			
Deburr/Polishing									

*1: Select the 4F-FS002H-W200 force sensor set when using the RV-5AS.

*2: RV-35/50/80FR are not compatible with force sensors.




Fig. 3-2: Moment by the tool shape and a posture change

3.4 System Configuration

The device configuration required to use the force sense function is shown below.

3.4.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets




Fig. 3-3: Force sense function system configuration drawing

*1: When the robot controller software version is Ver.E4 or later, extended force sensor functions are available without the MELFA Smart Plus card or the card pack.

3.4.2 4F-FS005H-IFUS Force Sensor Set




Fig. 3-4: Force sense function system configuration drawing

*1: When the robot controller software version is Ver.E4 or later, extended force sensor functions are available without the MELFA Smart Plus card or the card pack.

3.5 Force Sense Function Specifications

The force sense function specifications are as follows.

Table 3-5: Force sense function specifications

Item			Function Details	Compatible Force Sensor		Remarks
				1F-FS001-W200/ 1F-FS001-W1000	Canon Inc./ SINTOKOGIO, LTD.	
Controller	Force sense control	Robot program language	MELFA-BASIC VI (with dedicated force sense function commands)	○	○	
		Stiffness control	Function used to control robot softly (Sets stiffness coefficients, damping coefficients.)	○	○	
		Limited stiffness control	Function used to control robot softly (Sets stiffness coefficients, damping coefficients.) This function can restrict the force of the robot.	○	○	
		Force control	This function controls the robot while pushing with specified force.	○	○	
		Control characteristics change	This function changes the control characteristics of force control and stiffness control during robot movement.	○	○	
	Force sense detection	Interrupt execution	Interrupt processing can be performed using the status at the point the specified force and moment are exceeded.	○	○	
		Data latch	This function obtains the force sensor and robot position at the time of contact.	○	○	
		Data referencing	This function displays force sensor data and retains maximum values.	○	○	
	Force sense log	Synchronization data	This function obtains force sensor information synchronized with position information as log data.	○	○	
		Start/end triggers	Logging start and end commands can be specified in the robot program.	○	○	
		FTP transfer	This function transfers obtained log files to an FTP server.	○	○	
	Gravity offset cancel		Gravity offset cancel is a function that the offset cancel in response to a change in the direction of gravity applied to the force sensor by hand load at the time of posture change. To use this function, it is necessary to estimate the bias value of the force sensor, position of the center of gravity and the mass of hand load by the force calibration.	○	○	Gravity offset cancel function is available only for RV-FR series.
	Learning function		This function optimizes the force sense control parameters and operation speed.	○	○	Extended functions of the force sensor enabled with the MELFA Smart Plus card.
	R32TB	Force sense control (TB)	Enables/disables force sense control and sets control conditions while jogging.	○	○	
		Force sense monitor	Displays sensor data and the force sense control setting status.	○	○	
		Teaching position search	This function searches for the contact position.	○	○	
		Parameter setting screen	Dedicated force sense function parameter setting screen	×	×	

Item		Function Details	Compatible Force Sensor		Remarks
			1F-FS001-W200/ 1F-FS001-W1000	Canon Inc./ SINTOKOGIO, LTD.	
R56TB	Force sense control (TB)	Enables/disables force sense control and sets control conditions while jogging.	○	○	
	Force sense monitor	Displays sensor data and the force sense control setting status.	○	○	
	Teaching position search	This function searches for the contact position.	○	○	
	Parameter setting screen	Dedicated force sense function parameter setting screen	○	○	
R86TB	Force sense control (TB)	Enables/disables force sense control and sets control conditions while jogging.	○	○	
	Force sense monitor	Displays sensor data and the force sense control setting status.	○	○	
	Teaching position search	This function searches for the contact position.	○	○	
	Parameter setting screen	Dedicated force sense function parameter setting screen	○	○	
RT ToolBox3	Waveform data display	Displays force sensor and position data.	○	○	
	Oscilloscope	Displays the data which is retrieved from a force sensor.	○	○	
	Parameter setting screen	Dedicated force sense function parameter setting screen	○	○	
	Force sensor calibration screen	Executes the force sensor calibration in this screen.	○	○	
	Force sense wizard function	Insertion and fitting	○	×	Extended functions of the force sensor enabled with the MELFA Smart Plus card. Force sense wizard function is available only for RV-FR series. *1
		Phase match insertion			
		Contact detection			

*1: RT ToolBox3 force sense wizard cannot be used if a sensor manufactured by Canon Inc. or SINTOKOGIO, LTD. is selected for "Parameter FSTYPE". The force sense wizard function can only be started using either of the following methods when 1F-FS001-W200 or 1F-FS001-W1000 force sensors are used. For either method, start RT ToolBox3 and establish connection with the robot controller.

- Right-click [Program] in the project tree and select [Create force movement].
- Select [Tool] > [Force sensor] > [Force extension] > [Create force movement].

3.6 Force Sense Interface Unit Specifications

This section contains the specifications of the force sensor interface unit included with the force sensor set.

Table 3-6: Force sense interface unit specifications

Item		Unit	Specification Value	Remarks
Model		-	2F-DQ561	
Force sensor	No. of connected sensors	sensors	1	
Interface	RS-422	ch	2	Used to connect the sensor (One 5 V channel and one 24 V channel. Both cannot be used simultaneously.)
	SSCNET III	ch	2	For robot controller and additional axis amp connection
Power supply	Input voltage range	VDC	24 $\pm$ 5%	There should be no momentary power interruptions or momentary voltage drops.
	Power consumption	W	25	Includes power supply capacity for force sensor unit.
External dimensions		mm	225(W) x 111(D) x 40(H)	Does not include protrusions.
Weight		kg	Approx. 0.8	
Construction			Panel installation, open type	IP20
Operating temperature range		°C	0 to 40	
Relative humidity		%RH	45 to 85	There should be no dew condensation.
Paint color			Dark gray	Referential munsell: 3.5PB3.2/0.8 Referential PANTONE: 432C

3.6.1 Force Sense Interface Unit External Dimensions

Outline drawings of the force sense interface unit are shown below.





Fig. 3-5: Force sense interface unit outline drawings

3.6.2 Name of Each Force Sense Interface Unit Part

The name of each force sense interface unit part is as follows.



*1: Wire the connector set included with the force sensor set to the serial cable (FH-10M) when using a force sensor manufactured by Canon Inc.

The pin assignments for the CN422_24V connector of the force sensor interface unit are shown in the table below. Refer to the table below and wire the connector to the serial cable.

No.	Signal name	I/O	Description
1	SG	-	GND
2	RXD+	I	Serial differential receive+
3	NC	-	-
4	TXD+	O	Serial differential send+
5	SG	-	GND
6	NC	-	-
7	NC	-	-
8	NC	-	-
9	NC	-	-
10	NC	-	-
11	NC	-	-
12	NC	-	-
13	24V	-	Power
A	FG	-	Dedicated pin


No.	Signal name	I/O	Description
14	SG	-	GND
15	RXD-	I	Serial differential receive-
16	NC	-	-
17	TXD-	O	Serial differential send-
18	SG	-	GND
19	NC	-	-
20	NC	-	-
21	NC	-	-
22	NC	-	-
23	NC	-	-
24	NC	-	-
25	NC	-	-
26	NC	-	-
B	FG	-	Dedicated pin

3.7 Serial Cable Specifications

This cable is used to connect the force sensor to the force sensor interface unit.
The serial cable is included with the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets.
Please supply your own serial cable when using the 4F-FS005H-IFUS force sensor set.

3.7.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets

The serial cable is an accessory for the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets.



Connection diagram

3.7.2 4F-FS005H-IFUS Force Sensor Set

Please supply your own serial cable.

3.7.2.1 Force Sensors Manufactured by Canon Inc.

Please supply a serial cable from the cables shown in Table 3-10.

Wire the connector set included with the 4F-FS005H-IFUS force sensor set to the serial cable.

The signal names and colors of wires as well as corresponding connections are shown in Table 3-7.



Refer to section [3.6.2](#) for the pin assignment of the connector on the force sensor interface unit.

Table 3-7: Wire signals and colors for the serial cable (FH-10M)

Signal name	Wire color	Connection	
VIN (power input)	Red	Power: 7 V to 24 VDC ($\pm 5\%$)	
GND	Blue	Power supply GND	
TXD+	White	RS422 communication	RXD+
TXD-	Yellow		RXD-
RXD+	Green		TXD+
RXD-	Orange		TXD-
FG	Black	Frame ground	

Information on how to wire the connector set to the serial cable (FH-10M) is shown below.


- (1) Referring to the figure below, solder the serial cable signal wires (excluding the FG wire) to the connector.
(*1)




*1: When soldering, it is advisable to secure the serial cable connector case in place and adjust the length of the signal wire.

- (2) Prepare the FG wire (black) using the steps below.


- 1) Wrap the serial cable heat shrink tube with copper tape once.



- 2) Strip the insulation from the FG wire (black) then fold back the conductor over the copper tape. It is advisable to secure the serial cable connector case in place and adjust the length of the FG wire. Cut any excess electrical wire.




- 3) Wrap the conductor of the folded FG wire with copper tape.
Wrap the wire with enough tape so that it can be secured to the ground plate.



- (3) Secure the serial cable connector case in place using the steps below.

- 1) Loosen the two connector case screws, take the case apart and remove the ground plate.
- 2) Secure the prepared cable to the ground plate.



- 3) Assemble the connector case in the reverse order of Step 1 then use the screws to attach the case to the connector securely.

3.7.2.2 Force Sensors Manufactured by SINTOKOGIO, LTD.

Please supply a serial cable from the cables shown in Table 3-10.




Fig. 3-6: CN422-HR30-10000 wiring diagram





Fig. 3-7: CN422-HR34B-10000 wiring diagram

3.8 Adapter cable

This cable is required when using the optional forearm external wiring set or base external wiring set. It is included with the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets.



*1: For details on wiring, refer to "Wiring and piping system diagram for hand" in the separate Instruction Manual "Standard Specifications Manual" or "Installing the option devices" in the separate Instruction Manual "Robot Arm Setup and Maintenance".

3.9 24 VDC Power Supply Specifications

This section contains the specifications of the 24 VDC power supply included with the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets.

When the 4F-FS005H-IFUS force sensor set is selected, refer to Table 3-8 and supply a 24 VDC power supply and 24 VDC input cable. The 24 VDC output cable used to supply 24 VDC to the force sensor interface unit is included with the force sensor set. Prepare the 24 VDC output cable for the 24 VDC power supply which has been supplied by the customer.

Table 3-8: 24 VDC power supply specifications

Item		Unit	Specification Value	Remarks
Model		-	2F-PWR-01	
Input	Voltage	VAC	85 to 264	
	current	A	1.3 typ.	ACIN 100V
			0.7 typ.	ACIN 200V
	Frequency	Hz	50 or 60 (47 to 63)	
Output	Rated voltage	VDC	24	
	Rated current	A	4.3	
	Voltage setting accuracy	VDC	23.00 to 25.00	
External dimensions		mm	72(W) x 185(D) x 45(H)	
Weight		g	480	
Construction			Panel installation, open type	IP20
Operating temperature range		°C	-10 to 70	
Relative humidity		%RH	20 to 90	There should be no dew condensation.

3.9.1 24 VDC Power Supply Outline Drawing





Fig. 3-8: 24 VDC power supply outline drawing


3.9.2 24 VDC Output Cable

3.9.2.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets




3.9.2.2 4F-FS005H-IFUS Force Sensor Set

Prepare the side with the loose wires for the 24 VDC power supply selected by the customer.



3.9.3 24 VDC Input Cable



3.10 Force Sensor Specifications

3.10.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets

The specifications for the 1F-FS001-W200 and 1F-FS001-W1000 force sensors are shown below.

Table 3-9: Force sensor specifications

Item		Unit	Specification Value		Remarks
Model		-	1F-FS001-W200	1F-FS001-W1000	
Rated load (*1)	Fx, Fy, Fz	N	200	1000	Be sure to set the value within the rated load to the FSLMTMX (force sensor permissible value) parameter.
	Mx, My, Mz	Nm	4	30	
Resolution	Fx, Fy, Fz	N	Approx. 0.03	Approx. 0.15	
	Mx, My, Mz	Nm	Approx. 0.0006	Approx. 0.0046	
Minimum control force (*2)	Fx, Fy, Fz	N	0.3		This value can be changed by the FSMINCTL (force sensor minimum control force) parameter.
	Mx, My, Mz	Nm	0.03		
Linearity		%FS	3		
Hysteresis		%FS	3		
Other axis sensitivity		%FS	5		
Zero temperature properties	Fx, Fy, Fz	%FS/°C	±0.2		
	Mx, My, Mz	%FS/°C	±0.2		
Consumption current		mA	200		
Output form		-	RS422		
Weight (sensor unit)		g	360	580	
External dimensions		mm	Ø80 x 32.5	Ø90 x 40	See outline drawing.
Material		-	Aluminum alloy		
Color		-	Black		
Operating environment	Temperature	°C	0 to 50		
	Humidity	%RH	95 or less		

*1: When 1F-FS001-W200 is used with RV-7/13/20FR robot, the moment beyond the moment rated load of the force sensor is applied if the tool/workpiece of the robot's maximum load mass is grasped and its hand posture is set vertically to the installation surface (the robot set on the floor). Use the force sensor with the hand posture at which the moment does not exceed the moment rated load (for example, with the hand posture facing downward).

*2: Minimum value of force or moment for force sense control.





Caution

When a load beyond the rated load is applied repeatedly, distortion occurs gradually inside the sensor. Therefore, the force does not be detected precisely. Use the force sensor with a load within the rated range.

3.10.1.1 Force Sensor External Dimensions

Outline drawings of the force sensor are shown below.



3.10.2 4F-FS005H-IFUS Force Sensor Set

The 4F-FS005H-IFUS force sensor set is compatible with the force sensors in the table below.

Table 3-10: 4F-FS005H-IFUS compatible force sensors and serial cables

Item		Unit	Specifications *1				
Manufacturer		-	Canon Inc.	SINTOKOGIO, LTD.			
Force sensor type		-	FH-300-20	ZYX080A501	ZYX080A501Z	ZYX100A102	ZYX125A102
Rated load	Fx, Fy, and Fz	N	300	500	500	1000	1000
Rated moment	Mx, My, and Mz	Nm	20	20	20	45	75
Weight		g	Approx. 250	Approx. 280	Approx. 320	Approx. 540	Approx. 1000
External dimensions		mm	φ88×20	φ80×22	φ80×25	φ100×30	φ125×30
Protective structure		-	IP65	IP67	IP67	IP67	IP67
Operating environment	Temperature	°C	0 to 50	0 to 50	0 to 50	0 to 50	0 to 50
	Humidity *2	%RH	95 or lower	20 to 90	20 to 90	20 to 90	20 to 90
Model of serial cable between unit and sensor		-	FH-10M *3	CN422-HR30-10000	CN422-HR30-10000	CN422-HR30-10000	CN422-HR34B-10000
Cable length		m	10	10	10	10	10

*1: Values may differ due to specification changes. For details, refer to the manufacturer's specifications.

*2: Non-condensing.

*3: The connector used to connect this cable to the force sensor interface unit comes unwired. The connector set included with the force sensor set is to be wired by the customer. For information on the wiring method, refer to section [3.7.2.1](#).

3.11 Sensor Attachment Adapter External Dimensions

Outline drawings of the sensor attachment adapter are shown below.

3.11.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets

Although the sensor attachment adapter (for the RV-2FR, RV-4FR, and RV-7FR) shown in Fig. 3-11 is included with the 4F-FS002H-W200 force sensor set, the customer must supply the sensor attachment adapter for the RV-13FR and RV-20FR.

Furthermore, the sensor attachment adapter is not included with the 4F-FS002H-W1000 force sensor set. Refer to Fig. 3-12 and Fig. 3-13, when supplying a sensor attachment adapter.

For 1F-FS001-W200




Fig. 3-11: Sensor attachment adapter outline drawings (for RV-2/4/7FR)

For 1F-FS001-W1000




Fig. 3-12: Sensor attachment adapter outline drawings (for RV-2/4/7FR)



3.11.2 4F-FS005H-IFUS Force Sensor Set

When using compatible force sensors with the 4F-FS005H-IFUS force sensor set, the sensor attachment adapter must be created by the customer. Refer to the following information when creating the sensor attachment adapter.

For robot and sensor attachment adapter combinations, refer to Table 3-11.

When creating the sensor attachment adapter, ensure the surface of the sensor attachment adapter which mates with the force sensor has a flatness of 0.05mm or less. If a force sensor is attached to a surface that does not have the specified flatness, the force sensor will deform, leading to deteriorated sensor output reliability and failure.

When using adapter A (for FH-300-20 manufactured by Canon Inc. combined with RV-2FR, RV-4FR, or RV-7FR), the force sensor or end of the hand may interfere with the robot depending on the robot's operating range. Change the shape of the adapter if necessary.

Table 3-11: Robot and sensor attachment adapter combinations

Force sensor		Canon Inc.	SINTOKOGIO, LTD.		
		FH-300-20	ZYX080A501	ZYX080A501Z	ZYX100A102
Robot model	Installation dimensions	P.C.D. 78 (5×M6)	P.C.D. 63 (4×M6)	P.C.D. 80 (6×M8)	P.C.D. 100 (6×M8)
RV-2FR	P.C.D. 31.5 (4×M5)	Adapter A (Fig. 3-14)	Adapter B (Fig. 3-15)	-	-
RV-4FR					
RV-7FR					
RV-13FR	P.C.D. 40 (4×M6)	Adapter C (Fig. 3-16)	Adapter D (Fig. 3-17)	Adapter E (Fig. 3-18)	Adapter F (Fig. 3-19)
RV-20FR					




Fig. 3-14: Adapter A (for FH-300-20 manufactured by Canon Inc. in combination with RV-2FR, RV-4FR, or RV-7FR)




Fig. 3-15: Adapter B (for XYZ080A501 and XYZ080A501Z manufactured by SINTOKOGIO, LTD. in combination with RV-2FR, RV-4FR, or RV-7FR)




Fig. 3-16: Adapter C (for FH-300-20 manufactured by Canon Inc. in combination with RV-13FR or RV-20FR)




Fig. 3-17: Adapter D (for XYZ080A501 and XYZ080A501Z manufactured by SINTOKOGIO, LTD. in combination with RV-13FR or RV-20FR)




Fig. 3-18: Adapter E (for XYZ100A102 manufactured by SINTOKOGIO, LTD. in combination with RV-13FR or RV-20FR)




Fig. 3-19: Adapter F (for XYZ125A102 manufactured by SINTOKOGIO, LTD. in combination with RV-13FR or RV-20FR)

3.12 Coordinate System Definition

The force and moment coordinate systems used with the force sense function are summarized in "Table 3-12".


Table 3-12: Force sense coordinate system list

Coordinate System Name	Description
Force sense coordinate system (mechanical interface)	Coordinate system that forms reference for calibration (See section 6.6.2 for details on calibration.)
Force sense coordinate system (tool)	Coordinate system for force sense function (when tool selected)
Force sense coordinate system (XYZ)	Coordinate system for force sense function (when XYZ selected)
Force sensor coordinate system	Coordinate system for force sensor

A definition of each coordinate system is described below.

3.12.1 Force Sense Coordinate System (Mechanical Interface)


The force sense coordinate system (mechanical interface) is defined as follows.



The force sense coordinate system (mechanical interface) is the plus direction coordinate system for the direction receiving the reaction force when the robot is moved in the mechanical interface coordinate system plus direction. The coordinate system origin point overlaps with that of the mechanical interface coordinate system. (In this coordinate system, the mechanical interface coordinate system symbols are reversed.)

3.12.2 Force Sense Coordinate System (Tool)


If the tool coordinate system is set, the force sense coordinate system (tool) is defined as follows based on the set tool coordinate system.



The force sense coordinate system (tool) is the plus direction coordinate system for the direction receiving the reaction force when the robot is moved in the tool coordinate system plus direction. The coordinate system origin point overlaps with that of the tool coordinate system. (In this coordinate system, the tool coordinate system symbols are reversed.)

3.12.3 Force Sense Coordinate System (XYZ)

The assumed force sense coordinate system (XYZ) used in force sense function processing is defined as follows.




The force sense coordinate system (XYZ) is the plus direction coordinate system for the direction receiving the reaction force when the robot is moved in the XYZ coordinate system plus direction. The coordinate system origin point overlaps with that of the mechanical interface coordinate system.

3.12.4 Force Sensor Coordinate System

The coordinate systems for the 1F-FS001-W200 and 1F-FS001-W1000 force sensors are defined below.

Check the specifications sheet of each manufacturer when using force sensors compatible with the 4F-FS005H-IFUS force sensor set.



4 Check Before Use

4.1 Product Check


4.1.1 Force Sensor Set 4F-FS002H-W200

The standard configuration of this product is as follows. Please check.

Table 4-1: Force sensor set (4F-FS002H-W200) product configuration list

No.	Part Name	Model	Quantity	Remarks	
<1>	Force sensor	4F-FS002H-W200 (force sensor set)	1F-FS001-W200	1	
<2>	Force sense interface unit		2F-DQ561	1	
<3>	Sensor attachment adapter (RV-2/4/7FR)		1F-FSFLG-01	1	Weight 200 g
<4>	Adapter cable		1F-ADCBL-01	1	
<5>	24 VDC power supply		2F-PWR-01	1	
<6>	24 VDC power supply output cable (1 m)		2F-PWRCBL-01	1	
<7>	24 VDC power supply input cable (1 m)		2F-PWRCBL-02	1	
<8>	Serial cable between unit and sensor (2 m)		2F-FSCBL1-05	1	
<9>	SSCNET III cable (10 m)		MR-J3BUS10M-A	1	
<10>	CD-ROM		BFP-A3542	1	
<11>	Force sensor attachment accessories	-	1 set	- Hexagon socket bolt M5-12 (4) - Cylindrical pin φ 3 (2), φ 5 (1) - Cable tie (4) - Cable tie fixture (4) - P-type pan head screw M3-6 (4)	
<12>	Spare fuse	LM03	1		

Note) The numbers in the above table correspond to the numbers below.



4.1.2 Force Sensor Set 4F-FS002H-W1000


The standard configuration of this product is as follows. Please check.

Table 4-2: Force sensor set (4F-FS002H-W1000) product configuration list

No.	Part Name	Model		Quantity	Remarks
<1>	Force sensor (*1)	4F-FS002H-W1000 (force sensor set)	1F-FS001-W1000	1	
<2>	Force sense interface unit		2F-DQ561	1	
<3>	Adapter cable		1F-ADCBL-01	1	
<4>	24 VDC power supply		2F-PWR-01	1	
<5>	24 VDC power supply output cable (1 m)		2F-PWRCBL-01	1	
<6>	24 VDC power supply input cable (1 m)		2F-PWRCBL-02	1	
<7>	Serial cable between unit and sensor (5 m)		2F-FSCBL1-05	1	
<8>	SSCNET III cable (10 m)		MR-J3BUS10M-A	1	
<9>	CD-ROM		BFP-A3542	1	
<10>	Spare fuse		LM03	1	

*1: The sensor attachment adapter is not supplied. You should purchase the sensor attachment adapter separately. (See Table 4-3)

Note) The numbers in the above table correspond to the numbers below.



When using the force sensor set 4F-FS002H-W1000, you should purchase the sensor attachment adapter set separately, according to your robot.

Table 4-3: Additional items for force sensor set 4F-FS002H-W1000

Part Name	Model	Quantity	Remarks
Sensor attachment adapter (for RV-2/4/7FR)	1F-FSFLGSET-01	1	<ul style="list-style-type: none"> - Sensor attachment adapter 1F-FSFLG-01 (1) : Weight 200 g - Hexagon socket bolt M5-12 (4) - Cylindrical pin H7, ϕ 3 x 8 (2) H7, ϕ 5 x 10 (1) - Cable tie (4) - Cable tie fixture (4) - P-type pan head screw M3-6 (4)
Sensor attachment adapter (for RV-13/20FR)	1F-FSFLGSET-02	1	<ul style="list-style-type: none"> - Sensor attachment adapter 1F-FSFLG-02 (1) : Weight 230 g - Hexagon socket bolt M6-14 (4) - Cylindrical pin H7, ϕ 3 x 8 (2) H7, ϕ 6 x 12 (1) - Cable tie (4) - Cable tie fixture (4) - P-type pan head screw M3-6 (4)

4.1.3 Force Sensor Set 4F-FS005H-IFUS

The standard configuration of the product is as shown below.

Please supply your own force sensor, serial cable, and sensor attachment adapter.


For information on sensors that are compatible with this set and the serial cable, refer to Table 3-10.

Refer to section [3.11.2](#) to create the sensor attachment adapter.

Table 4-4: 4F-FS005H-IFUS force sensor set product configuration list

No.	Part Name	Model		Quantity	Remarks
<1>	Force sense interface unit	4F-FS005H-IFUS (force sensor set)	2F-DQ561	1	
<2>	SSCNET III cable (10 m)		MR-J3BUS10M-A	1	
<3>	Spare fuse		LM03	1	
<4>	Connector set		FCUA-DJ200	1	When using force sensors manufactured by Canon Inc., prepare the serial cable before wiring it to this connector set.
<5>	24 VDC power supply output cable (3m)		2F-PWRCBL-03	1	
<6>	Quick guide		BFP-A3889	1	

Note) The numbers in the above table correspond to the numbers below.



4.2 Software Versions

4.2.1 Force sense function

All software must support the force sense function to facilitate its use. Check all versions prior to use.

■ Robot controller

Part Name	Model	Supported Software Version		
		Force Sensors 1F-FS001-W200 and 1F-FS001-W1000	Force Sensors Manufactured by Canon Inc.	Force Sensors Manufactured by SINTOKOGIO, LTD.
Controller	CR800-D/R	Ver.A1 or later	Ver.E1 or later	Ver.E1 or later
	CR800-Q	Ver.A2 or later	Ver.E1 or later	Ver.E1 or later

■ Teaching pendant

Part Name	Model	Supported Software Version		
		Force Sensors 1F-FS001-W200 and 1F-FS001-W1000	Force Sensors Manufactured by Canon Inc.	Force Sensors Manufactured by SINTOKOGIO, LTD.
Teaching pendant	R32TB	Ver.1.7 or later	Ver.1.7 or later	Ver.1.7 or later
	R56TB	Ver.3.0 or later	Ver.3.0 or later	Ver.3.0 or later
	R86TB	Ver.1.10L or later	Ver.1.10L or later	Ver.1.10L or later

■ Support software

Part Name	Model	Supported Software Version		
		Force Sensors 1F-FS001-W200 and 1F-FS001-W1000	Force Sensors Manufactured by Canon Inc.	Force Sensors Manufactured by SINTOKOGIO, LTD.
MELSOFT RT ToolBox3	3F-14C-WINJ 3F-14C-WINE	Ver.1.00A or later	Ver.2.50C or later	Ver.2.50C or later
MELSOFT RT ToolBox3 mini	3F-15C-WINJ 3F-15C-WINE	Ver.1.00A or later	Ver.2.50C or later	Ver.2.50C or later
MELSOFT RT ToolBox3 Pro	3F-16D-WINJ 3F-16D-WINE	Ver.1.00A or later	Ver.2.50C or later	Ver.2.50C or later

4.2.2 Extended function

To enable extended functions of the force sensor, all software and a function enhancement card must support the functions. Check the software versions and the card type/name prior to use.

■ Robot controller

Part Name	Model	Supported Software Version		
		Force Sensors 1F-FS001-W200 and 1F-FS001-W1000	Force Sensors Manufactured by Canon Inc.	Force Sensors Manufactured by SINTOKOGIO, LTD.
Controller	CR800-D/R/Q *1	Ver.A4 or later	Ver.E1 or later	Ver.E1 or later

*1: Force sense wizard function is available only for RV-FR series.

■ Support software

Part Name	Model	Supported Software Version		
		Force Sensors 1F-FS001-W200 and 1F-FS001-W1000	Force Sensors Manufactured by Canon Inc. *1	Force Sensors Manufactured by SINTOKOGIO, LTD. *1
MELSOFT RT ToolBox3	3F-14C-WINJ 3F-14C-WINE	Ver.1.50C or later	Ver.2.50C or later	Ver.2.50C or later
MELSOFT RT ToolBox3 mini	3F-15C-WINJ 3F-15C-WINE	Ver.1.50C or later	Ver.2.50C or later	Ver.2.50C or later
MELSOFT RT ToolBox3 Pro	3F-16D-WINJ 3F-16D-WINE	Ver.1.50C or later	Ver.2.50C or later	Ver.2.50C or later

*1: The RT ToolBox3 force sense wizard function cannot be used if a force sensor manufactured by Canon Inc. or SINTOKOGIO, LTD. has been selected.

■ Function extended card *1

Part Name	Type	Model			Remarks
		Force Sensors 1F-FS001-W200 and 1F-FS001-W1000	Force Sensors Manufactured by Canon Inc.	Force Sensors Manufactured by SINTOKOGIO, LTD.	
MELFA Smart Plus card pack	AB type	2F-DQ520	2F-DQ520	2F-DQ520	Either one
MELFA Smart Plus card	A type	2F-DQ521	2F-DQ521	2F-DQ521	

*1: When the robot controller software version is Ver.E4 or later, extended force sensor functions are available without the MELFA Smart Plus card or the card pack.

5 Attaching the Force Sensor

This Chapter describes how to attach the force sensor. The force sensor is a precision measuring instrument, and attaching it carelessly may lead to a drop in accuracy or fault. Always check the following before performing attachment.

Furthermore, it is necessary to correctly define the correlation between the sensor coordinate system and robot coordinate system. Refer to the recommended attachment method in section [5.3](#) for details on the sensor attachment angle.

5.1 Sensor Attachment Adapter


A dedicated "sensor attachment adapter" is required to secure the force sensor to the robot. As shown in the following diagram, attach the sensor attachment adapter to the robot mechanical interface before installing the force sensor.

<If preparing your own sensor attachment adapter>

Refer to sections [3.10.1.1](#) and [3.11](#) for details on the installation shape for the sensor side of the adapter.

Furthermore, refer to the separate "Standard Specifications" for details on the shape of the robot mechanical interface.

(When using the RH-FRH series, purchase the sensor attachment adapter separately.)




5.2 Sensor Installation

The force sensor is secured by tightening the bolts built in to the sensor from the bolt holes on the force sensor tool side. Tighten each bolt in order diagonally a little at a time to ensure even contact between the sensor installation surface and sensor attachment adapter. The sensor may be damaged if any of the bolts are overly tightened at one time, and therefore caution is advised. Always tighten each bolt a little at a time until the recommended torque value is reached.

5.2.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets

Force sensor model	Sensor installation bolt nominal diameter	Recommended tightening torque (N•m)	Sensor installation bolt length [mm] *1
1F-FS001-W200	M6	6	20
1F-FS001-W1000	M6	10	20

*1: The bolts are built into the force sensor.



Caution


Forcefully tightening the bolts in an order other than specified may damage the sensor.

5.2.2 4F-FS005H-IFUS Force Sensor Set

5.2.2.1 Force Sensors Manufactured by Canon Inc.

For information on the positioning pin specifications, check the manufacturer's specifications sheet.

Force sensor manufacturer	Model	Sensor installation bolt nominal diameter	Recommended tightening torque (N•m)	Sensor installation bolt length [mm]
Canon Inc.	FH-300-20	M6	5.2	20



Caution


Forcefully tightening the bolts in an order other than specified may damage the sensor.

5.2.2.2 Force sensors manufactured by SINTOKOGIO, LTD.


For information on the positioning pin specifications, check the manufacturer's specifications sheet.

Force sensor manufacturer	Model	Sensor installation bolt nominal diameter	Recommended tightening torque (N•m)	Sensor installation bolt length [mm]
SINTOKOGIO, LTD.	ZYX080A501	M6	9.2	20 (RV-2FR, RV-4FR, and RV-7FR) 25 (RV-13FR and RV-20FR)
	ZYX080A501Z	M6	9.2	20 (RV-2FR, RV-4FR, and RV-7FR) 25 (RV-13FR and RV-20FR)
	ZYX100A102	M8	22	32 (RV-13FR and RV-20FR)
	ZYX125A102	M8	22	32 (RV-13FR and RV-20FR)


<ZYX080A501 and ZYX080A501Z force sensors>



<ZYX100A102 force sensor>




<ZYX125A102 force sensor>



⚠ Caution Forcefully tightening the bolts in an order other than specified may damage the sensor.

⚠ Caution By installing a ferrite core close to the sensor, force sensors manufactured by SINTOKOGIO, LTD. will be compliant with EN 61000-6-2:2005. Install a ferrite core as shown in the figures below if required.
Ferrite core (supplied by customer)

- Recommended product: E04SR301334
- Manufacturer: SEIWA ELECTRIC MFG CO. Ltd.




5.3 Recommended Attachment Angle

The following attachment method is recommended to ensure easy calibration with the force sensor coordinate system and force sense coordinate system (mechanical interface) that forms the reference for the force sense function.

5.3.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets

Attach the sensor so that the +FXs direction of the sensor coordinate system is parallel with the +Xm direction of the mechanical interface coordinate system.



<Calibration>

To ensure proper functioning of the force sense function, it is necessary to correctly set the correlation between the force sensor coordinate system and force sense coordinate system (mechanical interface).

* Refer to section [6.6.2](#) for details on the calibration method.

* Refer to section [3.10](#) for details on the coordinate system definition.

5.3.2 4F-FS005H-IFUS Force Sensor Set


5.3.2.1 Force Sensors Manufactured by Canon Inc.

The coordinate system for force sensors manufactured by Canon Inc. is described below.

When the J6 axis is aligned to 0 degrees using JOG operation, the mechanical interface coordinate system (X_m , Y_m , Z_m) will be as shown in the figure below. Align the direction of the force sensor and mechanical interface coordinate systems as shown below and attach the force sensor.

- Ensure that $+F_y$ s of the force sensor coordinate system is pointing in the same direction as $+X_m$ of the mechanical interface coordinate system.
- Ensure that $+F_z$ s of the force sensor coordinate system is pointing in the same direction as $+Z_m$ of the mechanical interface coordinate system.

Considering that the wiring runs toward the arm, the force sensor will be installed at an angle that faces the connector toward the J1 arm when the J6 axis is at 0 degrees and the $+Z_m$ coordinate is facing straight down.



5.3.2.2 Force Sensors Manufactured by SINTOKOGIO, LTD.

The coordinate system for force sensors manufactured by SINTOKOGIO, LTD. is described below.

When the J6 axis is aligned to 0 degrees using JOG operation, the mechanical interface coordinate system (X_m , Y_m , Z_m) will be as shown in the figure below. Align the direction of the force sensor and mechanical interface coordinate systems as shown below and attach the force sensor.

- Ensure that $+FX_s$ of the force sensor coordinate system is pointing 180 degrees in the opposite direction to $+X_m$ of the mechanical interface coordinate system.
- Ensure that $+FZ_s$ of the force sensor coordinate system is pointing in the same direction as $+Z_m$ of the mechanical interface coordinate system.


Considering that the wiring runs toward the arm, the force sensor will be installed at an angle that faces the connector toward the J1 arm when the J6 axis is at 0 degrees and the $+Z_m$ coordinate is facing straight down.

For the ZYX125A102 force sensor, the $+FX_s$ and $+FY_s$ directions in relation to the direction the cable is plugged in are different to that of other force sensors (see View A).

For this reason, align the direction of the force sensor and mechanical interface coordinate systems as shown below and attach the force sensor.

- Ensure that $+FX_s$ of the force sensor coordinate system is pointing in the same direction as $+X_m$ of the mechanical interface coordinate system.
- Ensure that $+FZ_s$ of the force sensor coordinate system is pointing in the same direction as $+Z_m$ of the mechanical interface coordinate system.

Note that the setting value will be different when setting parameter FSXTL.




View A


5.4 Securing the force sensor cable

- 1) Mount a cable tie fixture (attachment) on the sensor attachment adapter with cable tie fixation screw (attachment).
- 2) Connect the force sensor cable to the hand cable or serial cable between unit and sensor.
- 3) Secure the force sensor cable to the cable tie fixtures with cable ties.
The cable bending dimensions differ depending on the sensor. Secure the cable to the sensor ensuring the bending dimensions shown in the figure below are met.
* Ensure that the force sensor cable and connector are not subject to bending forces.
- 4) When purchasing the sensor attachment adapter, also purchase a cable tie and a cable tie fixture.


<Force Sensors 1F-FS001-W200 and 1F-FS001-W1000>




<Force sensor manufactured by Canon Inc.>




<ZYX080A501 and ZYX080A501Z force sensors manufactured by SINTOKOGIO, LTD.>



<ZYX100A102 force sensor manufactured by SINTOKOGIO, LTD.>



<ZYX125A102 force sensor manufactured by SINTOKOGIO, LTD.>



5.5 Tool installation


Use the bolt specified below when attaching a hand to the tool side of the force sensor. Tighten bolts little by little to ensure even contact.

For information on the tool installation dimensions for force sensors compatible with the 4F-FS005H-IFUS force sensor set, check the manufacturer specifications of the force sensor being used.

Force sensor model	Nominal diameter	Tightening torque [Nm]	Engagement allowance [mm]
1F-FS001-W200	M6	6	8 to 11
1F-FS001-W1000	M6	10	10 to 15

Also, pay attention to the following points. Inappropriate installation will lead to obtaining inaccurate force data, adversely affecting performance of the force sense control.

- Ensure that the hand attachment surface is as flat as possible, and ensure sufficient stiffness to avoid any loss in force or moment.
- Do not attach the sensor in such a way that its attachment prevents movement of movable parts of the force sensor (as a result of inappropriate cable routing, etc.).



Caution

For fixing the tool, do not apply the load equal to or beyond the rated load (especially the moment load) to the force sensor. When a load beyond the rated load is applied repeatedly, distortion occurs gradually inside the sensor. Therefore, the force does not be detected precisely.



Caution

There are some hands equipped with air supply cables and/or power supply cables. Attaching them to the tool side of the force sensor will cause the cables to be swung, resulting in generation of a centrifugal force, which may adversely affect the accuracy of obtained force data. The accuracy of the data may also be affected by the weight of the cables. Take appropriate measures, such as fixing the cables to the sensor attachment adapter.



Caution

When force sensors manufactured by Canon Inc. are used, the output values may drift due to localized temperature distribution if hot or cold items are grasped. In such situations, it is recommended that the value output immediately after execution of the zero reset function is used or measures against heat flow are implemented.


6 Device Connection, Wiring, and Settings

This Chapter describes "force sensor", "force sense interface unit", and "robot controller" connection, as well as default parameter settings.

6.1 Force Sensor Interface Unit ↔ Robot Controller

6.1.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets


Connect the force sense interface unit and robot controller as shown below.



6.1.2 4F-FS005H-IFUS Force Sensor Set


6.1.2.1 Force Sensors Manufactured by Canon Inc.

Connect the force sense interface unit and robot controller as shown below.



6.1.2.2 Force Sensors Manufactured by SINTOKOGIO, LTD.

Connect the force sense interface unit and robot controller as shown below.



6.2 Using Extended Functions of the Force Sensor

Insert the MELFA Smart Plus card or the MELFA Smart Plus card pack in the robot controller and set parameters and function codes to use extended functions of the force sensor such as the force sense wizard function and the learning function.

[When the robot controller software version is Ver.E4 or later]

When the robot controller software version is Ver.E4 or later, extended force sensor functions are available without the MELFA Smart Plus card or the card pack.

Steps (1) through (4) are not required.

Proceed to step (5).

(1) Turn OFF the robot controller power.

- CR800-D type : (1) Turn OFF the earth leakage breaker switch.
- CR800-R/Q type : (1) Turn OFF the robot CPU system power.
(2) Turn OFF the earth leakage breaker switch.

(2) Insert the "MELFA Smart Plus card" or "MELFA Smart Plus card pack" into the robot controller.


(For the corresponding model names, refer to "4.2 Software Versions 4.2.2 Extended function".)

(1) Pinch the interface cover removal lever and pull out the interface cover.

(2) Hold the pull of the MELFA Smart Plus card and insert it into SLOT1 or SLOT2.

At this time, insert the card so that the both ends of the card fit into the grooves of the slot (SLOT1 and SLOT2 in Fig. 7-6).

(3) Insert the connector fully into the slot until the removal lever is locked with clicking sound.



Note 1:
Refer to "4.2 Software Versions
4.2.2 Extended function". Check for details
of the card.

Fig. 6-1: Insertion of the MELFA Smart Plus card (MELFA Smart Plus card pack)



CAUTION

Insert only one MELFA Smart Plus card.

When multiple MELFA Smart Plus cards are inserted, the LED does not blink, and the error (L3782) occurs. For the error details, refer to "14.4 MELFA Smart Plus Card Related Error Details".

(3) Turn ON the robot controller power.

- CR800-D type : (1) Turn ON the earth leakage breaker switch.
(The POWER lamp of the robot controller blinks.)
- CR800-R/Q type : (1) Turn ON the earth leakage breaker switch.
(2) The POWER lamp of the robot controller blinks.
(3) After that, turn ON the robot CPU system power.

(4) When the MELFA Smart Plus card is used, enable extended functions of the force sensor by parameter setting

One of the functions supported by the card can be used. Change the setting of the parameter used to enable MELFA Smart Plus card and extended functions of the force sensor and reboot the robot controller.

Use the teaching pendant or RT ToolBox3 to set the parameters.

To use RT ToolBox3, connect it to the controller in which extended functions of the force sensor are to be enabled.

- (1) Change the setting value of the parameter "SMART+1" to [103].
- (2) Restart the robot controller.

- CR800-D type : Turn ON the earth leakage breaker switch.
- CR800-R/Q type : Turn OFF the robot CPU system power.
→ Turn OFF the earth leakage breaker switch.
→ Turn ON the earth leakage breaker switch.
→ Turn ON the robot CPU system power after the POWER lamp of the robot controller blinks.

- (3) The LED blinks in green when Extended function of force sensor is enabled.

[When using the MELFA Smart Plus card pack]

- Setting this parameter and restarting the robot controller are not required. Proceed to step (5).
- Check that the LED of the MELFA Smart Plus card pack blinks in blue.

(5) Set the function code of the MELFA Smart Plus card.

When the RT ToolBox3 version is Ver.2.70Y or later, the function code setting is not required.

Proceed to section 6.3.

[When setting the function code for RT ToolBox3 connected to the actual device]

- (1) Start RT ToolBox3 and connect it to the actual device.
- (2) Select [Option] in the [Workspace] tab in RT ToolBox3.
- (3) Select [MELFA Smart Plus] from the tree on the left of the Option window.
- (4) When the "Get function code" button is pressed, the function code of the MELFA Smart Plus card is input in the function code column.
- (5) Press the "OK" button and restart RT ToolBox3.




Fig. 6-2: Function code setting of the MELFA Smart Plus card (when connected to the actual device)

[When setting the function code for RT ToolBox3 not connected to the actual device]

- (1) Read the value of the parameter "MSPCODE" with the teaching pendant or RT ToolBox3 connected to the actual device. (The value of "MSPCODE" is the function code. It is not displayed when the MELFA Smart Plus card is not inserted.)
- (2) Note the displayed value of the parameter "MSPCODE" (24 alphanumeric characters).
- (3) In RT ToolBox3 not connected to the actual device, select [Option] in the [Workspace] tab. Select [MELFA Smart Plus] from the tree on the left of the Option window.
- (4) Input the function code of the MELFA Smart Plus card obtained at "Step 2" in the "Function code" column and press the Set button.
- (5) Press the "OK" button and restart RT ToolBox3.




Fig. 6-3: Function code setting of the MELFA Smart Plus card (when not connected to the actual device)

(6) Check that extended functions of force sensor is enabled.

- (1) Select [MELFA Smart Plus] - [Function list] from the tree on the left of the Option window.
- (2) The list of valid status of the MELFA Smart Plus functions is displayed on the right.
Check that the "Extended function of force sensor" state is "Enabled".





Fig. 6-4: Checking the state of the Extended function of force sensor

6.3 Force Sense Interface Unit ↔ Force Sensor


6.3.1 4F-FS002H-W200 and 4F-FS002H-W1000 Force Sensor Sets

Connect the force sense interface unit and force sensor as shown below.

<Robot with internal wiring> * RV-2FR is excepted.




<Robot with the forearm external wiring set option> * RV-2FR is excepted.



Refer to "Wiring and piping for hand" in the separate manual "Standard specifications" and "Installing the option devices" in separate manual "Robot arm setup and maintenance" for details on the cable connection.

<Standard robot>




6.3.2 4F-FS005H-IFUS Force Sensor Set

Connect the force sensor interface unit and force sensor manufactured by Canon Inc. as shown in the figure below.


The cable can only be routed on the outside of the robot. It cannot be routed internally.

Note that the cable of force sensors manufactured by Canon Inc. must be connected to the CN422_24V connector on the force sensor interface unit.

<When connecting standard robots (external) and force sensors manufactured by Canon Inc.>



<When connecting standard robots (external) and force sensors manufactured by SINTOKOGIO, LTD.>



6.4 Turning ON the Power

Turn ON the power only after checking that the force sense interface unit, robot controller, and force sensor have been properly connected. Turn the power ON and OFF in the following order.

<When turning the power ON>

Turn ON the power to the force sense interface unit followed by the robot controller (or simultaneously).

<When turning the power OFF>

Turn OFF the power to the robot controller followed by the force sense interface unit (or simultaneously).

(There is no need to turn OFF the force sense interface unit power if only the controller is ON.)



Caution

Do not disconnect the SSCNET III cable after turning ON the power. Furthermore, do not look directly at the light from the end of the SSCNET III connector or SSCNET III cable. Some discomfort may be experienced with direct exposure. (The SSCNET III light source is equivalent to the Class 1 source specified in JISC6802, IEC60825-1.)

6.5 Warm Up Operation

After the force sensor is started, the sensor output value may fluctuate due to heat generation of the internal circuit. Perform warm up operation for 10 to 30 minutes before use. The warm up operation means keeping a powered-on state.

■□■Precautions for use during warm up operation ■□■

For use during the warm up operation, while assuming the fluctuation of the sensor output value, perform an offset cancel frequently.

6.6 Default Parameter Settings

Set the following parameters after turning ON the power. (Using the parameter setting screen in RT ToolBox3 or on the R56TB/R86TB allows for efficient parameter setting. Refer to section [13.2](#), [13.3](#), and [13.4](#).)

After setting all parameters, reboot the controller. Settings are updated by rebooting.

Table 6-1: Default parameters


Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sense interface unit recognition	AXJNO	16 integers	Assigns the force sense interface unit connection. See section 6.6.1 for details on the setting method.	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
	AXMENO	16 integers		0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
Calibration	FSXTL	6 real numbers	Performs force sensor attachment calibration. See section 6.6.2 for details on the setting method.	0.0, 0.0, 0.0, 0.0, 180.0, 0.0 (vertical multi-joint robots)
	FSHAND	1 integer		0.0, 0.0, 0.0, 0.0, 0.0, 180.0 (horizontal multi-joint robots)
Force sensor tolerance	FSLMTMX	6 real numbers	Sets the force sensor tolerance. See section 6.6.3 for details on the setting method.	0
Force sense control offset limit	FSCORMX	2 real numbers	Sets the "maximum position offset" based on force sense control. See section 6.6.4 for details on the setting method.	0.0, 0.0, 0.0, 0.0, 0.0, 0.0
Force sensor data filter	FSFLCTL	1 real number	Sets the filter time constant for force sensor data control. See section 6.6.5 for details on the setting method.	10.0, 10.0
	HDFSFLJL	1 real number	Sets the force sensor data filter time constant that functions when MELFA High Drive is enabled. Refer to section 6.6.6 for information on the setting method.	1.7
Force sensor minimum control force	FSMINCTL	6 real numbers	Sets the minimum control force of the force sensor. See section 6.6.7 for details on the setting method.	5.00, 5.00, 5.00, 5.00, 5.00, 5.00
Selection of sensor	FSTYPE	1 integer	Used to select the sensor. Refer to section 6.6.8 for information on the setting method.	0.3, 0.3, 0.3, 0.03, 0.03, 0.03
Gravity direction	MEGDIR	4 real numbers	If the robot is installed on a wall or ceiling instead of the standard floor installation, the gravity direction must be set to match the installation. Gravity offset cancellation will not work properly if the settings are not correct. Example: 2, 0.0, 0.0, 0.0 for a ceiling-mounted robot For details, refer to the instruction manual "Detailed Explanations of Functions and Operations".	0
Base coordinate data for system	MEXSBS	6 real numbers	If the robot is installed on a wall or ceiling instead of the standard floor installation, the gravity direction must be set to match the installation. Gravity offset cancellation will not work properly if the settings are not correct. Example: 0 for a ceiling-mounted robot For details, refer to the instruction manual "Detailed Explanations of Functions and Operations".	0.0, 0.0, 0.0, 0.0, 0.0, 0.0

Each setting item is described below.

6.6.1 Force Sense Interface Unit identification

It is necessary to set parameters at the robot controller side in order for the robot controller to recognize the force sense interface unit. Set these parameters as follows. (The same parameters as that for the additional axis function are used.)

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Set axis No.	AXJNO	16 integers	Sets the force sense interface unit or additional axis number for the element corresponding to the servo control axis number being used. <If using force sense interface unit> Servo control axis No.: Set "9" for axis No.1.	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
Mechanical No. designation	AXMENO	16 integers	Enter a mechanical number corresponding to the servo control axis number being used. Always set "0" for axes that are not being used. <If using force sense interface unit> Servo control axis No.: Set "1" for axis No.1.	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
Servo amplifier model designation	AXAMPMDL	16 integers	Set the equipment to be connected in the element corresponding to the servo control axis number being used. 0: Force sense interface unit or MR-J4-B 1: MR-J5-B <If using force sense interface unit> Servo control axis No.: Set "0" for axis No.1. This parameter can be set when controller software version E4 or later is used.	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0



6.6.1.1 Parameter Setting for Using Additional Axis Functions

(1) Using Additional Axis Functions


AXJNO = (9, 7, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0)

AXMENO = (1, 1, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0)

AXAMPMDL = (0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0)

AXAMPMDL can be set when controller software version E4 or later is used. No setting is required for version E3 or earlier.

<Connection example>



The 1st station is used by the force sense interface unit, and therefore rotary switch 0 cannot be used for the additional axis (MR-J3B). Set to 1 or onward.

Up to 7 additional axes (from 2nd to 8th stations) can be used.

When using controller software version E4 or later and connecting a force sense interface unit, set the first axis of the AXAMPMDL parameter to "0".

(2) Not Using Additional Axis Functions

Set these parameters as follows if not using the additional axis functions.

AXJNO = (9, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0)

AXMENO = (1, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0)

6.6.2 Calibration

To use the force sense function, it is necessary to define (calibrate) the correlation between the force sensor coordinate system and force sense coordinate system (mechanical interface). Calibration is performed with the following parameter settings.



Caution

There is a danger that the robot may move in an unintended direction if the calibration settings are incorrect. After setting the parameters, always check that they have been set correctly by following the procedure in "Chapter 7".

Table 6-2: Details of parameters FSHAND and FSXTL

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sensor coordinate system selection	FSHAND	1 integer	<p>Selects the force sensor coordinate system hand system (left-hand system/right-hand system). The force sensor coordinate system hand system differs depending on the sensor attachment direction, and therefore it is necessary to change the setting based on the attachment direction. Settings also need to be changed depending on the type of sensor installed.</p> <p>0: Force sensor coordinate system left-hand system 1: Force sensor coordinate system right-hand system</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p><Left-hand system></p> </div> <div style="text-align: center;"> <p><Right-hand system></p> </div> </div>	0

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sensor attachment position	FSXTL	6 real numbers	<p>Sets the positional relationship between the force sensor coordinate system and the force sense coordinate system.</p> <p>1st element: X axis coordinate system origin offset [mm] 2nd element: Y axis coordinate system origin offset [mm] 3rd element: Z axis coordinate system origin offset [mm] 4th element: Coordinate system rotational angle [deg] around the X axis 5th element: Coordinate system rotational angle [deg] around the Y axis 6th element: Coordinate system rotational angle [deg] around the Z axis</p> <p>1st element to 3rd element: Set the offset from the mechanical interface coordinate system origin to the force sensor coordinate system origin. 4th element to 6th element: The angle to be specified depends on the setting of parameter FSHAND. Specify the rotational angle so that the force sense coordinate system (mechanical interface) [+FXm, +FYm, +FZm] matches the force sensor coordinate system [+FXs, +FYs, +FZs] when the setting is "0" (left-handed system). Specify the rotational angle so that the mechanical interface coordinate system [+Xm, +Ym, +Zm] matches the force sensor coordinate system [+FXs, +FYs, +FZs] when the setting is "1" (right-handed system). The rotation angle is applied in the following order: Around the Z axis, then around the Y axis, then around the X axis of the mechanical interface coordinate system.</p>	<p>0.0, 0.0, 0.0, 0.0, 180.0, 0.0 (vertical multi-joint robots)</p> <p>0.0, 0.0, 0.0, 0.0, 0.0, 180.0 (horizontal multi-joint robots)</p>




Fig. 6-5: Force sensor calibration

For more detailed setting methods, refer to the setting examples.


Table 6-3: Parameter setting examples

Setting example	Description	Reference
Parameter Setting Example 1	A parameter setting example for installing the force sensor included with the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets using the method specified in " 5.3 Recommended Attachment Angle ".	Section 6.6.2.1
Parameter Setting Example 2	A parameter setting example for installing the force sensors compatible with the 4F-FS005H-IFUS force sensor set using the method specified in " 5.3 Recommended Attachment Angle ".	Section 6.6.2.2
Parameter Setting Example 3	A parameter setting example for installing force sensors using a different method to that specified in " 5.3 Recommended Attachment Angle ".	Section 6.6.2.3

6.6.2.1 Parameter Setting Example 1

This section contains a parameter setting example for installing the force sensor included with the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets using the method specified in "5.3 Recommended Attachment Angle".

The parameter FSHAND and the 4th to 6th elements of parameter FSXTL are initialized to the factory default settings. Only the 1st to 3rd elements of parameter FSXTL should be changed.



[Coordinate system hand system]

The force sensor coordinate system will be the left-hand system, and should therefore be set as follows.

FSHAND = 0 (default)

[Parallel transfer]

The force sensor coordinate system origin position as viewed from the mechanical interface coordinate system is (0, 0, 32), and therefore the FSXTL settings are as follows.

FSXTL 1st element = 0
FSXTL 2nd element = 0
FSXTL 3rd element = +32

[Rotational transfer]

To align the posture of the force sense coordinate system (mechanical interface) and force sensor coordinate system, it is sufficient to rotate +180 degrees around the Ym-axis, and therefore the FSXTL settings are as follows.

FSXTL 4th element = 0 (default)
FSXTL 5th element = +180 (default)
FSXTL 6th element = 0 (default)

6.6.2.2 Parameter Setting Example 2

This section contains a parameter setting example for installing the force sensors compatible with the 4F-FS005H-IFUS force sensor set using the method specified in "5.3 Recommended Attachment Angle".

Refer to the force sensor coordinate systems below to set the parameter FSHAND.

Item	Specifications				
Force sensor manufacturer	Canon Inc.	SINTOKOGIO, LTD.			
Model	FH-300-20	ZYX080A501	ZYX080A501Z	ZYX100A102	ZYX125A102
Force sensor coordinate system	Right-handed system	Right-handed system	Right-handed system	Right-handed system	Right-handed system
FSHAND	1	1	1	1	1

Reference values for the origin offset value are shown in the table below.

Consider the installation position of the sensor attachment adapter before entering origin offset values.

Item	Specifications				
Force sensor manufacturer	Canon Inc.	SINTOKOGIO, LTD.			
Model	FH-300-20	ZYX080A501	ZYX080A501Z	ZYX100A102	ZYX125A102
FSXTL	X axis origin offset [mm]	0.00	0.00	0.00	0.00
	Y axis origin offset [mm]	0.00	0.00	0.00	0.00
	Z axis origin offset [mm] *1	8.55 + sensor attachment adapter thickness [mm]	13.50 + sensor attachment adapter thickness [mm]	16.00 + sensor attachment adapter thickness [mm]	18.50 + sensor attachment adapter thickness [mm]
	A axis rotational angle [deg.]	0.00	0.00	0.00	0.00
	B axis rotational angle [deg.]	0.00	0.00	0.00	0.00
	C axis rotational angle [deg.]	-90.00	180.00	180.00	180.00


*1: For the Z axis origin offset, enter the sum of the sensor thickness [mm] and the sensor attachment adapter thickness [mm].

The sensor attachment adapter thickness will be the thickness of the sensor attachment adapter created by the customer.

All the adapters from A to F indicated in section [3.11.2](#) are 14 [mm] thick.

This section contains a parameter setting example for when the following force sensor and sensor attachment adapter are used.

- Force sensor: FH-300-20 manufactured by Canon Inc.
- Sensor attachment adapter: Adapter A (Refer to section [3.11.2](#) for details.)



[Coordinate system hand setting]

The force sensor coordinate system will be a right-handed system. Therefore, configure the setting for FSHAND as follows.

FSHAND = 1

[Parallel movement]

The force sensor coordinate system origin position seen from the mechanical interface coordinate system is (0, 0, 22.55). Therefore, the setting for FSXTL is as follows.

FSXTL 1st element = 0
 FSXTL 2nd element = 0
 FSXTL 3rd element = +22.55

[Rotational movement]

To align the force sensor coordinate system with the mechanical interface coordinate system, it is necessary to rotate -90 degrees around the Zm axis. Therefore, the setting for FSXTL is as follows.

FSXTL 4th element = 0
 FSXTL 5th element = 0
 FSXTL 6th element = -90


6.6.2.3 Parameter Setting Example 3

A parameter setting example for installing force sensors using a different method to that specified in "[5.3 Recommended Attachment Angle](#)".

This section contains a parameter setting example for when the force sensor included with the 4F-FS002H-W200 and 4F-FS002H-W1000 force sensor sets is used.

The force sensor coordinate system differs depending on the sensor that will be installed. Take care when setting parameters.

If, as shown below, the force sensor coordinate system origin is offset 50 mm in the +Zm direction and rotated 30 degrees around the Zm-axis as viewed from the mechanical interface coordinate system, set the parameters as follows.



[Coordinate system hand system]

The force sensor coordinate system will be the left-hand system, and should therefore be set as follows.

FSHAND = 0

[Parallel transfer]

The force sensor coordinate system origin position as viewed from the mechanical interface coordinate system is (0, 0, 50), and therefore the FSXTL settings are as follows.

FSXTL 1st element = 0
 FSXTL 2nd element = 0
 FSXTL 3rd element = +50

[Rotational transfer]

To align the posture of the force sense coordinate system (mechanical interface) and force sensor coordinate system, it is sufficient to rotate +180 degrees around the Ym-axis after rotating +30 degrees around the Zm-axis, and therefore the FSXTL settings are as follows.

FSXTL 4th element = 0
 FSXTL 5th element = +180
 FSXTL 6th element = +30

6.6.3 Force Sensor Tolerance

The system is equipped with a function to stop robot operation in order to protect the force sensor if a value greater than that set for force and moment in parameter FSLMTMX is detected. Always set parameter FSLMTMX before use.

(* The default factory setting is 0, and therefore an "H7660" error will occur if this parameter is not set.)

Table 6-4: Sensor tolerance setting parameter

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sensor tolerance	FSLMTMX	6 real numbers	<p>Sets the force sensor tolerance. If sensor data exceeding the force and moment set at this parameter is detected, an error (H7660) occurs and the robot is stopped. (Force sense control will be disabled.)</p> <p>1st element: Force sensor data Fx tolerance [N] 2nd element: Force sensor data Fy tolerance [N] 3rd element: Force sensor data Fz tolerance [N] 4th element: Force sensor data Mx tolerance [N·m] 5th element: Force sensor data My tolerance [N·m] 6th element: Force sensor data Mz tolerance [N·m]</p>	0.0, 0.0, 0.0, 0.0, 0.0, 0.0

- * Set the minimum required tolerance for the work being performed, within the force sensor rated value. (Refer to section [3.10](#) for details on the force sensor rated value.)
- * The force sensor tolerance judgment is based not on the coordinate data converted with parameter FSXTL, but with raw data (with no offset cancel) sent from the force sensor.

<If force sensor tolerance exceeded>

If error H7660 occurs when the force sensor tolerance setting is exceeded, it will no longer be possible to turn the servo ON. In such a case, remedy the situation with either of the following method.

- (1) Temporarily clear the error from the T/B, and then retract the robot by JOG operation.
For the R32TB and R86TB, turning on the servos and performing JOG operation while the holding down the T/B [RESET] key temporarily clears the error and allows the robot to be moved.
In the case of R56TB, perform JOG operation while holding down the [CATION] key.
Move the robot to a position at which the error does not occur. (Refer to "Temporarily Resetting Errors that Cannot be Resolved" in instruction manual "Detailed Explanations of Functions and Operations" for more details.)



Caution

If a value larger than the force sensor rated value is applied, it may cause damage to the sensor.

6.6.4 Force Sensor Control Offset Limit

This parameter sets the position command offset upper limit for force sense control. If the offset exceeds this upper limit, an error (H2760) occurs. This acts as a protection function for inadequate operation or setting, and therefore the required minimum value should be set.

Table 6-5: Force sense control offset limit setting parameter

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sense control offset limit	FSCORMX	2 real numbers	Sets the maximum position offset for force sense control. 1st element: Position maximum offset [mm] 2nd element: Posture maximum offset [deg.] [Setting range] 1st element: 0 to +200.0 2nd element: 0 to +150.0	10.0, 10.0

6.6.5 Force Sensor Data Filter Setting

The force sensor data filter time constant can be changed. Sensor data that does not stabilize can be improved by increasing the time constant, however, as this affects force sense control characteristics, the default value should generally be used.

Table 6-6: Force sensor data filter setting parameter

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sensor data filter	FSFLCTL	1 real number	Sets the force sensor data filter time constant. [Unit]: ms [Setting range]: 0 to +1000.0	1.7

6.6.6 Force Sense Control Low Pass Filter Cutoff Time Constant When MELFA High Drive is Enabled

Enabling MELFA High Drive can improve the response of force sense control.

However, if the force sense control gain setting is high (15 or more), control can easily become unstable, and the robot will vibrate severely compared to when MELFA High Drive is disabled.

Such instances can be solved by increasing the force sense control filter time constant (HDFSFLJL). Increase the setting value while checking the operation until the vibration stops. (This parameter does not need to be adjusted when using materials such as metal or resin that easily absorb reaction forces as the force sense control gain setting is low enough.)

Refer to the instruction manual "Detailed Explanations of Functions and Operations" for details on MELFA High Drive.

Table 6-7: Force sense control filter time constant setting parameter

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sense control filter time constant	HDFSFLJL	1 real number	A cutoff time constant for the low-pass filter during force sense control that functions when MELFA High Drive is enabled. The lower the setting value the more responsiveness increases at the cost of increased vibration. Refer to the instruction manual "Detailed Explanations of Functions and Operations" for details on MELFA High Drive. [Unit]: ms [Setting range]: 0.00 to 1000.00	5.00, 5.00, 5.00, 5.00, 5.00, 5.00, 5.00, 5.00

6.6.7 Force Sensor Minimum Control Force

The minimum control force of force sensor can be changed.

Even if the force sensor does not touch the workpiece, etc. during force sense control, the robot may oscillate due to stationary noise of sensor data. In this case, increasing the minimum control force improves the problem. However, increasing the minimum control force widens the dead zone width. Therefore, the sensitivity of the force sense detection/force sense control will be deteriorated.

Table 6-8: Force sensor minimum control force parameter

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sensor minimum force control	FSMINCTL	6 real number	Sets the minimum control force of the force sensor. 1st element: Minimum control force of force sensor Fx [N] 2nd element: Minimum control force of force sensor Fy [N] 3rd element: Minimum control force of force sensor Fz [N] 4th element: Minimum control force of force sensor Mx [Nm] 5th element: Minimum control force of force sensor My [Nm] 6th element: Minimum control force of force sensor Mz [Nm]	0.3, 0.3, 0.3, 0.03, 0.03, 0.03

6.6.8 Selection of Sensor Setting

Configure the settings as shown below depending on the force sensor being used.

Table 6-9: Selection of sensor parameter setting

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting								
Selection of sensor	FSTYPE	1 integer	Set the sensor ID using a maximum of four digits. 1st element: Force sensor ID setting [Setting range]: 0 to 9999	0								
			<table><tr><th>Setting value</th><th>Force sensor</th></tr><tr><td>0</td><td>1F-FS001-W200/ 1F-FS001-W1000</td></tr><tr><td>100</td><td>ZYX080A501/ZYX080A501Z/ ZYX100A102/ZYX125A102 (SINTOKOGIO, LTD.)</td></tr><tr><td>200</td><td>FH-300-20 (Canon Inc.)</td></tr></table>		Setting value	Force sensor	0	1F-FS001-W200/ 1F-FS001-W1000	100	ZYX080A501/ZYX080A501Z/ ZYX100A102/ZYX125A102 (SINTOKOGIO, LTD.)	200	FH-300-20 (Canon Inc.)
			Setting value		Force sensor							
			0		1F-FS001-W200/ 1F-FS001-W1000							
			100		ZYX080A501/ZYX080A501Z/ ZYX100A102/ZYX125A102 (SINTOKOGIO, LTD.)							
200	FH-300-20 (Canon Inc.)											


7 Checking the Connection and Settings

Before using the force sense function, ensure that force sensor data is being sent to the robot controller in the correct coordinate system.


7.1 Checking Force Sensor Data Communication

Display the teaching pendant force sense control screen with the following operation, and ensure that the force sensor data is displayed correctly. If data does not show any change even when force is applied to the force sensor, there is a possibility that there is a problem with the device connection or parameter settings. If so, refer to "Chapter 6".


7.1.1 If Using R32TB



Menu screen



Extension function menu screen



Monitor mode

Ensure that the force sensor data changes.

7.1.2 If Using R56TB

If using the force sensor, an [F] button appears at the bottom of the JOG screen. By pressing this button, a force sense control screen appears on the left of the JOG screen. (If the [F] button does not appear, check the parameter settings in " section [6.6.1](#) ".)




Fig. 7-1: F button display




Fig. 7-2: Force sense control extension screen

7.1.3 If Using the R86TB

The force sense control option will appear in the lower section of the JOG operation guide when a force sensor is used. Clicking this button will display the force sense control screen to the left of the JOG operation guide. (If the force sense control options do not appear, check the parameter settings in section [6.6.1](#).)




Fig. 7-3: Force control option




Fig. 7-4: Force control screen

7.2 Checking the Force Sensor Attachment Coordinate System

Check force data when external force is applied by hand to the force sensor tool side. If set correctly, the correlation between the direction in which force is applied and the changed direction in the force data will be as shown in "Table 7-1". If the force data direction is different, check the calibration parameter settings in " section [6.6.2](#)".

Caution In the interest of safety, always perform this check with the servo power OFF.

Caution If tool coordinates are set, perform this check after disabling the tool designation. (Check after setting all parameter MEXTL setting values to 0.)




Table 7-1: Force direction check

	Direction in which Force Applied	Force Data Change
(1)	-Xm direction	Fx value changes to + direction.
(2)	-Ym direction	Fy value changes to + direction.
(3)	-Zm direction	Fz value changes to + direction.

8 Using the Force Sense Function (Programming)

This Chapter describes robot programming using the force sense function.

The force sense function consists of "force sense control", "force sense detection", and "force sense log" functions. Refer to the section numbers and pages under "Reference" in the following table for a "description" and "sample program" for each function. Contact your local sales representative for information on downloading the sample programs.

Table 8-1: Force sense function usage method reference list (programming)

Function Class		Function Overview	Reference	
			Description	Sample
Force sense control	Force control	Controls push force.	Section 8.1	Page 8-102
		Controls force and speed.		Page 8-103
	Stiffness control	Controls softness.		Page 8-105
	Limited stiffness control	Controls softness. Restricts the robot's force.		
	Control characteristics change	Changes control characteristics during robot movement.		Page 8-106
		Changes control characteristics in the trigger conditions.		Page 8-108
Force sense detection	Interrupt execution	Detects contact status and performs interrupt processing.	Section 8.2	Page 8-115
		Defines interrupt conditions and uses the conditions in the program.		Page 8-116
	Data latch / referencing	Latches force sense data and uses the data in the program.		Page 8-118
Force sense log	Log data acquisition	Acquires time series data during work.	Section 8.3	Page 8-130
	Log data display	Displays log data in a graph.		
	Log data transfer	Transfers log data to the FTP server.		Page 8-132
Gravity offset cancel		This function is the offset cancel in response to a change in the direction of gravity applied to the force sensor by hand load at the time of posture change.	Section 8.4	Page 8-133

8.1 Force Sense Control

The force sense control function is used to control robot softness and push force. Depending on the application, this function switches between "force control" and "stiffness control". The characteristics of each type of control are described below.

(1) Force control

This control mode controls the robot while pushing with a specified force. The robot moves automatically to the position at which the specified reaction force can be obtained.

The robot can be moved while pushing the workpiece with constant force and maintaining the contact status.

Force control has the following 2 modes.

<Speed priority mode>

If no contact has been made with the target object, the robot switches to speed control mode and moves at the specified speed toward the object.

<Force priority mode>

If contact has been made with the target object, the robot switches to force control mode and the robot is controlled in order that the specified reaction force can be obtained.

(2) Stiffness control/limited stiffness control

This control mode is used to control the robot softly like a spring. By applying external force, the robot moves automatically in the direction that allows it to escape the external force.

This type of control can be used to suppress the force acting on the workpiece when performing insertion work. Furthermore, the robot position is offset while following the assembly part shape, allowing teaching position displacements to be absorbed.

In the stiffness control, the reaction force will increase in proportion to displacement. If the reaction force is too large, please set the limit value for the reaction force using the stiffness control with limit.

(3) Position control

This control mode is used to control the robot position. Position control is applied to axes for which neither force control nor stiffness control are specified.

■□■ Offset and offset speed restrictions ■□■

The restrictions shown in "Table 8-2" are applied to positional offset and offset speed for force sense control. The positional offset restriction can be changed in parameter FSCORMX.

Table 8-2: Offset restrictions

	X,Y,Z	A,B,C	Remarks
Positional offset restriction	10 [mm]	10 [deg]	Can be changed in FSCORMX.
Speed offset restriction (Automatic)	80 [mm/s]	80 [deg/s]	
Speed offset restriction (Manual)	Approx.8 [mm/s]	Approx 8 [deg/s]	

■□■ Singular point adjacent operation restrictions ■□■

Singular point adjacent operation cannot be performed while force sense control is enabled, regardless of interpolation or JOG operation. If the robot approaches a point adjacent to a singular point during operation, an error (L3986) occurs. Use force sense control at a position that will avoid a singular point adjacent condition.

If necessary to move the robot adjacent to a singular point, or if wishing to pass through the singular point using the singular point pass function, disable the force sense function.

 Caution

By enabling force sense control, the robot moves automatically based on the external force acting on the sensor. Even if it seems that the robot has stopped at first glance, it may be moving at a very slow speed, and therefore attention should be paid to robot behavior while this function is enabled.

 Caution

Even if program operation is interrupted with an HLT command while force sense control is enabled, the force sense control enabled status is maintained, and therefore the robot may move. To stop the robot, it is necessary to perform the stop entry operation or disable force sense control.

 Caution

Always check "Chapter 5 before enabling force sense control. If there is a mistake with the connection or settings, the robot may move in an unintended direction.

 Caution

If resuming operation after an emergency stop condition or after interrupting program operation, a command to return the robot from its stationary position to the position when the program was interrupted is generated automatically. When force sense control is enabled, the difference between the position at which the program was interrupted and the actual stoppage position will be greater than that when force sense control is disabled, and therefore the robot may move significantly when operation is resumed.

* It is also possible to stop generation of the command to return the robot from to the position when the program was interrupted by changing the parameter RETPATH (setting for auto recovery after JOG feed when program interrupted), setting to "0". Refer to "Setting for Auto Recovery After JOG Feed when Program Interrupted" in instruction manual "Detailed Explanations of Functions and Operations" for details on the parameter RETPATH.

8.1.1 Force Sense Enable/Disable Commands

Force sense control is started with the MELFA-BASIC V/VI language Fsc On command based on conditions specified for arguments "Control mode", "Control characteristics ", and "Offset cancel command". (Refer to "Chapter [9](#) for details on operation from the teaching pendant.) Force sense control is disabled with the Fsc Off command. (Refer to "Chapter [12](#) for language details.)

Fsc On

[Function]

Enables the force sense control function using the force sensor.

[Syntax]

```
Fsc □ On, <Control mode>, <Control characteristics>, <Offset cancel designation>
```

[Terminology]

<Control mode>

Specify the control mode number for force sense control. (See section [8.1.2.](#))

Setting range: -1 to 9

<Control characteristics >

Specify the control characteristics number for force sense control. (See section [8.1.2.](#))

Setting range: -1 to 9

<Offset cancel command>

Specifies whether to cancel the force sensor data offset component.

(See section [8.1.3.](#))

Setting value: 0 (Do not cancel) / 1 (Cancel)

Fsc Off

[Function]

Disables the force sense control function using the force sensor.

[Syntax]

```
Fsc □ Off
```

[Terminology]

None

8.1.2 Control Mode / Control characteristics

When enabling force sense control, it is necessary to specify conditions for starting force sense control. Table 8-3 shows a list of setting items relating to force sense control conditions.

Table 8-3: Force sense control conditions

Setting Item	Description	Remarks
Force sense control coordinate system	Defines the coordinate system for force sense control. Select from Tool coordinate system/XYZ coordinate system.	
Force sense control mode	Selects the force sense control method for each force sense control coordinate system axis. Select from Positional control/Force control/Stiffness control/limited stiffness control.	
Stiffness coefficient	Sets the softness for axes for which stiffness control/limited stiffness control is selected. The greater the value, the stiffer the movement.	
Damping coefficient	Sets the responsiveness for axes for which force control or stiffness control/limited stiffness control is selected. Adjust if vibrations are experienced on contact.	
Force sensor bias value	Bias value of the force sensor is set. The bias value of the force sensor will be a constant offset occurring in the sensor in a no load. (by tightening at the time of installation a force sensor)	These values must be set only at the time of gravity offset cancel use. These values because these are set automatically by the force calibration function, so you do not need to be set again. (See section 8.4)
Load center of gravity position	Sets the center of gravity position of the load that attached to the force sensor.	
Load mass	Sets the mass of the load that attached to the force sensor.	
Force command value	Sets the force command for force control (force priority mode). The robot pushes with the specified force.	
Limit value	Sets the limit value for the limited stiffness control. Controls the robot's force within the setting value.	
Speed command value	Sets the speed command for force control (speed priority mode). Used at such times as wishing to specify the movement speed at times of no contact.	
Mode switching judgment value	Sets the speed/force control mode switching judgment value. This is valid only when a speed command value has been set.	
Force sense control gain	Sets the response sensitivity for axes for which force control/limited stiffness control or stiffness control is selected. Adjustment is required based on the stiffness of the target object.	
Force detection setting value	Sets the force detection setting value. This is used for the force sense detection and contact detection functions.	

As shown in "Table 8-4", these conditions are registered with parameters and status variables. Up to 11 types of settings can be registered for each setting item. (9 types of parameter, 2 types of status variable)

Table 8-4: Setting parameters and status variables for force sense control conditions

Setting Item		Description	Parameter	Status Variable
Control mode	<u>Force sense control coordinate system</u>	Specifies the coordinate system for force sense control. (See section 8.1.2.1.) 0: Tool coordinate system 1: XYZ coordinate system [Setting range]: 0, 1	FSCOD0#	M_FsCod0 M_FsCod1
	<u>Force sense control mode</u>	Selects the control mode for force sense control. (See section 8.1.2.2.) 0: Position control 1: Force control 2: Stiffness control 3: Limited stiffness control [Setting range]: 0, 1, 2, 3	FSFMD0#	P_FsMod0 P_FsMod1
	<u>Stiffness coefficient</u>	Specifies the stiffness coefficient for force sense control (stiffness control). (See section 8.1.2.3.) [Setting range]: 0.0 - 1000.0 [Setting unit]: X, Y, Z axes = N/mm A, B, C axes = N·m/deg (This setting is not required for axes for which stiffness control is not selected.)	FSSTF0#	P_FsStf0 P_FsStf1
	<u>Damping coefficient</u>	Sets the responsiveness for force sense control. (See section 8.1.2.4.) [Setting range]: 0.0 - 1.0 [Setting unit]: X, Y, Z axes = N/(mm/s), A, B, C axes = N·m/(deg/s)	FSDMP0#	P_FsDmp0 P_FsDmp1
	Force sensor bias value	Sets the force sensor bias value used for the gravity offset cancel. 1st element: Force sensor data Fx bias value [N] 2nd element: Force sensor data Fy bias value [N] 3rd element: Force sensor data Fz bias value [N] 4th element: Force sensor data Mx bias value [N·m] 5th element: Force sensor data My bias value [N·m] 6th element: Force sensor data Mz bias value [N·m] (These values because these are set automatically by the force calibration function, so you do not need to be set again.)	FSBIAS0#	P_FsBias0 P_FsBias1
	Load center of gravity position	Sets the load center of gravity position used for the gravity offset cancel. 1st element: Load center of gravity position X [mm] 2nd element: Load center of gravity position Y [mm] 3rd element: Load center of gravity position Z [mm] 4th element: Rotation angle of load center of gravity A [deg] 5th element: Rotation angle of load center of gravity B [deg] 6th element: Rotation angle of load center of gravity C [deg] (These values because these are set automatically by the force calibration function, so you do not need to be set again.)	FSGRP0#	P_FsGrPos0 P_FsGrPos1
	Load mass	Sets the load mass used for the gravity offset cancel. [Setting unit]: kg (These values because these are set automatically by the force calibration function, so you do not need to be set again.)	FSMASS0#	M_FsMass0 M_FsMass1

Control characteristics	<u>Force command value/limit value</u>	<p>The value has different roles in the force control and the limited stiffness control.</p> <p>[In the case of force control] Sets the force command for force sense control. (See section 8.1.2.5.) [Setting range]: - force sensor tolerance value to + force sensor tolerance value [Setting unit]: X, Y, Z component = N A, B, C component = N·m (This setting is not required for axes for which force control is not selected.)</p> <p>[In the case of the stiffness control with limit] Sets the limit value for the limited stiffness control. (See section 8.1.2.6.) [Setting range]: 0 to + force sensor tolerance value [Setting unit]: X, Y, Z, L1 component = N (L1 component sets the limit value for the resultant force.) A, B, C, L2 component = N·m (L2 component sets the limit value for the resultant moment.) (The value is not required in the axis that is not applying the limited stiffness control.)</p>	FSFCMD0#	P_FsFCd0 P_FsFCd1
	<u>Speed command value</u>	<p>Sets the offset speed used in force sense control (force control) speed priority mode. (See section 8.1.2.7.) [Setting range]: 0.0 - 50.0 (0.0 only for 7th and 8th elements) [Setting unit]: X, Y, Z component = mm/s A, B, C component = deg/s</p> <p>If set to 0.0, force control for that axis will always be in force priority mode. (This setting is not required for axes for which force control is not selected.)</p>	FSSPD0#	P_FsSpd0 P_FsSpd1
	<u>Mode switching judgment value</u>	<p>Sets the judgment value for switching between the force sense control (force control) speed priority and force priority modes. (See section 8.1.2.8.) [Setting range]: - force sensor tolerance value to + force sensor tolerance value [Setting unit]: X, Y, Z component = N A, B, C component = N·m If the setting is the same as the force command value (parameter FSFCMD0 1 – 09), the mode for force control will always be force priority for that axis.) (This setting is not required for axes for which force control is not selected.)</p>	FSSWF0#	P_FsSwF0 P_FsSwF1
	<u>Force sense control gain</u>	<p>Sets the response sensitivity for force sense control. (See section 8.1.2.9.) [Setting range]: 0.0 - 300.0 [Setting unit]: X, Y, Z axis component = 10^{-3} mm/N A, B, C axis component = 10^{-3} deg/(N·m)</p>	FSFGN0#	P_FsGn0 P_FsGn1
	<u>Force detection setting value</u>	<p>Sets the force detection setting for interrupt signals and data retention trigger for each coordinate axis. (See section 8.1.2.10.) [Setting range]: 0.0 - force sensor tolerance value [Setting unit]: X, Y, Z axis component = N A, B, C axis component = N·m</p>	FSFLMT0#	P_FsFLm0 P_FsFLm1

(# corresponds to group Nos. 1 to 9.)

- For those settings items that are underlined, setting is required for each coordinate axis of the force sense coordinate system. This corresponds to X, Y, Z, A, B, and C in this order from the 1st element of parameters and status variables. (Coordinate system definition is based on the "force sense control coordinate system".)
- There is no need to reboot the controller after writing parameters relating to control mode/control characteristics. (Settings are immediately updated.)
- Using the force sense function parameter setting screen in RT ToolBox3 or on the R56TB/R86TB allows for efficient parameter setting. (Refer to sections [13.2](#), [13.3](#), and [13.4](#).)

All parameter settings are classified by "condition groups" consisting of the control mode and control characteristics, and "condition Nos." constituting numbers -1 to 9. When specifying conditions with the Fsc On command, they are specified with a combination of these "condition groups" and "condition Nos."

Statement structure: Fsc□On, <Control mode>, <Control characteristics >, <Offset cancel designation>

If, for example, using the condition settings highlighted by the red boxes in Table 8-5 to start force sense control, set "1" for the "Control mode" argument and "-1" for the <Control characteristics > argument. (See section [8.1.3](#) for detail on <Offset cancel designation>.)



Table 8-5: Condition groups and condition Nos.

		Setting Item	Condition No.				
			-1	0	1	2 to 8	9
Condition group	Control mode	Force sense control coordinate system	M_FsCod1	M_FsCod0	FSCOD01	FSCOD0#	FSCOD09
		Force sense control mode	P_FsMod1	P_FsMod0	FSFMD01	FSFMD0#	FSFMD09
		Stiffness coefficient	P_FsStf1	P_FsStf0	FSSTF01	FSSTF0#	FSSTF09
		Damping coefficient	P_FsDmp1	P_FsDmp0	FSDMP01	FSDMP0#	FSDMP09
		Force sensor bias value	P_FsBias1	P_FsBias0	FSBIAS01	FSBIAS0#	FSBIAS09
		Load center of gravity position	P_FsGrPos1	P_FsGrPos0	FSGRP01	FSGRP0#	FSGRP09
		Load mass	M_FsMass1	M_FsMass0	FSMASS01	FSMASS0#	FSMASS09
	Control characteristics	Force command value/limit value	P_FsFCd1	P_FsFCd0	FSFCMD01	FSFCMD0#	FSFCMD09
		Speed command value	P_FsSpd1	P_FsSpd0	FSSPD01	FSSPD0#	FSSPD09
		Mode switching judgment value	P_FsSwF1	P_FsSwF0	FSSWF01	FSSWF0#	FSSWF09
		Force sense control gain	P_FsGn1	P_FsGn0	FSFGN01	FSFGN0#	FSFGN09
		Force detection setting value	P_FsFLm1	P_FsFLm0	FSFLMT01	FSFLMT0#	FSFLMT09

(# corresponds to group Nos. 2 to 8.)

8.1.2.1 Force Sense Control Coordinate System

The coordinate systems used with force sense control are specified from the following.

Tool coordinate system	XYZ coordinate system
<p>Force sense coordinate system (tool)</p>  <p>The coordinate system direction is the direction in which the tool coordinate system symbol is reversed, and the origin is the tool coordinate system origin.</p>	<p>Force sense coordinate system (XYZ)</p>  <p>The coordinate system direction is the direction in which the XYZ coordinate system symbol is reversed, and the origin is the mechanical interface coordinate system origin.</p>

8.1.2.2 Force Sense Control Mode

The force sense control mode is set for each axis. The characteristics of each mode are as follows.

Table 8-6: Force sense control mode characteristics

	Position Control Mode	Force Control Mode	Stiffness Control Mode/ Limited stiffness control
Control method	As with normal robot control, the robot is controlled with position commands.	The robot is controlled while pushing with a specified force. The force size and direction are set with the "Force command value".	Controls the robot softly. Softness is set with the "Stiffness coefficient". The limit value for the limited stiffness control is set with the "limit value".
Application	This is used in combination with force control and stiffness control.	Work involving pushing Grinding work	Fitting/insertion work Copying/teaching work


8.1.2.3 Stiffness Coefficient

Stiffness control/limited stiffness control softness is specified with the stiffness coefficient. The stiffness coefficient is the equivalent of spring constant, and the greater the value, the harder the control.

<Correlation between teaching position and reaction force>

If stiffness control mode is selected, when an external force acts on the arm tip, resulting in displacement between the teach position and actual position, the robot moves to a position at which the reaction force corresponding to the "displacement" and "stiffness coefficient" can be obtained.

In the following image, stiffness control is performed only for the tool Z-axis. By setting 0.5 [N/mm] for the Z-direction stiffness coefficient, and the teaching position at 5 mm below the contact surface, force F produced on the contact surface is calculated as follows.



$$F = 0.5 \text{ [N/mm]} \times 5 \text{ [mm]} = 2.5 \text{ [N]}$$

The smaller the stiffness coefficient, the smaller the reaction force, helping to deal with greater displacements.

When 0.0 is set with the stiffness coefficient, the reaction force is not generated in the case of the position is changed by external force.

When the limited stiffness control, the robot is controlled within the specified reaction force that is set with limit value.

8.1.2.4 Damping Coefficient


Vibrations that occur when applying positional offsets with force sense control (stiffness control, limited stiffness control, or force control) are adjusted with the damping coefficient. The greater the value, the greater the effect in suppressing vibrations, however, positional offsetting is delayed with sudden changes in force, resulting in a greater force applied the moment contact is made with the workpiece.

If required, damping coefficient adjustments should be made after force sense control gain adjustment is complete. (Vibrations also occur if the force sense control gain is too great.)

8.1.2.5 Force Command Value

Sets the force command value for force control (force priority mode). When force control is enabled, the robot moves so that the reaction force specified with the force command value can be obtained.

If no external force acts on the robot (if no contact is made), the robot moves in the force command value direction and reaction force direction (direction in which the specified force is produced when contact is made.)



<Example> The movement when force control mode is specified only for the FZt direction and the force command value is FZt = +5 N is as follows.


Table 8-7: Behavior corresponding to force command

	Robot Behavior
If contact made (if external force acting)	The robot is moved while offsetting its position until FZt = 5 N.
If no contact made (if no external force acting)	The robot moves in the +Zt direction so that external force is produced in the force command direction when contact is made. The movement speed is proportional to the force sense control gain x force command.

The movement speed when no external force is acting is dependent on the force sense control gain and force command. (The greater the force sense control gain and force command, the faster the movement.) If specifying the speed at this point, set the "Speed command value".

8.1.2.6 Limit value


Sets the limit value for the limited stiffness control. When an external force acts on the arm tip and the displacement occurs between the teach position and actual position while the limited stiffness control is enabled, the robot moves to a position at which the reaction force corresponding to the "displacement" and "stiffness coefficient" can be obtained. In the normal stiffness control, when the stiffness coefficient or displacement is increased, the reaction force becomes large. On the other hand, in the limited stiffness control, the force is automatically controlled so that the reaction force does not exceed the specified limit value. Since the limit is applied to the command value, as the value of the sensor may temporarily exceed the limit value.



8.1.2.7 Speed Command Value

Specifies the movement speed for force control (speed priority mode) when no contact is made with the target object. Use if performing work while automatically switching between speed control and force control, or to minimize impact by restricting the approach speed to the target object.

Set the switching condition for "speed priority mode" and "force priority mode" with the "Mode switching judgment value". If the speed command value is 0.0, priority mode switching is not performed. Force priority mode is always performed.



When 0.0 is set with the speed command value, the priority mode is not switched. The robot always operates in the force priority mode.



Caution

The speed specified with the speed command value is the force sense control offset speed, and not the actual robot movement speed. If the robot is not moving in other than in force sense control, such as when performing interpolation commands or JOG operation, but moving only in speed priority mode, the "specified offset speed = robot movement speed".

If interpolation commands or JOG operation are being performed in speed priority mode, the "(specified offset speed + speed specified for interpolation, JOG operation) = robot movement speed".

8.1.2.8 Mode Switching Judgment Value

Sets the threshold used for switching between "speed priority mode" and "force priority mode" when the speed command value is set for force sense control (force control).

The speed priority mode and force priority mode switch as follows based on the force command value and switching judgment value, and force sensor data magnitude correlation.

Table 8-8: Priority mode switching

Data Magnitude Correlation		Priority Mode	Applicable Area for Each Priority Mode
Force Command Value and Switching Judgment Value	Sensor Data and Switching Judgment Value		
Force command value > switching judgment value	Sensor data $\geq$ switching judgment value	Force priority mode	
	Sensor data < switching judgment value	Speed priority mode	
Force command value < switching judgment value	Sensor data $\leq$ switching judgment value	Force priority mode	
	Sensor data > switching judgment value	Speed priority mode	
Force command value = switching judgment value	-	Force priority mode	

<Force priority mode>

- Data from the force sensor is used to control the robot until the force specified with the force specification value is reached.
- The robot moves in the direction which satisfies the force specification value by following the axis direction for which force control is specified.
- The offset speed for force control is restricted to the speed command value or below.

<Speed priority mode>

- The robot is controlled so that the speed specified with the speed command value is reached.
- The robot moves in the direction which satisfies the force specification value by following the axis direction for which force control is specified.

Example: If the robot is moved toward the target object at 1.0 [mm/s] in the -Z direction with a force of 0.5 [N] until contact is made, and then 1.0 [N] is applied following contact:

- Force command value : (0.0, 0.0, 1.0, 0.0, 0.0, 0.0)
- Speed command value : (0.0, 0.0, 1.0, 0.0, 0.0, 0.0)
- Switching judgment value : (0.0, 0.0, 0.5, 0.0, 0.0, 0.0)

■□■ Mode switching judgment value setting ■□■

If the "force command value" and "mode switching judgment value" are near one another, sensor noise or vibrations may be generated while pushing with force control at a specified force, resulting in the possibility that switching between force priority mode or speed priority mode may occur unexpectedly. Adjust the judgment threshold to avoid sensor noise or vibrations while referring to the log data. Alternatively, use the FsGChg command or the FsCTrg command to change the control features.

8.1.2.9 Force Sense Control Gain

Force sense control gain is a parameter used to adjust the force sense control responsiveness. The higher the setting, the higher the force sense control responsiveness, however, increasing the value too much will result in an ultrasensitive response when contact is made, resulting in unstable operation.

Force sense control gain is affected by the stiffness of the target object, and therefore it is necessary to change the gain setting value based on the object. Adjust the gain setting value using the following method.

<Adjustment method>

- 1) Set 1.0 as an initial value to adjust the gain setting value to the axis which executes the force sense control.
- 2) Move the robot at low speed by JOG operation in the axis direction for which force sense control (force control/stiffness control/limited stiffness control) is enabled until contact is made with the target object. (speed override: approx. 5%)
- 3) If the robot rebounds in the opposite direction from the movement direction when contact is made, it is necessary to lower the gain setting value. (The gain setting value can be increased if the robot does not rebound.)

<Setting guide>

Target Object stiffness	Force Sense Control Gain
1.0 N/mm	50.0
10.0 N/mm	8.0
100.0 N/mm	1.0

If the force sense control gain setting is 0.0, offsetting with force sense control will not be performed. Control will be the same as normal position control (normal control). Control can be changed from position control to force control/stiffness control/limited stiffness control or vice versa by changing the gain setting value during robot movement. (Use the FsGChg command or the FsCTrg command.)

<When MELFA High Drive is enabled>

Enabling MELFA High Drive can improve the response of force sense control.

However, if the force sense control gain setting is high (15 or more), control can easily become unstable, and the robot will vibrate severely compared to when MELFA High Drive is disabled.

Such instances can be solved by increasing the force sense control filter time constant (HDFSFLJL). Increase the setting value while checking the operation until the vibration stops. (This parameter does not need to be adjusted when using materials such as metal or resin that easily absorb reaction forces as the force sense control gain setting is low enough.)

Refer to the instruction manual "Detailed Explanations of Functions and Operations" for details on MELFA High Drive.

8.1.2.10 Force Detection Setting Value

The force detection setting value is used with the following functions. Refer to the respective items.

Function Class		Description	Reference
Force sense detection	Interrupt execution	Monitors the status with regard to the force detection setting value. (The start-up and shut-down status with regard to the force detection setting value can be obtained.)	See section 8.2 .
	Data latch	Sensor data and position data at the moment the force detection setting value is exceeded is retained.	
Force sense control (T/B)	Contact detection	JOG operation is stopped the moment the specified force (moment) is exceeded.	See section 9.1 .

8.1.3 Offset Cancel Designation

To operate the force sense control function properly, it is necessary to perform a force/moment offset cancel (error component elimination) for each axis with no external force (robot stopped or with no contact made) other than gravity acting on the sensor.

The following two offset cancel methods are available.

	Offset Cancel Method	Details
1	Method using Fsc On command	Set "1" for the Fsc On command argument <Offset cancel designation>.
2	Offset cancel operation from T/B	See section 9.1.1.1 .

<Offset cancel conditions>

If performing offset cancel, always do so with the following conditions satisfied.

- Robot at complete stop
- No contact with hand/workpiece, etc. (no external force acting)



Caution

By performing an offset cancel with contact made (with external force other than gravity acting on sensor), the force balance will be upset, and force control/stiffness control will not function properly. Always perform the offset cancel with no contact made with the sensor.



Caution

If executing the Fsc On command when contact is made, disable the offset cancel designation. In a case such as this, it is necessary to perform the offset cancel at a position of no contact beforehand.



Caution

If the force sensor is used for a long time, the sensor's output value may be fluctuated by effect of the temperature drift. Create programs to execute the offset cancel periodically.

<Force sensor temperature drift>

If using the force sensor for long periods of time, sensor output values may fluctuate due the influence of temperature drift. Create a program to periodically perform offset cancel.

<Influence of gravity>

If changing the robot posture significantly, the force component applied to the sensor by gravity will change, resulting in the need to perform offset cancel again. If the posture changes significantly with each job, it is necessary to perform offset cancel again after the posture changes.

8.1.4 Control characteristics Change Commands

The "control characteristics " (force sense control gain, force specification value/limit value, speed command value, mode switching judgment value, force detection setting value) settings can be changed while force sense control is enabled using the MELFA-BASIC V/VI language FsGChg and FsCTrg commands.

Changing the "control characteristics " during movement facilitates work with a great degree of freedom. (The "control mode" cannot be changed until the Fsc Off command has been executed.)

Although the control mode setting cannot be changed until the Fsc Off command is completed, the stiffness coefficient and damping coefficient settings can be changed during force sense control using the status variable "M_FsCCSw".

These setting items can be changed using the FsGChng command or the FsCTrg command in the same way used for control feature. (This function is available with the controller software version A4 or later.)

For details of M_FsCCSw, refer to section 12.2

Refer to "Chapter [12](#) Language Specifications" for details on each command.

FsGChg (Fs gain change)

[Function]

Changes the control features of force sense control during movement.

[Syntax]

```
FsGChg □ <Change start position>, <Change time>, <Control features No. after change>
```

[Terminology]

<Change start position>

Specifies the position at which the change to the control features setting is started.

Specify with a percentage for the next interpolation start point → end point.

Setting range: 0 to 100 [%]

<Change time>

Specifies the time taken to change the control features setting.


The mode switching judgment value and force detection setting value changes immediately, regardless of this setting.

Setting range: 1 to 1000 [ms]

<Control features No. after change>

Specifies the control features value for which the force control gain, force command value, and force detection setting value, speed command value and mode switching judgment value are set after the change.

Setting range: -1 to 9



Example) in case of the change start position set at 30%

FsCTrg (FsC trigger)**[Function]**

Sets the control feature change for force sense control with an Mo trigger.

* If using the FsCTrg command, it is necessary to set the Mo trigger conditions beforehand.

[Syntax]

```
FsCTrg □ <Trigger No.>, <Change time>, <Control feature group No. after change>
                                     [, <Timeout>, <Execution method> [, <Error specification>]
```

[Terminology]**<Trigger No.>**

Specifies the Mo trigger No. used to change the control feature with a constant.

Setting range: 1 to 3

<Change time>

Specifies the time taken to change the control feature.

The force detection setting value and mode switching judgment value change immediately, regardless of this setting.

Setting range: 1 to 1000 [ms]

<Control feature group No. after change>

Specifies the control feature group No. applied after the change.

Setting range: -1 to 9

<Timeout>

Specifies the Mo trigger timeout monitoring time with a constant.

Setting range: 0 to 60 [s]

If omitted, timeout processing is not performed.

<Execution method>

Specifies the timeout monitoring execution method for this command with a constant.

0: Proceeds to next program without waiting for Mo trigger ON.

1: Does not proceed to next program until Mo trigger turns ON or timeout reached.

<Error specification>

Specifies whether an error occurs following a timeout.

0: An error occurs.

1: An error does not occur.

If omitted, an error occurs following a timeout.

By changing the control characteristics with the FsGChg command, the differences in changes to control characteristics made with the Mo trigger command are as follows.

Command	FsGChg Command	Mo Trigger Command (Def MoTrg/FsCTrg Command)
Trigger condition	Interpolation progress	Position command (orthogonal, joint) FB position (orthogonal, joint) Force sense position command Force sensor data (each axis, resultant force, resultant moment) Input signal (1-bit) Output signal (1-bit)
Change start timing	When interpolation progress for first interpolation command reaches specified value after executing FsGChg command.	When Mo trigger conditions defined with Def MoTrg command are satisfied
Restrictions	Changes are only possible while an interpolation command is being executed. To disable changes, it is necessary to disable force sense control.	If during operation, changes are possible regardless of whether an interpolation command has been executed. The change specification only can be disabled without disabling force control.

8.1.5 Usage Example (Force Sense Control)

This section describes the specific usage method for each function using sample programs.

<Control mode / control characteristics settings>

The sample programs described below set the "control mode" and "control characteristics " using status variables. The same settings are also possible using parameters and should be substituted as appropriate. (See following compatibility table.)

Setting Item		Status Variable (* = 0, 1)	Parameter (#=1 to 9)	Force Sense Control Mode			
				Position Control	Force Control	Stiffness Control	Limited stiffness control
Control mode	Force sense control coordinate system	M_FsCod*	FSCOD0#	○	○	○	○
	Force sense control mode	P_FsMod*	FSFMD0#	○	○	○	○
	Stiffness coefficient	P_FsStf*	FSSTF0#	×	×	○	○
	Damping coefficient	P_FsDmp*	FSDMP0#	×	△	△	△
	Force sensor bias value	P_FsBias*	FSBIAS0#	△	△	△	△
	Load center of gravity position	P_FsGrPos*	FSGRP0#	△	△	△	△
	Load mass	M_FsMass*	FSMASS0#	△	△	△	△
Control characteristics	Force command value	P_FsFCd*	FSFCMD0#	×	○	×	×
	Limit value			×	×	×	○
	Speed command value	P_FsSpd*	FSSPD0#	×	○	×	×
	Mode switching judgment value	P_FsSwF*	FSSWF0#	×	○	×	×
	Force sense control gain	P_FsGn*	FSFGN0#	×	○	○	○
	Force detection setting value	P_FsFLm*	FSFLMT0#	△	△	△	△

(○ : Setting required, △ : Set as required, × : No setting required)



Caution


The sample programs contained in this manual have been prepared for the purpose of understanding force sense functionality, and operation stability cannot be guaranteed. If using a sample contained in this manual on an actual system, please use with a sufficient understanding of the program content. Furthermore, the appropriate values for force sense control gain and damping coefficient, etc will vary greatly depending on the working environment, and therefore adjustments should be made with care.

8.1.5.1 Force Control 1

■ Operation details

The robot is pushed in the Z-direction with a force of 10 N.

- Force control is started from the PStart position.
- The robot is moved in the force sense control coordinate system (tool) +FZt direction until a reaction force of 10 N can be obtained.



■ Program example <Sample program F801.prg>

[Control mode (0)]	
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Stiffness coefficient [N/mm] ← No setting required
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Damping coefficient
P_FsMod0 = (+0.00,+0.00,+1.00,+0.00,+0.00,+0.00)(0,0)	'Force sense control mode (Z-axis force control)
M_FsCod0 = 0	'Force sense control coordinate system (tool)
[Control characteristics (0)]	
P_FsGn0 = (+0.00,+0.00,+30.00,+0.00,+0.00,+0.00)(0,0)	'Force control gain [μm/N] ← Adjustment required
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+10.00,+0.00,+0.00,+0.00)(0,0)	'Force command (10 N in FZt direction)
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets force/speed judgment value.
**** <Force control (Z-axis)> ****	
Servo On	
Mov PStart	'Move to start point.
Dly 1	
Fsc On,0,0,1	'Force sense control enabled (drop start with force control)
Dly 10	
Fsc Off	
End	

■ Description

- 1) The "control mode" and "control characteristics" are set at the beginning of the program. (In this example they are set with status variables, however, they can also be set with parameters.)
- 2) Force sense control is started with the Fsc On command based on the conditions set for "Control mode (0)" and "Control characteristics (0)". "Offset cancel" is performed to offset the sensor zero point.


* Adjust the force control gain based on the target object. The higher the setting, the higher the response sensitivity to the force command value, however, increasing the value too much may result in vibrations. (See section [8.1.2.9.](#))

8.1.5.2 Force Control 2 (Force-Speed Priority Mode Switching)

■ Operation details

The robot is moved at a speed of 5 mm/s in the tool Z-direction and pushed with a force of 10 N the moment it collides.

- Force control is started from the PStart position, and the robot is moved in speed priority mode at a speed of 5 mm/s in the tool Z-direction.
- The system detects when the force applies in the force sense coordinate system (tool) +FZt direction reaches 2.5 N or greater, switches to force priority mode, and pushes with a force of 10 N.



■ Program example <Sample program F802.prg>

```

[Control mode (0)]
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsMod0 = (+0.00,+0.00,+1.00,+0.00,+0.00,+0.00)(0,0)
M_FsCod0 = 0
[Control characteristics (0)]
P_FsGn0 = (+0.00,+0.00,+30.00,+0.00,+0.00,+0.00)(0,0)
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsFCd0 = (+0.00,+0.00,+10.00,+0.00,+0.00,+0.00)(0,0)
P_FsSpd0 = (+0.00,+0.00,+5.00,+0.00,+0.00,+0.00)(0,0)
P_FsSwF0 = (+0.00,+0.00,+2.50,+0.00,+0.00,+0.00)(0,0)

**** <Force control (force-speed hybrid)> ****
Servo On
Mov PStart
Dly 1
Fsc On,0,0,1
Dly 10
Fsc Off
End

```

'Stiffness coefficient [N/mm] ← No setting required

'Damping coefficient

'Force sense control mode (Z-axis force control)

'Force sense control coordinate system (tool)

'Force control gain [μm/N]

'Force detection setting value [N] ← No setting required

'Force command

'Sets speed control mode speed.

'Mode switching judgment value (switch threshold FZt=2.5N)

'Move to start point.

'Force sense control enabled (drop start with force control)

■ Description


- 1) Force sense control is started with the Fsc On command based on the conditions set for "Control mode (0)" and "Control characteristics (0)".
- 2) If the external force is less than the "mode switching judgment value (FZt=2.5N)" specified with the status variable P_FsSwF0, "speed priority mode" is applied and the robot moves at the speed specified with the status variable P_FsSpd0. The movement direction is the direction in which the reaction force specified with P_FsFCd0 can be obtained when contact is made.
- 3) If the external force is equal to or greater than the "mode switching judgment value (FZt=2.5N)", "force priority mode" is applied, and the robot pushes with the force specified with P_FsFCd0.

8.1.5.3 Stiffness Control

■ Operation details

Controls the robot softly like a spring with respect to external force applied in the force sense coordinate system (tool) $\pm F_{Xt}$ and $\pm F_{Yt}$ directions.

- Stiffness control is specified only for the F_{Xt} and F_{Yt} axes. (Position control is specified for all other axes.)
- The robot moves in the direction in which external force is received only on the X and Y planes. The robot moves to its original position when the external force is removed.



■ Program example <Sample program F803.prg>

```

[Control mode (0)]
P_FsStf0 = (+0.10,+0.10,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsMod0 = (+2.00,+2.00,+0.00,+0.00,+0.00,+0.00)(0,0)
M_FsCod0 = 0
[Control characteristics (0)]
P_FsGn0 = (+20.00,+20.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsFCd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)
**** <Stiffness control (X, Y-axes)> ****
Servo On
Mov PStart
Dly 1
Fsc On, 0, 0, 1
Hlt
Fsc Off
End

```

'Stiffness coefficient [N/mm]
'Damping coefficient
'Force control mode (X, Y-axis stiffness control)
'Force sense control coordinate system (tool)
'Force control gain [$\mu\text{m/N}$]
'Force detection setting value [N]
'Force command
'Sets speed control mode speed.
'Sets force/speed judgment value.
'Force sense enable
'Force sense disable

■ Description


- 1) Sets the robot softness with the status variable P_FsStf0 . The smaller the value, the softer (spring constant is small) the movement.
- 2) Force sense control is started with the Fsc On command based on the conditions set for "Control mode (0)" and "Control characteristics (0)". ("Offset cancel" is performed using the Fsc On command to offset the sensor zero point.)
- 3) The robot is controlled softly while the operation is interrupted by the Hlt command. When the operation is resumed, force sense control is then disabled and normal control mode is applied.

8.1.5.4 Control control characteristics Change 1

■ Operation details

The push force (control characteristics) is changed during robot movement.

- The robot starts moving from P1 to P2 while pushing with a force of 5.0 N in the Z-direction.
- The push force is increased gradually from areas with operating rate exceeding 50% until a final force of 12.0 N is reached.



■ Program example <Sample program F804.prg>

```
[Control mode (0)]
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Damping coefficient
P_FsMod0 = (+0.00,+0.00,+1.00,+0.00,+0.00,+0.00)(0,0)      'Force sense control mode (Z-axis force control)
M_FsCod0 = 0                                                  'Force sense control coordinate system (tool)

[Control characteristics (0)]
P_FsGn0 = (+0.00,+0.00,+4.00,+0.00,+0.00,+0.00)(0,0)        'Force control gain [μm/N]
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+5.00,+0.00,+0.00,+0.00)(0,0)        'Force command
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Sets force/speed judgment value.

[Control characteristics (-1)]
P_FsGn1 = (+0.00,+0.00,+4.00,+0.00,+0.00,+0.00)(0,0)        'Force control gain [μm/N]
P_FsFLm1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Force detection setting value [N]
P_FsFCd1 = (+0.00,+0.00,+12.00,+0.00,+0.00,+0.00)(0,0)       'Force command
P_FsSpd1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Sets speed control mode speed.
P_FsSwF1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Sets force/speed judgment value.

*** <Force control (control characteristics change)> ***

Spd 10
Servo On
Mvs P1, -3           'Moves to position 3 mm over contact position.
Dly 1
Fsc On, 0, 0, 1       'Force sense control enable
Dly 3
FsGChg 50,500, -1     'Set so that control characteristics changes to -1 at 50% position. (Change time: 500 ms)
Mvs P2
Fsc Off              'Force sense disable
End
```

■ Description


- 1) After the robot moves to the position 3 mm over the contact position, wait for 1 s until the robot comes to a complete stop.
- 2) Force sense control (force control) is started with the Fsc On command.
- 3) The control characteristics change conditions are specified with the FsGChg command. In this sample program, the control characteristics setting is changed gradually from "0" to "-1" over a period of 500 ms when the movement command position reaches the point between the movement start position and movement end position.
- 4) The control characteristics change starts at the midpoint (50% position) while moving to P2, and the force command value is increased gradually.

8.1.5.5 Control characteristics Change 2 (Mo Trigger)

■ Operation details

The robot moves while following a guide gauge.

- Movement is started in the +Y-direction at a speed of 10 mm/s while pushing in the -X direction with a force of 5 N.
- Contact with the +Y-direction wall surface is detected at position A, and robot movement changes to the +X-direction at a speed of 10 mm/s while pushing in the +Y direction with a force of 5 N.
- Movement stop when contact with the +X-direction wall surface is detected at position B.



■ Program example <Sample program F805.prg>

[Control mode (0)]	
P_FsStf0 = (+0.00,+0.10,+0.00,+0.00,+0.00,+0.00)(0,0)	'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Damping coefficient
P_FsMod0 = (+1.00,+1.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force sense control mode (X, Y-axis force control)
M_FsCod0 = 1	'Force sense control coordinate system (XYZ)
[Control characteristics (0)]	
P_FsGn0 = (+2.00,+2.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force control gain [$\mu\text{m/N}$]
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force detection setting value [N]
P_FsFCd0 = (-5.00,+5.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force command
P_FsSpd0 = (+0.00,+10.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+3.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets force/speed judgment value.
[Control characteristics (-1)]	
P_FsGn1 = (+2.00,+2.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force control gain [$\mu\text{m/N}$]
P_FsFLm1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force detection setting value [N]
P_FsFCd1 = (+5.00,+5.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force command
P_FsSpd1 = (+10.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets speed control mode speed.
P_FsSwF1 = (+3.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets force/speed judgment value.
*** <Force control-force direction change> ***	
Def MoTrg 1, P_FsCurD.Y>4.5	'Mo trigger 1 definition: Force sensor data Fy>4.5N
Mvs PStart	'Moves to start position.
Dly 1	'Wait until robot completely stopped.
Fsc On, 0, 0, 1	'Force sense enable
FsCTrg 1, 100, -1, 30, 0, 1	'Specify control characteristics change with Mo trigger.
*LBL1: If P_FsCurD.X < 4.5 Then GoTo *LBL1	
Fsc Off	'Force sense disable
End	

■ Description

- 1) Changes the control characteristics (force command direction, speed command when in speed priority mode) when the conditions specified for the Mo trigger are established using the FsCTrg command. (See section [8.2.1](#) for details on the Mo trigger.)
- 2) The Mo trigger is defined with the Def MoTrg command. In this example, Mo trigger condition 1 is established when $F_y > 4.5 \text{ N}$ is satisfied.
- 3) After moving to PStart, force control is started with the < Control characteristics (0)> conditions using the Fsc On command. The force direction and movement direction at this time are as follows.

Axis Direction	Movement Direction
X	Moves to the position where reaction force of $F_x = -5 \text{ N}$ can be obtained.
Y	Moves to the position where reaction force of $F_y = +5 \text{ N}$ can be obtained. However, if the reaction force is less than 3 N, the robot moves in speed priority mode to achieve a speed of 10 mm/s.
Z	No movement

- 4) When Mo trigger condition 1 is established (when position A is reached) with the FsCtrg command, the control characteristics is changed from "0" to "-1". The movement direction at this time is as follows. (The FsCtrg command has a timeout function, allowing an error to be generated if conditions are not established within the specified time.)

Axis Direction	Movement Direction
X	Moves to the position where reaction force of $F_x = +5 \text{ N}$ can be obtained. However, if the reaction force is less than 3 N, the robot moves in speed priority mode to achieve a speed of 10 mm/s.
Y	Moves to the position where reaction force of $F_y = +5 \text{ N}$ can be obtained.
Z	No movement

- 5) The system waits until position B is reached ($F_x \geq 4.5 \text{ N}$) using the If command, and force sense control is then stopped.

8.2 Force Sense Detection

The force sense detection function detects the robot contact status using force sensor information. By using this function, applications with high degree of freedom can be constructed in MELFA-BASIC VI to detect contact during movement, change the movement direction, detect work failures, and perform retry operation or error processing and so on.

<Features>

- 1) Trigger conditions combining force data and position data can be set. (Mo trigger)
- 2) Interrupt processing for start-up and shut-down conditions can be performed for force sensor data force detection setting values (set with Fsc On command conditions group (control characteristics)).
- 3) Sensor data and position data obtained when the force detection setting value is exceeded can be retained as status variables.
- 4) Current and maximum force sensor data values can be referenced.

Status variables for the force sense detection function are as follows.

Table 8-9: Force detection related status variables

Class	Status Variable	Function Overview
Mo trigger	M_MoTrg	Checks the Mo trigger status.
Force detection status	M_FsLmtS	Checks whether the force sensor data force detection setting value has been exceeded.
	P_FsLmtR	Checks the status of the current force sensor data with respect to the force sensor data force detection setting value.
Data latch	P_FsLmtX	Checks/resets axes for which the force sensor data force detection setting value is exceeded.
	P_FsLmtP	Checks/resets the robot FB position when the force sensor data force detection setting value is exceeded.
	P_FsLmtD	Checks/resets the force sensor data when the force sensor data force detection setting value is exceeded.
Data referencing	P_FsMaxD	Checks/resets the force sensor maximum data value during force sense control.
	P_FsCurD	Checks the current force sensor data.
	P_FsCurP	Checks the current position command offset with force sense control.
	M_FsRsltF	Checks the current force sensor resultant force.
	M_FsRsltM	Checks the current force sensor resultant moment.
	M_FsCSts	Checks the force sense control enabled/disabled status.
	M_FsRsltFMax	Checks/resets the maximum value of the force sensor resultant force data.(*1)
	M_FsRsltMMax	Checks/resets the maximum value of the force sensor resultant moment data.(*1)

➤ Refer to section [8.1.2](#) for details on force setting values.

➤ Refer to section [12.4](#) for details on status variables.

(*1) Available with the software version A4 or later.

8.2.1 Mo Trigger

The Mo trigger function is used to issue trigger signals when conditions are established based on conditions defined by combining the following data with a comparison operation. The Mo trigger status is output to status variable M_MoTrg.

Data	Description
Each P_Curr component	Robot current position (linear data)
Each P_Fbc component	Robot FB position (linear data)
Each J_Curr component	Robot current position (joint data)
Each J_Fbc component	Robot FB position (joint data)
Each P_FsCurP component	Position command after offsetting with force control
Each P_FsCurD component	Force sensor data (values after updating offset cancel, converting tool/XYZ coordinates)
M_FsRsltF	Force sensor data resultant force (values after updating offset cancel, converting tool/XYZ coordinates)
M_FsRsltM	Force sensor data resultant moment (values after updating offset cancel, converting tool/XYZ coordinates)
M_In	Input signal ON/OFF status
M_Out	Output signal ON/OFF status

By using this function, complicated trigger conditions can be specified for use with work completion judgment/interrupt processing when abnormal work is performed (DEF ACT command), and for changing force sense control characteristics (FsCTrg command), and so on.

To use the Mo trigger, define trigger conditions with the following procedure, and then start condition monitoring.

<Mo trigger setting procedure flow>

- (1) Define trigger conditions with the Def MoTrg command. Up to three types of conditions can be set.
- (2) Enable the Mo trigger with the SetMoTrg command.
- (3) Perform condition branching and interrupt processing using values output to status variable M_MoTrg.

* Procedures (2) and (3) are unnecessary if using FsCTrg command.



Refer to " Chapter [12](#) Language Specifications " for details on each command.

Def MoTrg (Def Mo trigger)

[Function]

Defines trigger conditions (Mo trigger) that reference position commands and the FB position, as well as force sensor data and so on.

[Syntax]

```
Def □ MoTrg □ <Trigger No.>, <Conditions>
```

[Terminology]

<Trigger No.> Specifies the defined Mo trigger No. with a constant.

Setting range: 1 to 3

<Conditions> Conditions under which the Mo trigger turns ON are described with the following syntax.

<Specification data> <Comparison operator> <Numerical data>

<Specification data> The following robot (system) status variables can be used.

- Status variables
All components of P_Curr, P_Fbc, J_Curr, J_Fbc, P_FsCurP, P_FsCurD,
M_FsRsItF, M_FsRsItM
- Input signal M_In
- Output signal M_Out

<Numerical data> The following constants and variables can be used.

- Numeric constants, numeric variables, numeric array variables
- Position variable component data
- Joint variable component data

* Up to four types of <Conditions> can be combined and used with And and Or operators.

[Example: (<Condition A> And <Condition B>) Or (<Condition C> And <Condition D>)]

SetMoTrg (Set Mo trigger)

[Function]

Enables/disables trigger conditions (Mo trigger) that reference position commands and the FB position, as well as force sensor data and so on.

[Syntax]

```
SetMoTrg □ <Trigger No.>
```

[Terminology]

<Trigger No.> Specifies the trigger No. for the Mo trigger to be enabled with a constant.

If 0 is specified, the Mo. Trigger is disabled.

Setting range: 0 - 3

M_MoTrg**[Function]**

References the Mo trigger enabled/disabled status, and the enabled trigger ON/OFF status.

[Syntax]

Example) <Numerical variable> = M_MoTrg (<Trigger No.>)

Value	Details		
	Defined/Undefined Status	Enabled/Disabled Status	Trigger ON/OFF Status
+1	Defined	Enabled	ON
0	Defined	Enabled	OFF
-1	Defined	Disabled	—
-2	Undefined	—	—

8.2.2 Force Detection Status

M_FsLmtS


Status variable M_FsLmtSw checks whether the force detection setting value specified with the " control characteristics " group has been exceeded. It can be used for interrupt processing and so on when a collision occurs.

(Refer to section [12.4](#) for details on status variables.)

P_FsLmtR

Status variable P_FsLmtR outputs the status for each axis based on the force detection setting value specified with the " control characteristics " group.

(Refer to section [12.4](#) for details on status variables.)



Sensor data absolute values are:
 (-2) Force detection value or less
 (+1) Conversion to value greater than force detection value
 (+2) Greater than force detection value
 (-1) Conversion to value less than or equal to force detection value

<Example 1>:

When the force in the X-direction exceeds the force detection setting value, the next command is skipped with an interrupt.

```
Mvs P2 Wthif P_FsLmtR . X = 1, Skip
```

< Example 2>:

When the force in the Z-direction becomes smaller than the force detection setting value, this status variable defines that interrupt processing is executed.

```
M1=-1
Def Act 1, P_FsLmtR.Z=M1 GoTo *PCEN, S
```

8.2.3 Data Latch

P_FsLmtX / P_FsLmtP / P_FsLmtD

Axis data, position data, and force sense data at the point the force sensor "force detection setting value" is exceeded is latched in status variables P_FsLmtX(), P_FsLmtP(), and P_FsLmtD().

(Refer to section [12.4](#) for details on status variables.)

8.2.4 Data Referencing

P_FsMaxD / P_FsCurD

The force sense data maximum and current values are stored in status variables P_FsMaxD() and P_FsCurD().

(Refer to section [12.4](#) for details on status variables.)

M_FsRsltFMax / M_FsRsltMMax

The maximum values of the force sensor resultant force data are stored in status variables M_FsRsltFMax and M_FsRsltMMax.

(Refer to section [12.4](#) for details on status variables.)

8.2.5 Usage Example (Force Sense Detection)

8.2.5.1 Interrupt Processing (M_FsLmtS)

■ Operation details

Abnormal force is detected at times of collision and the robot comes to an emergency stop.

- The force detection status is constantly monitored, and when contact is made, the robot is stopped swiftly and interrupt processing is executed.



■ Program example <Sample program F806.prg>

```

'[Control mode (0)]
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Damping coefficient
P_FsMod0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Force control mode (All axis position control)
M_FsCod0 = 0                                                  'Force sense control coordinate system (tool)

'[Control characteristics (0)]
P_FsGn0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Force control gain [μm/N]
P_FsFLm0 = (+50.00,+50.00,+50.00,+0.50,+0.50,+0.50)(0,0)    'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Force command
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Sets force/speed judgment value.
**** <Interrupt> ***

Def Act 1, M_FsLmtS=1 GoTo *XERR, F
Spd 10
Fsc On, 0, 0, 1                                             'Force sense enable (offset cancel designation)
Act 1=1                                                     ' Act 1 is enabled.
Mvs P1
Fsc Off                                                    'Force sense disable
End
*XERR
Act 1=0                                                       ' Act 1 is disabled.
Error 9100                                                    'Error occurrence
End

```

■ Description

When the force/moment exceeds the force detection setting value specified with the status variable P_FsFLm0, the status variable M_FsLmtS value changes from 0 to 1. By using this status variable M_FsLmtS as an interrupt signal, error processing can be performed when unnecessary force acts on the workpiece or sensor, and interrupt processing can be performed when a contact judgment/work failure occurs.

8.2.5.2 Interrupt Processing (Mo Trigger)

■ Operation details


The push force and position are inspected simultaneously, and the quality of the work is judged.

- Work is judged as being successful if the Z coordinate is less than 5 mm, and a reaction force greater than 18 N is detected in the FZt direction.
- If the above conditions are not satisfied within 5 seconds of assembly, assembly is judged as having failed, and an error is output.

Success



Failure



■ Program example <Sample program F807.prg>

[Control mode (0)]	
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Damping coefficient
P_FsMod0 = (+2.00,+2.00,+1.00,+0.00,+0.00,+0.00)(0,0)	'Force control mode (X,Y: stiffness control, Z: force control)
M_FsCod0 = 0	'Force sense control coordinate system (tool)
[Control characteristics (0)]	
P_FsGn0 = (+2.00,+2.00,+2.00,+0.00,+0.00,+0.00)(0,0)	'Force control gain [$\mu\text{m/N}$]
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.0,+0.0,+0.0)(0,0)	'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+20.00,+0.00,+0.00,+0.00)(0,0)	'Force command
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets force/speed judgment value.
**** <Interrupt> ***	
Def MoTrg 1, ((P_Fbc.Z <= 5) AND (P_FsCurD.Z > 18))	'Work complete conditions defined for Mo trigger 1.
Def Act 1,M_MoTrg(1)=1 GoTo *XOK,F	'Mo trigger 1 defined as interrupt condition.
Mvs PStart	'Robot moves over insertion position.
SetMoTrg 1	'Mo trigger 1 is enabled.
Fsc On,0,0,1	'Force sense control is enabled. (Insertion started with force control.)
Act 1=1	'Interrupt processing 1 is enabled.
M_Timer(1)=0	'Timer clear
*LBL1: If M_Timer (1) < 5000 Then GoTo *LBL1	'Waits for timeout time of 5 seconds.
Fsc Off	'Force sense control is disabled.
Error 9100	'Error occurs if insertion work not complete within 5 seconds.
End	
*XOK	'Insertion work complete interrupt processing
Act 1=0	
SetMoTrg 0	'Mo trigger is enabled.
Fsc Off	'Force sense control is disabled.
HOpen 1	
P2=P_Fbc	'Feedback position acquisition
P2.Z=P2.Z+100	'Target position determined as position +100 mm in Z-direction from current position
Mvs P2	

End

■ Description


- 1) Work complete conditions are defined for Mo trigger 1 with the Def MoTrg command.
- 2) Force sense control is enabled after enabling Mo trigger 1, and insertion work is started.
- 3) If insertion work is not complete within 5 seconds of work starting, a 9100 error is output, and insertion work is stopped.
- 4) If insertion work is successfully completed, M_MoTrg(1)=1, and interrupt processing (label: *XOK) is performed.

8.2.5.3 Data Latch/Data Referencing

■ Operation details

Position data and force data during push movement is latched, and the spring part spring constant is calculated.

- Data is set to that position and force data is saved at the point $FZ_t=10\text{ N}$ is exceeded. (Data latch function)
- The robot is moved to the final push position, and the spring constant is calculated from the current position and force data and data obtained with the data latch function.



■ Program example <Sample program F808.prg>

```
[Control mode (0)]
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Damping coefficient
P_FsMod0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Force control mode (all axis position control)
M_FsCod0 = 0                                                  'Force sense control coordinate system (tool)

[Control characteristics (0)]
P_FsGn0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Force control gain [μm/N]
P_FsFLm0 = (+200.00,+200.00,+10.00,+7.0,+7.0,+7.0)(0,0)    'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Force command
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Sets force/speed judgment value.

*** <Spring constant calculation> ***

Mvs PStart                                                    'Robot moves above start position.
Spd 10
Fsc On,0,0,1                                                  'Force sense control is enabled. (push start with force control)
Fine 100                                                      'Robot waits until positioning movement is complete.
Mvs PEnd
MFD=P_FsCurD.Z-P_FsLmtD.Z                                    'Force displacement calculation (N)
MPD=Abs(P_Fbc.Z-P_FsLmtP.Z)                                  'Spring displacement calculation (mm)
MSR=MFD/MPD                                                  'Spring constant is calculated (N/mm).
Fsc Off                                                       ' Force sense control is disabled.
End
```

■ Description

- 1) The force detection setting value is set and force control is enabled so that the position/force data are latched when $FZ_t=10\text{ N}$.
- 2) The robot is moved slowly to position PEnd at the speed of 10 mm/s and the spring is pushed.
- 3) Each of the position/force data at the moment the spring reaction force at the spring push process exceeds 10 N is saved to status variables P_FsLmtP and P_FsLmtD.
- 4) The current position/force data (P_Fbc, P_FsCurD) when the target position is reached is read, the amount of change from data saved during the movement is calculated, the spring constant is calculated, and then saved to variable MSR. (In this example, calculation is performed based on the assumption that the reaction force at the target position is sufficiently greater than 10 N.)

8.3 Force Sense log

The force sense log function is used to obtain and display log data such as force sensor data and position data. Log data can be viewed in a graph using the RT ToolBox3 force sense control log file viewer. This function can be used for such tasks as force sense control related parameter adjustments and checking the work status. Furthermore, this function is equipped with a feature to transfer force sense log files to the computer by FTP, facilitating robot quality control during operation by checking work quality and analyzing data when errors occur.

8.3.1 Force Sense Log Function Specifications

Table 8-10: Force sense log function specifications

Function	Item		Description
Force sense log data acquisition	Acquirable data		See Table 8-11
	Sample time		3.5 ms cycles (*If user mechanical is set, approx. 7.1 ms cycles)
	Max. data acquisition time		45 sec.* ¹
	Data acquisition trigger		Log data is acquired from the time the FsLog On command is executed until the FsLog Off command is executed.
	Data file format		CSV format (See Table Table 8-12.)
	No. of saved data files		2 * ² (Saved data is lost when the controller power is turned OFF.)
Force sense log data display (RT ToolBox3)	Graph display	Graph format	Scatter diagram format <Horizontal axis> Select from time, position commands, position FB, movement ratio. <Display data> Select from force sensor data, position commands, position FB, current FB.
		Display data qty	Vertical axis: 6, horizontal axis: 1
		Data processing	Filter processing (Filter processing is only possible for force sensor data.)
	Data operation		Force sense control log file reading from R/C
			Graph image backup
Force sense log file FTP transfer	Data transfer		Log files are saved to computer using FTP.

*1: If the Max. data acquisition time (45 s) is reached before the FsLog Off command is executed, data collection is automatically stopped.

*2: If the number of files stored in the controller exceeds 2, the file with oldest creation data is deleted.

Table 8-11: Collected data

Collected Data	Unit	Supplementary Information
Force sensor data	[N] or [Nm]	Set with parameter FSLOGFN from the following: <ul style="list-style-type: none"> • Force sensor raw data (with offset cancel) • Force sensor raw data (without offset cancel) • Data after coordinate conversion (with offset cancel) Fx, Fy, Fz, Mx, My, Mz
Position command	[mm] or [deg]	Command position Cmd-X, Cmd-Y, Cmd-Z, Cmd-A, Cmd-B, Cmd-C, Cmd-L1, Cmd-L2, Cmd-FL1, Cmd-FL2
Position FB	[mm] or [deg]	Feedback position FB-X, FB-Y, FB-Z, FB-A, FB-B, FB-C, FB-L1, FB-L2, FB-FL1, FB-FL2
Current FB	0.1%(Rated current ratio)	Motor current for each axis iFB-J1, iFB-J2, iFB-J3, iFB-J4, iFB-J5, iFB-J6, iFB-J7, iFB-J8

Table 8-12: Log file format (CSV)

Log File Version,1.0
Time Stamp,YYYY.MM.DD HH:MM:SS
Mecha No.,1
Robot Name,*****
Data Sampling,7.111ms
Sensor Data Type,2
Offset Cancel,-18.319,3.110,97.473,0.230,1.834,-0.787
Tool Data,0.000,0.000,0.000,0.000,0.000,0.000
Base Data,0.000,0.000,0.000,0.000,0.000,0.000
No.,Fx,Fy,...,Mz,Cmd-X,Cmd-Y,...,Cmd-FL2,FB-X,FB-Y,...,FB-FL2,iFB-J1,iFB-J2,...,iFB-J8
0,0.000,0.000,...,0.000,0.000,0.000,...,0.000,0.000,...,0.000,0.000,...,0.000
1,0.000,0.000,...,0.000,0.000,0.000,...,0.000,0.000,...,0.000,0.000,...,0.000
2,0.000,0.000,...,0.000,0.000,0.000,...,0.000,0.000,...,0.000,0.000,...,0.000
:
:

■ ■ ■ Base/tool conversion ■ ■ ■

- "Position commands" and "position FB" data are output in a coordinate system based on the tool/base conversion data specified when executing the PsLog Off command. (The applied tool/base conversion data is described at the beginning of the log file.)
- If the data is switched between tool and base or vice versa during log data collection, the position command/position FB before the change is not saved as a log file.

8.3.2 Parameter Settings

Parameter settings relating to the force sense log function are as follows.

It is necessary to set parameter FSLOGFN in order to use the force sense log function.

(Using the parameter edit screen shown in sections [13.2](#), [13.3](#), and [13.4](#) allows for efficient parameter setting.)

Table 8-13: Force sense log related parameter list

Parameter	Parameter Name	No. of Elements	Description	Default Factory Setting
Log function	FSLOGFN	3 integers	Specifies settings for the force sense log function. 1st element: Enables/disabled the log function. [Setting range] 0 (disable), 1 (enable) 2nd element: Selects the collected force sensor data type. [Setting range] 0: Raw data (with offset cancel) 1: Raw data (without offset cancel) 2: Data after coordinate conversion (offset cancel designation updated) 3rd element: Specifies whether to use/not use FTP. [Setting range] 0 (Do not use), 1 (Use)	0, 2, 0
Log data transfer	FTPID	1 character string	Sets the user ID used with FsOutLog command FTP communication. 1st element: user ID Setting range: Up to 8 single-byte alphanumeric characters (upper/lower case)	ftpuser
	FTPPASS	1 character string	Sets the password used with FsOutLog command FTP communication. 1st element: password [Setting range] Up to 16 single-byte alphanumeric characters (upper/lower case), or single-byte symbols (! # \$ % & = - @ . ? _)	ftppassword
	FTPSVRIP	1 character string	Sets the FTP server IP address used with FsOutLog command FTP communication. 1st element: IP address [Setting range] "0.0.0.0" to "255.255.255.255"	192.168.0.99

8.3.3 Force Sense Log Data Acquisition

Robot language MELFA-BASIC VI FsLog On and FsLog Off commands are used to specify the start and end of log data acquisition. When the FsLog Off command is executed, a log file with specified file No. name is generated.

(Refer to section "[12.5](#)" for details on language specifications.)

FsLog On

[Function]

Starts force sensor data and position command, position FB, and current FB value logging.

[Syntax]

```
FsLog □ On
```

FsLog Off

[Function]

Ends force sensor data and position command, position FB, and current FB value logging.

[Syntax]

```
FsLog □ Off <Log File No.>
```

[Terminology]

<Log File No.> Specifies the log file No. containing collected data.
Setting range: 1 to 999999999

8.3.4 Force Sense Log Data Display (RT ToolBox3)

The method used to display force sense log data in a graph using the RT ToolBox3 force sense control log file viewer function is described below.

8.3.4.1 Start Method

Select [Tools] → [Force Sensor] → [Force Sense Control Log File Viewer] in the RT ToolBox3 workspace to display the force sense control log file viewer screen.




Fig. 8-1: Start method when using force sense control log file viewer




Fig. 8-2: Force sense control log file viewer main screen

8.3.4.2 Main Screen

Log files are imported and displayed in a graph using the buttons on the force sense control log file viewer main screen. A description of each button is given below.






Fig. 8-3: Image of force sense control log file viewer main screen

Table 8-14: Main screen description

No.	Item	Description
(1)	[Read RC] button	<div>By pressing this button when the R/C (robot controller) is connected online, the following screen appears, allowing the user to read log files selected from a log file list to the computer.</div> <div></div>

No.	Item	Description
		<p>By pressing the [Read RC] button and reading a log file with the [Copy File] check box selected, a log file save screen appears after reading the log file.</p> <p>Specify the file save destination and file name, and then click [OK] to save the read log file to the computer.</p> 
(2)	[Select File] button	<p>By pressing this button, the following screen appears, allowing the user to read log files selected from the log file list.</p> 
(3)	[Select Data] button	<p>Displays a "Data Selection Screen" used for displaying data in a graph. This button can be used after selecting a log file. (See " 8.3.4.3 Data Selection Screen ".)</p>
(4)	[Display Range] button	<p>Displays a screen used to set the maximum and minimum values for the graph horizontal and vertical axes. This button can be used after selecting a log file. (See " 8.3.4.4 Display Range Setting Screen ".)</p>
(5)	[Save] button	<p>Converts content in the display area to a bitmap file and saves it to the computer.</p>

8.3.4.3 Data Selection Screen

Selects data displayed at the following Data Selection screen. If separating the graph into Graph 1 and Graph 2, select the "Graph 2" check boxes for data to be displayed in Graph 2.

Select Data

Horizontal Axis: Time(sec) Const Num on Filter(ms): 0.000

Graph Output

Graph2:

Data#1: ☐ Sensor Data Fx Data#4: ☐

Data#2: ☒ Position Cmd X Data#5: ☐

Data#3: ☐ Data#6: ☐

☐ Auto Adjust Ver Axis ☐ All Check Graph2

OK Cancel

Fig. 8-4: Data Selection screen

Table 8-15: Data Selection screen description

No.	Item	Description
(1)	Graph horizontal axis	Select data to be used for the graph horizontal axis from a combo-box. [Selectable data] Time Position command: 1 from X, Y, Z, A, B, C, L1, or L2 Position FB: 1 from X, Y, Z, A, B, C, L1, or L2 Movement ratio: 1 from X, Y, Z, A, B, or C
(2)	Graph output	Select the data to be displayed in Graph 1 from a combo-box. (Max. 6 types) Select the respective "Graph 2" check boxes to display in Graph 2. [Selectable data] Force sensor data: Fx, Fy, Fz, Mx, My, Mz Position command: X, Y, Z, A, B, C, L1, L2 Position FB: X, Y, Z, A, B, C, L1, L2 Current FB: J1, J2, J3, J4, J5, J6, J7, J8 Raw sensor data: Fx, Fy, Fz, Mx, My, Mz (Values for which filter in (3) below does not apply.)
(3)	Filter time constant	Specify the filter time constant used for force sensor data filter processing. (Use to eliminate the influence of noise.) [Setting range] 0.00 to 2000.00 ms (When 0.00 is specified, filter processing is not performed.)
(4)	Automatically adjust vertical axis range.	When selected, the vertical axis display range is automatically adjusted.

8.3.4.4 Display Range Setting Screen

Sets the range for the displayed waveform data from the [Display Range] screen.




Fig. 8-5: Image of Display Range setting screen

Table 8-16: Display Range setting screen description

No.	Item	Description
(1)	Vertical axis display range setting	Specifies the maximum and minimum values for the Graph 1 horizontal axis. If adjusting the Graph 2 display range, select the "Adjust Graph 2" check box. By pressing the [Reset] button, the horizontal axis maximum and minimum values return to their default settings.
(2)	Horizontal axis display range setting	Specifies the maximum and minimum values for the Graph 1 vertical axis. If adjusting the Graph 2 display range, select the "Adjust Graph 2" check box. By pressing the [Reset] button, the vertical axis maximum and minimum values return to their default settings.
(3)	Automatically adjust vertical axis range.	When selected, the vertical axis display range is automatically adjusted.

8.3.5 Force Sense Log File FTP Transfer

Force sense log files created in the robot controller can be transferred to an FTP server using the robot language MELFA-BASIC VI FsOutLog command.

FsOutLog

[Function]

Transfers logged data to the FTP server.

[Syntax]

```
FsOutLog □ <Log File No.>
```

[Terminology]

<Log File No.> Specifies the No. of the log file from which collected data is to be read.
Setting range: 1 to 999999999


The following preparations are required before the FsOutLog command can be executed.

(1) Network connection with Ethernet

Connect the robot controller and FTP server computer over the network with an Ethernet cable.

<CR800-R Series connection example>

With the CR800-R Series robot controller, FTP communication uses the robot CPU unit "DISPLAY I/F". Prepare a hub and Ethernet cable and connect to the network as shown below.



(2) FTP related parameter settings

Sets parameters FTPID, FTPPASS, FTPSVRIP, and FSLOGFN.
(Refer to section [8.3.2](#) for details on parameters.)

(3) FTP server preparation

Start up the FTP server on the target computer.


8.3.6 Usage Example (Force Sense Log)

8.3.6.1 Force Sense Log Data Acquisition and Display

■ Operation details

Acquires data for the force acting on the workpiece when performing assembly work and displays it in a graph.

- Pin insertion work is performed after starting force sense log data acquisition.
- After work is complete, force sense log data acquisition is terminated and log data acquired during work is saved.
- Acquired log data is displayed in a graph using the RT ToolBox3 force sense control log viewer function.



■ Program example <Sample program F809.prg>

'[Control mode (0)]	
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Damping coefficient
P_FsMod0 = (+1.00,+1.00,+1.00,+0.00,+0.00,+0.00)(0,0)	'Force control mode (X,Y,Z-axis force control)
M_FsCod0 = 0	'Force sense control coordinate system (tool)
'[Control characteristics (0)]	
P_FsGn0 = (+5.00,+5.00,+5.00,+0.00,+0.00,+0.00)(0,0)	'Force control gain [μ m/N]
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+5.00,+0.00,+0.00,+0.00)(0,0)	'Force command (X,Y-axes: 0.0 N, Z-axis: 5.0 N)
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets force/speed judgment value.
'*** <Log data acquisition> ***	
Mov PStart	
Dly 1	
FsLog On	'Force sense log data acquisition start
Fsc On, 0, 0, 1	'Force sense control enable (offset cancel designation)
*LBL1: If P_FsCurD.Z < 4.5 Then Goto *LBL1	
Fsc Off	'Force sense control enable
FsLog Off ,999	'Log file creation (File name: 999.fsl)
End	'

■ Description


- 1) Specifies settings to push the robot with a force of 0.0 N in the X- and Y-directions, and 5.0 N in the Z-direction with force control.
- 2) The FsLog On command is executed to start log data acquisition.
- 3) Insertion work is started with the Fsc On command, and the robot pushes until a reaction force of 4.5 N or greater acts in the Z-direction.
- 4) The FsLog Off command is executed to end log data acquisition. (The log data file name is set for the argument.)
- 5) Measurement data is displayed in a graph using the RT-ToolBox3 "force sense control log file viewer" to check the force acting on the workpiece. (See section [8.3.4](#) for details on how to use the force sense control log file viewer.)

8.3.6.2 Force Sense Log Data Transfer

■ Operation details

Transfers acquired log data files to the computer (FTP server).

- Force sense log data is collected during force sense control.
- Force sense log data is saved and saved log files are transferred to the computer.



■ Program example <Sample program F810.prg>

```

[Control mode (0)]
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Stiffness coefficient [N/mm]
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)      'Damping coefficient
P_FsMod0 = (+1.00,+1.00,+1.00,+0.00,+0.00,+0.00)(0,0)        'Force control mode (X,Y,Z-axis force control)
M_FsCod0 = 0                                                  'Force sense control coordinate system (tool)
[Control characteristics (0)]
P_FsGn0 = (+0.00,+0.00,+5.00,+0.00,+0.00,+0.00)(0,0)        'Force control gain [μm/N]
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+5.00,+0.00,+0.00,+0.00)(0,0)        'Force command (X,Y-axes: 0.0 N, Z-axis: 5.0 N)
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)        'Sets force/speed judgment value.
'*** < Log data acquisition > ***
Mov PStart
Dly 1
FsLog On
Fsc On, 0, 0, 1                                             'Force sense control enable (offset cancel designation)
Dly 10
Fsc Off                                                     'Force sense control enable
M1=Val(Left$(C_Time,2) + Mid$(C_Time,4,2) + Right$(C_Time,2)) 'Converts current time to numerical variable.
FsLog Off, M1                                              'Log file creation (File name: HHMMSS.fsl)
FsOutLog M1                                                'Log file transfer
End

```

■ Description

- 1) Starts log data acquisition by executing the FsLog On command.
- 2) Ends log data acquisition by executing the FsLog Off command. (The log data file name is set for the argument. In this example, the current time is used to create the file name.)
- 3) The acquired log file is transferred to the computer by executing the FsOutLog command. (See section [8.3.4.](#))

8.4 Gravity Offset Cancel Function

Gravity offset cancel is a function that the offset cancel in response to a change in the direction of gravity applied to the force sensor by hand load at the time of posture change. To use this function, it is necessary to estimate the bias value of the force sensor, position of the center of gravity and the mass of hand load by the force calibration.

8.4.1 Estimated data

The data estimated by the force sensor calibration function is explained below.

- (1) Force sensor bias value
- (2) Load center of gravity position
The center of gravity position of the load attached the force sensor.
- (3) Load mass
The mass of the load attached the force sensor.

8.4.2 About Calibration Posture

The force calibration is required nine posture shown in Table 8-17. It shows the movement image of the posture No. 1 to 5 in Fig. 8-6.

Table 8-17: Posture for force calibration

Posture No.	Condition
1	Posture that the mechanical interface is parallel to the ground.
2	Posture rotated in the +X-axis around the mechanical interface with respect to posture No.1.
3	Posture rotated in the -X-axis around the mechanical interface with respect to posture No.1.
4	Posture rotated in the +Y-axis around the mechanical interface with respect to posture No.1.
5	Posture rotated in the -Y-axis around the mechanical interface with respect to posture No.1.
6	Posture rotated in the +X-axis around the mechanical interface with respect to posture No.1. * Rotate at different angle from posture No.2.
7	Posture rotated in the -X-axis around the mechanical interface with respect to posture No.1. * Rotate at different angle from posture No.3.
8	Posture rotated in the +Y-axis around the mechanical interface with respect to posture No.1. * Rotate at different angle from posture No.4.
9	Posture rotated in the -Y-axis around the mechanical interface with respect to posture No.1. * Rotate at different angle from posture No.5.




Fig. 8-6: Movement image of force calibration



Caution

Set the angle smaller than reference value if the robot interfere with the peripheral device or the tension of air hose attached to hand of various cable changes by the robot's posture change and load is applied to force sensor other than gravity.

8.4.3 Calibration Procedure

Estimation by the force calibration has the following two ways.


- 1) Estimated using the force calibration screen. (See section [8.4.3.1](#))
- 2) Estimated using the robot program. (See section [8.4.3.2](#))

8.4.3.1 Estimated Using the Force Calibration Screen


- 1) Specify the program name for the calibration

Select [Tool] -> [Force sensor] -> [Force sensor calibration] from the project tree, Please Start force calibration screen. Please input the program name for the force calibration in the force calibration start screen.

(Input program is generated automatically, and execute force calibration. After calibration is complete, the program will be removed from the controller.)




- 2) Specify the control mode number that becomes a storage destination on the calibration results.
Please Specify the control mode number (1-9) to store the results, which is estimated by the calibration execute. In this screen, select the control mode number to store the results from the drop-down list. At the time of gravity offset cancel, data storage destination specified by the control mode number is used.



3) Register the start position

Please register the start position for force calibration. Set the position at which the mechanical interface of robot is parallel to the ground to the start position. In force calibration, rotate the X-axis and Y-axis around the mechanical interface. Please adjust the start position to the position that does not interfere with the peripheral device.

After moved the robot to near the start position, Please click [Auto adjustment] button. The robot moves to position the mechanical interface is parallel to the ground. After moved the robot to the start position, Please click [Get the current position] button. The current position of the robot is registered.




⚠ Caution

If [Auto adjustment] button is clicked, robot moves. Please check the safety of around the robot. If the override is greater than 10 %, override is changed to 10% for safety.

Please prepare T/B to stop anytime in the emergency.

4) Specify the rotary angle for calibration movement

Please specify the rotary angle from the start position. In force calibration, the robot is rotated by a specified angle twice in the X-axis and Y-axis around the mechanical interface to the start position.



! Caution

Set the angle smaller than reference value if the robot interfere with the peripheral device or the tension of air hose attached to hand of various cable changes by the robot's posture change and load is applied to force sensor other than gravity.

! Caution


If the rotary angle is below 10[deg], calibration calculation error can occur. In that case, set the rotary angle large and re-execute the calibration.

! Caution

If the angles of movement 1 and movement 2 are same value, calibration results are not calculated correctly. Set the different angle to movement 1 and movement 2.

5) Confirm the posture for calibration

Confirm the robot movement to 9 calibration movement data automatically made from the start position and rotary angle data to use [Position jump] button. After select the movement position in the movement position data list, please click [Position jump] button and confirm the robot movement.


**Caution**

If [Position jump] button is clicked, robot moves. Please check the safety of around the robot. If the override is greater than 10 %, override is changed to 10% for safety.

Please prepare T/B to stop anytime in the emergency.

6) Execute the calibration movement

Please execute the robot program for force calibration. If [Start operation panel] button is clicked, operation panel is started that the force calibration program is selected. Please click [Start] button from operation panel and start the calibration. If the calibration is completed, calibration result (hand's weight and center of gravity position) is displayed after the showing of complete message. Please click [Finish] button and end the calibration.



⚠ Caution

If [Start] button is clicked, robot moves. Please check the safety of around the robot. If the override is greater than 10 %, override is changed to 10% for safety. Please prepare T/B to stop anytime in the emergency.

⚠ Caution

If the movement speed of robot increases, calibration precision decreases. Do not change default override value as much as possible.

⚠ Caution

When you click [Finish] button to exit the force calibration, the program used in the calibration will be removed from the controller.

8.4.3.2 Estimated Using the Robot Program

Using the robot program estimate the mass and the position of the center of gravity of the hand load. If you want to estimate a robot program, use the following commands. Please refer to Chapter 12.6 for details commands.

Table 8-18: Gravity offset cancel commands

No.	Command	Function Overview
1	FsHndEst On	To begin the processing of the force calibration.
2	FsHndEst Off	To estimate the force calibration result, to complete the process.
3	FsGetDat	To get the data (current position and the force sensor data) required to the force calibration.

The force calibration by executing the following robot program, estimate the hand load.

■ Program example

```

*** < Force sense calibration execution > ***
Dim PP(9)
Servo On
Mov PP(1)                                'Robot moves to the start point.
Dly 1
FsHndEst On,0                            'Execute the calibration
For M1=1 To 9 Step 1
  Mov PP(M1)                             'Robot moves to the calibration posture
  Dly 1.5                                ' Wait until the robot stops
  FsGetDat M1                            'The current position and force sense data acquisition
  Mov PP(1)                              'Robot moves to the start point.
  Dly 0.5
Next M1
FsHndEst Off                             'Calibration is completed. Estiamte the load.
End

```


8.4.4 Usage Example (Gravity offset cancel)

8.4.4.1 Gravity offset cancel

■ Operation details

Estimates the mass and the center of gravity position of the hand by the force sensor calibration function.

- Execute the force sensor calibration.
- Enable the force sensor control that is enabled the gravity offset cancel.



■ Program example < Sample Program F811.prg >

'[Control mode (0)]	
P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Stiffness coefficient [N/mm] ← No setting required
P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Damping coefficient
P_FsMod0 = (+0.00,+0.00,+1.00,+0.00,+0.00,+0.00)(0,0)	'Force control mode (Z-axis force control)
M_FsCod0 = 0	'Force sense control coordinate system (tool)
'[Control characteristics (0)]	
P_FsGn0 = (+0.00,+0.00,+10.00,+0.00,+0.00,+0.00)(0,0)	'Force control gain [$\mu\text{m}/\text{N}$]
P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Force detection setting value [N]
P_FsFCd0 = (+0.00,+0.00,+10.00,+0.00,+0.00,+0.00)(0,0)	'Force command (FZt direction, 10N)
P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets speed control mode speed.
P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)	'Sets force/speed judgment value.
*** < Force sense calibration execution > ***	
Dim PP(9)	
Servo On	
Mov PP(1)	'Robot moves to the start point.
Dly 1	
FsHndEst On,0	'Execute the calibration
For M1=1 To 9 Step 1	
Mov PP(M1)	'Robot moves to the calibration posture
Dly 1.5	
FsGetDat M1	'The current position and force sense data acquisition
Mov PP(1)	'Robot moves to the start point.
Dly 0.5	
Next M1	
FsHndEst Off	'Calibration is completed. Estimate the load.
Fsc On,0,0,1	'Force sens control is enabled
Dly 10	
Fsc Off	'Force sens control is disabled
End	

■ Description

- 1) The "control mode" and "control characteristics " used after the calibration are set at the beginning of the program.
- 2) The force sense calibration is started with the FsHndEst On command.
- 3) After the robot moves to each calibration posture, the current position, the posture, and the force sensor data are obtained with the FsGetDat command.
- 4) The force sense calibration is completed with the FsHndEst Off command and the mass and the center of gravity position of the hand are estimated.
- 5) The force sense control in which the gravity offset is cancelled using the data estimated with the Fsc On command is enabled.

* Details for the FsHndEst command and FsGetDat command, see section [12.6](#).

9 Using the Force Sense Function (Teaching)

This Chapter describes how to use the force sense function (force sense T/B) using the teaching pendant, and how to perform teaching using the force sense function.

Refer to the section numbers and pages under "Reference" in the following table for a "description" and "usage example" for each function.

Table 9-1: Force sense function usage method reference list (teaching)

Function Class		Function Overview	Reference	
			Description	Usage Example
Force sense T/B	Force sense control (T/B)	Controls push force and softness.	Section 9.1.1	Page 9-155
	Force sense monitor	Checks force sense data.	Section 9.1.2	Page 9-157
	Contact detection	Checks the contact position.	Section 9.1.3	
Teaching		Teaches the push position.	Section 9.2	Page 9-163
		Teaches the insertion position (using force control).		Page 9-165
		Teaches the insertion position (using stiffness control).		Page 9-166

9.1 Force Sense T/B

The force sense functions that can be used from the R32TB, R56TB, and R86TB are listed in Table 9-2.

Table 9-2: Force sense functions that can be used from teaching pendant

Force Item		Function Overview
Force sense control (T/B)	Force control	Pushes with the specified force using force control.
	Stiffness control	Controls the robot softly like a spring.
Force sense monitor	Force sense data display	Displays the force sensor data current value on the T/B.
	Max. value retention	Retains the force sensor data maximum value. (Resetting is possible.)
Force sense monitor	Automatic stop	Stops the robot automatically when contact is detected during JOG operation.
	Buzzer sound	Sounds the buzzer when the contact detection threshold is exceeded.

Each function is described below.

9.1.1 Force Sense Control (T/B)

JOG operation using force sense control can be performed from the teaching pendant. Force sense control facilitates more precise teaching operations such as controlling the robot softly to the assembly position while escaping external force, and teaching positions pushed with a fixed force. (See section [8.1](#) for details on force sense control.)

If performing JOG operation while using force sense control, use the following procedure to sufficiently check the setting status before turning the servo ON.

[Turning the servo ON when force sense control is enabled]

Step 1: Offset cancel operation (See section [9.1.1.1](#).)

...Ensure that the force sensor offset component has been cancelled.



Step 2: Control mode/control characteristics selection (See section [9.1.1.2](#).)

...Ensure that the used control mode/ control characteristics have been set correctly.



Step 3: Force sense control enabled/disabled selection (See section [9.1.1.3](#).)

...Check the force sense control enabled/disabled status.



Servo ON

9.1.1.1 Offset Cancel Operation


If the force sensor data zero point is offset, force sense control will not function properly. Always perform the **offset cancel operation (sensor zero point offset)** before use. The offset cancel operation can only be performed when force sense control is disabled.

[Offset cancel operation]


- Move the robot to a position at which no external force acts on the sensor (position at which no contact is made with hand, etc.)
- Ensure that the robot is stationary and then perform the offset cancel operation. (See diagram below).

R32TB

[JOG] key




[FUNCTION] key




JOG operation screen

[F3] key: Force sense



R56TB



Force Control: ON OFF ON/OFF Run

Control Mode: -1 Control Feature: -1

FD(*1) Param.	Current	Maximum
Fx:	2000.000	0.000
Fy:	2000.000	0.000
Fz:	2000.000	0.000
Mx:	200.000	0.000
My:	200.000	0.000
Mz:	200.000	0.000

(*1): Force Detection

Offset Cancel Reset Max.


Joint: J1: 0.000 J2: 0.000 J3: 133.000 J4: 0.000 J5: **** J6: **** J7: 0.000

CAV ON

Sensor zero point offsetting is performed by pressing the [Offset Cancel] button.

By pressing the [F] key, a force sense control screen appears.

R86TB



Force Control: Mode 0 Feature 0 Teach Position Search

FD Param.	Current	Maximum
Fx	2000.000	0.000
Fy	2000.000	0.000
Fz	2000.000	0.000
Mx	200.000	0.000
My	200.000	0.000
Mz	200.000	0.000

FD:Force Detection

Offset Cancel Reset Max.

Force Control Limit Release

Tap the [Offset Cancel] button to correct the sensor zero point.

Tapping the [Force Control] button will display the force control screen.

■□■ Offset cancel operation precautions ■□■

- The offset cancel status is reset by rebooting the controller. If the controller is rebooted, perform the offset cancel operation again.
- The effects of gravity are contained in the sensor offset component, and therefore if the robot arm posture is changed significantly, it is necessary to perform the offset cancel operation again.
- The offset amount may change if used for long periods of time due to changes in sensor temperature (temperature drift). In such a case, perform the offset cancel operation again.

9.1.1.2 Selecting the Control Mode/Control characteristics

Before enabling force sense control, it is necessary to set the force sense control "control mode" and "control characteristics" (parameters/status variables shown in Table 9-3) beforehand. (See section 8.1.2 for details.)

Table 9-3: Control mode/Control characteristics settings

Setting Item		Status Variable (*=0, 1)	Parameter (#=1 - 9)	Default Factory Setting
Control mode	Force sense control coordinate system	M_FsCod*	FSCOD0#	0
	Force control mode	P_FsMod*	FSFMD0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
	Stiffness coefficient	P_FsStf*	FSSTF0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
	Damping coefficient	P_FsDmp*	FSDMP0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
Control characteristics	Force command value (force control)	P_FsFCd*	FSFCMD0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
	Limit value (Limited stiffness control)			
	Speed command value	P_FsSpd*	FSSPD0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
	Mode switching judgment value	P_FsSwF*	FSSWF0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
	Force sense control gain	P_FsGn*	FSFGN0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00
	Force detection setting value	P_FsFLm*	FSFLMT0#	0.00, 0.00, 0.00, 0.00, 0.00, 0.00

[Control mode/ Control characteristics selection operation]

- Specify the used "control mode" and "control characteristics" number.
- Ensure that the numbers used have been set correctly before enabling force sense control.

R32TB

JOG operation screen

[FUNCTION] key

IF3] key: Force sense


IF2] key: Conditions

Condition settings screen

R56TB

By pressing the [F] key, a force sense control screen appears.

Specify the "control mode" and "control features" number.



9.1.1.3 Force Sense Control Enable/Disable Selection

Enable or disable force sense control. If performing JOG operation using force sense control, select "Enable", and if performing normal JOG operation, select "Disable".

The enable/disable selection is common to both automatic operation and JOG operation. The enable/disable status is retained even if the controller mode is changed between MANUAL and AUTOMATIC.

<Example 1>

Force sense control enabled in automatic operation. → Operation interrupted. → Change the controller mode to MANUAL. → T/B enabled. → Force sense control enabled status retained.

< Example 2>

Force sense control enabled with T/B. → T/B disabled. → Change the controller mode to AUTOMATIC. → Force sense control enabled status retained.

However, if the enabled/disabled status differs when interrupting and resuming robot program automatic operation, error L3986 occurs when resuming operation.



Caution

The force sense control enable/disable status is retained even when automatic operation is stopped and the operation mode changed to MANUAL mode. Perform teaching after checking the force sense control enable/disable status, and control mode/control characteristics settings sufficiently.

[Force sense control enable/disable operation]

- Enable/disable force sense control with the ON/OFF button. (See below.)
- The enabled/disabled status is displayed on the T/B screen. (See below.)

R32TB

[FUNCTION] key

JOG operation screen

[F3] key:

Force sense

[F1] key: Enables/disable force sense control with ON/OFF button.

R56TB

Force Control

ON OFF ON/OFF

Control Mode -1

Control Feature -1

Force Monitor


FD(*1)	Param.	Current	Maximum
Fx	000.000	0.000	0.000
Fy	2000.000	0.000	0.000
Fz	2000.000	0.000	0.000
Mx	200.000	0.000	0.000
My	200.000	0.000	0.000
Mz	200.000	0.000	0.000

(*1): Force Detection

Offset Cancel Reset Max.

By pressing the [F] key, a force sense control screen appears.

Enable/disable force sense control with ON/OFF button.





9.1.2 Force Sense Monitor

Displays the force sensor current and maximum values. Retained maximum values can also be cleared.

[Checking the force sensor data current/maximum values]

- The force sensor data current and maximum values are shown below.
- The coordinate system for the displayed sensor data is based on the force sensor coordinate system set for the "control mode".







9.1.3 Contact Detection

If the force sense data exceeds the selected "control characteristics" force detection setting value while force sense control is enabled, JOG operation is automatically stopped. Furthermore, the buzzer sounds and the force sensor data display field on the teaching pendant changes color to notify the user that the force detection setting value has been exceeded.


[Contact detection operation]

- Set the threshold value used to detect the contact status for the "control characteristics" force detection setting value. (See section 9.1.1.2.)
- Enable force sense control. (See section 9.1.1.)
- If the force sensor data exceeds the force detection setting value during JOG operation, operation is stopped and the buzzer sounds.
- The currently selected force detection setting value appears on the teaching pendant. (See below.)



By pressing the [F] key, a force sense control screen appears.

Displays the currently selected detection setting value.



■□■ Contact detection precautions ■□■

- When the robot is stopped by contact detection, the robot moves from the point the force is detected until the robot stops, and therefore a larger force than the force detection setting value may act.
- If JOG operation is stopped when the force detection setting value is exceeded, check the force sensor data value and then move the robot in the direction that the acting force becomes smaller.
- If the force detection setting value is greatly exceeded while force sense control is enabled, it will not longer be able to perform JOG operation. (Slight movement is possible.) In such a case, disable force sense control, and then move the robot by JOG operation. When doing so, take caution not to move in a direction in which a large force acts.

9.1.4 Usage Example (Force Sense Function T/B)

9.1.4.1 Force Sense Control T/B (Force Control)

■ Operation details

The robot is pushed with a force of 20 N in the Z-direction (tool coordinates) with the teaching pendant.



■ Operation procedure

(1) Parameter settings

- Set the "control mode" and "control characteristics" so that the robot is pushed with a force of 20 N in the tool Z-direction. (See table below.)
- The settings can be easily configured using the dedicated screen in RT ToolBox3 (or on the R56TB or R86TB). Furthermore, parameters relating to the control mode/control characteristics are updated immediately, and therefore there is no need to reboot the controller. (See section [13.2](#).)

Control mode	Force sense control coordinate system	FSCOD01	0
	Force control mode	FSFMD01	+0.00, +0.00, +1.00, +0.00, +0.00, +0.00
	Stiffness coefficient	FSSTF01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Damping coefficient	FSDMP01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
Control characteristics	Force command value	FSFCMD01	+0.00, +0.00, +20.00, +0.00, +0.00, +0.00
	Speed command value	FSSPD01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Mode switching judgment value	FSSWF01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Force sense control gain	FSFGN01	+0.00, +0.00, +5.00, +0.00, +0.00, +0.00

(* In this example, settings are specified with parameters, however, setting is also possible with status variables.)

(2) Offset cancel operation (See section [9.1.1.1](#).)

- Perform force sensor zero point offset.
 - * Perform offset cancel with no external forces acting other than gravity.

(3) Control mode/control characteristics selection (See section [9.1.1.2.](#))

- Set the "control mode" and "control characteristics" numbers. In this example, control mode 1 and control characteristics 1 are used, and therefore the settings are as follows.

[R32TB]

<FORCE> PARAMETER	
CONTROL MODE	(1)
CONTROL FEATURE	(1)
	123
	CLOSE


(4) Force sense control enable operation (See section [9.1.1.3.](#))

- Turn the servo ON after enabling force sense control.
- Force sense control is enabled and the robot moves automatically to the position at which a reaction force of 20 N can be obtained. Movement is also possible with normal JOG operation while force sense control is enabled.

9.1.4.2 Contact Detection/Force Sense Monitor

■ Operation details

JOG operation is stopped automatically if unnecessary force acts on the workpiece. Check the maximum value for force applied to the workpiece.



■ Operation procedure

(1) Parameter settings

- When inserting, stiffness control (stiffness coefficient = 0) is specified only in the X- and Y-directions to ensure that the robot can move freely in response to the reaction force.
- Set the "force detection setting value" so that the robot stops following contact detection when a force of 5 N or more acts in the FXt, Fyt, or FZt directions, and a moment of 0.05 N·m or more acts in the MXt, MYt, or MZt directions. (See table below.)

Control mode	Force sense control coordinate system	FSCOD01	0
	Force control mode	FSFMD01	+2.00, +2.00, +0.00, +0.00, +0.00, +0.00
	Stiffness coefficient	FSSTF01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Damping coefficient	FSDMP01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
Control characteristics	Force command value	FSFCMD01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Speed command value	FSSPD01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Mode switching judgment value	FSSWF01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Force sense control gain	FSFGN01	+1.50, +1.50, +0.00, +0.00, +0.00, +0.00
	Force detection setting value	FSFLMT01	+5.00, +5.00, +5.00, +0.05, +0.05, +0.05

(* In this example, settings are specified with parameters, however, setting is also possible with status variables.)

(2) Offset cancel operation (See section [9.1.1.1.](#))

- Perform force sensor zero point offset.
 - * Perform offset cancel with no external forces acting other than gravity.

(3) Control mode/control characteristics selection (See section [9.1.1.2.](#))

- Set the "control mode" and "control characteristics" numbers. In this example, control mode 1 and control characteristics 1 are used, and therefore the settings are as follows.

[R32TB]

<FORCE> PARAMETER	
CONTROL MODE	(1)
CONTROL FEATURE	(1)
	123
	CLOSE

(4) Force sense control enable operation (See section [9.1.1.3.](#))

- Turn the servo ON after enabling force sense control, and then use JOG operation to move the robot to the insertion complete position.
- JOG operation is stopped automatically if unnecessary force acts on the workpiece. (The buzzer also sounds.)

(5) Force sense monitor (See section [9.1.2.](#))

- Check the force sense data maximum value with the force sense monitor.

9.2 Teaching Operation

This Chapter describes teaching operation using force sense control.

■□■ Teaching operation precautions ■□■

If using force sense control, the position displayed on the teaching pendant and the actual robot position will differ. This will affect teaching operation, and therefore it is necessary to have a proper understanding of the information in section [9.2.1](#) before performing teaching operation. Refer to section [9.2.2](#) for specific details on the operation method.

9.2.1 Teaching Position Precautions

When using force sense control, the robot control controls the following two types of position.

	Position Command Type	Description
(1)	Position command	This is a movement command generated by the robot program and JOG operation. It is referenced by the current position display and teaching operations. (Position displayed on T/B)
(2)	Force sense position command	Position command offset by force sense control. When force sense control is enabled, the robot moves based on this command.

By performing teaching operation (teaching operation from T/B or current position reading from RT ToolBox3) from the teaching pendant or RT ToolBox3 while force control is enabled, the position command (1) is taught, and a position different from the actual robot position (2) is taught.

[Example]...If the force control/stiffness control is enabled for the Z-axis




Fig. 9-1: Teaching position precautions

If teaching the actual position, perform teaching operation after changing the position command (position command displayed on T/B, etc.) to the force sense position command (actual position) with the following methods.

<Method 1>...Perform teaching operation after disabling force sense control.

By disabling force sense control, the "command position" changes to the "force sense position command".

<Method 2>...Perform teaching operation after pressing the "Teach pos. search" [Execute] button.

By pressing the "Teach pos. search" [Execute] button while force sense control is enabled, the "command position" is changed to the "force sense position command" while retaining the force sense control status. If performing teaching with force sense control enabled, use this method. (See section [9.2.1.1](#) for details on searching for the teaching position.)

9.2.1.1 Teaching Position Search

The "teaching position search" function is used to assist position teaching when force sense control is enabled.

While force control is enabled, a position offset with force sense control is added to the normal position command (position taught with T/B), resulting in a difference between the actual robot position and position displayed on the teaching pendant. By performing the teaching operation, the position displayed on the teaching pendant is registered, and so it is necessary to eliminate this difference before performing the teaching operation. (See section 9.2.1.)

By executing this function, the "position displayed on the teaching pendant" can be replaced with the "actual position" with force sense control still enabled.

[Using teaching position search]

R32TB

```
<CURRENT> XYZ 100% M1 T01 B1
X: +724.000 A: 0.000
Y: -219.000 B: 0.000
Z: 97.000 C: 0.000
FL1: 00000004 FL2: 00000000
JOINT TOOL 123 3-XYZ CYLNDR →
```

[FUNCTION] key

```
<CURRENT> XYZ 100% M1 T01 B1
X: +724.000 A: 0.000
Y: -219.000 B: 0.000
Z: 97.000 C: 0.000
FL1: 00000004 FL2: 00000000
ADD. AX WORK 123 FORCE CLOSE →
```

JOG操作画面

[F3] key: Force sense

```
<FORCE> XYZ 100% M1 T01 B1
Fx: 115.020 Mx: 0.023
Fy: -83.870 My: 0.017
Fz: 89.900 Mz: -0.055
FORCE: OFF MODE#: 0
ON PARAM 123 OFFSET JOG →
```

[FUNCTION] key


```
<FORCE> XYZ 100% M1 T01 B1
Fx: 115.020 Mx: 0.023
Fy: -83.870 My: 0.017
Fz: 89.900 Mz: -0.055
FORCE: OFF MODE#: 0
DETN MAX 123 PROBE JOG →
```

[F3] key: Search

<Precautions when using stiffness control>


The spring center position when using stiffness control is the position displayed on the teaching pendant. The spring center position also moves when performing "teaching position search", and so if a stiffness coefficient of other than 0.0 is set, the robot moves a little. Utilizing this characteristic, a position on which no external force acts can be taught when using stiffness control as shown in the following example.

R56TB




The "teaching position search" function is performed by pressing this button. (A confirmation screen appears.)

By pressing the [F] key, a force sense control screen appears.



(Example)..If inserting pins while following the workpiece shape with stiffness control (stiffness coefficient $\neq 0$), external force acts on one side of the pin. By performing "teaching position search" at such times, the robot can be moved in a direction in which no external force acts. There may be cases in which the robot is unable to move to a position in which no external force acts by performing this function only once. In such a case, perform several times while keeping an eye on the force sensor data until the reaction force becomes sufficiently small.




9.2.2 Usage Example (Teaching Operation)

9.2.2.1 Teaching a Position Pushed with Fixed Force

■ Teaching details

Teach the position at which the spring reaction force becomes 25 N.



■ Operation procedure

(1) Parameter settings

- Select force control for the Z-axis only, and set so that the robot is pushed with a force of 25 N in the tool coordinate system +Z-direction. (See table below.)

Control mode	Force sense control coordinate system	FSCOD01	0
	Force control mode	FSFMD01	+0.00, +0.00, <u>+1.00</u>, +0.00, +0.00, +0.00
	Stiffness coefficient	FSSTF01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Damping coefficient	FSDMP01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
Control characteristics	Force command value	FSFCMD01	+0.00, +0.00, <u>+25.00</u>, +0.00, +0.00, +0.00
	Speed command value	FSSPD01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Mode switching judgment value	FSSWF01	+0.00, +0.00, +0.00, +0.00, +0.00, +0.00
	Force sense control gain	FSFGN01	+0.00, +0.00, <u>+5.00</u>, +0.00, +0.00, +0.00

(* In this example, settings are specified with parameters, however, setting is also possible with status variables.)

(2) Offset cancel operation (See section [9.1.1.1](#).)

- Offset the force sensor zero point after first moving to the push start position (posture) by JOG operation.
* Perform offset cancel with no external forces acting other than gravity.

(3) Control mode/control characteristics selection (See section [9.1.1.2](#).)

- Set the "control mode" and "control characteristics" numbers.

(4) Force sense control enable operation (See section [9.1.1.3](#).)

- Turn the servo ON after enabling force sense control.
- The robot automatically moves to the position in the tool coordinate system +Z-direction at which a reaction force of 25 N can be obtained.

(5) Teaching (The following two teaching methods are available.)

<Method 1>

- Ensure that the force sensor data is $F_z=25\text{ N}$, and then disable force sense control with the servo ON.
(By disabling force sense control, the current position data appears on the teaching pendant.)
- Teach the current position.


<Method 2>

- Ensure that the force sensor data is $F_z=25\text{ N}$, and then perform "teaching position search" with the servo ON. By performing "teaching position search", the current position data appears on the teaching pendant. (See section [9.2.1.1.](#))
- Teach the current position.

9.2.2.2 Teaching the Insertion Position (Using Force Control)

■ Teaching details

Teach the ideal insertion position on which no external force acts.



■ Operation procedure

(1) Parameter settings

- Select all axes and force control, and set the force command so that the robot is pushed with a force of 5 N in the FZt direction, and external force is eliminated for all other axes. (FXt=FYt=0N, MXt=MYt=MZt=0 N·m)

Control mode	Force sense control coordinate system	FSCOD01	0
	Force control mode	FSFMD01	+1.00,+1.00,+1.00,+1.00,+1.00,+1.00
	Stiffness coefficient	FSSTF01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
	Damping coefficient	FSDMP01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
Control characteristics	Force command value	FSFCMD01	+0.00,+0.00,+5.00,+0.00,+0.00,+0.00
	Speed command value	FSSPD01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
	Mode switching judgment value	FSSWF01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
	Force sense control gain	FSFGN01	+0.50,+0.50,+0.50,+0.10,+0.10,+0.10

(* In this example, settings are specified with parameters, however, setting is also possible with status variables.)

(2) Offset cancel operation (See section [9.1.1.1](#).)

- Offset the force sensor zero point after first moving to the insertion start position (posture) by JOG operation.
* Perform offset cancel with no external forces acting other than gravity.

(3) Control mode/control characteristics selection (See section [9.1.1.2](#).)

- Set the "control mode" and "control characteristics" numbers.

(4) Force sense control enable operation (See section [9.1.1.3](#).)

- Turn the servo ON after enabling force sense control (stiffness control).
- The robot automatically moves to the insertion complete position with force control. (The robot moves slowly to the extent that the force sense control gain is lowered.)
* Adjust the force command or force sense control gain if required.

(5) Teaching (There are two teaching methods.)

<Method 1>

- Ensure that the force sensor data is Fz=5N and that other axis components are 0 N / 0 N·m, and then disable force sense control with the servo ON.


<Method 2>

- Ensure that the force sensor data is Fz=5N and that other axis components are 0 N / 0 N·m, and then perform "teaching position search" with the servo ON. (See section [9.2.1.1](#).)

9.2.2.3 Teaching the Insertion Position (Using Stiffness Control)

■ Teaching details

Teach the ideal insertion position on which no external force acts.



■ Operation procedure

(1) Parameter settings

- Specify force stiffness control for all axes until the robot becomes suitably soft.

Control mode	Force sense control coordinate system	FSCOD01	0
	Force control mode	FSFMD01	+2.00,+2.00,+2.00,+2.00,+2.00,+2.00
	Stiffness coefficient	FSSTF01	+0.10,+0.10,+0.50,+0.10,+0.10,+0.10
	Damping coefficient	FSDMP01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
Control characteristics	Force command value	FSFCMD01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
	Speed command value	FSSPD01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
	Mode switching judgment value	FSSWF01	+0.00,+0.00,+0.00,+0.00,+0.00,+0.00
	Force sense control gain	FSFGN01	+0.50,+0.50,+0.50,+0.50,+0.50,+0.50

(* In this example, settings are specified with parameters, however, setting is also possible with status variables.)

(2) Offset cancel operation (See section [9.1.1.1.](#))

- Offset the force sensor zero point after first moving to the insertion start position (posture) by JOG operation.
* Perform offset cancel with no external forces acting other than gravity.

(3) Control mode/control characteristics selection (See section [9.1.1.2.](#))

- Set the "control mode" and "control characteristics " numbers.

(4) Force sense control enable operation (See section [9.1.1.3.](#))

- Turn the servo ON after enabling force sense control (stiffness control).
- Move the robot to the insertion complete position by JOG operation. (Lower OVRD if required.)
- Perform "teaching position search" to move the control center value so that no unnecessary external force acts on the workpiece during movement.

(5) Teaching

- Perform "teaching position search" several times while checking the force sense sensor data displayed on the teaching pendant.
- Ensure that the robot is moving to a position at which external force no longer acts, and then teach the current position with force sense control still enabled.

9.3 Force Sense Function Screen

9.3.1 R32TB

Force sense function related screens are displayed by selecting from the extension function menu screen or by changing function from the JOG screen. These screens appear as follows on the R32TB.






Fig. 9-2: Force sense control related R32TB/R33TB screen transition

Table 9-4: Screen overview

Screen Name	Overview																								
Force sense control top screen	<p><Detection mode></p>  <p>The screen changes by pressing the [FUNCTION] key.</p> <ul style="list-style-type: none"> Detection mode is enabled when changing from the JOG operation screen. By operating the [-X] [+X] [-Y] [+Y] [-Z] [+Z] [-A] [+A] [-B] [+B] [-C] [+C] keys in detection mode, JOG operation can be performed. (* Operation rights required.) JOG operation types correspond to the JOG operation screen immediately before changing to the force sense control top screen. (The selected JOG operation type appears in the center of the screen.) <p><Monitoring mode></p>  <p>The screen changes by pressing the [FUNCTION] key.</p> <ul style="list-style-type: none"> Monitoring mode is enabled when changing from the extension function menu screen. JOG operation is not possible in monitoring mode. "Monitor" appears in the top center of the screen. <table border="1"> <thead> <tr> <th>Screen Display</th><th>Meaning</th></tr> </thead> <tbody> <tr> <td>"Fx" - "Mz"</td><td>Displays the current force sensor data (corresponding to status variable P_FsCurD.) * Displays values converted to the force sense coordinate system (Tool/XYZ). If the force sensor data exceeds the detection setting value during JOG operation, the background color of the exceeded data changes and the buzzer sounds.</td></tr> <tr> <td>"Force Sense"</td><td>Displays the current force sense control function enabled (ON)/disabled (OFF) status.</td></tr> <tr> <td>"Mode No."</td><td>Displays the currently specified control mode No.</td></tr> <tr> <td>"Feature No."</td><td>Displays the currently displayed control characteristics No.</td></tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Function</th><th>Description</th></tr> </thead> <tbody> <tr> <td rowspan="2">[F1]</td><td>ON/OFF Changes the force sense control function enabled/disabled status. (* Operation rights required.) The "Mode No." and "Feature No." values are used for the control mode and control characteristics. Offset cancel is not performed.</td></tr> <tr> <td>Setting Changes to the force detection setting value screen.</td></tr> <tr> <td rowspan="2">[F2]</td><td>Condition Changes to the conditions setting screen if force sense control is disabled.</td></tr> <tr> <td>Max. Value Changes to the maximum value display screen.</td></tr> <tr> <td rowspan="2">[F3]</td><td>Offset Changes to the cancel confirmation screen.</td></tr> <tr> <td>Search Changes to the position search execution confirmation screen.</td></tr> <tr> <td rowspan="2">[F4]</td><td>JOG Changes to the JOG operation screen.</td></tr> <tr> <td>Close Changes to the extension function menu screen.</td></tr> </tbody> </table>	Screen Display	Meaning	"Fx" - "Mz"	Displays the current force sensor data (corresponding to status variable P_FsCurD.) * Displays values converted to the force sense coordinate system (Tool/XYZ). If the force sensor data exceeds the detection setting value during JOG operation, the background color of the exceeded data changes and the buzzer sounds.	"Force Sense"	Displays the current force sense control function enabled (ON)/disabled (OFF) status.	"Mode No."	Displays the currently specified control mode No.	"Feature No."	Displays the currently displayed control characteristics No.	Function	Description	[F1]	ON/OFF Changes the force sense control function enabled/disabled status. (* Operation rights required.) The "Mode No." and "Feature No." values are used for the control mode and control characteristics. Offset cancel is not performed.	Setting Changes to the force detection setting value screen.	[F2]	Condition Changes to the conditions setting screen if force sense control is disabled.	Max. Value Changes to the maximum value display screen.	[F3]	Offset Changes to the cancel confirmation screen.	Search Changes to the position search execution confirmation screen.	[F4]	JOG Changes to the JOG operation screen.	Close Changes to the extension function menu screen.
Screen Display	Meaning																								
"Fx" - "Mz"	Displays the current force sensor data (corresponding to status variable P_FsCurD.) * Displays values converted to the force sense coordinate system (Tool/XYZ). If the force sensor data exceeds the detection setting value during JOG operation, the background color of the exceeded data changes and the buzzer sounds.																								
"Force Sense"	Displays the current force sense control function enabled (ON)/disabled (OFF) status.																								
"Mode No."	Displays the currently specified control mode No.																								
"Feature No."	Displays the currently displayed control characteristics No.																								
Function	Description																								
[F1]	ON/OFF Changes the force sense control function enabled/disabled status. (* Operation rights required.) The "Mode No." and "Feature No." values are used for the control mode and control characteristics. Offset cancel is not performed.																								
	Setting Changes to the force detection setting value screen.																								
[F2]	Condition Changes to the conditions setting screen if force sense control is disabled.																								
	Max. Value Changes to the maximum value display screen.																								
[F3]	Offset Changes to the cancel confirmation screen.																								
	Search Changes to the position search execution confirmation screen.																								
[F4]	JOG Changes to the JOG operation screen.																								
	Close Changes to the extension function menu screen.																								

Screen Name	Overview										
Force detection setting value screen	<p><FORCE> DETECTION SETTINGS F_x: 0.000 M_x: 0.000 F_y: 0.000 M_y: 0.000 F_z: 0.000 M_z: 0.000</p> <p>123 CLOSE</p> <table> <tr> <th>Screen Display</th><th>Meaning</th></tr> <tr> <td>"Fx" - "Mz"</td><td>Displays the current force detection setting value specified with the control characteristics.</td></tr> </table> <table> <tr> <th>Function</th><th>Description</th></tr> <tr> <td>[F4] Close</td><td>Changes to the force sense control top screen.</td></tr> </table>	Screen Display	Meaning	"Fx" - "Mz"	Displays the current force detection setting value specified with the control characteristics.	Function	Description	[F4] Close	Changes to the force sense control top screen.		
Screen Display	Meaning										
"Fx" - "Mz"	Displays the current force detection setting value specified with the control characteristics.										
Function	Description										
[F4] Close	Changes to the force sense control top screen.										
Conditions setting screen	<p><FORCE> PARAMETER CONTROL MODE (9) CONTROL FEATURE (-1)</p> <p>123 CLOSE</p> <table> <tr> <th>Screen Display</th><th>Meaning</th></tr> <tr> <td>"Control Mode"</td><td>Displays/sets the control mode No. By pressing the [EXE] key, the condition No. Set in parentheses () is updated.</td></tr> <tr> <td>"Control Feature"</td><td>Displays/sets the control characteristics No. By pressing the [EXE] key, the condition No. Set in parentheses () is updated.</td></tr> </table> <table> <tr> <th>Function</th><th>Description</th></tr> <tr> <td>[F4] Close</td><td>Changes to the force sense control top screen.</td></tr> </table>	Screen Display	Meaning	"Control Mode"	Displays/sets the control mode No. By pressing the [EXE] key, the condition No. Set in parentheses () is updated.	"Control Feature"	Displays/sets the control characteristics No. By pressing the [EXE] key, the condition No. Set in parentheses () is updated.	Function	Description	[F4] Close	Changes to the force sense control top screen.
Screen Display	Meaning										
"Control Mode"	Displays/sets the control mode No. By pressing the [EXE] key, the condition No. Set in parentheses () is updated.										
"Control Feature"	Displays/sets the control characteristics No. By pressing the [EXE] key, the condition No. Set in parentheses () is updated.										
Function	Description										
[F4] Close	Changes to the force sense control top screen.										
Maximum value display screen	<p><FORCE> MAXIMUM F_x: 115.020 M_x: 0.023 F_y: -83.070 M_y: 0.017 F_z: 89.980 M_z: -0.055</p> <p>RESET 123 CLOSE</p> <table> <tr> <th>Screen Display</th><th>Meaning</th></tr> <tr> <td>"Fx" - "Mz"</td><td>Displays the maximum force sensor data value during force sense control. (Corresponds to status variable P_FsMaxD.)</td></tr> </table> <table> <tr> <th>Function</th><th>Description</th></tr> <tr> <td>[F1] Reset</td><td>Changes to the reset confirmation screen.</td></tr> <tr> <td>[F4] Close</td><td>Changes to the force sense control top screen.</td></tr> </table>	Screen Display	Meaning	"Fx" - "Mz"	Displays the maximum force sensor data value during force sense control. (Corresponds to status variable P_FsMaxD.)	Function	Description	[F1] Reset	Changes to the reset confirmation screen.	[F4] Close	Changes to the force sense control top screen.
Screen Display	Meaning										
"Fx" - "Mz"	Displays the maximum force sensor data value during force sense control. (Corresponds to status variable P_FsMaxD.)										
Function	Description										
[F1] Reset	Changes to the reset confirmation screen.										
[F4] Close	Changes to the force sense control top screen.										
Reset confirmation screen	<p><FORCE> MAXIMUM RESET THE MAXIMUM VALUES. OK ?</p> <p>Yes 123 No</p> <table> <tr> <th>Function</th><th>Description</th></tr> <tr> <td>[F1] Yes</td><td>Resets the maximum force sensor data value during force sense control to 0. (* Operation rights required.) Changes to the maximum value display screen after resetting.</td></tr> <tr> <td>[F4] No</td><td>Changes to the maximum value display screen.</td></tr> </table>	Function	Description	[F1] Yes	Resets the maximum force sensor data value during force sense control to 0. (* Operation rights required.) Changes to the maximum value display screen after resetting.	[F4] No	Changes to the maximum value display screen.				
Function	Description										
[F1] Yes	Resets the maximum force sensor data value during force sense control to 0. (* Operation rights required.) Changes to the maximum value display screen after resetting.										
[F4] No	Changes to the maximum value display screen.										

Screen Name	Overview						
Cancel confirmation screen	<div><FORCE> OFFSET CANCEL THE OFFSET OF THE FORCE SENSOR. OK? <div>Yes123No</div></div>						
	<table><tr><th>Function</th><th>Description</th></tr><tr><td>[F1] Yes</td><td>Cancels the force sensor offset component. If the sensor data is not 0 with no external force acting on the sensor, it is necessary to perform offset cancel. (* Operation rights required.) An error occurs when force sense control is enabled and the servo is ON. Changes to the force sense control top screen after canceling.</td></tr><tr><td>[F4] No</td><td>Changes to the force sense control top screen.</td></tr></table>	Function	Description	[F1] Yes	Cancels the force sensor offset component. If the sensor data is not 0 with no external force acting on the sensor, it is necessary to perform offset cancel. (* Operation rights required.) An error occurs when force sense control is enabled and the servo is ON. Changes to the force sense control top screen after canceling.	[F4] No	Changes to the force sense control top screen.
	Function	Description					
	[F1] Yes	Cancels the force sensor offset component. If the sensor data is not 0 with no external force acting on the sensor, it is necessary to perform offset cancel. (* Operation rights required.) An error occurs when force sense control is enabled and the servo is ON. Changes to the force sense control top screen after canceling.					
	[F4] No	Changes to the force sense control top screen.					
Position search execution confirmation screen	<div><FORCE> TEACHING PROBE PROBE INTO THE POSITION FOR TEACHING. OK? <div>Yes123No</div></div>						
	<table><tr><th>Function</th><th>Description</th></tr><tr><td>[F1] Yes</td><td>Performs the teaching position search function. This is used when teaching the contact position. (* Operation rights required.) Changes to the force sense control top screen after processing.</td></tr><tr><td>[F4] No</td><td>Changes to the force sense control top screen.</td></tr></table>	Function	Description	[F1] Yes	Performs the teaching position search function. This is used when teaching the contact position. (* Operation rights required.) Changes to the force sense control top screen after processing.	[F4] No	Changes to the force sense control top screen.
	Function	Description					
	[F1] Yes	Performs the teaching position search function. This is used when teaching the contact position. (* Operation rights required.) Changes to the force sense control top screen after processing.					
	[F4] No	Changes to the force sense control top screen.					

9.3.2 R56TB

If using the force sensor, an [F] button appears in the bottom of the JOG screen. By pressing this button, a force sense control screen appears on the left of the JOG screen.




Fig. 9-3: [F] button display






Fig. 9-4: Force sense control extension screen

Table 9-5: Screen overview

No.	Screen Control	Overview
1	[F] button	Displays/hides a screen (surrounded by red box in Fig. 9-4) relating to force sense control. (Does not appear if the force sensor interface unit is not connected.)
2	Enable/Disable (ON/OFF)	<ul style="list-style-type: none"> Displays the current force sense control function enabled (ON)/disabled (OFF) status. By pressing the [ON/OFF] button when the force sense control function is disabled, force sense control is enabled with the specified control mode/control characteristics. (Corresponds to the Fsc On command.) By pressing the [ON/OFF] button when the force sense control function is enabled, force sense control is disabled. (Corresponds to the Fsc Off command.)  <p style="text-align: center;"><When function enabled> <When function disabled></p>
3	Control Mode /Control Feature	<ul style="list-style-type: none"> Displays the currently specified control mode/control characteristics. The used control mode/control characteristics can be specified only when the force sense control function is disabled. [Setting range -1 to 9] The control mode/control characteristics cannot be specified when the force sense control function is enabled. (Appears gray.)  <p style="text-align: center;"><When function enabled></p> <p style="text-align: center;"><Setting range></p>
4	Teach Pos. Search	<ul style="list-style-type: none"> By pressing the [Execute] button the system performs teaching position search. This is used to perform accurate contact position teaching. 
5	Force Monitor	<ul style="list-style-type: none"> Displays the force detection setting value (corresponds to parameters FSFLMT01 to 09 and status variables P_FsFLm0 and P_FsFLm1) specified at "Control characteristics "

No.	Screen Control	Overview
6	Current	<ul style="list-style-type: none"> Displays the current force sensor data (corresponds to status variable P_FsCurD.) <ul style="list-style-type: none"> * Displays the value converted to the force sense coordinate system (Tool/XYZ). Displays the current value when the force sense control function is disabled . If the force sensor data exceeds the detected setting value during JOG operation, the background color of the applicable data changes, and the buzzer sounds. <p style="text-align: center;">  Ex: -171.500 -171.500 -171.500 </p> <p style="text-align: center;"><When detection setting value over></p>
7	Maximum	<ul style="list-style-type: none"> Displays the force sensor data maximum value (corresponds to status variable P_FsMaxD) during force sense control. * The maximum value is reset with the maximum value reset operation or offset cancel operation.
8	Offset Cancel	<ul style="list-style-type: none"> Cancels the force sensor offset component (zero point offset). If sensor data is not 0 with no external force acting on the sensor, it is necessary to perform offset cancel. Offsets cannot be cancelled when the force sense control function is disabled. (Appears gray.)
9	Reset Max.	<ul style="list-style-type: none"> Resets the force sense data maximum value.

9.3.3 R86TB

When a force sensor is used, the [Force Control] button will appear in the lower section of the JOG operation guide. Clicking this button will display the force sense control screen to the left of the JOG operation guide.




Fig. 9-5: Force Control button






Fig. 9-6: Force control screen

Table 9-6: Screen overview

No.	Screen Control	Overview
1	Force Control	Displays/hides a screen (surrounded by red box in Fig. 9-6) relating to force sense control. (Does not appear if the force sensor interface unit is not connected.)
2	Force Control switch	<ul style="list-style-type: none"> Shows if the force sense control function is enabled/disabled. Tapping the switch when the force sense function is disabled, enables the force sense function using the specified control mode and control feature. (Corresponds to the Fsc On command) Tapping the switch when the force sense control function is enabled, disables the force sense control function. (Corresponds to the Fsc Off command) <div style="text-align: center;">  <p>Force Control  </p> <p><When function enabled> <When function disabled></p> </div>
3	Mode/Feature	<ul style="list-style-type: none"> Displays the currently specified control mode/control characteristics. The used control mode/control characteristics can be specified only when the force sense control function is disabled. [Setting range -1 to 9] The control mode/control characteristics cannot be specified when the force sense control function is enabled. (Appears gray.) <p style="text-align: center;"><Setting range></p> <div style="text-align: center;">  <p style="text-align: right;"><When function enabled></p> <div style="display: flex; justify-content: space-around;"> <div>Mode 0</div> <div>Feature 0</div> </div> </div>
4	Teach Position Search	<ul style="list-style-type: none"> Tap the [Teach Position Search] button to execute teaching position search. This is used to perform accurate contact position teaching. <div style="text-align: center;">  </div>
5	Force Monitor	<ul style="list-style-type: none"> Displays the force detection setting value (corresponds to parameters FSFLMT01 to 09 and status variables P_FsFLm0 and P_FsFLm1) specified at "Control characteristics "

No.	Screen Control	Overview
6	Current	<ul style="list-style-type: none"> Displays the current force sensor data (corresponds to status variable P_FsCurD.) * Displays the value converted to the force sense coordinate system (Tool/XYZ). Displays the current value when the force sense control function is disabled. If the force sensor data exceeds the detected setting value during JOG operation, the background color of the applicable data changes, and the buzzer sounds.  <p><When detection setting value over></p>
7	Maximum	<ul style="list-style-type: none"> Displays the force sensor data maximum value (corresponds to status variable P_FsMaxD) during force sense control. * The maximum value is reset with the maximum value reset operation or offset cancel operation.
8	Offset Cancel	<ul style="list-style-type: none"> Cancels the force sensor offset component (zero point offset). If sensor data is not 0 with no external force acting on the sensor, it is necessary to perform offset cancel. Offsets cannot be cancelled when the force sense control function is disabled. (Appears gray.)  <p><When function enabled></p>
9	Reset Max.	<ul style="list-style-type: none"> Resets the force sense data maximum value.

<<MEMO>>

10 How to Use the Learning Function

This chapter describes how to use the learning function.

The most suitable movement is learned by repeating the movement. The movement is repeated with different force sense control parameter settings or actions with different position, speed, or other conditions to find the most suitable possible movement in the acceptable range.

A sub-program for force sense movement setting and a main learning program for repeating the movement must be created for using the learning function. The force sense movement program is created automatically using the force sense wizard function.

To use this function, refer to “4.2.2 Extended function” to check applicable versions.

The force sense wizard function can only be used for 1F-FS001-W200 and 1F-FS001-W1000 force sensors. When using other force sensors, the force sense wizard will not appear and functions which the force sense wizard has been used for (insertion and fitting, phase match insertion, and contact detection) cannot be used.







Fig.10-1: Overview of the learning program creation

10.1 Force Sense Movement Specifications

The following section describes movements created by the wizard function.

Table 10-1 : Movements created by the wizard function

No.	Name	Description
1	Insertion and fitting	<p>Control the robot delicately for the movement from the taught start posture to the end posture. The workpiece held by the hand is inserted in the Z direction of the tool coordinate system.</p>  <p>Start from the taught start position Slowly approach to reduce impact force Insert the workpiece using delicate control while tracking the shape of the jig Insert/fit the workpiece quickly while reducing acting force</p>
2	Phase match insertion	<p>The workpiece held by the hand is brought into contact with the other workpiece and rotated to check phase match. The workpiece is automatically pushed into the other workpiece when the phase match is detected. The workpiece held by the hand is inserted in the Z direction of the tool coordinate system.</p>  <p>Detect contact with the workpiece Search for phase match while rotating the workpiece Start fitting after phase match detection</p>
3	Contact detection	<p>While the force is monitored, the movement starts from the start posture in a fixed direction and stops when the contact is detected.</p> <ul style="list-style-type: none"> After the movement is stopped, the stop position can be detected by referring to the current position of the robot (P_Fbc). When force control is performed, the travel distance is restricted for the sake of safety (initial value: 200 mm). Observe the limit for the movement.  <p>Workpiece Direction of detection force Detection force/torque Moved to the contact position</p>

10.1.1 Insertion and fitting

(1) Description

- Control the robot delicately for the movement from the start posture to the end posture. The workpiece is moved in the Z direction of the tool coordinate system.
- The moving speed is changed using three speed settings for fast fitting with impact force reduction.

(2) What is learned

- Movement to make the tact time as short as possible with acting force reduction.




Fig.10-2: Overview of the insertion and fitting movement

(3) Setting Item

The following table shows setting items required for creating an insertion and fitting movement.

Table 10-2: Setting items required for creating an insertion and fitting movement

No.	Setting Item	Description	Property
1	Start posture	Teach the start position. Teach a position 1 mm or so away from the workpiece insertion position. The movement from the start posture to the end posture is a linear interpolation movement. Teach positions to ensure consistency between the start and end postures (with the same tilt)	Mandatory
2	End posture	Teach the end position. Insert/fit the workpiece using the force sense teaching pendant (T/B) function and teach the end position.	
3	Movement speed limit	Set the upper limit for the robot speed.	
4	Force limit	Set the upper limit for the acting force for pressing operation of the force sense control. When the force sensor data exceeds the setting value, no more force is applied.	
5	Operation completion condition	Set the conditional expression used to determine the completion of the movement.	
6	Stand-by time before starting	Duration to wait for a robot arm to stop at the start position of the movement.	Changeable
7	Time-out time	Specify the time-out time for the movement. When the movement cannot be completed within the specified period, the result is judged as failed. The movement is terminated and the control returns back to the main program.	
8	Timer No.	Specify the M_Timer number for counting time in the library. Specify an unused number.	
9	Contact position	Set the contact position for the workpiece. Specify an offset amount from the start position in the direction of insertion.	
10	Stiffness coefficients 1 (Z, C)	Set stiffness coefficients. (Z axis, C axis)	
11	Force sense control gains 1 (Z, C)	Set force sense control gains. (Z axis, C axis)	
12	Movement switching position 1	First switching position for the movement parameter.	Learning range
13	Movement switching position 2	Second switching position for the movement parameter.	
14	Speed 1	Speed for the movement from the start position to the first switching position. Set the speed used when the workpiece approaches the contact point.	
15	Speed 2	Speed for the movement from the first switching position to the second switching position. Set the speed at the contact point.	
16	Speed 3	Speed for the movement from the second switching position to the end position. Set the speed used for tracking after the contact point.	
17	Stiffness coefficients 1 (XY)	Set stiffness coefficients. (X axis, Y axis)	
18	Stiffness coefficients 1 AB	Set stiffness coefficients. (A axis, B axis)	
19	Force sense control gains 1 XY	Set gains. (X axis, Y axis)	
20	Force sense control gains 1 AB	Set gains. (A axis, B axis)	

10.1.2 Phase match insertion

(1) Description

- Control the robot delicately for the linear interpolation movement from the taught start posture to the end posture.
- When the contact is detected, rotate the workpiece in the Z direction of the tool coordinate system around the C axis to check phase match.
- Fitting is started when the phase match completion is detected.

(2) What is learned

- Movement to make the tact time as short as possible with acting force reduction.




Fig. 10-3: Overview of the phase match insertion movement

(3)Setting Item

The following table shows setting items required for creating a phase match insertion movement.

Table 10-3: Setting items for phase match insertion movement

No.	Setting Item	Description	Property
1	Start posture	Teach the start position. Teach a position 1 mm or so away from the workpiece insertion position. The movement from the start posture to the end posture is based on a linear interpolation movement. Teach positions to ensure consistency between the start and end postures (with the same tilt)	Mandatory
2	End posture	Teach the end position. Insert/fit the workpiece using the force sense teaching pendant (T/B) function and teach the end position.	
3	Movement speed limit	Set the upper limit for the robot speed.	
4	Force limit	Set the upper limit for the acting force for pressing operation of the force sense control. When the force sensor data exceeds the setting value, no more force is applied.	
5	Operation completion condition	Set the conditional expression used to determine the completion of the movement.	
6	Stand-by time before starting	Duration to wait for a robot arm to stop at the start position of the movement.	Changeable
7	Time-out time	Specify the time-out time for the movement. When the movement cannot be completed within the specified period, the result is judged as failed. The movement is terminated and the control returns back to the main program.	
8	Timer No.	Specify the M_Timer number for counting time in the library. Specify an unused number.	
9	Contact determination condition	Set the amount of force applied in the Z direction of the tool coordinate system to determine contact of the workpiece. (1) When the force equal to or larger than the setting value is detected, the workpiece is regarded as in contact with the other workpiece, and the phase match movement (2) starts.	
10	Stiffness coefficients 1 (Z, C)	Set stiffness coefficients. (1) (Z axis, C axis)	
11	Force sense control gains 1 (Z, C)	Set force sense control gains. (1) (Z axis, C axis)	
12	Stiffness coefficients 2 (A, B)	Set stiffness coefficients. (2) (A axis, B axis)	
13	Force sense control gains 2 (A, B)	Set force sense control gains. (2) (A axis, B axis)	
14	Stiffness coefficients 3 (Z, C)	Set stiffness coefficients. (3) (Z axis, C axis)	
15	Force sense control gains 3 (Z, C)	Set force sense control gains. (3) (Z axis, C axis)	
16	Speed 1	Speed for the movement prior to the contact. (1)	Learning range
17	Stiffness coefficients 1 (XY, AB)	Set stiffness coefficients. (1) (X axis, Y axis, A axis, B axis)	
18	Force sense control gains 1 (XY, AB)	Set force sense control gains. (1) (X axis, Y axis, A axis, B axis)	
19	Interim target position	Set the target position for the phase match movement. (2) When the workpiece is pushed down to the interim target position, phase match is detected, and the push-in movement (3) starts.	
20	Speed 2	Speed for the movement prior to the phase match. (2)	

No.	Setting Item	Description	Property
21	Stiffness coefficients 2 (XY, Z, C)	Set stiffness coefficients. (2) (X axis, Y axis, Z axis, C axis)	Learning range
22	Force sense control gains 2 (XY, Z, C)	Set force sense control gains. (2) (X axis, Y axis, Z axis, C axis)	
23	Speed 3	Speed used until the push-in movement is completed. (3)	
24	Stiffness coefficients 3 (XY, AB)	Set stiffness coefficients. (3) (X axis, Y axis, A axis, B axis)	
25	Force sense control gains 3 (XY, AB)	Set force sense control gains. (3) (X axis, Y axis, A axis, B axis)	

10.1.3 Contact detection

(1) Description

- The movement is started in the specified direction from the start position.
- When the contact is detected, the workpiece is pressed with a fixed force.
- When the operation completion condition is satisfied, force sense control is terminated.

(2) What is learned

- Movement to make the tact time as short as possible with acting force reduction.




Fig. 10-4: Overview of the contact detection movement

(3)Setting Items

The following table shows setting items required for creating a contact detection movement.

Table 10-4: Setting items for a contact detection movement

No.	Setting Item	Description	Property
1	Direction	Set the direction for the movement.	Mandatory
2	Movement speed limit	Set the upper limit for the robot speed.	
3	Force limit	Set the upper limit for the acting force for pressing operation of the force sense control. When the force sensor data exceeds the setting value, no more force is applied.	
4	Operation completion condition	Set the conditional expression used to determine the completion of the movement.	
5	Stand-by time before starting	Duration to wait for a robot arm to stop at the start position of the movement.	Changeable
6	Time-out time	Specify the time-out time for the movement. When the movement cannot be completed within the specified period, the result is judged as failed. The movement is terminated and the control returns back to the main program.	
7	Timer No.	Specify the M_Timer number for counting time in the library. Specify an unused number.	
8	Speed command value	Set the speed command value.	Learning range
9	Force sense control gain	Set force sense control gains.	

10.2 Creation of Force Sense Movements (Sub-Program for Learning)


The following section describes creation of movements using the wizard function. Using the wizard function of RT ToolBox3, sub-programs are created for learning the movements.

10.2.1 Creation of new movement

Creation of force sense movements is performed online or in simulation mode in RT ToolBox3.


1) Start the wizard function.

Select [Tool] > [Force sensor] > [Create force movement].




* After setting the required items, a learning program template is created and displayed.

2) The create force movement screen is displayed.




The wizard function can be also started as follows.



<Procedure 2>

Right-click [Program] menu in the project tree and select [Create force movement].



<Procedure 3>

Open a program, right-click on the command edit screen to open the menu, and select [Create force movement].

* After setting the required items, command lines are inserted in the program on the edit screen to execute the created force sense movement.

* When the program is opened for debugging, the [Create force movement] on the right-click menu is not selectable.

10.2.2 Creation of force sense movements

In the first step in the create force movement screen, settings are required to register force sense movements.

[Step 1. Movement selection]

- (1) Set force sensor parameters.
- (2) Select a movement.
- (3) Click the [Next] button to continue to step 2.

Different settings are required in step 2 for each movement. For details of the setting method, refer to the section of each type of movement shown in “Table 10-5”.

Table 10-5: Reference section for force sense movement creation screen (Step 2) of each movement

No.	Movement type	Reference section
1	Insertion and fitting	10.2.3.1 Insertion and fitting
2	Phase match insertion	10.2.3.2 Phase match insertion
3	Contact detection	10.2.3.3 Contact detection





Fig. 10-5: Force sense movement creation screen


(1) Force sensor parameter setting

Perform initial setting of force sensor parameters. When "Not Set" is displayed, click the [Set] button to perform initial setting of force sensor parameters. For details of parameters, refer to "6.6 Default Parameter Settings".

- 1) When the [Set] button on the create force movement screen (step 1) is clicked, the force sense parameter setting screen is displayed.




- 2) Select the sensor type in the "Sensor type" field of the "initial settings" section and click the [Setting] button.
 3) The confirmation window appears. Click [Yes] to enter initial values of the force sensor.
 4) Check the values. Change initial values as required, and click the [Write] button.




5) After writing to the controller and power reset.

6) close the parameter setting screen.



6) "Set" is displayed in the create force movement screen.

Force sense movement creation screen (step 1)




(2) Force sense movement selection

Select the type of the movement from the drop-down list of force sense movement selection. The explanatory diagram changes according to the type of movement.
(Refer to 10.1 Force Sense Movement Specifications.)


Three types of movements are selectable.

Table 10-6: Selectable force sense movements


No.	Movement type
1	Insertion and fitting
2	Phase match insertion
3	Contact detection



Insertion and



Phase match



Contact detection

Fig. 10-6: Force sense movement creation screen (step 1), screen of each movement

(3) After the initial setting of force sensor parameters and the movement selection, click the [Next] button to continue to step 2.




Fig. 10-7: Force sense movement creation screen (step 2)

10.2.3 Force sense movement setting

In the movement setting screen (step 2), parameters related to the selected movement are set.

Items to be set differ for the movement type selected in step 1 in 10.2.2 Creation of force sense movements.

For details of the setting method, refer to the section of each type of movement.

Table 10-7: Reference section for details of each movement

No.	Movement type	Reference section
1	Insertion and fitting	10.2.3.1 Insertion and fitting
2	Phase match insertion	10.2.3.2 Phase match insertion
3	Contact detection	10.2.3.3 Contact detection

[Step 2. Movement settings]

1. Set positions for the start and end postures of force sense movement.
2. Set the operation completion condition.
3. Set limits for speed and force.
4. Set details of the movement selected in step 1.
5. Click the [Next] button to continue to step 3. (Refer to 10.2.4 Learning setting.)

10.2.3.1 Insertion and fitting

Settings for the insertion and fitting movement are described below.




Fig. 10-8: Force sense movement creation screen (step 2) (insertion and fitting)

Table 10-8: Setting items for insertion and fitting

Setting Item	Description
Start posture	Teach the start position. Click the [Teach] button to enter the current position data of the robot.
End posture	Teach the end position. Click the [Teach] button to enter the current position data of the robot. Click the [Force T/B set] button to display the force T/B setting screen to teach the end posture using the force T/B function.
Operation completion condition	Set the conditional expression used to determine that the force sense movement is completed. Click the [Set] button to display the operation completion condition setting screen.
Movement speed limit	Set the maximum speed value for the force sense movement.
Force limit	Set the maximum acting force value for the force sense movement. When the force sensor data exceeds the setting value, no more force is applied.
Detail settings	Set parameters for the insertion and fitting movement and the automatically adjustable parameters. Recommended values are initially set for the insertion and fitting movement. Click the [Detail] button to display the setting screen. Set the parameters according to each work environment.

(1) Start and end postures of force sense movement (mandatory)

Teach the start posture and the end posture. Click the [Teach] button to enter the current position data. Refer to Fig. 10-9 below for teaching.




Fig. 10-9: Starting posture and end posture (insertion and fitting)

<Teaching of the end posture>

When the assembly completion position is taught for the assembly of parts, use the force sense T/B function to teach a position which will not allow an external force to act on the workpiece.

Set parameters related to force sense control to use the function.

Click the [Force T/B set] button to display the force T/B setting screen. Enter setting values and click the [Write] button to write the setting values to use the force sense T/B function.




Fig. 10-10: Force T/B setting screen

For details of the force sense T/B function, refer to “9.1 Force Sense T/B”, or click the [How to use force T/B] button on the force T/B setting screen to display the description.

(2) Conditions to determine an operation has finished (mandatory)

Set conditions that determine when an operation has finished. Set conditional expressions used to finish the insertion or assembly.

Click the [Set] button in the operation completion condition section (2) to display the operation completion condition setting screen.

Refer to “10.2.3.4 How to set conditions to determine an operation has finished” for description on how to set the conditional expression.




Fig. 10-11: Conditions to determine an operation has finished

[Setting example]

Set the following settings for position feedback in the Z direction to determine that the operation is complete when the workpiece is within 5 mm of the end position.




Fig. 10-12: Conditions to determine an operation has finished

When the conditions remain unsatisfied after the predetermined time, a time-out error will occur and the operation will be determined as failed. A threshold value for the time-out error can be set in the advanced settings (4).

(3) Limiting speed and force (mandatory)

Set the maximum speed and the force limit values for force sense movement.

Make sure to specify these values since they are used as limit values when combinations of parameters are changed during learning operation.




Fig. 10-13: Speed and force limit settings (insertion and fitting)

<Movement speed limit>

This value is used as the upper limit value of the movement speed command value of the robot. (Unit: mm/s)

The speed is changed during learning operation. Set an appropriate speed to avoid a high impact force (about 50 mm/s for rigid bodies).

Details of the range for learning the speed can be set in the advanced settings (4). When fine adjustment is required, for example to decrease the speed at the contact point, set the range for each parameter in the advanced settings. (The lower of the speed limit value in this field or the upper limit value on the detail setting screen is effective.)

<Force limit>

The setting is used as the upper limit of the acting force for force sense control. Set an appropriate limit value to avoid damaging the workpiece. Note that changing the force limit setting values is not effective as a precaution to reduce the impact force since the speed setting is a critical factor. Set a speed limit to ensure protection.

**CAUTION**

Learning is required for parameters for the movement created using the wizard function. The workpiece may be brought into contact with the other object with a high impact force during learning while different combinations of various parameters are tried in the learning range. Set appropriate limit values for speed and force for the sake of safety.

**CAUTION**

Since the speed and force limit settings are applied to the command values, the sensor values may temporarily exceed the limit values.

Note that changing the force limit setting values is not effective as a precaution to reduce the impact force since the speed setting is a critical factor. Set a low enough speed.

(4) Advanced settings (optional)

The details of the learning range of automatically adjusted parameters can be set more precisely. Recommended values are initially set.

<Advanced settings for insertion and fitting>

Parameters other than automatically adjusted parameters are specified for the force sense movement. Recommended values are initially set. The settings can be changed as required for each work environment.

<Learning range for automatically adjusted parameters>

Automatically adjusted parameters are specified for the force sense movement.

Set the maximum and minimum values to set the learning range when searching for the optimum combination of parameters.

Recommended learning range values are initially set. The settings can be changed as required for each work environment.

When the settings are completed, click the [Next] button to continue to the next step, 10.2.4 Learning setting.




Fig. 10-14: Advanced settings for the insertion and fitting movement

Advanced settings for insertion and fitting




Fig. 10-15: Advanced settings for the insertion and fitting movement

Table 10-9: Setting items of the insertion and fitting movement

No.	Setting Item	Description	Initial value	Property
1	Stand-by time before starting	Duration to wait for a robot arm to stop at the start position of the movement. Unit: s	1.00	Changeable
2	Time-out time	Specify the time-out time for the movement. When the movement cannot be completed within the specified period, the result is judged as failed. The movement is terminated and the control returns back to the main program. Unit: s	30.00	
3	Timer No.	Specify the M_Timer number for counting time in the library. Specify an unused number.	8	



No.	Setting Item	Description	Initial value	Property
4	Contact position	Set the contact position for the workpiece. Specify an offset amount from the start position in the direction of insertion (Z direction of the tool coordinate system). Unit: mm 	5.00	Changeable
5	Stiffness coefficients 1 (Z, C)	Set stiffness coefficients. (Z axis, C axis) Unit for Z: N/mm, unit for C: N·m/deg Setting range: 0 to 1000	Z : 0.50 C : 0.00	
6	Force sense control gains 1 (Z, C)	Set force sense control gains. (Z axis, C axis) Unit for Z: 10^{-3} mm/N, unit for C: 10^{-3} deg./($N \cdot m$) Setting range: 0 to 300	Z : 5.00 C : 0.00	

Table 10-10: Learning range for automatically adjusted parameters (insertion and fitting)

No.	Setting Item	Description	Minimum	Maximum
1	Movement switching position 1	Specify the range used for adjusting the first switching position for a force sense movement parameter. The contact surface is used as a reference. Unit: mm Setting range: 0 to 100 for minimum value 0 to 100 for maximum value	0.00	5.00
2	Movement switching position 2		0.00	5.00
3	Speed 1	Set a learning range for the speed for the movement from the start position to the first switching position. Unit: mm/s	5.00	50.00
4	Speed 2	Set a learning range for the speed for the movement from the first switching position to the second switching position. Unit: mm/s	5.00	10.00
5	Speed 3	Set a learning range for the speed for the movement from the second switching position to the end position. Unit: mm/s	5.00	50.00

No.	Setting Item	Description	Minimum	Maximum
6	Stiffness coefficients 1 (XY)	Set the learning range for stiffness coefficients. (X axis, Y axis) Unit: N/mm Setting range: 0 to 1000 for minimum value, 0 to 1000 for maximum value	0.00	5.00
7	Stiffness coefficients 1 AB	Set the learning range for stiffness coefficients. (A axis, B axis) Unit: N·m/deg. Setting range: 0 to 1000 for minimum value, 0 to 1000 for maximum value	0.00	5.00
8	Force sense control gains 1 XY	Set the learning range of the force sense control gains. (X axis, Y axis) Unit: 10^{-3} mm/N Setting range: 0 to 300 for minimum value, 0 to 300 for maximum value	0.50	10.00
9	Force sense control gains 1 AB	Set the learning range of the force sense control gains. (A axis, B axis) Unit: 10^{-3} deg./(N·m) Setting range: 0 to 300 for minimum value, 0 to 300 for maximum value	0.50	10.00

10.2.3.2 Phase match insertion

Settings for the phase match insertion movement are described below.




Fig. 10-16: Force sense movement creation screen (step 2) (phase match insertion)

The following table shows setting items for phase match insertion.

Table 10-11: Setting items for the phase match insertion movement

Setting Item	Description
Start posture	Teach the start position. Click the [Teach] button to enter the current position data of the robot.
End posture	Teach the end position. Click the [Teach] button to enter the current position data of the robot. Click the [Force T/B set] button to display the force T/B setting screen to teach the position while the workpiece is inserted.
Operation completion condition	Set the conditional expression used to determine the completion of the movement. Click the [Set] button to display the operation completion condition setting screen.
Movement speed limit	Set the maximum speed value for the force sense movement.
Force limit	Set the maximum acting force value for the force sense movement. When the force sensor data exceeds the setting value, no more force is applied.
Detail settings	Set parameters for phase match insertion and the automatically adjustable parameters. Recommended values are initially set for phase match insertion. Click the [Detail] button to display the setting screen. Set the parameters according to each work environment.

(1) Start and end postures of force sense movement

Enter position data in the X to Z, A to C, L1, and L2 fields of the start posture and the end posture. Click the [Teach] button to read the current position, and data will be set in the X to Z, A to C, L1, and L2 fields.

Refer to Fig. 10-17 for the start and end postures.




Fig. 10-17: Starting posture and end posture (phase match insertion)

<Teaching of the end posture>

When the assembly completion position is taught for the assembly of parts, use the force sense T/B function to teach an ideal position.

For details of the force sense T/B function, refer to 9.1 Force Sense T/B, or click the [How to use force T/B] button on the force T/B setting screen to display the description.




Fig. 10-18: Force T/B setting screen

(2) Conditions to determine an operation has finished

Set conditions that determine when an operation has finished. Set conditional expressions used to finish the insertion or assembly.

Click the [Set] button in the operation completion condition section (2) to display the operation completion condition setting screen.

Refer to “10.2.3.4 How to set conditions to determine an operation has finished” for description on how to set the conditional expression.




Fig. 10-19: Conditions to determine an operation has finished

[Setting example]

Set the following settings for position feedback in the Z direction to determine that the operation is complete when the workpiece is within 5 mm of the end position.




Fig. 10-20: Conditions to determine an operation has finished

When the conditions remain unsatisfied after the predetermined time, a time-out error will occur and the operation will be determined as failed. A threshold value for the time-out error can be set in the advanced settings (4).

(3) Limiting speed and force

Set the maximum speed and the acting force limit values for the movement.

Make sure to specify these values since they are used as limit values when combinations of parameters are changed during learning operation. The upper and lower limit values can be changed also in the advanced settings (4).




Fig. 10-21: Speed and force limit settings (phase match insertion)

<Movement speed limit>

The setting is used as the upper limit for the robot movement. (Unit: mm/s)

Set an appropriate speed to avoid a high impact force.

<Force limit>

The setting is used as the upper limit of the acting force for force sense control. (Unit for X, Y, Z: N, unit for A, B, C: Nm)

Set an appropriate value to avoid damaging the workpiece.



CAUTION

Learning is required for parameters for the movement created using the wizard function. The workpiece may be brought into contact with the other object with a high impact force during learning while different combinations of various parameters are tried in the learning range. Set appropriate limit values for speed and force for the sake of safety.



CAUTION

Since the speed and force limit settings are applied to the command values, the sensor values may temporarily exceed the limit values.

Note that changing the force limit setting values is not effective as a precaution to reduce the impact force since the speed setting is a critical factor. Set a low enough speed.

(4) Advanced settings

<Advanced settings for phase match insertion>

Parameters other than automatically adjusted parameters are specified for the movement. Recommended values are initially set. The settings can be changed as required for each work environment.

<Learning range for automatically adjusted parameters>

Automatically adjusted parameters are specified for the movement.

Set the maximum and minimum values to set the learning range when searching for the optimum combination of parameters.

Recommended learning range values are initially set. The settings can be changed as required for each work environment.

When the settings are completed, click the [Next] button to continue to the next step, 10.2.4 Learning setting.




Fig. 10-22: Advanced settings for phase match insertion

Advanced settings for phase match insertion

Control the robot delicately for the linear interpolation movement from the taught start posture to the end posture.

When the workpiece is brought into contact with the other object and a predetermined force is detected, the workpiece is rotated to check phase match for insertion.

(Movement is learned to make the tact time as short as possible by combining parameters within the specified range.)

The phase match insertion is performed in three steps.

1. Contact

When the Z-axis value exceeds the threshold value, it is determined that the workpiece has been brought into the contact with the other object, and the operation continues to step 2.

2. Phase match (rotation and pushing)

When the workpiece is pushed down to the interim target position, it is determined that phase match has been detected, and the operation continues to step 3.

3. Push-in

When the completion condition is satisfied, the operation is finished.




Fig. 10-23: Advanced settings for phase match insertion

Table 10-12: Setting items of the phase match insertion movement

No.	Setting Item	Description	Initial value	Property
1	Stand-by time before starting	Duration to wait for a robot arm to stop at the start position of the movement. Unit: s	1.00	Changeable
2	Time-out time	Specify the time-out time for the movement. When the movement cannot be completed within the specified period, the result is judged as failed. The movement is terminated and the control returns back to the main program. Unit: s	30.00	
3	Timer No.	Specify the M_Timer number for counting time in the library. Specify an unused number.	8	
4	Contact determination condition (1)	Set the amount of force applied in the Z direction of the tool coordinate system to determine contact of the workpiece. When the force equal to or larger than the setting value is detected, the workpiece is regarded as in contact with the other workpiece, and the phase match movement (2) starts. Unit: N	5.00	
5	Stiffness coefficients 1 (Z, C) (1)	Set stiffness coefficients. (Z axis, C axis) Unit for Z: N/mm, unit for C: N·m/deg	Z : 0.50 C : 0.00	
6	Force sense control gains 1 (Z, C) (1)	Set force sense control gains. (Z axis, C axis) Unit for Z: 10^{-3} mm/N, unit for C: 10^{-3} deg./ (N·m)	Z : 5.00 C : 0.00	
7	Stiffness coefficients 2 (A, B) (2)	Set stiffness coefficients. (A axis, B axis) Unit: N·m/deg.	A : 0.50 B : 0.50	
8	Force sense control gains 2 (A, B) (2)	Set force sense control gains. (A axis, B axis) Unit: 10^{-3} deg./ (N·m)	A : 5.00 B : 5.00	
9	Stiffness coefficients 3 (Z, C) (3)	Set stiffness coefficients. (Z axis, C axis) Unit for Z: N/mm, unit for C: N·m/deg	Z : 0.50 C : 0.00	
10	Force sense control gains 3 (Z, C) (3)	Set force sense control gains. (Z axis, C axis) Unit for Z: 10^{-3} mm/N, unit for C: 10^{-3} deg./ (N·m)	Z : 5.00 C : 0.00	

Table 10-13: Learning range for automatically adjusted parameters (phase match insertion)

No.	Setting Item	Description	Minimum	Maximum
1	Speed 1 (1)	Speed for the movement prior to the contact (1). Unit: mm/s	5.00	20.00
2	Stiffness coefficients 1 XY (1)	Set the learning range for stiffness coefficients. (X axis, Y axis) Unit: N/mm	0.00	5.00
3	Stiffness coefficients 1 AB (1)	Set the learning range for stiffness coefficients. (A axis, B axis) Unit: N·m/deg.	0.00	5.00
4	Force sense control gains 1 XY (1)	Set the learning range of the force sense control gains. (X axis, Y axis) Unit: 10^{-3} mm/N	0.50	10.00
5	Force sense control gains 1 AB (1)	Set the learning range of the force sense control gains. (A axis, B axis) Unit: 10^{-3} deg./ (N·m)	0.50	10.00
6	Interim target position (2)	Set the target position for the phase match movement.	0.50	5.00

No.	Setting Item	Description	Minimum	Maximum
		When the workpiece is pushed down to the interim target position, phase match is detected, and the push-in movement (3) starts. Unit: mm		
7	Speed 2 (2)	Speed for the movement prior to the phase match. Unit: mm/s	5.00	10.00
8	Stiffness coefficients 2 XY (2)	Set the learning range for stiffness coefficients. (X axis, Y axis) Unit: N/mm	0.00	5.00
9	Stiffness coefficients 2Z (2)	Set the learning range for stiffness coefficients (Z axis). Unit: N/mm	0.50	5.00
10	Stiffness coefficients 2C (2)	Set the learning range for stiffness coefficients (C axis). Unit: N·m/deg.	0.50	5.00
11	Force sense control gains 2 XY (2)	Set the learning range for stiffness coefficients. (X axis, Y axis) Unit: 10 ⁻³ mm/N	0.50	10.00
12	Force sense control gains 2 Z (2)	Set the learning range for stiffness coefficients (Z axis). Unit: 10 ⁻³ mm/N	0.50	10.00
13	Force sense control gains 2 C (2)	Set the learning range for stiffness coefficients (C axis). Unit: 10 ⁻³ deg./ (N·m)	0.50	10.00
14	Speed 3 (3)	Speed used until the push-in movement is completed. Unit: mm/s	10.00	30.00
15	Stiffness coefficients 3 XY (3)	Set the learning range for stiffness coefficients. (X axis, Y axis) Unit: N/mm	0.00	5.00
16	Stiffness coefficients 3 AB (3)	Set the learning range for stiffness coefficients. (A axis, B axis) Unit: N·m/deg.	0.00	5.00
17	Force sense control gains 3 XY (3)	Set the learning range for stiffness coefficients. (X axis, Y axis) Unit: 10 ⁻³ mm/N	0.50	10.00
18	Force sense control gains 3 AB (3)	Set the learning range for stiffness coefficients. (A axis, B axis) Unit: 10 ⁻³ deg./N·m	0.50	10.00

10.2.3.3 Contact detection




Fig. 10-24: Force sense movement creation screen (step 2) (contact detection)

The following table shows setting items for contact detection.

Table 10-14: Setting items for the contact detection movement

Setting Item	Description
Start posture	Teach the start posture with which the movement starts. Click the [Teach] button to enter the current position data of the robot.
Tool movement direction	Select a direction for the movement.
Operation completion condition	Set the conditional expression used to determine the completion of the movement. Click the [Set] button to display the operation completion condition setting screen.
Movement speed limit	Set the maximum speed value for the movement.
Force limit	Set the maximum acting force value for the movement. When the force sensor data exceeds the setting value, no more force is applied.
Detail settings	Set parameters for contact detection and the automatically adjustable parameters. Recommended values are initially set for contact detection. Click the [Detail] button to display the setting screen. Set the parameters according to each work environment.

(1) Start posture and direction of force sense movement

Enter position data in the X to Z, A to C, L1, and L2 fields of the start posture.

Click the [Teach] button to read the current position, and data will be set in the X to Z, A to C, L1, and L2 fields.

Select the direction from the start position for each axis.

Select "Do not" for the axes with no position change. (Specify them in the tool coordinate system.)

Refer to Fig. 10-25 for the start posture and direction of the movement.




Fig. 10-25: Start posture and direction of movement (contact detection)

(2) Conditions to determine an operation has finished

Set a conditional expression to determine when an operation has finished. In addition to the use of a conditional expression, robot movement is monitored to detect when it has stopped. After conditions determining that the operation has finished have been satisfied, it is determined that the operation has finished once the robot has stopped moving.

Click the [Set] button in the operation completion condition section (2) to display the operation completion condition setting screen.

Refer to “10.2.3.4 How to set conditions to determine an operation has finished” for description on how to set the conditional expression.




Fig. 10-26: Conditions to determine an operation has finished

[Setting example]

(Example)

When the push-in force in the Z direction falls within ± 0.5 N of the setting value, it is determined that the operation has finished.

(The push-in force is the force set in the force limit field.)




Fig. 10-27: Conditions to determine an operation has finished

When the conditions remain unsatisfied after the predetermined time, a time-out error will occur and the operation will be determined as failed. A threshold value for the time-out error can be set in the advanced settings (4).

(3) Limiting speed and force

Set the maximum speed and the acting force limit values for the movement.

Make sure to specify these values since they are used as limit values when combinations of parameters are changed during learning operation. The upper and lower limit values can be changed also in the advanced settings (4).




Fig. 10-28: Speed and force limit settings (contact detection)

<Movement speed limit>

The setting is used as the upper limit for the robot movement. (Unit: mm/s)

Set an appropriate speed to avoid a high impact force.

<Force limit>

The setting is used as the upper limit of the acting force for force sense control. (Unit for X, Y, Z: N, unit for A, B, C: Nm)

Set an appropriate value to avoid damaging the workpiece.

**CAUTION**

Learning is required for parameters for the movement created using the wizard function. The workpiece may be brought into contact with the other object with a high impact force during learning while different combinations of various parameters are tried in the learning range. Set appropriate limit values for speed and force for the sake of safety.

**CAUTION**

Since the speed and force limit settings are applied to the command values, the sensor values may temporarily exceed the limit values.

Note that changing the force limit setting values is not effective as a precaution to reduce the impact force since the speed setting is a critical factor. Set a low enough speed.

(4) Advanced settings

<Advanced settings for contact detection>

Parameters other than automatically adjusted parameters are specified for the movement. Recommended values are initially set. The settings can be changed as required for each work environment.

<Learning range for automatically adjusted parameters>

Automatically adjusted parameters are specified for the movement.

Set the maximum and minimum values to set the learning range when searching for the optimum combination of parameters.

Recommended learning range values are initially set. The settings can be changed as required for each work environment.

When the settings are completed, click the [Next] button to continue to the next step, 10.2.4 Learning setting.




Fig. 10-29: Advanced settings for contact detection

Advanced settings for contact detection

The workpiece is moved in the specified direction with force control from the start position.

1. The workpiece is moved in the predetermined direction with force control in speed priority mode.
2. When the workpiece is brought into contact with the other object and a force equal to or higher than the mode change judgment value is detected, the control mode is switched to force priority mode to push the workpiece with the commanded force.
3. When the completion condition is satisfied, force sense control is terminated.




Fig. 10-30: Advanced settings for contact detection

Table 10-15: Setting items of the contact detection movement

No.	Setting Item	Description	Initial value	Property
1	Stand-by time before starting	Duration to wait for a robot arm to stop at the start position of the movement. Unit: s	1.00	Changeable
2	Time-out time	Specify the time-out time for the movement. When the movement cannot be completed within the specified period, the result is judged as failed. The movement is terminated and the control returns back to the main program. Unit: s	30.00	
3	Timer No.	Specify the M_Timer number for counting time in the library. Specify an unused number.	8	

Table 10-16: Learning range for automatically adjusted parameters (contact detection)

No.	Setting Item	Description	Minimum	Maximum
1	Speed command value	Set the learning range of the speed command value. Unit: mm/s	5.00	20.00
2	Force sense control gain	Set the learning range of the force sense control gains. Unit: 10^{-3} mm/N	0.50	10.00

10.2.3.4 How to set conditions to determine an operation has finished

<Conditional expression>

State a conditional expression used to determine the switching point or completion of movement (160 characters maximum).

Arithmetic expressions cannot be used in conditional expressions. To calculate values used in conditional expressions, use arithmetic expressions separately (see the description of arithmetic expression below).

(If any syntax error such as an operational expression error exists, an error message appears when the [Set] button is clicked.)

<Arithmetic expression>

For example, to specify a position 10 mm below the current position as the movement switching point, the result of calculation using an arithmetic expression (160 characters maximum) can be stored in a variable, and the variable can be used in the conditional expression as shown below.

Example) Specifying a position "10 mm below the current position"

Arithmetic expression: MValue1 = P_Fbc.Z - 10

Conditional expression: P_Fbc.Z <= Mvalue

How to create conditional expressions

The following example shows how to create a conditional expression.

<Example of conditional expression> Movement is complete when 20 N or more of force sensor data is detected in the minus Z direction.

$$\frac{\text{P_FsCurD.Z}}{(a)} \frac{}{(b)} \frac{}{(c)} \frac{-20}{(d)}$$

(a) Specified data (see Table 10-17.)

(b) Directional component

(c) Comparison operator

(d) Numerical data (see Table 10-18.)

Table 10-17: Specified data used in the conditional expression of force sense movement

Specified Data	Description
P_Curr	Robot current position (XYZ data)
P_Fbc	Robot FB position (XYZ data)
J_Curr	Robot current position (joint data)
J_Fbc	Robot FB position (joint data)
P_FsCurP	Position command after offsetting with force sense control
P_FsCurD	Force sensor data (Values after offset has been canceled and tool/XYZ coordinates have been converted)

Table 10-18: Numerical data used in the conditional expression of force sense movement

Numerical Data
Numeric constant
Numeric variable: MValue 1 to 4
Component data of position variables
Component data of joint variables



CAUTION

Arithmetic expressions cannot be used to represent numerical data. Arithmetic expressions can be set in MValue1 to 4. Variables Mvalue1 to 4 can be used as numerical data in conditional expressions.

Example of arithmetic expression)

MValue1 = P_Fbc.Z - 30

Up to four conditional expressions can be used in combination with And/Or operators.

<Example of conditional expression>

(P_FsCurD.Z <= -20 And P_Fbc.Z < Mvalue1) Or (△△△△△ And □□□□□)

Conditional expression A Conditional expression B Conditional expression C Conditional expression D

Insertion of variables

Right-click in the field of the conditional or arithmetic expression to insert variables.




Fig. 10-31: Insertion of variables

Table 10-19: Variables available for insertion

Type	Variable	Variable to be inserted
Position (XYZ)	Current position	P_Curr.X to C
	Feedback position	P_Fbc.X to C
	Force sense control offset position	P_FsCurP.X to C
Position (joint)	Current position	J_Curr.J1 to J6
	Feedback position	J_Fbc.J1 to J6
Force	Force sensor data	P_FsCurD.X to C
	Resultant force	M_FsRsltF
	Resultant moment	M_FsRsltM
Signal	Input signal	M_In(n) *n: signal No.
	Output signal	M_Out(n) *n: signal No.
Local variable	Start position	PG_Start.X to C
	Numeric variable 1 to 4	MValue1to 4

10.2.4 Learning setting

Set conditions for learning to adjust control parameters automatically.

[Step 3. Learning setting]

1. Set the permissible force for the movement. (Acting force)
2. Set the number of times for repeating the operation for learning and the condition for convergence.
3. Enter the name of the learning program(Note 1). (When the function is started using the menu in the project tree)

Click the Finish button to continue to the next step, "10.2.5 Saving force sense movements".




Fig. 10-32: Learning setting screen (step 3)

(1) Acting force

Set the permissible force for the movement. Movement is learned to make the tact time as short as possible on condition that the resultant force in X, Y, and Z directions does not exceed the setting in this field. Unit: N

CAUTION: Note that the force higher than the setting may be applied during learning.

(2) Trial times

The number of times for repeating the operation to adjust control parameters is displayed in this field. The value calculated according to the setting in the trial time field on the detail screen is displayed in this field.

(3) Learning program name

Enter the name of the program when the function is started using the menu in the project tree.

When the settings are complete, a learning program template is created with the name set in this field.

When the function is started using the "Insert force movement" menu on the program edit screen, the command for the operation will be inserted on the line indicated by the cursor.

(4) Detail settings

Set the [Detail] button to change the trial times or convergence condition.




Fig. 10-33: Detail setting screen

Table 10-20: Advanced settings

Setting Item	Description
Trial times	<p>Set the number of cycles for repeating the operation for each sample. The calculation result will be displayed on the learning setting screen.</p> <p><Number of times> = <Number of samples^(Note 2)> × <Number of cycles></p> <p>* When the number of repetition is increased, the learning performance will be improved. However, the time taken to converge learning becomes longer.</p>
Convergence condition	<p>Set the learning convergence conditions.</p> <p>Set the number of cycles for the operation without update of the average evaluation value of each learning sample for the relevant parameter.</p> <p>When the operation is repeated for the set number of cycles without update, it is determined that convergence is complete.</p> <p><Number of times> = <Number of samples^(Note 2)> × <Number of cycles></p>

Note 1) The name of the learning program is required only when the function is started using the menu in the project tree.

The name field is not displayed when the function is started using the menu on the program edit screen.

Note 2) The number of samples are fixed for each movement for interactive programming using the wizard function.

10.2.5 Saving force sense movements

Save the sub-program and create a program template.





Fig. 10-34: Saving the movement

(1) Save the movement.


- 1) Click the [Complete] button to display the save force movement screen.
- 2) Select the number of the line on the screen to save the movement. When the existing number is selected, the setting are overwritten. The selected number is displayed in the learning # field.
- 3) Enter a title of the operation (with learning function) in the 64-byte field and click the [OK] button.



(2) Template for learning program


(2)-1 When the function is started using the menu in the project tree

- 1) A learning program with a name specified in the learning setting screen is created and opened.
- 2) Sub-programs for force sense movements are created.



(2)-2 When the function is started using the menu on the program edit screen

- 1) The learning part will be inserted at the cursor position on the program edit screen.



Following sub-programs are created for the corresponding movements.

Table 10-21: Applications and sub-program names

No.	Force sense movement	Sub-program name
1	Insertion and fitting	FSINSERT
2	Phase match insertion	FSALIGN
3	Contact detection	FSDETECT

10.2.6 Editing the movement

The following section describes how to change settings for existing movements.


(1) Editing the movement

- 1) Select [Tool] > [Force extension] > [Force sensor] and double-click [Force movement list].
- 2) The edit force movement screen is displayed. Double-click the relevant line, or select the line and click the [Edit] button.
- 3) The force sense movement creation screen is displayed. Refer to “10.2.3 Force sense movement setting” and change the settings as required.
- 4) Set the acting force and the number of trial times on the learning setting screen (refer to 10.2.4 Learning setting), and click the [Complete] button to save the settings.

Note that setting is available only for the sub-program.

To change the start and end posture settings in an existing learning/operation program, change the arguments in the sub-program as required.

The start and end posture settings changed in 10.2.3 Force sense movement setting will be effective when the applicable basic template is inserted next time (10.3.2 Insertion of basic templates).



10.3 Creation of Learning Programs

Operation must be repeated for learning. Sub-programs created using the wizard function are programs for the movements with force sense control. To repeat operation for learning, it is necessary to create a learning program customized for each system using pre-processing, post-processing, and repeating instructions.

The operation must be repeated approximately 200 to 300 times before learning is complete (the number of repetition varies depending on the type of work or environment). When the number of times for insertion and removal is specified for parts, create a learning program with a flow process.

When factors such as the workpiece shape or position may vary in actual operation environment, assume maximum variation for learning. (For example, when the insertion axis may be tilted at an angle of ± 0.1 degree for pin insertion, intentionally set the start position with a 0.1-degree tilt for learning.)






Fig. 10-35: Repeated operation



10.3.1 Basic Templates used in the learning program

Use basic templates in the learning program.

The following section describes specifications of the program.



(1) How to implement movement

A CallIP command is used to implement sub-programs for force sense movement. The specified movement will start after a linear interpolation movement from the current position to the start position in the programmed operation. When the operating part may interfere with peripheral equipment, modify the program to move the robot to a safe position without any risk of interference before executing the CallIP command.

The syntax for each movement is as follows.

Table 10-22: Applications and sub-program names

No.	Force sense movement	Sub-program name
1	Insertion and fitting	FSINSERT
2	Phase match insertion	FSALIGN
3	Contact detection	FSDetect

FSINSERT

[Syntax]

CallIP "FSINSERT", <Learning No.>, <Start posture>, <End posture>,
<Offset cancel flag>, <Learning flag>

FSALIGN

[Syntax]

CallIP "FSALIGN", <Learning No.>, <Start posture>, <End posture>,
<Offset cancel flag>, <Learning flag>

FSDetect

[Syntax]

CallIP "FSDetect", <Learning No.>, <Start posture>, <Offset cancel flag>, <Learning flag>

Table 10-23: Description of arguments

Argument	Local variable name	Description
Learning No.	MIdx	Specify the mechanism number.
Start posture	PStart	Set the start position.
End posture	PEnd	Set the end position.
Offset cancel flag	MCancel	Used to enable or disable the offset cancel (sensor origin offset) while the force sense control is enabled. Although the offset cancel operation must be performed regularly, the operation can be skipped to reduce the tact time when it has been already performed. 1: Offset cancel enabled 0: Offset cancel disabled
Learning flag	MLearn	Used to enable or disable learning. While learning is enabled, the tact time or the acting force changes every time since various parameter settings are tried. Always disable learning during actual operation. 1: Learning enabled 0: Learning disabled

(2) Conditions to finish learning

After the sub-program is implemented by CallP, reference the status variable M_ApAns(1) to check the learning result. When the value in M_ApAns(1) is 0 or less, learning is not finished. In the basic template, operation will be repeated until the learning is finished (the number of trial times is exceeded or the convergence condition is satisfied).

When additional learning is required for operation for which learning has been finished (the number of trial times set using the wizard function has been exceeded), learning can be restarted by changing the condition to finish learning to "convergence condition satisfied" only.

Table 10-24: Description of the returned value


Returned value	Description
-1	Time-out, or the predetermined acting force exceeded
0	Learning not finished (number of trial times less than the setting)
1	Learning finished (number of trial times equal to or more than the setting)
2	Convergence condition satisfied (predetermined convergence condition satisfied)

10.3.2 Insertion of basic templates


Basic templates can be inserted on the program edit screen.

(1) Inserting a template in a new program

- 1) Create a new learning program and move the cursor to the command line to which the template is inserted.
- 2) Select [Insert force movement] on the right-click menu.
- 3) The insert force movement screen is displayed. Select the template of the sub-program to be inserted and click the [OK] button.



- 4) The sub-program will be inserted on the line indicated by the cursor mentioned in step 1). According to the settings in the create force movement screen, the start posture setting is substituted to PStart and the end posture setting is substituted to PEnd. Change the start posture (PStart) and end posture (PEnd) settings as required.



(2) Using a saved template

When the wizard function is started using the menu in the project tree, a learning program with the template is created by saving the sub-program. Create a learning program using the program with the name set in the program name field in the learning setting screen.

The start and end posture settings set in the create force movement screen will be inserted into the lines "PStart" and "PEnd". Change the start posture (PStart) and end posture (PEnd) settings as required.

- 1) Create a new learning program and move the cursor to the command line to which the operation is inserted.

New learning program

Workspace

- lay1
 - 3D Monitor
 - RC1
 - Simulation
 - RV-4FRL-D
 - Operation Panel
 - Program
 - 1
 - 2
 - 123
 - TEST**
 - FSINSERT
 - Splin

Learning program
(program name set in the name field on the learning setting screen)

Program 1: RC1 TEST.r (Simulation) [MELFA-BASIC VI]

```

1  ' MELFA SmartPlus Extended function of force sensor
2  ' Learning program
3  ' +-----+-----+-----+-----+
4  ' --- Describe pre-processing ---
5
6
7
8  ' --- Force movement setting ---
9  MIdx = 1 'Learn#
10 MCancel = 1 'Offset cancel specification (0:not execute/1:execute)
11 MLearn = 1 'Execution mode specification (0:operation/1:learning)
12 MRslt = 0 'Variable for storing operation result
13
14 ' --- Learning ---
15 ' Repeat learning operation until MRslt becomes 1 or more
16 ' MRslt(-1:operation failed /0:learning not completed /1:trials times el
17 While MRslt<=0
18   CallP "FSINSERT", MIdx, PStart, PEnd, MCancel, MLearn
19   MRslt = M_ApAns(1)
20   GoSub *Extraction
21 WEnd
22 Hit
23 End
24
25 *Extraction
26 ' --- Describe post processing ---
  
```

Movement implementation part

10.3.3 Addition of pre-processing/post-processing operation

Customize pre-processing and post processing operations such as opening and closing of the hand for each system. See the example below to modify the program to repeat operation for learning.

In addition, when haptic control ON (during execution) / OFF (end time) is executed in the haptic program subprogram and the haptic control function is used in pre-processing and post-processing, the haptic control is used each time it is necessary to execute control ON / OFF. In addition, although program override and linear designated speed have been changed in the subprogram, after subprogram execution, it returns to the customer designated program override and linear designated speed.

<Learning program example>




Fig. 10-36: Program example for repeated learning

10.4 Implementation of Learning

Start learning by implementing the created learning program. The progress of the learning process can be checked on the learning monitor screen. Repeat the learning program until the learning is converged.



CAUTION

Since various parameter settings are tried with significant changes in the tact time or the acting force during learning operation, operation will not be stable until the learning is converged. Disable the learning function during actual operation.

10.4.1 Learning monitor

Check the progress of learning on the learning monitor screen.

1) Start the learning monitor.

Select [Tool] > [Force sensor] > [Learning monitor].




Fig. 10-37: Learning monitor

Table 10-25: Description of the learning monitor screen

Data	Description
Maximum evaluation value	Transition of the maximum evaluation value after the learning is started is displayed. (Global best value)
Average evaluation value	The average of the maximum evaluation values of all samples (local best values) is displayed. (Average of local best values)


<How to read the graph>

The number on the horizontal axis represents how many times a series of processes has been performed for the learning sample. The value on the vertical axis represents the evaluation value for the learning sample. The maximum evaluation value and the average evaluation value will be plotted every time the number of trials increases. When the learning monitor screen is closed, the plotted graphs will be deleted, and therefore caution is advised.

When the learning monitor screen is opened during learning, the values after the opening of the screen will be plotted.

As convergence proceeds, the maximum evaluation value will become stable, and the difference between the average value and the maximum value will be reduced gradually as shown below.

When the learning program created using the wizard function is used and the learning fails (time-out, or predetermined acting force exceeded), -1 will be returned as the evaluation value.



10.4.2 Interruption/resumption of learning

Learning data are saved every time the operation is performed.

When the program is interrupted or reset during learning, the learning process can be resumed with the previous learning data saved before the interruption or resetting by re-running the program. However, learning must be started from the beginning if the sub-program has been edited.

10.5 Creation of Operation Programs

After the learning is finished, edit the program used for actual operation.

To change the mode of the sub-program from learning to operation, change the value of MLearn from 1 to 0 in the movement implementation part of the program inserted in "10.2.5 Saving force sense movements".

Optimum settings obtained through learning for relevant parameters will be fixed for actual operation.

```

7  '
8  ' --- Force movement setting ---
9  MIdx = 5 'Learn#
10 MCancel = 1 'Offset cancel specification (0: not execute / 1: execute)
11 MLearn = 1 'Execution mode specification (0: operation / 1: learning)
12 MRslt = 0 'Variable for storing operation result
13 ' --- Learning ---
14 While MRslt <= 0
15   CallP "FSINSERT", MIdx, PStart, PEnd, MCancel, MLearn
16   MRslt = M_ApAns(1)
17   GoSub *Extraction
18 WEnd
19 Hlt
20 End

```

10.6 Customized Learning

This section describes how to use the learning function without using the wizard function in other robot programs selected by users. The learning function can be used in customized programs for optimizing operation for movements not supported by the wizard function.

The terms learning parameter and learning sample used in this section are defined as follows.


Table 10-26: Definition of terms

Term	Description
Learning parameter	<p>Parameter to be optimized using the learning function. Up to 20 learning parameters can be set.</p> <p>Learning parameter 1 Learning parameter 2 ... Learning parameter 20</p>
Learning sample	<p>A set of learning parameters. Up to 50 learning samples can be set.</p> <p>Learning sample 1 Learning sample 2 Learning sample 50</p>

<Schematic overview of the learning process>

When two learning parameters are optimized using four learning samples, learning samples 1 to 4 are randomly located in the search range as shown in the following diagram. The best combination of parameters is searched for by repeating the learning process.

After the learning is finished, learning samples are converged into one point.



The following describes how to create programs for learning.

10.6.1 Initial setting of the learning function

The number of learning parameters, search range settings (maximum and minimum values) for each parameter, and number of learning samples must be set for learning.

Set a value in each of status variables: M_OptmzSamples, M_OptmzParams, M_OptmzParamMin, and M_OptmzParamMax, and execute the OptmzInitialize command.

M_OptmzParams (Number of learning parameters)

Set the number of parameters to be optimized using the learning function. Up to 20 parameters can be set.

M_OptmzParamMin / M_OptmzParamMax (Learning parameter range, maximum/minimum value)

Set the maximum/minimum value for each learning parameter. Different combinations of various parameters are tried in the learning range set by the values in these variables.

(Example)

M_OptmzParamMin(1) = 0

M_OptmzParamMax(1) = 50



CAUTION

Carefully set the upper limit value for the speed for optimization of the speed as different combinations of various parameters are tried in the learning range. When the setting value is large, the workpiece may be brought into contact with the other object with a high impact force during learning. Set a value equal to or less than 50 mm/s.

M_OptmzSamples (Number of learning samples)

Sets the number of learning samples. Up to 50 samples can be set. * When the number of samples increase, the learning performance will be improved. However, the time taken to converge learning becomes longer.

Set a value about one to two times as large as the number of learning parameters.

Example) M_OptmzSamples = 4

OptmzInitialize (Initialization)

OptmzInitialize (optimize initialize)

[Function]

Initializes learning parameters in the course of using the learning function.

[Syntax]

OptmzInitialize

[Terminology]

None

(Refer to “12.9 Status Variables Relating to Learning Function” and “12.11 Related Status Variables for MELFA Smart Plus” for details on commands and status variables related to the learning function.)

10.6.2 Setting of evaluation values for learning

Evaluation values for learning must be set as pass/fail criteria of operation. Evaluation values can be set by arithmetic expressions using status variables chosen by users. The evaluation value will be reflected in the learning sample by executing the OptmzEvaluate command.

<Evaluation value calculation example>

(Example 1) Evaluation of the operation time

```
M_Timer(8)=0          'Timer 8 clear
'Movement started
...
'Movement finished
MTime = M_Timer(8)    'Check the operation time.
MEval1 = 1 / MTime    'Create the evaluation value. (faster the higher)

OptmzEvaluate 1, MEval1  'Reflect the evaluation value in learning sample 1.
```

(Example 2) Use of the acting force as the evaluation value

```
MEval2 = 1 / M_FsRsltFMax 'Calculate the inverse of the maximum value of the acting force.
                          '(Smaller of the maximum values)
OptmzEvaluate 1, MEval2  'Reflect the evaluation value in learning sample 1.
```

OptmzEvaluate (optimize evaluate)

[Function]

Reflects the evaluation result of the work to the learning in the course of using the learning function.

[Syntax]

```
OptmzEvaluate <Learning sample No.>, <Evaluation value>
```

[Terminology]

<Sample No.> Specify the learning sample No.

Setting range: 1 to the number of learning samples (Value of status variable M_OptmzSamples)

<Evaluation value> Set the evaluation value of the specified learning sample.

(Refer to section “12.9 Status Variables Relating to Learning Function” for details on status variables.)

10.6.3 Updating the learning parameter

Learning parameters will be updated by executing the OptmzUpdate command after reflecting evaluation values in all learning samples. An error will occur if any sample in which its evaluation value has not been reflected using the OptmzEvaluate command exists.

OptmzUpdate (optimize update)

[Function]

Updates the learning parameter in the course of using the learning function.

[Syntax]

OptmzUpdate

[Terminology]

None

(Refer to section “12.9 Status Variables Relating to Learning Function” for details on status variables.)

<Program example>

```

Epoch = 0
*Learn
If Epoch >= 20 Then GoTo *Fin 'Specify the trial times.
For Idx = 1 To M_OptmzSamples 'Repeat the operation and evaluation for the number of samples.
    'Acquire values of learning parameters.
    MGn1 = M_OptmzParamVal(Idx,1) 'Gain
    '
    P_FsGn0.X = MGn1 '[Learning] Set the force sense control gain.
    P_FsGn0.Y = MGn1 '[Learning] Set the force sense control gain.
    '
    'Preparation before starting the movement
    Mov PStart
    Dly 1
    '
    'Start the movement.
    Fsc On, 0, 0, 1
    *Loop If P_Fbc.Z > PEnd.Z Then GoTo *Loop 'Loops until the target position is passed over.
    MTime = M_Timer(8)
    Fsc Off
    '
    'Calculate the evaluation value.
    MEval = 1 / MTime 'Use the inverse of the operation time as the evaluation value.
    '
    'Reflect the evaluation result in the learning.
    OptmzEvaluate Idx, MEval 'Set the evaluation value.
Next
OptmzUpdate 'Update the learning parameter values based on the evaluation
value.
Epoch = Epoch + 1
GoTo *Learn

```

10.6.4 Saving and reading of learning data

Learning data can be saved using the OptmzSave command, and can be read using the OptmzLoad command. After the learning is finished, always execute the OptmzSave command to save learning data. Data can be saved in the course of learning. When learning takes time, it is possible to save the data once and resume the learning later. Up to 10 files (learning number 1 to 10) can be saved.

Learning data after learning will be used to update each parameter using the status variable M_OptmzPrms.

OptmzSave (optimize save)

[Function]

Saves the learning result in the course of using the learning function.

[Syntax]

```
OptmzSave <Learning No.> [, <Overwrite flag>]
```

[Terminology]

<Learning No.> Specifies the file No. to save the learning result.
Setting range: 1 to 10

<Overwrite flag> Specify whether to overwrite when the specified file already exists.
0: Do not overwrite

1: Overwrite

(If omitted, the file is not overwritten.)

(Example) Saving learning data

```
OptmzSave 1          'Save the learning data in the learning No. 1 file.
```

OptmzLoad (optimize load)

[Function]

Reads the learning result in the course of using the learning function.

[Syntax]

```
OptmzLoad <Learning No.>
```

[Terminology]

<Learning No.> Specifies the file No. to save the learning result.
Setting range: 1 to 10

(Example) Reading learning data

```
OptmzLoad 2          'Reads the learning data saved in the learning No. 2 file.
```

```
'Acquire the parameters after learning.
```

```
MV   = M_OptmzParamVal(1,1) 'Speed
```

```
MStf = M_OptmzParamVal(1,2) 'Stiffness coefficient
```

```
MGn  = M_OptmzParamVal(1,3) 'Gain
```

```
,
```

```
'Set the force sense control parameters (parameters after learning).
```

```
P_FsStf0.X = MStf   'Set the stiffness coefficient.
```

```
P_FsStf0.Y = MStf   'Set the stiffness coefficient.
```

```
P_FsGn0.X  = MGn    'Set the force sense control gain.
```

```
P_FsGn0.Y  = MGn    'Set the force sense control gain.
```


10.6.5 Learning program examples

To perform the following operation, robot program examples are shown below for learning and operation.

■ Operation

Assemble the part while tracking the shape of the mating part using force control to prevent excessive force applied to the parts.

- Insertion with limited stiffness control from PStart to PEnd
- Optimization of the stiffness coefficients (X axis, Y axis), force sense control gains (X axis, Y axis), and insertion speed by learning to limit the acting force to 5 N or less and to make the tact time as short as possible.



■ Program example

```
'=====
'   Learning setting and initialization
'=====
*LearnInit
'Learning setting
'Set the number of learning parameters.
M_OptmzParams = 3
'

'Search range setting for learning parameters
'(1) Speed
M_OptmzParamMin(1) = 20
M_OptmzParamMax(1) = 50
'(2) Stiffness coefficient
M_OptmzParamMin(2) = 0.5
M_OptmzParamMax(2) = 2.0
'(3) Gain
M_OptmzParamMin(3) = 2.0
M_OptmzParamMax(3) = 10.0

Sets the number of learning samples.
M_OptmzSamples = 5      'Number of samples
'

'Initialization of automatically adjusted parameters
OptmzInitialize
```

```

'
'=====
'      Learning
'=====
'Set the force sense control parameters.
'Control mode (0)
M_FsCod0=1                                'Force sense control coordinate system (1: XYZ
                                         coordinate system)
P_FsMod0=(+3.0,+3.0,+3.0,+3.0,+3.0,+3.0) 'Force sense control mode (3: Limited stiffness control)
P_FsDmp0=(+0.0,+0.0,+0.0,+0.0,+0.0,+0.0) 'Damping coefficient
P_FsStf0=(+0.5,+0.5,+0.5,+0.0,+0.0,+0.0)  'Stiffness coefficient
'Control feature (0)
P_FsFCd0=(+10.0,+10.0,+50.0,+3.0,+3.0,+3.0) 'Limit value
P_FsGn0=(+5.0,+5.0,+5.0,+2.0,+2.0,+0.0)    'Force sense control gain
'

MSamples = M_OptmzSamples
Epoch = 0
*Learn
If Epoch >= 20 Then GoTo *Fin 'Specify the trial times.
For Idx = 1 To MSamples      'Repeat the operation and evaluation for the number of learning samples.
    '
    'Acquire values of learning parameters for automatic adjustment.
    MV   = M_OptmzParamVal(1,1) 'Speed
    MStf = M_OptmzParamVal(1,2) 'Stiffness coefficient
    MGn  = M_OptmzParamVal(1,3) 'Gain
    '
    'Sets the force sense control parameters.
    P_FsStf0.X = MStf '[Learning] Set the stiffness coefficient.
    P_FsStf0.Y = MStf '[Learning] Stiffness coefficient setting
    P_FsGn0.X  = MGn  '[Learning] Set the force sense control gain.
    P_FsGn0.Y  = MGn  '[Learning] Set the force sense control gain.
    '
    'Preparation before starting the movement
    Mov PStart
    Dly 1
    '
    M_Timer(8) = 0
    '
    'Start the movement.
    Fsc On, 0, 0, 1
    Spd MV          '[Learning] Specify the speed.
    Mvs PEnd
    *Loop If P_Fbc.Z > PEnd.Z + 5 Then GoTo *Loop    'Loops until the target position is passed over.
    MTime = M_Timer(8)
    Fsc Off
    '
    'Evaluation of movement (learning)
    MEval1 = M_FsRsltFMax 'Maximum reaction force of the force sense movement
    MEval2 = MTime / 1000 'Work time [s]

```



```

If MEval1 >= 10 Then      'Set the evaluation value to -1 when the reaction force is 10 N or more
                           during work.
    MEval = -1
Else                      'Set the inverse of tact time as evaluation value when the reaction force
                           is 10 N or less (faster the better).
    MEval = 1/MEval2
Endif
'Reflect the evaluation result in the learning.
OptmzEvaluate Idx, MEval  'Update the parameter based on the evaluation value.
Next
OptmzUpdate              'Update the parameter values based on the evaluation value.
Epoch = Epoch + 1
GoTo *Learn
'
*Fin
OptmzSave 1,1            'Overwrites the learning result to learning No. 1.
Hlt

```

■ Description

- 1) As the number of learning parameters is 3, the number of learning sample is set to 5 (one to two times as large as the number of learning parameters).
- 2) The tact time of the force sense control part is measured using the M_Timer variable to be used for the evaluation value.
- 3) The inverse of the tact time is used as the evaluation value to rate the shorter tact time higher. When the acting force exceeds the limit, 1 is subtracted from the evaluation value to lower the rating significantly.
- 4) The learning result is saved in the learning No. 1 file after the learning is finished.

(Operation)

```

'Set the force sense control parameters.
'Control mode (0)
M_FsCod0=1                'Force sense control coordinate system (1: XYZ coordinate
                           system)
P_FsMod0=(+3.0,+3.0,+3.0,+3.0,+3.0,+3.0) 'Force sense control mode (3: Limited stiffness control)
P_FsDmp0=(+0.0,+0.0,+0.0,+0.0,+0.0,+0.0) 'Damping coefficient
P_FsStf0=(+0.5,+0.5,+0.5,+0.0,+0.0,+0.0) 'Stiffness coefficient
'Control feature (0)
P_FsFCd0=(+10.0,+10.0,+50.0,+3.0,+3.0,+3.0) 'Limit value
P_FsGn0=(+5.0,+5.0,+5.0,+2.0,+2.0,+0.0)    'Force sense control gain
'
OptmzLoad 1
'Acquire the parameters after learning.
MV   = M_OptmzParamVal(Idx,1) 'Speed
MStf = M_OptmzParamVal(Idx,2) 'Stiffness coefficient
MGn   = M_OptmzParamVal(Idx,3) 'Gain
'
'Set the force sense control parameters (parameters after learning).
P_FsStf0.X = MStf  'Set the stiffness coefficient.
P_FsStf0.Y = MStf  'Set the stiffness coefficient.
P_FsGn0.X  = MGn   'Set the force sense control gain.
P_FsGn0.Y  = MGn   'Set the force sense control gain.
'
'Move to start position.
Mov PStart

```

```
Dly 1
,
M_Timer(8)=0
'Start the movement.
Fsc On, 0, 0, 1
Spd MV           '[Learning] Specify the speed.
M_Timer(1) = 0
Mvs PEnd
*Loop If P_Fbc.Z > PEnd.Z + 5 Then GoTo *Loop      'Loops until the target position is passed over.
MTime = M_Timer(8)
Fsc Off
Hlt
End
```


11 Application Examples

11.1.1.1 Part Assembly Work (Force Control)

■ Operation details

Assembles parts so that no unnecessary force acts on the parts when following the part fitting shape.

- The robot is controlled using force control so that the force acting in the X- and Y- directions is 0.0 N.
- The work complete condition is defined in the Mo trigger, and work is completed by interrupt processing.



■ Program example <Sample program FA01.prg>

<pre> [Control mode (0)] P_FsStf0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsMod0 = (+1.00,+1.00,+1.00,+0.00,+0.00,+0.00)(0,0) M_FsCod0 = 0 [Control characteristics (0)] P_FsGn0 = (+3.00,+3.00,+3.00,+0.00,+0.00,+0.00)(0,0) P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsFCd0 = (+0.00,+0.00,+5.00,+0.00,+0.00,+0.00)(0,0) P_FsSpd0=(+0.00,+0.00,+10.00,+0.00,+0.00,+0.00)(0,0) P_FsSwF0=(+0.00,+0.00,+4.00,+0.00,+0.00,+0.00)(0,0) **** <Assembly work> *** Def MoTrg 1, ((P_Fbc.Z <= 151) AND (P_FsCurD.Z > 4.8)) Def Act 1,M_MoTrg(1)=1 GoTo *XOK,F Mvs PStart SetMoTrg 1 Fsc On,0,0,1 Act 1=1 M_Timer(1)=0 *LBL1:If M_Timer(1) < 5000 Then Goto *LBL1 Fsc Off Error 9100 End **** <Work completed> *** *XOK' Act 1=0 SetMoTrg 0 Fsc Off HOpen 1 P2=P_Fbc P2.Z=P2.Z+100 Mvs P2 End </pre>	<p>'Stiffness coefficient [N/mm]</p> <p>'Damping coefficient</p> <p>'Force control mode (X,Y,Z-axis force control)</p> <p>'Force sense control coordinate system (tool)</p> <p>'Force control gain [$\mu\text{m/N}$]</p> <p>'Force detection setting value [N]</p> <p>'Force control (X,Y-axis: 0.0 N, Z-axis: 5.0 N)</p> <p>'Sets speed control mode speed. (Z-axis: 10 mm/s)</p> <p>'Sets force/speed judgment value.</p> <p>'Work complete conditions defined for Mo trigger 1.</p> <p>'Mo trigger 1 defined as interrupt condition.</p> <p>'Robot moves over insertion position.</p> <p>'Mo trigger 1 is enabled.</p> <p>'Force sense control is enabled. (Insertion started with force control.)</p> <p>'Interrupt processing 1 is enabled.</p> <p>'Timer clear</p> <p>'Waits for timeout time of 5 seconds.</p> <p>'Force sense control is disabled.</p> <p>'Error occurs if insertion work not complete within 5 seconds.</p> <p>'Insertion work complete interrupt processing</p> <p>'Mo trigger is enabled.</p> <p>'Force sense control is disabled.</p> <p>'Feedback position acquisition</p> <p>'Target position determined as position +100 mm in Z-direction from current position.</p>
--	--

■Description


- 1) With force control, the robot is set to push with a force of 0.0 N in the X- and Y-directions, and 5.0 N in the Z-direction. Furthermore, if the reaction force in the Z-direction is less than 4 N, the robot moves at a speed of 10 mm/s in speed priority mode.
- 2) Work complete conditions are defined for Mo trigger 1 with the Def MoTrg command. (In this example, when $Z \leq 151$ mm and $F_{zt} > 4.8$ N, it is judged that insertion work is complete.)
- 3) After moving to the assembly start position, by enabling Mo trigger 1 followed by force sense control, insertion work is started automatically.
- 4) If insertion work is not completed within 5 seconds of work starting, a 9100 error is output and insertion work is stopped.
- 5) If insertion work is completed successfully, M_MoTrg(1)=1 and interrupt processing (label: *XOK) is performed.

11.1.1.2 Phase Focusing Push

■ Operation details

The robot inserts into a metal axis while searching for a d-cut gear phase.

- The robot rotates in the C-axis direction while pushing softly in the Z-direction with robot stiffness softened by stiffness control.
- When the gear and metal axis phases match, the moment around the Z-axis (M_z) increases.
- The M_z increase is detected and push work is started.



■ Program example <Sample program FA02.prg>

<pre> [Control mode (0)] P_FsStf0 = (+0.00,+0.00,+3.00,+0.00,+0.00,+0.50)(0,0) P_FsDmp0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsMod0 = (+2.00,+2.00,+2.00,+0.00,+0.00,+2.00)(0,0) M_FsCod0 = 0 [Control characteristics (0)] P_FsGn0 = (+2.50,+2.50,+2.50,+0.00,+0.00,+2.50)(0,0) P_FsFLm0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.05)(0,0) P_FsFCd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsSpd0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsSwF0 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) [Control characteristics (-1)] P_FsGn1 = (+2.50,+2.50,+0.00,+0.00,+0.00,+3.00)(0,0) P_FsFLm1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsFCd1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsSpd1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) P_FsSwF1 = (+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0) **** <Assembly work> *** Mvs PStart Dly 1 Ovrd 5 Fsc On,0,0,1 Mvs P1 start pos. Mvs P2 Wthif M_FsLmtR.C>0, Skip If M_SkipCq = 0 Then *LERR performed. FsGChg 0,10,-1 Mvs ,10 HOpen 1 Fsc Off Mvs PStart End *LERR Error 9100 End </pre>	<pre> 'Stiffness coefficient [N/mm] 'Damping coefficient 'Force control mode (X,Y,Z,C: stiffness control) 'Force sense control coordinate system (tool) 'Force control gain [μm/N] 'Force detection setting value [N] (Mz=0.05Nm) 'Force control 'Sets speed control mode speed. 'Sets force/speed judgment value. 'Force control gain [μm/N] (Z axis=0.0[μm/N]) 'Force detection setting value [N] 'Force control 'Sets speed control mode speed. (Z-axis: 10mm/s) 'Sets force/speed judgment value. ' Robot moves over insertion position. 'X,Y,Z,C-axes set to stiffness control. 'Robot moves to pos. pushed approx. 1 mm from assembly 'C-axis is rotated and skip occurs when Mz≥0.5 N·m. 'Proceeds to failure processing if skip processing not '"Control characteristics " changed to "-1". 'Tool moved 10 mm in +Z-direction. 'Error processing </pre>
---	--

■ Description

- 1) The robot is set to control the X-, Y-, Z-, and C-axes softly with stiffness control. The force detection setting value is $Mz = 0.05 \text{ N}\cdot\text{m}$.
- 2) Force control is enabled, and the robot moves to a position approximately 1 mm below of the insertion start position. (MvsP1)
- 3) The C-axis is rotated with the Mvs command. If a moment of $Mz \geq 0.05 \text{ N}\cdot\text{m}$ is detected during operation using a Wthif sub-clause, operation is stopped and skip processing is performed at the next step.
- 4) The gear is twisted in the C-axis direction while pushing in the Z-direction, and therefore when the D-cut gear and metal axis phases match, Mz increases. Wthif sub-clause conditions are established, and therefore rotation is stopped and skip processing is performed for the next command. (If skip processing is not performed, the system determines that phase detection has failed and error processing is performed.)
- 5) Control characteristics "0" is changed to "-1" using the FsGChg command so that the Z-axis control gain becomes 0.0. (If the control gain is 0, the robot is not controlled softly even if stiffness control is selected. Control will be the equivalent of position control.)
- 6) The robot moves 10 mm in the tool coordinate system Z-direction and assembly work is completed.

12 Language Specifications

This Chapter describes specifications for force sense control function related to MELFA-BASIC VI commands and status variables.

■□■ Precautions when using status variables ■□■

By directly referencing P variable A-, B-, and C-axis values as component data, they are read as radian unit values. If reading values for each component and creating a program, unit conversion is required. (See following example.)

<Example>

By replacing P_FsLmtR = (0, 0, 1, 2, 0, 0, 0, 0) A-axis component data for M1 such as M1 = P_FsLmtR.A, M1 is replaced not by 2, but by 0.034906 ($=2 \times \pi \div 180$). To replace M1 with 2, use the Deg function.

M1% = Deg(P_FsLmtR.A)

By changing parameter PRGMDEG setting to 1, the unit system when the P variable rotational axis component data is referenced is deg, and therefore there is no need to use the Deg function. (Refer to instruction manual "Detailed Description of Functions and Operation" for details on the Deg function and parameter PRGMDEG.)

12.1 Commands Relating to Force Sense Control Function

MELFA-BASIC VI commands relating to the force sense control function are described below.

Table 12-1: Force sense control commands

No.	Command	Function Overview
1	Fsc On	Enables the force sense control function using force sensor.
2	Fsc Off	Disables the force sense control function using force sensor.
3	FsGChg	Changes control characteristics for force sense control during operation.
4	FsCTrg	Sets force sense control characteristics switching with the Mo trigger.

Fsc On**[Function]**

Enables the force sense control function using force sensor.

[Syntax]

Fsc□On <Control mode>, <Control characteristics >, <Offset cancel designation>

[Terminology]

<Control mode> Specifies the force sense control mode No. (See section [8.1.2.](#))
Setting range: -1 - 9

Table 12-2: Control mode setting items and corresponding values

Setting Item	Control Mode					
	-1	0	1	2	-	9
Force sense control coordinate system	M_FsCod1	M_FsCod0	FSCOD01	FSCOD02	-	FSCOD09
Force control mode	P_FsMod1	P_FsMod0	FSFMD01	FSFMD02	-	FSFMD09
Stiffness coefficient	P_FsStf1	P_FsStf0	FSSTF01	FSSTF02	-	FSSTF09
Damping coefficient	P_FsDmp1	P_FsDmp0	FSDMP01	FSDMP02	-	FSDMP09
Force sensor bias value	P_FsBias1	P_FsBias0	FSBIAS01	FSBIAS02	-	FSBIAS09
Load center of gravity position	P_FsGrPos1	P_FsGrPos0	FSGRP01	FSGRP02	-	FSGRP09
Load mass	M_FsMass1	M_FsMass0	FSMASS01	FSMASS02	-	FSMASS09

<Control characteristics > Specifies the force sense control characteristics No. (See section [8.1.2.](#))
Setting range: -1 - 9

Table 12-3: Control characteristics setting items and corresponding values

Setting Item	Control characteristics					
	-1	0	1	2	-	9
Force command value	P_FsFCd1	P_FsFCd0	FSFCMD01	FSFCMD02	-	FSFCMD09
Speed command value	P_FsSpd1	P_FsSpd0	FSSPD01	FSSPD02	-	FSSPD09
Mode switching judgment value	P_FsSwF1	P_FsSwF0	FSSWF01	FSSWF02	-	FSSWF09
Force sense control gain	P_FsGn1	P_FsGn0	FSFGN01	FSFGN02	-	FSFGN09
Force detection setting value	P_FsFLm1	P_FsFLm0	FSFLMT01	FSFLMT02	-	FSFLMT09

<Offset cancel designation> Specifies whether to cancel the force sensor data offset component.
(zero point offset)
Setting value: 0 (Do not cancel)/1 (Cancel)
(For details, see section [8.1.3.](#))

[Example]

Refer to examples in section [12.12.](#)

[Description]

- (1) Enables the force sense control function using force sensor. (Default: Disabled)
- (2) The force sense control content is specified with the "control mode" and "control characteristics " condition Nos. set beforehand.
- (3) If the force sensor is not connected and this command is executed, error L3986 occurs.
- (4) This command cannot be executed when the force sense control function is enabled (error L3987 occurs.) If changing the "control mode" or "control characteristics ", execute the Fsc Off command to disable the force sense control function, and then execute the Fsc On command again. However, the "control characteristics " can be changed during operation using the FsGChg command or FsCTrg command.
- (5) "Control mode" and "control characteristics " 1 to 9 use setting values for each corresponding parameter. (Refer to Table 12-2 for details of setting items contained in control mode and control characteristics.)
- (6) If the "control mode" or "control characteristics " is 0 or -1, conditions set with dedicated status variables are used. The default status is the same setting as if "control mode" and "control characteristics " 1 is specified. (Refer to Table 12-2 for details of setting items contained in control mode and control characteristics.)
- (7) If the offset cancel designation is 1, force sensor data becomes 0 for all axes when this command is executed, and the sensor offset component is offset (zero point offset). No offset is made if the offset cancel designation is 0.
- (8) If the offset cancel designation is 1 and a value is set in the following data specified in the <control mode> (force sense calibration executed), the offset component cancel data is updated in sequential consideration of the load while the force sense control is turned on.
 - Force sensor bias value
 - Load center of gravity position
 - Load mass
- (9) If the offset cancel designation is 1, execute this command after the robot stops completely. If the command is executed immediately after the movement, the zero point offset may not be performed properly due to an inertial force.
- (10) The force sense control enabled/disabled status and "control mode"/"control characteristics" settings are common to both AUTOMATIC and MANUAL modes.
- (11) Even if an interpolation continuous command is specified with the Cnt command, the command is executed after waiting for the robot movement to be completed.
- (12) Force sense control is disabled by performing a program reset or executing an End command. (See Fig. 12-1.)
- (13) Force sense control processing functions only when the servo is ON. Even if force sense control is enabled, force sense control processing is not performed while the servo is OFF. If the servo is turned OFF while performing force sense control processing, processing is stopped. Force sense control processing is then resumed by turning the servo ON again. (See Fig. 12-1.)




Fig. 12-1: Force sense control function status transition

- (14) When force sense control is not being performed, force sensor data checks using the force detection setting value are not performed.
- (15) The force sense control function and functions listed in Table 12-4 cannot be used at the same time.

Table 12-4: Behavior with simultaneous used with force sense control function

Function	Behavior with Simultaneous Use	Error
Compliance control (Cmp command)	Priority is given to the function enabled first.	L3986
Collision detection (ColChk command)	Priority is given to the force sense control function. If force sense control function is enabled while collision detection is enabled, collision detection is disabled. If force sense control function is then disabled, collision detection returns to the status specified at that time.	L3986 *1
Tool/base coordinate system conversion (Base/Tool command, etc.)	Tool/base conversion data is not changed while force sense control is enabled.	L3986
Jrc command	The Jrc command cannot be executed while force sense control is enabled.	L3986
Continue function	The force sense control function is not compatible with the continue function.	-

* 1: An error occurs if collision detection is enabled with the ColChk command during automatic operation and when the force sense control function is enabled.

- (16) If positioning complete is executed with the Fine J command (joint)/Fine P command (linear) while force sense control is enabled, there may be times when the robot is unable to arrive at its target destination due to the external force acting on the force sensor, preventing positioning from being completed. If executing positioning complete, use the Fine command (pulse).
- (17) If changing both the force sense control and tracking functions from an enabled status to disabled status when performing automatic operation, first execute the Trk Off command to disable the tracking function, and then disable force sense control with the Fsc Off command. If the Fsc Off command is executed first, an L2750 error occurs.
- (18) Even if force sense control is enabled, a user defined area and free plane limit check are performed by referencing the position command. The force sense position command is not referenced.

Fsc Off

[Function]

Disables the force sense control function using force sensor.

[Syntax]

Fsc□Off

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Disables the force sense control function using force sensor.
- (2) If the force sensor is not connected, no processing is performed when this command is executed.
- (3) Similarly, no processing is performed when this command is executed while the force sense control function is disabled.
- (4) The "position command" changes to the "force sense position command" when force sense control becomes disabled.

FsGChg (Fs gain change)**[Function]**

Changes control characteristics for force sense control during operation.

[Syntax]

FsGChg <Change start time>, <Change time>, <Control characteristics group No. after change>

[Terminology]


- <Change start time> Specifies the position at which the control characteristics setting change is started. This is specified with an interrupt during the next interpolation command start point and end point.
Setting range: 0 - 100 [%]
- <Change time> Specifies the time taken to change the control characteristics setting. The force detection setting value and mode switching judgment value change immediately, regardless of this specification.
Setting range: 1 - 1000 [ms]
- <Control characteristics group No. after change> Specifies the control characteristics group No. applied after the change.
Setting range: -1 to 9

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Changes the force sense control function control characteristics from the current setting to the specified control characteristics.
- (2) After executing this command, when the command position reaches the specified change start position, the control characteristics change is started for the first interpolation command. (The force detection setting value changes immediately when this position is reached.)
- (3) The force sense control gain and force command are changed to the setting values specified with "Control characteristics " over the time set in <Change time>.



Example 1: If change start position is 30%

- (4) If the force sensor is not connected, no processing is performed when this command is executed.
- (5) This command cannot be executed when the force sense control gain and force command are being changed (when the change time has not elapsed). (Error L3987)
- (6) If the force sense control function is disabled without executing the interpolation command, this command will be disabled.
- (7) The "Control characteristics " change specification can only be executed during automatic operation. If operation is interrupted before starting the change and the controller mode is switched from AUTOMATIC to MANUAL, change processing becomes invalid at that point.
- (8) When the force sense control gain and force command are being changed (when the change time has not elapsed), processing of these changes is continued until completion, even if the force sense control function is disabled.
- (9) After executing this command, the command specification also becomes invalid when the force sense control function is disabled, without executing the interpolation command.

FcCTrg (FsC trigger)**[Function]**

Sets force sense control characteristics switching with the Mo trigger.

[Syntax]

FsCtrg <Trigger No.>, <Change time>, <Control characteristics group No. after change>
[, <Timeout>, <Execution method> [, <Error specification>]]

[Terminology]

- <Trigger No.> Specifies the Mo trigger No. used to change the control characteristics with a constant.
Setting range: 1 - 3
- <Change time> Specifies the time taken to change the control characteristics.
The force detection setting value and mode switching judgment value change immediately, regardless of this setting.
Setting range: 1 – 1000 [ms]
- <Control characteristics group No. after change>
Specifies the control characteristics group No. applied after the change.
Setting range: -1 to 9
- <Timeout> Specifies the Mo trigger timeout monitoring time with a constant.
Setting range: 0 – 60 [s]
If omitted, timeout processing is not performed.
- <Execution method> Specifies the timeout monitoring execution method for this command with a constant.
0: Proceeds to next program without waiting for Mo trigger ON.
1: Does not proceed to next program until Mo trigger turns ON or timeout reached.
- <Error specification> Specifies whether an error occurs following a timeout.
0: Error occurs.
1: Error does not occur.
An error occurs following a timeout if omitted.

[Example]

```

1 Def MoTrg 3, (P_Fbc.Z < 100)      'Defines Mo trigger No.3.
2 Fsc On, 1, 1, 1                    'Enables force sense control.
3 FsCTrg 3, 100, 2                  'Enables Mo trigger No.3 and changes the control characteristics from 1 to 2 when the trigger turns ON.
4 Mvs P1

```

[Description]

- (1) Sets force sense control characteristics switching with the Mo trigger.
- (2) By executing this command, the Mo trigger for the specified trigger No. is enabled, and the control characteristics is changed when the trigger turns ON. When the control characteristics change is complete, the change setting with this command will become unset.
- (3) If this command is executed when the Mo trigger is disabled, the Mo trigger for the specified trigger No. is enabled.
- (4) If the Mo trigger for the specified trigger No. is undefined, an error occurs when the program is run. (Error L.3770)
- (5) If an Mo trigger for a different No. than that specified for <Trigger No.> is currently enabled, the enabled trigger is disabled, and the Mo trigger specified for <Trigger No.> is enabled.
- (6) After starting the change, the control characteristics "force sense control gain" and "force specification value", and "speed command value" are changed to linear values toward the <Control characteristics group No. after change> control characteristics setting, over the time set in <Change time>. The "force detection setting value" and "mode switching judgment value" change immediately, regardless of this setting.
- (7) If a <Timeout> is specified, an error occurs after executing this command if the Mo trigger turns ON and control characteristics change is not completed within the specified time. (Error L.3987)

- (8) If program execution is interrupted, the timeout processing count up is also interrupted. If program execution is resumed, the timeout processing count up is also resumed.
- (9) If program execution is interrupted, the timeout processing count up is also interrupted. If program execution is resumed, the timeout processing count up is also resumed.
- (10) If a timeout occurs, the change setting with this command becomes unset, regardless of the error specification.
- (11) After executing this command, if the force sense control function is disabled before the Mo trigger turns ON, the change setting with this command becomes unset.
- (12) After executing this command, if the Mo trigger is disabled with the SetMoTrg command before the Mo trigger turns ON, the change setting with this command becomes unset.
- (13) After executing this command, if operation is interrupted and the controller mode is changed from "AUTOMATIC" to "MANUAL" before the Mo trigger turns ON, the change setting with this command becomes unset.
- (14) Even if the force sense control function is disabled while processing the control characteristics change, processing continues until the change is complete. (Only the setting is changed. No control is performed.)
- (15) An error occurs if this command is executed while processing the control characteristics change. (Error L.3987)
- (16) An error occurs if this command is executed when the force sense control function is disabled. (Error L.3987)
- (17) An error occurs if this command is executed when the control characteristics change is set with the FsGChg command. (Error L.3987)
- (18) After executing this command, an error occurs when this command is executed again before the control characteristics changes. (Error L.3987)
If changing the change setting, disable the Mo trigger with the SetMoTrg command, and then execute this function.
- (19) After executing this command, an error occurs if the FsGChg command is executed before the control characteristics changes. (Error L.3987)
- (20) If an End command is executed for the slot for which this command is executed, or if the program reset operation is performed, the change setting with this command becomes unset.
- (21) This command setting is defined with respect to the robot. Unlike the Def Act command, if a sub-program is called with the CallP command, or if mechanical control rights are moved to another slot with the GetM or RelM commands, this command setting is continued.
- (22) If the force sensor is not connected, no processing is performed even when this command is executed. No error in particular occurs.

12.2 Status Variables Relating to Force Sense Control Function

This section describes MELFA-BASIC VI status variables relating to the force sense control function.

Table 12-5: Force sense control status variables

No.	Status Variable	Function Overview	
1	M_FsCod0, M_FsCod1	Specifies/references the force sense control coordinate system.	Control mode
2	P_FsMod0, P_FsMod1	Specifies/references the force sense control mode for each axis.	
3	P_FsStf0, P_FsStf1	Specifies/references the stiffness coefficient for each axis.	
4	P_FsDmp0, P_FsDmp1	Specifies/references the damping coefficient for each axis.	
5	P_FsFCd0, P_FsFCd1	Specifies/references the force command value for each axis.	Control characteristics
6	P_FsSpd0, P_FsSpd1	Specifies/references the speed command value for each axis.	
7	P_FsSwF0, P_FsSwF0	Specifies/references the mode switching judgment value for each axis.	
8	P_FsGn0, P_FsGn1	Specifies/references the force sense control gain for each axis.	
9	P_FsFLm0, P_FsFLm1	Specifies/references the force detection setting value for each axis.	Others
10	M_FsCCSw	Specify/reference the group of the stiffness/damping coefficient while force sense control is enabled.	

M_FsCod0, M_FsCod1**[Function]**

Specifies/references the force sense control coordinate system.

[Syntax]

Example)	M_FsCod0=<Numeric variable 1>
Example)	<Numeric variable 2>=M_FsCod1

[Terminology]

<Numeric variable 1> Specifies the force sense control coordinate system.

Setting	Mode
0	Coordinate system (Tool)
1	Coordinate system (XYZ)

<Numeric variable 2> Specifies the save destination for the read control coordinate information.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the coordinate system for which force control is performed contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter FSCOD01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control mode> = "0", it is not possible to write M_FsCod0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control mode> = "-1", it is not possible to write M_FsCod1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0 is output.

P_FsMod0, P_FsMod1**[Function]**

Specifies/references the force sense control mode for each axis.

[Syntax]

Example) P_FsMod0=<Position variable 1>
 Example) <Position variable 2>=P_FsMod1

[Terminology]

<Position variable 1> Specifies the force sense control mode for each axis.

Setting	Mode
0	Position control
1	Force control
2	Stiffness control
3	Limited stiffness control

<Position variable 2> Specifies the save destination for the read control coordinate information.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the force sense control mode for each axis contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter FSFMD01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control mode> = "0", it is not possible to write P_FsMod0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control mode> = "-1", it is not possible to write P_FsMod1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0.0 is output for all elements.

P_FsStf0, P_FsStf1**[Function]**

Specifies/references the stiffness coefficient for force sense control (stiffness control).

[Syntax]

Example) P_FsStf0=<Position variable 1>

Example) <Position variable 2>=P_FsStf1

[Terminology]

<Position variable 1> Specifies the stiffness coefficient for force sense control (stiffness control).

(The L1- and L2-axis components do not use this variable.)

Component	Setting Range	Unit
X, Y, Z	0.0 - 1000.0	N/mm
A, B, C	0.0 - 1000.0	N·m/deg
L1, L2	0.0	-

<Position variable 2> Specifies the save destination for the read stiffness coefficient.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the stiffness coefficient for stiffness control contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter FSSTF01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control mode> ="0", it is not possible to write P_FsStf0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control mode> = "-1", it is not possible to write P_FsStf1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0.0 is output for all elements.

P_FsDmp0, P_FsDmp1**[Function]**

Specifies/references the damping coefficient (responsiveness) for force sense control (stiffness control/force control).

[Syntax]

Example) P_FsDmp0=<Position variable 1>

Example) <Position variable 2>=P_FsDmp1

[Terminology]

<Position variable 1> Specifies the damping coefficient for force sense control.
(The L1- and L2-axis components do not use this variable.)

Component	Setting Range	Unit
X, Y, Z	0.0 - 1.0	N/(mm/s)
A, B, C	0.0 - 1.0	N·m/(deg/s)
L1, L2	0.0	-

<Position variable 2> Specifies the save destination for the read damping coefficient.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the damping coefficient contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter FSDMP01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control mode> = "0", it is not possible to write P_FsDmp0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control mode> = "-1", it is not possible to write P_FsDmp1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0.0 is output for all elements.

P_FsFCd0, P_FsFCd1**[Function]**

Specifies/references the force command value for force sense control (force control) or the limit value for the force control (limited stiffness control).

[Syntax]

Example) P_FsFCd0=<Position variable 1>

Example) <Position variable 2>=P_FsFCd1

[Terminology]

<Position variable 1> Specifies the force command value for force sense control (force control) or force sense control (limited stiffness control).

(In the force control, the L1- and L2-axis components do not use. In the limited stiffness control, set the resultant force to the L1-axis, and the limit value of the resultant moment to the L2-axis)

Component	Setting Range		Unit
	Force control	Limited stiffness control	
X, Y, Z	- force sense tolerance value to + force sense tolerance value	0.0 to + force sense tolerance value	N
A, B, C	- force sense tolerance value to + force sense tolerance value	0.0 to + force sense tolerance value	N·m
L1, L2	0.0	0.0 to + force sense tolerance value	Force control: idle Limited stiffness control: L1[N], L2[N·m]

<Position variable 2> Specifies the save destination for the read force command value/limit value.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the force command value (force control) or limit value (limited stiffness control) contained in the condition group (control characteristics).
- (2) The specified value is used if the Fsc On command <control characteristics > is set to "-1" or "0".
- (3) Default status: The parameter FSFCMD01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control characteristics > = "0", it is not possible to write P_FsFCd0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control characteristics > = "-1", it is not possible to write P_FsFCd1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0.0 is output for all elements.

P_FsSpd0, P_FsSpd1**[Function]**

Specifies/references the speed command value for force sense control (force control).

[Syntax]

Example) P_FsSpd0=<Position variable 1>
 Example) <Position variable 2>=P_FsSpd1

[Terminology]

<Position variable 1> Specifies the speed command value for force sense control (force control).
 (The L1- and L2-axis components do not use this variable.)

Component	Setting Range	Unit
X, Y, Z	0.0 - 50.0	mm/s
A, B, C	0.0 - 50.0	deg/s
L1, L2	0.0	-

 Caution

The speed restriction defined by the above setting range does not guarantee that the sensor will not malfunction as a result of collision on contact. When adjusting, move the robot at a low speed to begin with, and then increase the speed if required.

When doing so, check the force sensor data at the point of contact at the teaching pendant maximum value monitor, and set the speed to avoid too much force being applied.

<Position variable 2> Specifies the save destination for the read speed command value.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the speed command value contained in the condition group (control characteristics).
- (2) The specified value is used if the Fsc On command <control characteristics > is set to "-1" or "0".
- (3) Default status: The parameter FSSPD01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) If the specified value is 0.0, speed priority mode does not function, and the robot moves in force priority mode at all times.
- (6) When force sense control is enabled with <control characteristics > = "0", it is not possible to write P_FsSpd0. (Error L3987 occurs.)
- (7) When force sense control is enabled with <control characteristics > = "-1", it is not possible to write P_FsSpd1. (Error L3987 occurs.)
- (8) If the force sensor is not connected, the value is not updated even if written. Furthermore, even if the setting value is read, 0.0 is always output for all elements.
- (9) If multiple axes are moved simultaneously in speed control mode, the actual robot movement speed is a synthesized speed for all axes.

P_FsSwF0, P_FsSwF1**[Function]**

Specifies/references the force priority mode/speed priority mode switching judgment value for the force sense function (force control).

[Syntax]

Example) P_FsSwF0=<Position variable 1>

Example) <Position variable 2>=P_FsSwF0

[Terminology]

<Position variable 1>

Specifies the force control mode/speed control mode switching judgment value for force sense control (force control).

(The L1- and L2-axis components do not use this variable.)

Component	Setting Range	Unit
X, Y, Z	-	N
A, B, C	-	N·m
L1, L2	0.0	-

<Position variable 2> Specifies the save destination for the read mode switching judgment value.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the mode switching judgment value contained in the condition group (control characteristics).
- (2) The specified value is used if the Fsc On command <control characteristics > is set to "-1" or "0".
- (3) Default status: The parameter FSSWF01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control characteristics > = "0", it is not possible to write P_FsSwF0. (Error L3987 occurs.)
- (6) If a value same as the force command is specified, the speed priority mode is disabled, and the robot always operates in the force priority mode.
- (7) When force sense control is enabled with <control characteristics > = "-1", it is not possible to write P_FsSwF1. (Error L3987 occurs.)
- (8) If the force sensor is not connected, the value is not updated even if written. Furthermore, even if the setting value is read, 0.0 is always output for all elements.

P_FsGn0, P_FsGn1**[Function]**

Specifies/references the force sense control gain (responsiveness) for the force sense function.

[Syntax]

Example) P_FsGn0=<Position variable 1>
 Example) <Position variable 2>=P_FsGn1

[Terminology]

<Position variable 1> Specifies the force sense control gain for force sense control.
 (The L1- and L2-axis components do not use this variable.)

Component	Setting Range	Unit
X, Y, Z	0.0 - 300.0	10^{-3} mm/N
A, B, C	0.0 - 300.0	10^{-3} deg/(N·m)
L1, L2	0.0	-

<Position variable 2> Specifies the save destination for the read force sense control gain.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the force sense control gain for each axis contained in the condition group (control characteristics).
- (2) The specified value is used if the Fsc On command <control characteristics > is set to "-1" or "0".
- (3) Default status: The parameter FSFGN01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control characteristics > = "0", it is not possible to write P_FsGn0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control characteristics > = "-1", it is not possible to write P_FsGn1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0.0 is output for all elements.

P_FsFLm0, P_FsFLm1**[Function]**

Specifies/references the force sensor force detection setting value for the force sense function.

[Syntax]

Example) P_FsFLm0=<Position variable 1>
 Example) <Position variable 2>=P_FsFLm1

[Terminology]

<Position variable 1> Specifies the force sensor force detection setting value.
 (The L1- and L2-axis components do not use this variable.)

Component	Setting Range	Unit
X, Y, Z	0.0 - force sensor tolerance value	N
A, B, C	0.0 - force sensor tolerance value	N·m
L1, L2	0.0	-

<Position variable 2> Specifies the save destination for the read force detection setting value.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the force sensor force detection setting value contained in the condition group (control characteristics).
- (2) The specified value is used if the Fsc On command <control characteristics > is set to "-1" or "0".
- (3) Default status: The parameter FSFLMT01 setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) When force sense control is enabled with <control characteristics > = "0", it is not possible to write P_FsFLm0. (Error L3987 occurs.)
- (6) When force sense control is enabled with <control characteristics > = "-1", it is not possible to write P_FsFLm1. (Error L3987 occurs.)
- (7) When no force sensor is connected, the value is not applied even if it is written. Also if the setting value is read, always 0.0 is output for all elements

M_FsCCSw

[Function]

Specify/reference the group of the stiffness/damping coefficient while force sense control is enabled.

[Syntax]

```
M_FsCCSw = <Numeric variable 1>
<Numeric variable 2> = M_FsCCSw
```

[Terminology]

<Numeric variable 1> Specifies the group of the stiffness/damping coefficient.

0: Control mode

1: Control feature (changeable by the FsGChg/FsCTrg command while force sense control is enabled)

Setting range: 0 or 1 (initial value: 0)

<Numeric variable 2> References the group of the stiffness/damping coefficient.

0: Control mode

1: Control feature

[Example]

```
'Specify stiffness/damping coefficient as control feature.
M_FsCCSw=1 '(*1)
'Set the control mode (0).
P_FsMod0=(+3.00, +3.00, +3.00, +0.00, +0.00, +0.00)(0,0) 'Control mode (Limited stiffness control)
M_FsCod0=1 'Force sense control coordinate system (XYZ
coordinate system)
'Set the control feature (0).
P_FsStf0=(+0.50, +0.50, +0.50, +0.00, +0.00, +0.00)(0,0) 'Stiffness coefficient
P_FsDmp0=(+0.00, +0.00, +0.00, +0.00, +0.00, +0.00)(0,0) 'Damping coefficient
P_FsGn0=(+3.00, +3.00, +3.00, +0.00, +0.00, +0.00)(0,0) 'Force sense control gain
P_FsFCd0=(+50.00, +50.00, +50.00, +0.00, +0.00, +0.00)(0,0) 'Limit value
'Set the control feature (-1).
P_FsStf1=(+1.00, +1.00, +1.00, +0.00, +0.00, +0.00)(0,0) 'Stiffness coefficient
P_FsDmp1=(+0.50, +0.50, +0.50, +0.50, +0.50, +0.50)(0,0) 'Damping coefficient
P_FsGn1=(+5.00, +5.00, +5.00, +0.00, +0.00, +0.00)(0,0) 'Force sense control gain
P_FsFCd1=(+50.00, +50.00, +50.00, +0.00, +0.00, +0.00)(0,0) 'Limit value
'
Mov PStart 'Move to start position.
Dly 1 '
Fsc On, 0, 0, 1 '(*2) Force sense control ON (control mode = 0, control feature = 0)
Mvs P1 '
FsGChg 50,10, -1 '(*3) Change control feature (0 to -1)
Mvs P2 '
Fsc Off
End
```

(*1): The stiffness/damping coefficient is treated as the control feature setting item by setting 1 in M_FsCCSw.

(*2): Enable force sense control. Operation starts when control feature (0) is set.

(*3): Change control feature by the FsGChg command. When the interpolation is proceeded to a predetermined degree, the feature is changed.

Since the M_FsCCSw value is 1, the setting value changes to -1 (control feature) for the stiffness/damping coefficient.

[Description]

- (1) Specify/reference the group of the stiffness/damping coefficient while force sense control is enabled. To change the group, change the M_FsCCSw value before executing the Fsc_On command.
- (2) The M_FsCCSw value is forced to be cleared to zero when force sense control is disabled. Set the M_FsCCSw value again when force sense control is enabled. Force sense control is disabled when any of the following conditions is satisfied.

<Conditions to be satisfied to disable force sense control>

	Operation/conditions
1	Fsc_Off command implemented
2	Force sense control disabled using the T/B
3	End command
4	Program reset
5	Occurrence of an error related to force sense control
6	Conditions in which program selection is possible

- (3) When the value outside the setting range is specified, error L8911 "A value outside the range was set" occurs.
- (4) When the Fsc On command is executed, the property of the stiffness/damping coefficient is treated as control mode when 0 is set in this status variable, or as control feature when 1 is set.
- (5) A value cannot be written to this status variable while force sense control is enabled. Doing so causes error L3987 (force sense control enabled, status variable cannot be changed).

12.3 Commands Relating to Force Sense Detection Function

This section describes MELFA-BASIC VI commands relating to the force sense detection function (Mo trigger function).

Table 12-6: Mo trigger commands

No.	Command	Function Overview
1	Def MoTrg	Defines trigger conditions (Mo trigger) that reference position commands and the FB position, as well as force sensor data and so on.
2	SetMoTrg	Enables/disables trigger conditions (Mo trigger) that reference position commands and the FB position, as well as force sensor data and so on.

Def MoTrg (Def Mo trigger)

[Function]

Defines trigger conditions (Mo trigger) that reference position commands and the FB position, as well as force sensor data and so on.

[Syntax]

```
Def □MoTrg <Trigger No.>, <Conditions>
```

[Terminology]

<Trigger No.>

Specifies the defined Mo trigger No. with a constant.

Setting range: 1 - 3

<Conditions>

Conditions under which the Mo trigger turns ON are described with the following syntax.

<Specification data> <Comparison operator> <Numerical data>

<Specification data> The following robot (system) status variables can be used.

- Status variables
All components of P_Curr, P_Fbc, J_Curr, J_Fbc, P_FsCurP, P_FsCurD, M_FsRsItF, M_FsRsItM
- Input signal M_In
- Output signal M_Out

<Numerical data> The following constants and variables can be used.

- Numeric constants, numeric variables, numeric array variables
- Position variable component data
- Joint variable component data
- * If a variable is set, the variable when executing this command is used for trigger condition judgment.
(Even if a variable is changed after executing this command, it is not updated to the judgment.)

* Up to 4 types of <Conditions> can be combined and used with And and Or operators.

[Example: (<Condition A> And <Condition B>) Or (<Condition C> And <Condition D>)]

* If rotational axis component data is specified for <Specification data>, the unit for the data used for conditions judgment will be radians. If using a numeric constant for <Numerical data>, use radian values, or append "DEG" such as in "45DEG", and then convert to radians.

[Example]

```
1 Def MoTrg 1, ((P_Fbc.Z <= 100) Or (P_FsCurD.Z >= 10)) And (P_FsCurP.C < -45DEG)
  ' Defines the ON trigger as Mo trigger No.1 by satisfying the following conditions (1) and (2).
  ' (1) FB position Z-axis value is 100 mm or less, or Z-axis direction force sensor data is 10 N
    or greater.
  ' (2) Force sense command C-axis value is less than -45°.
```

[Description]

- (1) Defines Mo trigger conditions with this command. The following data can be specified as trigger conditions.

Data	Description
Each P_Curr component	Robot current position (XYZ data)
Each P_Fbc component	Robot FB position (XYZ data)
Each J_Curr component	Robot current position (joint data)
Each J_Fbc component	Robot FB position (joint data)
Each P_FsCurP component	Position command after offsetting with force control
Each P_FsCurD component	Force sensor data (values after updating offset cancel, converting Tool/XYZ coordinates)
M_FsRsltF	Force sensor data resultant force (values after updating offset cancel, converting tool/XYZ coordinates)
M_FsRsltM	Force sensor data resultant moment (values after updating offset cancel, converting tool/XYZ coordinates)
M_In	Input signal ON/OFF status
M_Out	Output signal ON/OFF status

- (2) The defined Mo trigger is enabled by executing the SetMoTrg command. The Mo trigger is not enabled simply by defining with this command.
- (3) If the Mo trigger for the trigger No. defined with this command is enabled, the trigger turns ON when the specified conditions are satisfied.
- (4) If multiple Def MoTrg commands are described for the same trigger No., the definition executed last is applied.
- (5) By executing this command for an enabled trigger No. Mo trigger, that Mo trigger becomes disabled, and changes to a new definition.
- (6) Up to 3 trigger Nos. can be defined for the Mo trigger. However, only one of these can be enabled. It is not possible to enable multiple Mo triggers.
- (7) Mo trigger conditions are defined for the robot. Unlike the Def Act command, if a sub-program is called with the CallP command, or if mechanical control rights are moved to another slot with the GetM or RelM commands, this command setting is continued.
- (8) Specify the same mechanical number for status variables used in <Conditions>. If mechanical Nos. are mixed, an error occurs when running the program. (Error L.3110)
- (9) If a non-existent mechanical number is specified for the status variable used in <Conditions>, an error occurs when running the program. (Error L.3870)
- (10) With robots that are not compatible with force sense control, it is not possible to specify P_FsCurP, P_FsCurD, M_FsRsltF, or M_FsRsltM for <Conditions>. An error occurs when running the program. (Error L.3986)

SetMoTrg (Set Mo trigger)**[Function]**

Enables/disables trigger conditions (Mo trigger) that reference position commands and the FB position, as well as force sensor data and so on.

[Syntax]

SetMoTrg <Trigger No.>

[Terminology]

<Trigger No.> Specifies the trigger No. for the Mo trigger to be enabled with a constant.
 If 0 is specified, the Mo. Trigger is disabled.
 Setting range: 0 - 3

[Example]

```
1 Def MoTrg 1, ((P_Fbc.Z <= 100) Or (P_FsCurD.Z >= 10)) And (P_FsCurP.C < -45DEG)
2 SetMoTrg 1                                ' Enables Mo trigger No.1.
   :
   :
100 SetMoTrg 0                              ' Disables the Mo trigger.
```

[Description]

- (1) The Mo trigger is enabled/disabled with this command.
- (2) It is not possible to enable multiple Mo triggers simultaneously. If this command is executed consecutively, the Mo trigger enabled last is applied.
- (3) When performing force sense control characteristics change processing (FsCTrg command) using an Mo trigger, it is not possible to enable the Mo trigger with this command. An error occurs when running the program. (Error L.3987)
The Mo trigger can be disabled.
- (4) If the specified Mo trigger No. has not been defined, an error occurs when running the program. (Error L3770)
- (5) If an End command is executed for the slot for which the trigger is enabled with this command, or if the program reset operation is performed, the Mo trigger will be disabled.
- (6) Mo trigger conditions are defined for the robot. Unlike the Def Act command, if a sub-program is called with the CallP command, or if mechanical control rights are moved to another slot with the GetM or RelM commands, the Mo trigger conditions continue to apply.

12.4 Status Variables Relating Force Sense Detection Function

This section describes MELFA-BASIC VI status variables relating to the force sense detection function.

Table 12-7: Force sensor function related status variables

No.	Status Variable	Function Overview	Class
1	M_MoTrg	Checks the Mo trigger enabled/disabled status and the trigger ON/OFF status while enabled.	Mo trigger
2	M_FsLmtS	Checks whether the force sensor data force detection setting value has been exceeded.	Status display
3	P_FsLmtR	Checks the status of the current force sensor data with respect to the force sensor data force detection setting value.	
4	P_FsLmtX	Checks/resets axes for which the force sensor data force detection setting value is exceeded.	Data latch
5	P_FsLmtP	Checks/resets the robot FB position when the force sensor data force detection setting value is exceeded.	
6	P_FsLmtD	Checks/resets the force sensor data when the force sensor data force detection setting value is exceeded.	
7	P_FsMaxD	Checks/resets the force sensor maximum data value during force sense control.	Data referencing
8	P_FsCurD	Checks the current force sensor data.	
9	P_FsCurP	Checks the current position command offset with force sense control.	
10	M_FsRsltF	Checks the current force sensor resultant force (Fx, Fy, Fz).	
11	M_FsRsltM	Checks the current force sensor resultant moment (Fx, Fy, Fz).	
12	M_FsCSts	Checks the force sense control enabled/disabled status.	
13	M_FsRsltFMax	Checks/resets the maximum value of the force sensor resultant force data.(*1)	
14	M_FsRsltMMax	Checks/resets the maximum value of the force sensor resultant moment data.(*1)	

(*1) Available with the controller software version A4 or later.

M MoTrg**[Function]**

Checks the Mo trigger enabled/disabled status and the trigger ON/OFF status while enabled.

[Syntax]

Example) <Numerical variable>= M_MoTrg (<Trigger No.>)

[Terminology]

<Trigger No.> Specifies the Mo trigger No. being checked with a constant.
Setting range: 1 - 3

<Numerical variable> Reads the Mo trigger defined/undefined status, enabled/disabled status, and trigger ON/OFF status while enabled, and specifies the save destination.

[Example]

```
100 If M_MoTrg(2) = -2 Then      'If Mo trigger No.2 undefined:
101   Def MoTrg 2, P_Fbc.X > 500 ' Defines Mo trigger No.2,
102   SetMoTrg 2                ' Enables Mo trigger No.2.
103 EndIf
```

[Description]

- (1) Checks the MO trigger defined/undefined status, enabled/disabled status, and trigger ON/OFF status while enabled.
- (2) If the Mo trigger is enabled and the defined conditions are satisfied, "+1" is returned, and if not satisfied, "0" is returned.
- (3) If the Mo trigger is disabled, "-1" is returned.
- (4) If the Mo trigger is undefined, "-2" is returned.
- (5) Immediately after turning ON the power, "-2" (undefined) is returned.

Value	Details		
	Defined/Undefined Status	Enabled/Disabled Status	Trigger ON/OFF Status
+1	Defined	Enabled	ON
0	Defined	Enabled	OFF
-1	Defined	Disabled	---
-2	Undefined	---	---

M_FsLmtS

[Function]

Checks whether the force sensor data force detection setting value has been exceeded.

[Syntax]

Example) <Numerical variable>= M_FsLmtS

[Terminology]

<Numerical variable>

Specifies the read numerical variable for determining whether the force detection setting value has been exceeded.

(1: Force detection setting value exceeded, 0: Force detection setting value not exceeded)

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Displays whether the absolute value of the force sensor data has exceeded the force detection setting value. Displays 1 if exceeded, and 0 if not exceeded.
- (2) If there is more than one axis for which the force detection setting value has been exceeded, 1 is output.
- (3) The default status (when power ON) is 0. The value changes to 1 when the force detection setting value is exceeded while the force sense control function is enabled, and returns to 0 when no axes exceed the force detection setting value, or when force sense control is disabled.
- (4) The value is always 0 if the force sensor is not connected.
- (5) If movement is stopped when the force detection setting value is exceeded during automatic operation, it can be used as the interrupt processing condition to stop the movement.

P_FsLmtR

[Function]

Checks the status of the current force sensor data with respect to the force sensor data force detection setting value.

[Syntax]

Example) <Position variable>= P_FsLmtR

[Terminology]


<Position variable> Specifies the substitute position variable.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Displays where the current force sensor data lies in the status shown in the following diagram with respect to the force detection setting value.



Sensor data absolute values are:
 (-2) Force detection value or less
 (+1) Conversion to value greater than force detection value
 (+2) Greater than force detection value
 (-1) Conversion to value less than or equal to force detection value

- (2) If force sense control is disabled, the value is 0 for all axes. When force sense control is enabled, the value is -2, -1, 1, or 2.
 (3) Axis correspondence is as follows: Fx=X-axis, Fy=Y-axis, Fz=Z-axis, Mx=A-axis, My=B-axis, Mz=C-axis.
 (4) The value is 0 for all axes if the force sensor is not connected.

P_FsLmtX

[Function]

Checks/resets axes for which the force sensor data force detection setting value is exceeded.

[Syntax]

Example)	<Position variable>= P_FsLmtX
Example)	P_FsLmtX =<Position variable>

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Displays whether the force sensor data's absolute value has exceeded the force detection setting value. Displays 1 if exceeded, and 0 if not exceeded. If any axes exist for which the value has been exceeded even once, 1 is set for the corresponding axis element. 0 is set for axes for which the value has not been exceeded. The value is retained until reset.
- (2) Axis correspondence is as follows: Fx=X-axis, Fy=Y-axis, Fz=Z-axis, Mx=A-axis, My=B-axis, Mz=C-axis.
- (3) The default status (when power ON) is 0 for all axes. A value is set when the force detection setting value is exceeded while the force sense control function is enabled, and that value is then reset to 0 for all axes in the following cases.
 - When force sense control is enabled. (Execute the Fsc On command and enable force sense control with the teaching pendant.)
 - When the robot servo is turned from OFF to ON while force sense control is enabled.
 - When operation (4) below is performed.
- (4) By substituting a position variable (any position variable value is okay) for P_FsLmtX, the value can be reset. By resetting, the P_FsLmtP and P_FsLmtD values are reset simultaneously.
- (5) The value is 0 for all axes if the force sensor is not connected.

P_FsLmtP**[Function]**

Checks/resets the robot FB position when the force sensor data force detection setting value is exceeded.

[Syntax]

Example)	<Position variable>= P_FsLmtP
Example)	P_FsLmtP =<Position variable>

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Checks robot position feedback when the force sensor data's absolute value exceeds the force detection setting value for the first time.
- (2) The default status (when power ON) is 0 for all axes. A value is set when the force detection setting value is exceeded while the force sense control function is enabled, and that value is then reset to 0 for all axes in the following cases.
 - When force sense control is enabled. (Execute the Fsc On command and enable force sense control with the teaching pendant.)
 - When the robot servo is turned from OFF to ON while force sense control is enabled.
 - When operation (3) below is performed.
- (3) By substituting a position variable (any position variable value is okay) for P_FsLmtP, the value can be reset. By resetting, the P_FsLmtX and P_FsLmtD values are reset simultaneously.
- (4) The value is 0 for all axes if the force sensor is not connected.

P_FsLmtD**[Function]**

Checks/resets the force sensor data when the force sensor data force detection setting value is exceeded.

[Syntax]

Example)	<Position variable>= P_FsLmtD
Example)	P_FsLmtD =<Position variable>

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

300 If P_FsLmtX.X=1 Then P_FsFLmt.X=P_FsLmtD.X * 0.8 'If X-direction sensor data exceeds the force detection setting value:

'80% of the exceeded value is set as the new force detection setting value.

[Description]

- (1) Checks force sensor data when the force sensor data's absolute value exceeds the force detection setting value for the first time.
- (2) The default status (when power ON) is 0 for all axes. A value is set when the force detection setting value is exceeded while the force sense control function is enabled, and that value is then reset to 0 for all axes in the following cases.
 - When force sense control is enabled. (Execute the Fsc On command and enable force sense control with the teaching pendant.)
 - When the robot servo is turned from OFF to ON while force sense control is enabled.
 - When operation (3) below is performed.
- (3) By substituting (any position variable value is okay) a position variable for P_FsLmtD, the value can be reset. By resetting, the P_FsLmtX and P_FsLmtP values are reset simultaneously.
- (4) The value is 0 for all axes if the force sensor is not connected.

P_FsMaxD

[Function]

Checks/resets the force sensor maximum data value during force sense control.

[Syntax]

Example)	<Position variable>= P_FsMaxD
Example)	P_FsMaxD =<Position variable>

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

1000 P1=P_FsMaxD 'In P1, retains maximum force sensor data value up to this point.

1010 P_FsMaxD=P1 'Resets the maximum value.

[Description]

- (1) Displays the force sensor data maximum value (maximum absolute value). (Maximum value of each axis is retained.)
- (2) The default status (when power OFF) is 0 for all axes. A value is set regardless of the force sense control function enabled/disabled status, and that value is retained when a value (any position variable value is okay) is substituted for P_FsMaxD and offset cancel is performed, or until the maximum value is reset with the T/B.
- (3) The value is always 0 for all axes if the force sensor is not connected.

P_FsCurD**[Function]**

Checks the current force sensor data.

[Syntax]

Example) <Position variable>= P_FsCurD
--

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

100 Def Act 1, P_FsCurD.Z > 10 GoTo *INTR1, S

'If the Z-direction sensor data exceeds 10 N, an interrupt used to perform interrupt processing
*INTR1 is defined.

200 M_DOut(6000)=P_FsCurD.X * 100

'Multiplies the X-axis sensor data value by 100 (converts unit to 0.01 N).
'Writes to CC-Link output register 6000.

[Description]

- (1) Displays the current force sensor data.
- (2) Force sensor data converted to the tool coordinate direction is normally displayed; however, if force sense control is enabled in XYZ coordinate mode, force sensor data converted to the XYZ coordinate direction is displayed. Furthermore, the offset cancel (zero point offset) result is updated.
- (3) The current force sensor data can be checked even if the force sense control function is disabled.
- (4) The value is always 0 for all axes if the force sensor is not connected.

P_FsCurP**[Function]**

Checks the position (force sense position command) offset with force sense control.

(Force sense position command = Position command calculated with movement command, etc. + position offset with force sense control)

[Syntax]

Example) <Position variable>= P_FsCurP
--

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

2000 PD=P_Curr – P_FsCurP

'Outputs the difference between the position command and force sense position command.

2010 MD=Sqr(PD.X*PD.X + PD.Y*PD.Y + PD.Z*PD.Z)

'Outputs the interpolation distance.

[Description]

- (1) Checks the position offset with force sense control.
- (2) If the force sense control function is disabled, the same value as P_Curr (position command) is output if the force sensor is not connected.

M_FsRsltF**[Function]**

Checks the current force sensor resultant force (Fx, Fy, Fz).

[Syntax]

Example) <Position variable>= M_FsRsltF

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

1 *L1 : If M_FsRsltF < 10 Then GoTo *L1

' If the force sensor resultant force is less than 10[N], repeat this step.

2 M_Out(100) = 1

' If the force sensor resultant force is more than 10[N], turn the output signal 100 ON.

[Description]

- (1) Displays the current resultant force of the force sensor. Resultant force F is determined as follows from the force component of the force sensor (Fx, Fy, Fz).

$$F = \sqrt{F_x^2 + F_y^2 + F_z^2}$$

- (2) The force sensor resultant force converted to the force in the tool coordinate direction is normally displayed; however, if force sense control is enabled in XYZ coordinate mode, the force sensor resultant force converted to the force in the XYZ coordinate direction is displayed. Furthermore, the offset cancel (zero point offset) result is updated.
- (3) Even if the force sense control function is invalid, it is possible to check the current resultant force of the force sensor.
- (4) When the force sensor is not connected, always returns 0.

M_FsRsltM

[Function]

Checks the current force sensor resultant moment (Fx, Fy, Fz).

[Syntax]

Example) <Position variable>= M_FsRsltM

[Terminology]

<Position variable> Specifies the substitute position variable.

[Example]

1 *L1 : If M_FsRsltM < 1 Then GoTo *L1

' If the force sensor resultant moment is less than 1[Nm], repeat this step.

2 M_Out(100) = 1

' If the force sensor resultant moment is more than 1[Nm], turn the output signal 100 ON.

[Description]

- (1) Displays the current resultant moment of the force sensor. Resultant moment M is determined as follows from the moment component of the force sensor (Mx, My, Mz).

$$M = \sqrt{M_x^2 + M_y^2 + M_z^2}$$

- (2) The force sensor resultant force converted to the force in the tool coordinate direction is normally displayed; however, if force sense control is enabled in XYZ coordinate mode, the force sensor resultant force converted to the force in the XYZ coordinate direction is displayed. Furthermore, the offset cancel (zero point offset) result is updated.
- (3) Even if the force sense control function is invalid, it is possible to check the current resultant moment of the force sensor.
- (4) When the force sensor is not connected, always returns 0.

M_FsCSts

[Function]

Checks the force sense control enabled/disabled status.

[Syntax]

Example) <Numerical variable>= M_FsCSts

[Terminology]

<Numerical variable> Specifies the substitute numerical variable.

(1: Force sense control enabled, 0: Force sense control disabled)

[Example]

2000 If M_FsCSts=1 Then Fsc Off 'Disables force sense control if enabled.

[Description]

- (1) Checks the force sense control enabled/disabled status.
- (2) The value is 1 if force sense control is enabled, and 0 if disabled.
- (3) If force sense control is enabled, the status will be enabled (1) even if the servo is OFF.

M_FsRsltFMax**[Function]**

Checks/resets the maximum resultant force value of all axial force values provided by the force sensor during force sense control.

[Syntax]

Example) <Numeric variable> = M_FsRsltFMax[(<Mechanical No.>)]
 Example) M_FsRsltFMax [(<Mechanical No.>)]=<Numeric variable>

[Terminology]

<Numeric variable> Specify the substitute numeric variable.

<Mechanical No.> Specify the mechanical No.
 Setting range: 1 to 3 (If 0 is set or the value is omitted, 1 is set.)
 When the value outside the setting range is specified, error L3870_17000 occurs.
 For the robot that does not support the force sense control, error L3986_10000 occurs.

[Example]

1 M1=M_FsRsltFMax	'Retains the maximum resultant force value of the force sensor up to this point in M1.
2 M_FsRsltFMax=M1	'Resets the maximum value.

[Description]

- (1) Returns the maximum resultant force value of the force sensor.
- (2) The default status (when power ON) is 0 for all axes. A value is set regardless of whether the force sense control function is enabled/disabled.
- (3) The value is reset when a numeric variable (any numeric value) is substituted for M_FsRsltFMax, the offset cancel data is updated, or the maximum value is reset with the T/B.
- (4) The value is always 0 if the force sensor is not connected.

M_FsRsltMMax**[Function]**

Checks/reset the maximum resultant moment value of all axial moment values provided by the force sensor during force sense control.

[Syntax]

Example) <Numeric variable> = M_FsRsltMMax[(<Mechanical No.>)]
Example) M_FsRsltMMax[(<Mechanical No.>)] = <Numeric variable>

[Terminology]

<Numeric variable> Specify the substitute numeric variable.

<Mechanical No.> Specify the mechanical No.
Setting range: 1 to 3 (If 0 is set or the value is omitted, 1 is set.)
When the value outside the setting range is specified, error L3870_17000 occurs.
For the robot that does not support the force sense control, error L3986_10000 occurs.

[Example]

1 M1=M_FsRsltFMax 'Retains the maximum resultant moment value of the force sensor up to this point in M1.
2 M_FsRsltMMax=M1 'Resets the maximum value.

[Description]

- (1) Returns the maximum resultant moment value of the force sensor.
- (2) The default status (when power ON) is 0 for all axes. A value is set regardless of whether the force sense control function is enabled/disabled.
- (3) The value is reset when a numeric variable (any numeric value is okay) is substituted for M_FsRsltFMax, the offset cancel data is updated, or the maximum value is reset with the T/B.
- (4) The value is always 0 if the force sensor is not connected.

12.5 Commands Relating to Force Sense Log Function

This section describes MELFA-BASIC VI status variables relating to the log function.

Table 12-8: Log function commands

No.	Command	Function Overview
1	FsLog On	Starts force sensor data and position command, position FB, and current FB value logging.
2	FsLog Off	Ends force sensor data and position command, position FB, and current FB value logging.
3	FsOutLog	Reads logged data using FTP.

FsLog On

[Function]

Starts force sensor data and position command, position FB, and current FB value logging.

[Syntax]

FsLog□On

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Collects the force sensor data and position command, position FB, and current FB value.
- (2) Data collection is ended 45s after the completion of this command, or when the FsLog Off command is executed.
- (3) This command cannot be executed again during data collection. (Error L3987 occurs.)
- (4) If the force sensor is not connected, no processing is performed when this command is executed.
- (5) If the log function is disabled (parameter FSLOGFN 1st element is 0), no processing is performed when this command is executed.

FsLog Off

[Function]

Ends force sensor data and position command, position FB, and current FB value logging.

[Syntax]

FsLog□Off <Log File No.>

[Terminology]

<Log File No.> Specifies the log file No. containing collected data.
Setting range: 1 to 999999999

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Ends collection of the force sensor data and position command, the position FB, and the current FB value, and creates a log file with the name specified for the log file No.
- (2) If the force sensor is not connected, no processing is performed when this command is executed.
- (3) No processing is performed if this command is executed without executing the FsLog On command.
- (4) If the log function is disabled (parameter FSLOGFN 1st element is 0), no processing is performed when this command is executed.
- (5) If 45s elapses after the execution of FsLog On command before executing this command, data collection stops automatically. However, log files are not created without executing this command.
- (6) Up to 2 log files can be stored in the controller. If the number of files stored exceeds 2, the file with oldest creation data is deleted.
- (7) If a log file No. the same as an existing log file is specified, the existing file is overwritten with the new file and saved.
- (8) If the log file size becomes larger than the file creation area during creation, data toward the end may be cut off.

FsOutLog

[Function]

Transfers logged data to the FTP server.

[Syntax]

```
FsOutLog <Log File No.>
```

[Terminology]

<<Log File No.> Specifies the No. of the log file from which collected data is to be read.
Setting range: 1 to 999999999

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Outputs CSV format log files created with the FsLog Off command to the FTP server.
- (2) The file name of the file output to the FTP server is "f<log file No.>.fsl".
- (3) Log files successfully transferred to the FTP server are deleted from the robot controller.
If FTP transfer fails, error L3987 occurs and the log file is not deleted.
- (4) Error L3987 occurs if the log file for the specified No. does not exist.
- (5) If the force sensor is not connected, no processing is performed when this command is executed.
- (6) If the log function is disabled (parameter FSLOGFN 1st element is 0), or FTP is not used (parameter FSLOGFN 3rd element is 0), no processing is performed when this command is executed.
- (7) If the log file size becomes larger than the file creation area during creation, data toward the end may be cut off.
- (8) The maximum log file size is approximately 1.8 MB. Depending on the file size, FTP communication may take several tens of seconds.
- (9) If FTP communication fails, error L3987 (failed to output log file) occurs maximum of approximately 75 seconds after executing the FsOutLog command. In such a case, check the following again and reboot the robot controller.
 - Parameter (FTPID, FTPPASS, FTPSVRIP) settings relating to FTP communication
 - Condition of network between robot controller and FTP server
 - Settings and startup status at FTP server

12.6 Related Commands for Gravity Offset Cancel Function

MELFA-BASIC VI commands relating to the gravity offset cancel function are described below.

Table 12-9: Gravity offset cancel commands

No.	Command	Function Overview
1	FsHndEst On	Starts the process of the force sensor calibration.
2	FsHndEst Off	Estimates the force sensor calibration result and finishes the process.
3	FsGetDat	Acquires the data (position and posture, force sensor data) required for the force sensor calibration.

FsHndEst On

[Function]

Starts the estimation process of the data (bias value, center of gravity position and mass of the load) required for the gravity offset cancel.

[Syntax]

FsHndEst□On <Control mode>

[Terminology]

<Control mode> Specifies the numerical value of status variables/parameters to store the estimated result.
The argument value corresponds to that of the Fsc On command <control mode>.
Setting range: -1 - 9

Setting item	Control mode					
	-1	0	1	2	-	9
Bias value	P_FsBias1	P_FsBias0	FSBIAS01	FSBIAS02	-	FSBIAS09
Center of gravity position	P_FsGrPos1	P_FsGrPos0	FSGRP01	FSGRP02	-	FSGRP09
Mass	M_FsMass1	M_FsMass0	FSMASS01	FSMASS02	-	FSMASS09

[Example]

1 FsHndEst On, 1	' Starts the data acquisition for the gravity offset cancel.
2 For M1=1 To 9 Step 1	' Repeats 9 times.
3 Mov PP(M1)	' Robot moves to PP(M1) by joint interpolation.
4 Dly 1	' Waits for 1 second.
5 FsGetDat M1	'Stores the current robot posture and the force sensor data to the FSEST#n parameter corresponding to the value of M1.
6 Next M1	'Completes the repeat process.
7 FsHndEst Off	'Completes the data measurement for the gravity offset cancel.

[Description]

- (1) Starts the estimation process of the bias value required for the gravity offset cancel and the center of gravity position and mass of the load installed to the force sensor.
- (2) If this command is executed without the force sensor, the process is not executed.
- (3) If this command is executed continuously, the <control mode> specified with the command executed last is enabled.

FsHndEst Off**[Function]**

Estimates the data (bias value, center of gravity position and mass of the load) required for the gravity offset cancel and finishes the process.

[Syntax]

FsHndEst□Off

[Example]

1 FsHndEst On, 1	' Starts the data acquisition for the gravity offset cancel.
2 For M1=1 To 9 Step 1	' Repeats 9 times.
3 Mov PP(M1)	' Robot moves to PP(M1) by joint interpolation.
4 Dly 1	' Waits for 1 second.
5 FsGetDat M1	'Stores the current robot posture and the force sensor data to the FSEST#n parameter corresponding to the value of M1.
6 Next M1	'Completes the repeat process.
7 FsHndEst Off	'Completes the data measurement for the gravity offset cancel.

[Description]

- (1) Estimates the bias value required for the gravity offset cancel and the center of gravity position and mass of the load installed to the force sensor, and finishes the process.
- (2) Executing this command starts the estimation process of the load using the data stored in the parameters from "FSEST01" to "FSEST09".
- (3) The result estimated by this command is stored in the status variable/parameter corresponding to the <control mode> specified in the FsHndEst On command.
- (4) If this command is executed when the FsHndEst On command is not executed, the process is not executed.
- (5) The estimated result is retained until the power supply is restarted or another FsHndEst Off command is executed.
- (6) If this command is executed without the force sensor, the process is not executed.
- (7) If this command is executed while the force sense control using the <control mode> specified in the FsHndEst On command is enabled, an error L3987 occurs.
- (8) When the invalid posture data is included in the parameters from "FSEST01" to "FSEST09", an error L3987 occurs. For the posture data used by this command, see section 13 .
- (9) If the estimation result is abnormal, an error L3987 occurs.

FsGetDat

[Function]

Acquires the data (robot's position posture and force sensor data) required for the force sense calibration and stores it in a parameter.

[Syntax]

FsGetDat□<Data No.>

[Terminology]

<Data No.>	Specifies the parameter number to store the data acquired. The argument value corresponding to the number of the parameter from "FSEST01" to "FSEST09". Setting range: 1 - 9
------------	--

[Example]

1 FsHndEst On, 1	' Starts the data acquisition for the gravity offset cancel.
2 For M1=1 To 9 Step 1	' Repeats 9 times.
3 Mov PP(M1)	' Robot moves to PP(M1) by joint interpolation.
4 Dly 1	' Waits for 1 second.
5 FsGetDat M1	'Stores the current robot posture and the force sensor data to the FSEST#n parameter corresponding to the value of M1.
6 Next M1	'Completes the repeat process.
7 FsHndEst Off	'Completes the data measurement for the gravity offset cancel.

[Description]

- (1) Stores the robot's position posture and the force sensor data at the time of this command execution in the parameter specified in the <Data No.>.
- (2) If this command is executed without the force sensor, the process is not executed.
- (3) If this command is executed when the FsHndEst On command is not executed, an error L3987 occurs.

12.7 Related Status Variables for Gravity Offset Cancel Function

MELFA-BASIC VI status variables relating to the gravity offset cancel function are described below.

Table 12-10: Gravity offset cancel status variables

No.	Status variables	Function Overview	
1	P_FsBias0, P_FsBias1	Specifies/references the bias value used for the gravity offset cancel.	Control mode
2	P_FsGrPos0, P_FsGrPos1	Specifies/references the load center of gravity position used for the gravity offset cancel.	
3	M_FsMass0, M_FsMass1	Specifies/references the load mass used for the gravity offset cancel.	

P_FsBias0, P_FsBias1**[Function]**

Specifies/references the bias value used for the gravity offset cancel.

[Syntax]

Example) P_FsBias0= <Position variable 1>

Example) <Position variable 2>= P_FsBias1

[Terminology]

< Position variable 1> Specifies the bias value used for the gravity offset cancel.

< Position variable 2> Specifies the save destination for the read bias value.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the force sensor bias value contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter "FSBIAS01" setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) The estimated result is substituted when the FsHndEst Off command is executed after the FsHndEst On command <control mode> is set to "-1" or "0".
- (6) When the force sense control is enabled with <control mode> = "0", it is not possible to write P_FsBias0.
(An error L3987 occurs.)
- (7) When the force sense control is enabled with <control mode> = "-1", it is not possible to write P_FsBias1.
(An error L3987 occurs.)
- (8) When no force sensor is connected, the value is not applied even if it is written. Also, if the setting value is read, always 0.0 is output for all elements.

P_FsGrPos0, P_FsGrPos1**[Function]**

Specifies/references the load center of gravity position used for the gravity offset cancel.

[Syntax]

Example) P_FsGrPos0= <Position variable 1>

Example) <Position variable 2>= P_FsGrPos1

[Terminology]

< Position variable 1> Specifies the load center of gravity position used for the gravity offset cancel.

< Position variable 2> Specifies the save destination for the read load center of gravity position.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the center of the gravity position of the load contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter "FSBIAS01" setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) The estimated result is substituted when the FsHndEst Off command is executed after the FsHndEst On command <control mode> is set to "-1" or "0".
- (6) When the force sense control is enabled with <control mode> = "0", it is not possible to write P_FsBias0. (An error L3987 occurs.)
- (7) When the force sense control is enabled with <control mode> = "-1", it is not possible to write P_FsBias1. (An error L3987 occurs.)
- (8) When no force sensor is connected, the value is not applied even if it is written. Also, if the setting value is read, always 0.0 is output for all elements.

M_FsMass0, M_FsMass1**[Function]**

Specifies/references the load mass used for the gravity offset cancel.

[Syntax]

Example) M_FsMass0= <Numeric variable 1>
--

Example) < Numeric variable 2>= M_FsMass1

[Terminology]

< Position variable 1> Specifies the load mass used for the gravity offset cancel.

< Position variable 2> Specifies the save destination for the read load mass.

[Example]

Refer to examples in section [12.12](#).

[Description]

- (1) Specifies/references the mass of the load contained in the condition group (control mode).
- (2) The specified value is used if the Fsc On command <control mode> is set to "-1" or "0".
- (3) Default status: The parameter "FSBIAS01" setting value is updated.
- (4) The value substituted for the status variable is retained until the power is turned OFF.
- (5) The estimated result is substituted when the FsHndEst Off command is executed after the FsHndEst On command <control mode> is set to "-1" or "0".
- (6) When the force sense control is enabled with <control mode> = "0", it is not possible to write P_FsBias0.
(An error L3987 occurs.)
- (7) When the force sense control is enabled with <control mode> = "-1", it is not possible to write P_FsBias1.
(An error L3987 occurs.)
- (8) When no force sensor is connected, the value is not applied even if it is written. Also, if the setting value is read, always 0.0 is output for all elements.

12.8 Commands Relating to Learning Function

MELFA-BASIC VI commands relating to the learning function are described below.

Table 12-11: Commands Relating to Learning Function

No.	Status variables	Function Overview
1	OptmzUpdate	Updates the learning target parameter.
2	OptmzInitialize	Initializes the learning target parameter.
3	OptmzEvaluate	Evaluates the learning target variable (parameter).
4	OptmzSave	Saves the learning result.
5	OptmzLoad	Reads the learning result.

OptmzUpdate (optimize update)**[Function]**

Updates the learning target parameter in the learning function.

[Syntax]

OptmzUpdate

[Terminology]

None

[Example]

Refer to examples in section “12.8.1 Reference program”.

[Description]

- (1) Updates the parameter value in the range of status variable M_OptmzParamMin/M_OptmzParamMax based on the evaluation value (value set with the OptmzEvaluate command).
- (2) The updated parameter value is checked with the status variable M_OptmzParamVal.
- (3) The transition of evaluation value (value set with the OptmzEvaluate command) at every update can be checked with the status variable M_OptmzParamVal.
- (4) If the learning target parameter is not initialized when this command is executed, error L3801_01000 "Unable to execute the command" occurs.
- (5) If the set of evaluation value sample that is not executed with the OptmzEvaluate command when this command is executed exists, error L3801 "Unable to execute the command" occurs.
- (6) The graph of the evaluation value is displayed after the OptmzUpdate command is executed while the learning monitor of RT ToolBox3 is activated. The learning monitor screen is refreshed at 50 ms intervals. When the learning parameter data is refreshed at shorter intervals, not all of the data is available to display the graph. To enable monitoring of all the data, add the Dly command to stop the operation about 100 ms after the OptmzUpdate command.

OptmzInitialize (optimize initialize)

[Function]

Initializes learning parameters in the course of using the learning function.

[Syntax]

OptmzInitialize

[Terminology]

None

[Example]

Refer to examples in section “12.8.1 Reference program”.

[Description]

- (1) Initializes the learning function after setting the status variables M_OptmzSamples, M_OptmzParams, M_OptmzParamMin, and M_OptmzParamMax.
- (2) If one of the status variables M_OptmzSamples, M_OptmzParams, M_OptmzParamMin, and M_OptmzParamMax is changed, execute this command again.
- (3) If this command is not executed after setting or changing the status variables M_OptmzSamples, M_OptmzParams, M_OptmzParamMin, or M_OptmzParamMax, OptmzEvaluate and OptmzUpdate cannot be executed. Error L3801_01000 "Unable to execute the command" occurs.

OptmzEvaluate (optimize evaluate)

[Function]

Reflects the evaluation result of the work to the learning in the course of using the learning function.

[Syntax]

`OptmzEvaluate <Learning sample No.>, <Evaluation value>`

[Terminology]

<Sample No.> Specify the learning sample No.
 Setting range: 1 to the number of learning samples (Value of status variable
 M_OptmzSamples)

<Evaluation value> Set the evaluation value of the specified learning sample.

[Example]

Refer to examples in section "12.8.1 Reference program".

[Description]

- (1) Reflects the evaluation result set in <Evaluation value> to the learning of the specified learning sample.
- (2) The transition of <Evaluation value> at every update can be checked with the status variable M_OptmzEval.
- (3) When the value outside the range is specified in <Learning sample No.>, error L3110 "A value outside the range was set" occurs.
- (4) If the learning parameters have not been initialized, error L3801_01000 "Unable to execute the command" occurs.

OptmzSave (optimize save)

[Function]

Saves the learning result in the course of using the learning function.

[Syntax]

OptmzSave <Learning No.> [, <Overwrite flag>]

[Terminology]

<Learning No.>	Specify the file No. to save the learning result. Setting range: 1 to 10
<Overwrite flag>	Specify whether to overwrite when the specified file already exists. 0: Do not overwrite 1: Overwrite (If omitted, the file is not overwritten.)

[Example]

1 OptmzSave 1,1 'Overwrites the learning result to learning No. 1.

[Description]

- (1) Saves the result of the learning with the OptimizeUpdate command to the file related to the specified learning No.
- (2) If 1 is specified to <Overwrite flag>, the file is overwritten and saved even if the file specified in <Learning No.> already exists.
If 0 is specified to <Overwrite flag> and the file specified in <Learning No.> already exists, error L3151 "The file already exists" occurs.
- (3) When the value outside the range is specified in <Learning No.> or <Overwrite flag>, error L3110 "A value outside the range was set" occurs.
- (4) If the force sense enhancement function is disabled when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

OptmzLoad (optimize load)**[Function]**

Reads the learning result in the course of using the learning function.

[Syntax]

OptmzLoad <Learning No.>

[Terminology]

<Learning No.>	Specifies the file No. to save the learning result. Setting range: 1 to 10
----------------	---

[Example]

1	OptmzLoad 2	'Reads the result of the learning for learning No. 2.
---	-------------	---

[Description]

- (1) Reads the result of the learning with the OptimizeUpdate command from the file related to <Learning No.>.
- (2) If the specified file does not exist, error L3801 " Cannot execute this command." occurs.
- (3) When the value outside the range is specified in <Learning No.>, error L3110 "A value outside the range was set" occurs.
- (4) If the force sense enhancement function is disabled when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

12.8.1 Reference program

The following is a program example for optimizing the operation speed, stiffness coefficient, and gain for a force sense work using the learning function.

```

'=====
'   Learning setting and initialization
'=====
*LearnInit
'Learning setting
M_OptmzSamples = 5      'Number of samples
M_OptmzParams = 3      'Number of parameters (parameters to be adjusted automatically)
'
'Search range setting for automatically adjusted parameters
' (1) Speed
M_OptmzParamMin(1) = 20
M_OptmzParamMax(1) = 100
' (2) Stiffness coefficient
M_OptmzParamMin(2) = 0.5
M_OptmzParamMax(2) = 2.0
' (3) Gain
M_OptmzParamMin(3) = 2.0
M_OptmzParamMax(3) = 10.0
'
'Initialization of automatically adjusted parameters
OptmzInitialize
'
'=====
'   Learning
'=====
'Set the force sense control parameters.
'Control mode (0)
M_FsCod0 = 1              'Force sense control coordinate system (1: XYZ coordinate
system)
P_FsMod0 = (+3.0,+3.0,+3.0,+3.0,+3.0,+3.0) 'Force sense control mode (3: Limited stiffness control)
P_FsDmp0 = (+0.0,+0.0,+0.0,+0.0,+0.0,+0.0) 'Damping coefficient
P_FsStf0 = (+0.5,+0.5,+0.5,+0.0,+0.0,+0.0) 'Stiffness coefficient
'Control feature (0)
P_FsFCd0 = (+10.0,+10.0,+50.0,+3.0,+3.0,+3.0) 'Limit value
P_FsGn0 = (+5.0,+5.0,+5.0,+2.0,+2.0,+0.0)    'Force sense control gain
'
Epoch = 0
*Learn
If Epoch >= 20 Then GoTo *Fin 'Specify the number of times for learning (epochs).
For Idx = 1 To M_OptmzSamples 'Repeat the operation and evaluation for the number of samples.
'
'Acquire values of learning parameters for automatic adjustment.
MV  = M_OptmzParamVal(Idx,1) 'Speed
MStf = M_OptmzParamVal(Idx,2) 'Stiffness coefficient
MGn  = M_OptmzParamVal(Idx,3) 'Gain
'
'Set the force sense control parameters.
P_FsStf0.X = MStf '[Learning] Set the stiffness coefficient.
P_FsStf0.Y = MStf '[Learning] Set the stiffness coefficient.
P_FsGn0.X  = MGn  '[Learning] Set the force sense control gain.
P_FsGn0.Y  = MGn  '[Learning] Set the force sense control gain.
'
'Preparation before starting force sense movement
Def Act 1, M_Timer(8) > MTimeOut GoSub *TimeOut, S
'
Mov PStart
Dly 1
'

```

```

M_Timer(8) = 0
If MTimeOut<>0 Then Act 1=1
,

'Start force sense movement.
Fsc On, 0, 0, 1
Spd MV           '[Learning] Specify the speed.
M_Timer(1) = 0
Mvs PEnd
*Loop If P_Fbc.Z > PEnd.Z Then GoTo *Loop    'Loops until the target position is passed over.
MTime = M_Timer(8)
Fsc Off
,

Act 1=0
,

'Evaluation of movement (learning)
MEval1 = M_FsRsltFMax    'Maximum reaction force of the force sense movement
MEval2 = MTime / 1000    'Work time [s]
If MEval1 > 30 Then      'Set the evaluation value to -1 when the reaction force is 30 N or more during
                        work.

    MEval = -1
Else                    'Set the inverse of tact time as evaluation value when the reaction force is 30
                        N or less (faster the better).

    MEval = 1/MEval
'Reflect the evaluation result to the learning.
OptmzEvaluate Idx, MEval    'Set the evaluation value.
Next
OptmzUpdate                'Update the parameter values based on the evaluation values.
Epoch = Epoch + 1
GoTo *Learn
,

*Fin
OptmzSave 1,1    'Save the result of the learning to the file in the controller.
Hit

```

12.9 Status Variables Relating to Learning Function

This section describes the status variables of MELFA-BASIC VI relating to the learning function.

Table 12-12: Status variable list relating to the learning function

No.	Status variables	Function Overview
1	M_OptmzSamples	Sets/checks the number of learning samples.
2	M_OptmzParams	Sets/checks the number of learning parameters.
3	M_OptmzParamMin	Sets/checks the minimum searching range value for learning parameters.
4	M_OptmzParamMax	Sets/checks the maximum searching range value for learning parameters.
5	M_OptmzParamVal	Checks the current value of learning parameters.
6	M_OptmzEval	Checks the evaluation value of the learning.
7	M_OptmzLearnNum	Checks the number of times for learning.

M_OptmzSamples

[Function]

Sets/checks the number of learning samples in the course of using the learning function.

[Syntax]

```
<Numeric variable> = M_OptmzSamples  
M_OptmzSamples = <Number of learning samples>
```

[Terminology]

<Numeric variable> Specify the substitute numeric variable.

<Number of learning samples> Specify the number of learning samples.
Setting range: 0 to 50 (initial value: 0)

[Example]

1 M_OptmzSamples = 5	'Set the number of learning samples to 5.
2 M1 = M_OptmzSamples	'Store the setting of number of learning samples in M1.

[Description]

- (1) Sets and checks the number of learning samples in the course of using the learning function.
- (2) When the value outside the setting range is specified in <Number of learning samples>, error L8911 "A value outside the range was set" occurs.
- (3) After this status variable is written, the OptimzInitialize command is always required to be executed. If the OptimzInitialize command is not executed, OptimzEvaluate and OptimzUpdate cannot be executed. Error L3801_01000 "Unable to execute the command" occurs.
- (4) If the force sense enhancement function is disabled^(*) when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

M_OptmzParams

[Function]

Sets/checks the number of parameters for learning (learning parameters) in the course of using the learning function.

[Syntax]

```
<Numeric variable> = M_OptmzParams
M_OptmzParams = <Number of learning parameters>
```

[Terminology]

<Numeric variable>	Specify the substitute numeric variable.
<Number of learning parameters>	Set the number of learning parameters. Setting range: 0 to 20 (initial value: 0)

[Example]

1 M_OptmzParams = 10	'Set the number of learning parameters to 10.
2 M1 = M_OptmzParams	'Store the setting of the current number of learning parameters in M1.

[Description]

- (1) Checks and sets the number of learning parameters.
- (2) When the value outside the setting range is specified in <Number of learning parameters>, error L8911 "A value outside the range was set" occurs.
- (3) After this status variable is written, the OptimzInitialize command is always required to be executed. If the OptimzInitialize command is not executed, OptimzEvaluate and OptimzUpdate cannot be executed. Error L3801 "Unable to execute the command" occurs.
- (4) If the force sense enhancement function is disabled when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

M_OptmzParamMin

[Function]

Sets/checks the minimum searching range value for learning parameters in the course of using the learning function.

[Syntax]

```
<Numeric variable> = M_OptmzParamMin(<Learning parameter No.>)  
M_OptmzParamMin(<Learning parameter No.>) = <Minimum value>
```

[Terminology]

<Numeric variable>	Specify the substitute numeric variable.
<Learning parameter No.>	Specify the learning parameter No. Setting range: 1 to the number of learning parameters (Value of status variable M_OptmzParams)
<Minimum value>	Specify the minimum value of the parameter searching range. (Initial value: 0.0)

[Example]

1 M_OptmzParamMin = 10	'Set the lower limit value of the learning parameter to 10.
2 M_OptmzParamMax = 50	'Set the upper limit value of the learning parameter to 50.

[Description]

- (1) Sets and checks the minimum searching range value of learning parameters.
- (2) When the value outside the setting range is specified in <Learning parameter No.>, error L3110 "A value outside the range was set" occurs.
- (3) After this status variable is written, the OptimzInitialize command is always required to be executed. If the OptimzInitialize command is not executed, OptimzEvaluate and OptimzUpdate cannot be executed. Error L3801 "Unable to execute the command" occurs.
- (4) If the force sense enhancement function is disabled^(*) when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

M_OptmzParamMax

[Function]

Sets/checks the maximum searching range value of learning parameters in the learning function.

[Syntax]

```
<Numeric variable> = M_OptmzParamMax(<Learning parameter No.>)
M_OptmzParamMax(<Learning parameter No.>) = <Maximum value>
```

[Terminology]

<Numeric variable>	Specify the substitute numeric variable.
<Parameter INDEX>	Specify the learning parameter No. Setting range: 1 to the number of learning parameters (Value of status variable M_OptmzParams)
<Maximum value>	Specify the maximum value of the parameter searching range. (Initial value: 1.0)

[Example]

- | | | |
|---|-------------------------|--|
| 1 | M_OptmzParamMin(1) = 10 | 'Set 10 for the lower limit value of the learning parameter 1. |
| 2 | M_OptmzParamMin(1) = 50 | 'Set 50 for the upper limit value of the learning parameter 1. |

[Description]

- (1) Sets and checks the maximum searching range value of learning parameters for optimization.
- (2) When the value outside the range is specified in <Learning parameter No.>, error L3110 "A value outside the range was set" occurs.
- (3) After this status variable is written, the OptimzInitialize command is always required to be executed. If the OptimzInitialize command is not executed, OptmzEvaluate and OptmzUpdate cannot be executed. Error L3801 "Unable to execute the command" occurs.
- (4) If the force sense enhancement function is disabled when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

M_OptmzParamVal

[Function]

Checks the latest learning parameter value in the course of using the learning function.

[Syntax]

<Numeric variable> = M_OptmzParamVal(<Learning sample No.>, <Learning parameter No.>)

[Terminology]

<Numeric variable>	Specify the substitute numeric variable. (Initial value: 0.0)
<Learning sample No.>	Specify the learning sample No. to be checked. Setting range: 0 to the number of learning parameters (Value of status variable M_OptmzSamples)
<Learning parameter No.>	Specify the learning parameter No. to be checked. Setting range: 1 to the number of learning parameters (Value of status variable M_OptmzParams)

[Example]

1 M1 = M_OptmzParamVal(1,3) 'Store the value of learning parameter 3 in learning sample 1 in M1.

[Description]

- (1) This status variable is read-only. It cannot be written.
- (2) Checks the value of the parameter after the learning (latest value).
When 0 is specified in <Learning sample No.>, the top-rated variable (parameter) of all the samples is returned.
When 1 or more is specified in <Learning sample No.>, the top-rated variable (parameter) of the specified sample is returned.
- (3) When the value outside the range is specified in <Learning sample No.> or <Learning parameter No.>, error L3110 "A value outside the range was set" occurs.
- (4) If the force sense enhancement function is disabled when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

M_OptmzEval

[Function]

Checks the evaluation value of the learning in the course of using the learning function.

[Syntax]

<code><Numeric variable> = M_OptmzEval([<Learning sample No.>])</code>
--

[Terminology]

`<Numeric variable>` Specify the substitute numeric variable.

`<Sample INDEX>` Specify the learning sample No. to be checked.
 Setting range: -1 to the number of learning samples (Value of status variable M_OptmzSamples)

[Example]

1 M1 = M_OptmzEval(1)	'Store the largest evaluation value of learning sample 1 in M1.
2 M2 = M_OptmzEval(0)	'Store the largest evaluation value of all learning samples in M2.
3 M3 = M_OptmzEval(-1)	'Store the average value of the largest evaluation value of each learning sample in M3.

[Description]

- (1) This status variable is read-only. It cannot be written.
- (2) Checks the evaluation value of learning. The value is updated by executing the OptmzUpdate command. Returns the largest evaluation value of the specified learning sample to `<Learning sample No.>`.
 When 0 is specified in `<Learning sample No.>`, the largest value of all evaluation values is returned.
 When -1 is specified in `<Learning sample No.>`, the average value of the largest evaluation value of each learning sample is returned.
- (3) When the value outside the range is specified in `<Learning sample No.>`, error L3110 "A value outside the range was set" occurs.
- (4) If the force sense enhancement function is disabled^(*) when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.
- (5) The minimum single-precision real number is set as each evaluation value by executing the OptmzInitialize command.
- (6) Zero is set for each evaluation value in the initial state at power-on.

M_OptmzLearnNum

[Function]

Checks the number of times for the learning in the course of using the learning function.

[Syntax]

<Numeric variable> = M_OptmzLearnNum

[Terminology]

<Numeric variable> Specify the substitute numeric variable.

[Example]

1 M1 = M_OptmzLearnNum 'Store the current number of times for the learning in M1..

[Description]

- (1) This status variable is read-only. It cannot be written.
- (2) The number of times for the learning (searching) for the learning parameters after OptmzInitialize is executed is returned.
- (3) The value is reset to 0 when the OptmzInitialize command is executed.
- (4) If the force sense enhancement function is disabled^(*) when this command is executed, error L3781 "Unable to use MELFA Smart Plus command" occurs.

12.10 Other Related Commands

Def Act

[Function]

Defines the interrupt conditions and processing for interrupt processing. Interrupts are used when input signals and so on are monitored while running programs to prioritize certain processing when the specified conditions are reached


* "F" (force sense stop) has been added to the argument <Type> for force sense control.

[Syntax]

Def□Act <Priority No.>, <Format>, <Processing> [, <Type>]

[Terminology]

- | | |
|----------------|---|
| <Priority No.> | This is the interrupt priority No. and sets Nos. 1 to 8 with a constant. |
| <Format> | <p>This function is described with the following formats as the interrupt conditions.</p> <p><Numerical data> <Comparison operator> <Numerical data> or,</p> <p><Numerical data> <Logic operator> <Numerical data></p> <p>* <Numerical data> refers to the following:</p> <p><Numeric constant> <Numeric variable> <Numeric array constant> <Component data></p> |
| <Processing> | Describes the GoTo or GoSub statement required for processing when an interrupt occurs. |
| <Type> | <p>Omission: Stop type 1</p> <p>Stops at the stop position assuming an external override of 100%.
It takes longer to stop if the external override is small, and so the robot always stops at the same position.</p> <p>S: Stop type 2</p> <p>Not dependent on the external override, and the robot decelerates to a stop over the minimum time and distance.</p> <p>L: Execution complete stop</p> <p>Performs interrupt processing after the robot has moved (1 line is completed during execution) to its target position.</p> <p>F: Force sense stop</p> <p>Not dependent on the external override, and the robot decelerates to a stop over the minimum time and distance.
If force sense control is enabled, the robot stops immediately when the robot movement speed linear component is 50 [mm/s] or less, and the rotational component is 50 [deg/s] or less.</p> |



If force sense control is disabled, the robot decelerates to a stop in the same manner as that for Stop type 2 (S).

* Additional axes decelerate to a stop in the same manner as that for Stop type 2 (S), regardless of whether force sense control is enabled or disabled.

- * If stopped with a Force sense stop (F), force sense control is disabled (including servo OFF), or position offset with force sense control is fixed at the stopped status until the interrupt is prohibited with "Act <Priority No.>=0".
- * Use upper case alphabet characters for the <Type>. If lower case alphabet characters are used, an error occurs when registering. (Error L.4220)

[Example]

```

1 Def Act 1,M_In(17)=1 GoSub *L100      ' When the input signal for general purpose input signal No. 17
                                         ' turns ON,
                                         ' this defines that the *L100 (step No. 10) sub-routine
                                         ' is called.
2 Def Act 2,MFG1 And MFG2 GoTo *L200    ' If logical products MFG1 and MFG2 become true,
                                         ' this defines a jump to *L200 (step No. 20).
3 Def Act 3,M_Timer(1)>10500 GoSub *LBL  ' Jumps to *LBL (step No. 30) sub-routine after 10.5 seconds
                                         ' has elapsed.
:
10 *L100:M_Timer(1)=0                    ' Sets the timer to zero.
11 Act 3=1                               ' Enables Act 3.
12 Return 0
:
20 *L200:Mov P_Safe
21 End
:
30 *LBL
31 M_Timer(1)=0                          ' Returns the timer to zero.
32 Act 3=0                               ' Disables Act 3.
32 Return 0

```

[Description]

- (10)Describes a Return command at the end of the jump destination processing called with the interrupt.
- (11)If returned to the next step from interrupt processing with Return 1, prohibit interrupts in the interrupt processing. If interrupts are not prohibited and interrupt conditions are left established, interrupt processing is performed again before returning to the next step, and therefore there are times when steps are skipped without being executed.
- (12)The interrupt priority sequence is fixed with the <Priority No.>, and the priority rises in the order 1 to 8 as the number increases.
- (13)Up to 8 interrupts can be set simultaneously, and are distinguished by <Priority No.>.
- (14)Only a simple <Logic operator> or <Comparison operator> can be used for <Format>. Parentheses (operator) cannot be used either.
- (15)If a Def Act command for the same priority No. is described, the latter defined command is enabled.
- (16)The Def Act command is used only to define interrupts, and therefore interrupt permission/prohibition should be specified with the Act command.
- (17)Priority for communication interrupts (Com) is even higher than for interrupts defined with the Def Act command.
- (18)The Def Act command is only valid within the defined program. If using interrupt processing in programs (sub-programs) called with the CallP command (call between programs), it is necessary to redefine processing at the sub-program.
- (19)If an interrupt occurs when a GoTo command is specified in <Processing> with the Def Act command, interrupts being processed while executing subsequent programs are left as is, and only interrupts with high priority are received. Processing of interrupts with the GoTo command is cancelled by executing the End command.
- (20)It is not possible to describe a condition format combined with a log operator such as in (M1 And &H001) = 1.

- (21) If an interrupt is entered while performing perfect circle interpolation or circular interpolation (Mvc, Mvr, Mvr2, Mvr3) and control is returned to the original step with Return 0, the robot returns to the perfect circle or circular interpolation start point before once again performing circular or arc interpolation.
- (22) If an interrupt is entered while performing arch interpolation and control is returned to the original step with Return 0, the robot performs arch interpolation from the position at that time.

[Related commands]

Act













Caution

Set the interrupt stop type correctly based on the application.

If wishing to stop the robot with an interrupt over the minimum time and distance when executing a movement command, specify "S" for the Stop type.

Conceptual drawings of each stop type for the execution program when interrupt conditions are established during robot movement are shown below.

Stop Type	External Override 100% (Max. Speed)	External Override 50%
Stop type 1 (Omission) $S1 = S2$		
Stop type 2 (S)		
Execution complete stop (L) $S3 = S4$		
Force sense stop (F)	<p>■ Force sense control enabled</p>  <p>50 [mm/s] 50 [deg/s]</p>	<p>■ Force sense control enabled</p>  <p>50 [mm/s] 50 [deg/s]</p>
	<p>■ Force sense control disabled (Same as Stop type)</p> 	<p>■ Force sense control disabled (Same as Stop type)</p> 

12.11 Related Status Variables for MELFA Smart Plus

<MELFA Smart Plus card>

Variable name	Array designation	Details	Attribute *1)	Data type, Unit	Page
M_SmartPlus*2)	1	MELFA Smart Plus function usage status	R	Integer type	—
C_SmartPlus*2)	1	MELFA Smart Plus function name	R	Character string type	—

*1) Attributes in the table, R: Read only


*2) For the Robot (system) status variable of MELFA Smart Plus card, refer to the separate volume, "Instruction Manual/MELFA Smart Plus".

12.12 Examples

Several force sense control program examples are shown below.

■ Example 1 〈Sample Program FB01.prg〉

The robot searches for the target object while moving in the Y-axis direction. When the object is found, the robot moves in the X-axis direction while applying a constant force in the target object Y-direction.



'Control mode (0) setting

P_FsStf0=(+0.00,+0.01,+0.00,+0.00,+0.00,+0.00)(0,0)

'Stiffness coefficient (Specifies Y-axis component as 0.01 [N/mm])

P_FsDmp0=(+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Damping coefficient (no specification)

P_FsMod0=(+0.00,+1.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Force sense control type (Specifies force control in Y-axis direction.)

M_FsCod0=1

'Force sense coordinate system (Specifies XYZ coordinate system.)

'Control characteristics (0) setting

P_FsGn0=(+0.00,+1.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Gain (Specifies Y-direction as 1.0 [10^{-3} mm/N].)

P_FsFLm0=(+20.00,+0.50,+20.00,+5.00,+5.00,+5.00)(0,0)

'Force detection setting value (Specifies Y-axis direction as 0.5 [N].)

P_FsFCd0=(+0.00,+2.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Force control (Specifies Y-axis direction as 2.0 [N].)

Def Act 1,M_FsLmtS=1 GoTo *XMOV,S 'Defines so that interrupt processing performed if force detection setting value exceeded.

FsLog On 'Starts collecting force sense log.

Fsc On,0,0,1 'Enables force sense control with control mode=0, control characteristics =0, and offset cancel enabled.

P1=P_Curr

P1.Y=P1.Y+200

Spd 5

Act 1=1

Mvs P1 'Performs interrupt processing if contact with the target object is made during movement.

Fsc Off 'Disables force sense control.

FsLog Off,7 'Ends force sense log collection and creates log file No.7.

Act 1=0

End

'Interrupt processing

*XMOV

P2=P_FsCurPr

P2.X=P2.X+100 'Sets position +100 mm in X-axis direction from current position as target position.

FsGChg 5,100,2 'Changes the gain to the control characteristics 2 (parameter) setting value over 100 ms from the interpolation progress rate 5% position.

Mvs P2 'Moves in the X-axis direction while applying 2.0 [N] of force in the Y-axis direction.

Fsc Off 'Disables force sense control.


FsLog Off,7 'Ends force sense log collection and creates log file No.7.

FsOutLog 7 'Transfers log file No.7 to the computer by FTP.

End

■ Example 2 〈Sample Program FB02.prg〉

Performs the insertion movement in the Z-axis direction with the X/Y-direction softened. An error occurs and movement is interrupted if a force greater than the specified value is applied when inserting.



'Control mode (0) setting

P_FsStf0=(+0.01,+0.01,+0.00,+0.00,+0.00,+0.00)(0,0)

'Stiffness coefficient (Specifies X/Y-axis component as 0.01 [N/mm].)

P_FsDmp0=(+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Damping coefficient (no specification)

P_FsMod0=(+2.00,+2.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Force sense control type (Specifies stiffness control in X/Y-axis direction.)

M_FsCod0=0

'Force sense coordinate system (Specifies tool coordinate system.)

,

'Control characteristics (0) setting

P_FsGn0=(+80.00,+80.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Gain (Specifies X/Y-axis direction as X,Y 80 [10^{-3} mm/N].)

P_FsFLm0=(+20.00,+20.00,+10.00,+5.00,+5.00,+5.00)(0,0)

'Force detection setting value (Specifies Z-axis direction as 10 [N].)

P_FsFCd0=(+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Force control (no specification)

,

Def Act 1,P_FsLmtX.Z=1 GoTo *ESCP,S

' Defines so that interrupt processing performed if the force detection setting value is exceeded in Z-direction.

Mov P1

'Moves to insertion start position.

,

FsLog On 'Starts collecting force sense log.

Fsc On,0,0,1 'Enables force sense control with control mode=0, control characteristics =0, and offset cancel enabled.

Spd 5

Act 1=1

Mvs P2 'Performs the insertion movement in the Z-axis direction and performs interrupt processing if the force detection setting value is exceeded.

Fsc Off 'Disables force sense control.

FsLog Off,1 'Ends force sense log collection and creates log file No.1.

Act 1=0

End

,

'Interrupt processing

*ESCP

Fsc Off 'Disables force sense control.

Spd 50

Mvs P1 'Retreats to insertion start position.

FsLog Off,1 'Ends force sense log collection and creates log file No.1.


FsOutLog 1 'Transfers log file No.7 to the computer by FTP.

Error 9100 Elicits error L9100.

End

■ Example 3 〈Sample Program FB03.prg〉

Searches for open holes on the XY plane. If a hole is found, the XY coordinates for the holes center position are calculated.



'Control mode (0) setting

P_FsStf0=(+0.00,+0.00,+1.00,+0.00,+0.00,+0.00)(0,0)

'Stiffness coefficient (Specifies Z-axis component as 1 [N/mm].)

P_FsDmp0=(+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Damping coefficient (no specification)

P_FsMod0=(+0.00,+0.00,+2.00,+0.00,+0.00,+0.00)(0,0)

'Force sense control type (Specifies stiffness control in Z-axis direction.)

M_FsCod0=1

'Force sense coordinate system (Specifies XYZ coordinate system.)

,

'Control characteristics (0) setting

P_FsGn0=(+0.00,+0.00,+40.00,+0.00,+0.00,+0.00)(0,0)

'Gain (Specifies Z-axis direction as 40 [10^{-3} mm/N].)

P_FsFLm0=(+20.00,+20.00,+5.00,+5.00,+5.00,+5.00)(0,0)

'Force detection setting value (Specifies Z-axis direction as 5 [N].)

P_FsFCd0=(+0.00,+0.00,+0.00,+0.00,+0.00,+0.00)(0,0)

'Force control (no specification)

,

Def Act 1,P_FsLmtR.Z=-1 GoTo *PCEN,S

'Defines so that interrupt processing is performed if the Z-axis direction becomes smaller than force detection setting value.

P2=P1

P2.X=P2.X+100

'Searches for width of 100 mm in X-direction.

Fsc On,0,0,1

'Enables force sense control with control mode=0, control characteristics =0, and offset cancel enabled.

Mvs P1

'Moves to search start position (Moves approximately -10 mm in the Z-axis direction from the search plane to a low position, and then pushes in the Z-direction.)

,

Spd 5

Act 1=1

For M1=1 To 10

'Searches in 5 mm intervals in the Y-direction. Force is lost in the Z-axis direction if the robot axis drops into a hole, and therefore an interrupt is entered.

Mvs P1

Mvs P2

P1.Y=P1.Y+5

P2.Y=P1.Y

Mvs P2

Mvs P1

P1.Y=P1.Y+5

P2.Y=P1.Y

Next M1

Act 1=0

Fsc Off

End

,

'Interrupt processing

*PCEN

Dim PX(2),PY(2)

P0=P_Curr

'The position at which the robot axis falls into the hole and stops is used as a reference.

PX(1)=P0

```

PX(2)=P0
PY(1)=P0
PY(2)=P0
PX(1).X=P0.X+10      'The position ±10 mm in the XY-direction from the reference position is calculated.
PX(2).X=P0.X-10
PY(1).Y=P0.Y+10
PY(2).Y=P0.Y-10
,

Fsc Off
P_FsFLm0=(+2.00,+2.00,+5.00,+5.00,+5.00,+5.00)(0,0)      'Changes the X,Y-axis direction force detection setting value to 2 [N].
Fsc On,0,0,1
MFLG=0
,

For M1=1 To 2
Mvs PX(M1) Wthlf P_FsLmtR.X=1,Skip 'Moves ±10 mm in the X-axis direction and skips if the force detection setting is exceeded.
If M_SkipCq=1 Then
PX(M1)=P_FsLmtP      'If skipped, the position at which the force detection setting value is exceeded is retained.
MFLG=MFLG+1
EndIf
Mvs P0
Fsc Off              'Force sense control is temporarily enabled to reset P_FsLmtP.
Fsc On,0,0,1
Next M1
,


For M1=1 To 2
Mvs PY(M1) Wthlf P_FsLmtR.Y=1,Skip 'Moves ±10 mm in the Y-axis direction and skips if the force detection setting is exceeded.
If M_SkipCq=1 Then
PY(M1)=P_FsLmtP      'If skipped, the position at which the force detection setting value is exceeded is retained.
MFLG=MFLG+1
EndIf
Mvs P0
Fsc Off              ' Force sense control is temporarily enabled to reset P_FsLmtP.
Fsc On,0,0,1
Next M1
,

If MFLG=4 Then      '4 points are found.
PTMP=(PX(1)+PX(2))/2
P0.X=PTMP.X        'The X-axis direction center position is set for P0.
PTMP=(PY(1)+PY(2))/2
P0.Y=PTMP.Y        ' The Y-axis direction center position is set for P0.
Else                '4 points are not found.
Error 9100          'Elicits error L9100.
EndIf
End

```

■ Example 4 〈Sample Program FB04.prg〉

The robot moves at the specified speed in the Z-direction to make contact with the target object. If the Z-axis direction robot position and force sensor data satisfy the specified conditions following contact, the robot starts moving in the Y-axis direction while pushing in the Z-axis direction.



```

M_FsCod0 = 0                                ' Specifies the tool coordinate system.
P_FsMod0 = (0, 1, 1, 0, 0, 0)(0, 0)         ' Specifies a force control in the Y/Z-axis direction.
'Control characteristics group ( 0 ) setting
P_FsFCd0 = (0, 0, 5, 0, 0, 0)(0, 0)         ' Specifies a force control of 5 N in the Z-axis direction.
P_FsSpd0 = (0, 0, 10, 0, 0, 0)(0, 0)        ' Specifies a speed of 10 mm/s in the Z-axis direction.
P_FsSwF0 = (0, 0, 0.5, 0, 0, 0)(0, 0)       ' Specifies a switching judgment value of 0.5 N in the Z-axis direction.
P_FsGn0 = (0, 0, 10, 0, 0, 0)(0, 0)         ' Sets a force control gain of 10*10-3 mm/N in the Z-axis direction.
:                                             ' No movement is made in the Y-axis direction and so 0 is specified.
:
'Control characteristics group ( -1 ) setting
P_FsFCd1 = (0, 3, 5, 0, 0, 0)(0, 0)         ' Specifies a force control of 3 N in the Y-axis direction, and the Z-axis direction is left at 5 N.
P_FsSpd1 = (0, 20, 0, 0, 0, 0)(0, 0)        ' Specifies a speed of 20 mm/s in the Y-axis direction.
:                                             ' Force control is maintained in the Z-axis direction and so 0 mm/s is specified.
P_FsSwF1 = (0, 2, 0, 0, 0, 0)(0, 0)         ' Specifies a switching judgment value of 2 N in the Y-axis direction.
P_FsGn1 = (0, 10, 10, 0, 0, 0)(0, 0)        ' Sets a force control gain of 10*10-3 mm/N in the Y-axis direction.
:                                             ' (Moves the robot in the Y-axis direction.)
:
Def MoTrg 1, (P_Fbc.Z < 100) And (P_FsCurD.Z > 4.8) ' Defines Mo trigger No.1.
SetMoTrg 1                                ' Enables Mo trigger No.1.
Fsc On, 0, 0, 1                            ' Enables force control for control characteristics 0.
Wait M_MoTrg(1) = 1                        ' Moves in the Z-direction until the trigger when contact made with the target
:                                             object turns ON.
Dly 3                                      ' Waits for settling after contact.
FsCTrg 1, 100, -1                          ' Mo trigger No.1 is ON and so the control characteristics changed to -1.
:                                             ' Movement starts in the Y-axis direction while pushing with 5 N in the Z-axis direction.
:


```


13 Parameter Specifications

This Chapter describes parameters relating to the force sense function.

13.1 Force Sense Function Related Parameter List

Table 13-1: Force sense control related parameters

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Force sense interface unit recognition	AXJNO	16 integers	Sets the force sense interface unit or additional axis number for the element corresponding to the servo control axis number being used. <If using force sense interface unit> Servo control axis No.: Set "9" for axis No.1.	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
	AXMENO	16 integers	Enter a mechanical number corresponding to the servo control axis number being used. Always set "0" for axes that are not being used.	0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
Calibration	FSHAND	1 integer	<p>Selects the force sensor coordinate system hand system (left-hand system/right-hand system). The force sensor coordinate system hand system differs depending on the sensor attachment direction, and therefore it is necessary to change the setting based on the attachment direction. Settings also need to be changed depending on the type of sensor installed.</p> <p>0: Force sensor coordinate system left-hand system 1: Force sensor coordinate system right-hand system</p> <p><Left-hand system> <Right-hand system></p> 	0
	FSXTL	6 real numbers	<p>Sets the positional relationship between the force sensor coordinate system and the force sense coordinate system.</p> <p>1st element to 3rd element: Set the offset from the mechanical interface coordinate system origin to the force sensor coordinate system origin.</p> <p>4th element to 6th element: The angle to be specified depends on the setting of parameter FSHAND. Specify the rotational angle so that the force sensor coordinate system [+FXs, +FYs, +FZs] matches the force sense coordinate system (mechanical interface) [+FX, +FY, +FZ] as shown in Fig. 6-5 when the setting is "0" (left-handed system). Specify the rotational angle so that the force sensor coordinate system matches the mechanical interface coordinate system [+Xm, +Ym, +Zm] when the setting is "1" (right-handed system).</p>	<p>0.0, 0.0, 0.0, 0.0, 180.0, 0.0 (vertical multi-joint robots)</p> <p>0.0, 0.0, 0.0, 0.0, 0.0, 180.0 (horizontal multi-joint robots)</p>
Force sensor tolerance	FSLMTMX	6 real numbers	<p>Sets the force sensor tolerance. If sensor data exceeding the force and moment set at this parameter is detected, an error (H7660) occurs and the robot is stopped. (Force sense control will be disabled.)</p> <p>1st element: Force sensor data Fx tolerance [N] 2nd element: Force sensor data Fy tolerance [N] 3rd element: Force sensor data Fz tolerance [N] 4th element: Force sensor data Mx tolerance [N·m] 5th element: Force sensor data My tolerance [N·m] 6th element: Force sensor data Mz tolerance [N·m]</p>	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting								
Force sense control offset limit	FSCORMX	2 real numbers	Sets the maximum position offset for force sense control. 1st element: Position maximum offset [mm] 2nd element: Posture maximum offset [deg.] [Setting range] 1st element: 0 to +200.0 2nd element: 0 to +150.0	10.0, 10.0								
Force sensor data filter	FSFLCTL	1 real number	Sets the force sensor data filter time constant. [Unit]: ms [Setting range]: 0 to +1000.0	1.7								
	HDFSFLJL	1 real number	Sets the force sensor data filter time constant that functions when MELFA High Drive is enabled. [Unit]: ms [Setting range]: 0 to +1000.00	5.00, 5.00, 5.00, 5.00, 5.00, 5.00								
Selection of sensor	FSTYPE	1 integer	Set the sensor ID using a maximum of four digits. 1st element: Force sensor ID setting [Setting range]: 0 to 9999 <table border="1"><thead><tr><th>Setting value</th><th>Force sensor</th></tr></thead><tbody><tr><td>0</td><td>1F-FS001-W200/ 1F-FS001-W1000</td></tr><tr><td>100</td><td>ZYX080A501/ZYX080A501Z/ ZYX100A102/ZYX125A102 (SINTOKOGIO, LTD.)</td></tr><tr><td>200</td><td>FH-300-20 (Canon Inc.)</td></tr></tbody></table>	Setting value	Force sensor	0	1F-FS001-W200/ 1F-FS001-W1000	100	ZYX080A501/ZYX080A501Z/ ZYX100A102/ZYX125A102 (SINTOKOGIO, LTD.)	200	FH-300-20 (Canon Inc.)	0
Setting value	Force sensor											
0	1F-FS001-W200/ 1F-FS001-W1000											
100	ZYX080A501/ZYX080A501Z/ ZYX100A102/ZYX125A102 (SINTOKOGIO, LTD.)											
200	FH-300-20 (Canon Inc.)											
Force sensor minimum force control	FSMINCTL	6 real number	Sets the minimum force controlfor the force sensor. 1st element: Minimum force control setting value for force sensor Fx [N] 2nd element: Minimum force control setting value for force sensor Fy [N] 3rd element: Minimum force control setting value for force sensor Fz [N] 4th element: Minimum force control setting value for force sensor Mx [Nm] 5th element: Minimum force control setting value for force sensor My [Nm] 6th element: Minimum force control setting value for force sensor Mz [Nm]	0.3, 0.3, 0.3, 0.03, 0.03, 0.03								
Force sensor calibration data	FSEST01 ~09	12 real number	Sets the robot's posture and the force sensor data used for the force sensor calibration execution. 1st element: Robot position X [mm] 2nd element: Robot poisition Y [mm] 3rd element: Robot poisition Z [mm] 4th element: Robot posture A [deg] 5th element: Robot posture B [deg] 6th element: Robot posture C [deg] 7th element: Force sensor data Fx [N] 8th element: Force sensor data Fy [N] 9th element: Force sensor data Fz [N] 10th element: Force sensor data Mx [Nm] 11th element: Force sensor data My [Nm] 12th element: Force sensor data Mz [Nm] (The value is updated at the FsGetDat command is executed.)	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0								

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Control mode	FSCOD01 - 09	1 integer	Specifies the force sense coordinate system. (See section 8.1.2.1 .) 0: Tool coordinate system 1: XYZ coordinate system [Setting range]: 0, 1	0
	FSFMD01 - 09	8 integers	Selects the force sense control mode for each coordinate system axis. (See section 8.1.2.2 .) 0: Position control 1: Force control 2: Stiffness control 3: Limited stiffness control [Setting range]: 0, 1, 2, 3	0, 0, 0, 0, 0, 0, 0, 0
	FSSTF01 - 09	8 integers	Sets the stiffness coefficient for force sense control (stiffness control). (See section 8.1.2.3 .) [Setting range]: 0.0 - 1000.0 [Setting unit]: X, Y, Z axes = N/mm A, B, C axes = N·m/deg (This setting is not required for axes for which stiffness control is not selected.)	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0
	FSDMP01 - 09	8 real numbers	Sets the damping coefficient (responsiveness) for force sense control. (See section 8.1.2.4 .) [Setting range]: 0.0 - 1.0 [Setting unit]: X, Y, Z axes = N/(mm/s), A, B, C axes = N·m/(deg/s)	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0
Control mode	FSBIAS01-09	6 real numbers	Sets the bias value used for gravity offset cancel. 1st element: Force sensor data Fx bias value [N] 2nd element: Force sensor data Fy bias value [N] 3rd element: Force sensor data Fz bias value [N] 4th element: Force sensor data Mx bias value [N·m] 5th element: Force sensor data My bias value [N·m] 6th element: Force sensor data Mz bias value [N·m] (These values because these are set automatically by the force calibration function, so you do not need to be set again.)	0.0, 0.0, 0.0, 0.0, 0.0, 0.0
	FSGRP01-09	6 real numbers	Sets the load center of gravity position used for gravity offset cancel. 1st element: Load center of gravity position X [mm] 2nd element: Load center of gravity position Y [mm] 3rd element: Load center of gravity position Z [mm] 4th element: Rotation angle of load center of gravity A [deg] 5th element: Rotation angle of load center of gravity B [deg] 6th element: Rotation angle of load center of gravity C [deg] (These values because these are set automatically by the force calibration function, so you do not need to be set again.)	0.0, 0.0, 0.0, 0.0, 0.0, 0.0
	FSMASS01 - 09	1 real number	Sets the load mass used for gravity offset cancel. [Setting unit]: kg (These values because these are set automatically by the force calibration function, so you do not need to be set again.)	0.0

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Control characteristics	FSFCMD01 - 09	8 real numbers	<p>The value has different roles in the force control and the limited stiffness control.</p> <p>[In the case of force control] Sets the force command for force sense control (force control). (See section 8.1.2.5.) [Setting range]: - force sensor tolerance value to + force sensor tolerance value [Setting unit]: X, Y, Z component = N A, B, C component = N·m (This setting is not required for axes for which force control is not selected.)</p> <p>[In the case of the stiffness control with limit] Sets the limit value for the limited stiffness control. (See section 8.1.2.6.) [Setting range]: 0 to + force sensor tolerance value [Setting unit]: X, Y, Z, L1 component = N (L1 component sets the limit value for the resultant force.) A, B, C, L2 component = N·m (L2 component sets the limit value for the resultant moment.) (The value is not required in the axis that is not applying the limited stiffness control.)</p>	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0
	FSSPD01 - 09	8 real numbers	<p>Sets the speed command value for force sense control (force control). (See section 8.1.2.7.) [Setting range]: 0.0 - 50.0 [Setting unit]: X, Y, Z component = mm/s A, B, C component = deg/s (This setting is not required for axes for which force control is not selected.)</p>	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0
Control characteristics	FSSWF01 - 09	8 real numbers	<p>Sets the mode switching judgment value for force sense control (force control). (See section 8.1.2.8.) [Setting range]: - force sensor tolerance value to + force sensor tolerance value [Setting unit]: X, Y, Z component = N A, B, C component = N·m (This setting is not required for axes for which force control is not selected.)</p>	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0
Filter time constant for offset cancel	FSFLOFST	1 real number	<p>Sets the filter time constant used for gravity offset cancel. It is not required to change this value in normal use.</p> <p>[Setting range] : 0 or more [Setting unit] : ms</p>	30.0
Control characteristics	FSFGN01 - 09	8 real numbers	<p>Sets the force sense control gain (response sensitivity) for force sense control. (See section 8.1.2.9.) [Setting range]: 0.0 - 300.0 [Setting range]: X, Y, Z axis component = 10⁻³ mm/N A, B, C axis component = 10⁻³ deg/(N·m)</p>	0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0
	FSFLMT01 - 09	6 real numbers	<p>Sets the force detection setting for interrupt signals and data retention trigger for each coordinate axis. (See section 8.1.2.10.) [Setting range]: 0.0 - force sensor tolerance value [Setting range]: X, Y, Z axis component = N A, B, C axis component = N·m</p>	2000.0, 2000.0, 2000.0, 200.0, 200.0, 200.0

Parameter	Parameter Name	No. of Elements	Description	Factory Default Setting
Log function	FSLOGFN	3 integers	<p>Specifies settings for the force sense log function.</p> <p>1st element: Enables/disabled the log function. [Setting range] 0 (disable), 1 (enable)</p> <p>2nd element: Selects the collected force sensor data type. [Setting range] 0: Raw data (with offset cancel) 1: Raw data (without offset cancel) 2: Data after coordinate conversion (offset cancel designation updated)</p> <p>3rd element: Specifies whether to use/not use FTP. [Setting range] 0 (Do not use), 1 (Use)</p>	0, 2, 0
	FTPID	1 character string	<p>Sets the user ID used with FsOutLog command FTP communication.</p> <p>1st element: user ID [Setting range]: Up to 8 single-byte alphanumeric characters (upper/lower case)</p>	ftpuser
	FTPPASS	1 character string	<p>Sets the password used with FsOutLog command FTP communication.</p> <p>1st element: password [Setting range] Up to 16 single-byte alphanumeric characters (upper/lower case), or single-byte symbols (! # \$ % & = - @ . ? _)</p>	ftppassword
	FTPSVRIP	1 character string	<p>Sets the FTP server IP address used with FsOutLog command FTP communication.</p> <p>1st element: IP address [Setting range] "0.0.0.0" - "255.255.255.255"</p>	192.168.0.99

13.2 RT ToolBox3 Force Sense Function Parameter Setting Screen

(1) Initial settings

This screen is used to set the force sense control function default parameters. It is necessary to reboot the controller after setting parameters.

Fig. 13-1: Force sense control initial setting screen

(2) Force control mode

This screen is used to set the control mode for force sense control. Parameter settings are updated immediately, and therefore there is no need to reboot the controller.

Fig. 13-2: Force control mode screen

(3) Force control characteristics

This is a screen for setting the control features of force sense control. Parameter settings are updated immediately, and therefore there is no need to reboot the controller.





Fig. 13-3: Force control characteristics screen

(4) Force log setting

This screen is used to set parameters for the force sense log function. It is necessary to reboot the controller after writing parameters.



The image shows a software window titled "Force Log 1:RC1 (Online)". It contains two main sections: "Configuration(FSLOGFN)" and "FTP setting".

Configuration(FSLOGFN)

- Log**: A dropdown menu with "Invalid" selected.
- Kind of Sensor Data**: A dropdown menu with "Transformed data" selected.
- FTP**: A dropdown menu with "Not used" selected.

FTP setting

- User Name(FTPID)**: A text input field containing "ftpuser".
- Password(FTPPASS)**: A text input field containing "ftppassword".
- IP Address of FTP Server(FTPSVRIP)**: A text input field containing "192.168.0.99".


At the bottom right, there are two buttons: "Explain" and "Write". The "Write" button is highlighted with a yellow border.

Fig. 13-4: Force log setting screen

13.3 R56TB Force Sense Function Parameter Setting Screen

(1) Initial settings

This screen is used to set the force sense control function default parameters. It is necessary to reboot the controller after setting parameters.



The 'Force initial setting' screen contains the following sections:

- Arrange sensors:** A table for setting robot axes.


Designation	Robot #	Setting axis #
(AXMENO)	(AXJNO)	
1:		7
2:	1	9
3:	2	1
4:	2	2
5:	2	3
6:	3	1
7:	3	2
8:	3	3
- Sensor coordinates:**
 - Coordinate systems(FSHAND):** Radio buttons for Left-Handed and Right-Handed (selected).
 - Place / Angle(FSXTL):** Fields for X, Y, Z (mm) and A, B, C (deg). X=0.00, Y=0.00, Z=0.00, A=180.00, B=0.00, C=0.00.
 - Filter's element(FSFLCTL):** Delay: 1.70 [ms].
- Restriction:**
 - Maximum(FSCORMX):** Position: 10.10 [mm], Angle: 10.10 [deg].
 - Tolerance level(FSLMTMX):** Fields for Fx, Fy, Fz, Mx, My, Mz (N,Nm). Fx=1.01, Fy=2.02, Fz=3.03, Mx=4.04, My=5.05, Mz=6.06.

Buttons: Write, Close. A 'KEY' icon is at the bottom left.

Fig. 13-5: Force sense control Initial setting screen

(2) Force control mode

This screen is used to set the control mode for force sense control. Parameter settings are updated immediately, and therefore there is no need to reboot the controller.



The 'Force control mode' screen contains the following sections:


- Control mode:** A dropdown menu set to 'Control mode1'.
- Coordinate system(FSCOD01):** Radio buttons for Tool coordinate system (selected) and XYZ coordinate system.
- Control mode of axes(FSFMD01):** A list of axes (X, Y, Z, A, B, C, L1, L2) each with a dropdown menu set to 'Position'.
- Coefficients of stiffness(FSSTF01):** Fields for X, Y, Z, A, B, C, L1, L2 (N/mm or Nm/deg). X=0.10, Y=0.10, Z=0.10, A=0.10, B=0.10, C=0.10, L1=0.00, L2=0.00.
- Coefficients of dumping(FSDMP01):** Fields for X, Y, Z, A, B, C, L1, L2 (N/(mm/s) or Nm/(deg/s)). X=0.00, Y=0.00, Z=0.00, A=0.00, B=0.00, C=0.00, L1=0.00, L2=0.00.

Buttons: Write, Close. A 'KEY' icon is at the bottom left.

Fig. 13-6: Force control mode screen

(3) Force control characteristics

This is a screen for setting the control features of force sense control. Parameter settings are updated immediately, and therefore there is no need to reboot the controller.



[Mode switch judgment/Speed reference] button ↓ ↑ [Gain/Instruction/Detection] button





Fig. 13-7: Force control feature screen

(4) Force log setting

This screen is used to set parameters for the force sense log function. It is necessary to reboot the controller after writing parameters.



The screenshot shows a 'Force log setting' window with two main sections: 'Configuration(FSLOGFN)' and 'FTP setting'. The 'Configuration' section has three dropdown menus: 'Log' set to 'Valid', 'Kind of sensor data' set to 'Transformed data', and 'FTP' set to 'Used'. The 'FTP setting' section has three text input fields: 'User name(FTPID)' with 'ftpuser2', 'Password(FTPPASS)' with 'ftppassword2', and 'IP address of FTP server(FTPSVRIP)' with '192.168.0.99'. At the bottom left is a 'KEY' icon, and at the bottom right are 'Write' and 'Close' buttons.

Configuration(FSLOGFN)	
Log	Valid
Kind of sensor data	Transformed data
FTP	Used

FTP setting	
User name(FTPID)	ftpuser2
Password(FTPPASS)	ftppassword2
IP address of FTP server(FTPSVRIP)	192.168.0.99

KEY Write Close

Fig. 13-8: Force log setting screen

13.4 R86TB Force Sense Function Parameter Setting Screen

(1) Initial settings

This screen is used to set the force sense control function default parameters. It is necessary to reboot the controller after setting parameters.

Initial settings

Sensor type : 1F-FS001-W200 Setting

Assign Sensor		Sensor Coordinates		Restriction	
Robot # (AXMENO)	Axis # (AXJNO)	Coordinate Systems (FSHAND)		Max. Offset (FSCORMX)	
1:	1	9	Left	Position :	200.00 [mm]
2:	0	0	Right	Angle :	150.00 [deg]
3:	0	0			
4:	0	0			
5:	0	0			
6:	0	0			
7:	0	0			
8:	0	0			

Place / Angle (FSXTL)

Place / Angle (FSXTL)	Value	Unit
X:	0.00	[mm]
Y:	0.00	[mm]
Z:	32.00	[mm]
A:	0.00	[deg]
B:	180.00	[deg]
C:	0.00	[deg]

Tolerance Level (FSLMTMX)

Force / Moment	Value	Unit
Fx:	200.00	[N]
Fy:	200.00	[N]
Fz:	200.00	[N]
Mx:	4.00	[Nm]
My:	4.00	[Nm]
Mz:	4.00	[Nm]

Filter Time Constant (FSFLCTL)

Sensor Data : 1.70 [ms]

Fig. 13-9: Force sense control Initial setting screen

(2) Force control mode

This screen is used to set the control mode for force sense control. Parameter settings are updated immediately, and therefore there is no need to reboot the controller.

Coordinate System(FSCOD01)

Control Mode1 Tool Coordinate System: XYZ Coordinate System

Control Mode of Axes(FSMD01)		Stiffness Coefficients(FSSTF01)		Damping Coefficients(FSDMP01)	
X:	Position	X:	0.10 [N/mm]	X:	0.00 [N/(mm/s)]
Y:	Position	Y:	0.10 [N/mm]	Y:	0.00 [N/(mm/s)]
Z:	Position	Z:	0.10 [N/mm]	Z:	0.00 [N/(mm/s)]
A:	Position	A:	0.10 [Nm/deg]	A:	0.00 [Nm/(deg/s)]
B:	Position	B:	0.10 [Nm/deg]	B:	0.00 [Nm/(deg/s)]
C:	Position	C:	0.10 [Nm/deg]	C:	0.00 [Nm/(deg/s)]
L1:	Position	L1:	0.00	L1:	0.00
L2:	Position	L2:	0.00	L2:	0.00

Fig. 13-10: Force control mode screen

(3) Force control characteristics

This is a screen for setting the control features of force sense control. Parameter settings are updated immediately, and therefore there is no need to reboot the controller.

The screenshot displays the 'Force control feature screen' with a 'Control Char.1' dropdown menu at the top. Below the menu are five sections of parameter settings, each with a title and a list of parameters with their current values and units.

Force Gain(FSFGN01)		Force Cmd. (FSFCMD01)		Force Detection (FSFLMT01)	
X:	0.00 [1.0°(-3)mm/N]	X:	0.00 [N]	X:	2000.00 [N]
Y:	0.00 [1.0°(-3)mm/N]	Y:	0.00 [N]	Y:	2000.00 [N]
Z:	0.00 [1.0°(-3)mm/N]	Z:	0.00 [N]	Z:	2000.00 [N]
A:	0.00 [1.0°(-3)deg/(Nm)]	A:	0.00 [Nm]	A:	200.00 [Nm]
B:	0.00 [1.0°(-3)deg/(Nm)]	B:	0.00 [Nm]	B:	200.00 [Nm]
C:	0.00 [1.0°(-3)deg/(Nm)]	C:	0.00 [Nm]	C:	200.00 [Nm]
L1:	0.00	L1:	0.00		
L2:	0.00	L2:	0.00		

Mode Switch Judgment(FSSWF01)		Speed Command (FSSPD01)	
X:	0.00 [N]	X:	0.00 [mm/s]
Y:	0.00 [N]	Y:	0.00 [mm/s]
Z:	0.00 [N]	Z:	0.00 [mm/s]
A:	0.00 [Nm]	A:	0.00 [deg/s]
B:	0.00 [Nm]	B:	0.00 [deg/s]
C:	0.00 [Nm]	C:	0.00 [deg/s]
L1:	0.00	L1:	0.00
L2:	0.00	L2:	0.00

Fig. 13-11: Force control feature screen

(4) Force log setting

This screen is used to set parameters for the force sense log function. It is necessary to reboot the controller after writing parameters.

The screenshot displays the 'Force log setting screen' with a 'Configuration(FSLOGFN)' section. It includes three dropdown menus for 'Log', 'Kind of Sensor Data', and 'FTP'. Below these is an 'FTP setting' section with three input fields for 'User Name(FTPID)', 'Password(FTPPASS)', and 'IP Address of FTP Server(FTPSVRIP)'.

Configuration(FSLOGFN)	
Log	Invalid
Kind of Sensor Data	Transformed Data
FTP	Not Used

FTP setting	
User Name(FTPID)	ftpuser
Password(FTPPASS)	ftppassword
IP Address of FTP Server(FTPSVRIP)	192 . 168 . 0 . 99

Fig. 13-12: Force log setting screen

14 Troubleshooting

14.1 Behavior when Force Sense Control Errors Occur

If any of the following types of error occurs, force sense control is disabled and the servo turns OFF.

Table 14-1: Behavior when force sense control error occurs

Type	Error No.	Error Details
Force sense position command	H2760	Offset limit over
	H3988	Force sense position command calculation not possible
	H2770	Outside joint movement range
	H2780	Speed over
Force sense I/F unit	H8920	Force sense interface unit error
Force sensor data	H7660	Sensor tolerance over

14.2 Force Sense Function Related Error List

The following error numbers consist of 4 digits + 5 digits. The first 4 digits appear on the operation panel and teaching pendant. The last 5 digits can be checked at the RT ToolBox3 error details display. (See below.)





Table 14-2: Error List

Error No.	Error Details
L_1864_00000	The FTP communication parameters are incorrect.
L_2750_01000	Unable to disable force sense control while tracking.
H_2760_00000	The force sense control offset value was approaching the limit value. (★)
H_2770_00000	The force sense control offset position is outside the movement range. (★)
H_2780_00000	The force sense control offset position exceeded the speed limit. (★)
L_3110_76000	A value outside the range was set for the force sense control command argument.
L_3110_77000	A value outside the range was set for the force sense control status variable argument.
L_3110_78000	A value outside the range was set for a force sense control related argument.
L_3110_80000	A value outside the range was set for the Mo trigger No.
L_3110_81000	A value outside the range was set for the Def MoTrg command argument.
L3770_00000	An attempt was made to use an undefined Mo trigger.
L_3870_17000	An invalid value was set for the force sense control status variable mechanical No.
L_3870_22000	The mechanical No. specified with the Def MoTrg command is invalid.
L_3986_01000	Unable to enable force sense function. (Force sensor not connected)
L_3986_02000	Unable to enable force sense function. (Compliance control function enabled)
L_3986_04000	Unable to enable compliance control function. (Force sense control function enabled)
L_3986_05000	Unable to enable collision detection function. (Force sense control function enabled)
L_3986_07000	Unable to enable force sense function. (Initialization failure)
L_3986_08000	Unable to move the singular point adjacent area. (Force sense control function enabled)
L_3986_09000	The force sense control enabled/disabled status differs from that when operation is interrupted.
L_3986_10000	This force sense control function cannot be used.
L_3986_11000	Unable to change tool conversion data. (Force sense control function enabled)
L_3986_12000	Unable to change base conversion data. (Force sense control function enabled)
L_3986_13000	Unable to execute Jrc command. (Force sense control function enabled)
L_3986_14000	Unable to perform JOG operation. (Force sense control function enabled)
L_3986_16000	Unable to perform offset cancel. (Force sense control function enabled)
L_3987_01000	The force sense control function is disabled.
L_3987_02000	An attempt was made to enable force sense control while enabled.
L_3987_04000	An attempt was made to execute an FsGChg command during force sense control gain change processing.
L_3987_07000	Failed to output a force sense log file to the FTP server.
L_3987_08000	The specified force sense log file does not exist.
L_3987_10000	Unable to change force sense control status variable settings. (Force sense control function enabled)
L_3987_11000	Unable to create/output another file while creating/outputting a force sense log file.
L_3987_12000	Unable to create force sense log file.
L_3987_14000	Unable to execute Fsc On command while changing the gain.
L_3987_16000	Unable to execute Fsc On command while registering log data.
L_3987_26000	Unable to change force sense control parameter settings. (Force sense control function enabled)
L_3987_27000	Unable to enable Mo trigger. (The FsCTrg command Mo trigger executed first is enabled.)
L_3987_28000	Mo trigger timeout. The Mo trigger did not turn ON within the specified time.
L_3987_29000	Unable to executed FsCTrg command. (Changing control characteristics)
L_3987_30000	Unable to executed FsCTrg command. (The FsCTrg command Mo trigger executed first is enabled.)
L_3987_31000	Unable to specify control characteristics change. A control characteristics change has been set with another command.
L_3987_40000	FsHndEst command is not executed
L_3987_41000	Input data error(F.Ctrl Calib)
L_3987_42000	Calculation error(F.Ctrl Calib)
H_3988_00000	Unable to convert linear position data to joint angle after offsetting with force control. (★)
H_7650_00000	The force sensor quantity setting is incorrect.
H_7651_00000	Unable to initialize force sense interface unit.
H_7652_00000	This is a force sense interface unit for an unsupported revision.
H_7660_02000	The force acting on the sensor exceeded the tolerance value. (★)
H_8920_00000	Force sense interface unit error (★)
C_8921_00000	Force sense interface unit warning

(★) Force sense control is disabled if an error occurs while force sense control is enabled.

14.3 Force Control Function Related Error Details

Table 14-3: Force control function related error details

(The power must be reset for errors with * in the Error No. "First 4 Digits" field.)

Error No.		Error Cause and Remedy	
First 4 Digits	Last 5 Digits		
L1864	00000	Err. message	FTP parameter setting error (**) *) "*" is substituted with the "parameter name".
		Cause	The FTP communication parameter setting lies outside the range.
		Remedy	Check the setting and correct.
L2750	01n00 n=Mech. No.	Err. message	Unable to disable force sense control. (Tracking being performed)
		Cause	Unable to disable force sense control while tracking function being executed.
		Remedy	Try again after disabling the tracking function.
H.2760	00n00 n=Mech. No.	Err. message	The force sense control offset limit was reached.
		Cause	The robot attempted to move beyond the force sense control offset limit.
		Remedy	Check whether there is a problem with robot movement while force sense control is enabled. (The offset limit is the value set in parameter FSCORMX.)
H.2770	xxn00 xx=Axis No. n=Mech. No.	Err. message	Outside offset position movement range (**) *) "*" is substituted with "±Jn" (n is axis No.)
		Cause	The position after force sense control offset lies outside the range. The robot may have been moved near the movement range limit.
		Remedy	Review the movement position or force sense control settings, and ensure that the offset position does not exceed the movement range.
H.2780	0xn00 x=Axis No. n=Mech. No.	Err. message	Offset position speed over (**) *) "*" is substituted with "Jn" (n is axis No.)
		Cause	The speed of movement to the position after offsetting with force sense control exceeded the speed limit. The movement speed may be too fast, or the robot may have been moved at the singular point adjacent.
		Remedy	Review the movement speed and movement position, or the force sense control settings.
L.3110	76n00 n=Mech. No.	Err. message	The force sense control command argument lies outside the range.
		Cause	A value outside the range was set for the force sense control command argument.
		Remedy	Check the argument range and set a correct value.
L.3110	77n00 n=Mech. No.	Err. message	The force sense control status variable argument lies outside the range.
		Cause	A value outside the range was set for the force sense control status variable argument.
		Remedy	Check the argument range and set a correct value.
L.3110	78n00 n=Mech. No.	Err. message	The force sense control related argument lies outside the range.
		Cause	A value outside the range was set for the force sense control related argument.
		Remedy	Check the argument range and set a correct value.
L.3110	80n00 n=Mech. No.	Err. message	The Mo trigger No. lies outside the range.
		Cause	A value outside the range was set for the Mo trigger No.
		Remedy	Check the setting range and set a correct value.
L.3110	81n00 n=Mech. No.	Err. message	Def MoTrg command argument error
		Cause	An unusable variable or different mechanical No. was set.
		Remedy	Set a usable variable or same mechanical No.
L.3770	00n00 n=Mech. No.	Err. message	This is an undefined Mo trigger.
		Cause	An attempt was made to use an undefined Mo trigger.
		Remedy	Define the specified Mo trigger before use.
L.3870	17000	Err. message	The force sense control status variable mechanical No. is an invalid value.
		Cause	An invalid variable was set for the force sense control status variable mechanical No.
		Remedy	Set a correct mechanical No.

Error No.		Error Cause and Remedy	
First 4 Digits	Last 5 Digits		
L.3870	22000	Err. message	The mechanical No. specified with the Def MoTrg command is an invalid value.
		Cause	The mechanical No. specified with the Def MoTrg command is an invalid value.
		Remedy	Set a correct mechanical No.
L.3986	01n00 n=Mech. No.	Err. message	Unable to enable force sense control. (Sensor)
		Cause	Unable to execute because the force sensor is not connected.
		Remedy	Connect the force sensor, or delete the command that cause the error.
L.3986	02n00 n=Mech. No.	Err. message	Unable to enable force sense control. (Cmp command)
		Cause	It is not possible to enable force sense control function while the compliance control function is enabled.
		Remedy	The force sense control function and compliance control function cannot be enabled simultaneously. If using the force sense control function, disable the compliance control function.
L.3986	04n00 n=Mech. No.	Err. message	Unable to execute the Cmp command. (Force sense control)
		Cause	It is not possible to enable the compliance control function while the force sense control function is enabled.
		Remedy	The force sense control function and compliance control function cannot be enabled simultaneously. If using the compliance control function, disable the force sense control function.
L.3986	05n00 n=Mech. No.	Err. message	Unable to enable the collision detection function. (Force sense control)
		Cause	It is not possible to enable the collision detection function while force sense control function is enabled.
		Remedy	The force sense control function and collision detection function cannot be enabled simultaneously. If using the collision detection function, disable the force sense control function.
L.3986	07n00 n=Mech. No.	Err. message	Unable to enable force sense control. (Initialization)
		Cause	It is not possible to perform initialization when starting force sense control.
		Remedy	Check the parameter settings.
L.3986	08n00 n=Mech. No.	Err. message	This is the singular point adjacent area. (Force sense control)
		Cause	It is not possible to move the singular point adjacent area while the force sense control function is enabled.
		Remedy	If moving the singular point adjacent area, disable the force sense control function.
L.3986	09n00 n=Mech. No.	Err. message	The force sense control status is different.
		Cause	The force sense control enabled/disabled status when resuming program operation differs from that during program operation.
		Remedy	Set the force sense control enabled/disabled status to the correct status. (This occurs only once when resuming program operation.)
L.3986	10n00 n=Mech. No.	Err. message	This function cannot be used.
		Cause	This model is not compatible with the executed force sense control function.
		Remedy	Do not use this force sense control function. Contact the maker for details on the latest compatibility status.
L.3986	11n00 n=Mech. No.	Err. message	Unable to change tool conversion data. (Force sense control)
		Cause	It is not possible to change tool conversion data while the force sense control function is enabled.
		Remedy	If changing tool conversion data, disable the force sense control function.
L.3986	12n00 n=Mech. No.	Err. message	Unable to change base conversion data. (Force sense control)
		Cause	It is not possible to change base conversion data while the force sense control function is enabled.
		Remedy	If changing base conversion data, disable the force sense control function.
L.3986	13n00 n=Mech. No.	Err. message	Unable to execute the Jrc command. (Force sense control)
		Cause	It is not possible to execute the Jrc command while the force sense control function is enabled.
		Remedy	To execute the Jrc command, disable the force sense control function.

Error No.		Error Cause and Remedy	
First 4 Digits	Last 5 Digits		
L.3986	14n00 n=Mech. No.	Err. message	Disable force sense control.
		Cause	JOG operation cannot be performed on your model while the force sense control function is enabled.
		Remedy	Disable the force sense control function.
L.3986	16n00 n=Mech. No.	Err. message	Unable to perform offset cancel. (Force sense control)
		Cause	It is not possible to perform offset cancel while the force sense control function is enabled.
		Remedy	If performing offset cancel, disable the force sense control function.
L.3987	01n00 n=Mech. No.	Err. message	Force sense control is disabled.
		Cause	Force sense control is disabled, and so unable to execute the command.
		Remedy	Enable the force sense control function.
L.3987	02n00 n=Mech. No.	Err. message	Force sense control is enabled.
		Cause	It is not possible to enable force sense control again while already enabled.
		Remedy	First disable the force sense control function, and then enable again.
L.3987	04n00 n=Mech. No.	Err. message	Unable to execute the FsGChg command.
		Cause	It is not possible to execute the FsGChg command when force control gain change is not complete.
		Remedy	Review the program so that the FsGChg command is executed after force control gain change is complete.
L.3987	07n00 n=Mech. No.	Err. message	Unable to output log file.
		Cause	FTP processing was not properly performed.
		Remedy	Check the FTP related parameter setting. Check the Ethernet cable connection. Check the FTP server settings at the computer.
L.3987	08n00 n=Mech. No.	Err. message	The specified log file does not exist.
		Cause	The log file for the No. specified with the FsOutLog command does not exist.
		Remedy	Check whether the log file No. is incorrect.
L.3987	10n00 n=Mech. No.	Err. message	Unable to change the force sense status variable.
		Cause	The status variable setting is currently being used by the force sense control function and so cannot be changed.
		Remedy	If changing the setting, disable the force sense control function.
L.3987	11n00 n=Mech. No.	Err. message	Force sense log commands executed simultaneously.
		Cause	It is not possible to create/output another file while creating (FsLog Off command) or outputting (FsOutLog command) a force sense log file.
		Remedy	Process after force sense log file creation/output is complete.
L.3987	12n00 n=Mech. No.	Err. message	Unable to create log file.
		Cause	Unable to create a force sense log file.
		Remedy	Check the amount of available record space in the robot controller.
L.3987	14n00 n=Mech. No.	Err. message	Unable to execute the Fsc ON command.
		Cause	It is not possible to execute the Fsc On command while changing the force control gain.
		Remedy	Execute the Fsc On command after force control gain change is complete.
L.3987	16n00 n=Mech. No.	Err. message	Unable to perform log data related processing.
		Cause	It is not possible to execute FsLog On command file while recording force sense control log data.
		Remedy	Execute the FsLog On command after log data recording is complete.

Error No.		Error Cause and Remedy	
First 4 Digits	Last 5 Digits		
L.3987	26n00 n=Mech. No.	Err. message	Force sense control is enabled.
		Cause	The parameter setting is currently being used by the force sense control function and so cannot be changed.
		Remedy	If changing the parameter, disable the force sense control function once.
L.3987	27n00 n=Mech. No.	Err. message	Unable to enable the Mo trigger.
		Cause	The Mo trigger for the FsCtrg command executed first is enabled.
		Remedy	Execute after changing the control characteristics.
L.3987	28n00 n=Mech. No.	Err. message	Mo trigger timeout
		Cause	The Mo trigger did not turn ON within the specified time.
		Remedy	Review the Mo trigger conditions and robot program.
L.3987	29n00 n=Mech. No.	Err. message	Unable to execute the FsCTrg command.
		Cause	The control characteristics is currently being changed.
		Remedy	Execute after changing the control characteristics.
L.3987	30n00 n=Mech. No.	Err. message	Unable to execute the FsCTrg command.
		Cause	The Mo trigger for the FsCTrg command executed first is enabled.
		Remedy	Execute after changing the control characteristics.
L.3987	31n00 n=Mech. No.	Err. message	Unable to specify the control characteristics change.
		Cause	The control characteristics change has been set with another command.
		Remedy	Change the program so that the command is not executed at the same time as another command.
L.3987	40n00 n=Mech. No.	Err. message	FsHndEst command is not executed
		Cause	Cannot execute without FsHndEst On command
		Remedy	Please execute FsHndEst command and then execute FsGetDat
L.3987	41n00 n=Mech. No.	Err. message	Input data error(F.Ctrl Calib)
		Cause	Input data for the force sensor calibration is illegal
		Remedy	Please confirm data for the force sensor calibration
L.3987	42n00 n=Mech. No.	Err. message	Calculation error(F.Ctrl Calib)
		Cause	Calculation result of the force sensor calibration is illegal
		Remedy	Increase the rotation angle of the calibration operation then get data for the force sensor calibration again.
H.3988	00n00 n=Mech. No.	Err. message	Unable to create a position command.
		Cause	It is not possible to convert linear position data to joint angle after offsetting with force control. The position after offsetting lies outside the movement range or is a singular point.
		Remedy	Review the movement and, settings so that adjacents outside the movement range and singular point adjacents are avoided.
H.7650	00n00 n=Mech. No.	Err. message	The force sensor quantity setting is incorrect.
		Cause	Only 1 force sensor can be used for a single robot.
		Remedy	Check the parameter (AXJNO, AXMENO) settings to see whether multiple force sensors have been set.
H.7651 *	00n00 n=Mech. No.	Err. message	Force sense I/F unit initialization error
		Cause	The force sense I/F unit was not recognized, and therefore it was not possible to successfully complete initialization.
		Remedy	Check the force sense I/F unit wiring and whether the power supply is ON.

Error No.		Error Cause and Remedy	
First 4 Digits	Last 5 Digits		
H.7652 *	00n00 n=Mech. No.	Err. message	Force sense I/F unit revision illegal
		Cause	This force sense I/F unit revision is not supported.
		Remedy	Contact the maker.
H.766x	02n00 n=Mech. No. x=Sensor axis	Err. message	The force sensor data exceeded the tolerance value.
		Cause	The force acting on the force sensor exceeded the set tolerance value.
		Remedy	Check whether too large a force is acting on the force sensor. Check whether an appropriate value has been set for parameter FSLMTMX. * See section 6.6.3 for details on the error recovery method.
H8920	00n00 n=Mech. No.	Err. message	Sensor I/F unit error (**) *) "***" is substituted with the "sensor I/F unit error No." (2 hexadecimal digits)
		Cause	An error occurred at the force sensor interface unit.
		Remedy	See "Table 14-4" based on the error No. in the Err. Message.
C8921	00n00 n=Mech. No.	Err. message	Sensor I/F unit warning (**) *) "***" is substituted with the "sensor I/F unit warning No." (2 hexadecimal digits)
		Cause	A warning occurred at the force sensor interface unit.
		Remedy	See "Table 14-4" based on the warning No. in the Err. Message.

Table 14-4: Force sense interface unit errors


Error No. (Name)	Cause	Remedy	Detected sensor		
			1F-FS001-W200 1F-FS001-W1000	SINTOKOGIO, LTD.	Canon Inc.
12 (memory error)	Force sense interface unit internal part fault	Replace the unit.	•	•	•
13 (S/W processing error)			•	•	•
21 (sensor initial communication error)	(1) The force sensor connection cable is disconnected. (2) The force sensor connection cable is damaged. (3) The connector set has not been prepared correctly (Canon Inc.). (4) Noise contamination occurred. (5) The fuse inside the force sensor interface unit has blown.	(1) Check the cable connection. (2) Replace the cable. (3) Check how to prepare the connector set. (*1) Wiring the connector set incorrectly may damage the sensor's internals. Contact the manufacturer if the problem cannot be resolved. (4) Perform noise countermeasures. (*2) (5) When the LED located on the front of the force sense interface unit is off, the fuse is blown. Replace the F2 or F3 fuse inside the force sensor interface unit (Model: LM03). (*3)	•	•	•
25 (sensor communication error)			•	•	•
28 (sensor error 1)			-	•	-
29 (sensor error 2)			-	•	•
2A (sensor error 3)			-	•	-
34 (communication data error)	(1) The SSCNET III cable is disconnected. (2) The SSCNET III cable end face is dirty. (3) The SSCNET III cable is damaged. (4) Noise contamination occurred.	(1) Power off the interface unit and check the connections. (2) Wipe any dirt from the end face. (3) Replace the cable. (4) Perform noise countermeasures. (*2)	•	•	•
36 (communication error)			•	•	•
37 (initial parameter error)			•	•	•
38 (communication frame error)			•	•	•
39 (communication axis information error)			•	•	•
46 (sensor temperature error)	A force sensor temperature was detected outside the operating temperature range.	Ensure the temperature of the force sensor is within the operating range. Contact the manufacturer if this error occurs repeatedly. Operating range: 0 to 50 [°C]	-	-	•
E5 (sensor alarm)	A problem may have occurred with the sensor.	Continued use is possible but consider the following: • Check the temperature of the environment the unit is being used in. • The sensor may have degraded.	-	-	•

*1: Refer to ["3.7.2.1 Force Sensors Manufactured by Canon Inc."](#) for information on how to prepare the connector set.

*2: The noise suppression method is shown below. Take the measures against a noise by a method suitable for the environment (if necessary). All the measures are not necessarily required.

- a) Install the noise filter to the power supply of the peripheral equipment.
- b) Attach the ferrite core to the 24 VDC output cable.

When adding a ferrite core, ensure that it is placed in a suitable position that will not place an excessive load on the cable or connector.




- c) Earth clamp for the serial cable between unit and sensor

Strip the insulation from the cable near the base of the robot and ground the metal shield via an earth clamp (supplied by the customer) using the earth (ground) terminal.


Do not damage the shielded wire when stripping the insulation.

Consider the movement of the robot then fix the cable in place ensuring that no load is placed on the cable.




*3: The following diagrams indicate where the LEDs and fuses are on the force sensor interface unit.

Force sensor interface unit



Force sensor interface unit internal circuit board



14.4 MELFA Smart Plus Card Related Error Details

Table 14-5: MELFA Smart Plus card related error details

Error No.	Error cause and countermeasure	
L3780	Error message	Cannot use the MELFA Smart Plus.
	Cause	The MELFA Smart Plus card or MELFA Smart Plus card pack is inserted. If the MELFA Smart Plus card is inserted, the value of the parameter SMART+1 is not set correctly.
	Countermeasure	Insert the MELFA Smart Plus card or MELFA Smart Plus card pack. Set the value of the parameter SMART+1 correctly.
L3781	Error message	Cannot use the MELFA Smart Plus.
	Cause	The MELFA Smart Plus card or MELFA Smart Plus card pack is inserted. If the MELFA Smart Plus card is inserted, the value of the parameter SMART+1 is not set correctly.
	Countermeasure	Insert the MELFA Smart Plus card or MELFA Smart Plus card pack. Set the value of the parameter SMART+1 correctly.
L3782	Error message	Multiple MELFA Smart Plus cards are inserted.
	Cause	Multiple MELFA Smart Plus cards are inserted.
	Countermeasure	Turn OFF the controller power, and remove the unnecessary MELFA Smart Plus cards.

14.5 Q & A

	Cause	Measures
The robot vibrates during the force sense control.	Force sense control gain is high.	Decrease the force sense control gain. (section 8.1.2.9)
	The response sensitivity of the sensor is high.	Increase the filter time constant of the force sensor data. (section 6.6.5)
	The minimum control force is small.	Increase the minimum control force of the force sensor. (section 6.6.7)
The robot moves to an unintended direction during the force sense control.	Incorrect setting of a calibration parameter.	Confirm the setting of a calibration parameter. (section 6.6.2)
	The offset cancel operation (sensor zero point offset) of the sensor is not performed.	Perform the offset cancel operation. (section 8.1.3)
	The offset cancel operation is performed before the robot is completely stopped.	Use the Dly command etc., and wait until the robot complete stop and the sensor data become stabilizing, and then perform the offset cancel operation of the sensor. (section 8.1.3)
	The offset cancel operation is performed when the external force is applied to the sensor.	Perform the offset cancel operation without the external force applied to the sensor. (section 8.1.3)
	The force from a cable etc. is applying.	Do not attach in such a way as to prevent movement of moveable parts of the force sensor. Confirm the cable fixation place. (section 5.2)
	Incorrect attachment of the sensor.	Confirm followings. - Contact between the sensor attachment surface and sensor attachment adapter. - Tightening torque of the built-in bolt of sensor. (section 5.2)
The robot moves like a bouncing on contact during the force sense control.	Force sense control gain is high.	Decrease the force sense control gain. (section 8.1.2.9)
	Operating speed on contact is high.	When a contact object is hard, decrease the operating speed at the time of contact. (section 8.1.2.7)

15 Appendix

15.1 Example FTP Server Settings (Microsoft Internet Information Services)


In this section, the FTP server service of the Microsoft web server software (IIS) is used as an example to explain how to configure FTP server settings.

(Refer to the Microsoft home page for details.)

15.1.1 Windows 10


(1) Installing Internet Information Services (IIS)

- a) Select [Start] from the menu then select [Control Panel].
- b) Select [Programs].
- c) Select [Turn Windows features on or off] under [Programs and Features].




- d) In the [Windows Features] window, select the check boxes indicated below under [Internet Information Services] then click the [OK] button.

- [FTP Server] → [FTP Service]
- [Web Management Tools]
- [World Wide Web Services]




e) Internet Information Services (IIS) will be installed.




(2) Disabling the firewall


- a) Select [Start] from the menu then select [Control Panel].
- b) Select [System and Security] → [Administrative Tools].
- c) Select [Windows Defender Firewall with Advanced Security].




- d) Select [Inbound Rules].
- e) Right-click on the items indicated below and select [Enable Rule] from the menu.
- [FTP Server (FTP Traffic-In)]
 - [FTP Server Passive (FTP Passive Traffic-In)]



- f) Select [Administrative Tools] → [Services].




g) Click [Restart the service] while [Microsoft FTP Service] is selected.




(3) Registering FTP server usernames

(FTP usernames do not need to be registered if an existing Windows user is used. However, it is recommended that a separate username is registered as the Windows password will be required to be set for the robot parameter "FTPPASS".)


- Select [Start] from the menu then select [Control Panel].
- Select [System and Security] → [Administrative Tools] from the Control Panel.
- Select [Computer Management].



- d) In the [Computer Management] window go to [System Tools] → [Local Users and Groups] → [Users].
Right-click [Users] then select [New User...].




- e) Enter a username and password in the [New User] window.
[User name]: The username used for FTP communication. Used for robot parameter FTPID.
[Password]: The password used for FTP communication. Used for robot parameter FTPID.
- f) Click the [Create] button to create a new user.




- g) Check the created username has been added.

(4) Creating an FTP service

- a) Select [Start] from the menu then select [Control Panel].
- b) Select [System and Security] → [Administrative Tools] from the Control Panel.
- c) Select [Internet Information Service (IIS) Manager].



- d) Right-click on the [Connections] tree in the [Internet Information Service (IIS) Manager] window and select [Add FTP Site...] to open the [Add FTP Site] wizard.




- e) Enter the settings indicated below on the [Site Information] screen then click the [Next] button.
- [FTP site name]: Enter a site name.
 - [Physical path]: Specify the FTP server home directory.
(This is the path of the folder which stores the files sent over FTP by the robot controller)

The screenshot shows the 'Add FTP Site' dialog box with the 'Site Information' tab selected. The 'FTP site name' field contains 'ftpuser'. The 'Content Directory' section shows the 'Physical path' as 'C:\inetpub\ftproot'. The 'Next' button at the bottom is highlighted with a red box.


- f) Enter the settings indicated below on the [Binding and SSL Settings] screen then click the [Next] button.
- [IP Address]: Select [All Unassigned].
 - [Port]: Enter "21".
 - [Enable Virtual Host Names]: Deselected
 - [Start FTP site automatically]: Selected
 - [SSL]: Select [No SSL].

The screenshot shows the 'Add FTP Site' dialog box with the 'Binding and SSL Settings' tab selected. Under 'Binding', the 'IP Address' dropdown is set to 'All Unassigned' and the 'Port' is '21'. The 'Enable Virtual Host Names' checkbox is unchecked. Under 'Start FTP site automatically', the checkbox is checked. Under 'SSL', the 'No SSL' radio button is selected. The 'Next' button at the bottom is highlighted with a red box.

- g) Enter the settings indicated below on the [Authentication and Authorization Information] screen then click the [Finish] button.
- [Anonymous] under [Authentication]: Deselected
 - [Basic] under [Authentication]: Selected
 - [Allow access to]: Select [Specified users] and enter the FTP server username.
 - [Permissions]: Select both [Read] and [Write].



- h) Check that the specified site name for the FTP site has been added.
i) Right-click the added FTP site then select [Edit Permissions...].




- j) The properties of the specified home directory will appear. Select the [Security] tab.
k) Add and select an FTP username then select [Allow] for [Modify] under [Permissions for].
l) Click the [OK] button to save the settings.
m) Go to the [Internet Information Service (IIS) Manager] window → [Actions] → [Manage Web Site] then select [Restart].


15.1.2 Windows 11

(1) Installing Internet Information Services (IIS)


- a) Select [Start] from the menu then select [Control Panel].
- b) Select [Programs].
- c) Select [Turn Windows features on or off] under [Programs and Features].



- d) In the [Windows Features] window, select the check boxes indicated below under [Internet Information Services] then click the [OK] button.
 - [FTP Server] → [FTP Service]
 - [Web Management Tools]
 - [World Wide Web Services]




- e) Internet Information Services (IIS) will be installed.




(2) Disabling the firewall


- a) Select [Start] from the menu then select [Control Panel].
- b) Select [System and Security] → [Windows Tools].
- c) Select [Windows Defender Firewall with Advanced Security].




- d) Select [Inbound Rules].
- e) Right-click on the items indicated below and select [Enable Rule] from the menu.
 - [FTP Server (FTP Traffic-In)]
 - [FTP Server Passive (FTP Passive Traffic-In)]



f) Select [Windows Tools] → [Services].




g) Click [Restart the service] while [Microsoft FTP Service] is selected.




(3) Registering FTP server usernames

(FTP usernames do not need to be registered if an existing Windows user is used. However, it is recommended that a separate username is registered as the Windows password will be required to be set for the robot parameter "FTPPASS".)

- a) Select [Start] from the menu then select [Control Panel].
- b) Select [System and Security] → [Windows Tools] from the Control Panel.
- c) Select [Computer Management].



- d) In the [Computer Management] window go to [System Tools] → [Local User and Groups] → [Users]. Right-click [Users] then select [New User...].



- e) Enter a username and password in the [New User] window.
 [User name]: The username used for FTP communication. Used for robot parameter FTPID.
 [Password]: The password used for FTP communication. Used for robot parameter FTPID.
- f) Click the [Create] button to create a new user.


The 'New User' dialog box is shown with the following fields and options:

- User name: ftpuser
- Full name: ftpuser
- Description: FTPUserID
- Password: (masked with dots)
- Confirm password: (masked with dots)
- ☐ User must change password at next logon
- ☐ User cannot change password
- ☒ Password never expires
- ☐ Account is disabled
- Buttons: Help, Create (highlighted), Close


- g) Check the created username has been added.

(4) Creating an FTP service


- a) Select [Start] from the menu then select [Control Panel].
- b) Select [System and Security] → [Windows Tools] from the Control Panel.
- c) Select [Internet Information Service (IIS) Manager].



- d) Right-click on the [Connections] tree in the [Internet Information Service (IIS) Manager] window and select [Add FTP Site...] to open the [Add FTP Site] wizard.



- e) Enter the settings indicated below on the [Site Information] screen then click the [Next] button.
- [FTP site name]: Enter a site name.
 - [Physical path]: Specify the FTP server home directory.
(This is the path of the folder which stores the files sent over FTP by the robot controller)




- f) Enter the settings indicated below on the [Binding and SSL Settings] screen then click the [Next] button.
- [IP Address]: Select [All Unassigned].
 - [Port]: Enter "21".
 - [Enable Virtual Host Names]: Deselected
 - [Start FTP site automatically]: Selected
 - [SSL]: Select [No SSL].

The screenshot shows the 'Add FTP Site' dialog box with the 'Binding and SSL Settings' tab selected. The 'Binding' section has 'IP Address' set to 'All Unassigned' and 'Port' set to '21'. The 'Enable Virtual Host Names' checkbox is unchecked. The 'Start FTP site automatically' checkbox is checked. Under the 'SSL' section, 'No SSL' is selected. The 'Next' button at the bottom is highlighted with a red box.

- g) Enter the settings indicated below on the [Authentication and Authorization Information] screen then click the [Finish] button.
- [Anonymous] under [Authentication]: Deselected
 - [Basic] under [Authentication]: Selected
 - [Allow access to]: Select [Specified users] and enter the FTP server username.
 - [Permissions]: Select both [Read] and [Write].

The screenshot shows the 'Add FTP Site' dialog box with the 'Authentication and Authorization Information' tab selected. Under the 'Authentication' section, the 'Basic' checkbox is checked. Under the 'Authorization' section, 'Allow access to:' is set to 'Specified users' and 'ftputer' is entered in the text box. Under the 'Permissions' section, both 'Read' and 'Write' checkboxes are checked. The 'Finish' button at the bottom is highlighted with a red box.

- h) Check that the specified site name for the FTP site has been added.
- i) Right-click the added FTP site then select [Edit Permissions...].



- j) The properties of the specified home directory will appear. Select the [Security] tab.
- k) Add and select an FTP username then select [Allow] for [Modify] under [Permissions for].
- l) Click the [OK] button to save the settings.
- m) Go to the [Internet Information Service (IIS) Manager] window → [Actions] → [Manage Web Site] then select [Restart].

15.1.3 Checking the FTP Server Starts

Check that you can login to the FTP server as an FTP server user.

- From the [Start] menu of the computer being used for the FTP server, go to [All Programs] → [Accessories] → [Command Prompt] to run the command prompt.
- Enter "FTP 127.0.0.1" then press the [Enter] key.
- A username will be requested once the FTP server is running. Enter the FTP server username (parameter FTPID setting value).
- A password will be requested. Enter the FTP server password (parameter "FTPPASS" setting value).
- Check if you can login to the FTP server.

```

Microsoft Windows [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\>FTP 127.0.0.1
Connected to 127.0.0.1.
220 Microsoft FTP Service
User (127.0.0.1:(none)): ftpuser
331 Password required for ftpuser.
Password:
230 User ftpuser logged in.
ftp>

```


If you cannot login, check if the settings from the previous section have been configured correctly or that the parameters FTPID and FTPPASS have been set correctly.

15.2 Control Status Transition

Force sense control has the following 4 statuses.

Status	Description
Force sense status disabled	This is the force sense control disabled status. This is the status when the power is turned ON.
Offsetting	In this status, force sense control is enabled and the robot position is being offset based on the "control mode" and "control characteristics" settings.
Offsetting stopped	Force sense control is enabled; however, robot position offset processing has been stopped with a stop input or due to an error. (This status is possible only when the controller mode is set to "AUTOMATIC".)
Processing stopped	Force sense control is enabled; however, as the servo power is OFF, robot position offset processing is not being performed.

The transition for each status by executing dedicated commands or by turning the servo ON and OFF is as follows.



⚠ Caution

Stop input in the above diagram refers to a stop input from the operation panel, teaching pendant, I/O, or RT ToolBox3.

However, stoppages with the Hlt command and stop inputs by releasing the key during step or JOG operation are not included.

⚠ Caution

If a stop is input and the offset amount becomes fixed while pushing with force sense controller the moment contact is made with the target object, error H.094n (servo amplifier overload) or H.096n (servo amplifier error excessive) may occur. (n is axis No.)

⚠ Caution

If the controller mode is set to "MANUAL", robot movement by force sense control will not stop even if a stop is entered. To stop robot movement by force sense control, release the teaching pendant 3-position enable switch and turn OFF the servo power.

Trademarks

- No part of this manual may be reproduced by any means or in any form, without prior consent from Mitsubishi.
- The details of this manual are subject to change without notice.
- An effort has been made to make full descriptions in this manual. However, if any discrepancies or unclear points are found, please contact your dealer.
- The information contained in this document has been written to be accurate as much as possible. Please interpret that items not described in this document "cannot be performed" or "error may occur". Please contact your nearest dealer if you find any doubtful, wrong or skipped point.
- This specifications is original.

Copyright(C) 2017 MITSUBISHI ELECTRIC CORPORATION

Copyrights

- The screens (screenshots) are used in accordance with the Microsoft Corporation guideline.

mitsubishi electric corporation

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN