

BCN-P5999-1381-E(2506)MEE

GENESIS64



ご使用の前にお読みください

ご使用になる前に、本資料をお読みください。お読みになった後は、いつでも読めるように大切に保管してください。また、本製品のユーザが代わる場合も、必ず最終ユーザまでお届けいただくようお願いいたします。

■同梱品の確認

開梱後、下記製品が入っていることを確認してください。

品名	個数
DVD ^{*1}	ICONICS Suite GENESIS64 (Installation DVD)
	ICONICS Suite GENESIS64 (Additional Tools DVD)
	ICONICS Suite GENESIS64 (Contents DVD)
ご使用の前にお読みください (本資料)	1
Product Registration Information	1
SupportWorX License Information	1 ^{*2}
USB H/W キー	1 ^{*3,4}
Marking based on "Marking Requirements for the Restriction on the Use of Hazardous Substances in Electrical and Electronic Products"	1 ^{*3}

*1 GENESIS Version 11には同梱されません。

*2 SupportWorXを契約されている場合にのみ同梱されます。

*3 三菱電機 GENESIS64 SI/パートナー制度へのご入会/事業所追加の場合にのみ同梱されます。

*4 GENESIS Version 11のライセンス適用は非対応です。

■関連マニュアル

●GENESIS Version 11

本製品をご使用の前に、三菱電機FAサイトの案内に従い、下記のマニュアルを必ずお読みください。

内容	マニュアル名称
インストール	Installation Guide
アップグレード	Upgrade Guide
ライセンス(登録/削除)	Licensing Guide
システム構築	Start-Up Guide

●GENESIS64 Version 10.97以降

本製品をご使用の前に、DVD(Contents DVD)の"ICONICS Product Suiteスタートガイド"フォルダに格納されている下記のマニュアルを必ずお読みください。

内容	マニュアル名称
システム要件 インストール ライセンス(登録/削除)	ICONICS Product Suite Getting Started Guide

■インストール

●GENESIS Version 11

三菱電機FAサイトの案内に従ってダウンロードできるインストーラを実行します。

●GENESIS64 Version 10.97以降

DVD(Installation DVD)のインストーラを実行します。

■アップグレード

GENESIS64 Version 10.97以降からGENESIS Version 11へアップグレードできます。

アップグレード方法はUpgrade Guideを参照してください。

Upgrade Guideで説明されるツールは、三菱電機FAサイトの案内に従ってダウンロードしてください。

■アップデート

本製品をインストールした後に、製品が安定して動作するように設計されたアップデート版を追加インストールすることを推奨します。

三菱電機FAサイトにてアップデート版の有無を確認し、ダウンロードしてください。

■インターネットによる情報サービス「三菱電機FAサイト」

三菱電機FAサイトでは、製品や事例などの技術情報に加え、トレーニングスクール情報や各種お問い合わせ窓口をご提供しています。また、メンバー登録いただくとマニュアルやCADデータ等のダウンロード、eラーニングなどの各種サービスをご利用いただけます。

三菱電機FAサイト

www.MitsubishiElectric.co.jp/fa

日本以外の地域では、お取引先の弊社にご相談ください。

Before Using the Product

Before using the product, please read this manual. Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

■ Packing list

Check that the following items are included in the package of the product.

Item	Quantity
DVD ^{*1}	ICONICS Suite GENESIS64 (Installation DVD)
	ICONICS Suite GENESIS64 (Additional Tools DVD)
	ICONICS Suite GENESIS64 (Contents DVD)
Before Using the Product (this manual)	1
Product Registration Information	1
SupportWorX License Information	1 ^{*2}
USB H/W Key	1 ^{*3} *4
Marking based on "Marking Requirements for the Restriction on the Use of Hazardous Substances in Electrical and Electronic Products"	1 ^{*3}

*1 Not included with GENESIS Version 11.

*2 Included only when contracting for SupportWorX.

*3 Included only when enrolling in Mitsubishi Electric GENESIS64 System Integrator Program or when enrolling additional office in the program.

*4 Applying a license for GENESIS Version11 is not supported.

■ Relevant manual

● GENESIS Version 11

Before using the product, please read the following manual that can be displayed via the Mitsubishi Electric FA website.

Content	Manual name
INSTALLATION	Installation Guide
UPGRADE	Upgrade Guide
LICENSING	Licensing Guide
SYSTEM CONFIGURATIONS	Start-Up Guide

● GENESIS64 Version 10.97 or later

Before using the product, please read the following manual stored on the DVD (Contents DVD).

Content	Manual name
SYSTEM REQUIREMENTS INSTALLATION LICENSING	ICONICS Product Suite Getting Started Guide

■ Installation

● GENESIS Version 11

Execute the installer that can be downloaded via the Mitsubishi Electric FA website.

● GENESIS64 Version 10.97 or later

Execute the installer on the DVD (Installation DVD).

■ Upgrade

GENESIS64 Version 10.97 or later can be upgraded to GENESIS Version 11.

For the upgrade method, refer to Upgrade Guide.

Download the tool explained in Upgrade Guide via the Mitsubishi Electric FA website.

■ Update

After installing this product, it is recommended to install a software update for the stable operation.

For the information on how to obtain the software update, please contact your local Mitsubishi Electric sales office or representative.

■ Information and services

For further information and services, please contact your local Mitsubishi Electric sales office or representative.

Visit our website to find our locations worldwide.

MITSUBISHI ELECTRIC Factory Automation Global Website

Locations Worldwide

www.MitsubishiElectric.com/fa/about-us/overseas/

三菱電機株式会社

〒100-8310 東京都千代田区丸の内2-7-3(東京ビル)

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

GENESIS64-U-SW